

---

# INTAKE AND EXHAUST

## CONTENTS

E15AA--

<b>SPECIFICATIONS</b> .....	<b>2</b>	<b>INTAKE MANIFOLD</b> .....	<b>3-2</b>
General Specifications .....	2	<b>EXHAUST MANIFOLD</b> .....	<b>4</b>
Service Specifications .....	2	<b>EXHAUST PIPE AND MAIN MUFFLER</b> .....	<b>6</b>
<b>SERVICE ADJUSTMENT PROCEDURES</b> .....	<b>2</b>		
Variable Induction Control System Inspection .....	2		
Intake Manifold Vacuum Inspection .....	3-1		

# 15-2 INTAKE AND EXHAUST – Specifications/Service Adjustment Procedures

## SPECIFICATIONS

### GENERAL SPECIFICATIONS



E15CA--

Items	Specifications
Air cleaner Element	Unwoven cloth type
Exhaust system Front exhaust pipe	Dual type
Muffler	Expansion resonance type
Coupling	Flat coupling
Suspension system	Rubber hangers

### SERVICE SPECIFICATIONS

E15CB--

Items	Standard value	Limit
Intake manifold and air intake plenum Distortion of the installation surface mm (in.)	0.15 (0.006) or less	0.2 (0.008)



## SERVICE ADJUSTMENT PROCEDURES

E15FGAAa

### VARIABLE INDUCTION CONTROL SYSTEM INSPECTION <Vehicles built up to November, 1991>

#### SYSTEM INSPECTION


- (1) Warm up the engine.
- (2) Connect the tachometer. (Refer to GROUP 11 - Service Adjustment Procedures.)
- (3) Make sure that when the engine speed is increased from the idle speed to 5,000 r/min., the induction control valve shaft turns.

#### VARIABLE INDUCTION CONTROL SERVO INSPECTION

- (1) Disconnect the variable induction control servo connectors.
- (2) Check the variable induction control servo coil for continuity.

#### Standard value


Measured terminal	Continuity
Between terminals ① and ②	Present [5 – 35 Ω: 20°C (68°F)]




- (3) Make sure that when DC 6V is applied to terminals ① and ② of the variable induction control servo connector, the induction control valve shaft turns smoothly.

**Caution**

**Be sure to apply a voltage of not higher than DC 6V to the variable induction control servo connector terminals since application of high voltage may lock the servo gears.**



- (4) If deviation from the standard value occurs or the variable induction control valve shaft does not turn smoothly replace the air intake plenum assembly.




**<Vehicles built from December, 1991>  
SYSTEM INSPECTION**


- (1) Disconnect the induction control valve position sensor connector.
- (2) Connect the special tool (test harness set) between the disconnected connectors. (All terminals should be connected.)
- (3) Connect a circuit tester between terminal ② and terminal ③ of the induction control valve position sensor and measure the voltage. In addition, measure the voltage between terminal ③ and terminal ④ in the same way.

**Standard value**

Engine condition	Voltage [V]
Idle	0-1 or 4.5-5.5
Engine speed gradually increases to 5,000 r/min.,	1.5-4.0 (momentarily)
5,000 r/min.	0-1 or 4.5-5.5



- (4) If the voltages are outside the standard values, inspect the induction control valve position sensor, variable induction control (VIC) servo and the related harnesses.




**VARIABLE INDUCTION CONTROL SERVO INSPECTION**

- (1) Disconnect the variable induction control servo connectors.
- (2) Disconnect the air intake hose from the throttle body.
- (3) Check the variable induction control servo coil for continuity.

**Standard value**

Measured terminal	Continuity
Between terminals ① and ②	Present [5 – 35 Ω: 20°C (68°F)]




- (4) Make sure that when DC 6V is applied to terminals ① and ② of the variable induction control servo connector, the induction control valve opens and closes smoothly

**Caution**

**Be sure to apply a voltage of not higher than DC 6V to the variable induction control servo connector terminals since application of high voltage may lock the servo gears.**

- (5) If outside the standard value, or if the variable induction valve does not open and close smoothly, replace the air intake plenum assembly.



**INTAKE MANIFOLD VACUUM INSPECTION**

E15FBAB

Refer to GROUP 11- Service Adjustment Procedures.

# INTAKE MANIFOLD



## REMOVAL AND INSTALLATION <SOHC>

### Pre-removal Operation

- Releasing of Residual Fuel Pressure (Refer to GROUP 13 – Service Adjustment Procedures.)
- Draining of Coolant (Refer to GROUP 14 – Service Adjustment Procedures.)
- Removal of Intake Manifold Plenum

### Post-installation Operation


- Installation of Intake Manifold Plenum
- Supplying of Coolant (Refer to GROUP 14 – Service Adjustment Procedures.)
- Adjustment of Accelerator Cable (Refer to GROUP 13 – Service Adjustment Procedures.)




05N0016

### Removal steps

- ◆◆ 1. Connection for high-pressure fuel hose
- ◆◆ 2. O-ring
- ◆◆ 3. Connection for fuel return hose
- ◆◆ 4. Connection for vacuum hoses
- ◆◆ 5. Wiring harness connector
- ◆◆ 6. Delivery pipe, injector and pressure regulator assembly
- ◆◆ 7. Insulators
- ◆◆ 8. Connection for radiator upper hose
- ◆◆ 9. Connection for heater hose
- ◆◆ 10. Connection for water hose
- ◆◆ 11. Water outlet fitting
- ◆◆ 12. Water outlet fitting gasket
- ◆◆ 13. Thermostat
- ◆◆ 14. Engine coolant temperature sensor
- ◆◆ 15. Engine coolant temperature gauge unit
- ◆◆ 16. Intake manifold
- ◆◆ 17. Intake manifold gasket



**SERVICE POINTS OF REMOVAL**

E15MBAS 1

**6. REMOVAL OF DELIVERY PIPE, FUEL INJECTOR AND PRESSURE REGULATOR**

Remove the delivery pipe with fuel injectors and pressure regulators on.

**Caution**

**Do not drop the injectors when removing the delivery pipe.**

**SERVICE POINTS OF INSTALLATION****2. INSTALLATION OF O-RING/1. HIGH PRESSURE FUEL HOSE**

- (1) Apply a little amount of new engine oil to the O-ring.

**Caution**

**Be sure to prevent the engine oil from entering into the delivery pipe.**

- (2) Insert the hose, being careful not to damage the O-ring, and tighten securely.

**NOTE**

Be sure to tighten securely to prevent fuel leaks so that there will be high pressure between the fuel pump and the delivery pipe.


REMOVAL AND INSTALLATION <DOHC>

**Pre-removal Operation**

- Releasing of Residual Fuel Pressure (Refer to GROUP 13 – Service Adjustment Procedures.)
- Draining of Coolant (Refer to GROUP 14 – Service Adjustment Procedures.)
- Removal of Intake Manifold Plenum

**Post-installation Operation**

- Installation of Intake Manifold Plenum
- Supplying of Coolant (Refer to GROUP 14 – Service Adjustment Procedures.)
- Adjustment of Accelerator Cable (Refer to GROUP 13 – Service Adjustment Procedures.)






05N0015

**Removal steps**

- ◆◆ 1. Connection for high-pressure fuel hose
- ◆◆ 2. O-ring
- ◆◆ 3. Connection for fuel return hose
- ◆◆ 4. Connection for vacuum hoses
- ◆◆ 5. Wiring harness connector
- ◆◆ 6. Delivery pipe, injector and pressure regulator assembly
- ◆◆ 7. Insulators
- ◆◆ 8. Timing belt upper cover
- ◆◆ 9. Water pump stay mounting bolt
- ◆◆ 10. Intake manifold mounting nut\*1
- ◆◆ 11. Intake manifold mounting nut\*2
- ◆◆ 12. Cone disc spring\*2
- ◆◆ 13. Intake manifold
- ◆◆ 14. Intake manifold gasket

NOTE  
 \*1 <Vehicles built up to October, 1992>  
 \*2 <Vehicles built from November, 1992>





## SERVICE POINTS OF REMOVAL

E15MBAS2

### 6. REMOVAL OF DELIVERY PIPE, FUEL INJECTOR AND PRESSURE REGULATOR

Remove the delivery pipe with fuel injectors and pressure regulators on.

#### Caution

**Do not drop the injectors when removing the delivery pipe.**

## SERVICE POINTS OF INSTALLATION

### 11. INSTALLATION OF INTAKE MANIFOLD MOUNTING NUT <Vehicles built from November, 1992>

Tighten the intake manifold mounting nuts one bank after the other by the following procedure.

#### <Vehicles built from November, 1992 up to November, 1993>

- (1) Tighten the nuts in the front bank to 3–5 Nm (0.3–0.5 kgm, 2.2–3.6 ft.lbs.).
- (2) Tighten the nuts in the rear bank to 12–15 Nm (1.2–1.5 kgm, 9–11 ft.lbs.).
- (3) Tighten the nuts in the front bank to 12–15 Nm (1.2–1.5 kgm, 9–11 ft.lbs.).
- (4) Repeat steps (2) and (3) one more time respectively.

#### <Vehicles built from December, 1993>

- (1) Tighten the nuts in the front bank to 5–8 Nm (0.5–0.8 kgm, 4–6 ft.lbs.)
- (2) Tighten the nuts in the rear bank to 20–23 Nm (2.0–2.3 kgm, 14–17 ft.lbs.).
- (3) Tighten the nuts in the front bank to 20–23 Nm (2.0–2.3 kgm, 14–17 ft.lbs.).
- (4) Repeat steps (2) and (3) one more time respectively.

### 2. INSTALLATION OF O-RING/1. HIGH PRESSURE FUEL HOSE

- (1) Apply a little amount of new engine oil to the O-ring.

#### Caution

**Be sure to prevent the engine oil from entering into the delivery pipe.**

- (2) Insert the hose, being careful not to damage the O-ring, and tighten securely.

#### NOTE

Be sure to tighten securely to prevent fuel leaks so that there will be high pressure between the fuel pump and the delivery pipe.



**NOTES**



## EXHAUST MANIFOLD

## REMOVAL AND INSTALLATION &lt;SOHC&gt;

E15NA--

**Pre-removal and Post-installation Operation**

- Removal and Installation of Front Exhaust Pipe (Refer to P.15-6.)

**Removal steps****Front bank side**

1. Heat protector
2. Exhaust manifold
3. Oil level gauge guide
4. Gasket

**Rear bank side**

5. Roll stopper stay
6. Heat protector
7. Air intake plenum stay
8. Air intake plenum stay bracket
9. EGR pipe
10. EGR valve } <Vehicles built from November, 1992>
11. Gasket
12. Exhaust manifold
13. Gasket

**INSPECTION****EXHAUST MANIFOLD**



Check for damage or cracking of any part.

E15NCAD1

REMOVAL AND INSTALLATION <DOHC>

E15NA-A

**Pre-removal and Post-installation Operation**  
 ● Removal and Installation of Front Exhaust Pipe (Refer to P.15-6.)



**Removal steps**

**Front bank side**

1. Condenser fan assembly (Vehicles with air conditioner)
2. Drive belt (Refer to GROUP 11 – Service Adjustment Procedures)
3. Alternator bracket (Refer to GROUP 16 – Engine Electrical)
4. Alternator (Refer to GROUP 16 – Engine Electrical)
5. Compressor (Vehicles with air conditioner)
6. Oil level gauge guide
7. Heat protector
8. Exhaust manifold
9. Gasket

**Rear bank side**

10. Stud
11. Roll stopper stay
12. Heat protector
13. EGR pipe
14. EGR valve
15. Gasket
16. Spacer <Vehicles with TCL>
17. Gasket <Vehicles with TCL>
18. Exhaust manifold
19. Gasket

<Vehicles built from November, 1992>

**SERVICE POINTS OF REMOVAL**

E15NBAE

**5. REMOVAL OF COMPRESSOR**

Remove the air conditioning compressor from the bracket with the hoses still attached.

**NOTE**

Move the compressor to a place where it will not be an obstruction.

**INSPECTION**

E15NCAQ2

**EXHAUST MANIFOLD**

Check for damage or cracking of any part.


**NOTES**

## EXHAUST PIPE AND MAIN MUFFLER


E15RA--

## REMOVAL AND INSTALLATION

&lt;Vehicles built up to October, 1992&gt;



&lt;Vehicles built from November, 1992&gt;



05N0025

## Removal steps

1. Hanger
2. Main muffler
3. Gasket
4. Muffler cutter
5. Hanger bracket
6. Rear floor heat protector
7. Rear floor heat protector front
8. Self-locking nut
9. Hanger
10. Center exhaust pipe
11. Dynamic damper
12. Hanger bracket
13. Gasket
14. Catalytic converter
15. Gasket
16. Oxygen sensor
17. Self-locking nut
18. Hanger
19. Front exhaust pipe
20. Gasket
21. Front floor heat protector

## INSPECTION

E15RCAH

- Check the mufflers and pipes for corrosion or damage.
- Check the rubber hangers for deterioration or damage.
- Check for gas leakage from mufflers and pipes.