

Engine & CoolingFuelIgnitionElectricalRunning gearTorque settingsCapacitiesNotes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENUHELP

Engine and cooling system

Mentor 1.5i1996 to 1997

Type		SOHC 8V
Capacity (cm ³) / number of cylinders		1498 / 4
Compression ratio / pressure	bar	9.4 / ≥9.5
Oil pressure	bar	[3.5 to 4.0]
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	82
Radiator cap pressure	bar	0.76 to 1.04

Fuel system

Mentor 1.5i1996 to 1997

Idle speed - manual [auto]	rpm	700 to 800 WSM
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.5
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO2 @ idle speed [3000 rpm] - see page VI	%	—
O2 @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		—
Type / ref		MPI
Main jet / needle		—
Injection pressure	bar	2.6 to 3.2
Pump pressure	bar	—
Octane rating	RON	95[U]

Ignition system

Mentor 1.5i1996 to 1997

Type		Electronic
Ignition coil		—
Primary resistance	ohms	0.81 to 0.99
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		—
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		—
Ignition timing - basic [static	° Crankshaft @ rpm	7±1 BTDC @ 700 to 800 WSM
V = Vacuum NV = No Vacuum		—
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		NGK
Type		BPR5ES
Electrode gap	mm	0.70 to 0.80

Electrical system

Mentor 1.5i1996 to 1997

Battery	V / CC / RC	12 / 48Ah
Alternator voltage / full load current / engine rpm		14.1 to 14.7 / 70 / —
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear

Mentor 1.5i1996 to 1997

Brakes -		
Front (min. friction material thickness)	mm	2.0
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	175/70x13
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	2.0 / 2.0
- Estate / Van	bar	—

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	-2.6±3.0
Camber		0°±30’
Castor		2°±45’
King pin inclination		11°58’

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	-0.5±3.0
Camber		—

Torque wrench settings

Mentor 1.5i1996 to 1997


Cylinder head - stage 1	Nm	40 oiled
- stage 2	Nm	78 to 81
Cylinder head - stage 3	Nm	—
- stage 4	Nm	—
Big-end bearings	Nm	29 to 34
Main bearings	Nm	54 to 59
Clutch cover	Nm	18 to 26
Flywheel [driveplate]	Nm	96 to 103
Front hubs	Nm	209 to 279
Rear hubs	Nm	209 to 279
Wheel nuts / bolts	Nm	89 to 117
Spark plugs	Nm	15 to 23

Capacities

Mentor 1.5i1996 to 1997

Engine oil & filter	litres	3.3
Gearbox - 4-speed [5-speed]	litres	2.7
Automatic transmission - refill	litres	5.7
Final drive	litres	WT
Cooling system	litres	5.0
Fuel tank	litres	48

Notes and Illustrations



1498 cm³