


Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive
Technical
DATA
BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU	HELP
------	------

Engine and cooling system323, 1.3i CAT1991 to 1995

Type		B3. SOHC 16V 55kW
Capacity (cm³) / number of cylinders		1324 / 4
Compression ratio / pressure	bar	9.4 / ≥9.5
Oil pressure	bar	[3.0 to 4.0]
Oil temperature	°C	—
Valve clearance - inlet	mm	0.30 H
Valve clearance - exhaust	mm	0.30 H
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	86.5 to 89.5
Radiator cap pressure	bar	0.76 to 1.04

Fuel system323, 1.3i CAT1991 to 1995

Idle speed - manual [auto]	rpm	850±50
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.3
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO2 @ idle speed [3000 rpm] - see page VI	%	—
O2 @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		Mazda
Type / ref		EGI EFI
Main jet / needle		—
Injection pressure	bar	2.6 to 3.2
Pump pressure	bar	4.4 to 5.9
Octane rating	RON	91[U]

Ignition system323, 1.3i CAT1991 to 1995

Type		Electronic
Ignition coil		—
Primary resistance	ohms	0.81 to 0.99
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		Hitachi
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		Anticlockwise
Ignition timing - basic [static	° Crankshaft @ rpm	10±1 BTDC @ 850±50
V = Vacuum NV = No Vacuum		NV
Total ignition advance	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		NGK
Type		BKR5E-11
Electrode gap	mm	1.00 to 1.10

Electrical system323, 1.3i CAT1991 to 1995

Battery	V / CC / RC	12 / 60Ah
Alternator voltage / full load current / engine rpm		14.1 to 14.7 / 65 / 2500
Starter motor current / voltage - cranking	A / V	—
- locked	A / V	—

Running gear323, 1.3i CAT1991 to 1995

Brakes -		
Front (min. friction material thickness)	mm	2.0
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	155x13: 175/70x13
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	1.9 / 1.8
- Estate / Van	bar	—

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	+2.0±3.0
Camber		-5'±45'
Castor		+2°5'±45'
King pin inclination		+12°25'

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	+2.0±3.0
Camber		-20'±45'



Torque wrench settings323, 1.3i CAT1991 to 1995

Cylinder head - stage 1	Nm	40
- stage 2	Nm	76 to 81
Cylinder head - stage 3	Nm	—
- stage 4	Nm	—
Big-end bearings	Nm	29 to 34
Main bearings	Nm	54 to 59
Clutch cover	Nm	18 to 26
Flywheel [driveplate]	Nm	96 to 103
Front hubs	Nm	235 to 319
Rear hubs	Nm	177 to 235
Wheel nuts / bolts	Nm	118
Spark plugs	Nm	15 to 23


Capacities323, 1.3i CAT1991 to 1995

Engine oil & filter	litres	3.2
Gearbox - 4-speed [5-speed]	litres	2.7
Automatic transmission - refill	litres	—
Final drive	litres	WT
Cooling system	litres	5.0
Fuel tank	litres	50

Notes and Illustrations



1324 cm³, 16V



1324 cm³, 16V, fwd