

Engine & Cooling

Fuel

Ignition

Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system626, 2.01987 to 1990

Type		FE. SOHC 12V
Capacity (cm³) / number of cylinders		1998 / 4
Compression ratio / pressure	bar	9.5 / ≥10.0
Oil pressure	bar	[3.0 to 3.9]
Oil temperature	°C	—
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	80 to 83
Radiator cap pressure	bar	1.04

Fuel system626, 2.01987 to 1990

Idle speed - manual [auto]	rpm	800±50 [900±50]
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	≤0.3
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO2 @ idle speed [3000 rpm] - see page VI	%	—
O2 @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		—
Type / ref		30-34 2V downdraught
Main jet / needle		114, 155 [AT: 112, 155]
Injection pressure	bar	—
Pump pressure	bar	0.19 to 0.30
Octane rating	RON	95[E 95 RON]

Ignition system626, 2.01987 to 1990

Type		Electronic
Ignition coil		—
Primary resistance	ohms	1.03 to 1.27
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		—
Points gap (air gap)	mm	—
Dwell angle	° (%)	—
Condenser capacity	µF	—
Rotation		Anticlockwise
Ignition timing - basic [static	° Crankshaft @ rpm	6±1 BTDC @ idle
V = Vacuum NV = No Vacuum		NV
Total ignition advance	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	0±2 @ 1200
	° Crankshaft @ rpm	12±2 @ 2400
	° Crankshaft @ rpm	18±2 @ 5000
Vacuum range check	mbar	160 to 400
Maximum vacuum advance	° Crankshaft	11 to 15
Spark plugs		NGK/Champion
Type		BCPR6E / RN9YC
Electrode gap	mm	0.75 to 0.85

Electrical system626, 2.01987 to 1990

Battery	V / CC / RC	12 / 210 / 65
Alternator voltage / full load current / engine rpm		14.1 to 14.7 / _ / 2000
Starter motor current / voltage - cranking	A / V	90 / 11.5 (no load)
- locked	A / V	—

Running gear626, 2.01987 to 1990

Brakes -		
Front (min. friction material thickness)	mm	2.0
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	185/70x14: 195/60x15
Estate / Van	Size	185/70x14: 195/60x15
Pressure - front / rear - Saloon	bar	1.9 / 1.8
- Estate / Van	bar	1.9 / 1.9

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	+3.0±3.0 ¹
Camber		+17'±45'
Castor		+1°13'±45'
King pin inclination		+12°47'

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (–)	mm [°]	0±3.0
Camber		-30'±45'

Torque wrench settings626, 2.01987 to 1990

Cylinder head - stage 1	Nm	80 to 86
- stage 2	Nm	—
Cylinder head - stage 3	Nm	—
- stage 4	Nm	—
Big-end bearings	Nm	65 to 69
Main bearings	Nm	83 to 88
Clutch cover	Nm	22 to 32
Flywheel [driveplate]	Nm	96 to 103
Front hubs	Nm	235 to 319
Rear hubs	Nm	98 to 117
Wheel nuts / bolts	Nm	108
Spark plugs	Nm	15 to 23


Capacities626, 2.01987 to 1990

Engine oil & filter	litres	4.3
Gearbox - 4-speed [5-speed]	litres	3.4
Automatic transmission - refill	litres	6.8
Final drive	litres	WT
Cooling system	litres	7.5
Fuel tank	litres	60


Notes and Illustrations

¹Estate: 0±3.0


1: Idle speed 2: CO / Mixture



1998 cm³, 12V



1998 cm³, 12V



30-34 carburettor