

VAUXHALL/OPEL

Astra-F 1.8i 16V

1996 to 1997

Engine & Cooling

Fuel

Ignition


Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system

Astra-F 1.8i 16V

1996 to 1997

Type		X18XE 16V 85kW 94/12/EC
Capacity (cm ³) / number of cylinders		1798 / 4
Compression ratio / pressure	bar	10.8 / _
Oil pressure	bar	2.0
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
Valve clearance - exhaust	mm	0: Hyd.
Firing order		1-3-4-2
No 1 cylinder position		TBE
Thermostat opening temperature	°C	92
Radiator cap pressure	bar	1.2 to 1.5

Fuel system

Astra-F 1.8i 16V

1996 to 1997

Idle speed - manual [auto]	rpm	700 to 1000
Fast idle speed - manual [auto]	rpm	_
CO @ idle speed [3000 rpm] - see page VI	%	1.5±0.5 WSM
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO2 @ idle speed [3000 rpm] - see page VI	%	_
O2 @ idle speed [3000 rpm] - see page VI	%	_
Carburettor / fuel injection		_GM
Type / ref		Simtec 56.5
Main jet / needle		_
Injection pressure	bar	_
Pump pressure	bar	_
Octane rating	RON	95[U]

Ignition system

Astra-F 1.8i 16V

1996 to 1997

Type		DIS
Ignition coil		_
Primary resistance	ohms	_
Ballast resistor	ohms	_
Voltage - Tmnl 15(+) to earth	V	_
Distributor		_
Points gap (air gap)	mm	_
Dwell angle	° (%)	_
Condenser capacity	µF	_
Rotation		_
Ignition timing - basic [static	° Crankshaft @ rpm	Computer control N/A
V = Vacuum NV = No Vacuum		
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	_
Spark plugs		Bosch
Type		FR8LDC
Electrode gap	mm	0.7 to 0.8

Electrical system

Astra-F 1.8i 16V

1996 to 1997

Battery	V / CC / RC	_
Alternator voltage / full load current / engine rpm		_
Starter motor current / voltage - cranking	A / V	_
- locked	A / V	_

Running gear

Astra-F 1.8i 16V

1996 to 1997

Brakes -		
Front (min. friction material thickness)	mm	_
Rear (min. friction material thickness)	mm	_

Tyres		
Saloon	Size	175/65x14: 195/55x15
Estate / Van	Size	175/65x14: 195/55x15
Pressure - front / rear - Saloon	bar	Refer to vehicle
- Estate / Van	bar	Refer to vehicle

Front suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	-1.5±1.0
Camber		-1°5'±45'
Castor		2°15'±1°
King pin inclination		_

Rear suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	1.0±2.0
Camber		-1°40'±30'

Torque wrench settings

Astra-F 1.8i 16V

1996 to 1997

Cylinder head - stage 1	Nm	25 N
- stage 2	Nm	+90°
Cylinder head - stage 3	Nm	+90°
- stage 4	Nm	+90°
Big-end bearings	Nm	35 +45° +15° N
Main bearings	Nm	50 +45° +15° N
Clutch cover	Nm	15
Flywheel [driveplate]	Nm	65 +30° +15° [50] N
Front hubs	Nm	WSM
Rear hubs	Nm	WSM
Wheel nuts / bolts	Nm	110
Spark plugs	Nm	25

Capacities

Astra-F 1.8i 16V

1996 to 1997

Engine oil & filter	litres	4.0
Gearbox - 4-speed [5-speed]	litres	1.9
Automatic transmission - refill	litres	_
Final drive	litres	WT
Cooling system	litres	6.9
Fuel tank	litres	52

Notes and Illustrations

1798 cm³, 16V