



Self-diagnosis LED indicator blinks twice.

Disconnect the 26P connector from the control unit.

Turn the ignition switch ON.

Measure the voltage between the A4 (GRN/BLK) and A25 (BLK/RED) terminals.

Is there voltage?

YES

NO

Turn the ignition switch OFF.

Measure the resistance between the A4 (GRN/BLK) and A25 (BLK/RED) terminals.

Is the resistance 12–24 Ω ?

NO

YES

Disconnect the 2P connector from the lock-up control solenoid valve assembly.

Check for continuity between the A4 (GRN/BLK) and A25 (BLK/RED) terminals.

Is there continuity?

YES

NO




Connect the 2P connector to the lock-up control solenoid valve assembly.

Check for loose control unit connectors. If necessary, substitute a known-good control unit and recheck.

Repair short to power source in GRN/BLK wire between the A4 terminal and the lock-up control solenoid valve B.

Check for open in GRN/BLK wire between the A4 terminal and the lock-up control solenoid valve B. If wire is OK, check the Lock-Up Control Solenoid Valve B.


Repair short to ground in GRN/BLK wire between the A4 terminal and the lock-up control solenoid valve B.



(cont'd)

Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)





Self-diagnosis LED indicator blinks four times.

Jack up the front of the car and block one wheel.

Shift transmission to **N**.

Disconnect the 26P and 22P connectors from the control unit.

Turn the ignition switch ON.

Rotate the front wheel and check for voltage between the A25 (BLK/RED) and D9 (ORN) terminals.

Does the voltage 0–5 V appear alternately?


NO

YES

Check for loose control unit connectors. If necessary, substitute a known-good control unit and recheck.

⚠ WARNING

- Set the parking brake securely and block the rear wheels.
- Jack up the front of the car and support with a rigid rack.






Check for short or open in ORN wire between the D9 terminal and the Speed Sensor. If wire is OK, check the Speed Sensor.

(cont'd)

Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)





From page 9-34

Shift to other than **D4** position.

Measure the voltage between the A17 (GRN/BLK) and A25 (BLK/RED) terminals.

Is there battery voltage?

NO

YES

Shift to other than **D3** position.

Measure the voltage between the A15 (GRN/BLU) and A25 (BLK/RED) terminals.

Is there battery voltage?

NO

YES

Shift to other than **2** position.

Measure the voltage between the A13 (GRN/YEL) and A25 (BLK/RED) terminals.

Is there battery voltage?

NO

YES

Shift to other than **1** position.

Measure the voltage between the A11 (LT GRN/WHT) and A25 (BLK/RED) terminals.

Is there battery voltage?

NO

YES





Substitute a known-good control unit and recheck.

Check for short in GRN/BLK wire between the A17 terminal and the shift position console switch. If wire is OK, check for loose control unit connectors. If necessary, substitute a known-good control unit and recheck.

Check for short in GRN/BLU wire between the A15 terminal and the shift position console switch. If wire is OK, check for loose control unit connectors. If necessary, substitute a known-good control unit and recheck.

Check for short in GRN/YEL wire between the A13 terminal and the shift position console switch. If wire is OK, check for loose control unit connectors. If necessary, substitute a known-good control unit and recheck.




Check for short in LT GRN/WHT wire between the A11 terminal and shift position console switch or shift position indicator. If wire is OK, check for loose control unit connectors. If necessary, substitute a known-good control unit and recheck.



(cont'd)

Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)





From page 9-36

Shift to **D4** position.

Measure the voltage between the A17 (GRN/BLK) and A25 (BLK/RED) terminals.

Is there voltage?

YES

NO

Repair open in GRN/BLK wire between the A17 terminal and the shift position console switch.

Shift to **D3** position.

Measure the voltage between the A15 (GRN/BLU) and A25 (BLK/RED) terminals.

Is there voltage?

YES

NO

Repair open in GRN/BLU wire between the A15 terminal and the shift position console switch.

Shift to **2** position.

Measure the voltage between the A13 (GRN/YEL) and A25 (BLK/RED) terminals.

Is there voltage?

YES

NO

Repair open in GRN/YEL wire between the A13 terminal and the shift position console switch.

Shift to **1** position.

Measure the voltage between the A11 (LT GRN/WHT) and A25 (BLK/RED) terminals.





Is there voltage?

YES

NO

Repair open in LT GRN/WHT wire between the A11 terminal and the shift position console switch.





Check for loose control unit connectors. If necessary, substitute a known-good control unit and recheck.



(cont'd)

Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)





Self-diagnosis LED indicator blinks eight times.

Disconnect the 26P connector from the control unit.

Turn the ignition switch ON.

Measure the voltage between the A3 (GRN/WHT) and A25 (BLK/RED) terminals.

Is there voltage?

YES

Repair short to power source in GRN/WHT wire between the A3 terminal and shift control solenoid valve B.

NO

Turn the ignition switch OFF.

Measure the resistance between the A3 (GRN/WHT) and A25 (BLK/RED) terminals.

Is the resistance 12–24 Ω ?

NO

Check for open in GRN/WHT wire between the A3 terminal and the shift control solenoid valve B. If wire is OK, check the Shift Control Solenoid Valve B.

YES

Disconnect the 2P connector from the shift control solenoid valve assembly.

Check for continuity between the A3 (GRN/WHT) and A25 (BLK/RED) terminals.

Is there continuity?




YES

Repair short to ground in GRN/WHT wire between the A3 terminal and the shift control solenoid valve B.

NO

Connect the 2P connector to the shift control solenoid valve assembly.


Check for loose control unit connectors. If necessary, substitute a known-good control unit and recheck.



(cont'd)


Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)






From page 9-40





(cont'd)

Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)







(cont'd)

Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)





(cont'd)

Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)

Self-diagnosis LED indicator blinks fourteen times.

Start the engine and warm it up to normal operating temperature.


Shift to **P** position.

Turn the ignition switch OFF.

Connect the ECU test harness between the control unit and connectors.

Turn the ignition switch ON and wait for at least two seconds.

Using an analog voltmeter, measure the voltage between the D16 (+) and A25 (-) terminals.



Is there approx. 5 V for over five seconds?

YES

Jack up the front of the car.

Start the engine.

Shift to **D₄** position.

Raise the engine to over 2,000 min⁻¹ (rpm) (over 40 mph in 4th gear) for five seconds.

To page 9-47

NO

Does the meter jerk from 0 V to 4 V approx. every four seconds?

YES

Refer to PGM-FI A/T Signal (Section 6).

NO

Is the Check Engine warning light on?

YES


Repair the PGM-FI System (Section 6).

NO

Turn the ignition switch OFF.

Disconnect the A connector from the PGM-FI ECU.

To page 9-47



(cont'd)

Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)

From page 9-47

Apply the brake and shift to **P** position.

Turn the ignition switch OFF.

Disconnect the A connector from the PGM-FI ECU.

Check for continuity on the BRN/WHT wire between the D16 terminal on the A/T control unit and the A18 terminal on the PGM-FI ECU.

Is there continuity?

NO


Repair open in BRN/WHT wire.

YES

To page 9-49




From page 9-48



(cont'd)

Electrical Troubleshooting


Troubleshooting Flowchart (cont'd)





From page 9-50

From page 9-50





(cont'd)

Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)

From page 9-51







(cont'd)


Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)




Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)






From page 9-56



(cont'd)


Electrical Troubleshooting

Troubleshooting Flowchart (cont'd)





From page 9-58



Lock-up Control Solenoid Valve A/B

Test


NOTE: Lock-up control solenoid valves A and B must be removed/replaced as an assembly.

1. Disconnect the connector from the lock-up control solenoid valve A/B.

NOTE: Do not remove the lock-up control solenoid valve A/B stay.

2. Measure the resistance between the No.1 terminal (SOL. V A) of the lock-up control solenoid valve connector and body ground and between the No. 2 terminal (SOL. V B) and body ground.

STANDARD: 14–16 Ω (25°C)




3. Replace the lock-up control solenoid valve assembly if the resistance is out of specification.
4. Connect the No.1 terminal of the lock-up control solenoid valve connector to the battery positive terminal. Connect the No.2 terminal to the battery positive terminal.
A clicking sound should be heard each time the connection is made.
5. If not, check for continuity between the A/T control unit A24 or A25 harness and body ground. (page 9-30, 31).
6. Replace the lock-up control solenoid valve assembly if there is continuity between the A/T control unit A 24 or A 25 harness and body ground. (page 9-30, 31)

Replacement

1. Remove the mounting bolts and lock-up control solenoid valve assembly.

NOTE: Be sure to remove or replace the lock-up control solenoid valves A and B as an assembly.

2. Check the lock-up control solenoid valve oil passages for dust or dirt and replace as an assembly, if necessary.



3. Clean the mounting surface and oil passages of the lock-up control solenoid valve assembly and install a new base gasket.
4. Check the connector for rust, dirt or oil and reconnect it securely.