



Lift and Support Points

Lift

⚠ WARNING When heavy rear components such as suspension, fuel tank, spare tyre and tailgate are to be removed, place additional weight in the luggage area before hoisting. When substantial weight is removed from the rear of the car, the center of gravity may change and can cause the car to tip forward on the hoist.

NOTE: Since each tyre/wheel assembly weighs approximately 14 kg (30 lbs), placing the front wheels in the trunk can assist with weight distribution.

1. Place the lift blocks as shown.
2. Raise the hoist until the tyres are slightly off the ground and rock the car to be sure it is firmly supported.
3. Raise the hoist to full height and inspect lift points for solid support.

