

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	A44	Air Mix Control Servo Motor (Driver Side)	90980-11165
A 2	A/C Magnetic Clutch and Lock Sensor	90980-11016	A45	Air Mix Control Servo Motor (Front Passenger Side)	
A 3	A/C Pressure Sensor	90980-10845	A46	Air Vent Mode Control Servo Motor (Driver Side)	
A 7	ABS Speed Sensor Front RH	90980-11291	A47	Air Vent Mode Control Servo Motor (Front Passenger Side)	
	Pad Wear Indicator SW Front RH				
A 8	ABS Speed Sensor Front LH	90980-11247	A48	A/C Amplifier	90980-10848
A 9	Air Flow Meter	90980-11317	A49	Air Purifier Light	-
A10	Airbag Sensor Front LH	90980-11856	A50	Audio and Rear A/C Control SW	90980-10799
A11	Airbag Sensor Front RH		B 1	Brake Fluid Level Warning SW	90980-11207
A12	Alternator	90980-09363	B 2	Blower Motor	90980-11667
A13	Alternator	90980-11964	B 3	Brake Pedal Load Sensing SW	90980-10860
A14	A/C Control Assembly	90980-11421	B 4	Buckle SW Front LH	90980-11194
A15	A/C Control Assembly	90980-11476	B 5	Buckle SW Front RH	
A16	A/C Control Assembly	90980-11586	B 6	Buckle SW Rear LH	90980-10795
A17	A/C Room Temp. Sensor (LHD)	90980-10825	B 7	Buckle SW Rear RH	
	A/C Room Temp. Sensor (RHD)	90980-11918	C 1	Camshaft Position Sensor	90980-10947
A18	A/C Room Temp. SW (Driver's Side)	90980-11923	C 2	Camshaft Timing Oil Control Valve LH	90980-11162
A19	A/C Room Temp. SW (Front Passenger's Side)	90980-11909	C 3	Camshaft Timing Oil Control Valve RH	
A21	Absorber Control SW	90980-11950	C 4	Crankshaft Position Sensor	
A22	Accel Position Sensor	90980-11144	C 6	Center Cluster Integration Panel	90980-11923
A23	Air Suspension ECU	82824-48130	C 7	Cigarette Lighter (Front) (LHD)	90980-11399
A24	Air Suspension ECU	82824-48140		Cigarette Lighter (Front) (RHD)	90980-10858
A25	Air Suspension ECU	90980-12151	C 8	Cigarette Lighter (Rear)	90980-10858
A26	Airbag Sensor Assembly	90980-12392	C 9	Clearance Sonar Buzzer (Front)	90980-10825
A27	Airbag Sensor Assembly	90980-12391	C10	Clock	90980-12113
A28	Airbag Sensor Assembly	90980-12390	C11	Coin Box Illumination	90980-11918
A29	Airbag Squib (Front Passenger Airbag Assembly)	90980-12160	C12	Combination Meter	90980-11915
A30	Airbag Squib (Steering Wheel Pad)		C13	Combination SW	90980-12183
A31	A/C Solar Sensor (Front)	90980-12056	C14	Combination SW	90980-11911
	Automatic Light Control Sensor		C15	Console Box Illumination	90980-10886
A32	A/C Solar Sensor (Rear)	90980-10825	C16	Clearance Sonar Buzzer (Rear)	90980-10825
A33	ABS Speed Sensor Rear RH	90980-10794	C17	Clearance Sonar ECU	90980-11877
	Pad Wear Indicator SW Rear RH		C18	Curtain Shield Airbag Squib LH	90980-11884
A34	ABS Speed Sensor Rear LH	90980-10859	C19	Curtain Shield Airbag Squib RH	
A35	Acceleration Sensor	90980-10845	C20	Climate Control Seat ECU (Driver's Seat)	82824-50190
A36	Ashtray Illumination Rear LH	90980-12111	C21	Climate Control Seat ECU (Front Passenger's Seat)	
A37	Ashtray Illumination Rear RH		C22	Cooling Fan ECU	90980-12058
A38	A/C Control Assembly	90980-11637	C23	Cooling Fan ECU	90980-10837
A39	A/C Control Assembly	90980-11638	C24	Cooling Fan ECU	90980-10841
A40	AFS ECU	90980-12259	C25	Compressor Assembly	90980-11156
A41	AFS ECU	90980-12153	C26	Cool Air Bypass Servo Motor (Driver Side)	90980-11909
A42	AFS Off SW	90980-11090	C27	Cool Air Bypass Servo Motor (Front Passenger Side)	
A43	Air Inlet Control Servo Motor	90980-11909			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
C28	Cool Box Illumination	90980-11918	F 1	Front Clearance Light LH	90980-11156
C29	Climate Control Seat ECU (Rear LH Seat)	90980-12166	F 2	Front Clearance Light RH	
C30	Climate Control Seat ECU (Rear LH Seat)	90980-11973	F 3	Front Fog Light LH	90980-11096
C31	Climate Control Seat ECU (Rear RH Seat)	90980-12166	F 4	Front Fog Light RH	
C32	Climate Control Seat ECU (Rear RH Seat)	90980-11973	F 5	Front Height Control Valve	90980-11143
C33	Climate Control Seat SW (Rear)	90980-11911	F 6	Front Side Turn Signal Light LH	90980-11162
D 1	DLC3	90980-11665	F 7	Front Side Turn Signal Light RH	
D 2	Driver Side J/B ECU	90980-11973	F 8	Front Turn Signal Light LH	90980-11019
D 3	Driver Side J/B ECU	90980-11923	F 9	Front Turn Signal Light RH	
D 4	Driver Side J/B ECU		F10	Front Wiper Motor	90980-11290
D 5	Driver Side J/B ECU	90980-11915	F11	Fuel Pump Resistor	90980-11003
D 6	Duct Sensor (Driver's Side)	90980-10825	F12	Fuel Lid Opener SW	90980-10825
D 7	Duct Sensor (Front Passenger's Side)		F13	Fuel Lid Opener SW Illumination	90980-11013
D 8	Door Courtesy Light Front LH	90980-11148	F14	Front Door Speaker LH	90980-10935
D 9	Door Courtesy Light Front RH		F15	Front Door Speaker RH	
D10	Door Courtesy Light Rear LH		F16	Front Passenger Door ECU	90980-12151
D11	Door Courtesy Light Rear RH		F17	Front Passenger Door ECU	90980-12150
D12	Door Courtesy SW Front LH	90980-10871	F18	Fuel Lid Opener Motor	90980-11019
D13	Door Courtesy SW Front RH		F19	Fuel Pump	90980-11077
D14	Door Courtesy SW Rear LH			Fuel Sender (Main)	
D15	Door Courtesy SW Rear RH		F20	Fuel Sender (Sub)	90980-12168
D16	Door Lock Control Receiver	90980-11950	F21	Front Door Outside Handle LH	90980-11181
D17	Door Lock Control SW Front LH		F22	Front Door Outside Handle RH	
D18	Door Lock Control SW Front RH		F23	Front Door with Motor Lock Assembly LH	90980-12149
D19	Door Lock SW (Luggage)	90980-11141	F24	Front Door with Motor Lock Assembly RH	
D20	Door Oscillator Front LH	90980-11923	G 1	Gateway ECU	90980-12404
D21	Door Oscillator Front RH		G 2	Glove Box Light	90980-11918
D22	Door Oscillator Rear LH		H 3	Headlight Cleaner Control Relay	90980-10939
D23	Door Oscillator Rear RH		H 4	Headlight Cleaner Motor	90980-11410
D24	Driver Door ECU	90980-12151	H 5	Headlight Control ECU LH	90980-11003
D25	Driver Door ECU	90980-12150	H 6	Headlight Control ECU RH	
D26	Driving Position Memory SW	90980-11989	H 7	Headlight LH (High)	90980-11095
D27	Driver Seat ECU	90980-10807	H 8	Headlight RH (High)	
D28	Driver Seat ECU	90980-12094	H 9	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-10869
D29	Distance Control ECU	90980-12203	H10	Heated Oxygen Sensor (Bank 2 Sensor 1)	
E 1	ECT Solenoid	90980-12293	H11	Height Control Compressor	90980-10990
E 2	EFI Water Temp. Sensor	90980-10736	H12	Height Control Exhaust Valve	90980-11156
E 3	Engine and ECT ECU	90980-12146	H13	Height Control Sensor Front LH	90980-11929
E 4	Engine and ECT ECU	90980-12142	H14	Height Control Sensor Front RH	
E 5	Engine and ECT ECU	90980-12143	H15	Horn (High)	90980-10619
E 6	Engine and ECT ECU	90980-12144	H16	Horn (Low)	
E 7	Engine and ECT ECU	90980-12145	H17	Hazard SW	90980-10801
E 8	Engine Hood Courtesy SW	90980-11189	H19	Heated Oxygen Sensor (Bank 1 Sensor 2) (LHD)	90980-10858
E 9	Engine Oil Level Sensor	90980-11235		Heated Oxygen Sensor (Bank 1 Sensor 2) (RHD)	90980-11399
E10	Exhaust Gas Sensor	90980-11034			
E11	ECT Pattern Select SW	90980-11986			

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
H20	Heated Oxygen Sensor (Bank 2 Sensor 2) (LHD)	90980-11399	J 9	Junction Connector	90980-11398
	Heated Oxygen Sensor (Bank 2 Sensor 2) (RHD)	90980-10858	J10	Junction Connector	
H21	Height Control SW	90980-11909	J11	Junction Connector	90980-11915
H22	Height Control Sensor Rear	90980-11860	J12	Junction Connector	
H23	High Mounted Stop Light	90980-10825	J13	Junction Connector	
H24	Head Rest Limit SW Rear LH		J14	Junction Connector	
H25	Head Rest Limit SW Rear RH		J15	Junction Connector	
H26	Headlight Beam Level Control Actuator LH	90980-11028	J16	Junction Connector	
H27	Headlight Beam Level Control Actuator RH		J17	Junction Connector	
H28	Headlight LH	90980-10931	J18	Junction Connector	90980-11398
H29	Headlight RH		J19	Junction Connector	90980-11686
H30	Height Control Sensor Rear LH	90980-11860	J22	Junction Connector	90980-11686
H31	Height Control Sensor Rear RH		J23	Junction Connector	90980-11915
I 1	Ignition Coil and Igniter No.1	90980-11885	J24	Junction Connector	90980-11686
I 2	Ignition Coil and Igniter No.2		J25	Junction Connector	90980-11915
I 3	Ignition Coil and Igniter No.3		J26	Junction Connector	90980-10976
I 4	Ignition Coil and Igniter No.4		J27	Junction Connector	
I 5	Ignition Coil and Igniter No.5		J28	Junction Connector	90980-11661
I 6	Ignition Coil and Igniter No.6		J29	Junction Connector	
I 7	Ignition Coil and Igniter No.7		J30	Junction Connector	90980-11686
I 8	Ignition Coil and Igniter No.8		J31	Junction Connector	90980-11915
I 9	Injector No.1	90980-11153	J32	Junction Connector	90980-11398
I10	Injector No.2		J34	Junction Connector	90980-12355
I11	Injector No.3		J35	Junction Connector	
I12	Injector No.4		J36	Junction Connector	90980-10871
I13	Injector No.5		J37	Junction Connector	
I14	Injector No.6		J38	Junction Connector	
I15	Injector No.7		J39	Junction Connector	
I16	Injector No.8		J40	Junction Connector	
I17	Ignition SW	90980-11778	J41	Junction Connector	
I18	Instrument Panel Register	90980-12135	J42	Junction Connector	
I19	Door Lock Control Receiver	90980-11989	J43	Junction Connector	90980-10871
	Inner Mirror		J44	Junction Connector	
I20	Inside Handle Illumination Front LH	90980-12063	J45	Junction Connector	90980-12355
I21	Inside Handle Illumination Front RH		J46	Junction Connector	
I22	Inside Handle Illumination Rear LH		J47	Junction Connector	90980-11915
I23	Inside Handle Illumination Rear RH		J49	Junction Connector	
I24	Interior Light Rear LH	90980-11471	J50	Junction Connector	90980-12355
I25	Interior Light Rear RH		J51	Junction Connector	
J 1	Junction Connector	90980-11661	J52	Junction Connector	90980-10871
J 2	Junction Connector		J53	Junction Connector	
J 3	Junction Connector		J54	Junction Connector	90980-11915
J 4	Junction Connector		J55	Junction Connector	
J 7	Junction Connector	90980-11542	J56	Junction Connector	90980-11398
J 8	Junction Connector	90980-11537	J57	Junction Connector	90980-12355
			K 1	Keyless Buzzer	90980-11156

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
K 2	Knock Sensor (Bank 1)	90980-11875	P 5	Passenger Side J/B ECU	90980-11923
K 3	Knock Sensor (Bank 2)		P 6	Power Outlet	90980-11155
K 4	Keyless Buzzer On/Off SW	90980-10860	P 7	Power Tilt and Power Telescopic ECU	90980-10799
K 5	Kick Down SW	90980-11156	P 8	Power Tilt and Power Telescopic ECU	90980-10848
K 6	Knee Airbag Squib LH	90980-12452	P 9	Power Window Control SW Front LH	90980-12113
K 7	Knee Airbag Squib RH		P10	Power Window Control SW Front RH	
L 1	Luggage Compartment Door Opener SW	90980-10860	P11	Power Window Control SW Rear LH	
L 2	License Plate Light LH	90980-11148	P12	Power Window Control SW Rear RH	
L 3	License Plate Light RH		P13	Power Window Master SW	90980-12166
L 4	Luggage Compartment Door Closer Motor	90980-11011	P14	Power Window Motor Front LH	90980-10797
L 5	Luggage Electrical Key SW	90980-10825	P15	Power Window Motor Front RH	
L 6	Luggage Compartment Door Key Unlock SW		P16	Power Window Motor Rear LH	90980-11011
L 7	Luggage Compartment Light No.1	90980-11148	P17	Power Window Motor Rear RH	
L 8	Luggage Compartment Light No.2		P18	Pretensioner Front LH	90980-12253
L 9	Luggage Oscillator (Inner)	90980-11909	P19	Pretensioner Front RH	
L10	Luggage Oscillator (Outer)		P20	Pretensioner Rear LH	90980-11862
L11	Luggage Room J/B ECU	90980-11911	P21	Pretensioner Rear RH	
L12	Luggage Room J/B ECU	90980-11923	P22	Power Seat Control SW (Driver's Seat Cushion)	90980-10601
L13	Luggage Room J/B ECU	90980-11915	P23	Power Seat Control SW (Driver's Seat Lumbar Support)	90980-10964
L14	Laser Sensor	90980-12292	P24	Power Seat Control SW (Front Passenger's Seat Lumbar Support)	90980-10601
M 1	Multi-Display	90980-12410	P25	Power Seat Control SW (Front Passenger's Seat)	90980-10807
M 2	Multi-Display	90980-12203	P26	Power Seat Control SW Sub (Front Passenger's Seat)	90980-10801
M 4	Moon Roof Control ECU and Motor	90980-10997	P27	Power Seat Motor (Driver's Seat Cushion Control)	90980-10825
M 5	Millimeter Wave Radar Sensor	90980-12292	P28	Power Seat Motor (Driver's Seat Front Vertical Control)	
M 6	Multi-Display	90980-12012	P29	Power Seat Motor (Driver's Seat Lifter Control)	
N 1	A/T Indicator Light SW	90980-11784	P30	Power Seat Motor (Driver's Seat Lumbar Support Lower Side Control)	
	Back-Up Light SW		P31	Power Seat Motor (Driver's Seat Lumbar Support Upper Side Control)	
	Neutral Start SW		P32	Power Seat Motor (Driver's Seat Reclining Control)	
N 2	Noise Filter (Ignition Left Bank)	90980-10843	P33	Power Seat Motor (Driver's Seat Slide Control)	
N 3	Noise Filter (Ignition Right Bank)		P34	Power Seat Motor (Front Passenger's Seat Front Vertical Control)	
N 4	Noise Filter (Rear Window Defogger)	90980-11184	P35	Power Seat Motor (Front Passenger's Seat Head Rest Control)	90980-11085
N 5	Navigation ECU	90980-11973	P36	Power Seat Motor (Front Passenger's Seat Lifter Control)	90980-10825
N 6	Navigation ECU	90980-11923	P37	Power Seat Motor (Front Passenger's Seat Lumbar Support Control)	
N 7	Noise Filter (Rear Window Defogger)	90980-10916	P38	Power Seat Motor (Front Passenger's Seat Reclining Control)	
N 8	Navigation ECU	90980-12221			
N 9	Navigation ECU	90980-12012			
O 2	Oil Pressure SW	90980-11363			
O 3	Outer Mirror SW	90980-11657			
O 4	Outer Mirror SW	90980-11989			
O 5	Outer Mirror SW (LHD)	90980-11950			
	Outer Mirror SW (RHD)	90980-11090			
O 6	Overhead J/B	90980-12153			
P 1	PPS Solenoid	90980-11162			
P 2	Parking Brake SW	90980-10871			
P 3	Passenger Side J/B ECU	90980-11973			
P 4	Passenger Side J/B ECU	90980-11915			

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
P39	Power Seat Motor (Front Passenger's Seat Slide Control)	90980-10825	R25	Rear Window Defogger	90980-10914
P40	Power Seat Motor and Position Sensor (Driver's Seat Head Rest Control)	90980-11085	R26	Room Oscillator (Rear)	90980-11920
P41	Power Seat Position Sensor (Driver's Seat Cushion Control)	90980-10908	R27	Rear LH Seat ECU	90980-11877
P42	Power Seat Position Sensor (Driver's Seat Front Vertical Control)		R28	Rear RH Seat ECU	
P43	Power Seat Position Sensor (Driver's Seat Lifter Control)		R30	Rear Door Outside Handle LH	90980-11181
P44	Power Seat Position Sensor (Driver's Seat Reclining Control)		R31	Rear Door Outside Handle RH	
P45	Power Seat Position Sensor (Driver's Seat Slide Control)		R32	Rear Blower Motor	90980-10908
P46	Power Seat Motor (Rear Passenger's LH Seat Slide Control)	90980-10825	R33	Rear Blower Resistor	90980-10216
P47	Power Seat Motor (Rear Passenger's RH Seat Slide Control)		R34	Rear Damper Servo Motor	90980-11989
P48	Power Seat Motor and Position Sensor (Rear Passenger's LH Seat Head Rest Top and Bottom Control)	90980-10789	R35	Rear Door with Motor Lock Assembly LH	90980-12149
P49	Power Seat Motor and Position Sensor (Rear Passenger's RH Seat Head Rest Top and Bottom Control)		R36	Rear Door with Motor Lock Assembly RH	
P50	Power Seat Position Sensor (Rear Passenger's LH Seat Slide Control)	90980-10908	R37	Rear Magnetic Valve	90980-10860
P51	Power Seat Position Sensor (Rear Passenger's RH Seat Slide Control)		R38	Remote Control Mirror LH	90980-12156
P52	PPS ECU	90980-10797	R39	Remote Control Mirror RH	
P53	Pressure SW	90980-10906	R40	Rear Armrest Courtesy SW	90980-10859
P54	Power Seat Control SW (Rear Seat)	90980-11909	R41	Rear Sunshade SW (Rear)	90980-11471
R 4	Radio and Player	90980-12038	R42	Radio and Player	90980-12221
R 5	Radio and Player	90980-12183	S 1	Short Connector	90980-11920
R 6	Rheostat	90980-11989	S 2	Short Connector	90980-11909
R 7	Room Oscillator (Front)	90980-11909	S 3	Speed Sensor	90980-11156
R 8	Rain Sensor	90980-11987	S 4	Starter	90980-09585
R10	Rear Combination Light LH	90980-11399	S 5	Starter	90980-11400
R11	Rear Combination Light LH		S 6	Suspension Control Actuator Front LH	90980-10789
R12	Rear Combination Light RH		S 7	Suspension Control Actuator Front RH	
R13	Rear Combination Light RH		S 8	Shift Lock Control ECU	90980-12183
R14	Rear Door LH ECU	90980-12151	S 9	Short Connector (Height Control)	90980-12002
R15	Rear Door LH ECU	90980-12150	S10	Short Connector (Height Control)	90980-12003
R16	Rear Door RH ECU		S15	Smart Key System Cancel SW	90980-10825
R17	Rear Door RH ECU	90980-12151	S16	Speed Warning Buzzer	90980-11148
R18	Rear Door Speaker LH	90980-10935	S17	Steering Lock ECU	90980-11913
R19	Rear Door Speaker RH		S18	Steering Sensor	90980-12162
R20	Rear Height Control Valve	90980-11860	S19	Step Light Front LH	90980-12063
R21	Rear Seat Memory SW LH	90980-11989	S20	Step Light Front RH	
R22	Rear Seat Memory SW RH		S21	Stop Light SW	90980-10795
R23	Rear Sunshade Control Relay	90980-10789	S22	Shoulder Belt Adjust SW Front LH	90980-11987
R24	Rear Window Defogger	90980-11259	S23	Shoulder Belt Adjust SW Front RH	
			S24	Shoulder Belt Anchor Motor and Position Sensor LH	90980-12056
			S25	Shoulder Belt Anchor Motor and Position Sensor RH	
			S26	Shoulder Belt Anchor Motor LH	82824-50130
			S27	Shoulder Belt Anchor Motor RH	
			S28	Side Airbag Sensor Front LH	90980-12225
			S29	Side Airbag Sensor Front RH	
			S30	Side Airbag Sensor Rear LH	90980-12241
			S31	Side Airbag Sensor Rear RH	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
S32	Stereo Component Amplifier	90980-10801	T 7	Climate Control Seat SW Front LH	90980-11915
S33	Stereo Component Amplifier	90980-12200		Climate Control Seat SW Front RH	
S34	Stereo Component Amplifier	90980-10821		Headlight Cleaner SW	
S35	Stereo Component Tuner	90980-11877		Rear Seat Reset SW	
S36	Suspension Control Actuator Rear LH	90980-10789		Rear Sunshade SW (Front)	
S37	Suspension Control Actuator Rear RH			Seat Heater SW Front LH	
S38	Seat Climate Controller Front LH (Seat Back)	90980-11920		Seat Heater SW Front RH	
S39	Seat Climate Controller Front RH (Seat Back)			Traction Control SW	
S40	Seat Heater Front LH	90980-10907	T 8	Ignition Key Cylinder Light	90980-12092
S41	Seat Heater Front RH		Transponder Key Amplifier		
S42	Side Airbag Squib LH	90980-11864	T 9	Transponder Key Computer	90980-11911
S43	Side Airbag Squib RH		T10	Trip SW	90980-11490
S44	Seat Heater Rear LH	90980-10795	T11	Tweeter Front LH	90980-10860
S45	Seat Heater Rear RH		T12	Tweeter Front RH	
S48	Skid Control ECU with Actuator	90980-12297	T16	Theft Deterrent Siren	90980-11034
S49	Short Connector	90980-12377	T17	Tweeter Rear LH	90980-10795
S50	Short Connector	90980-12378	T18	Tweeter Rear RH	
S51	Smoke Sensor	90980-10908	T19	Throttle Control Motor	90980-11858
S52	Seat Climate Controller Front LH (Seat Cushion)	90980-12012		Throttle Position Sensor	
S53	Seat Climate Controller Front RH (Seat Cushion)		T20	Turbine Speed Sensor	90980-11156
S54	Step Light Rear LH	90980-11918	T21	Transmission Control SW	90980-12221
S55	Step Light Rear RH		T22	Television Camera	90980-12211
S56	Seat Climate Controller Rear LH (Seat Back)	90980-11920	T23	Television Camera ECU	90980-10997
S57	Seat Climate Controller Rear LH (Seat Cushion)		T24	Television Camera ECU	90980-12169
S58	Seat Climate Controller Rear RH (Seat Back)		U 1	Ultrasonic Sensor (Front Left Center)	90980-11246
S59	Seat Climate Controller Rear RH (Seat Cushion)		U 2	Ultrasonic Sensor (Front Left Side)	
S60	Seat Climate Fan Motor Rear LH (Seat Back)		U 3	Ultrasonic Sensor (Front Left)	
S61	Seat Climate Fan Motor Rear LH (Seat Cushion)		U 4	Ultrasonic Sensor (Front Right Center)	
S62	Seat Climate Fan Motor Rear RH (Seat Back)	U 5	Ultrasonic Sensor (Front Right Side)		
S63	Seat Climate Fan Motor Rear RH (Seat Cushion)	U 6	Ultrasonic Sensor (Front Right)		
S64	Seat Heater SW (Rear)	90980-12003	U 7	Unlock Warning SW (w/ Smart Key System)	90980-11909
S65	Seat Belt Control ECU	90980-11973		Unlock Warning SW (w/o Smart Key System)	90980-10795
S66	Seat Belt Motor LH	90980-10860	U 8	Ultrasonic Sensor (Rear Left Center)	90980-11246
S67	Seat Belt Motor RH		U 9	Ultrasonic Sensor (Rear Left)	
T 1	Theft Deterrent Horn	90980-10619	U10	Ultrasonic Sensor (Rear Right Center)	
T 4	Telescopic Motor and Position Sensor	90980-10799	U11	Ultrasonic Sensor (Rear Right)	
T 5	Theft Deterrent ECU	90980-12169	V 1	Variable Motor	90980-11194
T 6	Tilt Motor and Position Sensor	90980-10799	V 2	Variable Resistor	90980-10902
			V 3	VSV (ACIS)	90980-11156
			V 4	VSV (EVAP)	
			V 5	VVT Sensor LH	90980-10947
			V 6	VVT Sensor RH	
			V 7	VSC Warning Buzzer	90980-10906
			V 8	Vanity Light Front LH	90980-11369
			V 9	Vanity Light Front RH	

G PART NUMBER OF CONNECTORS

[illegible]

Note: Not all of the above part numbers of the connector are established for the supply.

