

PROBLEM SYMPTOMS TABLE

If a normal system code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

Symptom	Suspected Area	See page
Damping force control does not operate at all	1. Absorber control actuator circuit 2. TS terminal 3. Pneumatic cylinder/shock absorber 4. Suspension control ECU	05-276 05-512 26-12 27-10 25-20
Lighting up position of height control indicator light does not change according to operation of height control switch	1. Height control switch circuit 2. Suspension control ECU	05-328 25-20
Vehicle height control function does not operate	1. Height control sensor circuit 2. Height control solenoid valve circuit 3. Height control switch circuit 4. Height control exhaust valve circuit 5. AIR SUS relay circuit 6. Suspension control ECU	05-257 05-286 05-328 05-283 05-294 25-20
Hunting of vehicle height occurs	1. Air leakage 2. Height control sensor circuit 3. Suspension control ECU	25-4 05-257 25-20
Vehicle height control operates, but vehicle height is uneven	1. Height control sensor circuit 2. Height control sensor link 3. Suspension control ECU	05-257 25-4 25-20
Vehicle height control operates, but vehicle height is high or low. (Vehicle height in NORMAL mode varies from the standard value)	1. Height control sensor link 2. Height control sensor circuit 3. Suspension control ECU	25-4 05-257 25-20
When vehicle height control is adjusted, it stops at extremely high or extremely low position	Height control sensor circuit	05-257
Height control indicator abnormal	1. Height control indicator circuit 2. Combination meter assy 3. Suspension control ECU	05-334 05-2135 25-20
Absorber control indicator light abnormal	1. Absorber control indicator circuit 2. Combination meter assy 3. Suspension control ECU	05-337 05-2135 25-20
DTC check cannot be done	Only when 1, 2 and 3 are all normal and the problem is still occurring, replace the suspension control ECU. 1. Absorber control indicator circuit 2. CAN communication system 3. TC terminal circuit	05-337 05-3294 05-508
Input signal check (Test mode) cannot be done	1. CAN communication system 2. TS terminal circuit 3. Suspension control ECU	05-3294 05-512 25-20

Vehicle height is extremely low when vehicle is parked	1. Air leakage	25-4
	2. Pneumatic cylinder/shock absorber	26-12
	3. Height control sensor link	27-10
	4. Height control exhaust valve circuit	25-4
Compressor motor continues to operate		05-283
	1. Air leakage	25-4
	2. AIR SUS relay circuit	05-294
	3. Height control compressor circuit	05-299
	4. Height control sensor link	25-4
	5. Pneumatic cylinder/shock absorber	26-12
	6. Suspension control ECU	27-10
		25-20