

NO SOUND CAN BE HEARD FROM THE SPEAKERS (AUDIO IS MUTE)

2 CHECK AUDIO SETTINGS

OK

END

NG

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
([SEE PAGE 05-1660](#))**