



POWER SOURCE CIRCUIT (RADIO RECEIVER ASSY)

CIRCUIT DESCRIPTION

This circuit provides the power to the radio receiver assy.

WIRING DIAGRAM



INSPECTION PROCEDURE**1 INSPECT RADIO RECEIVER ASSY(+B, ACC, GND)**

- (a) Disconnect the radio receiver assy connector R4.
(b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
GND - Body ground	Always	Below 1 Ω

- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
+B - GND	Always	10 to 14 V
ACC - GND	Ignition SW ACC	10 to 14 V

NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK**

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE OR DIAGNOSTIC TROUBLE CODE CHART (SEE PAGE 05-1660 OR 05-1673)