





INSPECTION PROCEDURE

1 INSPECT TELEVISION CAMERA ECU(+B, ACC, IG, GND1)



- (a) Disconnect the television camera ECU connector T23.
(b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
GND1 - Body ground	Always	Below 1 Ω

- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
+B - GND1	Always	10 to 14 V
ACC - GND1	Ignition SW ACC	10 to 14 V
IG - GND1	Ignition SW ON	10 to 14 V

NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK**

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE OR DIAGNOSTIC TROUBLE CODE CHART (SEE PAGE 05-1771 OR 05-1788)