

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
When shift lever is in R position, parking assist monitor image is not displayed (Screen is not black).	1. Power source circuit 2. Neutral start switch 3. Television camera ECU	05-1931 05-563 67-15
When shift lever is in R position, parking assist monitor image is not displayed (Screen is black).	1. Display signal circuit (Television camera assy – Television camera ECU) 2. Television camera assy 3. Television camera ECU	05-1937 67-14 67-15
When shift lever is not in R position, parking assist monitor image is displayed.	1. Neutral start switch 2. Television camera ECU	05-563 67-15
Even if switching into "Serial Parking Assist" mode, system changes into "Manual" mode.	1. Steering sensor 2. AVC-LAN circuit 3. Navigation ECU 4. Television camera ECU	32-65 05-1933 67-9 67-15
Problem with the parking assist monitor image (color, disorder of picture).	1. Display signal circuit (Television camera assy – Television camera ECU) 2. Display signal circuit (Television camera ECU – Multi-display assy) 3. Television camera assy 4. Television camera ECU 5. Multi-display	05-1937 05-1935 67-14 67-15 67-8
When parking the vehicle with "Serial Parking Assist" mode, even if vehicle starts to run, screen does not change.	This may occur when reversing at very low speed.	–
"SYSTEM INITIALIZING" is displayed.	Correct the steering angle neutral point without fail.	05-1913