

TERMINALS OF ECU

1. CHECK DRIVER SEAT ECU



B74378

- Disconnect the D27 and D28 ECU connectors.
- Measure the voltage of each terminal of the wire harness side connectors.

Standard:

LHD models

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
GND (D27-6) – Body ground	W-B – Body ground	Ground	Constant	Below 1 V
SGND (D28-1) – Body ground	BR – Body ground	Ground	Constant	Below 1 V
IG (D28-10) – SGND (D28-1)	R-L – BR	Ignition switch	Ignition switch OFF → ON	0 V → 0 to 14 V
+B (D27-14) – GND (D27-6)	B-R – W-B	Battery	Constant	10 to 14 V
SYSB (D28-9) – SGND (D28-1)	V-Y – BR	Battery	Constant	10 to 14 V

RHD models

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
GND (D27-1) – Body ground	W-B – Body ground	Ground	Constant	Below 1 V
SGND (D28-8) – Body ground	BR – Body ground	Ground	Constant	Below 1 V
IG (D28-15) – SGND (D28-8)	R-L – BR	Ignition switch	Ignition switch OFF → ON	0 V → 0 to 14 V
+B (D27-7) – GND (D27-1)	B-R – W-B	Battery	Constant	10 to 14 V
SYSB (D28-16) – SGND (D28-8)	V-Y – BR	Battery	Constant	10 to 14 V

If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the D27 and D28 ECU connectors.
 (d) Measure the voltage of each terminal of connectors.

Standard:**LHD models**

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
SLD+ (D27-8) – GND (D27-6)	B – W-B	Sliding motor signal (forward)	Seat moving forward using sliding switch Others	10 to 14 V Below 1 V
SLD- (D27-1) – GND (D27-6)	R-B – W-B	Sliding motor signal (rearward)	Seat moving rearward using sliding switch Others	10 to 14 V Below 1 V
FRV+ (D27-5) – GND (D27-6)	R – W-B	Front vertical motor signal (upward)	Seat cushion front portion raising using front vertical switch Others	10 to 14 V Below 1 V
FRV- (D27-2) – GND (D27-6)	L – W-B	Front vertical motor signal (downward)	Seat cushion front portion lowering using front vertical switch Others	10 to 14 V Below 1 V
RRV+ (D27-9) – GND (D27-6)	B-R – W-B	Lifter motor signal (upward)	Seat raising using lifter switch Others	10 to 14 V Below 1 V
RRV- (D27-4) – GND (D27-6)	W – W-B	Lifter motor signal (downward)	Seat lowering using lifter switch Others	10 to 14 V Below 1 V
RCL+ (D27-13) – GND (D27-6)	L – W-B	Reclining motor signal (forward)	Seatback moving forward using reclining switch Others	10 to 14 V Below 1 V
RCL- (D27-10) – GND (D27-6)	L-R – W-B	Reclining motor signal (rearward)	Seatback moving rearward using reclining switch Others	10 to 14 V Below 1 V
C+ (D27-7) – GND (D27-6)	B-W – W-B	Seat cushion motor signal (forward)	Seat cushion moving forward using cushion switch Others	10 to 14 V Below 1 V
C- (D27-11) – GND (D27-6)	Y – W-B	Seat cushion motor signal (rearward)	Seat cushion moving rearward using cushion switch Others	10 to 14 V Below 1 V
H+ (D27-12) – GND (D27-6)	B-W – W-B	Headrest motor signal (upward)	Headrest moving upward using headrest switch Others	10 to 14 V Below 1 V
H- (D27-3) – GND (D27-6)	R-L – W-B	Headrest motor signal (downward)	Headrest moving downward using headrest switch Others	10 to 14 V Below 1 V
CSNR (D28-4) – SGND (D28-1)	Y-B – BR	Seat cushion switch signal (rear)	Seat cushion switch OFF → REAR Seat cushion switch OFF → FRONT	Below 1 V 10 to 14 V
CSNF (D28-12) – SGND (D28-1)	Y – BR	Seat cushion switch signal (front)	Seat cushion switch OFF → FRONT Seat cushion switch OFF → REAR	Below 1 V 10 to 14 V
SSRS (D28-5) – SGND (D28-1)	LG – BR	Slide direction position signal	Slide operation	0 to 8 V
SSFV (D28-14) – SGND (D28-1)	LG-R – BR	Front vertical direction position signal	Front vertical operation	0 to 8 V
SSRV (D28-6) – SGND (D28-1)	LG-B – BR	Lifter position signal	Lifter operation	0 to 8 V

DIAGNOSTICS – FRONT POWER SEAT CONTROL SYSTEM

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
SSRR (D28-13) – SGND (D28-1)	GR – BR	Reclining position signal	Reclining operation	0 to 8 V
SSRC (D28-15) – SGND (D28-1)	GR-R – BR	Seat cushion position signal	Seat cushion operation	0 to 8 V
SSRH (D28-7) – SGND (D28-1)	O – BR	Headrest position signal	Headrest operation	0 to 8 V
PVCC (D28-16) – SGND (D28-1)	V-W – BR	Position sensor power supply	Power seat operation	8 V
*IDL (D28-8) – Body ground	W – Body ground	Engine Idle-up signal	Ignition switch ON Turn Climate control switch OFF → ON	10 to 14 V → 0 V

HINT:

*: w/ Climate control seat system

RHD models


Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
SLD+ (D27-13) – GND (D27-1)	B – W-B	Sliding motor signal (forward)	Seat moving forward using sliding switch Others	10 to 14 V Below 1 V
SLD- (D27-6) – GND (D27-1)	R-B – W-B	Sliding motor signal (rearward)	Seat moving rearward using sliding switch Others	10 to 14 V Below 1 V
FRV+ (D27-2) – GND (D27-1)	R – W-B	Front vertical motor signal (upward)	Seat cushion front portion raising using front vertical switch Others	10 to 14 V Below 1 V
FRV- (D27-5) – GND (D27-1)	L – W-B	Front vertical motor signal (downward)	Seat cushion front portion lowering using front vertical switch Others	10 to 14 V Below 1 V
RRV+ (D27-12) – GND (D27-1)	B-R – W-B	Lifter motor signal (upward)	Seat raising using lifter switch Others	10 to 14 V Below 1 V
RRV- (D27-3) – GND (D27-1)	W – W-B	Lifter motor signal (downward)	Seat lowering using lifter switch Others	10 to 14 V Below 1 V
RCL+ (D27-8) – GND (D27-1)	L – W-B	Reclining motor signal (forward)	Seatback moving forward using reclining switch Others	10 to 14 V Below 1 V
RCL- (D27-11) – GND (D27-1)	L-R – W-B	Reclining motor signal (rearward)	Seatback moving rearward using reclining switch Others	10 to 14 V Below 1 V
C+ (D27-14) – GND (D27-1)	B-W – W-B	Seat cushion motor signal (forward)	Seat cushion moving forward using cushion switch Others	10 to 14 V Below 1 V
C- (D27-10) – GND (D27-1)	Y – W-B	Seat cushion motor signal (rearward)	Seat cushion moving rearward using cushion switch Others	10 to 14 V Below 1 V
H+ (D27-9) – GND (D27-1)	B-W – W-B	Headrest motor signal (upward)	Headrest moving upward using headrest switch Others	10 to 14 V Below 1 V
H- (D27-4) – GND (D27-1)	R-L – W-B	Headrest motor signal (downward)	Headrest moving downward using headrest switch Others	10 to 14 V Below 1 V

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
CSNR (D28-5) – SGND (D28-8)	Y-B – BR	Seat cushion switch signal (rear)	Seat cushion switch OFF → REAR Seat cushion switch OFF → FRONT	Below 1 V 10 to 14 V
CSNF (D28-13) – SGND (D28-8)	Y – BR	Seat cushion switch signal (front)	Seat cushion switch OFF → FRONT Seat cushion switch OFF → REAR	Below 1 V 10 to 14 V
SSRS (D28-4) – SGND (D28-8)	LG – BR	Slide direction position signal	Slide operation	0 to 8 V
SSFV (D28-11) – SGND (D28-8)	LG-R – BR	Front vertical direction position signal	Front vertical operation	0 to 8 V
SSRV (D28-3) – SGND (D28-8)	LG-B – BR	Lifter position signal	Lifter operation	0 to 8 V
SSRR (D28-12) – SGND (D28-8)	GR – BR	Reclining position signal	Reclining operation	0 to 8 V
SSRC (D28-10) – SGND (D28-8)	GR-R – BR	Seat cushion position signal	Seat cushion operation	0 to 8 V
SSRH (D28-2) – SGND (D28-8)	O – BR	Headrest position signal	Headrest operation	0 to 8 V
PVCC (D28-9) – SGND (D28-8)	V-W – BR	Position sensor power supply	Power seat operation	8 V
*IDL (D28-1) – Body ground	W – Body ground	Engine Idle-up signal	Ignition switch ON Turn Climate control switch OFF → ON	10 to 14 V → 0 V

HINT:

*: w/ Climate control seat system

If the result is not as specified, replace the power seat or the ECU may be malfunctioning.

2. CHECK DRIVER DOOR ECU

- Disconnect the D25 ECU connector.
- Measure the voltage of each terminal of the wire harness side connector.

Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
GND (D25-1) – Body ground	W-B – Body ground	Ground	Constant	Below 1 V
CPUB (D25-4) – GND (D25-1)	V-Y – W-B	Battery (ECU power source)	Constant	10 to 14 V

DIAGNOSTICS – FRONT POWER SEAT CONTROL SYSTEM

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
SIG (D25-5) – GND (D25-1)	R-L – W-B	Ignition power supply	Ignition switch OFF → ON	0 V → 10 to 14 V
BDR (D25-6) – GND (D25-1)	R – W-B	Battery (ECU power source)	Constant	10 to 14 V

If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the D25 ECU connector.
- (d) Measure the voltage of each terminal of the D24 ECU connector.

Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
MM (D24-29) – MSWE (D24-28)	GR – BR-W	Memory SET switch signal	Memory SET switch OFF Memory SET switch ON	10 to 14 V Below 1 V
M1 (D24-21) – MSWE (D24-28)	P – BR-W	Memory 1 switch signal	Memory 1 switch OFF Memory 1 switch ON	10 to 14 V Below 1 V
M2 (D24-20) – MSWE (D24-28)	P-B – BR-W	Memory 2 switch signal	Memory 2 switch OFF Memory 2 switch ON	10 to 14 V Below 1 V
M3 (D24-9) – MSWE (D24-28)	P-L – BR-W	Memory 3 switch signal	Memory 3 switch OFF Memory 3 switch ON	10 to 14 V Below 1 V

If the result is not as specified, replace the driver door ECU may be malfunctioning.