

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
All functions of rear power seat system do not operate. (Both left and right)	1. Rear seat control switch power source circuit If the suspected area above is functioning normally, replace the rear seat control switch.	05-2411
Rear left side power seat system does not operate.	1. Rear LH seat ECU power source circuit 2. Rear seat control switch power source circuit 3. Rear seat control switch circuit If the 3 suspected areas above is functioning normally, replace the rear LH seat ECU.	05-2354 05-2411 05-2413
Rear right side power seat system does not operate.	1. Rear RH seat ECU power source circuit 2. Rear seat control switch power source circuit 3. Rear seat control switch circuit If the 3 suspected areas above is functioning normally, replace the rear RH seat ECU.	05-2356 05-2411 05-2413
Slide operation does not operate. (Rear left side)	1. Rear seat control switch circuit 2. Slide power seat motor circuit (LH) 3. Slide position sensor circuit (LH) If the 3 suspected areas above is functioning normally, replace the rear LH seat ECU.	05-2413 05-2367 05-2389
Slide operation does not operate. (Rear right side)	1. Rear seat control switch circuit 2. Slide power seat motor circuit (RH) 3. Slide position sensor circuit (RH) If the 3 suspected areas above is functioning normally, replace the rear RH seat ECU.	05-2413 05-2370 05-2393
Headrest operation does not operate. (Rear left side)	1. Rear seat control switch circuit 2. Headrest motor circuit (LH) 3. Headrest limit switch circuit (LH) 4. Headrest position sensor circuit (LH) If the 4 suspected areas above is functioning normally, replace the rear LH seat ECU.	05-2413 05-2373 05-2383 05-2373
Headrest operation does not operate. (Rear right side)	1. Rear seat control switch circuit 2. Headrest motor circuit (RH) 3. Headrest limit switch circuit (RH) 4. Headrest position sensor circuit (RH) If the 4 suspected areas above is functioning normally, replace the rear RH seat ECU.	05-2413 05-2378 05-2386 05-2378
Rear left side seat position memory function does not operate.	1. Rear door LH ECU power source circuit 2. Rear seat memory switch circuit (LH) 3. Slide position sensor circuit (LH) 4. Headrest position sensor circuit (LH) If the 4 suspected areas above is functioning normally, replace the rear LH seat ECU.	05-2361 05-2418 05-2389 05-2373
Rear right side seat position memory function does not operate.	1. Rear door RH ECU power source circuit 2. Rear seat memory switch circuit (RH) 3. Slide position sensor circuit (RH) 4. Headrest position sensor circuit (RH) If the 4 suspected areas above is functioning normally, replace the rear RH seat ECU.	05-2364 05-2421 05-2393 05-2378
Rear seat position return function does not operate.	1. Passenger side J/B ECU power source circuit 2. Rear seat return switch circuit If the 2 suspected areas above is functioning normally, replace the rear LH seat ECU that is malfunctioning.	05-2358 05-2415
Rear left side door open linked return function does not operate.	1. Rear door LH ECU power source circuit 2. Door courtesy switch circuit (LH) If the 2 suspected areas above is functioning normally, replace the rear LH seat ECU.	05-2361 05-2424

DIAGNOSTICS – REAR POWER SEAT CONTROL SYSTEM

Rear right side door open linked return function does not operate.	1. Rear door RH ECU power source circuit 2. Door courtesy switch circuit (RH) If the 2 suspected areas above is functioning normally, replace the rear RH seat ECU.	05-2364 05-2427
Rear left side vibration seat function does not operate.	1. Vibration seat function does not operate (Rear seat ECU operation check) 2. Vibration seat ECU communication circuit (LHD models LH) Vibration seat ECU communication circuit (RHD models LH) 3. Vibration circuit (LH) If the 3 suspected areas above is functioning normally, replace the vibration ECU LH.	05-2430 05-2403 05-2407 05-2397
Rear right side vibration seat function does not operate.	1. Vibration seat function does not operate (Rear seat ECU operation check) 2. Vibration seat ECU communication circuit (LHD models RH) Vibration seat ECU communication circuit (RHD models RH) 3. Vibration circuit (RH) If the 3 suspected areas above is functioning normally, replace the vibration ECU RH.	05-2430 05-2405 05-2409 05-2400