


INSPECTION PROCEDURE**1 INSPECT FUSE (P RR-IG, AM1)**

- (a) Remove the P RR-IG fuse from the passenger side J/B.
- (b) Remove the AM1 fuse from the driver side J/B.
- (c) Measure the resistance.

Standard: Below 1 Ω **NG****REPLACE FUSE****OK****2 CHECK WIRE HARNESS (VIBRATION SEAT ECU RH - REAR RH SEAT ECU AND BODY GROUND)****Wire Harness Side**

Y

B74406

- (a) Disconnect the V11 and R28 ECU connectors.
- (b) Measure the voltage and resistance of the wire harness side connector.

Standard:

Tester Connection	Condition	Specified Condition
V11-5 (IG) - Body ground	Ignition switch OFF → ON	0 V → 10 to 14 V
V11-2 (STRT) - R28-6 (STRT)	Constant	Below 1 Ω
V11-7 (STOP) - R28-19 (STOP)	Constant	Below 1 Ω
V11-10 (GND1) - Body ground	Constant	Below 1 Ω

NG**REPAIR OR REPLACE HARNESS AND CONNECTOR****OK****PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE**
(See page 05-2340)