

PROBLEM SYMPTOMS TABLE

Problem Symptom	Suspected Area	See Page
Engine does not start	1. ECU power source circuit	05-3024
	2. Steering lock ECU	05-3024