

## PROBLEM SYMPTOMS TABLE

| Symptom                                                  | Suspected Area                                                                                                                                                                                                | See Page                                                                                                                                                  |
|----------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Rear window defogger does not operate<br>(Indicator ON)  | 1. DEFOG H-fuse<br>2. FR IG fuse<br>3. DEFOG relay<br>4. Rear window defogger wire<br>5. Wire harness                                                                                                         | <a href="#">70-21</a><br><a href="#">70-21</a><br><a href="#">70-21</a><br><a href="#">70-26</a><br>–                                                     |
| Rear window defogger does not operate<br>(Indicator OFF) | 1. DEFOG H-fuse<br>2. FR IG fuse<br>3. DEFOG relay<br>4. Heater control panel assy (w/o LEXUS navigation)<br>5. Multi-display assy (w/ LEXUS navigation)<br>6. Rear window defogger wire<br>7. Wire harness   | <a href="#">70-21</a><br><a href="#">70-21</a><br><a href="#">70-21</a><br><a href="#">05-778</a><br><a href="#">05-778</a><br><a href="#">70-26</a><br>– |
| Mirror heater does not operate<br>(Indicator ON)         | 1. D DOOR fuse<br>2. P DOOR fuse<br>3. D-IG1 relay<br>4. Outer rear view mirror assy<br>5. Wire harness                                                                                                       | <a href="#">70-21</a><br><a href="#">70-21</a><br><a href="#">70-21</a><br><a href="#">70-26</a><br>–                                                     |
| Mirror heater does not operate<br>(Indicator OFF)        | 1. D DOOR fuse<br>2. P DOOR fuse<br>3. D-IG1 relay<br>4. Heater control panel assy (w/o LEXUS navigation)<br>5. Multi-display assy (w/ LEXUS navigation)<br>6. Outer rear view mirror assy<br>7. Wire harness | <a href="#">70-21</a><br><a href="#">70-21</a><br><a href="#">70-21</a><br><a href="#">05-778</a><br><a href="#">05-778</a><br><a href="#">70-26</a><br>– |

### HINT:

The wind defogger system is part of the large-scale multiplex communication system. This system features shared communication wiring that reduces the wiring complexity of the communication lines. The first step in any repair is to confirm the proper operation of the communication system. Proceed with troubleshooting after the communication has been verified (see the Multiplex Communication System).