

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

Symptom	Suspect Area	See page
Damping force control does not operate at all	3. Suspension control actuator circuit 4. T _D terminal 5. Pneumatic cylinder/shock absorber 6. Suspension control ECU	DI-277 DI-337 SA-30 SA-101 IN-35
Only anti-roll control does not operate	1. Steering angle sensor circuit 2. Vehicle speed sensor circuit 3. Suspension control ECU	DI-315 DI-313 IN-35
Only anti-squat control does not operate	1. Crankshaft position sensor circuit 2. Vehicle speed sensor circuit 3. Suspension control ECU	DI-320 DI-313 IN-35
Only anti-dive control does not operate	1. Stop light switch circuit 2. Vehicle speed sensor circuit 3. Suspension control ECU	DI-323 DI-313 IN-35
Only high speed control does not operate	1. Vehicle speed sensor circuit 2. Suspension control ECU	DI-313 IN-35
Only bouncing control does not operate	1. Acceleration sensor circuit 2. Height control sensor circuit 3. Height control sensor link 4. Vehicle speed sensor circuit 5. Suspension control ECU	DI-271 DI-265 SA-123 DI-313 IN-35
Lighting up position of height control indicator light does not change according to operation of height control switch	1. Height control switch circuit 2. Suspension control ECU	DI-325 IN-35
Vehicle height control function does not operate	1. Height control sensor circuit 2. Height control solenoid valve circuit 3. Height control switch circuit 4. Height control exhaust valve circuit 5. Height control relay circuit 6. Suspension control ECU	DI-265 DI-284 DI-325 DI-284 DI-292 IN-24
Hunting of vehicle height occurs	1. Air leakage 2. Height control sensor circuit 3. Suspension control ECU	SA-121 DI-265 IN-35
Vehicle height control operates, but vehicle height is uneven	1. Height control sensor circuit 2. Height control sensor link 3. Suspension control ECU	DI-265 SA-123 IN-35
Vehicle height control operates, but vehicle height is high or low. (Vehicle height in NORMAL mode varies from the standard value)	1. Height control sensor link 2. Height control sensor circuit 3. Suspension control ECU	SA-123 DI-265 IN-35
When vehicle height control is adjusted, it stops at extremely high or extremely low position	Height control sensor circuit	DI-265
Absorber control indicator light abnormal	1. Absorber control indicator light circuit 2. Suspension control ECU	DI-331 IN-35
DTC check cannot be done	Only when 1. and 2. are all normal and the problem is still occurring, replace the suspension control ECU. 1. Absorber control indicator light circuit 2. Tc terminal circuit	DI-331 DI-333
Input signal check (Test mode) cannot be done	1. Ts terminal circuit 2. Suspension control ECU	DI-335 IN-35

Vehicle height is extremely low when vehicle is parked	1. Air leakage 2. Pneumatic cylinder/shock absorber 3. Height control sensor link 4. Height control exhaust valve circuit	SA-121 SA-30 SA-101 SA-123 DI-284
Compressor motor continues to operate	1. Air leakage 2. Height control relay circuit 3. Height control compressor circuit 4. Height control sensor link 5. Pneumatic cylinder/shock absorber 6. Suspension control ECU	SA-121 DI-292 DI-284 SA-123 SA-30 SA-101 IN-35