

DTC	Always ON	Malfunction in ECU ABS Warning Light Circuit
------------	------------------	---


CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
Always ON	Malfunction in skid control ECU	• Power source circuit • ABS warning light circuit • Multiplex communication circuit • Skid control ECU

HINT:

In some cases the hand-held tester cannot be used when the skid control ECU is abnormal.

WIRING DIAGRAM




INSPECTION PROCEDURE**1 Is DTC output?**Check DTC on [page DI-343](#).**YES****Repair circuit indicated by the code output.****NO****2 Check that the skid control ECU connectors are securely connected to the skid control ECU.****NO****Connect the connector to the skid control ECU.****YES****3 Check voltage of the ECU IG power source.****In case of using the hand-held tester:****PREPARATION:**

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and turn the hand-held tester main switch ON.
- (c) Select the DATALIST mode on the hand-held tester.

CHECK:

Check the voltage condition output from the ECU observed in the hand-held tester.

OK:**"Normal" is displayed.****In case of not using the hand-held tester:****PREPARATION:**

Remove the skid control ECU with the connectors still connected to it.

CHECK:

- (a) Turn the ignition switch ON.
- (b) Measure voltage between the terminals IG1 (S12 – 6) and GND (S14 – 15, 22, S11 – 3, 5) of the skid control ECU.

OK:**Voltage: 10 – 14 V****OK****Check and replace skid control ECU.****NG**

4 Check battery voltage.

CHECK:

Check the battery voltage.

OK:

Voltage: 10 – 14 V

NG

Check and repair the charging system.

OK

5 Check for open and short circuit in harness and connector between terminals Tc of DLC3 to skid control ECU (See page IN-35).

NG

Repair or replace harness or connector.

OK

6 Check operation of the ABS warning light.

In case of using the hand-held tester:

PREPARATION:

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and turn the hand-held tester main switch ON.
- (c) Select the ACTIVE TEST mode on the hand-held tester.

CHECK:

Check that "ON" and "OFF" of the ABS warning light can be shown on the combination meter by the hand-held tester.

In case of not using the hand-held tester:

PREPARATION:

- (a) Turn the ignition switch OFF.
- (b) Disconnect the connector from the skid control ECU.
- (c) Turn the ignition switch ON.

CHECK:

Check that the ABS warning light lights up.

OK

Check and replace skid control ECU.

NG

- | | |
|----------|--|
| 7 | Check for short circuit in multiplex communication circuit between terminal MPX1 of skid control ECU and terminal MPX- of combination meter (See page IN-35). |
|----------|--|

NG

Repair or replace harness or connector.

OK

Repair or replace combination meter.