

CIRCUIT INSPECTION


DTC	B1244	Light Sensor Circuit Malfunction
------------	--------------	---

CIRCUIT DESCRIPTION

This DTC is output when failure of light control sensor circuit is detected.

DTC No.	DTC Detecting Condition	Trouble Area
B1244	- Malfunction of light sensor - Open or short of light sensor circuit	- Light sensor - Wire harness - Driver side J/B ECU

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

In case of using the LEXUS hand-held tester, start the inspection from step 1 and in case of not using the LEXUS hand-held tester, start from step 2.

1	Check light sensor.
----------	----------------------------

PREPARATION:

- (a) Connect the LEXUS hand-held tester to the DLC3.
- (b) Turn ignition switch ON and LEXUS hand-held tester main switch ON.

CHECK:

The value of the illumination rate should change in the following range when the light sensor is put in the light or covered by a hand.

OK:

0.8 ms – 22.0 ms

HINT:

- This is the time to be taken for the light sensor to generate one circle of frequency according to the brightness.
- When not using LEXUS hand-held tester ([See page BE-33](#)).

NG

Replace the light sensor.

OK

2	Check wire harness and connector between light sensor and driver side J/B ECU (See page IN-35).
----------	--

NG

Repair or replace wire harness.

OK

Replace driver side J/B ECU.