

Illumination (Door courtesy switch signal) circuit


CIRCUIT DESCRIPTION

Receiving the courtesy signal from either of the door ECU, the passenger side J/B ECU makes the front personal light, interior right rear light, center console spot light, step light, inside handle illumination and ignition key cylinder light come on.

Installation Function List:

Control Functions	Illuminated entry system	Illumination control	Fade in/Fade out
Front personal light	○	X	○
Interior light rear light	X	X	○
Center console spot light	X	X	○
Step light	○	○	○
Inside handle illumination	○	○	○
Ignition key cylinder light	○	X	○

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

In case of using the LEXUS hand-held tester, start the inspection from step 1 and in case of not using the LEXUS hand-held tester, start from step 2.

- | | |
|---|--|
| 1 | Check the illumination (front personal light, interior light rear light, center console spot light, step light) using LEXUS hand-held tester. |
|---|--|

PREPARATION:

Connect the LEXUS hand-held tester to the DLC3.

CHECK:

Check that the illumination can light in an ACTIVE TEST.

OK

Proceed to next circuit inspection shown on problem symptom table ([See page DI-1071](#)).

NG

- | | |
|---|--|
| 2 | Check the illumination light (See page BE-49, BE-52). |
|---|--|

NG

Replace the illumination light.

OK

- | | |
|---|--|
| 3 | Check wire harness and connector between illumination light and passenger side J/B ECU, battery and each illumination light (See page IN-35). |
|---|--|

NG

Repair or replace wire harness or connector.

OK

Proceed to next circuit inspection shown on problem symptom table ([See page DI-1071](#)).