




INSPECTION


NOTICE:

When using a vise, do not overtighten it.

1. w/o Smart key system:

INSPECT STEERING LOCK OPERATION

Check that the steering lock mechanism operates properly.



2. w/o Smart key system:

IF NECESSARY, REPLACE KEY CYLINDER

- Place the ignition key at the ACC position.
- Using a screwdriver, push down the stop pin of the cylinder, and pull out the key cylinder.
- Install a new cylinder.

HINT:

Make sure the key is at the ACC position.

3. INSPECT IGNITION SWITCH (See page BE-30)

4. IF NECESSARY, REPLACE IGNITION SWITCH

- Remove the 2 screws and ignition switch.
- Install a new ignition switch with the 2 screws.

5. w/ Key unlock warning switch:

INSPECT KEY UNLOCK WARNING SWITCH (See page BE-30)

6. w/ Key unlock warning switch:

w/o Smart key system:

IF NECESSARY, REPLACE KEY UNLOCK WARNING SWITCH

- Slide the key unlock warning switch out of the column upper bracket.
- Slide a new key unlock warning switch in the column upper bracket.

7. INSPECT KEY INTERLOCK SOLENOID (See page AT-19)

8. w/o Smart key system:

IF NECESSARY, REPLACE KEY INTERLOCK SOLENOID


- Remove the 2 screws and key interlock solenoid.
- Install a new key interlock solenoid with the 2 screws.

9. INSPECT TRANSPONDER KEY AMPLIFIER WITH COIL

(w/o Smart key system: See page DI-900)

(w/ Smart key system: See page DI-873)

10. IF NECESSARY, REPLACE TRANSPONDER KEY AMPLIFIER WITH COIL

**11. INSPECT BEARING**

- (a) Check the bearing rotation condition and check for abnormal noise.

If the bearing is worn or damaged, replace the column upper tube sub-assembly.

- (b) Coat the bearing with molybdenum disulfide lithium base grease.