

DTC	P0327	Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor)
DTC	P0328	Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor)
DTC	P0332	Knock Sensor 2 Circuit Low Input (Bank 2)
DTC	P0333	Knock Sensor 2 Circuit High Input (Bank 2)

DESCRIPTION

ES

A flat type knock sensor (non-resonant type) can detect vibrations in a wide band of frequency (about 6 kHz to 15 kHz) and has the following features:

- Knock sensors are fitted on the cylinder block to detect the engine knocking.
- The sensor contains a piezoelectric element which generates a voltage when the cylinder block vibrates due to knocking. If engine knocking occurs, the ignition timing is retarded to suppress it.

DTC No.	DTC Detection Condition	Trouble Area
P0327 P0332	Output voltage of the knock sensor 1 or 2 is 0.5 V or less	<ul style="list-style-type: none"> • Short in knock sensor 1 or 2 circuit • Knock sensor 1 or 2 • ECM
P0328 P0333	Output voltage of the knock sensor 1 or 2 is 4.5 V or more	<ul style="list-style-type: none"> • Open in knock sensor 1 or 2 circuit • Knock sensor 1 or 2 • ECM

MONITOR DESCRIPTION

The knock sensor, located on the cylinder block, detects spark knock. When spark knock occurs, the sensor picks up vibrations in a specific frequency range. When the ECM detects the voltage in this frequency range, it retards the ignition timing to suppress the spark knock.

The ECM also senses background engine noise with the knock sensor and uses this noise to check for faults in the sensor. If the knock sensor signal level is too low for more than 10 seconds, and if the knock sensor output voltage is out of normal range, the ECM interprets this as a fault in the knock sensor and sets a DTC.

MONITOR STRATEGY

Related DTCs	P0327: Knock Sensor (Bank 1) Range Check (Low voltage) P0328: Knock Sensor (Bank 1) Range Check (High voltage) P0332: Knock Sensor (Bank 2) Range Check (Low voltage) P0333: Knock Sensor (Bank 2) Range Check (High voltage)
Required sensors / components (Main)	Knock Sensor
Required sensors / components (Related)	MAF meter, Crankshaft position sensor, ECT sensor
Frequency of operation	Continuous
Duration	1 second
MIL operation	Immediate
Sequence operation	None

TYPICAL ENABLING CONDITIONS

The monitor will run whenever these DTCs are not present	None
Battery voltage	10.5 V or more
Time after engine start	5 seconds or more

Ignition switch	ON
Starter	OFF

TYPICAL MALFUNCTION THRESHOLDS

Knock Sensor Range Check (Low voltage):


Knock sensor Voltage	Less than 0.5 V
----------------------	-----------------

Knock Sensor Range Check (High voltage):

Knock sensor voltage	More than 4.5 V
----------------------	-----------------

WIRING DIAGRAM


ES



HINT:

- DTC P0327 and P0328 are for the bank 1 knock sensor circuit.
- DTC P0332 and P0333 are for the bank 2 knock sensor circuit.
- Read freeze frame data using the intelligent tester. The ECM records vehicle and driving condition information as freeze frame data the moment a DTC is stored. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air-fuel ratio was LEAN or RICH, and other data from the time the malfunction occurred.

1 READ OUTPUT DTC (CHECK KNOCK SENSOR CIRCUIT)



(a) Disconnect the EA1 connector.
 (b) Using lead wires, connect the EA1 terminals as follows.

Male Connector - Female Connector

Terminal 2 - Terminal 4

Terminal 1 - Terminal 3

Terminal 4 - Terminal 2

Terminal 3 - Terminal 1

(c) Warm up the engine.
 (d) Run the engine at 3,000 rpm for 10 seconds or more.
 (e) Check the DTC (See page [ES-28](#)).

Result


Display	Proceed to
DTC same as when vehicle brought in P0327, P0328 → P0327, P0328 or P0332, P0333 → P0332, P0333	A
DTC different from when vehicle brought in P0327, P0328 → P0332, P0333 or P0332, P0333 → P0327, P0328	B

Go to step 4

A

2 CHECK HARNESS AND CONNECTOR (EA1 FEMALE CONNECTOR - ECM)

Wire Harness Side:



(a) Disconnect the EA1 connector.
 (b) Disconnect the E9 ECM connector.
 (c) Measure the resistance of the wire harness side connector.


Standard resistance

Tester Connection	Specified Condition
2 of EA1 female connector - E9-1 (KNK1) 1 of EA1 female connector - E9-28 (EKNK) 4 of EA1 female connector 4 - E9-2 (KNK2) 3 of EA1 female connector - E9-20 (EKN2)	Below 1 Ω
2 of EA1 female connector or E9-1 (KNK1) - Body ground 1 of EA1 female connector or E9-28 (EKNK) - Body ground 4 of EA1 female connector or E9-2 (KNK2) - Body ground 3 of EA1 female connector or E9-20 (EKN2) - Body ground	10 kΩ or higher

NG



REPAIR OR REPLACE HARNESS OR CONNECTOR

ES



OK

3 CHECK ECM (KNK1, KNK2 VOLTAGE)



(a) Disconnect the E9 ECM connector.
 (b) Turn the ignition switch ON.

(c) Measure the voltage of ECM terminals.
Standard voltage

Tester Connection	Specified Condition
E9-1 (KNK1) - E9-28 (EKNK) E9-2 (KNK2) - E9-20 (EKN2)	4.5 to 5.5 V

Reconnect the E9 ECM connector.

HINT:

Reference: Inspection using an oscilloscope.

After warming up, run the engine at 4,000 rpm and check the waveform between terminal KNK1 and EKNK of the ECM connector.

Standard voltage

Tester Connection	Specified Condition
E9-1 (KNK1) - E9-28 (EKNK) E9-2 (KNK2) - E9-20 (EKN2)	Correct waveform is as shown

NOTICE:

Fault may be intermittent. Check harness and connectors carefully and retest.

NG


REPLACE ECM

OK

CHECK FOR INTERMITTENT PROBLEMS

4 INSPECT KNOCK SENSOR (RESISTANCE)

Wire Harness Side:



(a) Disconnect the EA1 connector.

(b) Measure the resistance between the terminals of the EA1 male connector.

Standard resistance

Tester Connection	Specified Condition
2 - 1 of EA1 male connector	120 to 280 kΩ
4 - 3 of EA1 male connector	

OK

CHECK FOR INTERMITTENT PROBLEMS

NG

ES

5 CHECK HARNESS AND CONNECTOR (EA1 MALE CONNECTOR - KNOCK SENSOR)

HINT:

- If DTC P0327 has changed to P0328, or if DTC P0332 has changed to P0333, check the knock sensor circuit on the bank 1 side.
- If DTC P0332 has changed to P0327, or if DTC P0333 has changed to P0338, check the knock sensor circuit on the bank 2 side.

(a) Disconnect the EA1 connector.

(b) Disconnect the K2 or K3 knock sensor connector.

(c) Measure the resistance of the wire harness side connectors.



Standard resistance

Tester Connection	Specified Condition
2 of EA1 male connector - K2-2 1 of EA1 male connector - K2-1 4 of EA1 male connector - K3-2 3 of EA1 male connector - K3-1	Below 1 Ω
2 of EA1 male connector or K2-2 - Body ground 1 of EA1 male connector or K2-1 - Body ground 4 of EA1 male connector or K3-2 - Body ground 3 of EA1 male connector or K3-1 - Body ground	10 kΩ or higher

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

Wire Harness Side:



A085847E03

OK

REPLACE KNOCK SENSOR