


IMPORT SERVICE BACKUP *MANUAL*

LASERTALON



ENGINE, CHASSIS & BODY

Volume — 1

Partial BACKUP Service Manual

LASER TALON

1993

Volume-1
Engine, Chassis
& Body

FOREWORD

This Service Manual has been prepared with the latest service information available at the time of publication. It is subdivided into various group categories and each section contains diagnosis, disassembly, repair, and installation procedures along with complete specifications and tightening references. Use of this manual will aid in properly performing any servicing necessary to maintain or restore the high levels of performance and reliability designed into these outstanding vehicles.

This BACKUP DSM manual is to be used ONLY as a BACKUP. Please DO NOT REDISTRIBUTE WHOLE SECTIONS. This BACKUP was sold to you under the fact that you do indeed OWN a GENUINE DSM MANUAL. It CANNOT BE considered a REPLACEMENT (Unless your original manual was lost or destroyed.)

Please See README.TXT or README.HTML for additional information.

Thank you. Gimmieymymanual@hotmail.com



**CHRYSLER
CORPORATION**

Chrysler Corporation reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

GROUP INDEX

| | |
|---|----|
| Introduction and Master Troubleshooting | 0 |
| Lubrication and Maintenance | 2 |
| Front Suspension | 3 |
| Rear Axle | 5 |
| Brakes—Service Parking | 6 |
| Clutch | 7 |
| Cooling | 9 |
| Engine | 11 |
| Intake and Exhaust | 14 |
| Fuel System | 16 |
| Propeller Shaft | 17 |
| Rear Suspension | 19 |
| Steering—Manual Power | 21 |
| Transaxle—Manual Automatic | 22 |
| Wheels and Tires | 23 |
| Body | 24 |
| Heater & Air Conditioning | 25 |
| Emission Control Systems | |

NOTE: For Electrical, refer to
Volume-2 "Electrical".

BRAKES

SERVICE AND PARKING

CONTENTS

N05AA--

| | | | |
|--|-----|--|----|
| ANTI-LOCK BRAKING SYSTEM | | | |
| TROUBLESHOOTING | 9 | Front Disc Brake Pad Check and Replacement | 51 |
| BRAKE BOOSTER | 71 | Front Disc Brake Rotor Inspection | 53 |
| BRAKE LINE | 73 | Inspection of Hydraulic Unit | 59 |
| BRAKE PEDAL | 63 | Measurement of Wheel Speed Sensor Output Voltage | 57 |
| ELECTRONIC CONTROL UNIT <VEHICLES WITH ABS> | 102 | Parking Brake Lever Stroke Check | 48 |
| FRONT DISC BRAKE | 76 | Parking Brake Switch Check | 49 |
| G-SENSOR <AWD-ABS> | 101 | Proportioning Valve Function Test | 50 |
| HYDRAULIC UNIT <VEHICLES WITH ABS> | 92 | Rear Brake Disc Run-out Check | 57 |
| MASTER CYLINDER | 67 | Rear Brake Disc Run-out Correction | 57 |
| PARKING BRAKES | 103 | Rear Brake Disc Thickness Check | 56 |
| REAR DISC BRAKE | 85 | Rear Disc Brake Pad Check and Replacement | 55 |
| SERVICE ADJUSTMENT PROCEDURES | 47 | Run-out Check | 54 |
| ABS Power Relay Check | 62 | Run-out Correction | 54 |
| Bleeding | 50 | Thickness Check | 55 |
| Brake Booster Operating Inspection | 49 | SPECIAL TOOLS | 6 |
| Brake Fluid Level Sensor Check | 48 | SPECIFICATIONS | 2 |
| Brake Pedal Inspection and Adjustment | 47 | General Specifications | 2 |
| Check Valve Operation Check | 49 | Lubricants | 5 |
| Flat Battery Remedy | 62 | Service Specifications | 4 |
| | | Torque Specifications | 4 |
| | | TROUBLESHOOTING | 7 |
| | | WHEEL SPEED SENSOR <VEHICLES WITH ABS> | 95 |

CAUTION

When servicing brake assemblies or components, do not create dust by sanding, grinding or by cleaning brake parts with a dry brush or with compressed air. A WATER DAMPENED CLOTH SHOULD BE USED. Many brake components contain asbestos fibers which can become air-borne if dust is created during service operations. Breathing dust which contains asbestos fibers can cause serious bodily harm.

SPECIFICATIONS**GENERAL SPECIFICATIONS**
<Non-Turbo>

N05C

| Items | Vehicles without ABS | Vehicles with ABS |
|---|---|---|
| Master cylinder Type I.D. | Tandem type (with level sensor) mm (in.) 22.2 (7/8) | Tandem type (with level sensor) 23.8 (15/16) |
| Brake booster Type Effective dia. of power cylinder | Vacuum type mm (in.) 230 (9.0) | Vacuum type Front side: 180 (7.0) Rear side: 205 (8.0) |
| | Boosting ratio [Brake pedal depressing force] | 5.0 [at 220 N (48 lbs.)] 5.5 [at 220 N (48 lbs.)] |
| Proportioning valve Type Split point Decompression ratio | Dual type 4,200 (597) 0.3 | Dual type 4,200 (597) 3.3 |
| Front brakes Type Disc O.D. Disc thickness Pad thickness Wheel cylinder I.D. Clearance adjustment | Floating caliper, single-piston, ventilated disc (M-R44V) mm (in.) 256 (10.1) mm (in.) 24 (.94) mm (in.) 16.0 (.63) mm (in.) 53.9 (2 1/8) Automatic | Floating caliper, single-piston, ventilated disc (M-R44V) 256 (10.1) 24 (.94) 16.0 (.63) 53.9 (2 1/8) Automatic |
| Rear disc brakes Type Disc O.D. Disc thickness Pad thickness Wheel cylinder I.D. Clearance adjustment | Floating caliper, single-piston, ventilated disc (AD30P) mm (in.) 265 (10.4) mm (in.) 10 (.39) mm (in.) 14.5 (.57) mm (in.) 30.1 (13/16) Automatic | Floating caliper, single-piston, ventilated disc (AD30P) 265 (10.4) 10 (.39) 14.5 (.57) 30.1 (13/16) Automatic |
| Rotor teeth Front wheel side Rear wheel side | — — | 47 47 |
| Speed sensor | — | Magnet coil type |
| Parking brakes' Type Brake lever type Cable arrangement | Mechanical brake acting on rear wheels Lever type V-type | Mechanical brake acting on rear wheels -ever type V-type |

<Turbo>

| Items | FWD | AWD |
|---|---|--|
| Master cylinder | | |
| Type | Tandem type (with level sensor) | Tandem type (with level sensor) |
| I.D. mm (in.) | 25.4 (1) | 25.4 (1) |
| Brake booster | | |
| Type | Vacuum type | Vacuum type |
| Effective dia. of power cylinder mm (in.) | Front side: 188 (7.4) Rear side: 215 (8.5) | Front side: 188 (7.4) Rear side: 215 (8.5) |
| Boosting ratio [Brake pedal depressing force] | 6.0 [at 220 N (48 lbs.)] | 6.0 [at 220 N (48 lbs.)] |
| Proportioning valve | | |
| Type | Dual type | Dual type |
| Split point kPa (psi) | 2,500 (363) | 3,500 (508) |
| Decompression ratio | 0.25 | 0.25 |
| Front brakes | | |
| Type | Floating caliper, single-piston, ventilated disc (M-R46V) | Floating caliper, double-piston ventilated disc (M-R56W) |
| Disc O.D. mm (in.) | 256 (10.1) | 276 (10.9) |
| Disc thickness mm (in.) | 24 (.94) | 24 (.94) |
| Pad thickness mm (in.) | 16.0 (.63) | 16.0 (.63) |
| Wheel cylinder I.D. mm (in.) | 60.3 (2 ³ / ₈) | 41.3 (1 ⁵ / ₈) × 2 |
| Clearance adjustment | Automatic | Automatic |
| Rear disc brakes | | |
| Type | Floating caliper, single-piston, ventilated disc (AD30P) | Floating caliper, single-piston, ventilated disc (AD35P) |
| Disc O.D. mm (in.) | 265 (10.4) | 265 (10.4) |
| Disc thickness mm (in.) | 10 (.39) | 10 (.39) |
| Pad thickness mm (in.) | 14.5 (.57) | 14.5 (.57) |
| Wheel cylinder I.D. mm (in.) | 30.1 (1 ¹³ / ₁₆) | 34.9 (1 ³ / ₈) |
| Clearance adjustment | Automatic | Automatic |
| Rotor teeth* | | |
| Front wheel side | 47 | 47 |
| Rear wheel side | 47 | 47 |
| Speed sensor* | Magnet coil type | Magnet coil type |
| Parking brakes | | |
| Type | Mechanical brake acting on rear wheels | Mechanical brake acting on rear wheels |
| Brake lever type | Lever type | Lever type |
| Cable arrangement | V-type | V-type |

NOTE

The *symbol indicates vehicles with ABS.

SERVICE SPECIFICATIONS

N05CB-

| Items | Specifications | |
|--|-------------------------|-----------------------------------|
| Standard value | | |
| Brake pedal height | mm (in.) | 176–181 (6.9–7.1) |
| Brake pedal free play | mm (in.) | 3–8 (.1–.3) |
| Brake pedal to floorboard clearance | mm (in.) | 80 (3.1) or more |
| Parking brake lever stroke. | | 5–7 notches |
| Output pressure proportioning valve | MPa (psi) | |
| Split point | | |
| <FWD> | | 3.95–4.45 (561–633) |
| <AWD> | | 3.45–3.95 (491–561) |
| Output pressure [input pressure] | | |
| <FWD> | | 5.15–5.65 (732–804) [8.2 (1,163)] |
| <AWD> | | 4.65–5.15 (661–732) [7.7 (1,095)] |
| Disc brake dragging force at hub bolt | N (lbs.) [Nm (ft.lbs.)] | 70 (15) or less [4 (3) or less] |
| Booster push rod to master cylinder piston clearance | mm (in.) | |
| 9 inch brake booster | | 0.8–1.0 (.031–.039) |
| 7 + 8 inch brake booster | | 0.5–0.7 (.020–.028) |
| Speed sensor's internal resistance | kΩ | 0.8–1.2* |
| Clearance between the speed pole piece and the toothed rotor | mm (in.) | 0.3–0.9 (.012–.035)* |
| Limit | | |
| Left/right proportioning valve out pressure difference | MPa (psi) | 0.4 (57) |
| Disc brake pad thickness | mm (in.) | 2.0 (.08) |
| Front disc thickness | mm (in.) | 22.4 (.882) |
| Rear disc thickness | mm (in.) | 8.4 (.331) |
| Disc runout | mm (in.) | |
| Front | | 0.07 (.0028) |
| Rear | | 0.08 (.0031) |
| Hub end play | mm (in.) | 0.2 (.008) |

NOTE

∴ Vehicles with ABS

TORQUE SPECIFICATIONS

N05CC-




| Items | Nm | ft.lbs. |
|--|-------|---------|
| Pedal support bracket installation bolts | 8–12 | 6–9 |
| Pedal support bracket installation nut | 10–15 | 7–11 |
| Pedal rod to pedal support bracket | 17–26 | 12–19 |
| Pedal rod to clutch pedal bracket | 17–26 | 12–19 |
| Clutch pedal bracket installation bolt | 8–12 | 6–9 |
| Turn-over spring mounting bolt | 17–26 | 12–19 |
| Stop lamp switch mounting nut | 10–15 | 7–11 |
| Clutch master cylinder installation nuts | 10–15 | 7–11 |
| Clutch pedal installation nut | 20–25 | 14–18 |
| Lever assembly (A) installation nut | 20–25 | 14–18 |
| Lever assembly (B) installation nut | 20–25 | 14–18 |

| Items | Nm | ft.lbs. |
|--|---------|---------|
| Master cylinder to brake booster | 8-12 | 6-9 |
| Piston stopper bolt | 1.5-3.0 | 1-2 |
| Nipple installation screw | 1.5-3.0 | 1-2 |
| Brake booster installation nuts | 11-17 | 8-12 |
| Fitting | 15-18 | 11-13 |
| Flared brake line nuts | 13-17 | 9-12 |
| Brake hose bracket installation bolts | 17-26 | 12-19 |
| Front disc brake assembly installation bolts | 80-100 | 58-72 |
| Lock pin (front) | 64-86 | 46-62 |
| Guide pin (front) | 64-86 | 46-62 |
| Bleeder screw | 7-9 | 5-7 |
| Wheel bearing nut | 200-260 | 144-188 |
| Dust shield to axle beam | 9-14 | 7-10 |
| Rear disc brake assembly installation bolts | 50-60 | 36-43 |
| Drive shaft to companion flange | 55-65 | 39-47 |
| Companion flange to rear axle shaft | 160-200 | 116-159 |
| Brake hose to caliper body (rear) | 25-35 | 18-25 |
| Lock pin (rear) | 22-32 | 16-23 |
| Guide pin (rear) | 22-32 | 16-23 |
| Spindle lever to parking brake lever | 40-55 | 29-40 |
| Rear speed sensor installation bolt | 9-14 | 7-10 |
| Speed sensor bracket installation bolt | 9-14 | 7-10 |
| Rotor to front hub | 7-11 | 5-8 |
| Rotor to rear hub | 9-14 | 7-10 |

LUBRICANTS

N05CD--

| Items | Specified lubricant |
|-----------------------------------|--|
| Brake fluid | MOPAR Brake Fluid/ Conforming to DOT3 or DOT4 |
| Brake pedal bushing inner surface | |
| Clevis pin and washer | MOPAR Multi-mileage Lubricant |
| Parking brake lever sliding parts | Part No. 2525035 or equivalent |
| Bushing inner surface | |



2. Check the operation of the check valve by using a vacuum pump.

| Vacuum pump connection | Accept/reject criteria |
|---|---|
| Connection at the brake booster side ① | A negative pressure (vacuum) is created and held. |
| Connection at the -intake manifold side ② | A negative pressure (vacuum) is not created. |

Caution

If the check valve is defective, replace it as an assembly unit together with the vacuum hose.

PROPORTIONING VALVE FUNCTION TEST NOSFKJ

1. Connect two pressure gauges, one each to the input side and output side of the proportioning valve, as shown.
2. Air bleed the brake line and the pressure gauge.
3. While gradually depressing the brake pedal, make the following measurements and check to be sure that the measured values are within the allowable range.
 - (1) Output pressure begins to drop relative to input pressure (split point).

Standard value:

| | |
|--------------------|------------------------------------|
| <FWD> | 3.95-4.45 MPa (561-633 psi) |
| <AWD> | 3.45-3.95 MPa (491-561 psi) |

- (2) Output fluid pressure when input fluid pressure are as follows.

Standard value:

| | |
|--------------------|--|
| <FWD> | 5.15-5.65 MPa (732-804 psi) [at 8.2 MPa (1,163 psi)] |
| <AWD> | 4.65-5.15 MPa (661-732 psi) [at 7.7 MPa (1,095 psi)] |

- (3) Output pressure difference between left and right brake lines

Limit: 0.4 MPa (57 psi)

4. If the measured pressures are not within the permissible ranges, replace the proportioning valve.


BLEEDING

NOSFYAN


When the master cylinder is empty of brake fluid, bleed air from the master cylinder by proceeding with procedures (1) thru (6). (Because this master cylinder is not equipped with a check valve.)

When brake fluid remains in the master cylinder, proceed with step (6).

- (1) Disconnect the brake tube from the master cylinder.
- (2) Two persons should conduct the air bleeding, one person slowly depressing the brake pedal and holding the pedal depressed.



14A0416



14A0454

(3) In this condition, the other person should use a finger to close the outlet part of the master cylinder, and then the first person should release the brake pedal.

(4) Steps (2) and (3) should be repeated three or four times, and then the master cylinder should be filled with brake fluid to the specified level.

NOTE

The air is completely bled from the master cylinder by steps (1) to (4).

(5) Connect the brake tube to the master cylinder.

(6) Start the engine; then, in the sequence shown in the illustration, bleed the air from each wheel cylinder.

Specified brake fluid: MOPAR Brake Fluid/ Conforming to DOT3 or DOT4

Caution

1. Use the specified brake fluid. Avoid using a mixture of the specified brake fluid and other fluid.
2. If brake fluid is exposed to the air, it will absorb moisture; as water is absorbed from the atmosphere, the boiling point of the brake fluid will decrease and the braking performance will be seriously impaired. For this reason, use a hermetically sealed 1 lit. (1.06 qt.) or 0.5 lit. (0.52 qt.) brake fluid container.
3. Firmly close the cap of the brake fluid container after use.
4. For vehicles with the anti-lock braking system, be sure to install a filter to the master cylinder reservoir tank when supplying brake fluid.

ORDINARY AIR-BLEEDING PROCEDURES

(1) Depress the brake pedal several times until resistance is felt; then, with the pedal depressed, loosen the bleeder screw 1/3 to 1/2 turn and then tighten it before the fluid pressure is all gone.

(2) Release the brake pedal. Repeat this procedure until there are no more air bubbles in the brake fluid.

FRONT DISC BRAKE PAD CHECK AND REPLACEMENT

N05F0AF

NOTE


The brake pads have wear indicators that contact the brake disc when the brake pad thickness becomes 2 mm (.08 in.), and emit a squealing sound to warn the driver.

1. Check brake pad thickness through caliper body check port.


Standard value: 10.0 mm (.39 in.)
Limit: 2.0 mm (.08 in.)

Caution

1. When the limit is exceeded, replace the pads at both sides, and also the brake pads for the wheels on the opposite side at the same time.
2. If there is a significant difference in the thicknesses of the pads on the left and right sides, check the sliding condition of the piston, lock pin sleeve and guide pin sleeve.




14G0017



14 L0169


14L0290



2. Remove guide pin. Lift caliper assembly and retain with wires.

Caution

Do not wipe off the special grease that is on the guide pin or allow it to contaminate the guide pin.




3. Remove the following parts from caliper support.

- ① Pad & wear indicator assembly
- ② Pad assembly
- ③ Clip
- ④ Inner shim
- ⑤ Outer shim


1 -piston type

14L0291




14N0284

P-piston type



14N0283




4. With the pad removed, use a spring balance to measure the rotation sliding resistance of the hub in the forward direction.

NOTE



Tighten the nuts in order to secure the disc to the hub.

5. Securely attach the pad clip to the caliper support.



6. Clean piston and insert into cylinder with tool.

7. Be careful that the piston boot does not become caught, when lowering the caliper assembly and install the guide pin.



8. Apply repair kit grease to both sides of the inner shims.

**Specified grease: Brake grease SAE J310,
NLGI No.1**

Caution

1. Make sure that the friction surfaces of pads and brake discs are free of grease and other contaminants.
2. The grease should never squeeze out from around the shim.

9. Check the disc brake drag force as follows.

- (1) Start the engine, and after depressing the brake pedal hard two or three times, stop the engine.
- (2) Turn brake disc forward 10 times.
- (3) Use a spring balance to measure the rotation Sliding resistance of the hub in the forward direction.

(4) Calculate the drag torque of the disc brake (difference between measured values in 3 and 4).

Standard value: 70 N (15.4 lbs.) or less

10. If the disc brake drag force exceeds the standard value, disassemble piston and clean the piston. Check for corrosion or worn piston seal, and check the sliding condition of the lock pin and guide pin.


FRONT DISC BRAKE ROTOR INSPECTION

CAUTION


When servicing disc brakes, it is necessary to exercise caution to keep the disc brakes within the allowable service values in order to maintain normal brake operation.

Before re-finishing or re-processing the brake disc surface, the following conditions should be checked.


| Inspection items | Remarks. |
|--|---|
| Scratches, rust, saturated lining materials and wear | <ul style="list-style-type: none"> If the vehicle is not driven for a certain period, the sections of the discs that are not in contact with lining will become rusty, causing noise and shuddering. If grooves resulting from excessive disc wear and scratches are not removed prior to installing a new pad assembly, there will momentarily be inappropriate contact between the disc and the lining (pad). |
| Run-out or drift | Excessive run-out or drift of the discs will increase the pedal depression resistance due to piston knock-back. |
| Change in thickness (parallelism) | If the thickness of the disc changes, this will cause pedal pulsation, shuddering, and surging. |
| Inset or warping (flatness) | Overheating and improper handling while servicing will cause inset or warping. |




14A0020




14R0310



14A0391



14A0408



14A0407

RUN-OUT CHECK

NO5FTAB

1. Remove the caliper support; then raise the caliper assembly upward and secure by using wire.
2. Inspect the disc surface for grooves, cracks, and rust. Clean the disc thoroughly and remove all rust.

3. Place a dial gauge approximately 5 mm (.2 in.) from the outer circumference of the brake disc, and measure the run-out of the disc.

Limit: 0.07 mm (.0028 in.)

NOTE

Tighten the nuts in order to secure the disc to the hub..

RUN-OUT CORRECTION

NO5FTAB

1. If the run-out of the brake disc is equivalent to or exceeds the limit specification, change the phase of the disc and hub, and then measure the run-out again.
- (1) Before removing the brake disc, chalk both sides of the wheel stud on the side at which run-out is greatest.


- (2) Remove the brake disc, and then place a dial gauge as shown in the illustration; then move the hub in the axial direction and measure the play.

Limit: 0.2 mm (.008 in.)

If the play is equivalent to or exceeds the limit, disassemble the hub knuckle and check each part.

- (3) If the play does not exceed the limit specification, and then check the run-out of the brake disc once again. Mount the brake disc on the position dislocated from the chalk mark.

2. If the run-out cannot be corrected by changing the phase of the brake disc, replace the disc or turn rotor with on the car type brake lathe (MAD DL-8700PF or equivalent).'



14A0022

THICKNESS CHECK

1. Using a micrometer, measure disc thickness at eight positions, approximately 45° apart and 10 mm (.39 in.) in from the outer edge of the disc.

Brake Disc Thickness


Standard value: 24 mm (.94 in.)

Limit: 22.4 mm (.882 in.)

Thickness Variation (At least 8 position)

The *difference between any thickness measurements should not be more than 0.015 mm (.0006 in.).

2. If the disc is beyond the limits for thickness, remove it and install a new one. If thickness variation exceeds the specification, replace the disc or turn rotor with on the car type brake lathe (MAD, DL-8700PF or equivalent).



14A0281

REAR DISC BRAKE PAD CHECK AND REPLACEMENT

1. Check brake pad thickness through caliper body port.

Limit: 2.0 mm (.08 in.)


Caution

1. When the limit is exceeded, replace the pads at both sides, and also the brake pads for the wheels on the opposite side at the same time.
2. If there is a significant difference in the thicknesses of the pads on the left and right sides, check the sliding condition of the piston, 'lock pin sleeve and guide pin sleeve.'
2. Loosen the parking brake cable (from the vehicle interior), and disconnect the parking brake end installed to the rear brake assembly.
3. Remove lock pin. Lift caliper assembly and retain with wires.

Caution

Do not wipe off the special grease that is on the lock pin or allow it to contaminate the lock pin.

4. Remove the following parts from caliper support.







(1) Outer shim

(2) Pad assembly

(3) Pad clips C

(4) Pad clips B



SERVICE POINTS OF REMOVAL

6. REMOVAL OF VACUUM HOSE WITH CHECK VALVE

NOTE

Since the check valve is fit to the vacuum hose, replace the check valve as an assembly unit together with the vacuum hose if the check valve is defective.

SERVICE POINTS OF INSTALLATION

10. APPLICATION OF GREASE TO CLEVIS PIN/9. WASHER

After applying the specified grease to the clevis pin and washer, insert the clevis pin and bend the cotter pin tightly.

Grease: MOPAR Multi-mileage Lubricant
Part No. 2525035 or equivalent

7. APPLICATION OF SEALANT TO FITTING

When installing the vacuum hose fitting, apply semi-drying sealant to its threaded portion.

6. INSTALLATION OF VACUUM HOSE WITH CHECK VALVE

- (1) Attach the vacuum hose so that it may be inserted to a dimension illustrated.

Caution

Prevent interference between the check valve and brake booster.

- (2) The vacuum hose at the engine should be securely connected until it contacts the hexagonal edge of the fitting, and then should be secured by the hose clip.

BRAKE LINE REMOVAL AND INSTALLATION


NOSKA--

Vehicles without ABS

Pre-removal Operation *Draining of Brake Fluid

Post-installation Operation

- Supplying Brake Fluid
- Bleeding (Refer to P.5-50.)





Flared brake line nuts

13-17 Nm
9-12 ft.lbs.




14F038




<FWD>


17-26 Nm
12-19 ft.lbs.



17-26 Nm
12-19 ft.lbs.



17-26 Nm
12-19 ft.lbs.



14


- 1. Front brake hose
- 2. Strut brake tube
- 3. Front brake tube (R.H.)
- 4. Front brake tube (L.H.)
- 5. Brake tube (A)
- 6. Brake tube (B)
- 11. Main brake tube (R.H.)
- 12. Main brake tube (L.H.)
- 13. Proportioning valve
- 14. Rear brake hose
- 15. Rear axle brake tube
- 16. Bracket

14A0583

Vehicles with ABS

Pre-removal Operation
*Draining of Brake Fluid

Post-installation Operation
① Supplying Brake Fluid
② Bleeding (Refer to P.5-50.)




Flared brake line nuts

13-17 Nm
9-12 ft.lbs.




14F038




25-35 Nm
18-25 ft.lbs.

Connecting part of hydraulic unit




14A0572




17-26 Nm
12-19 ft.lbs.


25-35 Nm
18-25 ft.lbs.



17-26 Nm
12-19 ft.lbs.




17-26 Nm
12-19 ft.lbs.



13

- ◆◆ 1. Front brake hose
- 2. Strut brake tube
- 3. Front brake tube (R.H.)
- 4. Front brake tube (L.H.)
- 5. Brake tube (A)
- 6. Brake tube (B)
- 7. Rear brake tube (R.H.)
- 8. Rear brake tube (L.H.)
- 9. Hydraulic unit
- 10. Main brake tube (R.H.)
- 11. Main brake tube (L.H.)
- 12. Proportioning valve
- ◆◆ 13. Rear brake hose
- 14. Rear axle brake tube
- 15. Bracket

14A0585



SERVICE POINTS OF REMOVAL

N05K8AMa

1. REMOVAL OF FRONT BRAKE HOSE / 13. REAR BRAKE HOSE

- (1) Holding the lock nut on the brake hose side, loosen the flared brake line nut.
- (2) Pull off the brake hose clip and remove the brake hose from the bracket.


12. REMOVAL OF PROPORTIONING VALVE

Do not disassemble the proportioning valve because its performance depends on the set load of the spring.

INSPECTION

N05KCAA

- Check the brake tubes for cracks, crimps and corrosion.
- Check the brake hoses for cracks, damage and leakage.
- Check the flared brake line nuts for damage and leakage.



SERVICE POINTS OF INSTALLATION

N05KDAJ


9. CONNECTION OF TUBE TO HYDRAULIC UNIT

Connect the tubes to the hydraulic unit as shown in the illustration.

FRONT DISC BRAKE

REMOVAL AND INSTALLATION

N05LA...




Removal steps

➡ ● 1. Connection for the brake hose and the
brake tube
● + 2. Front brake assembly
3. Brake disc

NOTE

(1) Reverse the removal procedures to reinstall.
(2) ➡: Refer to "Service Points of Removal".
(3) ● +: Refer to "Service Points of Installation".

14N0140
14A0420

N05LBAF

SERVICE POINTS OF REMOVAL

1. DISCONNECTION OF BRAKE HOSE

Holding the nut on the brake hose side. Loosen the flared
brake line nut.

INSPECTION

INSPECTION OF BRAKE DISC

- Check disc for wear. (Refer to P.5-55, Thickness Check.)
- Check disc for runout. (Refer to P.5-54, Run-out Check.)
- Check disc for damage.

N05LCAD

SERVICE POINTS OF INSTALLATION

2. INSTALLATION OF FRONT BRAKE ASSEMBLY




Measure the disc brake drag force after installation of the brake assembly by the following procedure.

- (1) With the brake assembly removed, use a spring balance to measure the rotation sliding resistance of the hub in the forward direction.

NOTE

Tighten the nuts in order to secure the disc to the hub.

- (2) After installing the caliper support to the knuckle, expand the piston, and then install the caliper body.




- (3) Start the engine, and after depressing the brake pedal hard two or three times, stop the engine.
- (4) Turn brake disc forward 10 times.
- (5) Use a spring balance to measure the rotation sliding resistance of the hub in the forward direction.
- (6) Calculate the drag torque of the disc brake (difference between measured values in 5 and 1).

Standard value: 70 N (15.4 lbs.) or less

- (7) If the disc brake drag force exceeds the standard value, disassemble piston and clean the piston. Check for corrosion or worn piston seal.

DISASSEMBLY AND REASSEMBLY

< 1 -piston type>



Caliper assembly disassembly steps

- ◆◆ 1. Guide pin
- + 2. Lock pin
- + 3. Bushing
- 4. Caliper support (Pad, clip, shim)
- + 5. Guide pin boot
- ◆◆ 6. Lock pin boot
- ◆◆ 7. Boot ring
- ◆◆ 8. Piston boot
- *** 9. Piston
- ◆◆ ● 10. Piston seal
- 1. Brake hose
- + 12. Caliper body


Pad assembly disassembly steps

- ◆◆ 1. Guide pin
- + 2. Lock pin
- ◆◆ 3. Bushing
- 4. Caliper support (Pad, clip, shim)
- 13. Pad and wear indicator assembly
- 14. Pad assembly
- ◆◆ 15. Outer shim
- 16. Clip
- ◆◆ 17. Inner shim


NOTE

- (1) Reverse the disassembly procedures to reassemble.
- (2) ◆◆: Refer to "Service Points of Disassembly".
- (3) ● +: Refer to "Service Points of Reassembly".
- (4) N: Non-reusable parts


Brake caliper kit




Pad repair kit



Seal and boots repair kit






SERVICE POINTS OF DISASSEMBLY

N05LFAJ

When disassembling the front disc brakes, disassemble both sides (left and right) as a set.

7. REMOVAL OF BOOT RING

Remove boot ring with flat tip (–) screwdriver.




8. REMOVAL OF PISTON BOOT/9. PISTON

Protect caliper body with cloth. Blow compressed air through brake hose to remove piston boot and piston.

Caution

Blow compressed air gently.



10. REMOVAL OF PISTON SEAL

(1) Remove piston seal with finger tip.

Caution

Do not use flat tip (–) screwdriver or other tool to prevent damage to inner cylinder.


(2) Clean piston surface and inner cylinder with trichloroethylene, alcohol or specified brake fluid.

**Specified brake fluid: MOPAR Brake Fluid/
Conforming to DOT3 or DOT4**

INSPECTION

N05LG AJ






- Check cylinder for wear, damage or rust.
- Check piston surface for wear, damage or rust.
- Check caliper body guide pin or lock pin for wear.
- Check pad for damage or adhesion of grease, check backing metal for damage.



PAD WEAR CHECK

Measure thickness at the thinnest and worn area of the pad. Replace pad assembly when pad thickness is less than the limit value.

Limit value: 2.0 mm (.08 in.)



SERVICE POINTS OF REASSEMBLY

NOSLHA

17. INSTALLATION OF INNER SHIM/15. OUTER SHIM

Coat the mounting surfaces of the pad and inner shim and the mounting surface of the inner shim and outer shim with repair kit grease, and assemble them. Coat grease with care to prevent swelling.

Specified grease: Repair kit grease (orange)

Caution

Prevent oily materials and other dirt from sticking to the friction surfaces of the pad and brake disc.

12. APPLICATION OF BRAKE FLUID TO CALIPER BODY

Apply specified brake fluid to inner cylinder.

Specified brake fluid: MOPAR Brake Fluid/Conforming to DOT3 or DOT4

10. INSTALLATION OF PISTON SEAL

Install piston seal in cylinder groove.

Caution

Do not wipe special grease on piston seal.

9. INSTALLATION OF PISTON

(1) Apply specified brake fluid to piston. Insert into cylinder without twisting.

Specified brake fluid: MOPAR Brake Fluid/Conforming to DOT3 or DOT4


(2) Fill piston edge with specified grease. Install piston boots.

Specified grease: Repair kit grease (orange)

6. APPLICATION OF GREASE TO LOCK PIN BOOT/5. GUIDE PIN BOOT/3. BUSHING

Grease parts as illustrated with specified grease.


Specified grease: Repair kit grease (orange)

**2. INSTALLATION OF LOCK PIN/ 1. GUIDE PIN**


Install the guide pin and lock pin so the identification mark on the caliper body and head mark on the guide pin and lock pin are aligned.

DISASSEMBLY AND REASSEMBLY

<2-piston type>



Brake caliper kit





Caliper assembly disassembly steps

- + 1. Guide pin
- ➡➡ 2. Lock pin
- 3. Bushing
- 4. Caliper support (pad, clip, shim)
- ➡➡ 5. Boot
- 6. Boot ring
- 7. Piston boot
- ➡➡➡ 8. Piston
- ➡➡ ● + 9. Piston seal
- + 0. Caliper body

Pad repair kit

Seal and boots repair kit



Pad assembly disassembly steps


- ◆◆ 1. Guide pin
- + 2. Lock pin
- ◆◆ 3. Bushing
- 4. Caliper support (pad, clip, shim)
- 11. Pad assembly (with wear indicator)
- 12. Pad assembly
- +13. Outer shim
- 414. Inner shim
- 15. Clip

NOTE

(1) Reverse the disassembly procedures to reassemble.
(2) d*: Refer to "Service Points of Disassembly".
(3) ● 4: Refer to "Service Points of Reassembly".
(4) N: Non-reusable parts


N05LE

N05LFCB



14A0553

14A0552



14A0551

SERVICE POINTS OF DISASSEMBLY

When disassembling the rear disc brakes, disassemble both sides (left and right) as a set.

7. REMOVAL OF PISTON BOOT/8. PISTON

Pump in compressed air through the brake hose installation hole and remove the pistons and piston boot.

Caution

When removing the pistons, be sure to use the handle of a plastic hammer and adjust the height of the two pistons while pumping in air slowly in so that the pistons protrude evenly.

Do not remove one piston completely before trying to remove the other piston because it will become impossible to remove the second piston.

9. REMOVAL OF PISTON SEAL

(1) Remove piston seal with finger tip.

Caution

Do not use a screwdriver or other tool to prevent damage to inner cylinder.

(2) Clean piston surface and inner cylinder with trichloroethylene, alcohol or specified brake fluid.

Specified brake fluid: DOT3 or DOT4

INSPECTION

N05LGCB


- Check cylinder for wear, damage or rust.
- Check piston surface for wear, damage or rust.
- Check caliper body or sleeve for wear.
- Check pad for damage or adhesion of grease, check backing metal for damage.
- Check wear indicator for damage.

PAD WEAR CHECK






Measure thickness at the thinnest and worn area of the pad. Replace pad assembly when pad thickness is less than the limit value.

Standard value: 10 mm (.39 in.)

Limit: 2.0 mm (.08 in.)



14U0072



SERVICE POINTS OF REASSEMBLY

7. INSTALLATION OF INNER SHIM/13. OUTER SHIM

Coat the mounting surfaces of the pad and inner shim and the mounting surface of the inner shim and outer shim with repair kit grease, and assemble them.

Coat grease with care to prevent swelling.

Specified grease: Repair kit grease (orange)

Caution

Prevent oily materials and other dirt from sticking to the friction surfaces of the pad and brake disc.

12. APPLICATION OF BRAKE FLUID TO CALIPER BODY

Apply specified brake fluid to inner cylinder.

Specified brake fluid: MOPAR Brake Fluid/Conforming to DOT3 or DOT4

10. INSTALLATION OF PISTON SEAL

Install piston seal in cylinder groove.

Caution

Do not wipe special grease on piston seal.

9. INSTALLATION OF PISTON

(1) Apply specified brake fluid to piston. Insert into cylinder without twisting.

Specified brake fluid: MOPAR Brake Fluid/Conforming to DOT3 or DOT4


(2) Fill piston edge with specified grease. Install piston boots.

Specified grease: Repair kit grease (orange)

6. APPLICATION OF GREASE TO BOOT/3. BUSHING

Grease parts as illustrated with specified grease.

Specified grease: Repair kit grease (orange)



2. INSTALLATION OF LOCK PIN/I. GUIDE PIN

Install the guide pin and lock pin so the identification mark on the caliper body and head mark on the guide pin and lock pin are aligned.

REAR DISC BRAKE

N05MA--

REMOVAL AND INSTALLATION


Pre-removal Operation

- Draining of Brake Fluid

Post-installation Operation

- *Supplying Brake Fluid
- Bleeding
(Refer to P.5-50.)
- *Adjustment of Parking Brake Lever Stroke
(Refer to P.5-48.)

<FWD>




Removal steps

- ↔ 1. Parking brake cable connection
- ↔ 2. Brake hose connection
- 3. Rear brake assembly
- 4. Rear brake disc
- 5. Hubcap
- 6. Wheel bearing nut
- 7. Washer
- 8. Rear speed sensor bracket
<Vehicles with ABS>
- 9. Rear hub assembly
- 14. Dust shield

NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ↔ : Refer to "Service Points of Removal".
- (3) ● + : Refer to "Service Points of Installation".
- (4) ■ : Non-reusable parts

<AWD>



14A0669

Removal steps

- 1. Parking brake cable connection
- 2. Brake hose connection
- 3. Rear brake assembly
- 4. Rear brake disc
- 5. *10. Self locking nut
- 6. *11. Companion flange
- 7. 12. Rear speed sensor
<Vehicles with ABS>
- 8. 13. Rear axle shaft
- 9. 14. Dust shield

Pre-removal Operation

Post-installation Operation


Post-installation Operation

- Supplying Brake Fluid
- Bleeding
(Refer to P.5-50.)
- Adjustment of Parking Brake Lever
Stroke
(Refer to P.5-48.)

NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) Refer to "Service Points of Removal".
- (3) Refer to "Service Points of Installation".
- (4) Non-reusable parts


N05MBAD



SERVICE POINTS OF -REMOVAL


2. DISCONNECTION OF BRAKE HOSE

Holding the lock nut on the brake hose side, loosen the flared brake line nut.



10. REMOVAL OF SELF LOCKING NUT

Using end yoke holder, secure and hold the rear axle shaft, and remove the self locking nut.



13. REMOVAL OF REAR AXLE SHAFT

Using the special tool, remove the rear axle shaft.

INSPECTION

N05MDABa

- Check disc for wear. (Refer to P.5-56, Rear Brake Disc Thickness Check.)
- Check disc for runout. (Refer to P.5-57, Rear Brake Disc Run-out Check.)
- Check disc for damage.

SERVICE POINTS OF INSTALLATION


N05MCAF


13. INSTALLATION OF REAR AXLE SHAFT/11. COMPANION FLANGE/10. SELF LOCKING NUT

- (1) Provisionally install the rear axle shaft to the trailing arm.
- (2) Install the companion flange to the rear axle shaft, and install the self locking nut.
- (3) Then, using end yoke holder, secure and hold the rear axle shaft, and tighten the self locking nut.

6. INSTALLATION OF WHEEL BEARING NUT

After tightening the wheel bearing nut, align with the indentation in the spindle, and then crimp.






SERVICE POINTS OF REMOVAL


2. DISCONNECTION OF BRAKE HOSE

Holding the lock nut on the brake hose side, loosen the flared brake line nut.



10. REMOVAL OF SELF LOCKING NUT

Using end yoke holder, secure and hold the rear axle shaft, and remove the self locking nut.




13. REMOVAL OF REAR AXLE SHAFT

Using the special tool; remove the rear axle shaft.

INSPECTION


- Check disc for wear. (Refer to P.5-56, Rear Brake Disc Thickness Check.)
- Check disc for runout. (Refer to P.5-57, Rear Brake Disc Run-out Check.)
- Check disc for damage.



SERVICE POINTS OF INSTALLATION

13. INSTALLATION OF REAR AXLE SHAFT/11. COMPANION FLANGE/10. SELF LOCKING NUT

- (1) Provisionally install the rear axle shaft to the trailing arm.
- (2) Install the companion flange to the rear axle shaft, and install the self locking nut.
- (3) Then, using end yoke holder, secure and hold the rear axle shaft, and tighten the self locking nut.



6. INSTALLATION OF WHEEL BEARING NUT



After tightening the wheel bearing nut, align with the indentation in the spindle, and then crimp.

WHEEL AND TIRE

REMOVAL AND INSTALLATION


N22GA--

Steel type




11A0385

Aluminium type



11A0405




11A0384

Removal steps


- 1. Wheel cover <Vehicles with wheel cover>
- 2. Center cover <Vehicles with center cover>
- + 3. Wheel nuts
- 4. Center cap <Vehicles with center cap>
- 5. Spring
- 6. Ornament
- 7. Balance weight
- 8. Tire
- 9. Wheel

NOTE

(1) Reverse the removal procedures to reinstall.
 (2) ● 4: Refer to "Service Points of Installation".



11A0406



N22GDABA

SERVICE POINT OF INSTALLATION

3. INSTALLATION OF WHEEL NUTS

On the high speed tire (205/55R16 88V) vehicle, the left and right tires are respectively specified. Attach the tires as follows:

Observe the wheel in the P direction as illustrated, and the direction characters will be found.

Attach the (△△ ROTATION LEFT SIDE) tire on the left wheel, and the (ROTATION RIGHT SIDE DD) tire on the right wheel.

INSTRUCTIONS FOR ALUMINUM TYPE WHEELS

N22GFAA

1. Aluminum is vulnerable to alkalies. If a vehicle washing detergent has been used, or salt from sea water or road chemicals has adhered, wash the vehicle as soon as possible. After washing the vehicle, apply body or wheel wax to the aluminum type wheels to prevent corrosion.
2. When cleaning the vehicle with steam, do not direct steam onto the aluminum type wheels. When tightening nuts for aluminum type wheels, particularly observe the following:
 - (1) Clean the hub surface of aluminum type wheels.
 - (2) After finger-tightening wheel nuts, tighten them to specifications.
 - (3) Do not use an impact wrench or push the wrench by foot to tighten the wheel nuts.
 - (4) Do not apply oil to the threaded portions.

INSTRUCTIONS FOR TIRE CHAINS AND SNOW TIRES

N22GGAA

1. Use tire chains only on front wheels. Do not use tire chains on rear wheels.
2. When using snow tires, use them on all four wheels for maneuverability and safety.

INSTRUCTIONS FOR COMPACT SPARE TIRE

N22GHA

1. The compact spare tire is designed to save space in the luggage compartment, and its lighter weight makes it easier to use if a flat tire occurs.
2. The following instructions for the compact spare tire should be observed.
 - (1) Check the inflation pressure after installing the spare, and adjust to the specified pressure.
 - (2) Avoid driving through automatic car washes and over obstacles that could possibly damage the vehicle's undercarriage. Because the tire is smaller than the original tire, car ground clearance is slightly reduced.
 - (3) The compact spare tire should not be used on any other wheels, nor should standard tires, snow tires, wheel covers or trim rings be used with the compact spare wheel. If such use is attempted, damage to these items or other vehicle components may occur.

BODY

CONTENTS


N23AA--

| | | | |
|---|----|--------------------------------------|----|
| AERO PARTS..... | 72 | QUARTER WINDOW GLASS..... | 59 |
| CENTRAL DOOR LOCKING SYSTEM | 68 | REAR BUMPER | 41 |
| DOOR ASSEMBLY..... | 61 | REAR SEAT | 93 |
| DOOR GLASS AND REGULATOR..... | 64 | SEAT BELT | 94 |
| DOOR HANDLE AND LATCH | 67 | SERVICE ADJUSTMENT PROCEDURES..... | 30 |
| DOOR MIRROR..... | 70 | Door Adjustment | 31 |
| DOOR MOULDING AND DRIP LINE WEATHERSTRIP | 70 | Door Glass Adjustment | 31 |
| DOOR RUNCHANNEL | 69 | Door Inside Handle Play Check | 31 |
| DOOR TRIM AND WATERPROOF FILM..... | 63 | Door Outside Handle Play Check | 31 |
| ELECTRIC REMOTE CONTROLLED MIRROR SWITCH..... | 71 | Floor Pan Inspection | 32 |
| FENDER..... | 49 | Fuel Filler Door Adjustment | 30 |
| FLOOR CONSOLE | 84 | Hood Adjustment | 30 |
| FRONT BUMPER | 37 | Liftgate Adjustment | 30 |
| FRONT SEAT | 90 | Water Test | 32 |
| FUEL TANK FILLER DOOR | 36 | SPECIAL TOOLS | 5 |
| GARNISHES | 45 | SPECIFICATIONS | 2 |
| HEADLINING | 89 | General Specifications | 2 |
| HOOD..... | 33 | Lubricants | 5 |
| INSTRUMENT PANEL,..... | 79 | Sealants and Adhesives | 5 |
| LIFTGATE | 35 | Service Specifications | 3 |
| LIFTGATE WINDOW GLASS | 60 | Torque Specifications | 3 |
| LOOSE PANEL..... | 51 | SUNROOF | 77 |
| MOULDING | 46 | TRIMS | 85 |
| POWER WINDOW..... | 65 | TROUBLESHOOTING | 6 |
| | | WINDOW GLASS..... | 52 |
| | | WINDSHIELD..... | 56 |

HOOD

REMOVAL AND INSTALLATION

N23HAASa



Removal

- 1. Bumper
- 2. Hood weatherstrip
- 3. Hood front weatherstrip
- 4. Heat protector
- 5. Hood weatherstrip
- 6. Bumper
- 7. Hood support rod
- 8. Bumper
- 9. Bumper
- 10. Bumper bracket
- 11. Hood lock release handle
- 12. Front fascia bracket
- 13. Clip
- 14. Hood latch

Hood lock release cable removal steps

- 11. Hood lock release handle
- 12. Front fascia bracket
- 13. Clip
- 14. Hood latch
- 15. Hood lock release cable

Hood removal steps

- 16. Connection for washer tube and nozzle
- 17. Hood

Hood hinge removal steps

- 16. Connection for washer tube and nozzle
- 17. Hood
- Windshield wiper arms (Refer to GROUP 5 1 - Windshield Wiper.)
- 18. Front deck garnish
- 19. Hood hinge


NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ● : Refer to "Service Points of Installation".

SERVICE POINTS OF INSTALLATION**19. APPLICATION OF GREASE TO HOOD HINGE/14.
HOOD LATCH/I 1. HOOD LOCK RELEASE HANDLE**

Apply multipurpose grease to all moving parts.

**Grease: MOPAR Multipurpose Grease Part No
2932524 or equivalent**

**6. INSTALLATION OF BUMPER**

Install the bumper so that the amount of projection from the front end upper bar is as shown in the illustration.


LIFTGATE

REMOVAL AND INSTALLATION

N230AAT

Post-installation Operation

- Liftgate Adjustment
(Refer to P.23-30.)



18A0473

18A0973

Removal

1. Bumper
2. Liftgate damper (upper)
3. Liftgate outer weatherstrip
4. Liftgate damper (lower)
5. Liftgate opening weatherstrip

Liftgate hinge removal steps

- Headlining (Refer to P.23-89.)
- 6. Connection for rear washer tube
- Center pillar trim (driver's side) { (Refer to
- Quarter trim (driver's side) } P.23-85.)
- 7. Connection for liftgate wiring harness
- 8. Liftgate
- 9. Liftgate hinge

Liftgate removal steps

6. Connection for rear washer tube
- Center pillar trim (driver's side) { (Refer to
- Quarter trim (driver's side) } P.23-85.)
7. Connection for liftgate wiring harness
8. Liftgate

Liftgate lock release cable removal steps

- Rear seat (Refer to P.23-93.)
- Scuff plate (driver's side)
- Quarter trim (driver's side) { (Refer to
- Rear end trim } P.23-85.)
- Rear side trim
- 10. Liftgate latch
- 13. Release handle cover
- 14. Liftgate lock release handle
- 15. Liftgate lock release cable

Liftgate lock release handle removal steps

- Scuff plate (driver's side)
(Refer to P.23-85.)

- 13. Release handle cover
- * 14. Liftgate lock release handle

Liftgate latch removal steps

- Rear end trim (Refer to P.23-85.)
- * 10. Liftgate latch

Liftgate lock cylinder removal steps

- Rear end trim (Refer to P.23-85.)
- 11. Retainer
- 12. Liftgate lock cylinder

Liftgate striker removal steps

- Liftgate trim (Refer to P.23-86.)
- 16. Liftgate striker

Liftgate stopper removal steps

- Rear side trim (Refer to P.23-85.)
- 17. Liftgate stopper



NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ◀▶ : Refer to "Service Points of Removal".
- (3) ◀▶ : Refer to "Service Points of Installation".

SERVICE POINTS OF REMOVAL

17. REMOVAL OF LIFTGATE STOPPER

Caution

1. Never try to disassemble the liftgate gas spring or burn it.
2. Always bore a hole in the gas spring to release the interior gas before the spring is discarded.

SERVICE POINTS OF INSTALLATION

14. APPLICATION OF GREASE TO LIFTGATE LOCK RELEASE HANDLE/ 10. LIFTGATE LATCH

Apply multipurpose grease to all moving parts

Grease: MOPAR Multipurpose Grease Part No. 2932524 or equivalent

FUEL TANK FILLER DOOR REMOVAL AND INSTALLATION


N23JAAQ

Pre-removal Operation

- Removal of Rear Seat (Refer to P.23-93.)
- Removal of Rear Side Trim, Quarter Trim and Scuff Plate. (Refer to P.23-85.)

Post-installation Operation

- Installation of Rear Side Trim Quarter Trim and Scuff Plate (Refer to P.23-85.)
- Installation of Rear Seat (Refer to P.23-93.)
- Fuel Filler Door Adjustment (Refer to P.23-30.)



18A0462

Removal steps

- ◆ 1. Fuel filler door
- 2. Fuel filler door hook
- 3. Release handle cover
- * 4. Fuel filler door lock release handle
- 5. Fuel filler door lock release cable

NOTE

(1) Reverse the removal procedures to reinstall.
(2) ◆: Refer to "Service Points of Installation".

SERVICE POINTS OF INSTALLATION

4. APPLICATION OF GREASE TO FUEL FILLER DOOR LOCK RELEASE HANDLE/1. FUEL FILLER DOOR

Apply multipurpose grease to all moving parts


Grease: MOPAR Multipurpose Grease Part No. 2932524 or equivalent

FRONT BUMPER

N23ZAAY

REMOVAL AND INSTALLATION

<EAGLE Talon>



Front bumper assembly removal steps

1. Splash shield mounting clip
2. Front combination light
3. Headlight
4. Fog light
5. Center upper plate
6. Front fascia bracket
7. Clip
8. License plate bracket
9. Front bumper assembly (No. 1 O-I 3)
10. Front bumper reinforcement
11. Fog light bracket
12. Side upper plate
13. Front bumper fascia


Front bumper fascia removal steps

1. Splash shield mounting clip
2. Front combination light
3. Headlight
4. Fog light
5. Center upper plate
6. Front fascia bracket
7. Clip
8. License plate bracket
12. Side upper plate
13. Front bumper fascia

NOTE

Reverse the removal procedures to reinstall.

<PLYMOUTH Laser>

**Front bumper assembly removal steps**

1. Splash shield mounting clip
2. Front combination light
3. Headlight
4. Fog light
5. Center upper plate
6. Front fascia bracket
7. Clip
8. License plate bracket
9. Front bumper assembly (No. 1 O-I 3)
10. Front bumper reinforcement
11. Fog light bracket
12. Side upper plate
13. Front bumper fascia

Front bumper fascia removal steps


1. Splash shield mounting clip
2. Front combination light
3. Headlight
4. Fog light
5. Center upper plate
6. Front fascia bracket
7. Clip
8. License plate bracket
12. Side upper plate
13. Front bumper fascia

NOTE

Reverse the removal procedures to reinstall.

DISASSEMBLY AND REASSEMBLY

<EAGLE Talon>





18A0933

Disassembly steps

➡➡➡ 1. Bumper absorber
 2. Lower plate
 3. Front bumper reinforcement
 4. Front bumper fascia

NOTE

(1) Reverse the disassembly procedures to reassemble.
 (2) ➡➡: Refer to "Service Points of Disassembly"
 (3) ● +: Refer to "Service Points of Reassembly"



SERVICE POINTS OF DISASSEMBLY

1. REMOVAL OF BUMPER ABSORBER

Caution


1. Do not attempt to repair a bumper absorber that has been compressed in an accident; replace it with a new one.
2. Before discarding the bumper absorber, drill a 3 mm (.13 in.) diameter hole to discharge the gas contained in the unit.
3. If the bumper absorber is to be discarded, do not burn it.

SERVICE POINTS OF REASSEMBLY

1. INSTALLATION OF BUMPER ABSORBER

If the squareness between the front bumper reinforcement and the bumper absorber is improper, adjust it by putting a spacer between them.


<PLYMOUTH Laser>

**Disassembly steps**


◆◆◆◆ 1. Bumper absorber
 2. Lower plate
 3. Front bumper reinforcement
 4. Front bumper fascia

NOTE

(1) Reverse the disassembly procedures to reassemble.
 (2) ◆◆: Refer to "Service Points of Disassembly".
 (3) ● +: Refer to "Service Points of Reassembly".

**SERVICE POINTS OF DISASSEMBLY****1. REMOVAL OF BUMPER ABSORBER****Caution**

1. Do not attempt to repair a bumper absorber that has been compressed in an accident; replace it with a new one.
2. Before discarding the bumper absorber, drill a 3 mm (.13 in.) diameter hole to discharge the gas contained in the unit.
3. If the bumper absorber is to be discarded, do not burn it.

**SERVICE POINTS OF REASSEMBLY****1. INSTALLATION OF BUMPER ABSORBER**

If the squareness between the front bumper reinforcement and the bumper absorber is improper, adjust it by putting a spacer between them.

REAR BUMPER

N23ZAAZ


REMOVAL AND INSTALLATION

<EAGLE Talon>

Pre-removal Operation

*Removal of Rear End Trim
(Refer to P.23-85.)

Post-installation Operation

● Installation of Rear End Trim
(Refer to P.23-85.)

18A0947

Rear bumper assembly removal steps

1. Splash shield mounting clip
2. Back up light
3. Rear panel garnish
4. Rear combination light
5. Connection for license plate light wiring harness and body wiring harness
6. Rear bumper assembly (No. 7-12)
7. Rear fascia side plate
8. Rear fascia upper plate
9. Rear side marker light
10. Rear fascia side plate
11. Rear bumper reinforcement assembly
12. Rear fascia lower plate
13. Rear bumper fascia

Rear bumper fascia removal steps

1. Splash shield mounting clip
2. Back up light
3. Rear panel garnish
4. Rear combination light
5. Rear fascia side plate
6. Rear fascia upper plate
7. Rear side marker light
8. Rear fascia side plate
9. Rear fascia lower plate
10. Rear bumper reinforcement assembly
11. Rear bumper reinforcement assembly
12. Rear fascia lower plate
13. Rear bumper fascia


NOTE

Reverse the removal procedures to reinstall.

<PLYMOUTH Laser>

Pre-removal Operation
 • Removal of Rear End Trim
 (Refer to P.23-85.)

Post-installation Operation
 • Installation of Rear End Trim
 (Refer to P.23-85.)

**Rear bumper assembly removal steps**

1. Splash shield mounting clip
2. Rear panel garnish
3. Rear combination light
4. Connection for license plate light wiring harness and body wiring harness
5. Rear bumper assembly (No.8-13)
6. Fascia plate upper
7. Rear side marker light
8. Rear fascia side plate
9. Rear bumper reinforcement assembly
10. Rear bumper fascia

Rear bumper fascia removal steps


1. Splash shield mounting clip
2. Rear panel garnish
3. Rear combination light
4. License plate light harness connector
5. Back-up light harness connector
6. Fascia plate upper
7. Rear side marker light
8. Rear fascia side plate
9. Rear bumper fascia

NOTE

Reverse the removal procedures to reinstall.

DISASSEMBLY AND REASSEMBLY

<EAGLE Talon>




Disassembly steps

◀◆ 1 Bumper absorber
 2 Rear bumper reinforcement

NOTE

(1) Reverse the disassembly procedures to reassemble.
 (2) ◀◆ : Refer to "Service Points of Disassembly".




SERVICE POINTS OF DISASSEMBLY

1. REMOVAL OF BUMPER ABSORBER

Caution

1. Do not attempt to repair a bumper absorber that has been compressed in an accident; replace it with a new one.
2. Before discarding the bumper absorber, drill a 3 mm (.13 in.) diameter hole to discharge the gas contained in the unit.
3. If the bumper absorber is to be discarded, do not burn it.


<PLYMOUTH Laser>



18A0948

Disassembly steps



1. License plate light
 2. Back-up light
 3. License plate light wiring harness
 4. Bumper absorber
 5. Rear bumper reinforcement
 6. License plate bracket
 7. Rear bumper fascia

**SERVICE POINTS OF DISASSEMBLY****4. REMOVAL OF BUMPER ABSORBER****Caution**

1. Do not attempt to repair a bumper absorber that has been compressed in an accident; replace it with a new one.
2. Before discarding the bumper absorber, drill a 3 mm (.13 in.) diameter hole to discharge the gas contained in the unit.
3. If the bumper absorber is to be discarded, do not burn it.

GARNISHES**REMOVAL AND INSTALLATION**

N23RDAH

**Front deck garnish removal steps**

Windshield wiper arms
(Refer to GROUP 8 - Windshield Wiper.)


1. Front deck garnish

Rear panel garnish removal steps

Rear end trim
(Refer to P.23-85.)

2. Cover
3. Back up light
4. Rear panel garnish


NOTE
Reverse the removal procedures to reinstall.

PLYMOUTH Laser

MOULDING

REMOVAL AND INSTALLATION

N23REAI



18A0954

- ◆◆ 1. Drip moulding
- ◆◆ 2. Windshield upper moulding
- ◆◆ 3. Quarter window moulding lower
- ◆◆ 4. Quarter window moulding upper
- ◆◆ 5. Quarter window moulding front
- ◆◆ 6. Liftgate moulding lower
- ◆◆ 7. Liftgate moulding upper
- ◆◆ 8. Liftgate moulding side
- ◆◆◆ 9. Side protect moulding fender
- ◆◆◆ 10. Side protect moulding front door
- ◆◆◆ 11. Side protect moulding quarter

NOTE

(1) ◆◆: Refer to "Service Points of Removal".
 (2) ● +: Refer to "Service Points of Installation".

SERVICE POINTS OF REMOVAL

1. REMOVAL OF DRIP MOULDING

Refer to P.23-70.

2. REMOVAL OF WINDSHIELD UPPER MOULDING


Refer to P.23-56.

3. REMOVAL OF QUARTER WINDOW MOULDING LOWER/
4. QUARTER WINDOW MOULDING UPPER/B. QUARTER WINDOW MOULDING FRONT


Refer to P.23-59.

6. REMOVAL OF LIFTGATE MOULDING LOWER/7. LIFTGATE MOULDING UPPER/8. LIFTGATE MOULDING SIDE

Refer to P.23-60.



18A0938



18U0386

9. REMOVAL OF SIDE PROTECT MOULDING FENDER/

10. SIDE PROTECT MOULDING FRONT DOOR/I
1. REMOVAL OF SIDE PROTECT MOULDING QUARTER

(1) Using the plastic trim tool, pry off the side protect moulding.

(2) Using the plastic trim tool, scale off the both-side adhesive tape which sticks to the body.

SERVICE POINTS OF INSTALLATION

9. INSTALLATION OF SIDE PROTECT MOULDING FENDER/10. SIDE PROTECT MOULDING FRONT DOOR/

11. SIDE PROTECT MOULDING QUARTER

(1) Wipe off application surface of body with clean cloth dampened with degreaser (MOPAR SUPER KLEEN or equivalent).

NOTE


After wiping surface, leave surface as it is to volatilize degreaser.

(2) Using an infrared light or similar instrument, heat the body painted surface and the side protect moulding.


Heating temperature

Body painted surface 25–55°C (77–131°F)

Side protect moulding.... 25–40°C (77–104°F)



18U0387



(3) Remove backing paper from adhesive tape, and apply specified adhesive tape as shown in the illustration,

Specified adhesive tape:

3M ATD Part No. 6383 or equivalent

(4) Apply specified sealant to the places shown in the illustration.

**Specified sealant: 3M Super Fast Urethane Primer
Part No. 8608 or equivalent**


(5) Attach the side protect mouldings at the places shown in the illustration.

(6) Use hand roller or similar tool to apply even pressure to entire surface of moulding.


NOTE

Press moulding ends firmly against the body surface.


Side protect moulding mounting positions



18A0400



Section A-A



Section B-B

18A0942

FENDER

REMOVAL AND INSTALLATION


N23KAAT

Pm-removal Operation

- Removal of Front Garnish (Refer to P.23-45.)
- Removal of Front Turn Signal Light and Front Combination Light (Refer to GROUP 8—Front Combination Light)
- Removal of Headlight Lower Bezel (Refer to GROUP 8—Headlights)
- Removal of Side Air Dam (Refer to P.23-72.)

Post-installation Operation

- Installation of Side Air Dam (Refer to P.23-72.)
- Installation of Headlight Lower Bezel (Refer to GROUP 8—Headlight)
- Installation of Front Turn Signal Light and Front Combination Light (Refer to GROUP 8—Front Combination Light)
- Installation of Front Garnish (Refer to P.23-45.)




Removal steps

1. Front splash shield extension
- C 2. Front splash shield
- 3. Front fender panel

NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ►: Refer to "Service Points of Installation".
- (3) . 1: This shows a tightening torque of 2.0-2.2 Nm (1.4–1.6 ft.lbs.).
- (4) . 2: This shows a tightening torque of 4-6 Nm (2-4 ft.lbs.).




SERVICE POINTS OF INSTALLATION

3. APPLICATION OF SEALANT TO FRONT FENDER PANEL

When installing the fenders, apply specified sealant between the fenders and the body panels, so that there are no gaps when the fenders are mounted.

Specified sealant: MOPAR Silicone Rubber Sealer Part No.4026070 or equivalent

**2. APPLICATION OF ADHESIVE TO SPLASH SHIELD**


When installing the splash shield, apply specified adhesive to the flange part of the fender.


Specified adhesive: MOPAR Silicone Rubber Sealer
Part No. 4026070 or Auto Glass
Adhesive and Sealer Part
No. 2299925 or equivalent

LOOSE PANEL

/& OVAL AND INSTALLATION

N23SAAK



AERO PARTS**REMOVAL AND INSTALLATION**

18A0941

Side air dam removal steps**<EAGLE Talon>**


Quarter trim
(Refer to P.23-85.)

- ↔↔ 1. Door side garnish
- ↔↔ 2. Front side air dam
- ↔↔ 3. Air outlet garnish
- ↔↔↔ 4. Rear side air dam


<PLYMOUTH Laser>

- ↔↔ 1. Door side garnish
- ↔↔ 2. Front side air dam
- ↔↔↔ 4. Rear side air dam

<EAGLE Talon>



<PLYMOUTH Laser>



18A1004

18A0967

Rear air spoiler assembly (center)
removal steps <EAGLE Talon>

- ◆ Rear wiper
(Refer to GROUP 8 – Rear Wiper.)
- ◆ Liftgate trim (Refer to P.23-89.)
- ◆ High mounted stop light
(Refer to GROUP 8 – Lighting System.)
- ◆ 5. Rear wiper grommet
- ◆ 6. Rear air spoiler assembly (center)

Rear air spoiler assembly (side)
removal steps <EAGLE Talon>

- 7. Mast antenna
- 8. Mounting nut
- 9. Mounting insulator
- 10. Rear air spoiler assembly (side)
- 11. Air spoiler cover
- 12. Air spoiler bracket assembly


Rear air spoiler removal steps
<PLYMOUTH-AWD>

- Liftgate trim (Refer to P.23-89.)
- High mounted stop light
(Refer to GROUP 8 – Lighting System.)

- ◆ 13. Rear air spoiler

NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ● *: Refer to "Service Points of Removal".
- (3) ● a: Refer to "Service Points of Installation".



18A0245


SERVICE POINTS OF REMOVAL

1. REMOVAL OF SIDE AIR DAM (DOOR)/4. SIDE AIR DAM


- (1) After the mounting screws are removed, apply the plastic trim tool to the bonding and clipped areas to remove the side air dam.
- (2) Scale off the both-side adhesive tape with the plastic trim tool.

5. REMOVAL OF REAR WIPER GROMMET

Remove the rear wiper grommet with the plastic trim tool.



18A0414




Tapping screw

18A0415

6. REMOVAL OF REAR AIR SPOILER ASSEMBLY (CENTER)/10. REAR AIR SPOILER ASSEMBLY (SIDE)/13. REAR AIR SPOILER

After the rear air spoiler mounting bolts or screws have been removed, move the rear air spoiler to the rear of the vehicle, remove the rear air spoiler from the tapping screws, and pull off the rear air spoiler.



Clips

18A0416

SERVICE POINTS OF INSTALLATION

13. INSTALLATION OF REAR AIR SPOILER/10. REAR AIR SPOILER ASSEMBLY (SIDE)/6. REAR AIR SPOILER ASSEMBLY (CENTER)

Install the rear air spoiler in position so that its clips are held by the tapping screws.

NOTE


When the clip remains on the body side, securely attach the clip to the rear air spoiler, and mount them.

4. INSTALLATION OF REAR SIDE AIR DAM


- (1) Wipe off application surface of body with clean cloth dampened with degreaser (MOPAR SUPER KLEEN or equivalent).

NOTE

After wiping surface, leave surface as it is to volatilize degreaser.



18A0410



(2) Using an infrared light or similar instrument, heat the body painted surface and the side air dam.

Heating temperature

Body painted surface 25-55°C (77-131°F)
Side air dam 25-40°C (77-104°F)

(3) Peel off the paper from the adhesive tape, apply specified adhesive and sealant at the places shown in the figure, and attach to the body adhesive surface.

Specified adhesive tape: 3M ATD Part No. 6383 or equivalent


(4) Using a hand roller or similar tool, apply pressure to the entire surface of the side air dam.

NOTE

The ends of the side air dam tend to loosen easily, so apply manual pressure again.


Side air dam positions

<EAGLE Talon>



18A0940


Section A-A



Front door

Front fender panel

Section B-B




Front door

Quarter panel outer


18A0944

<PLYMOUTH Laser>



18A0940


Section A-A



Front fender panel

Front door

Section B-B



Front door

Quarter panel outer

18A0943