

GROUP 55

HEATER, AIR CONDITIONER AND VENTILATION

CONTENTS

GENERAL INFORMATION	55-4	damper <vehicles with dual automatic A/C>	55-29
SERVICE SPECIFICATIONS.....	55-4	Code No. B1061,B1062: Potentiometer system for air outlet changeover damper <LHD>	55-32
LUBRICANTS	55-4	Code No. B1061,B1062: Potentiometer system for air outlet changeover damper <RHD>	55-34
SPECIAL TOOL.....	55-5	Code No. B1065: Motor drive system for air outlet switching damper	55-35
TROUBLESHOOTING	55-7	Code No.U1073 Bus off error	55-38
DIAGNOSIS TROUBLESHOOTING FLOW	55-7	Code No.U1100: Engine CAN communication time-out	55-38
DIAGNOSIS FUNCTION.....	55-7	Code No.U1109: ETACS related CAN communication time-out	55-40
DIAGNOSIS CODE CHART.....	55-8	Code No.U1113 Multi-centre display CAN communication time-out	55-41
DIAGNOSTIC TROUBLE CODE PROCEDURES	55-10	Code No.U1120 Engine-related CAN communication failure information	55-42
Code No. B1001,B1002: Interior temperature sensor system.....	55-10	TROUBLE SYMPTOM CHART	55-43
Code No. B1011,B1012: Ambient temperature sensor system.....	55-12	SYMPTOM PROCEDURES	55-45
Code No. B1021,B1022: Air thermo sensor system	55-15	INSPECTION PROCEDURE 1: Communication with the MUT-III is not possible.	55-45
Code No. B1041,B1042: Potentiometer system for the front air mix damper <LHD>	55-17	INSPECTION PROCEDURE 2: Cool air does not come	55-46
Code No. B1041,B1042: Potentiometer system for the air mix damper <RHD>	55-19	INSPECTION PROCEDURE 3: The front blower does not work	55-47
Code No.B1045: Motor drive system for the front air mix damper	55-21	INSPECTION PROCEDURE 4: The blower air volume cannot be changed	55-59
Code No. B1051,B1052: Potentiometer system for rear air mix damper <vehicles with LHD dual automatic A/C>	55-23	INSPECTION PROCEDURE 5: The inside/outside air changeover is impossible. <LHD>.....	55-63
Code No. B1051,B1052: Potentiometer system for rear air mix damper <vehicles with RHD dual automatic A/C>	55-26	INSPECTION PROCEDURE 6: The inside/outside air changeover is impossible. <RHD>	55-67
Code No.B1055 Motor drive system for rear air mix		INSPECTION PROCEDURE 7: The compressor does not work <LHD>.....	55-71
		INSPECTION PROCEDURE 8: The compressor does	

not work <RHD>	55-78
INSPECTION PROCEDURE 9: The outlet air temperature can not be changed even if the amount of solar radiation changes	55-84
INSPECTION PROCEDURE 10: The PTC heater does not work <LHD>	55-87
INSPECTION PROCEDURE 11: The PTC heater does not work <RHD>	55-99
INSPECTION PROCEDURE 12: The rear window defogger does not work.	55-109
INSPECTION PROCEDURE 13: The A/C indicator flashes.	55-119
INSPECTION PROCEDURE 14: Rear blower does not work <Vehicle with rear heater or rear cooler>	55-120
INSPECTION PROCEDURE 15: Rear blower does not work <vehicles with dual automatic A/C> ..	55-127
INSPECTION PROCEDURE 16: Air volume of rear blower cannot be changed	55-134
INSPECTION PROCEDURE 17: The temperature of rear air conditioner cannot be controlled <vehicles with dual automatic A/C>	55-138
INSPECTION PROCEDURE 18: A/C pressure sensor system <LHD>	55-142
INSPECTION PROCEDURE 19: A/C pressure sensor system <RHD>	55-144
INSPECTION PROCEDURE 20: Rear fan switch system <LHD>	55-146
INSPECTION PROCEDURE 21: Rear fan switch system <RHD>	55-149
INSPECTION PROCEDURE 22: Rear blower motor power supply system <LHD>	55-152
INSPECTION PROCEDURE 23: Rear blower motor power supply system <RHD>	55-160
INSPECTION PROCEDURE 24: PTC heater switch system <LHD>	55-168
INSPECTION PROCEDURE 25: PTC heater switch system <RHD>	55-171
INSPECTION PROCEDURE 26: A/C-ECU power supply system <LHD>	55-174
INSPECTION PROCEDURE 27: A/C-ECU power supply system <RHD>	55-178
SERVICE DATA REFERENCE TABLE	55-183
ACTUATOR TEST TABLE	55-186
CHECK AT A/C-ECU TERMINALS	55-187
ON-VEHICLE SERVICE.....	55-190
COMPRESSOR DRIVE BELT ADJUSTMENT	55-190
DISCHARGING SYSTEM.....	55-190
CHARGING.....	55-191
CHECK THE REFRIGERANT LEVEL	55-193
CORRECTING LOW REFRIGERANT LEVEL IN CASE THE SERVICE CAN IN USED	55-193
PERFORMANCE TEST	55-193
SIMPLE INSPECTION OF THE A/C PRESSURE SENSOR	55-195
RELAY CONTINUITY CHECK	55-196
IDLE-UP OPERATION CHECK	55-198
CLEAN AIR FILTER REPLACEMENT PROCEDURE	55-198
HEATER CONTROL UNIT	55-199
REMOVAL AND INSTALLATION	55-199
INSPECTION.....	55-199
HEATER UNIT AND BLOWER ASSEMBLY	55-200
REMOVAL AND INSTALLATION	55-200
DISASSEMBLY AND REASSEMBLY	55-203
HEATER UNIT DISASSEMBLY AND REASSEMBLY	55-204
BLOWER ASSEMBLY DISASSEMBLY AND REASSEMBLY	55-205
INSPECTION.....	55-205
MODE SELECTION DAMPER CONTROL MOTOR, AIR MIXING DAMPER CONTROL MOTOR, OUTSIDE/INSIDE AIR SELECTION DAMPER CONTROL MOTOR, POWER TRANSISTOR AND BLOWER MOTOR	55-206
REMOVAL AND INSTALLATION	55-206
INSPECTION.....	55-208
PHOTO SENSOR AND INTERIOR TEMPERATURE SENSOR.....	55-210
REMOVAL AND INSTALLATION	55-210
INSPECTION.....	55-211
AMBIENT TEMPERATURE SENSOR	55-211
REMOVAL AND INSTALLATION	55-211
INSPECTION.....	55-211
HEAT SWITCH	55-212
REMOVAL AND INSTALLATION <REAR HEATER OR REAR A/C VEHICLES>.....	55-212
INSPECTION.....	55-212
REAR A/C SWITCH	55-213
REMOVAL AND INSTALLATION	55-213

INSPECTION	55-213	CONDENSER ASSEMBLY.....	55-222
REAR HEATER UNIT	55-214	REMOVAL AND INSTALLATION	55-222
REMOVAL AND INSTALLATION	55-214	INSPECTION.....	55-223
DISASSEMBLY AND REASSEMBLY <VEHICLES WITH REAR HEATER, REAR COOLER OR DUAL AUTOMATIC A/C>	55-215	REFRIGERANT LINE.....	55-224
INSPECTION	55-216	REMOVAL AND INSTALLATION <L.H.D. FRONT SIDE>	55-224
REAR BLOWER MOTOR AND REAR POWER TRANSISTOR	55-217	REMOVAL AND INSTALLATION <R.H.D. FRONT SIDE>	55-225
REMOVAL AND INSTALLATION	55-217	REAR REFRIGERANT REMOVAL AND INSTALLATION <REAR SIDE>	55-226
INSPECTION	55-217	DUCTS	55-227
COMPRESSOR ASSEMBLY.....	55-218	REMOVAL AND INSTALLATION	55-227
REMOVAL AND INSTALLATION	55-218	REMOVAL AND INSTALLATION	55-228
INSPECTION	55-219	VENTILATORS.....	55-229
DISASSEMBLY AND REASSEMBLY.....	55-220	REMOVAL AND INSTALLATION	55-229
INSPECTION	55-221		

GENERAL INFORMATION

M1552000100425

The heater and cooling units of front and rear air conditioners in the heater and air conditioner systems are integrated for greater fan power and reduced noise. In the air conditioner system, single automatic air conditioner for the front, and heater, cooler, or dual automatic air conditioner for the rear are established.

GENERAL SPECIFICATIONS

Item	Specification	
Heater control type	Rotary type	
Compressor type	MSC105CA	
Front air conditioner	Cooling output W	5400
	Heating output W	5500
	Heating capacity of PTC heater (W)	120 × 2
Rear air conditioner	Cooling output W	2100
	Heating output W	2700

SERVICE SPECIFICATIONS

M1551000300125

Item	Standard value	
Idle speed r/min (N or P range)	700 ± 50	
Idle-up speed r/min (N or P range)	850 ± 50	
Air gap (magnetic clutch) mm	0.3 – 0.5	
A/C refrigerant temperature switch operating temperature °C	Being turned off	155
	Being turned on	125
Resistance value for front air mixing damper control motor and potentiometer kΩ	1.7 – 5.0	
Resistance value for mode selection damper control motor and potentiometer kΩ	0.8 – 4.8	
Resistance value for rear air mixing damper control motor and potentiometer kΩ	1.2 – 4.8	



LUBRICANTS







M1551000400111

Item	Specified lubricant	Quantity
Compressor refrigerant unit lubricant mL	SUN PAG 56	160 – 180 (target value: 160)
Each connection of refrigerant line	SUN PAG 56	As required
Refrigerant g	Single A/C	HFC134a (R134a)
	Vehicles with rear cooler or dual automatic A/C	560 ± 25
		750 ± 25

SPECIAL TOOL

M1551000600085

Tool	Number	Name	Use
 B991367	MB991367	Special spanner	Removal and installation of air conditioner compressor armature mounting nut
 B991386	MB991386	Pin	
 MB991658	MB991658	Test harness	Inspection of the A/C pressure sensor

Tool	Number	Name	Use
A  MB991824	MB991955 A: MB991824 B: MB991827 C: MB991910 D: MB991911 E: MB991825 F: MB991826	MUT-III sub-assembly A: V. C. I. (Vehicle Communication Interface) B: USB cable C: MUT-III main harness A (applicable to vehicles with CAN communication) D: MUT-III main harness B (applicable to vehicles without CAN communication) E: Measurement adapter F: Trigger harness	Check the air conditioner (The MUT-III diagnosis codes display, service data display and actuator test) CAUTION For vehicles with CAN communication, use MUT-III main harness A to send simulated vehicle speed. If you connect MUT-III main harness B instead, the CAN communication does not function correctly.
B  MB991827			
C  MB991910			
D  DO NOT USED MB991911			
E  MB991825			
F  MB991826			
	MB991955		

TROUBLESHOOTING

DIAGNOSIS TROUBLESHOOTING FLOW

M1554004700168

Refer to GROUP 00, How to Use
Troubleshooting/Inspection Service Points [P.00-5](#).

DIAGNOSIS FUNCTION

M1554004800187

HOW TO READ DIAGNOSIS CODE

Connect the MUT-III to the 16-pin diagnosis connector to read diagnosis code (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

HOW TO ERASE DIAGNOSIS CODE

Refer to GROUP 00, How to Use
Troubleshooting/Inspection Service Points [P.00-5](#).

DIAGNOSIS CODE CHART

M1554004900258


Code No.	Diagnostic item	Reference page	Service data display contents when diagnosis code is set
B1001	Interior temperature sensor system (short circuit) <LHD>	P.55-10	25°C
	Interior temperature sensor system (short circuit) <RHD>	P.55-10	
B1002	Interior temperature sensor system (open circuit) <LHD>	P.55-10	20°C
	Interior temperature sensor system (open circuit) <RHD>	P.55-10	
B1011	Ambient temperature sensor system (short circuit) <LHD>	P.55-12	-6°C
	Ambient temperature sensor system (short circuit) <RHD>	P.55-12	
B1012	Ambient temperature sensor system (open circuit) <LHD>	P.55-12	Moved to MAX HOT position
	Ambient temperature sensor system (open circuit) <RHD>	P.55-12	
B1021	Air thermo sensor system (short circuit) <LHD>	P.55-15	
	Air thermo sensor system (short circuit) <RHD>	P.55-15	
B1022	Air thermo sensor system (open circuit) <LHD>	P.55-15	
	Air thermo sensor system (open circuit) <RHD>	P.55-15	
B1041	Potentiometer system for front air mix damper (short to power supply) <LHD>	P.55-17	
	Potentiometer system for front air mix damper (short to power supply) <RHD>	P.55-19	
B1042	Potentiometer system for front air mix damper (short to earth or open circuit) <LHD>	P.55-17	
	Potentiometer system for front air mix damper (short to earth or open circuit) <RHD>	P.55-19	
B1045	Motor drive system for front air mix damper	P.55-21	-
B1051	Potentiometer system for rear air mix damper (short to power supply) <vehicles with LHD dual automatic A/C>	P.55-23	
	Potentiometer system for rear air mix damper (short to power supply) <vehicles with RHD dual automatic A/C>	P.55-26	
B1052	Potentiometer system for rear air mix damper (short to earth or open circuit) <vehicles with LHD dual automatic A/C>	P.55-23	
	Potentiometer system for rear air mix damper (short to earth or open circuit) <vehicles with RHD dual automatic A/C>	P.55-26	

Code No.	Diagnostic item	Reference page	Service data display contents when diagnosis code is set
B1055	Motor drive system for rear air mix damper <vehicles with dual automatic A/C>	P.55-29	–
B1061	Potentiometer system for air outlet switching damper (short to power supply) <LHD>	P.55-32	Moved to DEF position
	Potentiometer system for air outlet switching damper (short to power supply) <RHD>	P.55-34	
B1062	Potentiometer system for air outlet switching damper (short to earth or open circuit) <LHD>	P.55-32	
	Potentiometer system for air outlet switching damper (short to earth or open circuit) <RHD>	P.55-34	
B1065	Motor drive system for air outlet switching damper	P.55-35	–
U1073	Bus off error	P.55-38	–
U1100	Engine-related CAN time-out	P.55-38	–
U1109	ETACS related CAN communication time-out	P.55-40	–
U1113	Multi-centre display-related CAN time-out	P.55-41	–
U1120	Engine-related failure data	P.55-42	–

DIAGNOSTIC TROUBLE CODE PROCEDURES

Code No. B1001,B1002: Interior temperature sensor system

Interior Temperature Sensor Circuit



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E10AA

COMMENTS ON TROUBLE SYMPTOM

This code is set when the interior temperature sensor circuit is open (Code No.B1002) or is short (Code No.B1001).

POSSIBLE CAUSES

- Malfunction of the interior temperature sensor
- Damaged the wiring harness or connectors
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183.](#))


- Item 01: Inside temperature sensor

Q: Is the check result normal?




YES : Go to Step 5.

NO : Go to Step 2.

Step 2. Connector check: C-106 A/C-ECU connector and C-26 interior temperature sensor connector



Step 3. Check the wiring harness between C-106 A/C-ECU connector (terminals 1 and 18) and C-26 interior temperature sensor connector (terminals 1 and 2).



Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.

- Check the sensor signal line and earth line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the wiring harness.

Step 4. Check the interior temperature sensor.Refer to [P.55-211](#).**Q: Is the check result normal?**

YES : Go to Step 5.


NO : Replace the interior temperature sensor.

Step 5. MUT-III diagnosis code**Q: Is the diagnosis code set?**

YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).**Code No. B1011,B1012: Ambient temperature sensor system**

Ambient Temperature Sensor Circuit



Wire colour code

B : Black	LG : Light green	G : Green	L : Blue	W : White	Y : Yellow	SB : Sky blue
BR : Brown	O : Orange	GR : Gray	R : Red	P : Pink	V : Violet	

W4X55E08AA

COMMENTS ON TROUBLE SYMPTOM

This code is set when the ambient temperature sensor circuit is open (Code No.B1012) or is short (Code No.B1011).

POSSIBLE CAUSES

- Malfunction of the ambient temperature sensor
- Damaged the wiring harness and connectors
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS**Step 1. MUT-III data list**

Check that the following service data display contents are normal. (Refer to [P.55-183](#).)

- Item 02: Ambient temperature sensor





Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 2.

Step 2. Connector check: A-28 ambient temperature sensor connector and C-106 A/C-ECU connector


YES : Go to Step 3.
NO : Repair the connector.



Q: Is the check result normal?

Step 3. Check the wiring harness between A-28 ambient temperature sensor connector (terminals 1 and 2) and C-106 A/C-ECU connector (terminals 1 and 24).

Connector: A-28 <LHD>




Harness side



AC310403AB

Connector: A-28 <RHD>




Harness side




AC310398AB

Connectors: C-106, C-125 <LHD>

Harness side
C-106


13	12	11	10	9	8	7	6	5	4	3	2	1
26	25	24	23	22	21	20	19	18	17	16	15	14

C-125



AC310614BD


Connector: C-106 <LHD>



Harness side

13	12	11	10	9	8	7	6	5	4	3	2	1
26	25	24	23	22	21	20	19	18	17	16	15	14

AC310613AB



NOTE: Prior to the wiring harness inspection, check intermediate connector C-125, and repair if necessary.

- Check the sensor signal line and earth line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 4.
NO : Repair the wiring harness.

Step 4. Check the ambient temperature sensor.
Refer to [P.55-211](#).


Q: Is the check result normal?
YES : Go to Step 5.
NO : Replace the ambient temperature sensor.

Step 5. MUT-III diagnosis code

Q: Is the diagnosis code set?
YES : Replace the automatic air conditioner control panel (A/C-ECU)
NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).

Code No. B1021,B1022: Air thermo sensor system

Air Thermo Sensor Circuit



Wire colour code
B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E06AA

COMMENTS ON TROUBLE SYMPTOM

This code is set when the air thermo sensor circuit is open (Code No.B1022) or is short (Code No.B1021).

POSSIBLE CAUSES

- Malfunction of the air thermo sensor
- Damaged the wiring harness or connectors
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. MUT-III data list


Check that the following service data display contents are normal. (Refer to [P.55-183](#).)

- Item 03: Air thermo sensor




Q: Is the check result normal?

YES : Go to Step 5.
NO : Go to Step 2.

Step 2. Connector check: C-106 A/C-ECU connector and C-05 air thermo sensor connector



Step 3. Check the wiring harness between C-106 A/C-ECU connector (terminals 1 and 19) and C-05 air thermo sensor connector (terminals 2 and 1).



Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.

- Check the sensor signal line and earth line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the wiring harness.

Step 4. Check the air thermo sensor.

Refer to [P.55-205](#).

Q: Is the check result normal?

YES : Go to Step 5.

NO : Replace the air thermo sensor.

Step 5. MUT-III diagnosis code


Q: Is the diagnosis code set?

YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

Code No. B1041,B1042: Potentiometer system for the front air mix damper <LHD>

Front Air Mixing Damper Control Motor And Potentiometer Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E05AA

COMMENTS ON TROUBLE SYMPTOM

This code is set when the air mixing damper control motor potentiometer does not send any signal to the A/C-ECU due to short or open circuit.

POSSIBLE CAUSES

- Malfunction of the front air mixing damper control motor and potentiometer
- Damaged the wiring harness or connectors
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183](#).)



- Item 10: F.Air mix potentiometer
- Item 11: F.Air mix potentiometer (Target)

Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 2.

Step 2. Connector check: C-106 A/C-ECU connector and C-11 front air mixing damper control motor and potentiometer connector





Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.

Step 3. Check the wiring harness between C-106 A/C-ECU connector (terminals 1, 14 and 20) and C-11 front air mixing damper control motor and potentiometer connector (terminals 7, 5 and 3).



NOTE: Prior to the wiring harness inspection, check joint connector C-01, and repair if necessary.

- Check the potentiometer power supply, earth and signal line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the wiring harness.

Step 4. Check the front air mixing damper control motor and potentiometer.

Refer to [P.55-208](#).

Q: Is the check result normal?

YES : Go to Step 5.

NO : Replace the front air mixing damper control motor and potentiometer.

Step 5. MUT-III diagnosis code


Q: Is the diagnosis code set?

YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5.](#))

Code No. B1041,B1042: Potentiometer system for the air mix damper <RHD>

Front Air Mixing Damper Control Motor And Potentiometer Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E04AA

COMMENTS ON TROUBLE SYMPTOM

This code is set when the front air mixing damper control motor potentiometer does not send any signal to the A/C-ECU due to short or open circuit.

POSSIBLE CAUSES

- Malfunction of the front air mixing damper control motor and potentiometer
- Damaged the wiring harness or connectors
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183.](#))



- Item 10: F.Air mix potentiometer
- Item 11: F.Air mix potentiometer (Target)

Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 2.

Step 2. Connector check: C-106 A/C-ECU connector and C-11 front air mixing damper control motor and potentiometer connector





Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.

Step 3. Check the wiring harness between C-106 A/C-ECU connector (terminals 14, 20 and 1) and C-11 front air mixing damper control motor and potentiometer connector (terminals 5, 3 and 7).



- Check the potentiometer power supply, earth and signal line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the wiring harness.

Step 4. Check the front air mixing damper control motor and potentiometer.

Refer to [P.55-208](#).

Q: Is the check result normal?

YES : Go to Step 5.

NO : Replace the front air mixing damper control motor and potentiometer.

Step 5. MUT-III diagnosis code


Q: Is the diagnosis code set?

YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

Code No.B1045: Motor drive system for the front air mix damper

Front Air Mix Damper Control Motor And Potentiometer Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E03AA

COMMENTS ON TROUBLE SYMPTOM

This code is set when the air mixing damper cannot be rotated to the preset opening angle.

POSSIBLE CAUSES

- Malfunction of the front air mixing damper control motor and potentiometer
- Malfunction of the automatic air conditioner control panel (A/C-ECU)
- Damaged the wiring harness or connectors

DIAGNOSIS

Step 1. MUT-III actuator test

Check that the following actuator test can be executed normally.

- Item 10: F.Air mix dumper motor: 0%
- Item 11: F.Air mix dumper motor: 50%
- Item 12: F.Air mix dumper motor: 100%


Q: Is the check result normal?

YES : Go to Step 5.


NO : Go to Step 2.

Step 2. Connector check: C-105 A/C-ECU connector and C-11 front air mixing damper control motor and potentiometer connector


Connector: C-11 <LHD>




Connector: C-11 <RHD>



Connector: C-105 <LHD>



Connector: C-105 <RHD>




Q: Is the check result normal?

YES : Go to Step 3.


NO : Repair the connector.

Step 3. Check the wiring harness between C-105 A/C-ECU connector (terminals 31 and 32) and C-11 front air mixing damper control motor and potentiometer connector (terminals 1 and 2).


Connector: C-11 <LHD>




Connector: C-11 <RHD>



Connector: C-105 <LHD>



Connector: C-105 <RHD>



- Check the motor activating lines for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the wiring harness.

Step 4. Check the front air mixing damper control motor and potentiometer.
Refer to P.55-208.

Q: Is the check result normal?

YES : Go to Step 5.

NO : Replace the air mixing damper control motor and potentiometer.

Step 5. MUT-III diagnosis code


Q: Is the diagnosis code set?

YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)

Code No. B1051,B1052: Potentiometer system for rear air mix damper <vehicles with LHD dual automatic A/C>

Rear Air Mixing Damper Control Motor And Potentiometer Circuit



COMMENTS ON TROUBLE SYMPTOM

This code is set when the rear air mixing damper control motor potentiometer does not send any signal to the A/C-ECU due to short or open circuit.

POSSIBLE CAUSES

- Malfunction of the rear air mixing damper control motor and potentiometer
- Damaged the wiring harness or connectors

- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to P.55-183.)



- Item 12: R.Air mix potentiometer
- Item 13: R.Air mix potentiometer (Target)

Q: Is the check result normal?

W4X55E31AA

YES : Go to Step 5.
NO : Go to Step 2.

**Step 2. Connector check: C-106 A/C-ECU
connector and G-13-1 rear air mixing damper
control motor and potentiometer connector**




Q: Is the check result normal?

YES : Go to Step 3.
NO : Repair the connector.

Step 3. Check the wiring harness between C-106 A/C-ECU connector (terminals 14, 22 and 1) and G-13-1 rear air mixing damper control motor and potentiometer connector (terminals 4, 3 and 5).

Connectors: C-01, C-106 <LHD>



C-01

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22
23	24	25	26	27	28	29	30	31	32	33
33	34	35	36	37						


Harness side

C-106

13	12	11	10	9	8	7	6	5	4	3	2	1
26	25	24	23	22	21	20	19	18	17	16	15	14

AC310614AG

Connectors: G-13, G-13-1



G-13

1	2	3	4	5
---	---	---	---	---


Harness side

G-13-1

5	4	3	2	1
---	---	---	---	---

AC311185AB

Connector: C-15 <LHD>



1	2	3	X	4	5	6	7	8	9	10	X	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25			
26	27	28	29	30	31									
32	33	34	35	36	37									

AC310615AD

Prior to the wiring harness inspection, check intermediate connector G-13, C-15 and joint connector C-01, and repair if necessary.

- Check the potentiometer power supply, earth and signal line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the wiring harness.

Step 4. Check the rear air mixing damper control motor and potentiometer.

Refer to [P.55-216](#).

Q: Is the check result normal?

YES : Go to Step 5.

NO : Replace the rear air mixing damper control motor and potentiometer.

Step 5. MUT-III diagnosis code

Q: Is the diagnosis code set?


YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

NOTE:

Code No. B1051,B1052: Potentiometer system for rear air mix damper <vehicles with RHD dual automatic A/C>

Rear Air Mixing Damper Control Motor And Potentiometer Circuit



COMMENTS ON TROUBLE SYMPTOM

This code is set when the rear air mixing damper control motor potentiometer does not send any signal to the A/C-ECU due to short or open circuit.

POSSIBLE CAUSES

- Malfunction of the rear air mixing damper control motor and potentiometer
- Damaged the wiring harness or connectors
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to P.55-183.)

- Item 12: R.Air mix potentiometer
- Item 13: R.Air mix potentiometer (Target)

Q: Is the check result normal?



YES : Go to Step 5.

NO : Go to Step 2.

W4X55E038A



**Step 2. Connector check: C-106 A/C-ECU
connector and G-13-1 rear air mixing damper
control motor and potentiometer connector**

YES : Go to Step 3.
NO : Repair the connector.




Q: Is the check result normal?

Step 3. Check the wiring harness between C-106 A/C-ECU connector (terminals 14, 22 and 1) and G-13-1 rear air mixing damper control motor and potentiometer connector (terminals 4, 3 and 5).



NOTE:



Prior to the wiring harness inspection, check intermediate connector G-13 and C-15, and repair if necessary.

- Check the potentiometer power supply, earth and signal line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the wiring harness.

Step 4. Check the rear air mixing damper control motor and potentiometer.

Refer to [P.55-216](#).

Q: Is the check result normal?

YES : Go to Step 5.

NO : Replace the rear air mixing damper control motor and potentiometer.

Step 5. MUT-III diagnosis code


Q: Is the diagnosis code set?

YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

Code No.B1055 Motor drive system for rear air mix damper <vehicles with dual automatic A/C>

Rear Air Mixing Damper Control Motor And Potentiometer Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E35AA

COMMENTS ON TROUBLE SYMPTOM

This code is set when the rear air mixing damper cannot be rotated to the preset opening angle.

POSSIBLE CAUSES

- Malfunction of the rear air mixing damper control motor and potentiometer
- Malfunction of the automatic air conditioner control panel (A/C-ECU)
- Damaged the wiring harness or connectors

DIAGNOSIS

Step 1. MUT-III actuator test

Check that the following actuator test can be executed normally.

- Item 13: R.Air mix dumper motor: 0%
- Item 14: R.Air mix dumper motor: 50%
- Item 15: R.Air mix dumper motor: 100%




Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 2.




**Step 2. Connector check: C-105 A/C-ECU
connector and G-13-1 rear air mixing damper
control motor and potentiometer connector**

YES : Go to Step 3.
NO : Repair the connector.




Q: Is the check result normal?

Step 3. Check the wiring harness between C-105 A/C-ECU connector (terminals 35 and 36) and G-13-1 rear air mixing damper control motor and potentiometer connector (terminals 2 and 1).




NOTE:

Connector: C-15 <LHD>



Connector: C-15 <RHD>



Prior to the wiring harness inspection, check intermediate connector C-15 and G-13, and repair if necessary.

- Check the motor activating lines for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the wiring harness.

Step 4. Check the rear air mixing damper control motor and potentiometer.

Refer to [P.55-216](#).

Q: Is the check result normal?

YES : Go to Step 5.

NO : Replace the air mixing damper control motor and potentiometer.

Step 5. MUT-III diagnosis code


Q: Is the diagnosis code set?

YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

Code No. B1061,B1062: Potentiometer system for air outlet changeover damper <LHD>

Mode Selection Damper Control Motor And Potentiometer Circuit



W4X55E01AA

COMMENTS ON TROUBLE SYMPTOM

This code is set when the mode selection damper control motor potentiometer does not send any signal to the A/C-ECU due to short or open circuit.

POSSIBLE CAUSES

- Malfunction of the mode selection damper control motor and potentiometer
- Damaged the wiring harness or connectors
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to P.55-183.)

- Item 14: F.Air outlet c/o potentiometer
- Item 15: F.Air outlet c/o potentiometer (Target)


Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 2.

Step 2. Connector check: C-106 A/C-ECU connector and C-04 mode selection damper control motor and potentiometer connector

Connectors: C-04, C-106 <LHD>



Harness side

C-04

7	6	5	4	3	2	1
---	---	---	---	---	---	---

Harness side

C-106

13	12	11	10	9	8	7	6	5	4	3	2	1
26	25	24	23	22	21	20	19	18	17	16	15	14

AC310614AH

Q: Is the check result normal?


YES : Go to Step 3.

NO : Repair the connector.

YES : Go to Step 4.

NO : Repair the wiring harness.

Step 3. Check the wiring harness between C-106 A/C-ECU connector (terminals 1, 21 and 14) and C-04 mode selection damper control motor and potentiometer connector (terminals 7, 3 and 5).



NOTE: Prior to the wiring harness inspection, check joint connector C-01, and repair if necessary.

- Check the potentiometer power supply, earth and signal line for open or short circuit.

Q: Is the check result normal?

Step 4. Check the mode selection damper control motor and potentiometer.

Refer to [P.55-208](#).

Q: Is the check result normal?

YES : Go to Step 5.

NO : Replace the mode selection damper control motor and potentiometer.

Step 5. MUT-III diagnosis code


Q: Is the diagnosis code set?

YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

Code No. B1061,B1062: Potentiometer system for air outlet changeover damper <RHD>

Mode Selection Damper Control Motor And Potentiometer Circuit



W4X55E00AA

COMMENTS ON TROUBLE SYMPTOM

This code is set when the mode selection damper control motor potentiometer does not send any signal to the A/C-ECU due to short or open circuit.

POSSIBLE CAUSES

- Malfunction of the mode selection damper control motor and potentiometer
- Damaged the wiring harness or connectors
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to P.55-183.)

- Item 14: F.Air outlet c/o potentiometer
- Item 15: F.Air outlet c/o potentiometer (Target)


Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 2.

Step 2. Connector check: C-106 A/C-ECU connector and C-04 mode selection damper control motor and potentiometer connector

Connectors: C-04, C-106 <RHD>



Harness side

C-04

7	6	5	4	3	2	1
---	---	---	---	---	---	---

Harness side

C-106

13	12	11	10	9	8	7	6	5	4	3	2	1
26	25	24	23	22	21	20	19	18	17	16	15	14


AC310632AD

Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.

Step 3. Check the wiring harness between C-106 A/C-ECU connector (terminals 1, 21 and 14) and C-04 mode selection damper control motor and potentiometer connector (terminals 7, 3 and 5).



- Check the potentiometer power supply, earth and signal line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 4.
NO : Repair the wiring harness.

Step 4. Check the mode selection damper control motor and potentiometer.
Refer to [P.55-208](#).


Q: Is the check result normal?
YES : Go to Step 5.
NO : Replace the mode selection damper control motor and potentiometer.

Step 5. MUT-III diagnosis code

Q: Is the diagnosis code set?
YES : Replace the automatic air conditioner control panel (A/C-ECU)
NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

Code No. B1065: Motor drive system for air outlet switching damper

Mode Selection Damper Control Motor And Potentiometer Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

COMMENTS ON TROUBLE SYMPTOM

This code is set when the mode selection damper cannot be rotated to the preset opening angle.

POSSIBLE CAUSES

- Malfunction of the rear mode selection damper control motor and potentiometer
- Malfunction of the automatic air conditioner control panel (A/C-ECU)
- Damaged the wiring harness or connectors

DIAGNOSIS**Step 1. MUT-III actuator test**


Check that the following actuator test can be executed normally.

- Item 20: Air outlet c/o dumper: FACE
- Item 21: Air outlet c/o dumper: Bi-Level
- Item 22: Air outlet c/o dumper: FOOT
- Item 23: Air outlet c/o dumper: DEF/FOOT
- Item 24: Air outlet c/o dumper: DEF

Q: Is the check result normal?


YES : Go to Step 5.

NO : Go to Step 2.

Step 2. Connector check: C-105 A/C-ECU connector and C-04 rear mode selection damper control motor and potentiometer connector**Connectors: C-04, C-105 <LHD>**


Harness side

C-04




Harness side

C-105



AC310614AJ

Connectors: C-04, C-105 <RHD>


Harness side

C-04



Harness side

C-105




AC310632AE

Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.

Step 3. Check the wiring harness between C-105 A/C-ECU connector (terminals 33 and 34) and C-04 rear mode selection damper control motor and potentiometer connector (terminals 1 and 2).



YES : Go to Step 4.
NO : Repair the wiring harness.

Step 4. Check the rear mode selection damper control motor and potentiometer.
Refer to [P.55-208](#).


Q: Is the check result normal?

YES : Go to Step 5.
NO : Replace the mode selection damper control motor and potentiometer.

Step 5. MUT-III diagnosis code

Q: Is the diagnosis code set?

YES : Replace the automatic air conditioner control panel (A/C-ECU)
NO : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)



- Check the motor activating lines for open or short circuit.

Q: Is the check result normal?

Code No.U1073 Bus off error

⚠ CAUTION

If diagnosis code No. U1073 is set in the A/C-ECU, diagnose the CAN main bus line.

⚠ CAUTION

Whenever the ECU is replaced, ensure that the communication circuit is normal.

TROUBLE JUDGMENT

If the A/C-ECU ceases communicating once (i.e. bus off) and then returns to it, the combination meter will not communicate for three minutes immediately after that point. This three-minute period is called "Penalty mode." Immediately after the combination meter returns to communication, the diagnosis code is set.

COMMENTS ON TROUBLE SYMPTOM

The wiring harness wire or connectors may have loose, corroded, or damage terminals, or terminals pushed back in the connector, or the A/C-ECU may be defective.

POSSIBLE CAUSES

- Damaged harness wires and connectors
- Malfunction of the A/C-ECU

Step 1. MUT-III CAN bus diagnostics

Use the MUT-III to diagnose the CAN bus lines.

Q: Is the check result normal?

YES : Go to Step 2

NO : Repair the CAN bus lines. (Refer to GROUP 54D – Troubleshooting [P.54D-16](#).) On completion, go to Step 3.

Step 2. MUT-III diagnosis code.

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Replace the A/C-ECU, and then go to Step 3.

NO : If a trouble is solved, it is determined that there is an intermittent malfunction such as poor engaged connector(s) or open circuit. (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

Step 3. MUT-III diagnosis code

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Return to Step 1.

NO : The procedure is complete.

Code No.U1100: Engine CAN communication time-out

⚠ CAUTION

If diagnosis code No. U1100 is set in the A/C-ECU, diagnose the CAN main bus line.

⚠ CAUTION

Whenever the ECU is replaced, ensure that the communication circuit is normal.

TROUBLE JUDGMENT**U1100**

- A/C-ECU receives engine control system-related signals from the engine-ECU <M/T> or the engine-A/T-ECU <A/T> via CAN bus lines. If the display unit can not receive the necessary signals, diagnosis code U1100 will be set.

COMMENTS ON TROUBLE SYMPTOM**Current trouble**

- Connector(s) or wiring harness in the CAN bus lines between the engine-ECU <M/T>, engine-A/T-ECU <A/T> and the A/C-ECU, the power supply system to the engine-A/T-ECU, the A/C-ECU, the engine-ECU <M/T> or the engine-A/T-ECU <A/T> may be defective.

Past trouble

- Carry out diagnosis with particular emphasis on connector(s) or wiring harness in the CAN bus lines between the engine-ECU <M/T>, engine-A/T-ECU <A/T> and the A/C-ECU, the power supply system to the engine-ECU <M/T>

or the engine-A/C-ECU <A/T>. For diagnosis procedures, refer to "How to cope with past trouble" (Refer to GROUP 00– How to Use Troubleshooting/Inspection Service Points P.00-5).

NOTE: For a past trouble, you can not find it by the MUT-III CAN bus diagnostics even if there is any failure in CAN bus lines. In this case, refer to GROUP 00, How to Cope with Intermittent Malfunctions P.00-5 and check the CAN bus lines. You can narrow down the possible cause of the trouble by referring to the diagnosis code, which is set regarding the CAN communication-linked ECUs (Refer to GROUP 54D – Explanation about the MUT-III CAN bus diagnostics P.54D-9).

⚠ CAUTION

If the ignition switch is turned to the ON position without starting the engine, the diagnosis code U1100 (past trouble) may be set to the A/C-ECU after three minutes.

POSSIBLE CAUSES

- Damaged harness wires and connectors
- Malfunction of engine-ECU <M/T> or engine-A/T-ECU <A/T>
- Malfunction of the A/C-ECU

Step 1. MUT-III CAN bus diagnostics

Use the MUT-III to diagnose the CAN bus lines.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the CAN bus lines. (Refer to GROUP 54D – Troubleshooting P.54D-16. Repair the CAN bus line and then go to Step 6.

Step 2. MUT-III Diagnosis code of other systems

Check whether the engine-related diagnosis code is set.

Q: Is the diagnosis code set?

YES : Diagnose the engine control system. Refer to P.13A-20.

NO : Go to Step 3.

Step 3. MUT-III Diagnosis code of other systems

Check if a diagnosis code, which relates to CAN communication-linked systems below, is set.

- Combination meter

U1100: Engine-related time-out diagnosis code

- Multi-centre display

U1100: Engine-related time-out diagnosis code

- ETACS

011 or 012: diagnosis code of engine-related time-out

Q: Is the diagnosis code set?

YES : Go to Step 4.

NO : Go to Step 5.

Step 4. Check whether the diagnosis code is reset.

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.

2. Ignition switch: LOCK (OFF) to ON

3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Replace the engine-ECU <M/T> or the engine-A/T-ECU <A/T>, go to Step 6.

NO : A poor connection, open circuit or other intermittent malfunction is present in the CAN bus lines between the engine-ECU <M/T> or the engine-A/T-ECU <A/T> and the A/C-ECU. (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)

Step 5. Check whether the diagnosis code is reset.

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.

2. Ignition switch: LOCK (OFF) to ON

3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Replace the A/C-ECU, and then go to Step 6.

NO : A poor connection, open circuit or other intermittent malfunction is present in the CAN bus lines between the engine-ECU <M/T> or the engine-A/T-ECU <A/T> and the A/C-ECU. (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)

Step 6. Check whether the diagnosis code is reset.

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Return to Step 1.

NO : The procedure is complete.

Code No.U1109: ETACS related CAN communication time-out**⚠ CAUTION**

If diagnosis code No. U1109 is set in the A/C-ECU, diagnose the CAN main bus line.

⚠ CAUTION

Whenever the ECU is replaced, ensure that the communication circuit is normal.

TROUBLE JUDGMENT

The A/C-ECU receives air conditioner operation-related signal from the ETACS-ECU via the CAN bus lines. If the A/C-ECU can not receive the air conditioner operation-related signal at all on the ETACS-ECU, diagnosis code No.U1109 will be set.

COMMENTS ON TROUBLE SYMPTOM**Current trouble**

- Connector(s) or wiring harness in the CAN bus lines between the ETACS-ECU and the A/C-ECU, the power supply system to the ETACS-ECU, the ETACS-ECU itself, or the A/C-ECU may be defective.

Past trouble

- Carry out diagnosis with particular emphasis on connector(s) or wiring harness in the CAN bus lines between the ETACS-ECU and the A/C-ECU, and the power supply system to the ETACS-ECU. For diagnosis procedures, refer to "How to cope with past trouble" (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NOTE: For a past trouble, you can not find it by the MUT-III CAN bus diagnostics even if there is any failure in CAN bus lines. In this case, refer to GROUP 00 – How to Cope with Intermittent Malfunctions [P.00-5](#) and check the CAN bus lines. You can narrow down the possible cause of

the trouble by referring to the diagnosis code, which is set regarding the CAN communication-linked ECUs (Refer to GROUP 54D – Explanation about the MUT-III CAN bus diagnostics [P.54D-9](#)).

⚠ CAUTION

If the ignition switch is turned to the ON position without starting the engine, the diagnosis code U1109 (past trouble) may be set to the A/C-ECU after three minutes.

POSSIBLE CAUSES

- Damaged harness wires and connectors
- Malfunction of ETACS-ECU
- Malfunction of the A/C-ECU

Step 1. MUT-III CAN bus diagnostics

Use the MUT-III to diagnose the CAN bus lines.

Q: Is the check result normal?

YES : Go to Step 2

NO : Repair the CAN bus lines. (Refer to GROUP 54D – Troubleshooting [P.54D-16](#).) On completion, go to Step 6.

Step 2. MUT-III Diagnosis code of other systems

Check whether the ETACS-related diagnosis code is set.

Q: Is the diagnosis code set?

YES : Diagnose the ETACS-ECU. Refer to [P.54B-29](#).

NO : Go to Step 3

Step 3. MUT-III Diagnosis code of other systems

Check if a diagnosis code, which relates to CAN communication-linked systems below, is set.

- combination meter

U1109: ETACS-related time-out diagnosis code

Q: Is the diagnosis code set?

YES : Go to Step 4
NO : Go to Step 5

Step 4. Check whether the diagnosis code is reset.

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Replace the ETACS-ECU, and then go to Step 6 .

NO : A poor connection, open circuit or other intermittent malfunction in the CAN bus line between the ETACS-ECU and the A/C-ECU. (Refer to GROUP 00 – How to Cope with Intermittent Malfunction [P.00-5](#).)

Step 5. Check whether the diagnosis code is reset.

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Replace the A/C-ECU, and then go to Step 6 .

NO : A poor connection, open circuit or other intermittent malfunction in the CAN bus line between the ETACS-ECU and the A/C-ECU. (Refer to GROUP 00 – How to Cope with Intermittent Malfunction [P.00-5](#).)

Step 6. Check whether the diagnosis code is reset.

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Return to Step 1.

NO : The procedure is complete.

Code No.U1113 Multi-centre display CAN communication time-out**⚠ CAUTION**

If diagnosis code No. U1113 is set in the A/C-ECU, diagnose the CAN main bus line.

⚠ CAUTION

Whenever the ECU is replaced, ensure that the communication circuit is normal.

TROUBLE JUDGMENT

The A/C-ECU receives air conditioner operation-related signal from the multi-centre display via the CAN bus lines. If the A/C-ECU can not receive the air conditioner operation-related signal at all on the multi-centre display, diagnosis code No.U1113 will be set.

COMMENTS ON TROUBLE SYMPTOM**Current trouble**

- Connector(s) or wiring harness in the CAN bus lines between the multi-centre display and the A/C-ECU, the power supply system to the multi-centre display, the multi-centre display itself, or the A/C-ECU may be defective.

Past trouble

- Carry out diagnosis with particular emphasis on connector(s) or wiring harness in the CAN bus lines between the multi-centre display and the A/C-ECU, and the power supply system to the multi-centre display. For diagnosis procedures, refer to "How to cope with past trouble" (Refer to GROUP 00– How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NOTE: For a past trouble, you can not find it by the MUT-III CAN bus diagnostics even if there is any failure in CAN bus lines. In this case, refer to GROUP 00 – How to Cope with Intermittent Malfunctions [P.00-5](#) and check the CAN bus lines. You can narrow down the possible cause of the trouble by referring to the diagnosis code, which is set regarding the CAN communication-linked ECUs (Refer to GROUP 54D – Explanation about the MUT-III CAN bus diagnostics [P.54D-9](#)).

⚠ CAUTION

If the ignition switch is turned to the ON position without starting the engine, the diagnosis code U1113 (past trouble) may be set to the A/C-ECU after three minutes.

POSSIBLE CAUSES

- Damaged harness wires and connectors
- Malfunction of multi-centre display
- Malfunction of the A/C-ECU

Step 1. MUT-III CAN bus diagnostics

Use the MUT-III to diagnose the CAN bus lines.

Q: Is the check result normal?

YES : Go to Step 2

NO : Repair the CAN bus lines. (Refer to GROUP 54D – Troubleshooting [P.54D-16](#).) On completion, go to Step 6.

Step 2. MUT-III Diagnosis code of other systems

Check that the multi-centre display unit sets a diagnosis code.

Q: Is the diagnosis code set?

YES : Diagnose the multi-centre display. Refer to [P.54A-144](#).

NO : Go to Step 3

Step 3. MUT-III Diagnosis code of other systems

Check if a diagnosis code, which relates to CAN communication-linked systems below, is set.

- ETACS

15: Multi-centre display-related time-out diagnosis code

Q: Is the diagnosis code set?

YES : Go to Step 4

NO : Go to Step 5

Step 4. Check whether the diagnosis code is reset.

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Replace the multi-centre display, and then go to Step 6 .

NO : A poor connection, open circuit or other intermittent malfunction in the CAN bus line between the multi-centre display and the A/C-ECU. (Refer to GROUP 00 – How to Cope with Intermittent Malfunction [P.00-5](#).)

Step 5. Check whether the diagnosis code is reset.

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Replace the A/C-ECU, and then go to Step 6 .

NO : A poor connection, open circuit or other intermittent malfunction in the CAN bus line between the multi-centre display and the A/C-ECU. (Refer to GROUP 00 – How to Cope with Intermittent Malfunction [P.00-5](#).)

Step 6. Check whether the diagnosis code is reset.

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Return to Step 1.

NO : The procedure is complete.

Code No.U1120 Engine-related CAN communication failure information**⚠ CAUTION**

If diagnosis code No. U1120 is set in the A/C-ECU, diagnose the CAN main bus line.

TROUBLE JUDGMENT

The A/C-ECU receives vehicle speed signal from the engine-ECU <M/T> or the engine-A/T-ECU <A/T> via CAN bus lines. If failure information is sent to the

vehicle speed signal, diagnosis code U1120 will be set.

COMMENTS ON TROUBLE SYMPTOM**Current trouble**

- The vehicle speed sensor, A/C-ECU, engine-ECU <M/T> or engine-A/T-ECU <A/T> may be defective.

Past trouble

- Carry out diagnosis with particular emphasis on connector(s) or wiring harness between the engine-ECU <M/T> or engine-A/T-ECU <A/T> and the vehicle speed sensor. For diagnosis procedures, refer to "How to treat past trouble" (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

POSSIBLE CAUSES

- Damaged harness wires and connectors
- Malfunction of the engine-A/T-ECU
- Malfunction of the A/C-ECU

Step 1. MUT-III CAN bus diagnostics

Use the MUT-III to diagnose the CAN bus lines.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the CAN bus lines. (Refer to GROUP 54D – Troubleshooting [P.54D-16](#).) On completion, go to Step 6.

Step 2. MUT-III Diagnosis code of other systems

Check whether the engine-related diagnosis code is set.

Q: Is the diagnosis code set?

YES : Diagnose the engine control system. Refer to [P.13A-20](#).

NO : Go to Step 3.

Step 3. MUT-III Diagnosis code of other systems

Check if a diagnosis code, which relates to CAN communication-linked systems below, is set.

- Combination meter
- U1120: Diagnosis code of engine-related failure information

Q: Is the diagnosis code set?

YES : Go to Step 4.

NO : Go to Step 5.

Step 4. MUT-III diagnosis code

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Replace the engine-ECU <M/T> or the engine-A/T-ECU <A/T>, go to Step 6 .

NO : A poor connection, open circuit or other intermittent malfunction between the engine-ECU <M/T> or the engine-A/T-ECU <A/T> and the vehicle speed sensor. (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

Step 5. MUT-III diagnosis code

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Replace the A/C-ECU, and then go to Step 6 .

NO : A poor connection, open circuit or other intermittent malfunction between the engine-A/T-ECU <A/T> and the vehicle speed sensor. (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

Step 6. MUT-III diagnosis code

Recheck if the diagnosis code is set.

1. Erase the diagnosis code.
2. Ignition switch: LOCK (OFF) to ON
3. Check if the diagnosis code is set.

Q: Is the diagnosis code set?

YES : Return to Step 1.

NO : The procedure is complete.

TROUBLE SYMPTOM CHART

M1554005000247


Trouble symptom	Inspection procedure number	Reference page
Communication with the MUT-III is not possible.	1	P.55-45
Cool air does not come	2	P.55-46
The front blower does not work	3	P.55-47

Trouble symptom	Inspection procedure number	Reference page
The blower air volume cannot be changed	4	P.55-59
The inside/outside air changeover is impossible. <LHD>	5	P.55-63
The inside/outside air changeover is impossible. <RHD>	6	P.55-67
The compressor does not work <LHD>	7	P.55-71
The compressor does not work <RHD>	8	P.55-78
The outlet air temperature can not be changed even if the amount of solar radiation changes	9	P.55-84
The PTC heater does not work <LHD>	10	P.55-87
The PTC heater does not work <RHD>	11	P.55-99
The rear window defogger does not work.	12	P.55-109
The A/C indicator flashes	13	P.55-119
Rear blower does not work <Vehicle with rear heater or rear cooler>	14	P.55-120
Rear blower does not work <vehicles with dual automatic A/C>	15	P.55-127
Air volume of rear blower cannot be changed	16	P.55-134
The temperature of rear air conditioner cannot be controlled <vehicles with dual automatic A/C>	17	P.55-138
A/C pressure sensor system <LHD>	18	P.55-142
A/C pressure sensor system <RHD>	19	P.55-144
Rear fan switch system <LHD>	20	P.55-146
Rear fan switch system <RHD>	21	P.55-149
Rear blower motor power supply system <LHD>	22	P.55-152
Rear blower motor power supply system <RHD>	23	P.55-160
PTC heater switch system <LHD>	24	P.55-168
PTC heater switch system <RHD>	25	P.55-171
A/C-ECU power supply system <LHD>	26	P.55-174
A/C-ECU power supply system <RHD>	27	P.55-178

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: Communication with the MUT-III is not possible.

A/C-ECU CAN-BAS Line Circuit



Wire colour code

COMMENTS ON TROUBLE SYMPTOM
 If communication with all other systems is not possible, there is a high possibility that there is a malfunction of the diagnosis line. If only the A/C system can not communicate with the MUT-III, the A/C-ECU may be defective.

POSSIBLE CAUSES

- Malfunction of the A/C-ECU

DIAGNOSIS**Step 1. Check that Engine-A/T-ECU
communicates with the MUT-III**

Use the MUT-III to confirm that it communicates with the engine-A/T-ECU.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Diagnose the MPI system. Refer to GROUP 13A – Troubleshooting [P.13A-20](#).

Step 2. MUT-III CAN bus diagnostics

Use the MUT-III to diagnose the CAN bus lines.

Q: Is the check result normal?

YES <RHD> : INSPECTION PROCEDURE 26:
Refer to A/C-ECU power supply system
<LHD>[P.55-174](#).

YES <LHD> : INSPECTION PROCEDURE 27:
Refer to A/C-ECU power supply system
<RHD>[P.55-178](#).

NO : Repair the CAN bus line (Refer to GROUP 54D - Troubleshooting [P.54D-16](#)).

INSPECTION PROCEDURE 2: Cool air does not come**CIRCUIT OPERATION**

If the blower air temperature can not be cool when turning A/C switch ON and lowering the preset temperature, inadequate refrigerant quantity, sensors, harness or connectors may be suspected.

POSSIBLE CAUSES

- Damaged the wiring harness or connectors

Step 1. Check the blower operation

- (1) Turn the ignition switch to the ON position.
- (2) Blower knob: Other than OFF
- (3) Check that the air comes out of the blower.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Refer to Inspection Procedure 3 " Front blower does not work [P.55-47](#)".

Step 3. MUT-III diagnosis code

Check that the diagnosis code related to the air conditioner is not set.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Carry out the diagnosis code procedures. Refer to [P.55-8](#).

Step 4. MUT-III data list

Check that the following service data MUT-III display contents are normal.

- Item 04: Pressure sensor
- Item 50: Front preset temperature

Q: Is the check result normal?

YES : Go to Step 5.

NO <Item 04 is abnormal> : Inspection Procedure 18: Refer to A/C pressure sensor system [P.55-142](#) <LHD> or Inspection Procedure 19: Refer to A/C pressure sensor system [P.55-144](#) <RHD>.

NO <Item 50 is abnormal> : Replacement of the A/C-ECU

STEP 5. Refrigerant level check

Check that the refrigerant level is adequate. Refer to [P.55-193](#).

Q: Is the check result normal?

YES : Intermittent malfunction. (Refer to GROUP 00 – How to Cope with Intermittent Malfunction [P.00-5](#).)

NO : Charge or remove the refrigerant level. Refer to [P.55-191](#) or [P.55-190](#).

Step 2. Check the A/C compressor operation

Check that the compressor operates under the following conditions.

- Engine operation
- Air conditioner switch: ON
- Temperature control dial: 18°C (MAX COOL)


Q: Is the check result normal?

YES : Go to Step 3.

NO <LHD> : Refer to Inspection Procedure 7 " Front compressor does not work <LHD>[P.55-71](#) ".

NO <RHD> : Refer to Inspection Procedure 8 " Front compressor does not work <RHD>[P.55-78](#) ".

INSPECTION PROCEDURE 3: The front blower does not work



COMMENTS ON TROUBLE SYMPTOM

If the blower motor does not operate, the blower motor circuit system may be defective.

POSSIBLE CAUSES

- Malfunction of the front blower motor (blower linear controller).

- Malfunction of the automatic air conditioner control panel (A/C-ECU)
- Damaged the wiring harness or connectors

DIAGNOSIS

Step 1. Check the operation of the heater control panel

Check that the A/C switch, rear window defogger switch and outside/inside air selection switch can operate.

Q: Is the check result normal?

YES <RHD> : INSPECTION PROCEDURE 26:

Refer to A/C-ECU power supply system
<LHD>[P.55-174](#) .

YES <LHD> : INSPECTION PROCEDURE 27:

Refer to A/C-ECU power supply system
<RHD>[P.55-178](#) .

NO : Repair the CAN bus line (Refer to GROUP 54D - Troubleshooting [P.54D-16](#).)

Step 2. MUT-III actuator test

Carry out the actuator test.

- Item 01, 02, 03: Front blower fan

Q: Does the blower motor work normally?

YES : Go to Step 3.

NO : Go to Step 4.



Step 3. Recheck the trouble symptom

Q: Is the check result normal?

YES : Intermittent malfunction. (GROUP 00 – How to Cope with Intermittent Malfunction [P.00-5](#))

NO : Replace the air conditioner control panel (A/C-ECU) or the blower motor (blower linear controller).

Step 4. Connector check: C-209 front blower relay connector



Q: Is the check result normal?

YES : Go to Step 5.

NO : Repair the connector.

Step 5. Check the blower relay.





Refer to GROUP 55, On-vehicle Service – Power relay check [P.55-196](#).

Q: Is the blower relay in good condition?

YES : Go to Step 6.



NO : Replace the blower relay.

Step 6. Connector check: C-13 front blower motor connector and C-105 A/C-ECU connector



YES : Go to Step 7.
NO : Repair the connector.




Step 7. Voltage measurement at the C-13 front blower motor controller connector.




(1) Disconnect the connector, and measure at the wiring harness side.

Q: Is the check result normal?

(2) Turn the ignition switch to the ON position.



(3) Disconnect A/C-ECU connector C-105, and earth terminal 45.



(4) measure the voltage between terminal 1 and

body earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 14.


NO : Go to Step 8.

Step 8. Voltage measurement at C-209 front blower relay connector.



(1) Remove the relay, and measure at the junction block side.

(2) Turn the ignition switch to the ON position.



(3) Voltage between terminal 3 and body earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 10.

NO : Go to Step 9.

Step 9. Check the wiring harness between C-209 front blower relay connector terminal No.3 and the ignition switch (IG2).





NOTE: Prior to the wiring harness inspection, check junction block connector C-202, and repair if necessary.

- Check the blower relay power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 10. Voltage measurement at C-209 front blower relay connector.



- (1) Remove the relay, and measure at the junction block side.
- (2) Turn the ignition switch to the ON position.






- (3) Voltage between terminal 5 and body earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 12.
NO : Go to Step 11.

Step 11. Check the wiring harness between C-209 front blower relay connector terminal No.5 and fusible link (30).




Prior to the wiring harness inspection, check intermediate connectors C-125 and junction block connector C-204, and repair if necessary.

- Check the blower relay power supply line for open circuit.

Q: Is the check result normal?





YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)

NO : Repair the wiring harness.



NOTE:

**Step 12. Check the wiring harness between C-209
front blower relay connector terminal No.4 and
C-13 front blower motor connector terminal No.1.**



NOTE: Prior to the wiring harness inspection, check junction block connector C-202, and repair if necessary.





- Check the blower relay earth wires for open circuit.

Q: Is the check result normal?

YES : Go to Step 13.

NO : Repair the wiring harness.

**Step 13. Check the wiring harness between C-209
front blower relay connector terminal No.1 and
C-105 A/C-ECU connector terminal No.45.**



NOTE: Prior to the wiring harness inspection, check junction block connector C-205, and repair if necessary.

- Check the blower relay power supply line for open circuit.

Q: Is the check result normal?



YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)
NO : Repair the wiring harness.

Step 14. Check the front blower motor
Refer to [P.55-208](#).

Q: Is the check result normal?

YES : Go to Step 15.
NO : Replace the outside/inside air selection damper control motor.

Step 15. Connector check: C-12 front power transistor controller connector





Q: Is the check result normal?

YES : Go to Step 16.


NO : Repair the connector.

Step 16. Resistance measurement at the C-12 front power transistor connector.



(1) Disconnect the connector, and measure at the

wiring harness side.



(2) Continuity between terminal 2 and body earth



OK: 2Ω or less

Q: Is the check result normal?

YES : Go to Step 18.

NO : Go to Step 17.

Step 17. Check the wiring harness between C-12 front power transistor connector terminal No.2 and body earth.




- Check the blower linear controller earth line for open circuit.

Q: Is the check result normal?






YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5).

NO : Repair the wiring harness.

Step 18. Check the wiring harness between C-13 front blower motor connector terminal No.2 and C-12 front power transistor controller connector terminal No.4.



Step 19. Check the wiring harness between C-106 A/C-ECU connector (terminals 2 and 3) and C-12 front power transistor controller connector (terminals 3 and 1).



- Check the blower linear controller power supply line for open circuit.

Q: Is the check result normal?

YES : Go to Step 19.

NO : Repair the wiring harness.

- Check the blower linear controller power supply line for open circuit.

Q: Is the check result normal?

YES : Go to Step 20.

NO : Repair the wiring harness.

Step 20. Replace the front power transistor and recheck the trouble symptom

Check that the front blower motor operates normally.


Q: Is the check result normal?

YES : This diagnosis is complete.

NO : Replace the A/C-ECU.

INSPECTION PROCEDURE 4: The blower air volume cannot be changed

Blower Motor Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue
 W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Gray R : Red P : Pink V : Violet

COMMENTS ON TROUBLE SYMPTOM

If the blower air volume can not be changed when the blower switch is operated, the circuit between front power transistor and A/C-ECU may be defective.

POSSIBLE CAUSES

- Front power transistor
- Damaged the wiring harness or connectors

- Malfunction of the automatic air conditioner control panel (A/C-ECU)

Step 1. MUT-III actuator test

Carry out the actuator test. (Refer to [P.55-186.](#))

- Item 01, 02, 03: Blower motor

Q: Does the blower motor work normally?

YES : Go to Step 2.

NO : Go to Step 4.

Step 2. MUT-III data list

Check that the following service data display contents are normal. (Refer to P.55-183.)

- Item 20: Front blower fan
- Item 21: Front blower fan (Target)

Q: Does the blower motor work normally?

YES : Go to Step 3.

NO : Go to Step 10.

YES : Go to Step 5.

NO : Repair the connector.

Step 3. Replace the front power transistor and check the trouble symptom

Check that the front blower motor operates normally.


Q: Does the blower motor work normally?

YES : This diagnosis is complete.


NO : Replace the automatic air conditioner control panel (A/C-ECU)

Step 4. Connector check: C-12 front power transistor controller connector

Connector: C-12 <LHD>




Connector: C-12 <RHD>




Q: Is the check result normal?

Step 5. Resistance measurement at the C-12 front power transistor connector.

Connector: C-12 <LHD>




Connector: C-12 <RHD>



(1) Disconnect the connector, and measure at the wiring harness side.

Connector C-12
(Harness side)





(2) Continuity between terminal 2 and body earth
OK: 2Ω or less

Q: Is the check result normal?

YES : Go to Step 7.

NO : Go to Step 6.

Step 6. Check the wiring harness between C-12 front power transistor connector terminal No.2 and body earth.





- Check the blower linear controller earth line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.





Step 7. Connector check: C-106 A/C-ECU controller connector



Q: Is the check result normal?

YES : Go to Step 8.
NO : Repair the connector.

Step 8. Check the wiring harness between C-106 A/C-ECU connector (terminals 2 and 3) and C-12 front power transistor controller connector (terminals 3 and 1).



YES : Go to Step 9.

NO : Repair the wiring harness.

Step 9. Replace the front power transistor and check the trouble symptom

Check that the front blower motor operates normally.

Q: Does the blower motor work normally?

YES : This diagnosis is complete.

NO : Replace the automatic air conditioner control panel (A/C-ECU)

STEP 10. Check the trouble symptom

Check that the front blower motor operates normally.

Q: Is the check result normal?

YES : This diagnosis is complete.


NO : Replace the A/C-ECU.

- Check the blower linear controller power supply line for open circuit.

Q: Is the check result normal?

INSPECTION PROCEDURE 5: The inside/outside air changeover is impossible. <LHD>

Outside/Inside Air Selection Damper Control Motor Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E16AA

COMMENTS ON TROUBLE SYMPTOM

When inside air cannot be changed to outside air vice versa even if its changeover switch is on, the outside/inside air selection damper control motor system may be defective.

POSSIBLE CAUSES

- Malfunction of the outside/inside air selection damper control motor
- Damaged the wiring harness or connectors
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

STEP 1. Check the operation of the heater control panel

Check that the A/C switch, rear window defogger switch and air volume control dial can operate.

Q: Is the check result normal?

YES : Go to Step 2.

NO : INSPECTION PROCEDURE 26: Refer to A/C-ECU power supply system <LHD>[P.55-174](#) .

Step 2. MUT-III actuator test

Carry out the actuator test. (Refer to [P.55-186](#).)


- Item 30: In/out changeover dumper: Recirc
- Item 31: In/out changeover dumper: Fresh

Q: Does the blower motor work normally?

YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : Go to Step 3.

Step 3. Connector check: C-10 outside/inside air selection damper control motor connector




Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the connector.


Step 4. Voltage measurement at C-10 outside/inside air selection damper control motor connector.



(1) Disconnect the connector, and measure at the

wiring harness side.

(2) Turn the ignition switch to the ON position.



(3) Measure the voltage between terminal 1 and body earth.


OK: System voltage

Q: Is the check result normal?



YES : Go to Step 6.

NO : Go to Step 5.

Step 5. Check the wiring harness between C-10 outside/inside air selection damper control motor connector terminal No.1 and the ignition switch (IG2).



NOTE:



Prior to the wiring harness inspection, check joint connector C-31 and junction block connectors C-205 and C-202, and repair if necessary.

- Check the motor power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).

NO : Repair the wiring harness.


Step 6. Check the outside/inside air selection damper control motor
Refer to [P.55-208](#).

Q: Is the check result normal?

YES : Go to Step 7.

NO : Replace the outside/inside air selection damper control motor.

Step 7. Connector check: C-105 A/C-ECU connector





Q: Is the check result normal?

YES : Go to Step 8.

NO : Repair the connector.

Step 8. Check the wiring harness between C-105 A/C-ECU connector (terminals 37 and 38) and C-10 outside/inside air selection damper control motor connector (terminals 2 and 3).

YES : Replace the automatic air conditioner control panel (A/C-ECU).
NO : Repair the wiring harness.




- Check the motor activating lines for open or short circuit.

Q: Is the check result normal?

INSPECTION PROCEDURE 6: The inside/outside air changeover is impossible. <RHD>

Outside/Inside Air Selection Damper Control Motor Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E17AA

COMMENTS ON TROUBLE SYMPTOM

When inside air cannot be changed to outside air vice versa even if its changeover switch is on, the outside/inside air selection damper control motor system may be defective.

POSSIBLE CAUSES

- Malfunction of the outside/inside air selection damper control motor
- Damaged the wiring harness or connectors
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

STEP 1. Check the operation of the heater control panel

Check that the A/C switch, rear window defogger switch and air volume control dial can operate.

Q: Is the check result normal?

YES : Go to Step 2.

NO : INSPECTION PROCEDURE 27: Refer to A/C-ECU power supply system <RHD>[P.55-178](#) .

Step 2. MUT-III actuator test

Carry out the actuator test.


- Item 30: In/out changeover dumper: Recirc
- Item 31: In/out changeover dumper: Fresh

Q: Does the blower motor work normally?

YES : Replace the automatic air conditioner control panel (A/C-ECU)

NO : Go to Step 3.

Step 3. Connector check: C-10 outside/inside air selection damper control motor connector




Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the connector.


Step 4. Voltage measurement at C-10 outside/inside air selection damper control motor connector.



(1) Disconnect the connector, and measure at the

wiring harness side.

(2) Turn the ignition switch to the ON position.



(3) Measure the voltage between terminal 1 and body earth.


OK: System voltage

Q: Is the check result normal?



YES : Go to Step 6.

NO : Go to Step 5.

Step 5. Check the wiring harness between C-10 outside/inside air selection damper control motor connector terminal No.1 and the ignition switch (IG2).



NOTE:



Prior to the wiring harness inspection, check joint connector C-01 and junction block connectors C-205 and C-202, and repair if necessary.

- Check the motor power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5.](#))

NO : Repair the wiring harness.

Step 6. Check the outside/inside air selection damper control motor


Refer to GROUP 55, Resistor, blower motor and inside/outside air selection damper control motor [P.55-208.](#)

Q: Is the check result normal?

YES : Go to Step 7.

NO : Replace the outside/inside air selection damper control motor.

Step 7. Connector check: C-105 A/C-ECU connector





Q: Is the check result normal?

YES : Go to Step 8.

NO : Repair the connector.

Step 8. Check the wiring harness between C-105 A/C-ECU connector (terminals 37 and 38) and C-10 outside/inside air selection damper control motor connector (terminals 2 and 3).

YES : Replace the automatic air conditioner control panel (A/C-ECU).
NO : Repair the wiring harness.




- Check the motor activating lines for open or short circuit.

Q: Is the check result normal?

INSPECTION PROCEDURE 7: The compressor does not work <LHD>

A/C Compressor Assembly Circuit



COMMENTS ON TROUBLE SYMPTOM

When the A/C compressor does not work, the A/C

compressor circuit system or the CAN bus line may be defective.

POSSIBLE CAUSES

- Malfunction of A/C compressor
- Malfunction of A/C compressor relay
- Malfunction of A/C pressure sensor
- Damaged harness wires and connectors
- Malfunction of engine-ECU <M/T> or engine-A/T-ECU <A/T>
- Malfunction of the A/C-ECU

Step 1. MUT-III CAN bus diagnostics

Use the MUT-III to diagnose the CAN bus lines.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the CAN bus lines. (Refer to GROUP 54D – Troubleshooting [P.54D-16](#).)

Step 2. MUT-III diagnosis code

Check whether the air conditioner sets a diagnosis code or not.

Q: Is the check result normal?

YES : Go to Step 3.

NO : Refer to diagnosis code chart [P.55-8](#).

Step 3. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183](#).)

- Item 04: Pressure sensor


Q: Is the check result normal?

YES : Go to Step 4.


NO : Inspection Procedure 18: Refer to A/C pressure sensor system [P.55-142 <LHD>](#).

Step 4. Connector check: B-120 A/C compressor assembly connector and C-110 engine-ECU connector <M/T> or engine-A/T-ECU <A/T>

Connector: B-120 <LHD>



Connector: C-110 <LHD>




Q: Is the check result normal?

YES : Go to Step 5.

NO : Repair the connector.



Step 5. Voltage measurement at B-120 A/C compressor assembly connector.

Connector: B-120 <LHD>




(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the "ON" position.



(3) Disconnect engine-ECU connector or engine-A/T-ECU connector C-110 and earth terminal 8.



(4) Voltage between terminal 1 and body earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 13.

NO : Go to Step 6.

Step 6. Check the A/C compressor relay continuity.


Refer to GROUP 55, On vehicle service-power relay P.55-196.

Q: Is the A/C compressor relay in good condition?

YES : Go to Step 7.


NO : Replace the A/C compressor relay.

Step 7. Voltage measurement at B-16X A/C compressor relay connector.



(1) Remove the relay, and measure at the relay block side.

(2) Turn the ignition switch to the "ON" position.



(3) Voltage between terminal 3 and body earth.





OK: System voltage

Q: Is the check result normal?

YES : Go to Step 9.

NO : Go to Step 8.

Step 8. Check the wiring harness between B-16X A/C compressor relay connector terminal No.3 and the ignition switch (IG2).




Prior to the wiring harness inspection, check junction block connectors C-202, C-205, joint connector C-31 and intermediate connector C-17, and repair if necessary.

- Check the A/C compressor relay power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 9. Voltage measurement at B-16X A/C compressor relay connector.



(1) Remove the relay, and measure at the relay block side.




(2) Voltage between terminal 4 and body earth.

OK: System voltage


Q: Is the check result normal?

YES : Go to Step 11.
NO : Go to Step 10.

Step 10. Check the wiring harness between B-16X A/C compressor relay connector terminal No.4 and the fusible link (26).



NOTE:




Prior to the wiring harness inspection, check intermediate connector A-16, and repair if necessary.

- Check the A/C compressor relay power supply line for open circuit.



Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 11. Check the wiring harness between B-16X A/C compressor relay connector terminal No.2 and C-110 engine-ECU <M/T> or engine-A/T-ECU <A/T> connector terminal No.8.



Step 12. Check the wiring harness between B-16X A/C compressor relay connector terminal No.1 and B-120 A/C compressor assembly connector terminal No.1.




- Check the A/C compressor relay power supply line for open circuit.

Q: Is the check result normal?

YES : Go to Step 12.

NO : Repair the wiring harness.



- Check the A/C compressor power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)

NO : Repair the wiring harness.

Step 13. Check the magnetic clutch operation.
Refer to P.55-219.

Q: Can the sound of the magnetic clutch (click) be heard?

YES : Go to Step 14.

NO : Replace the compressor magnet clutch.

Step 14. Check the refrigerant temperature switch.
Refer to [P.55-221](#).

Q: Is the refrigerant temperature switch operating properly?
YES : Go to Step 15.
NO : Replace the refrigerant temperature switch.

Step 15. Check the refrigerant level.
Refer to [P.55-193](#).

Q: Is the refrigerant level correct?

YES : Go to Step 16.
NO : Correct the refrigerant level (Refer to On-vehicle Service [P.55-191](#).)

Step 16. Replace the A/C-ECU, and then recheck the trouble symptom


Check that the compressor works normally.

Q: Is the check result normal?

YES : This diagnosis is complete.
NO : Replace the engine-ECU or the engine-A/T-ECU.

INSPECTION PROCEDURE 8: The compressor does not work <RHD>

A/C Compressor Circuit



COMMENTS ON TROUBLE SYMPTOM

When the A/C compressor does not work, the A/C

compressor circuit system or the CAN bus line may be defective.

POSSIBLE CAUSES

- Malfunction of A/C compressor
- Malfunction of A/C compressor relay
- Malfunction of A/C pressure sensor
- Damaged harness wires and connectors
- Malfunction of engine-ECU <M/T> or engine-A/T-ECU <A/T>
- Malfunction of the A/C-ECU

Step 1. MUT-III CAN bus diagnostics

Use the MUT-III to diagnose the CAN bus lines.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the CAN bus lines. (Refer to GROUP 54D – Troubleshooting [P.54D-16](#).)

Step 2. MUT-III diagnosis code

Check whether the air conditioner sets a diagnosis code or not.

Q: Is the check result normal?

YES : Go to Step 3.

NO : Refer to diagnosis code chart [P.55-8](#).

Step 3. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183](#).)

- Item 04: Pressure sensor


Q: Is the check result normal?

YES : Go to Step 4.


NO : Inspection Procedure 19: Refer to A/C pressure sensor system [P.55-144 <RHD>](#).

Step 4. Connector check: B-120 A/C compressor assembly connector and C-110 engine-ECU connector <M/T> or engine-A/T-ECU <A/T>

Connector: B-120 <RHD>



Connector: C-110 <RHD>




Q: Is the check result normal?

YES : Go to Step 5.

NO : Repair the connector.



Step 5. Voltage measurement at B-120 A/C compressor assembly connector.

Connector: B-120 <RHD>




(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the "ON" position.



(3) Disconnect engine-ECU connector or engine-A/T-ECU connector C-110 and earth terminal 8.



(4) Voltage between terminal 1 and body earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 13.

NO : Go to Step 6.

Step 6. Check the A/C compressor relay continuity.


Refer to GROUP 55 - On vehicle service, power relay [P.55-196](#).

Q: Is the A/C compressor relay in good condition?

YES : Go to Step 7.


NO : Replace the A/C compressor relay.

Step 7. Measure the voltage at B-16X A/C compressor relay connector.



(1) Remove the relay, and measure at the relay block side.

(2) Turn the ignition switch to the "ON" position.



(3) Voltage between terminal 3 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 9.

NO : Go to Step 8.


Step 8. Check the wiring harness between B-16X A/C compressor relay connector terminal No.3 and the ignition switch (IG2).




Connector: C-01 <RHD>



Connector: C-17 <RHD>



Connectors: C-202, C-205 <RHD>
Junction block (Front view)



NOTE:


Prior to the wiring harness inspection, check junction block connectors C-202, C-205, joint connector C-01 and intermediate connector C-17, and repair if necessary.

- Check the A/C compressor relay power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5).
NO : Repair the wiring harness.

Step 9. Measure the voltage at B-16X A/C compressor relay connector.



(1) Remove the relay, and measure at the relay block side.




(2) Voltage between terminal 4 and body earth.

OK: System voltage



Q: Is the check result normal?

YES : Go to Step 11.
NO : Go to Step 10.

Step 10. Check the wiring harness between B-16X A/C compressor relay connector terminal No.4 and the fusible link (26).



NOTE:





Prior to the wiring harness inspection, check intermediate connector A-16, and repair if necessary.

- Check the A/C compressor relay power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).
NO : Repair the wiring harness.

Step 11. Check the wiring harness between B-16X A/C compressor relay connector terminal No.2 and C-110 engine-ECU <M/T> or engine-A/T-ECU <A/T> connector terminal No.8.





- Check the A/C compressor relay power supply line for open circuit.

Q: Is the check result normal?

YES : Go to Step 12.
NO : Repair the wiring harness.

Step 12. Check the wiring harness between B-16X A/C compressor relay connector terminal No.1 and B-120 A/C compressor assembly connector terminal No.1.



- Check the A/C compressor power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).
NO : Repair the wiring harness.

Step 13. Check the magnetic clutch operation.
Refer to [P.55-219](#).

Q: Can the sound of the magnetic clutch (click) be heard?

YES : Go to Step 14.
NO : Replace the compressor magnet clutch.

Step 14. Check the refrigerant temperature switch.
Refer to [P.55-221](#).

Q: Is the refrigerant temperature switch operating properly?
YES : Go to Step 15.
NO : Replace the refrigerant temperature switch.

Step 15. Check the refrigerant level.
Refer to [P.55-193](#).

Q: Is the refrigerant level correct?

YES : Go to Step 16.

NO : Correct the refrigerant level (Refer to On-vehicle Service [P.55-191](#)).

Step 16. Replace the A/C-ECU, and then recheck the trouble symptom


Check that the compressor works normally.

Q: Is the check result normal?

YES : This diagnosis is complete.
NO : Replace the engine-ECU or the engine-A/T-ECU.

INSPECTION PROCEDURE 9: The outlet air temperature can not be changed even if the amount of solar radiation changes

Photo Sensor Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E13AA

CIRCUIT OPERATION

When the blower air temperature can not be changed even if the amount of solar radiation is changed, the photo sensor may be defective.

POSSIBLE CAUSES

- Malfunction of photo sensor
- Damaged harness wires and connectors
- Malfunction of the A/C-ECU

DIAGNOSIS

Step 1. MUT-III diagnosis code.

Check whether the air conditioner sets a diagnosis code or not.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Refer to diagnosis code chart [P.55-8](#).

Step 2. MUT-III data list.

Check that the following service data display contents are normal. (Refer to [P.55-183](#).)

- Item 06: Photo sensor

Q: Is the check result normal?

YES : Go to Step 3.

NO : Go to Step 4.


STEP 3. Recheck the trouble symptom

Q: Is the check result normal?




YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).
NO : Replace the automatic air conditioner control panel (A/C-ECU).

YES : Go to Step 5.
NO : Repair the connector.

Step 4. Connector check: C-03 photo sensor connector and C-106 A/C-ECU connector



Step 5. Check the wiring harness between C-03 photo sensor connector (terminal 1 and 2) and C-106 A/C-ECU connector (terminal 1 and 23).



- Check the A/C compressor relay power supply line for open circuit.

Q: Is the check result normal?

Q: Is the check result normal?

YES : Go to Step 6.

NO : Repair the wiring harness. Check that the air conditioner works normally.

Step 6. Replace the photo sensor and recheck the trouble symptom

Check that the air conditioner works normally.


Q: Is the check result normal?

YES : This diagnosis is complete.

NO : Replace the automatic air conditioner control panel (A/C-ECU).

INSPECTION PROCEDURE 10: The PTC heater does not work <LHD>

PTC Heater Relay Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E041A

COMMENTS ON TROUBLE SYMPTOM

When the PTC heater does not work under the following conditions, the PTC heater switch system or the PTC heater circuit system may be defective.

PTC heater operating conditions

- PTC heater switch: ON
- Air outlet: FOOT/DEF, FOOT, FACE/FOOT
- Temperature control dial: MAX HOT
- Coolant temperature: 82 degrees celsius or less

NOTE: When the coolant temperature becomes above 82 degrees celsius and PTC heater stops the operation, the PTC heater does not operate until coolant temperature becomes below 72 degrees celsius.

POSSIBLE CAUSES

- Malfunction of the PTC heater switch system
- Damaged the wiring harness or connectors
- Malfunction of the PTC heater relay 1
- Malfunction of the PTC heater relay 2
- Malfunction of the PTC heater
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183](#).)


- Item 35: PTC heater switch

Q: Does the blower motor work normally?

YES : Go to Step 4.

NO : Go to Step 2.

Step 2. Connector check: C-106 A/C-ECU connector




Q: Is the check result normal?


YES : Go to Step 3.

NO : Repair the connector.

Step 3. Voltage measurement at C-106 A/C-ECU connector.



- (1) Disconnect the connector, and measure at the wiring harness side.
- (2) Turn the ignition switch to the "ON" position.
- (3) Turn the PTC heater switch to the "ON" position.



- (4) Voltage between terminal 26 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 28.

NO : Inspection Procedure 24: Refer to PTC heater switch system <LHD>[P.55-168](#) .

Step 4. Connector check: C-103 PTC heater connector




Q: Is the check result normal?


YES : Go to Step 5.

NO : Repair the connector.

Step 5. Resistance measurement at the C-103 PTC heater connector.



(1) Disconnect the connector, and measure at the wiring harness side.




(2) Continuity between terminal 1 and body earth
OK: 2Ω or less

Q: Is the check result normal?

YES : Go to Step 7.

NO : Go to Step 6.

Step 6. Check the wiring harness between C-103 PTC heater connector terminal No.1 and body earth.




- Check the PTC heater earth line for open circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)

NO : Repair the wiring harness.

Step 7. Resistance measurement at the C-103 PTC heater connector.



(1) Disconnect the connector, and measure at the wiring harness side.




(2) Continuity between terminal 3 and body earth
OK: 2Ω or less

Q: Is the check result normal?

YES : Go to Step 9.

NO : Go to Step 8.

Step 8. Check the wiring harness between C-103 PTC heater connector terminal No.3 and body earth.




- Check the PTC heater earth line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)

NO : Repair the wiring harness.

Step 9. Connector check: C-105 A/C-ECU connector




Q: Is the check result normal?

YES : Go to Step 10.



NO : Repair the connector.

Step 10. Voltage measurement at C-103 PTC heater connector.




(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the "ON" position.



(3) Disconnect A/C-ECU connector C-105 and earth terminal 46.



(4) Voltage between terminal 2 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 19.

NO : Go to Step 11.

Step 11. Connector check: C-206 PTC heater relay 1 controller connector



Q: Is the check result normal?

YES : Go to Step 12.

NO : Repair the connector.

Step 12. Check the PTC heater switch relay 1 continuity.


Refer to [P.55-196](#).

Q: Is the PTC heater switch relay 1 in good condition?

YES : Go to Step 13.


NO : Replace the PTC heater switch relay 1.

Step 13. Voltage measurement at C-206 PTC heater relay 1 connector.



(1) Remove the relay, and measure at the relay block side.

(2) Turn the ignition switch to the "ON" position.



(3) Voltage between terminal 3 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 15.

NO : Go to Step 14.

Step 14. Check the wiring harness between C-206 PTC heater relay 1 connector terminal No.3 and the ignition switch (IG2).



NOTE:




Prior to the wiring harness inspection, check junction block connectors C-202, C-203 and joint connector C-32, and repair if necessary.

- Check the PTC heater relay 1 earth supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 15. Voltage measurement at C-206 PTC heater relay 1 connector.



- (1) Remove the relay, and measure at the relay block side.



- (2) Voltage between terminal 4 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 17.

NO : Go to Step 16.

Step 16. Check the wiring harness between C-206 PTC heater relay 1 connector terminal No.4 and the fusible link (28).



NOTE:



Prior to the wiring harness inspection, check intermediate connector C-124, and repair if necessary.



- Check the PTC heater relay 1 power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).

NO : Repair the wiring harness.

Step 17. Check the wiring harness between C-206 PTC heater relay 1 connector terminal No.1 and C-105 A/C-ECU connector terminal No.46.



NOTE: Prior to the wiring harness inspection, check joint connector C-01, and repair if necessary.



- Check the PTC heater relay 1 earth line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 18.

NO : Repair the wiring harness.

Step 18. Check the wiring harness between C-206 PTC heater relay 1 connector terminal No.5 and C-103 PTC heater connector terminal No.2.




- Check the PTC heater relay 1 power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).
NO : Repair the wiring harness.



Step 19. Voltage measurement at C-103 PTC heater connector.




- Disconnect the connector, and measure at the

wiring harness side.

- Turn the ignition switch to the "ON" position.



- Disconnect A/C-ECU connector C-105 and earth terminal 46.




- Voltage between terminal 4 and body earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 28.
NO : Go to Step 20.

Step 20. Connector check: C-207 PTC heater relay 2 controller connector



Q: Is the check result normal?

YES : Go to Step 21.

NO : Repair the connector.

Step 21. Check the PTC heater relay 2 continuity.


Refer to GROUP 55 - On vehicle service, power relay [P.55-196](#).

Q: Is the PTC heater relay 2 in good condition?

YES : Go to Step 22.


NO : Replace the PTC heater relay 2.

Step 22. Voltage measurement at C-207 PTC heater relay 2 connector.



(1) Remove the relay, and measure at the relay block side.

(2) Turn the ignition switch to the "ON" position.



(3) Voltage between terminal 3 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 24.

NO : Go to Step 23.

Step 23. Check the wiring harness between C-207 PTC heater relay 2 connector terminal No.3 and the ignition switch (IG2).



NOTE:




Prior to the wiring harness inspection, check junction block connectors C-202, C-203 and joint connector C-32, and repair if necessary.

- Check the PTC heater relay 2 power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 24. Voltage measurement at C-207 PTC heater relay 2 connector.



- (1) Remove the relay, and measure at the relay block side.



- (2) Voltage between terminal 4 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 26.

NO : Go to Step 25.

Step 25. Check the wiring harness between C-207 PTC heater relay 2 connector terminal No.4 and the fusible link (28).



NOTE:



Prior to the wiring harness inspection, check intermediate connector C-124, and repair if necessary.



- Check the PTC heater relay 2 power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).

NO : Repair the wiring harness.

Step 26. Check the wiring harness between C-207 PTC heater relay 2 connector terminal No.1 and C-105 A/C-ECU connector terminal No.46.



NOTE: Prior to the wiring harness inspection, check joint connector C-01, and repair if necessary.


- Check the PTC heater relay 2 earth line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 27.

NO : Repair the wiring harness.


Step 27. Check the wiring harness between C-207 PTC heater relay 2 connector terminal No.5 and C-103 PTC heater connector terminal No.4.



YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)
NO : Repair the wiring harness.

STEP 28. Check the trouble symptom
 Check that the PTC heater works normally.


Q: Is the check result normal?
YES : This diagnosis is complete.
NO : Replace the A/C-ECU.



- Check the PTC heater power supply line for open circuit.

Q: Is the check result normal?

INSPECTION PROCEDURE 11: The PTC heater does not work <RHD>



COMMENTS ON TROUBLE SYMPTOM

When the PTC heater does not work under the following conditions, the PTC heater switch system or the PTC heater circuit system may be defective.

PTC heater operating conditions

- PTC heater switch: ON
- Air outlet: FOOT/DEF, FOOT, FACE/FOOT
- Temperature control dial: MAX HOT

- Coolant temperature: 82 degrees celsius or less

NOTE: When the coolant temperature becomes above 82 degrees celsius and PTC heater stops the operation, the PTC heater does not operate until coolant temperature becomes below 72 degrees celsius.

POSSIBLE CAUSES

- Malfunction of the PTC heater switch system

- Damaged the wiring harness or connectors
- Malfunction of the PTC heater relay 1
- Malfunction of the PTC heater relay 2
- Malfunction of the PTC heater
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183](#).)


- Item 35: PTC heater switch

Q: Does the blower motor work normally?

YES : Go to Step 4.

NO : Go to Step 2.

Step 2. Connector check: C-106 A/C-ECU connector




Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.


Step 3. Voltage measurement at C-106 A/C-ECU connector.



(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the "ON" position.

(3) Turn the PTC heater switch to the "ON" position.



(4) Voltage between terminal 26 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 28.

NO : Inspection Procedure 25: Refer to PTC heater switch system <RHD>[P.55-171](#) .

Step 4. Connector check: C-103 PTC heater connector




Q: Is the check result normal?

YES : Go to Step 5.


NO : Repair the connector.

Step 5. Resistance measurement at the C-103 PTC heater connector.



(1) Disconnect the connector, and measure at the

wiring harness side.



(2) Continuity between terminal 1 and body earth


OK: 2Ω or less

Q: Is the check result normal?

YES : Go to Step 7.

NO : Go to Step 6.

Step 6. Check the wiring harness between C-103 PTC heater connector terminal No.1 and body earth.




- Check the PTC heater earth line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)


NO : Repair the wiring harness.

Step 7. Measure the resistance at the C-103 PTC heater connector.



- (1) Disconnect the connector, and measure at the

wiring harness side.



(2) Continuity between terminal 3 and body earth


OK: 2Ω or less

Q: Is the check result normal?

YES : Go to Step 9.

NO : Go to Step 8.

Step 8. Check the wiring harness between C-103 PTC heater connector terminal No.3 and body earth.




- Check the PTC heater earth line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)

NO : Repair the wiring harness.

Step 9. Connector check: C-105 A/C-ECU connector




Q: Is the check result normal?

YES : Go to Step 10.



NO : Repair the connector.

Step 10. Voltage measurement at C-103 PTC heater connector.




(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the "ON" position.



(3) Disconnect A/C-ECU connector C-105 and earth

terminal 46.



(4) Voltage between terminal 2 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 19.

NO : Go to Step 11.

Step 11. Connector check: C-206 PTC heater relay 1 controller connector



Q: Is the check result normal?

YES : Go to Step 12.

NO : Repair the connector.

Step 12. Check the PTC heater switch relay 1 continuity.


Refer to GROUP 55 - On vehicle service, power relay P.55-196.

Q: Is the PTC heater switch relay 1 in good condition?


YES : Go to Step 13.

NO : Replace the PTC heater switch relay 1.

Step 13. Voltage measurement at C-206 PTC heater relay 1 connector.



- (1) Remove the relay, and measure at the relay block side.
- (2) Turn the ignition switch to the "ON" position.



- (3) Voltage between terminal 3 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 15.

NO : Go to Step 14.

Step 14. Check the wiring harness between C-206 PTC heater relay 1 connector terminal No.3 and the ignition switch (IG2).



NOTE: Prior to the wiring harness inspection, check junction block connectors C-202 and C-203, and repair if necessary.

- Check the PTC heater relay 1 earth line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent

malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)


NO : Repair the wiring harness.

Step 15. Measure the voltage at C-206 PTC heater relay 1 connector.



- (1) Remove the relay, and measure at the relay block

side.



(2) Voltage between terminal 4 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 17.

NO : Go to Step 16.

Step 16. Check the wiring harness between C-206 PTC heater relay 1 connector terminal No.4 and the fusible link (28).



NOTE:





Prior to the wiring harness inspection, check intermediate connector C-124, and repair if necessary.

- Check the PTC heater relay 1 power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 17. Check the wiring harness between C-206 PTC heater relay 1 connector terminal No.1 and C-105 A/C-ECU connector terminal No.46.





- Check the PTC heater relay 1 earth line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 18.

NO : Repair the wiring harness.

Step 18. Check the wiring harness between C-206 PTC heater relay 1 connector terminal No.5 and C-103 PTC heater connector terminal No.2.




- Check the PTC heater relay 1 power supply line for open circuit.

Q: Is the check result normal?



YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).
NO : Repair the wiring harness.

Step 19. Measure the voltage at C-103 PTC heater connector.




- Disconnect the connector, and measure at the

wiring harness side.
(2) Turn the ignition switch to the "ON" position.



- Disconnect A/C-ECU connector C-105 and earth terminal 46.




- Voltage between terminal 4 and body earth.
OK: System voltage

Q: Is the check result normal?

YES : Go to Step 28.
NO : Go to Step 20.

Step 20. Connector check: C-207 PTC heater relay 2 controller connector



Q: Is the check result normal?

YES : Go to Step 21.

NO : Repair the connector.

Step 21. Check the PTC heater relay 2 continuity.


Refer to GROUP 55 - On vehicle service, power relay [P.55-196](#).

Q: Is the PTC heater relay 2 in good condition?

YES : Go to Step 22.


NO : Replace the PTC heater relay 2.

Step 22. Voltage measurement at C-207 PTC heater relay 2 connector.



(1) Remove the relay, and measure at the relay block side.

(2) Turn the ignition switch to the "ON" position.



(3) Voltage between terminal 3 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 24.

NO : Go to Step 23.

Step 23. Check the wiring harness between C-207 PTC heater relay 2 connector terminal No.3 and the ignition switch (IG2).



NOTE: Prior to the wiring harness inspection, check junction block connectors C-202 and C-203, and repair if necessary.


- Check the PTC heater relay 2 power supply line for open circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

NO : Repair the wiring harness.

Step 24. Voltage measurement at C-207 PTC heater relay 2 connector.



(1) Remove the relay, and measure at the relay block side.



(2) Voltage between terminal 4 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 26.


NO : Go to Step 25.

Step 25. Check the wiring harness between C-207 PTC heater relay 2 connector terminal No.4 and the fusible link (28).



NOTE:

Connector: C-124 <RHD>



Prior to the wiring harness inspection, check intermediate connector C-124, and repair if necessary.

- Check the PTC heater relay 2 power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent




malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5).

NO : Repair the wiring harness.

Step 26. Check the wiring harness between C-207 PTC heater relay 2 connector terminal No.1 and C-105 A/C-ECU connector terminal No.46.



Step 27. Check the wiring harness between C-207 PTC heater relay 2 connector terminal No.5 and C-103 PTC heater connector terminal No.4.



- Check the PTC heater relay 2 earth line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 27.

NO : Repair the wiring harness.

- Check the PTC heater power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent

malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).

NO : Repair the wiring harness.

STEP 28. Check the trouble symptom


Check that the PTC heater works normally.

Q: Is the check result normal?

YES : This diagnosis is complete.

NO : Replace the A/C-ECU.

INSPECTION PROCEDURE 12: The rear window defogger does not work.



W4X55E039A

CIRCUIT OPERATION

If the rear window defogger does not operate when the rear window defogger switch is turned on, the rear window defogger relay system may be defective.

TROUBLESHOOTING HINTS

- Malfunction of the A/C-ECU
- Malfunction of the rear window defogger relay
- Damaged the wiring harness or connectors
- Malfunction of the rear window defogger

DIAGNOSIS

Step 1. Check the A/C and outside/inside air selection damper control motor operation.




Q: Do the A/C and outside/inside air selection damper control motor work normally?

YES : Go to Step 2.

NO <LHD> : Refer to Inspection procedure 26
 "Malfunction of the A/C-ECU power supply system <LHD>[P.55-174](#) ."

NO <RHD> : Refer to Inspection procedure 27
 "Malfunction of the A/C-ECU power supply system <RHD>[P.55-178](#) ."

Step 2. Connector check: C-106 A/C-ECU connector and G-07 rear window defogger




Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.


Step 3. Voltage measurement at G-07 rear window defogger connector.



(1) Disconnect the connector, and measure at the

wiring harness side.

- (2) Turn the ignition switch to the "ON" position.
- (3) Disconnect A/C-ECU connector C-105 and earth terminal 46.



- (4) Measure the voltage between terminal 1 and body earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 12.

NO : Go to Step 4.

Step 4. Connector check: C-208 rear window defogger relay connector



Q: Is the check result normal?

YES : Go to Step 5.

NO : Repair the connector.

Step 5. Check the rear window defogger relay continuity.



Refer to P.55-196.

Q: Is the rear window defogger relay in good condition?

YES : Go to Step 6.

NO : Replace the rear window defogger relay.


Step 6. Voltage measurement at C-208 rear window defogger relay connector.



(1) Remove the relay, and measure at the junction

block side.

Connector C-208
(Junction block side)



(2) Measure the voltage between terminal 5 and body earth.




OK: System voltage

Q: Is the check result normal?

YES : Go to Step 8.

NO : Go to Step 7.

Step 7. Check the wiring harness between C-208 rear window defogger relay connector terminal No.5 and the fusible link (30).




Prior to the wiring harness inspection, check intermediate connectors C-125, and junction block connector C-204, and repair if necessary.

- Check the rear window defogger relay power supply line for open or short circuit.

Q: Is the check result normal?



YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)

NO : Repair the wiring harness.




NOTE:

Step 8. Voltage measurement at C-208 rear window defogger relay connector.



- (1) Remove the relay, and measure at the junction block side.
- (2) Turn the ignition switch to the "ON" earth position.



- (3) Voltage between terminal 3 and body earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 10.

NO : Go to Step 9.

Step 9. Check the wiring harness between C-208 rear window defogger relay connector No.3 and ignition switch (IG2).



NOTE: Prior to the wiring harness inspection, check junction block connector C-202, and repair if necessary.





- Check the rear window defogger power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5.](#))

NO : Repair the wiring harness.

**Step 10. Check the wiring harness between C-208
rear window defogger relay connector No.3 and
C-106 A/C-ECU connector No.12.**



NOTE: Prior to the wiring harness inspection, check junction block connector C-205, and repair if necessary.




- Check the rear window defogger power supply line for open circuit.

Q: Is the check result normal?

YES : Go to Step 11.

NO : Repair the wiring harness.

**Step 11. Check the wiring harness between C-208
rear window defogger relay connector No.4 and
G-07 rear window defogger connector No.1.**



NOTE: Prior to the wiring harness inspection, check junction block connector C-210 and intermediate connector G-14, and repair if necessary.


- Check the rear window defogger relay line for open or short circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5.](#))

NO : Repair the wiring harness.

Step 12. Connector check: G-02 rear window defogger connector




Q: Is the check result normal?


YES : Go to Step 13.

NO : Repair the connector.

Step 13. Resistance measurement at G-02 rear window defogger connector.



(1) Disconnect the connector, and measure at the wiring harness side.



(2) Continuity between terminal 1 and body earth.


OK: 2Ω or less

Q: Is the check result normal?

YES : Go to Step 15.

NO : Go to Step 14.

Step 14. Check the wiring harness between G-02 rear window defogger connector terminal No.1 and earth.



- Check the rear window defogger earth line for open or short circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).
NO : Repair or replace the wiring harness.

Step 15. Check the rear window defogger.

Refer to GROUP 54A, Rear Window rear window defogger Switch Inspection [P.54A-176](#).

Q: Does the rear window defogger work normally?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).
NO : Repair the rear window defogger.

INSPECTION PROCEDURE 13: The A/C indicator flashes

CIRCUIT OPERATION

If the A/C indicator flashes then the possible causes may be due to a defective A/C pressure system or insufficient refrigerant gas.

TROUBLESHOOTING HINTS

- Malfunction of the A/C pressure sensor
- Malfunction of the outside thermo sensor
- Malfunction of the A/C-ECU

Step 1. MUT-III CAN bus diagnostics

Use the MUT-III to diagnose the CAN bus lines.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the CAN bus lines. (Refer to GROUP 54D – Troubleshooting [P.54D-16](#).)

Step 2. MUT-III diagnosis code

Check whether the air conditioner sets a diagnosis code or not.

Q: Is the check result normal?

YES : Go to Step 3.

NO : Refer to diagnosis code chart [P.55-8](#).

Step 3. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183](#).)

- Item 04: Pressure sensor

Q: Is the check result normal?

YES : Go to Step 4.


NO : Inspection Procedure 18: Refer to A/C pressure sensor system [P.55-142](#) <LHD> or Inspection Procedure 19: Refer to A/C pressure sensor system [P.55-144](#) <RHD>.

Step 4. Check the refrigerant level.Refer to [P.55-193](#).**Q: Is the refrigerant level correct?**

YES : Go to Step 5.

NO : Correct the refrigerant level (Refer to On-vehicle Service [P.55-191](#).)**STEP 5. Recheck the trouble symptom****Q: Is the check result normal?**YES : Intermittent malfunction. (Refer to GROUP 00 – How to Cope with Intermittent Malfunction [P.00-5](#).)NO : Inspection Procedure 18: Refer to A/C pressure sensor system [P.55-142](#) <LHD> or Inspection Procedure 19: Refer to A/C pressure sensor system [P.55-144](#) <RHD>.**INSPECTION PROCEDURE 14: Rear blower does not work <Vehicle with rear heater or rear cooler>**


Rear Heater Controller Circuit <L.H.D>



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

Rear Heater Controller Circuit <R.H.D>



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E33AA

COMMENTS ON TROUBLE SYMPTOM

If the rear blower motor does not operate, the rear blower motor circuit system may be defective.

POSSIBLE CAUSES

- Malfunction of rear blower relay
- Malfunction of rear blower motor
- Malfunction of rear power transistor
- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

DIAGNOSIS

Step 1. MUT-III diagnosis code

Check whether the air conditioner sets a diagnosis code or not.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Refer to diagnosis code chart P.55-8.

Step 2. MUT-III actuator test

Carry out the actuator test. (Refer to [P.55-186.](#))

- Item 04: Rear blower fan: OFF
- Item 05: Rear blower fan: AUTO <vehicles with dual automatic A/C>
- Item 06: Rear blower fan: Lo
- Item 07: Rear blower fan: Middle
- Item 08: Rear blower fan: High

Q: Does the rear blower motor work normally?

YES : Go to Step 3.

NO : Go to Step 9.

Step 3. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183.](#))

- Item 22: Rear blower fan
- Item 23: Rear blower fan (Target)
- Item 31: Rear fan SW (Front)
- Item 32: Rear control OFF switch
- Item 33: Rear control fan OFF switch

Q: Is the check result normal?


YES : Go to Step 8.

NO <Item 22, 23, 32, 33 is abnormal> : Go to Step 4.


NO <Item 31 is abnormal> : Refer to Inspection Procedure 20: rear fan switch system <LHD>[P.55-146](#) or Inspection Procedure 21: rear fan switch system <RHD>[P.55-149](#)

Step 4. Connector check: E-03 rear heater controller connector

Connector: E-03 <LHD>



Connector: E-03 <RHD>



Q: Is the check result normal?

YES : Go to Step 5.

NO : Repair the connector.

STEP 5. Check the rear heater controller

Refer to [P.55-213.](#)



Q: Is the check result normal?

YES : Go to Step 6.

NO : Replace the rear heater controller.

Step 6. Connector check: C-104 A/C-ECU


YES : Go to Step 7.
NO : Repair the connector.



Q: Is the check result normal?

Step 7. Check the wiring harness between E-03 rear heater controller connector (terminals 4, 6, 7, 8 and 9) and C-104 A/C-ECU connector (terminals 70, 68, 67, 66 and 65).

Connectors: C-104, C-128 <LHD>



Harness side
C-104


61	60	59	58	57	56	55	54	53	52	51
72	71	70	69	68	67	66	65	64	63	62

C-128


1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	X	20	21	22	23	24	25

AC310614AN


Connector: E-03 <LHD>



Connector: E-03 <RHD>



Connectors: C-104, C-128 <RHD>



Harness side
C-104

61	60	59	58	57	56	55	54	53	52	51
72	71	70	69	68	67	66	65	64	63	62

C-128

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	X	20	21	22	23	24	25

AC310632AI

NOTE: Prior to the wiring harness inspection, check intermediate connector C-128, and repair if necessary.

- Check the input line for open circuit.

Q: Is the check result normal?

YES : Go to Step 8.


NO : Repair the wiring harness.

STEP 8. Recheck the trouble symptom

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5.](#))

NO : Replace the A/C-ECU.

Step 9. Connector check: C-215 rear blower motor connector


YES : Go to Step 10.
NO : Repair the connector.

STEP 10. Check the rear blower relay
Refer to [P.55-196](#).

Q: Is the check result normal?

YES : Refer to Inspection Procedure 22: Rear blower motor power supply system <LHD>[P.55-152](#) or Inspection Procedure 23: Rear blower motor power supply system <RHD>[P.55-160](#) .


NO : Replace the rear blower relay.




Q: Is the check result normal?

INSPECTION PROCEDURE 15: Rear blower does not work <vehicles with dual automatic A/C>

Rear Heater Controller Circuit <L.H.D>



Rear Heater Controller Circuit <R.H.D>



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E32AA

COMMENTS ON TROUBLE SYMPTOM

If the rear blower motor does not operate, the rear blower motor circuit system may be defective.

POSSIBLE CAUSES

- Malfunction of rear blower relay
- Malfunction of rear blower motor
- Malfunction of rear power transistor
- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

DIAGNOSIS

Step 1. MUT-III diagnosis code

Check whether the air conditioner sets a diagnosis code or not.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Refer to diagnosis code chart P.55-8.

Step 2. MUT-III actuator test

Carry out the actuator test. (Refer to [P.55-186.](#))

- Item 04: Rear blower fan: OFF
- Item 05: Rear blower fan: AUTO <vehicles with dual automatic A/C>
- Item 06: Rear blower fan: Lo
- Item 07: Rear blower fan: Middle
- Item 08: Rear blower fan: High

Q: Does the rear blower motor work normally?

YES : Go to Step 3.

NO : Go to Step 9.

Step 3. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183.](#))

- Item 22: Rear blower fan
- Item 23: Rear blower fan (Target)
- Item 31: Rear fan SW (Front)
- Item 32: Rear control OFF switch
- Item 33: Rear control fan OFF switch

Q: Is the check result normal?


YES : Go to Step 8.

NO <Item 22, 23, 32, 33 is abnormal> : Go to Step 4.


NO <Item 31 is abnormal> : Refer to Inspection Procedure 20: rear fan switch system <LHD>[P.55-146](#) or Inspection Procedure 21: rear fan switch system <RHD>[P.55-149](#)

Step 4. Connector check: E-03 rear heater controller connector

Connector: E-03 <LHD>



Connector: E-03 <RHD>



Q: Is the check result normal?

YES : Go to Step 5.

NO : Repair the connector.

STEP 5. Check the rear heater controller

Refer to [P.55-213.](#)



Q: Is the check result normal?

YES : Go to Step 6.

NO : Replace the rear heater controller.





Step 6. Connector check: C-104 A/C-ECU

YES : Go to Step 7.
NO : Repair the connector.



Q: Is the check result normal?

Step 7. Check the wiring harness between E-03 rear heater controller connector (terminals 4, 5, 6, 7, 8 and 9) and C-104 A/C-ECU connector (terminals 70, 69, 68, 67, 66 and 65).



NOTE: Prior to the wiring harness inspection, check intermediate connector C-128, and repair if necessary.

- Check the input line for open circuit.

Q: Is the check result normal?

YES : Go to Step 8.


NO : Repair the wiring harness.

STEP 8. Recheck the trouble symptom

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5.](#).)

NO : Replace the A/C-ECU.

Step 9. Connector check: C-215 rear blower motor connector


YES : Go to Step 10.
NO : Repair the connector.

STEP 10. Check the rear blower relay
Refer to [P.55-196](#).

Q: Is the check result normal?

YES : Refer to Inspection Procedure 22: Rear blower motor power supply system
<LHD>[P.55-152](#) or Inspection Procedure 23: Rear blower motor power supply system
<RHD>[P.55-160](#) .


NO : Replace the rear blower relay.



Q: Is the check result normal?

INSPECTION PROCEDURE 16: Air volume of rear blower cannot be changed

Rear Blower Motor Circuit



Wire colour code
 B : Black LG : Light green G : Green L : Blue
 W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E045A

COMMENTS ON TROUBLE SYMPTOM

If the blower air volume can not be changed when the blower switch is operated, the wiring harness between A/C-ECU and rear heater controller, and rear power transistor circuit system may be defective.

POSSIBLE CAUSES

- Malfunction of rear power transistor
- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

Step 1. MUT-III diagnosis code

Check whether the air conditioner sets a diagnosis code or not.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Refer to diagnosis code chart [P.55-8](#).

Step 2. MUT-III actuator test

Carry out the actuator test. (Refer to [P.55-186](#).)

- Item 04: Rear Blower fan: OFF
- Item 05: Rear Blower fan: AUTO <vehicles with dual automatic A/C>
- Item 06: Rear Blower fan: Lo
- Item 07: Rear Blower fan: Middle
- Item 08: Rear Blower fan: High

Q: Does the blower motor work normally?

YES : Go to Step 3.

NO : Go to Step 4.

Step 3. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183](#).)


- Item 22: Rear blower motor
- Item 23: Rear blower motor (target value)
- Item 32: Rear control OFF SW
- Item 33: Rear control FAN SW

Q: Is the check result normal?

YES : Go to Step 10.

NO : Refer to Inspection Procedure 14: Rear blower does not work <Vehicle with rear heater or rear cooler>[P.55-120](#) or
Inspection Procedure 15: Rear blower does not work <Vehicle with rear heater or rear cooler>[P.55-127](#)

Step 4. Connector check: D-11 rear power transistor connector




Q: Is the check result normal?

YES : Go to Step 5.


NO : Repair the connector.

Step 5. Resistance measurement at D-11 rear power transistor connector.



(1) Disconnect the connector, and measure at the

wiring harness side.



(2) Continuity between terminal 2 and body earth.


OK: 2 ohm or less

Q: Is the check result normal?

YES : Go to Step 7.

NO : Go to Step 6.

Step 6. Check the wiring harness between D-11 rear power transistor connector terminal No.2 and earth.



- Check the rear window defogger earth line for open or short circuit.



Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

NO : Repair or replace the wiring harness.




Step 7. Connector check: C-104 A/C-ECU
connector

YES : Go to Step 8.
NO : Repair the connector.




Q: Is the check result normal?


Step 8. Check the wiring harness between D-11 rear power transistor connector (terminal 1 and 3) and C-104 A/C-ECU connector (terminal 60 and 59).



Connector: C-15 <LHD>



Connector: C-15 <RHD>



NOTE: Prior to the wiring harness inspection, check intermediate connector C-15, and repair if necessary.

- Check the rear window defogger relay line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 9.
NO : Repair the wiring harness.

Step 9. Replace the rear power transistor and recheck the trouble symptom

Check that the rear blower motor should work normally.

Q: Is the check result normal?

YES : This diagnosis is complete.
NO : Replace the A/C-ECU.


STEP 10. Recheck the trouble symptom

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Replace the A/C-ECU.

INSPECTION PROCEDURE 17: The temperature of rear air conditioner cannot be controlled <vehicles with dual automatic A/C>

Rear heater Controller Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E050A

COMMENTS ON TROUBLE SYMPTOM

If the temperature of rear air conditioner con not be controlled, the rear heater controller circuit system or the rear air mix damper control motor circuit system may be defective.

POSSIBLE CAUSES

- Malfunction of rear air mix damper control motor
- Malfunction of rear heater controller
- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

Step 1. MUT-III diagnosis code

Check whether the air conditioner sets a diagnosis code or not.

Q: Is the check result normal?

YES : Go to Step 2.

NO : Refer to diagnosis code chart [P.55-8](#).

Step 2. MUT-III actuator test

Carry out the actuator test. (Refer to [P.55-186](#).)

- Item 13: R.Air mix dumper motor: 0%
- Item 14: R.Air mix dumper motor: 50%
- Item 15: R.Air mix dumper motor: 100%

Q: Does the rear blower motor work normally?

YES : Go to Step 3.

NO : Go to Step 8.

Step 3. MUT-III data list

Check that the following service data display contents are normal. (Refer to [P.55-183](#).)



- Item 12: R.Air mix potentiometer
- Item 13: R.Air mix potentiometer (Target)
- Item 51: Rear Temperature setting

Q: Is the check result normal?

YES : Go to Step 8.

NO : Go to Step 4.

Step 4. Connector check: E-03 rear heater controller connector



Q: Is the check result normal?

YES : Go to Step 5.

NO : Repair the connector.

STEP 5. Check the rear heater controller



Refer to [P.55-213](#).

Q: Is the check result normal?

YES : Go to Step 6.

NO : Replace the rear heater controller.

Step 6. Connector check: C-106 A/C-ECU




Q: Is the check result normal?

YES : Go to Step 7.


NO : Repair the connector.

Step 7. Check the wiring harness between E-03 rear heater controller connector (terminals 14, 15, and 16) and C-106 A/C-ECU connector (terminals 15, 14 and 1).


Connectors: C-106, C-128 <LHD>




Connector: E-03 <LHD>



Connector: E-03 <RHD>



Connectors: C-106, C-128 <RHD>



NOTE: Prior to the wiring harness inspection, check intermediate connector C-128, and repair if necessary.

- Check the input line for open circuit.

Q: Is the check result normal?

YES : Go to Step 8.

NO : Repair the wiring harness.

STEP 8. Recheck the trouble symptom


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5).

NO : Replace the A/C-ECU.

INSPECTION PROCEDURE 18: A/C pressure sensor system <LHD>

A/C Pressure Sensor



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E046A

COMMENTS ON TROUBLE SYMPTOM

If the A/C pressure sensor is defective, the damaged wiring harness between the A/C pressure sensor and the A/C-ECU may be suspected.

POSSIBLE CAUSES

- Malfunction of A/C pressure sensor
- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to P.55-183.)


- Item 04: Pressure sensor

Q: Is the check result normal?

YES : Go to Step 6.

NO : Go to Step 2.

Step 2. Connector check: A-37 A/C pressure sensor connector



Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.

Step 3. Inspection of A/C pressure sensor


Refer to P.55-195.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Replace the A/C pressure sensor.

Step 4. Connector check: C-106 A/C-ECU connector




Q: Is the check result normal?


YES : Go to Step 5.

NO : Repair the connector.

Step 5. Check the wiring harness between A-37 A/C pressure sensor connector (terminals 2, 1 and 3) and C-106 A/C-ECU connector (terminals 25, 14 and 1).



Connectors: C-01, C-106, C-125 <LHD>



NOTE: Prior to the wiring harness inspection, check intermediate connector C-125 and joint connector C-01, and repair if necessary.

- Check the input line for open circuit.

Q: Is the check result normal?

YES : Go to Step 6.

NO : Repair the wiring harness.

STEP 6. Recheck the trouble symptom


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).

NO : Replace the A/C-ECU.

INSPECTION PROCEDURE 19: A/C pressure sensor system <RHD>

Outside/Inside Air Selection Damper Control Motor Circuit



Wire colour code
 B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W3Z08E07AA

COMMENTS ON TROUBLE SYMPTOM

If the A/C pressure sensor is defective, the damaged wiring harness between the A/C pressure sensor and the A/C-ECU may be suspected.

POSSIBLE CAUSES

- Malfunction of A/C pressure sensor
- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

Step 1. MUT-III data list

Check that the following service data display contents are normal. (Refer to P.55-183.)


- Item 04: Pressure sensor

Q: Is the check result normal?

YES : Go to Step 6.

NO : Go to Step 2.

Step 2. Connector check: A-37 A/C pressure sensor connector



Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.

Step 3. Inspection of A/C pressure sensor


Refer to P.55-195.

Q: Is the check result normal?

YES : Go to Step 4.

NO : Replace the A/C pressure sensor.

Step 4. Connector check: C-106 A/C-ECU connector




Q: Is the check result normal?


YES : Go to Step 5.

NO : Repair the connector.


Step 5. Check the wiring harness between A-37 A/C pressure sensor connector (terminals 2, 1 and 3) and C-106 A/C-ECU connector (terminals 25, 14 and 1).



Connectors: C-106 <RHD>



Connector: C-125 <RHD>



NOTE: Prior to the wiring harness inspection, check intermediate connector C-125, and repair if necessary.

- Check the input line for open circuit.

Q: Is the check result normal?

YES : Go to Step 6.

NO : Repair the wiring harness.

STEP 6. Recheck the trouble symptom


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).

NO : Replace the A/C-ECU.

INSPECTION PROCEDURE 20: Rear fan switch system <LHD>

Rear Fan Switch Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E036A

COMMENTS ON TROUBLE SYMPTOM


If a rear fan switch signal is not set to the A/C-ECU, the rear fan switch or the rear fan switch circuit system may be defective.

POSSIBLE CAUSES

- Malfunction of the rear fan switch
- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

DIAGNOSIS

Step 1. Connector check: C-19 rear fan switch



Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the connector.

Step 2. Check the rear fan switch


Refer to P.55-199.

Q: Is the check result normal?

YES : Go to Step 3.


NO : Replace the rear fan switch.

Step 3. Voltage measurement at C-19 rear fan switch connector.



(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the ON position.



(3) Measure the voltage between terminal 1 and body earth.

OK: System voltage


Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 4.


Step 4. Check the wiring harness between C-19 rear fan switch connector terminal No.1 and the ignition switch (IG2).

Connectors: C-19, C-31 <LHD>



NOTE:

Connectors: C-202, C-205 <LHD>
Junction block (Front view)




Prior to the wiring harness inspection, check joint connector C-31 and junction block connector C-205 and C-202, and repair if necessary.

- Check the rear fan switch power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)
NO : Repair the wiring harness.


Step 5. Connector check: C-104 A/C-ECU connector.



Q: Is the check result normal?

YES : Go to Step 6.
NO : Repair the connector.

Step 6. Check the wiring harness between C-19 rear fan switch connector terminal No.2 and C-104 A/C-ECU connector terminal No.71.



- Check the rear fan switch activating lines for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 7.
NO : Repair the wiring harness.


STEP 7. Recheck the trouble symptom

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)
NO : Replace the A/C-ECU.

INSPECTION PROCEDURE 21: Rear fan switch system <RHD>

Rear Fan Switch Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E29AA

COMMENTS ON TROUBLE SYMPTOM


If a rear fan switch signal is not set to the A/C-ECU, the rear fan switch or the rear fan switch circuit system may be defective.

POSSIBLE CAUSES

- Malfunction of the rear fan switch
- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

DIAGNOSIS

Step 1. Connector check: C-19 rear fan switch



Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the connector.

Step 2. Check the rear fan switch


Refer to P.55-199.

Q: Is the check result normal?

YES : Go to Step 3.


NO : Replace the rear fan switch.

Step 3. Voltage measurement at C-19 rear fan switch connector



(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the ON position.



(3) Measure the voltage between terminal 1 and body earth.

OK: System voltage


Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 4.

Step 4. Check the wiring harness between C-19 rear fan switch connector terminal No.1 and the ignition switch (IG2).

Connectors: C-01, C-19 <RHD>



C-01

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22
23	24	25	26	27	28	29	30	31	32	33

Harness side


C-19

6	5	4	3	2	1
---	---	---	---	---	---

AC310632AJ

NOTE:

Connectors: C-202, C-205 <RHD>
Junction block (Front view)



Harness side

C-202

2			1
6	5	4	3

Harness side

C-205

14	13	12	11	10	9	8	7	6	5	4	3	2	1
28	27	26	25	24	23	22	21	20	19	18	17	16	15

AC310619AF


Prior to the wiring harness inspection, check joint connector C-01 and junction block connector C-205 and C-202, and repair if necessary.

- Check the rear fan switch power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.



Step 5. Connector check: C-104 A/C-ECU connector



Q: Is the check result normal?

YES : Go to Step 6.
NO : Repair the connector.

Step 6. Check the wiring harness between C-19 rear fan switch connector terminal No.2 and C-104 A/C-ECU connector terminal No.71.



- Check the rear fan switch activating lines for open or short circuit.

Q: Is the check result normal?


YES : Go to Step 7.
NO : Repair the wiring harness.

STEP 7. Recheck the trouble symptom

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Replace the A/C-ECU.

INSPECTION PROCEDURE 22: Rear blower motor power supply system <LHD>

**CIRCUIT OPERATION**

If the rear blower motor does not operate, the rear blower motor circuit system may be defective.


POSSIBLE CAUSES

- Malfunction of rear blower relay

- Malfunction of rear blower motor
- Malfunction of rear power transistor
- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

W4X55E30AA

Step 1. Connector check: C-215 rear blower motor connector



Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the connector.

Step 2. Check the rear blower relay


Refer to [P.55-196](#).

Q: Is the check result normal?

YES : Go to Step 3.

NO : Replace the rear blower relay.

Step 3. Connector check: C-15 intermediate connector




Q: Is the check result normal?

YES : Go to Step 4.



NO : Repair the connector.

Step 4. Voltage measurement at C-15 intermediate connector.




(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the ON position.



(3) Disconnect A/C-ECU connector C-104 and earth terminal 56.



(4) Measure the voltage between terminal 1 and

body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 11.


NO : Go to Step 5.

Step 5. Voltage measurement at C-215 rear blower relay connector.



(1) Remove the relay, and measure at the relay block side.

(2) Turn the ignition switch to the "ON" position.



(3) Voltage between terminal 3 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 7.

NO : Go to Step 6.

Step 6. Check the wiring harness between C-215 rear blower relay connector terminal No.3 and the ignition switch (IG2).



NOTE:



Prior to the wiring harness inspection, check junction block connectors C-202, C-205 and joint connector C-31, and repair if necessary.


- Check the rear blower relay power supply line for open circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5).

NO : Repair the wiring harness.

Step 7. Voltage measurement at C-215 rear blower relay connector.



- (1) Remove the relay, and measure at the relay block side.
- (2) Turn the ignition switch to the "ON" position.



- (3) Voltage between terminal 4 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 9.

NO : Go to Step 8.

Step 8. Check the wiring harness between C-215 rear blower relay connector terminal No.4 and the fusible link (30).



NOTE:



Prior to the wiring harness inspection, check intermediate connector C-125 and junction block connector C-201, and repair if necessary.


- Check the rear blower relay power supply line for open circuit.

Q: Is the check result normal?




YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5).

NO : Repair the wiring harness.

Step 9. Check the wiring harness between C-215 rear blower relay connector terminal No.2 and C-104 A/C-ECU connector terminal No.56.



Step 10. Check the wiring harness between C-215 rear blower relay connector terminal No.4 and C-15 intermediate connector terminal No.1.



NOTE: Prior to the wiring harness inspection, check junction block connector C-201, and repair if necessary.

- Check the rear blower relay power supply line for open circuit.

Q: Is the check result normal?

YES : Go to Step 10.

NO : Repair the wiring harness.

NOTE: Prior to the wiring harness inspection, check junction block connector C-201, and repair if necessary.


- Check the rear blower relay power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).

NO : Repair the wiring harness.

Step 11. Connector check: D-10 rear blower motor



Q: Is the check result normal?

YES : Go to Step 12.

NO : Repair the connector.

YES : Go to Step 14.
NO : Repair the wiring harness.

Step 12. Check the rear blower motor



Refer to [P.55-217](#).

Q: Is the check result normal?

YES : Go to Step 13.

NO : Replace the rear blower motor.


Step 13. Check the wiring harness between D-10 rear blower motor connector terminal No.1 and C-15 intermediate connector terminal No.1.



- Check the rear blower relay power supply line for open circuit.

Q: Is the check result normal?

Step 14. Connector check: D-11 rear power transistor connector




Q: Is the check result normal?


YES : Go to Step 15.

NO : Repair the connector.

Step 15. Resistance measurement at the D-11 rear power transistor connector.



(1) Disconnect the connector, and measure at the wiring harness side.




(2) Continuity between terminal 2 and body earth
OK: 2Ω or less

Q: Is the check result normal?

YES : Go to Step 17.

NO : Go to Step 16.

Step 16. Check the wiring harness between D-11 rear power transistor terminal No.2 and body earth.



- Check the blower linear controller earth line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)

NO : Repair the wiring harness.

YES : Go to Step 18.
NO : Repair the connector.

Step 18. Check the wiring harness between D-11 rear power transistor connector terminal No.4 and D-10 rear blower motor connector terminal No.2.




- Check the blower linear controller earth line for open circuit.

Q: Is the check result normal?


YES : Go to Step 19.
NO : Repair the wiring harness.

Step 17. Connector check: C-104 A/C-ECU connector



Q: Is the check result normal?

Step 19. Check the wiring harness between D-11 rear power transistor connector (terminal 1 and 3) and D-10 A/C-ECU connector (terminal 60 and 59).



YES : Go to Step 20.
NO : Repair the wiring harness.


Step 20. Replace the rear power transistor and recheck the trouble symptom

Check that the rear blower motor should work normally.

Q: Is the check result normal?

YES : This diagnosis is complete.
NO : Replace the A/C-ECU.

NOTE:




Prior to the wiring harness inspection, check intermediate connector C-15, and repair if necessary.

- Check the blower linear controller earth line for open circuit.

Q: Is the check result normal?

INSPECTION PROCEDURE 23: Rear blower motor power supply system <RHD>

Rear blower motor circuit

**CIRCUIT OPERATION**

If the rear blower motor does not operate, the rear blower motor circuit system may be defective.


POSSIBLE CAUSES

- Malfunction of rear blower relay

- Malfunction of rear blower motor
- Malfunction of rear power transistor
- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

DIAGNOSIS

Step 1. Connector check: C-215 rear blower motor connector



Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the connector.

Step 2. Check the rear blower relay


Refer to P.55-196.

Q: Is the check result normal?

YES : Go to Step 3.

NO : Replace the rear blower relay.

Step 3. Connector check: C-15 intermediate connector




Q: Is the check result normal?

YES : Go to Step 4.


NO : Repair the connector.

Step 4. Voltage measurement at C-15 intermediate connector.




(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the ON position.



(3) Disconnect A/C-ECU connector C-104 and earth terminal 56.



(4) Measure the voltage between terminal 1 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 11.

NO : Go to Step 5.

Step 5. Voltage measurement at C-215 rear blower relay connector.



- (1) Remove the relay, and measure at the relay block side.
- (2) Turn the ignition switch to the "ON" position.



- (3) Voltage between terminal 3 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 7.

NO : Go to Step 6.

Step 6. Check the wiring harness between C-215 rear blower relay connector terminal No.3 and the ignition switch (IG2).



NOTE:



Prior to the wiring harness inspection, check junction block connectors C-202, C-205 and joint connector C-01, and repair if necessary.


- Check the rear blower relay power supply line for open circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5).

NO : Repair the wiring harness.

Step 7. Voltage measurement at C-215 rear blower relay connector.



- (1) Remove the relay, and measure at the relay block side.
- (2) Turn the ignition switch to the "ON" position.



- (3) Voltage between terminal 4 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 9.

NO : Go to Step 8.

Step 8. Check the wiring harness between C-215 rear blower relay connector terminal No.4 and the fusible link (30).



NOTE:



Prior to the wiring harness inspection, check intermediate connector C-125 and junction block connector C-201, and repair if necessary.


- Check the rear blower relay power supply line for open circuit.

Q: Is the check result normal?




YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5).

NO : Repair the wiring harness.

Step 9. Check the wiring harness between C-215 rear blower relay connector terminal No.2 and C-104 A/C-ECU connector terminal No.56.



Step 10. Check the wiring harness between C-215 rear blower relay connector terminal No.4 and C-15 intermediate connector terminal No.1.



NOTE: Prior to the wiring harness inspection, check junction block connector C-201, and repair if necessary.

- Check the rear blower relay power supply line for open circuit.

Q: Is the check result normal?

YES : Go to Step 10.

NO : Repair the wiring harness.

NOTE: Prior to the wiring harness inspection, check junction block connector C-201, and repair if necessary.


- Check the rear blower relay power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).

NO : Repair the wiring harness.

Step 11. Connector check: D-10 rear blower motor



Q: Is the check result normal?

YES : Go to Step 12.

NO : Repair the connector.

YES : Go to Step 14.

NO : Repair the wiring harness.

Step 12. Check the rear blower motor



Refer to [P.55-217](#).

Q: Is the check result normal?

YES : Go to Step 13.

NO : Replace the rear blower motor.


Step 13. Check the wiring harness between D-10 rear blower motor connector terminal No.1 and C-15 intermediate connector terminal No.1.



- Check the rear blower relay power supply line for open circuit.

Q: Is the check result normal?

Step 14. Connector check: D-11 rear power transistor connector




Q: Is the check result normal?


YES : Go to Step 15.

NO : Repair the connector.

Step 15. Resistance measurement at the D-11 rear power transistor connector.



- Disconnect the connector, and measure at the wiring harness side.




- Continuity between terminal 2 and body earth
OK: 2Ω or less

Q: Is the check result normal?

YES : Go to Step 17.


NO : Go to Step 16.

Step 16. Check the wiring harness between D-11 rear power transistor terminal No.2 and body earth.



YES : Go to Step 18.
NO : Repair the connector.

Step 18. Check the wiring harness between D-11 rear power transistor connector terminal No.4 and D-10 rear blower motor connector terminal No.2.




- Check the blower linear controller earth line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).
NO : Repair the wiring harness.

Step 17. Connector check: C-104 A/C-ECU connector




Q: Is the check result normal?

- Check the blower linear controller earth line for open circuit.

Q: Is the check result normal?

YES : Go to Step 19.
NO : Repair the wiring harness.

Step 19. Check the wiring harness between D-11 rear power transistor connector (terminal 1 and 3) and D-10 A/C-ECU connector (terminal 60 and 59).



YES : Go to Step 20.
NO : Repair the wiring harness.


Step 20. Replace the rear power transistor and recheck the trouble symptom

Check that the rear blower motor should work normally.

Q: Is the check result normal?

YES : This diagnosis is complete.
NO : Replace the A/C-ECU.

NOTE:




Prior to the wiring harness inspection, check intermediate connector C-15, and repair if necessary.

- Check the blower linear controller earth line for open circuit.

Q: Is the check result normal?

INSPECTION PROCEDURE 24: PTC heater switch system <LHD>



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet


W4X55E048A

COMMENTS ON TROUBLE SYMPTOM

If a PTC heater switch signal is not set to the A/C-ECU, the PTC heater switch or the PTC heater switch circuit system may be defective.

POSSIBLE CAUSES

- Malfunction of the PTC heater switch
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS**Step 1. Connector check: C-30 PTC heater switch connector**

Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the connector.

Step 2. Check the PTC heater switch.


Refer to [P.55-212](#).

Q: Is the refrigerant temperature switch operating properly?

YES : Go to Step 3.


NO : Replace the refrigerant temperature switch.

Step 3. Voltage measurement at C-30 PTC heater switch connector.



(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the "ON" position.



(3) Voltage between terminal 2 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 5.


NO : Go to Step 4.

Step 4. Check the wiring harness between C-30 PTC heater switch connector terminal No.2 and the ignition switch (IG2).



NOTE:

Connectors: C-202, C-205 <RHD>
Junction block (Front view)



Prior to the wiring harness inspection, check joint connector C-31 and junction block connector C-205 and C-202, and repair if necessary.


- Check the PTC heater switch power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#)).

NO : Repair the wiring harness.

Step 5. Connector check: C-106 A/C-ECU connector




Q: Is the check result normal?

YES : Go to Step 6.

NO : Repair the connector.

Step 6. Check the wiring harness between C-30 PTC heater switch connector terminal No.1 and C-106 A/C-ECU connector terminal No.26.



- Check the PTC heater switch earth line for open circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent

malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)

NO : Repair the wiring harness.

INSPECTION PROCEDURE 25: PTC heater switch system <RHD>

PTC Heater Switch Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E049A

COMMENTS ON TROUBLE SYMPTOM


If a PTC heater switch signal is not set to the A/C-ECU, the PTC heater switch or the PTC heater switch circuit system may be defective.

POSSIBLE CAUSES

- Malfunction of the PTC heater switch
- Malfunction of the automatic air conditioner control panel (A/C-ECU)

DIAGNOSIS

Step 1. Connector check: C-30 PTC heater switch connector



Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the connector.

Step 2. Check the PTC heater switch.


Refer to P.55-212.

Q: Is the refrigerant temperature switch operating properly?

YES : Go to Step 3.


NO : Replace the refrigerant temperature switch.

Step 3. Voltage measurement at C-30 PTC heater switch connector.



(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the "ON" position.



(3) Voltage between terminal 2 and body earth.

OK: System voltage


Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 4.

Step 4. Check the wiring harness between C-30 PTC heater switch connector terminal No.2 and the ignition switch (IG2).

Connectors: C-01, C-30 <RHD>



1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22
23	24	25	26	27	28	29	30	31	32	33

Harness side


C-30

1	2	3
4	5	6

AC310632AY

NOTE:

Connectors: C-202, C-205 <RHD>
Junction block (Front view)



Harness side


C-202

2		1
6	5	4

Harness side

C-205

2		1
6	5	4




Prior to the wiring harness inspection, check joint connector C-01 and junction block connector C-205 and C-202, and repair if necessary.

- Check the PTC heater switch power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)
NO : Repair the wiring harness.


Step 5. Connector check: C-106 A/C-ECU connector



Q: Is the check result normal?

YES : Go to Step 6.
NO : Repair the connector.

Step 6. Check the wiring harness between C-30 PTC heater switch connector terminal No.1 and C-106 A/C-ECU connector terminal No.26.




- Check the PTC heater switch earth line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)
NO : Repair the wiring harness.

INSPECTION PROCEDURE 26: A/C-ECU power supply system <LHD>

A/C-ECU Power Supply Circuit



CIRCUIT OPERATION

If a power supply is not provided to the A/C-ECU, the A/C-ECU power supply system or the earth system may be defective.


POSSIBLE CAUSES

- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

W4X55E18AA

DIAGNOSIS

Step 1. Connector check: C-106 A/C-ECU connector




Q: Is the check result normal?

YES : Go to Step 2.


NO : Repair the connector.

Step 2. Voltage measurement at C-106 A/C-ECU connector.



(1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the ON position.



(3) Measure the voltage between terminal 6 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 4.

NO : Go to Step 3.

Step 3. Check the wiring harness between C-106 A/C-ECU connector terminal No.6 and the ignition switch (IG2).



NOTE:




Prior to the wiring harness inspection, check joint connector C-31 and junction block connector C-205 and C-202, and repair if necessary.

- Check the A/C-ECU power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 4. Voltage measurement at C-106 A/C-ECU connector.



- (1) Disconnect the connector, and measure at the wiring harness side.
- (2) Turn the ignition switch to the ON position.




- (3) Measure the voltage between terminal 5 and body earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 6.
NO : Go to Step 5.

Step 5. Check the wiring harness between C-106 A/C-ECU connector terminal No.5 and the ignition switch (ACC).




NOTE: Prior to the wiring harness inspection, check joint connector C-32 and intermediate connector C-125, and repair if necessary.

- Check the A/C-ECU power supply line for open circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 6. Voltage measurement at C-106 A/C-ECU connector.



- (1) Disconnect the connector, and measure at the

wiring harness side.



(2) Measure the voltage between terminal 4 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 8.

NO : Go to Step 7.

Step 7. Check the wiring harness between C-106 A/C-ECU connector terminal No.4 and the fusible link (30).




NOTE: Prior to the wiring harness inspection, check joint connector C-32 and intermediate connector C-125, and repair if necessary.

- Check the rear fan switch power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5).
NO : Repair the wiring harness.

Step 8. Measure the resistance at the C-106 front power transistor connector.



(1) Disconnect the connector, and measure at the wiring harness side.




(2) Continuity between terminal 7 and body earth
OK: 2Ω or less

Q: Is the check result normal?

YES : Replace the A/C-ECU.

NO : Go to Step 9.

Step 9. Check the wiring harness between C-106 A/C-ECU connector terminal No.7 and body earth.



- Check the A/C-ECU earth line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5.](#))

NO : Repair the wiring harness.

INSPECTION PROCEDURE 27: A/C-ECU power supply system <RHD>

A/C-ECU Power Supply Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Gray R : Red P : Pink V : Violet

W4X55E19AA


CIRCUIT OPERATION

may be defective.

If a power supply is not provided to the A/C-ECU, the A/C-ECU power supply system or the earth system

POSSIBLE CAUSES


- Malfunction of the A/C-ECU
- Damaged harness wires and connectors

DIAGNOSIS**Step 1. Connector check: C-106 A/C-ECU connector**


Q: Is the check result normal?

YES : Go to Step 2.

NO : Repair the connector.

Step 2. Voltage measurement at C-106 A/C-ECU connector.

- (1) Disconnect the connector, and measure at the wiring harness side.
- (2) Turn the ignition switch to the ON position.



- (3) Measure the voltage between terminal 6 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 4.

NO : Go to Step 3.

Step 3. Check the wiring harness between C-106 A/C-ECU connector terminal No.6 and the ignition switch (IG2).



NOTE:




Prior to the wiring harness inspection, check joint connector C-01 and junction block connector C-205 and C-202, and repair if necessary.

- Check the A/C-ECU power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 4. Voltage measurement at C-106 A/C-ECU connector.



- (1) Disconnect the connector, and measure at the wiring harness side.
- (2) Turn the ignition switch to the ON position.



- (3) Measure the voltage between terminal 5 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 6.

NO : Go to Step 5.

Step 5. Check the wiring harness between C-106 A/C-ECU connector terminal No.5 and the ignition switch (ACC).



NOTE:




Prior to the wiring harness inspection, check joint connector C-01 and intermediate connector C-125, and repair if necessary.

- Check the A/C-ECU power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 6. Voltage measurement at C-106 A/C-ECU connector.



- (1) Disconnect the connector, and measure at the wiring harness side.



- (2) Measure the voltage between terminal 4 and body earth.


OK: System voltage

Q: Is the check result normal?


YES : Go to Step 8.

NO : Go to Step 7.

Step 7. Check the wiring harness between C-106 A/C-ECU connector terminal No.4 and the fusible link (26).



NOTE:




Prior to the wiring harness inspection, check joint connector C-31 and intermediate connector C-125, and repair if necessary.

- Check the rear fan switch power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-5.)
NO : Repair the wiring harness.

Step 8. Resistance measurement at the C-106 front power transistor connector.



- (1) Disconnect the connector, and measure at the wiring harness side.




- (2) Continuity between terminal 7 and body earth
OK: 2Ω or less

Q: Is the check result normal?

YES : Replace the A/C-ECU.
NO : Go to Step 9.

Step 9. Check the wiring harness between C-106 A/C-ECU connector terminal No.7 and body earth.



YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-5](#).)
NO : Repair the wiring harness.

SERVICE DATA REFERENCE TABLE

M1554005100192

NOTE: Prior to the wiring harness inspection, check joint connector C-01, and repair if necessary.

- Check the A/C-ECU earth line for open circuit.

Q: Is the check result normal?

Item No.	Check items	Inspection status	The display contents under normal conditions
01	Inside temperature sensor	—	Interior temperature is the same as MUT-III displayed temperature
02	Outside temperature sensor	—	Ambient temperature is the same as MUT-III displayed temperature
03	Air thermo sensor	—	Evaporator outlet temperature is the same as MUT-III displayed temperature
04	Pressure sensor	—	Refrigerant pressure is the same as MUT-III displayed pressure.
05	heater water temperature sensor	—	The coolant temperature is the same as MUT-III displayed temperature
06	Photo sensor	—	The amount of solar radiation is indirectly proportional to MUT-III displayed voltage

Item No.	Check items	Inspection status	The display contents under normal conditions
10	F.Air mix potentiometer	Front air mix damper position: MAX HOT	Approximately 100%
		Front air mix damper position: MAX COOL	Approximately 0%
11	F.Air mix potentiometer (Target)	–	Display the target value for air mix damper
12	R.Air mix potentiometer <Vehicles with Dual automatic A/C>	Rear air mix damper position: MAX HOT	Approximately 100%
		Rear air mix damper position: MAX COOL	Approximately 0%
13	R.Air mix potentiometer (Target) <Vehicles with Dual automatic A/C>	–	Display the target value for air mix damper
14	F.Air outlet c/o potentiometer	Air outlet changeover damper position: FACE	Opening angle: approximately 100%
		Air outlet changeover damper position: DEF	Opening angle: approximately 0%
15	F.Air outlet c/o potentiometer (Target)	–	Display the target value for air mix damper
16	In/out air damper motor	Outside/inside air selection switch: ON	Inside air
		Outside/inside air selection switch: OFF	Outside air
20	Front blower fan	Air volume control dial: Other than OFF	Display the rotation speed of front blower motor
21	Front blower fan (Target)	Air volume control dial: Other than OFF <Vehicles with multi-centre display>	Display the target rotation speed of front blower motor
22	Rear blower fan <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear fan switch: ON	Display the rotation speed of rear blower motor
		Rear air volume adjusting switch: Other than OFF	
23	Rear blower fan (Target) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear fan switch: ON	Display the target rotation speed of rear blower motor
		Rear air volume adjusting switch: Other than OFF	
30	Air conditioner switch	Compressor ON	ON
		Compressor OFF	OFF
31	Rear fan SW (Front) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear fan switch: ON	ON
		Rear fan switch: OFF	OFF
32	Rear control OFF switch <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear air volume adjusting switch: OFF	OFF controlled
		Rear air volume adjusting switch: Other than OFF	ON controlled

Item No.	Check items	Inspection status	The display contents under normal conditions
33	Rear control fan OFF switch <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear air volume adjusting switch: AUTO	AUTO
		Rear air volume adjusting switch: 1	Lo
		Rear air volume adjusting switch: 2	Me
		Rear air volume adjusting switch: 3	Hi
34	Rear defogger switch	Rear window defogger switch: ON	ON
		Rear window defogger switch: OFF	OFF
35	PTC heater switch <Vehicles with rear heater, rear cooler or dual automatic A/C>	Heater switch ON	ON
		Heater switch OFF	OFF
36	Rear fan SW lamp (Front) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear fan switch: ON	ON
		Rear fan switch: OFF	OFF
37	Rear control OFF SW lamp (Front) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear fan switch: ON	ON
38	Rear control OFF SW lamp <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear air volume adjusting switch: OFF	ALL OFF
		Rear air volume adjusting switch: AUTO	AUTO
		Rear air volume adjusting switch: 1	Lo
		Rear air volume adjusting switch: 2	Me
		Rear air volume adjusting switch: 3	Hi
		—	ALL ON
39	PTC heater lamp <Vehicles with rear heater or dual automatic A/C>	Heater switch ON	ON
		Heater switch OFF	OFF
40	Illuminations power supply	Lighting switch: ON	ON
		Lighting switch: OFF	OFF
41	PTC heater relay <Vehicles with rear heater or dual automatic A/C>	PTC heater relay: ON	ON
		PTC heater relay: OFF	OFF

Item No.	Check items	Inspection status	The display contents under normal conditions
50	Front Temperature setting	—	Display the temperature control dial position (18.0 - 32.0°C)
51	Rear Temperature setting <Vehicles with rear heater, rear cooler or dual automatic A/C>	—	Display the rear temperature control lever position (20.0 - 30.0°C)
55	Refrigerant leak	Normal refrigerant level	NORMAL
		Checking refrigerant level	Checking
		Defective refrigerant level	Fail
56	Low pressure	Normal refrigerant pressure	NORMAL
		Checking refrigerant pressure	Checking
		Defective refrigerant pressure	Fail

ACTUATOR TEST TABLE

M1554005200188

Item No.	Check items	Drive content
01	Front blower fan: OFF	Stop
02	Front blower fan: Middle	Middle speed
03	Front blower fan: High	High speed
04	Rear blower fan: OFF <Vehicles with rear heater, rear cooler or dual automatic A/C>	Stop
05	Rear blower fan: AUTO <Vehicles with rear heater, rear cooler or dual automatic A/C>	AUTO
06	Rear blower fan: Lo <Vehicles with rear heater, rear cooler or dual automatic A/C>	Low speed
07	Rear blower fan: Middle <Vehicles with rear heater, rear cooler or dual automatic A/C>	Middle speed
08	Rear blower fan: High <Vehicles with rear heater, rear cooler or dual automatic A/C>	High speed
09	Condenser fan: OFF	Stop
0A	Condenser fan: 50%	Middle speed
0B	Condenser fan: 100%	High speed
10	F.Air mix dumper motor: 0%	Opening angle: Approximately 0% (MAX COOL)
11	F.Air mix dumper motor: 50%	Opening angle: Approximately 50%
12	F.Air mix dumper motor: 100%	Open angle: Approximately 100% (MAX COOL)
13	R.Air mix dumper motor: 0% <Vehicles with rear heater, rear cooler or dual automatic A/C>	Opening angle: Approximately 0% (MAX COOL)
14	R.Air mix dumper motor: 50% <Vehicles with rear heater, rear cooler or dual automatic A/C>	Opening angle: Approximately 50%

Item No.	Check items	Drive content
15	R.Air mix dumper motor: 100% <Vehicles with rear heater, rear cooler or dual automatic A/C>	Open angle: Approximately 100% (MAX COOL)
20	Air outlet c/o dumper: FACE	Air outlet at FACE position
21	Air outlet c/o dumper: Bi-Level	Air outlet at FACE/FOOT position
22	Air outlet c/o dumper: FOOT	Air outlet at FOOT position
23	Air outlet c/o dumper: DEF/FOOT	Air outlet at DEF/FOOT position
24	Air outlet c/o dumper: DEF	Air outlet at DEF position
30	In/out changeover dumper: Recirc	Moved to recirculation-side
31	In/out changeover dumper: Fresh	Moved to outside air-side
40	Rear defogger switch: OFF	Rear window defogger OFF
41	Rear defogger switch: ON	Rear window defogger ON
42	PTC heater relay: OFF <Vehicles with rear heater or dual automatic A/C>	PTC heater OFF
43	PTC heater relay: ON <Vehicles with rear heater or dual automatic A/C>	PTC heater ON (air outlet at FACE or DEF position, not operate with blower OFF)
50	Idle up request: OFF	Idle rpm (not operate with compressor ON)
51	Idle up request: low load	Idle up with low load rpm
52	Idle up request: high load	Idle up with high load rpm

CHECK AT A/C-ECU TERMINALS

M1552010300668

<C-11>

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

<C-09>

31	32	33	34	35	36	37	38
39	40	41	42	43	44	45	46

<C-08>

51	52	53	54	55	56	57	58	59	60	61
62	63	64	65	66	67	68	69	70	71	72

AC303234 AB

Terminal No.	Check items	Check conditions	Normal conditions
1	Sensor earth	Always	0 V
2	Front power transistor (DRAIN)	Air volume control dial: Maximum air volume (Preset temperature 18°C)	0 – 2 V
3	Front power transistor (GATE)	Air volume control dial: Maximum air volume (Preset temperature 18°C)	System voltage
4	Back-up power supply	Always	System voltage
5	ACC power supply	Ignition switch: ACC	System voltage
6	IG2 power supply	Ignition switch: IG2	System voltage
7	Earth	Always	0 V
8~10	–	–	–
11	Compressor relay input	Compressor relay: ON	System voltage

Terminal No.	Check items	Check conditions	Normal conditions
12	Rear window defogger relay	Rear window defogger relay: ON	0 – 1 V
13	PTC heater switch indicator <Vehicles with rear heater or dual automatic A/C>	PTC heater switch: ON	0 – 1 V
		PTC switch: OFF	0 V
14	Sensor power supply:	Ignition switch: IG2	5 V
15	Rear temperature control lever <Vehicles with dual automatic A/C>	Rear temperature control lever MAX HOT position	0 V
16, 17	–	–	–
18	Interior temperature sensor	Sensor probe temperature: 25°C (4kΩ)	2.1 – 2.7 V
19	Air thermo sensor	Sensor probe temperature: 25°C (4kΩ)	2.1 – 2.7 V
20	Front air mix damper motor (Potentiometer input)	Front air mix damper motor MAX HOT position	1.2 – 1.6 V
21	Air outlet changeover damper motor (Potentiometer input)	DEF position	0.5 – 0.8 V
22	Rear air mix damper motor (Potentiometer input) <Vehicles with dual automatic A/C>	Rear air mix damper motor MAX HOT position	0.8 – 1.2 V
23	Solar sensor input	Brightness 0 lux	5 V
		Brightness 100000 lux or more	0 V
24	Ambient temperature sensor	Sensor probe temperature 25°C (1.5k Ω)	2.1 – 2.7 V
25	A/C pressure sensor input	Refer to P.55-195	Refer to P.55-195
26	Heat switch <Vehicles with dual automatic A/C>	Ignition switch: IG2 Heater switch ON	System voltage
31	Front air mix damper motor (COOL)	When the front air conditioner is moved to the COOL position	System voltage
		When the front air conditioner is moved to the HOT position	0 – 1 V
32	Front air mix damper motor (HOT)	When the front air conditioner is moved to the HOT position	System voltage
		When the front air conditioner is moved to the COOL position	0 – 1 V
33	Air outlet changeover damper motor (FACE)	When moving toward FACE position	System voltage
		When moving toward DEF position	0 – 1 V
34	Air outlet changeover damper motor (DEF)	When moving toward DEF position	System voltage
		When moving toward FACE position	0 – 1 V

Terminal No.	Check items	Check conditions	Normal conditions
35	Rear air mix damper motor (COOL) <Vehicles with dual automatic A/C>	When the rear air conditioner is moved to the COOL position	System voltage
		When the rear air conditioner is moved to the HOT position	0 – 1 V
36	Rear air mix damper motor (HOT) <Vehicles with dual automatic A/C>	When the rear air conditioner is moved to the HOT position	System voltage
		When the rear air conditioner is moved to the COOL position	0 – 1 V
37	Outside/inside air selection damper motor (Fresh air position)	When setting the Fresh air position	0 – 1 V
		When setting the air recirculation position	System voltage
38	Outside/inside air selection damper motor (Air recirculation position)	When moving to air recirculation position	0 – 1 V
		When moving to fresh air position	System voltage
35~42	–	–	–
43	ILL power supply	Lighting switch: ON	System voltage
44	ILL earth	Always	0 V
45	Front blower relay	Ignition switch: IG2	0 – 1 V
46	PTC heater relay <Vehicles with dual automatic A/C>	PTC heater: ON	0 – 1 V
		PTC heater: OFF	System voltage
51	Rear temperature control lever indicator <Vehicles with dual automatic A/C>	Rear air volume adjusting switch: OFF	System voltage
		Rear air volume adjusting switch: Other than OFF	0 – 1 V
52	Rear air conditioner switch indicator (AUTO) <Vehicles with dual automatic A/C>	Rear air volume adjusting switch: AUTO	0 – 1 V
53	Rear air conditioner switch indicator (Lo) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear air volume adjusting switch: 1	0 – 1 V
54	Rear air conditioner switch indicator (Me) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear air volume adjusting switch: 2	0 – 1 V
55	Rear air conditioner switch indicator (Hi) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear air volume adjusting switch: 3	0 – 1 V
56	Rear blower relay	Ignition switch: ON	0 – 1 V
57	–	–	–

Terminal No.	Check items	Check conditions	Normal conditions
58	Rear fan switch indicator <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear fan switch: Other than OFF	0 V
59	Rear power transistor (DRAIN)	Rear air volume adjusting switch: 3 (Preset temperature 20°C)	0 – 2 V
60	Rear power transistor (GATE)	Rear air volume adjusting switch: 3 (Preset temperature 20°C)	System voltage
61~64	–	–	–
65	Rear air conditioner switch (Shielded wire) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Always	0 V
66	Rear air conditioner switch (Hi) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear air volume adjusting switch: 3	Approximately 5 V
67	Rear air conditioner switch (Me) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear air volume adjusting switch: 2	Approximately 5 V
68	Rear air conditioner switch (Lo) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear air volume adjusting switch: 1	Approximately 5 V
69	Rear air conditioner switch (AUTO) <Vehicles with dual automatic A/C>	Rear air volume adjusting switch: AUTO	Approximately 5 V
70	Rear air conditioner switch (OFF) <Vehicles with rear heater, rear cooler or dual automatic A/C>	Rear air volume adjusting switch: OFF	Approximately 5 V
71	Rear fan switch input	Rear fan switch: ON (switch pushed) Ignition switch: IG2	System voltage
72	Rear air conditioner switch indicator power supply	Rear air volume adjusting switch: Other than OFF	System voltage

ON-VEHICLE SERVICE

COMPRESSOR DRIVE BELT ADJUSTMENT

Refer to GROUP 11A, On-vehicle Service – Drive Belt Tension Check [P.11A-7](#).

M1552001000410

DISCHARGING SYSTEM


M1552013000127

Use the refrigerant recovery unit to discharge refrigerant gas front the system.

NOTE: Refer to the Refrigerant Recovery and Recycling Unit instruction Manual for operation of the unit.

CHARGING

M1552001200447



1. With the handles turned back all the way (valve closed), install the adaptor valve to the low-pressure side of the gauge manifold.
2. Connect the charging hose (blue) to the adaptor valve.
3. Connect the quick joint (for low-pressure) to the charging hose (blue).

⚠ CAUTION

- Use tools that are suited to R134a.
- To install the quick joint, press section when connecting, run your hand along the hose while pressing to ensure that there are no bends in the hose.

4. Connect the quick joint (for low-pressure) to the low-pressure service valve.

NOTE: The low-pressure service valve should be connected to the flexible suction hose.

5. Close the high and low-pressure valves of the gauge manifold.

⚠ CAUTION


Be sure to connect the power plug of the vacuum pump to the vacuum pump adaptor, and then connect the power plug of the adapter to a 100-V outlet.

6. Install the vacuum pump adaptor to the vacuum pump.
7. Connect the charging hose (yellow) to the R-134a connection port of the vacuum pump adaptor.
8. Tighten the adaptor valve handle (valve open).
9. Open the low-pressure valve of the gauge manifold.
10. Turn the power switch of the vacuum pump to the ON position.

NOTE: Even if the vacuum pump power switch is turned ON, the vacuum pump will not operate because of the power supply connection in step (6).

⚠ CAUTION

Do not operate the compressor for evacuation.




11. Turn the vacuum pump adaptor switch to the R134a side to start the vacuum pump.
12. Evacuate to a vacuum reading of 100 kPa or higher (takes approx. 10 minutes).

⚠ CAUTION

Do not operate the compressor in the vacuum condition; damage may occur.


13. Loosen the valve of the adapter valve fully (valve closed), and turn off the vacuum pump adapter switch. Then leave it for five minutes.
14. Check the system for proper sealing (negative pressure should not decrease).



15. Connect the service can valve to the service can with the handle loosened fully (valve closed).
16. Turn the handle of the adaptor valve back all the way (valve closed), remove it from the gauge manifold and install the service can.
17. Tighten the handle of the charging valve (valve closed) to puncture the service can.

⚠ CAUTION

If the service can is inverted, liquid refrigerant may be drawn into the compressor damaging it by liquid compression. Keep the service can upright to ensure that refrigerant is charged in gas state.



18. Turn the handle of the charging valve back (valve open) and tighten the handle of the adaptor valve (valve open) to charge the system with refrigerant.
19. If the refrigerant is not drawn in, turn the handle of the adaptor valve back all the way (valve closed).
20. Check for gas leaks using a leak detector. If a gas leak is detected, re-tighten the connections, and then repeat the charging procedure from evacuation in step (11).

⚠ CAUTION

The leak detector for R-134a should be used.

21. Start the engine.
22. Operate the A/C and set to the lowest temperature (MAX. COOL).
23. Fix the engine speed at 1,500 r/min.

⚠ CAUTION

If the service can is inverted, liquid refrigerant may be drawn into the compressor damaging it by liquid compression. Keep the service can upright to ensure that refrigerant is charged in gas state.

24. Tighten the handle of the adaptor valve (valve open) to charge the required volume of refrigerant.

25. After charging with refrigerant, turn the handle of the adaptor valve back all the way (valve closed).
26. Tighten the charging valve handle (valve closed). Remove the quick joint (for low-pressure) from the low-pressure service valve.
27. Remove the service can.

NOTE: If the service can is not emptied completely, keep the handles of the charging valve and adaptor valve closed for the next charging.


CHECK THE REFRIGERANT LEVEL

M1552021700013

Remove the refrigerant by the flon reclaim machine and replenish the specified quantity of refrigerant.

NOTE: Refer to the Refrigerant Recovery and Recycling Unit instruction Manual for operation of the unit.


4. Connect the charging hose (blue) to the quick joint (for low-pressure).
5. Tighten the handle of the charge valve (valve close), and pierce the service can.
6. Turn the handle of the adaptor valve to bleed the air.



AC300373AB

CORRECTING LOW REFRIGERANT LEVEL IN CASE THE SERVICE CAN IS USED

M1552014600122




1. Install the charge valve with the handle turned all the way back (valve open) to the service can.
2. Install the adaptor valve with the handle turned all the way back (valve close) to the charging valve.
3. Connect the charging hose (blue) to the adaptor valve.

7. Install the quick joint (for low-pressure) to the low-pressure service valve.
- NOTE: The low-pressure service valve should be connected to the suction hose.*
8. Start the engine.
9. Operate the air conditioner and set at the lowest temperature (MAX. COOL).
10. Fix the engine speed at 1,500 r/min.
11. Tighten the handle of the adaptor valve (valve open), and replenish refrigerant while checking the quantity through the sight glass.
12. After replenishing is completed, turn the handle of the adaptor valve all the way back (valve close), and remove the quick joint.
- NOTE: When there is remainder of refrigerant in the service can, keep it for next use with the charge valve and the valve of the adaptor valve being closed.*

PERFORMANCE TEST

M1552001400452

1. The vehicles to be tested should be in a place that is not in direct sunlight.



2. Close the high and low-pressure valve of the gauge manifold.
3. Connect the charging hose (blue) to the low-pressure valve and connect the charging hose (red) to the high-pressure valve of the gauge manifold.

CAUTION

- To connect the quick joint, press section A firmly against the service valve until a click is heard.
- When connecting, run your hand along the hose while pressing to ensure that there are no bends in the hose.

4. Install the quick joint (for low-pressure) to the charging hose (blue), and connect the quick joint (for high-pressure) to the charging hose (red).
5. Connect the quick joint (for low-pressure) to the low-pressure service valve and connect the quick joint (for high-pressure) to the high-pressure service valve.
6. Start the engine.

NOTE: The high-pressure service valve is on the A/C pipe and the low-pressure service valve is on the suction hose.

7. Set the A/C controls as follows:



When the front A/C test

- A/C switch: A/C – ON position
- Mode selection: FACE position
- Temperature control: MAXIMUM COOLING position
- Air selection: RECIRCULATION position
- Blower switch: Fast position

When the rear A/C test

- The front A/C should be set as above
- A/C switch: A/C ON position
- Temperature control: MAXIMUM COOLING position
- Blower switch: Fast position

8. Adjust engine speed to 1,500 r/min with A/C clutch engaged.
9. Engine should be warmed up with doors and windows opened.



10. Insert a thermometer in the centre air outlet and operate the engine for 20 minutes.

NOTE: If the clutch cycles, take the reading before the clutch disengages.

11. Note the discharge air temperature.

PERFORMANCE TEMPERATURE CHART

FRONT-A/C TEST

Garage ambient temperature °C	20	25	30	35
Discharge air temperature °C	3.5 – 5.5	3.5 – 5.5	4.5 – 6.5	5.5 – 7.5
Compressor high pressure kPa	1,050 – 1,250	1,050 – 1,250	1,400 – 1,600	1,650 – 1,850
Compressor low pressure kPa	120 – 140	120 – 140	130 – 150	160 – 180


FRONT-A/C TEST

Garage ambient temperature °C	20	25	30	35
Discharge air temperature °C	5.5 – 7.5	5.5 – 7.5	6.5 – 8.5	7.5 – 9.5
Compressor high pressure kPa	1,150 – 1,350	1,150 – 1,350	1,500 – 1,700	1,750 – 1,950
Compressor low pressure kPa	130 – 150	130 – 150	140 – 160	180 – 200



SIMPLE INSPECTION OF THE A/C PRESSURE SENSOR

M1552014700152

1. Assemble a gauge manifold on the high pressure service valve.



2. Disconnect the A/C pressure sensor connector and connect the special tool test harness (MB991658) as shown.
3. Start the engine and then turn ON the air conditioner switch.




4. At this time, check to see that the voltage of the A/C pressure sensor connector terminal No. 2 reflects the specifications of the figure.

NOTE: The allowance shall be defined as $\pm 5\%$.


RELAY CONTINUITY CHECK

A/C COMPRESSOR RELAY CONTINUITY
CHECK

M1552008800439




Battery voltage	Tester connection	Specified condition
Not applied	4 – 5	Open circuit
<ul style="list-style-type: none"> Connect terminal 3 to the positive battery terminal Connect terminal 1 to the negative battery terminal 	4 – 5	Less than 2 ohms


REAR BLOWER RELAY CONTINUITY
CHECK

Battery voltage	Tester connection	Specified condition
Not applied	1 – 4	Open circuit
<ul style="list-style-type: none"> Connect terminal 3 to the positive battery terminal Connect terminal 2 to the negative battery terminal 	1 – 4	Less than 2 ohms

**FRONT BLOWER RELAY CONTINUITY
CHECK**




**PTC HEATER RELAY 1 CONTINUITY
CHECK**



Battery voltage	Tester connection	Specified condition
Not applied	4 – 5	Open circuit
<ul style="list-style-type: none"> • Connect terminal 3 to the positive battery terminal • Connect terminal 1 to the negative battery terminal 	4 – 5	Less than 2 ohms

Battery voltage	Tester connection	Specified condition
Not applied	4 – 5	Open circuit
<ul style="list-style-type: none"> • Connect terminal 3 to the positive battery terminal • Connect terminal 1 to the negative battery terminal 	4 – 5	Less than 2 ohms

PTC HEATER RELAY 2 CONTINUITY CHECK



Battery voltage	Tester connection	Specified condition
Not applied	4 – 5	Open circuit
<ul style="list-style-type: none"> • Connect terminal 3 to the positive battery terminal • Connect terminal 1 to the negative battery terminal 	4 – 5	Less than 2 ohms

IDLE-UP OPERATION CHECK

M1552001600456

1. Before inspection and adjustment, set vehicle in the following condition:
 - Engine coolant temperature: 80 – 90 °C
 - Lamps, electric cooling fan and accessories: Set to OFF
 - Transmission: Neutral ("N" or "P" for vehicles with A/T)
 - Steering wheel: Straightforward
2. Check whether or not the idle speed is the standard value.
Refer to GROUP 11A, On-vehicle Service – Basic Idle Speed Adjustment [P.11A-12](#).

Standard value: $750 \pm 50 \text{ r/min}$

3. When the A/C is running after turning the A/C switch to ON, and the blower switch to the 3(MH) or 4(HI) position, check to be sure that the idle speed is at the standard value.


Standard value: $850 \pm 50 \text{ r/min}$

NOTE: It is not necessary to make an adjustment, because the idling speed is automatically adjusted by the ISC system. If, however, a deviation from the standard value occurs for some reason, check the ISC system.

CLEAN AIR FILTER REPLACEMENT PROCEDURE

M1552020600024

1. Remove the glove box. (Refer to GROUP 52A, Instrument Panel [P.52A-2](#).)



2. Remove the two screws as shown, and replace the clean air filter.
3. Install the glove box.


HEATER CONTROL UNIT

REMOVAL AND INSTALLATION

M1554014700051

Pre-removal and Post-installation Operation

- Instrument centre panel Removal and Installation (Refer to GROUP 52A, Instrument Panel P.52A-2.)



AC310128AB


Removal steps

- Rear fan switch
- Heater control lever knob
- Automatic air conditioner control panel (A/C-ECU)
- Defogger switch knob
- Inside/outside air selection switch knob
- Panel
- Instrument centre panel

INSPECTION

M1552014301362

REAR FAN SWITCH CONTINUITY CHECK



AC310127

Switch position	Tester connection	Specified condition
OFF	1 – 2	Open circuit
ON		Less than 2 ohms

HEATER UNIT AND BLOWER ASSEMBLY

REMOVAL AND INSTALLATION


M1552020800028

Pre-removal Operation

- Engine coolant Draining (Refer to P.14-17.)
- Refrigerant draining (Refer to P.55-190.)
- Air cleaner Removal (Refer to GROUP 15, Air Cleaner P.15-3.)
- Front seat assembly Removal (Refer to GROUP 52A, Front Seat Assembly P.52A-21.)
- Rear heater duct Removal (Refer to Duct P.55-227.)
- Instrument panel Removal (Refer to GROUP 52A, Instrument Panel P.52A-2.)
- SRS-ECU Removal (Refer to GROUP 52B, SRS Air Bag P.52B-223.)

Post-installation Operation

- Adjust the front air mix damper control motor. (Refer to P.55-206.)
- SRS-ECU Installation (Refer to GROUP 52B, SRS Air Bag P.52B-223.)
- Instrument panel Installation (Refer to GROUP 52A, Instrument Panel P.52A-2.)
- Rear heater duct Removal (Refer to Duct P.55-227.)
- Front seat assembly Installation (Refer to GROUP 52A, Front Seat Assembly P.52A-21.)
- Air cleaner Installation (Refer to GROUP 15, Air Cleaner P.15-3.)
- Engine coolant Refilling (Refer to P.14-17.)
- Refrigerant Refilling (Refer to P.55-191.)



AC310129AC

<<A>>

Removal steps



- Harness and clamp
- Junction block installation
- 1. Heater hose
- Canister installation
- 2. Suction pipe
- 3. Liquid pipe B
- 4. O ring
- 5. Drain hose
- 6. Front deck cross member heater unit assembly

<>

<>


REMOVAL SERVICE POINTS**<<A>> CONNECTOR DISCONNECTION**



Disconnect the following connectors to remove the front deck crossmember and the heater unit assembly.



<L.H.D.>


Connector number	Connector name
C-15	Instrument panel wiring harness and floor wiring harness combination
C-16	Instrument panel wiring harness and floor wiring harness combination
C-27	Instrument panel wiring harness and front door wiring harness (LH) combination
C-110	Engine-ECU <M/T> or Engine-A/T-ECU <A/T>
C-111	Engine-ECU <M/T> or Engine-A/T-ECU <A/T>
C-112	Engine-ECU <M/T> or Engine-A/T-ECU <A/T>
C-113	Engine-ECU <M/T> or Engine-A/T-ECU <A/T>
C-114	Engine-ECU <M/T> or Engine-A/T-ECU <A/T>
C-115	Earth
C-124	Instrument panel wiring harness and front wiring harness combination
C-125	Instrument panel wiring harness and front wiring harness combination
C-127	Stop lamp switch
C-128	Instrument panel wiring harness and roof wiring harness combination
C-210	Floor wiring harness and J/B combination
C-211	Roof wiring harness and J/B combination





<R.H.D.>

Connector number	Connector name
C-14	Instrument panel wiring harness and front door wiring harness (RH) combination
C-15	Instrument panel wiring harness and floor wiring harness combination
C-16	Instrument panel wiring harness and floor wiring harness combination
C-17	Instrument panel wiring harness and control wiring harness combination
C-18	Instrument panel wiring harness and control wiring harness combination
C-27	Instrument panel wiring harness and front door wiring harness (LH) combination
C-110	Engine-ECU <M/T> or Engine-A/T-ECU <A/T>
C-111	Engine-ECU <M/T> or Engine-A/T-ECU <A/T>
C-112	Engine-ECU <M/T> or Engine-A/T-ECU <A/T>
C-113	Engine-ECU <M/T> or Engine-A/T-ECU <A/T>
C-114	Engine-ECU <M/T> or Engine-A/T-ECU <A/T>
C-119	SRS-ECU
C-125	Instrument panel wiring harness and front wiring harness combination
C-124	Instrument panel wiring harness and front wiring harness combination



Connector number	Connector name
C-128	Instrument panel wiring harness and roof wiring harness combination
C-211	Roof wiring harness and J/B combination
C-210	Floor wiring harness and J/B combination

<> SUCTION FLEXIBLE HOSE AND LIQUID PIPE B DISCONNECTION


CAUTION

Use the plug which is not breathable because A/C compressor oil or receiver have high hygroscopicity.

Plug the removed nipple of the pipe, hose and expansion valve to prevent the entry of dust and dirt.

DISASSEMBLY AND REASSEMBLY

M1552020900025



AC310130AB

Disassembly steps


1. Air intake duct
2. Blower assembly

Disassembly steps (Continued)

3. Heater unit
4. Front deck cross member

HEATER UNIT DISASSEMBLY AND
REASSEMBLY

M1554009200102



AC310132AB

Disassembly steps


1. Heater foot duct
2. Mode selection damper control motor and potentiometer
3. Aspirator
4. Aspirator hose
5. Heater side cover
6. PTC heater
7. Joint duct
8. Expansion valve
9. O ring
10. Evaporator
11. Air thermo sensor clip
12. Air thermo sensor

Disassembly steps (Continued)

13. Front air mixing damper control motor and potentiometer
14. Heater core
15. Air mixing control link A
16. Air mixing control link B
17. Air mixing control link C
18. Air mixing control link D
19. Air mixing control link E
20. Heater case lower
21. Heater case upper
22. Air mixing damper
23. Mode selection damper

**BLOWER ASSEMBLY DISASSEMBLY
AND REASSEMBLY**

M1554017700016



AC310131AB


Removal steps

1. Front blower motor
2. Front power transistor
3. Inside/outside air selection damper motor
4. Inside/outside air selection damper lever A
5. Inside/outside air selection damper lever B
6. Clean air filter
7. Air intake plate
8. Inside air damper
9. Heater blower case upper
10. Heater blower case lower

INSPECTION

M1552014301373

AIR THERMO SENSOR CHECK




AC209196AB

Check that the resistance shown in the graph is almost satisfied when measuring the resistance between the terminals under two or more different temperature conditions.

NOTE: The temperature condition in checking should be within the range shown.

PTC HEATER CHECK <VEHICLE WITH
REAR HEATER OR DUAL AUTOMATIC
A/C>


Check that there is continuity between the connector terminals 1 and 2 as well as 3 and 4.



MODE SELECTION DAMPER CONTROL MOTOR, AIR MIXING DAMPER CONTROL MOTOR, OUTSIDE/INSIDE AIR SELECTION DAMPER CONTROL MOTOR, POWER TRANSISTOR AND BLOWER MOTOR

REMOVAL AND INSTALLATION

M1554014900022




- Mode selection damper control motor removal step
 - Front deck cross member and heater unit assembly (Refer to P.55-200.)
- 1. Mode selection damper control motor
- Front air mixing damper control motor removal step
 - Cowl side trim (Refer to GROUP 52A, Interior Trim P.52A-10.)
 - Selector lever, selector lever panel and glove box (Refer to GROUP 52A, Instrument Panel P.52A-2.)
- <<A>> >>A<< 2. Front air mixing damper control motor
- Outside/inside air selection damper control motor and front power transistor removal step
 - Cowl side trim (Refer to GROUP 52A, Interior Trim P.52A-10.)
 - Selector lever, selector lever panel and glove box (Refer to GROUP 52A, Instrument Panel P.52A-2.)
- 3. Front power transistor
- 4. Outside/inside air selection damper control motor
- Front blower motor removal step
 - Front blower motor


REMOVAL SERVICE POINT

<<A>> FRONT AIR MIX DAMPER CONTROL MOTOR REMOVAL

1. Turn the temperature control dial to the MAX COOL position.
2. Turn the air outlet changeover mode to the FACE or FACE/FOOT position, and then turn it to the FOOT position.




3. Cut the water proof cover away from the groove section.




4. Rotate the front air mix damper control motor to the direction B by approximately 20°, and remove it while pushing the air mixing control link A.

INSTALLATION SERVICE POINT


>>A<< FRONT AIR MIX DAMPER CONTROL MOTOR INSTALLATION




1. Install the front air mix damper control motor to the link and rotate it to the direction C by approximately 20°.
2. Temporarily secure the front air mix damper motor by the screw.




3. Operate the blower by maximum air volume, check the air leak from FACE air outlet. If there is the air leak, rotate the air mix damper control motor to the direction C to prevent the leak.



- Check that there is the pin at the end of hole. If there is not, move the front air mix damper control motor so that the pin is positioned at the end of hole.
- Retighten the screw.



- Drill in the section shown.



- Secure the water proof cover with its replacement bracket.


INSPECTION

M1552014301384

CHECK THE AIR OUTLET CHANGEOVER DAMPER MOTOR AND POTENTIOMETER

CAUTION

Stop energizing when the lever is set to the operation stopping position.



MOTOR CHECK

Battery connection (+) terminal	Battery connection (-) terminal	Lever operation
2	1	Rotate to the DEF side
1	2	Rotate to the FACE side

Potentiometer check


When the resistance value between connector terminals 3 and 5 is measured while checking the motor, check that the resistance value changes gradually within the standard value.

Standard value: 0.80 (FACE) – 4.80 (DEF) $k\Omega$

CHECK THE FRONT AIR MIX DAMPER MOTOR AND POTENTIOMETER

CAUTION

Stop energizing when the lever is set to the operation stopping position.



MOTOR CHECK

Battery connection (+) terminal	Battery connection (-) terminal	Lever operation
2	1	Rotate to the HOT side.
1	2	Rotate to the COOL side.

Connection (+) terminal	Connection (-) terminal	Lever operation
1	2	The rotation stops at the fresh air position
1	3	The rotation stops at the air recirculation position



Potentiometer check

When the resistance value between connector terminals 3 and 5 is measured while checking the motor, check that the resistance value changes gradually within the standard value.

Standard value: 1.7 (MAX HOT) – 5.0 (MAX COOL) k Ω

CHECK THE OUTSIDE/INSIDE AIR SELECTION DAMPER MOTOR**CAUTION**


Stop energizing when the lever is set to the operation stopping position.

**FRONT BLOWER MOTOR CHECK**

Check that the motor turns when applying battery power between the connector terminals. Also check to see that there is no abnormal sound emitted from the motor at this time.

PHOTO SENSOR AND INTERIOR TEMPERATURE SENSOR REMOVAL AND INSTALLATION

M1554015100029



Inside temperature sensor removal steps

- Cowl side trim (Refer to GROUP 52A, Interior Trim [P.52A-10.](#))
- Selector lever, selector lever panel and instrument lower panel (Refer to GROUP 52A, Instrument Panel [P.52A-2.](#))


1. Interior temperature sensor
2. Aspirator hose

Photo sensor removal steps

- Combination meter bezel, combination meter (Refer to GROUP 54A, Combination meter [P.54A-84.](#))
- Door opening trim, front pillar trim (Refer to GROUP 52A, Interior Trim [P.52A-10.](#))
- Defroster garnish (Refer to GROUP 52A, Instrument Panel [P.52A-2.](#))

<<A>>

REMOVAL SERVICE POINTS <<A>> PHOTO SENSOR REMOVAL




Cut the connector behind the combination meter away and tie it with string so that the photo sensor can be drawn out from the instrument panel easily.

INSPECTION

INTERIOR TEMPERATURE SENSOR CHECK

M1552014301395



Check to see that the resistance shown in the graph is almost satisfied when measuring the resistance between the terminals under two or more different temperature conditions.


PHOTO SENSOR CHECK

Check that the display voltage changes between in direct sunlight and in doors when checking the MUT-III service data item No.06.

AMBIENT TEMPERATURE SENSOR

REMOVAL AND INSTALLATION

M1554003400131




Removal steps

- Front bumper (GROUP 51, Front Bumper [P.51-3](#).)
- 1. Ambient temperature sensor

INSPECTION

M1552014301403




Check to see that the resistance shown in the graph is almost satisfied when measuring the resistance between the sensor terminals under two or more different temperature conditions.

HEAT SWITCH

REMOVAL AND INSTALLATION <REAR
HEATER OR REAR A/C VEHICLES>

M1554017000028




AC311594AB

Removal steps

1. Combination meter bezel (GROUP 52A, Instrument Panel [P.52A-2](#).)
2. Heat switch holder
3. Heat switch (PTC heater switch)

INSPECTION

M1554011900034

PTC HEATER SWITCH CONTINUITY
CHECK


AC303103

Switch position	Tester connection	Specified condition
OFF	1 – 2	Open circuit
ON		Less than 2 ohms

REAR A/C SWITCH

REMOVAL AND INSTALLATION

M1554017200022




Removal steps

1. Rear heater controller (Refer to GROUP 52A, Headlining [P.52A-17.](#))
- Headlining (Refer to GROUP 52A, Headlining [P.52A-17.](#))
2. Rear heater controller bracket

INSPECTION

M1552014301414

REAR HEATER CONTROLLER
CONTINUITY CHECK

REAR AIR VOLUME ADJUSTING SWITCH

Switch status	Checking terminal	Normal conditions
OFF	4 – 9	2 Ω or less
AUTO <vehicles with dual automatic A/C>	5 – 9	2 Ω or less
1	6 – 9	2 Ω or less
2	7 – 9	2 Ω or less
3	8 – 9	2 Ω or less

REAR TEMPERATURE CONTROL KNOB
<VEHICLES WITH DUAL AUTOMATIC A/C>

Check that the resistance value between connector terminals 14 and 15 changes gradually within the standard value when moving the knob.

Standard value: Approximately 3kΩ or less


REAR HEATER UNIT

REMOVAL AND INSTALLATION

M1554015300023

Pre-removal and Post-installation Operation

- Engine coolant Draining and Refilling (Refer to GROUP 14, On vehicles service [P.14-16.](#))
- Refrigerant draining and Refilling (Refer to Charging [P.55-191](#) and Discharging [P.55-190.](#))
- Third seat assembly removal and installation (Refer to GROUP 52A, Third Seat Assembly [P.52A-33.](#))
- Quarter trim lower and quarter trim upper removal and installation (Refer to GROUP 52A, Interior Trim [P.52A-10.](#))



AC303098AB

<<A>>

Removal steps

1. Rear pillar duct
2. Rear floor duct A
3. Rear A/C pipe connection
4. O ring
5. Heater hose connection
6. Rear heater unit


REMOVAL SERVICE POINTS**<<A>> REAR A/C PIPE REMOVAL****⚠ CAUTION**

Use the plug which is not breathable because A/C compressor oil or receiver have high hygroscopicity.

Plug the pipe nipple to prevent the entry of dust and dirt.

DISASSEMBLY AND REASSEMBLY**<VEHICLES WITH REAR HEATER, REAR COOLER OR DUAL AUTOMATIC A/C>**

M1554017600019



AC302508AB

Removal steps

1. Rear blower motor <Vehicles with rear heater, rear cooler or dual automatic A/C>
2. Rear power transistor <Vehicles with rear heater, rear cooler or dual automatic A/C>
3. Harness <Vehicles with dual automatic A/C>
4. Rear air mix damper control motor <Vehicles with dual automatic A/C>

Removal steps (Continued)

5. Rear heater pipe bracket <Vehicles with rear heater or dual automatic A/C>
6. Rear heater core <Vehicles with rear heater or dual automatic A/C>
7. Rear air mix lever <Vehicles with dual automatic A/C>
8. Rear mode selection damper lever A <Vehicles with dual automatic A/C>

Removal steps (Continued)

9. Rear mode selection damper lever
B <Vehicles with dual automatic A/C>
10. Rear mode selection damper lever
C <Vehicles with dual automatic A/C>
11. Rear heater case <Vehicles with rear heater, rear cooler or dual automatic A/C>
12. Evaporator <Vehicles with rear cooler or dual automatic A/C>
13. Rear mode selection damper
<Vehicles with dual automatic A/C>
14. Rear mode selection damper
<Vehicles with dual automatic A/C>

MOTOR CHECK

Battery connection (+) terminal	Battery connection (-) terminal	Lever operation
2	1	Rotate to the MAX HOT side.
1	2	Rotate to the MAX COOL side.

Potentiometer check

When the resistance value between connector terminals 3 and 5 is measured while checking the motor, check that the resistance value changes gradually within the standard value.


Standard value: 1.20 (MAX COOL) – 4.80 (MAX HOT) kΩ

INSPECTION

M1552014301425

CHECK THE REAR AIR MIX DAMPER**MOTOR AND POTENTIOMETER****<VEHICLES WITH DUAL AUTOMATIC A/C>****CAUTION**

Stop energizing when the lever is set to the operation stopping position.




REAR BLOWER MOTOR AND REAR POWER TRANSISTOR REMOVAL AND INSTALLATION

M1554015500027

Pre-removal and Post-installation Operation

- Third seat assembly Removal and Installation (Refer to GROUP 52A, Third Seat Assembly [P.52A-33](#).)
- Quarter trim lower, quarter trim upper Removal and Installation (Refer to GROUP 52A, Interior Trim [P.52A-10](#).)



AC302929AC


Rear power transistor removal step

1. Rear power transistor <Vehicles with rear heater, rear cooler or dual automatic A/C>
2. Rear blower motor removal steps
 - Rear floor duct A <Vehicles with rear heater or rear A/C> (Refer to [P.55-228](#).)

INSPECTION

M1554011900045

REAR BLOWER MOTOR INSPECTION <VEHICLES WITH REAR HEATER, REAR COOLER OR DUAL AUTOMATIC A/C>



AC303108

Check that the motor turns when applying battery power between the connector terminals. Also check to see that there is no abnormal sound emitted from the motor at this time.

COMPRESSOR ASSEMBLY

REMOVAL AND INSTALLATION




M1552004400183

Pre-removal Operation

- Refrigerant Discharging (Refer to [P.52A-10.](#))
- Front Under Cover Panel Assembly

Post-installation Operation

- Refrigerant Charging (Refer to [P.52A-33.](#))
- Drive Belt Tension Adjustment (Refer to GROUP 11A, On-vehicles Service – Drive Belt Tension Check [P.11A-7.](#))
- Front Under Cover Panel Assembly



AC303224 AB

<<A>>
<<A>>

Removal steps

1. Flexible suction hose connection
2. Flexible discharge hose connection
3. O ring

<>
<<C>> >>A<<

Removal steps (Continued)

4. Drive belt
5. A/C compressor assembly
6. A/C compressor bracket


REMOVAL SERVICE POINTS**<<A>> FLEXIBLE SUCTION HOSE AND
FLEXIBLE DISCHARGE HOSE
DISCONNECTION****CAUTION**

Use the plug which is not breathable because A/C compressor oil or receiver have high hygroscopicity.

Plug the hose nipple removed to prevent the entry of dust and dirt.

<> DRIVE BELT REMOVAL


The following operations will be needed due to the introduction of the serpentine drive system with the drive belt auto-tensioner.



1. Securely insert the spindle handle or ratchet handle with a 12.7 mm insertion angle into the jig hole of the auto-tensioner.
2. Rotate the auto-tensioner anti-clockwise and align hole A with hole B.

CAUTION

To reuse the drive belt, draw an arrow indicating the rotating direction (clockwise) on the back of the belt using chalk, etc.



3. Insert an L-shaped hexagon wrench, etc. into the hole to fix and then remove the drive belt.

<<C>> COMPRESSOR REMOVAL

Be careful not to spill the A/C compressor oil and remove the A/C compressor.

INSTALLATION SERVICE POINT**>>A<< A/C COMPRESSOR****INSTALLATION**

When installing the new A/C compressor, install the A/C compressor after adjusting the oil volume as follows.

1. Measure the oil of A/C compressor removed. (X cm^3)
2. Drain the oil (Y cm^3) given by the following expression from a new A/C compressor, and then install the A/C compressor.


$$160 \text{ cm}^3 - X \text{ cm}^3 = Y \text{ cm}^3$$

NOTE:

1. 160 cm^3 shows the oil volume contained in the new A/C compressor.
2. $Y \text{ cm}^3$ shows the oil volume stored in the refrigerant line, condenser, and cooling unit, etc.

INSPECTION


M1552004500209

**CHECK THE MAGNETIC CLUTCH FOR
A/C COMPRESSOR**

Connect the connector battery to positive battery terminal in the A/C compressor, and then earth the battery (-) terminal to the A/C compressor itself. At this time, check that the magnetic clutch operating sound can be heard.

DISASSEMBLY AND REASSEMBLY

M1552004600530



AC302963AB

Cooling temperature switch
disassembly steps

1. Snap ring
2. Refrigerant temperature switch

Magnetic clutch disassembly

<<A>> >>D<< • Air gap adjustment

<<A>> >>C<< 3. Self-locking nut

<<A>> >>B<< 4. Armature

<<A>> >>A<< 5. Snap ring

<<A>> >>A<< 6. Rotor

<<A>> >>A<< 7. Snap ring


<<A>> >>A<< 8. A/C compressor coil

<<A>> >>A<< 9. Shim

<<A>> >>A<< 10. A/C compressor

DISASSEMBLY SERVICE POINT

<<A>> SELF-LOCKING NUT REMOVAL




AC208431AB

Use the special tools to remove the self-locking nut.

- Special spanner (MB991367)
- Pin (MB991386)


REASSEMBLY SERVICE POINTS

>>A<< A/C COMPRESSOR COIL INSTALLATION



Install the A/C compressor coil while aligning the pin hole of A/C compressor itself with the protrusion of A/C compressor coil

>>B<< SNAP RING INSTALLATION




Use the snap ring plier and Install the snap ring so that the taper faces the outside.

>>C<< SELF-LOCKING NUT INSTALLATION

Use the special tool as during removal to secure the armature and tighten the self-locking nut.

>>D<< AIR GAP ADJUSTMENT



Check that the air gap of clutch satisfies the standard value. If not within the standard value, use shims to adjust it.

Standard value: 0.3 – 0.5 mm


INSPECTION

M1552004700087


REFRIGERANT TEMPERATURE SWITCH



Do not heat than necessary.



1. Immerse the refrigerant temperature sensor probe into engine oil to heat the sensor probe.



2. If the oil temperature reaches the standard value, there should be continuity between the switch terminals.

Switch status	Operating temperature °C
Being turned off (No continuity)	155
Being turned on (2Ω or less)	125

NOTE: When the oil temperature is 155°C or more and there is no continuity, the resistance will not be 2Ω or lower until the oil temperature reduces to 125 °C or less.


CONDENSER ASSEMBLY

REMOVAL AND INSTALLATION


M1552015400079

Pre-removal and Post-installation Operation

- Refrigerant draining and Refilling (Refer to Charging P.55-191 and Discharging P.55-190.)
- Battery and Battery tray
- Air cleaner intake duct (Refer to GROUP 15, Air Cleaner P.15-3.)



A/C compressor oil:
SUN PAG 56



AC312941AB

<<A>>
<<A>>
<>

Removal steps

1. Front bumper clip
2. Front end upper bar
3. Air guide panel RH
4. Flexible discharge hose connection
5. Liquid pipe A connection
6. Condenser
 - Front bumper (Refer to GROUP 51, Front Bumper Assembly P.51-3.)
7. Air guide panel LH
8. Air guide panel centre

*NOTE: Condenser fan removal and installation
(Refer to GROUP 14 – Radiator P.14-25).*

REMOVAL SEVICE POINTS


<<A>> FLEXIBLE SUCTION HOSE AND LIQUID PIPE A REMOVAL

CAUTION

Use the plug which is not breathable because
A/C compressor oil or receiver have high
hygroscopicity.

Plug the removed nipple of the pipe, hose and
condenser to prevent the entry of dust and dirt.

<> CONDENSER ASSEMBLY REMOVAL




Remove the condenser while pushing the radiator
towards the direction shown to make room.

INSPECTION

M1552014301436

CONDENSER FAN MOTOR CHECK



Battery connection (+) terminal	Battery connection (-) terminal	Motor operation
1	2	Rotate



REFRIGERANT LINE

REMOVAL AND INSTALLATION <L.H.D.
FRONT SIDE>

M1552006400543

Pre-removal and Post-installation Operation

- Refrigerant Draining and Refilling (Refer to Charging and Discharging P.55-191).



AC310133AB

Removal steps

<<A>>	1. A/C pressure sensor	<<A>>
<<A>>	2. Flexible discharge hose	<<A>>
<<A>>	3. Liquid pipe A	<<A>>
<<A>>	4. Flexible suction hose	<<A>>
<<A>>	5. Suction pipe A <Without vehicles with rear cooler or dual automatic A/C>	<<A>>

Removal steps (Continued)

6. Connection with suction pipe B <Vehicles with rear cooler or dual automatic A/C>
7. Suction pipe A <Vehicles with rear cooler or dual automatic A/C>
8. Liquid pipe B <Without vehicles with rear cooler or dual automatic A/C>

9. Removal steps (Continued)

<Vehicles with rear cooler or dual automatic A/C>

10. Connection with liquid pipe C
<Vehicles with rear cooler or dual automatic A/C>

11. Expansion valve

12. O ring

REMOVAL SERVICE POINT

<>A>> HOSES AND PIPES REMOVAL

⚠ CAUTION

Use the plug which is not breathable because A/C compressor oil or receiver have high hygroscopicity.



Plug the nipple of condenser, compressor, and expansion valve to prevent the entry of dust and dirt.

REMOVAL AND INSTALLATION <R.H.D. FRONT SIDE>

M1552006400598

Pre-removal and Post-installation Operation

- Refrigerant Draining and Refilling (Refer to Charging and Discharging P.55-191.)



AC310260AB

Removal steps

<<A>> 1. A/C pressure sensor
<<A>> 2. Flexible discharge hose
<<A>> 3. Liquid pipe A
<<A>> 4. Flexible suction hose
<<A>> 5. Suction pipe A <Vehicles without rear cooler and dual automatic A/C>
<<A>> 6. Suction pipe B connection <Vehicles with rear cooler or dual automatic A/C>
<<A>> 7. Suction pipe A <Vehicles with rear cooler or dual automatic A/C>
<<A>> 8. Liquid pipe B <Vehicles without rear cooler and dual automatic A/C>
<<A>> 9. Liquid pipe C connection <Vehicles with rear cooler or dual automatic A/C>
<<A>> 10. Liquid pipe A <Vehicles with rear cooler or dual automatic A/C>

Removal steps (Continued)

<<A>> 11. Expansion valve
<<A>> 12. O ring

REMOVAL SERVICE POINT

<<A>> HOSE/PIPE DISCONNECTION

CAUTION

As the compressor oil and receiver are highly moisture absorbent, use a non-porous material to plug the hose and nipples.



To prevent the entry of other foreign bodies, plug the condenser, compressor, and expansion valve nipples.

REAR REFRIGERANT REMOVAL AND INSTALLATION <REAR SIDE>

M1552006400554

Pre-removal and Post-installation Operation

Refrigerant Draining and Refilling (Refer to P.55-190)



Removal steps

<<A>> 1. Liquid pipe C
<<A>> 2. Suction pipe B
• 3rd seat assembly (Refer to GROUP 52A, 3rd Seat Assembly P.52A-33)
• Quarter trim lower (Refer to GROUP 52A, Interior Trim P.52A-10)

Removal steps (Continued)

• Floor carpet
3. Rear A/C pipe B
• A/C pipe protector
4. Rear A/C pipe A
5. O ring

AC302526AB

REMOVAL SERVICE POINT

<<A>> PIPES REMOVAL

CAUTION


Use the plug which is not breathable because
A/C compressor oil or receiver have high
hygroscopicity.

Plug the pipe nipple to prevent the entry of dust and
dirt.

DUCTS

REMOVAL AND INSTALLATION

M1553001000156



AC310258AB

Side defroster duct, defroster nozzle and ventilation air distribution duct removal steps


- Front pillar trim, cowl side trim upper (Refer to GROUP 52A, Interior Trim [P.52A-10.](#))
- 1. Side defroster duct A
- Instrument panel assembly (Refer to GROUP 52A, Instrument panel [P.52A-2.](#))
- 2. Defroster and distribution duct assembly
- 3. Side defroster duct B
- 4. Defroster nozzle
- 5. Ventilation air distribution duct

Rear heater duct removal steps

- Front scuff plate inner, cowl side trim (Refer to GROUP 52A, Interior Trim [P.52A-10.](#))
- Selector lever, selector lever panel and glove box and lower panel and console side cover and centre console (Refer to GROUP 52A, Instrument Panel [P.52A-2.](#))
- Front seat assembly (Refer to GROUP 52A, Front Seat Assembly [P.52A-21.](#))
- 6. Rear heater duct

REMOVAL AND INSTALLATION

M1553001000167



AC302509AB

Roof duct, rear pillar duct removal steps

- Front pillar trim, centre pillar trim upper and quarter trim lower (Refer to GROUP 52A, Interior Trim [P.52A-10.](#))
- Headlining (Refer to GROUP 52A, Headlining [P.52A-17.](#))
- 1. Side roof duct
- 2. Centre roof duct
- 3. Rear pillar duct

Floor duct removal steps

- Quarter trim lower (Refer to GROUP 52A, Interior Trim [P.52A-10.](#))
- Third seat assembly (Refer to 52A, Third Seat Assembly [P.52A-33.](#))
- 4. Rear floor duct A <Rear heater or rear A/C vehicles>
- 5. Rear floor duct B <Rear heater or rear A/C vehicles>
- 6. Air outlet <Rear heater or rear A/C vehicles>
- 7. Seat bracket panel assembly
- 8. Rear floor duct C <Rear heater or rear A/C vehicles>


VENTILATORS

REMOVAL AND INSTALLATION

M1553002800070

Pre-removal and Post-installation Operation

- Rear bumper removal and installation (Refer to GROUP 51, Rear Bumper P.51-6.)



AC303128AB