

GROUP 27A

REAR AXLE <2WD>

CONTENTS

GENERAL INFORMATION	27A-2	ON-VEHICLE SERVICE	27A-4
SERVICE SPECIFICATIONS.....	27A-2	WHEEL BEARING AXIAL PLAY CHECK ..	27A-4
SEALANT.....	27A-2	REAR HUB ROTARY-SLIDING RESISTANCE CHECK	27A-4
SPECIAL TOOLS.....	27A-3	HUB BOLT REPLACEMENT.....	27A-4
		REAR AXLE HUB ASSEMBLY	27A-5
		REMOVAL AND INSTALLATION	27A-5
		INSPECTION.....	27A-6


GENERAL INFORMATION

M1271000100285

The rear axle has the following features:

- The wheel bearing is a unit ball bearing (double-row angular contact ball bearing) which incorporates the oil seals and is highly resistant to a thrust load.
- ABS rotors for detecting the wheel speeds are press-fitted to the rear hub in vehicles with ABS.

CONSTRUCTION DIAGRAM



AC300617AB

SERVICE SPECIFICATIONS

M1271000300427

Item	Limit
Wheel bearing axial play mm	0.05
Rear hub rotary-sliding resistance N	19






SEALANT

M1271000500249

Item	Specified sealant	Remark
Hub cap	3M ATD Part No.8663 or equivalent	Semi-drying sealant

SPECIAL TOOLS

M1271000600439


Tool	Number	Name	Use
 B990767	MB990767	End yoke holder	Hub fixing
 MB991618	MB991618	Hub bolt remover	Hub bolt removal
 MD998801	MD998801	Remover	Removal of ABS rotor
 MD998812	MD998812	Installer cap	
 MD998813	MD998813	Installer 100	
 MD998815	MD998815	Installer adapter	

ON-VEHICLE SERVICE

WHEEL BEARING AXIAL PLAY CHECK

M1271000900377

1. Remove the caliper assembly, and suspend the caliper assembly with a wire and remove the brake disc.



2. Check the bearing's axial play. Place a dial gauge against the hub surface; then move the hub in the axial direction and check whether or not there is axial play.

Limit: 0.05 mm

3. If the play exceeds the limit, the self-locking nut should be tightened to the specified torque and check the axial play again.


Tightening torque: $175 \pm 25 \text{ N}\cdot\text{m}$

4. Replace the rear hub assembly if an adjustment cannot be made to within the limit.

REAR HUB ROTARY-SLIDING RESISTANCE CHECK

M1271001100222

1. Remove the caliper assembly, and suspend the caliper assembly with a wire and remove the brake disc.
2. Turn the hub a few times to seat the bearing.



3. Wind a rope around the hub bolt and turn the hub by pulling at a 90° angle with a spring balance. Measure to determine whether or not the rotary-sliding resistance of the rear hub is at the limit value.

Limit: 19 N

4. If limit value is exceeded, loosen the self-locking nut and then tighten it to the specified torque and check the rear hub rotary sliding resistance again.


Tightening torque: $175 \pm 25 \text{ N}\cdot\text{m}$

5. Replace the rear hub assembly if an adjustment cannot be made to within the limit.

HUB BOLT REPLACEMENT

M1271001000214


1. Remove the caliper assembly, and suspend the caliper assembly with a wire and remove the brake disc.



2. Use the following special tools to remove the hub bolts.

- End yoke holder (MB990767)
- Hub bolt remover (MB991618)

NOTE: To retain a space for removing the hub bolts, remove them near the retainer spring mounting position.



3. Install the plain washer to the new hub bolt, and install the bolt with a nut.


REAR AXLE HUB ASSEMBLY

REMOVAL AND INSTALLATION

M1271002000347

CAUTION

- Care must be taken not to scratch or damage the teeth of the ABS rotor. The ABS rotor must never be dropped. If the teeth of the ABS rotor are chipped, resulting in a deformation of the ABS rotor, it will not be able to accurately detect the wheel rotation speed, and the system will not function normally.
- The rear hub assembly should not be dismantled. When removing the rear hub assembly, the wheel bearing inner race may be left at the spindle side. In this case, always replace the rear hub assembly, otherwise the hub will damage the oil seal, causing oil leaks or excessive play.



Removal steps

<<A>>	1. Caliper assembly
	2. Brake disc
	3. Hub cap
<> >>B<<	4. Self-locking nut

Removal steps (Continued)

<<C>> >>A<<	5. Rear hub assembly
	6. ABS rotor
	7. Hub bolt


AC301185 AB

REMOVAL SERVICE POINTS

<<A>> CALIPER ASSEMBLY REMOVAL

Secure the removed caliper assembly with wire, etc.


<> SELF-LOCKING NUT REMOVAL

CAUTION

AC301112 AB

Do not apply the vehicle weight to the wheel bearing while loosening the self-locking nut, or the wheel bearing will be damaged.

<<C>> ABS ROTOR REMOVAL



AC210936 AC

Use the following special tools to press out ABS rotor from the rear hub assembly.


- Remover (MD998801)
- Installer cap (MD998812)
- Installer100 (MD998813)
- Installer adapter (MD998815)

INSTALLATION SERVICE POINTS

>>A<< ABS ROTOR INSTALLATION

CAUTION


When installing, take care not to deform the ABS rotor.



AC102209 AC

Press-fit the ABS rotor to the rear hub assembly.

>>B<< SELF-LOCKING NUT INSTALLATION

CAUTION

AC301113 AB

Before securely tightening the self-locking nuts, make sure there is no load on the wheel bearings. Otherwise the wheel bearing will be damaged.

Tighten the self-locking nut to the specified torque.

INSPECTION

M1271002100225

- Check the rear hub assembly for crack or damage.
- Check the oil seal of the rear hub assembly for crack or damage.
- Check the ABS rotor for chipped teeth.