
GROUP 34

REAR SUSPENSION

CONTENTS


GENERAL INFORMATION	34-2	TRAILING ARM ASSEMBLY	34-11
REMOVAL AND INSTALLATION <2WD>..		34-11	
SERVICE SPECIFICATIONS.....	34-3	REMOVAL AND INSTALLATION <4WD>..	34-13
INSPECTION.....		34-13	
LUBRICANT.....	34-3	TRAILING ARM BUSHING	
REPLACEMENT		34-16	
SPECIAL TOOLS.....	34-4	REMOVAL AND INSTALLATION	34-17
34-4		INSPECTION.....	
ON-VEHICLE SERVICE.....	34-7	DISASSEMBLY AND REASSEMBLY	34-20
REAR WHEEL ALIGNMENT CHECK AND			
ADJUSTMENT	34-7		
LOWER ARM PILLOW BALL BUSHING AXIAL			
PLAY CHECK	34-8		
STABILIZER LINK BALL JOINT DUST COVER			
INSPECTION	34-8		
CONTROL LINK, UPPER ARM AND LOWER			
ARM	34-8		
REMOVAL AND INSTALLATION	34-8	STABILIZER BAR	34-23
INSPECTION	34-9	REMOVAL AND INSTALLATION	34-23
LOWER ARM BUSHING AND LOWER ARM		INSPECTION.....	34-24
PILLOW BALL BUSHING REPLACEMENT	34-10	STABILIZER LINK BALL JOINT DUST	
		COVER REPLACEMENT	34-24
REAR SUSPENSION			
CROSSMEMBER			
REMOVAL AND INSTALLATION		REAR SUSPENSION	
INSPECTION.....		CROSSMEMBER	34-25
		REMOVAL AND INSTALLATION	34-25
		INSPECTION.....	34-25

GENERAL INFORMATION

M1341000100416

A trailing arm type multi-link suspension has been adopted as the rear suspension. The shock absorber is a hydraulic, cylindrical double-acting type.

CONSTRUCTION DIAGRAM



AC301439AB

SPECIFICATION

COIL SPRING

Item	2WD	4WD
Wire diameter mm	11	11
Average diameter mm	91	91
Free length mm	342	350

SERVICE SPECIFICATIONS

M1341000300379

Item	Standard value
Toe-in	At the centre of tyre tread mm 3 ± 2
	Toe-angle (per wheel) $0^\circ 08' \pm 05'$
Camber	$-0^\circ 40' \pm 30'$ (Difference between right and left within 30')
Thrust angle	$0^\circ 00' \pm 09'$
Control link pillow ball bushing starting torque N·m	0.5 – 3.0
Upper arm pillow ball bushing starting torque N·m	0.5 – 3.0
Lower arm pillow ball bushing starting torque N·m	0.5 – 3.0
Stabilizer link ball joint turning torque N·m	1.7 – 3.1





LUBRICANT








M1341000400161






Item	Specified lubricant	Quantity
Stabilizer link ball joint (inside of dust cover)	Multipurpose grease SAE J310, NLGI No.2 or equivalent	As required

SPECIAL TOOLS

M1341000600369

Tool	Number	Name	Use
 MB991004	MB991014	Wheel alignment gauge attachment	Wheel alignment measurement <2WD-vehicles with aluminium wheels>
 MB991004	MB991004	Wheel alignment gauge attachment	Wheel alignment measurement <4WD-vehicles with aluminium wheels>
 MB990326	MB990326	Preload socket	<ul style="list-style-type: none"> • Pillow ball bushing starting torque check • Stabilizer link ball joint turning torque check
	MB991447	Bushing remover and installer	Lower arm bushing removal and press-fitting
	MB991448	Bushing remover and installer base	
	MB991449	Bushing remover and installer supporter	
 MB990957 A: MB990969 B: MB990971	MB990957 A: MB990969 B: MB990971	Lower arm bushing remover and installer A: Guide B: Base	Lower arm pillow ball bushing removal and press-fitting
 B990996	MB990996	Lower arm bushing arbor	

Tool	Number	Name	Use
 B990767	MB990767	End yoke holder	Rear axle hub fixing
 MB990241	MB990241 A: MB990243 B: MB990244 C: MB990242	Axe shaft puller A: Puller body B: Puller bar C: Puller shaft	Drive shaft removal <4WD>
 MB991354	MB991354	Puller body	<ul style="list-style-type: none"> Removal of the drive shaft <4WD> Rear hub assembly removal <4WD>
 AC100320AB	A: MB991017 B: MB990998 C: MB991000	A, B: Front hub remover and installer C: Spacer	Provisional holding of the wheel bearing <4WD>
 MB990590	MB990590 A: MB990212 B: MB990211	Rear axle shaft oil seal remover A: Adapter B: Sliding hammer	Rear hub assembly removal <4WD>
 MB990560	MB990560	Bearing remover	Wheel bearing inner race removal <4WD>
 MB990934	MB990934	Adapter	Wheel bearing removal <4WD>
 B990938	MB990938	Bar	

Tool	Number	Name	Use
 MB991400	MB991400	Rear wheel bearing and hub installer	<ul style="list-style-type: none"> • Wheel bearing press-fitting <4WD> • Rear hub assembly press-fitting <4WD>
 MB991401	MB991401	Rear wheel bearing and hub installer base	Wheel bearing press-fitting <4WD>
 MB991411	MB991411	Rear wheel bearing and hub installer	Rear hub assembly press-fitting <4WD>
 B991444	MB991444	Bushing remover and installer arbor	Trailing arm bushing removal and press-fitting
 MB991445	MB991445	Bushing remover and installer base	
 A B MB991237	A: MB991237 B: MB991239	A: Spring compressor body B: Arm set	Coil spring removal and installation

ON-VEHICLE SERVICE

REAR WHEEL ALIGNMENT CHECK AND
ADJUSTMENT

M1341011000349

Measure wheel alignment with an alignment equipment on level earth. The rear suspension, wheels, and tyres should be serviced to the normal condition prior to wheel alignment measurement.

CAMBER

Standard value: $-0^\circ 40' \pm 30'$ (Left/right deviation within 30')

NOTE: Camber is preset at the factory and cannot be adjusted.


CAUTION

Never subject the wheel bearings to the vehicle load when the trailing arm spindle self-locking nuts (2WD), the driveshaft nuts (4WD), or the special tool wheel alignment gauge attachment (MB991004 or MB991014) are loosened.

NOTE:

<2WD-vehicles with aluminium wheels>

MB991014




AC001079 AD

For 2WD-vehicles with aluminium wheels, attach the camber/caster/kingpin gauge to the trailing arm spindle by using special tool wheel alignment gauge attachment (MB991014). Tighten the special tool to the same torque 175 ± 25 N·m as the trailing arm spindle self-locking nut.

NOTE:

<4WD-vehicles with aluminium wheels>

MB991004



AC001079 AE

For 4WD-vehicles with aluminium wheels, attach the camber/caster/kingpin gauge to the driveshaft by using special tool wheel alignment gauge attachment (MB991004). Tighten the special tool to the same torque 245 ± 29 N·m as the driveshaft nut.

TOE-IN

Standard value:

At the centre of tyre tread: 3 ± 2 mm


Toe angle (per wheel): $0^\circ 08' \pm 05'$

If toe-in is not within the standard value, adjust by following procedures.


CAUTION

To prevent bushings from breakage, the toe adjusting bolt should be temporarily tightened, and then fully tightened with the vehicle on the ground in the unladen condition.

<Control link front view>



<Control link rear view>



AC107070 AC

Carry out adjustment by turning the toe adjusting bolt (control link mounting bolt which is located on the inner side of the body).

NOTE:

- LH: Clockwise viewed from the front → Toe-in
- RH: Clockwise viewed from the front → Toe-out
- Turning the toe adjusting bolt by one groove of the scale, toe can be changed approximately 2.6 mm (single side toe angle equivalent to 16').

LOWER ARM PILLOW BALL BUSHING
AXIAL PLAY CHECK

M1341016900046

1. Raise the vehicle.
2. Remove the stabilizer link and shock absorber from the lower arm assembly.
3. Move the lower arm up and down with your hands to check for an excessive play in the axial direction of the pillow ball bushing. If there is an excessive play, replace the lower arm pillow ball bushing (Refer to P.34-10).

4. After inspection, install the stabilizer link and shock absorber to the lower arm assembly (Refer to P.34-8).

STABILIZER LINK BALL JOINT DUST
COVER INSPECTION

M1341012800252

1. Check dust covers for cracks or damage by pushing it with your finger.
2. If a dust cover is cracked or damaged, replace the stabilizer link.

NOTE: Cracks or damage to the dust cover may cause damage to the ball joint.

CONTROL LINK, UPPER ARM AND LOWER ARM
REMOVAL AND INSTALLATION


M1341004800161

⚠ CAUTION

*: Indicates parts which should be temporarily tightened, and then fully tightened with the vehicle on the ground in an unladen condition.

Post-installation Operation

- Rear Wheel Alignment Check and Adjustment (Refer to P.34-7).



AC107089AC

Control link and upper arm
removal steps

<<A>> >>A<< 1. Control link
>>A<< 2. Upper arm


<>

Lower arm removal steps

3. Stabilizer link connection
4. Lower arm and trailing arm connection
5. Shock absorber connection
6. Lower arm


REMOVAL SERVICE POINTS

<<A>> CONTROL LINK REMOVAL



After making a mating mark on the toe-in adjusting bolt, remove the control link.


<> LOWER ARM AND TRAILING ARM DISCONNECTION



After supporting the lower arm with a jack, separate the lower arm and the trailing arm.

INSTALLATION SERVICE POINT

>>A<< UPPER ARM/CONTROL LINK INSTALLATION



Install the upper arm/control link as shown so that its identification colour faces the trailing arm.


INSPECTION

M1341004900146

- Check the bushings for wear and deterioration.
- Check the control link, upper arm and lower arm for bending or breakage.


- Check all bolts for condition and straightness.

CONTROL LINK/UPPER ARM/LOWER ARM PILLOW BALL BUSHING STARTING TORQUE CHECK



Check each pillow ball bushing as follows.

1. Insert the mounting bolt to the pillow ball bushing. In the opposite direction, insert a washer, then install the mounting nut.




2. After rotating the inner sleeve (contained washer) several times, measure the starting torque of the pillow ball bushing using special tool preload socket (MB990326).

Standard value: 0.5 – 3.0 N·m

3. If the measured value exceeds the standard value, replace the control link, the upper arm, or the lower arm pillow ball bushing.
4. If the measured value is lower than the standard value, check that the pillow ball bushing turns smoothly without excessive play. If there is no excessive play and it turns smoothly, the pillow ball bushing can be reused.

LOWER ARM BUSHING AND LOWER ARM PILLOW BALL BUSHING REPLACEMENT

M1341011800196





Replace the lower arm bushing and lower arm pillow ball bushing as follows.

LOWER ARM BUSHING REPLACEMENT

CAUTION

Because the outside of both edges of the bushing are different, be careful not to mistake the direction.




Use following special tools to drive out and press fit the bushing.

- MB991447: Bushing Remover and Installer
- MB991448: Bushing Remover and Installer Base
- MB991449: Bushing Remover and Installer Supporter

After press fitting, the space between the edges of the bushing outer sleeve and of the lower arm should be 1.5 mm.

LOWER ARM PILLOW BALL BUSHING REPLACEMENT



Use following special tools to drive out and press fit the bushing.

- MB990957: Lower Arm Bushing Remover and Installer
 - MB990969: Guide
 - MB990971: Base
- MB990996: Lower Arm Bushing Arbor

After press fitting, the space between the edges of the bushing outer sleeve and of the lower arm should be 3 mm.

TRAILING ARM ASSEMBLY

REMOVAL AND INSTALLATION <2WD>

M1341002200323

CAUTION


* : Indicates parts which should be temporarily tightened, and then fully tightened with the vehicle on the ground in the unladen condition.

Pre-removal Operation

- Brake Fluid Draining
- Rear ABS Sensor Removal (Refer to GROUP 35B, ABS Sensor [P.35B-67](#)).
- Rear Brake Caliper Assembly Removal (Refer to GROUP 35A, Rear Disc Brake Assembly [P.35A-24](#)).
- Rear Hub Assembly Removal (Refer to GROUP 27A, Rear Axle Hub Assembly [P.27A-5](#)).

Post-installation Operation

- Rear Hub Assembly Installation (Refer to GROUP 27A, Rear Axle Hub Assembly [P.27A-5](#)).
- Rear Brake Caliper Assembly Installation (Refer to GROUP 35A, Rear Disc Brake Assembly [P.35A-24](#)).
- Rear ABS Sensor Installation (Refer to GROUP 35B, ABS Sensor [P.35B-67](#)).
- Brake Fluid Supplying and Bleeding (Refer to GROUP 35A, On-vehicle Service – Bleeding [P.35A-7](#)).
- Rear Wheel Alignment Check and Adjustment (Refer to [P.34-7](#)).
- Parking Brake Lever Stroke Adjustment (Refer to GROUP 36, On-vehicle Service – Parking Brake Lever Stroke Check and Adjustment [P.36-4](#)).



AC301223AB

Removal steps

1. Parking brake cable connection (Refer to GROUP 36, Parking Brake Cable [P.36-9](#)).
2. Brake hose and trailing arm connection
3. Lower arm and stabilizer link connection
4. Lower arm and shock absorber connection

<<A>>


Removal steps (Continued)

5. Control link and trailing arm connection
6. Upper arm and trailing arm connection
7. Lower arm and trailing arm connection
8. Rear parking brake assembly
9. Trailing arm and trailing arm bracket connecting bolt

Removal steps (Continued)

10. Trailing arm
11. Trailing arm bracket

REMOVAL SERVICE POINT

<<A>> LOWER ARM AND TRAILING ARM
DISCONNECTION

AC107126 AB

After supporting the lower arm with a jack, separate the lower arm and trailing arm connection.

REMOVAL AND INSTALLATION <4WD>

M1341002200334

CAUTION


* : Indicates parts which should be temporarily tightened, and then fully tightened with the vehicle on the ground in the unladen condition.

Pre-removal Operation

- Brake Fluid Draining
- Rear ABS Sensor Removal (Refer to GROUP 35B, ABS Sensor [P.35B-67](#)).

Post-installation Operation

- Rear ABS Sensor Installation (Refer to GROUP 35B, ABS Sensor [P.35B-67](#)).
- Brake Fluid Supplying and Bleeding (Refer to GROUP 35A, On-vehicle Service – Bleeding [P.35A-7](#)).
- Rear Wheel Alignment Check and Adjustment (Refer to [P.34-7](#)).
- Parking Brake Lever Stroke Adjustment (Refer to GROUP 36, On-vehicle Service – Parking Brake Lever Stroke Check and Adjustment [P.36-4](#)).

**Removal steps**

- Brake hose and trailing arm connection
- Parking brake cable
- Rear brake caliper assembly
- Upper arm and trailing arm connection
- Lower arm and stabilizer link connection
- Lower arm and shock absorber connection
- Control link and trailing arm connection
- Lower arm and trailing arm connection

<<A>>

Removal steps (Continued)

- Trailing arm and trailing arm bracket connecting bolt
- Drive shaft nut
- Brake disc
 - Drive shaft connection
- Rear hub assembly
- Rear parking brake assembly
- Trailing arm bracket
- Snap ring
- Wheel bearing
- Trailing arm


<> >>C<<

<<C>>

<<D>> >>B<<

<<E>> >>A<<

REMOVAL SERVICE POINTS



<<A>> LOWER ARM AND TRAILING ARM
DISCONNECTION

After supporting the lower arm with a jack, separate the lower arm and trailing arm connection.

<> DRIVE SHAFT NUT REMOVAL


CAUTION

Do not apply pressure to the wheel bearing by the vehicle weight to avoid possible damage to the wheel bearing before tightening the drive shaft nut fully.




Use special tool end yoke holder (MB990767) to fix the rear axle hub, and then remove the drive shaft nut.

<<C>> DRIVE SHAFT DISCONNECTION



1. Use following special tools to push out the drive shaft from the hub.
 - MB990241: Axle Shaft Puller
 - MB990242: Puller Shaft
 - MB990244: Puller Bar
 - MB990767: End Yoke Holder
 - MB991354: Puller Body
2. Hang the drive shaft on the vehicle body with a rope.


CAUTION

Do not apply pressure to the wheel bearing by the vehicle weight to avoid possible damage when the drive shaft is removed. If, however, vehicle weight must be applied to the bearing in moving the vehicle, temporarily secure the wheel bearing by using special tools front hub remover and installer, and spacer (MB991000 and MB991017).

<<D>> REAR HUB ASSEMBLY REMOVAL

CAUTION


Replace the wheel bearing with a new part because wheel bearing frictional surface will be damaged when removing the hub.




Use following special tools to pull out the rear hub assembly.

- MB990211: Sliding Hammer
- MB990241: Axle Shaft Puller
 - MB990244: Puller Bar
- MB991354: Puller Body

<<E>> WHEEL BEARING REMOVAL



1. Use special tool bearing remover (MB990560) to remove the wheel bearing inner race (outside) from the rear hub assembly.




2. Use following special tools to remove the wheel bearing from the trailing arm.

- MB990934: Adapter
- MB990938: Bar

INSTALLATION SERVICE POINTS

>>A<< WHEEL BEARING INSTALLATION




Use following special tools to press-in the wheel bearing.

- MB991400: Rear Wheel Bearing and Hub Installer
- MB991401: Rear Wheel Bearing and Hub Installer Base

>>B<< REAR HUB ASSEMBLY INSTALLATION

CAUTION

If the wheel bearing inner race has been pushed out, set the wheel bearing to the trailing arm again before installing the rear hub assembly.



Use following special tools to press-in the rear hub assembly.


- MB991400: Rear Wheel Bearing and Hub Installer

- MB991411: Rear Wheel Bearing and Hub Installer

>>C<< DRIVE SHAFT NUT INSTALLATION

CAUTION

Do not apply pressure to the wheel bearing by the vehicle weight to avoid possible damage to the wheel bearing before tightening the drive shaft nut fully.



1. Assemble the drive shaft washer in the illustrated direction.
2. Use special tool end yoke holder (MB990767) to fix the rear axle hub, and the tighten the drive shaft nut fully.


INSPECTION

M1341002300171


- Check the bushings for wear and deterioration.
- Check the trailing arm for bending or damage.

TRAILING ARM BUSHING
REPLACEMENT


M1341011300209



1. Use following special tools to drive out the trailing arm bushing.
 - MB991444: Bushing Remover and Installer Arbor
 - MB991445: Bushing Remover and Installer Base



2. Set the installation direction and installation location of the trailing arm bushing.
 - (1) Place the long projection end of the trailing arm bushing inner pipe towards the inside of the vehicle.
 - (2) Make sure that the hollow of the trailing arm bushing is located as shown in the illustration.



3. Using the special tools, press the trailing arm bushing into the position shown.


SHOCK ABSORBER ASSEMBLY

REMOVAL AND INSTALLATION

M1341002500335

CAUTION

* : Indicates parts which should be temporarily tightened, and then fully tightened with the vehicle on the ground in the unladen condition.



AC107092AB


<<A>>

Removal steps


1. Stabilizer link connection
2. Lower arm and trailing arm connection
3. Shock absorber mounting nut

Removal steps (Continued)

4. Shock absorber and lower arm connecting bolt
- >>A<< 5. Shock absorber assembly

REMOVAL SERVICE POINT**<<A>> LOWER ARM AND TRAILING ARM
DISCONNECTION**

After supporting the lower arm with a jack, separate the lower arm and trailing arm connection.

INSTALLATION SERVICE POINT**>>A<< SHOCK ABSORBER ASSEMBLY
INSTALLATION**

Install the spring seat stepped section so that it points towards the rear side of the vehicle.


INSPECTION

M1341002600149

- Check the rubber parts for cracks and wear.
- Check the shock absorber for malfunctions, oil leakage, or abnormal noise.

DISASSEMBLY AND REASSEMBLY

M1341005300318



AC209952AC

Disassembly steps


<<A>> >>D<< 1. Self-locking nut
2. Washer
3. Upper bushing B
>>C<< 4. Bracket assembly
5. Collar
6. Upper bushing A
7. Plate
8. Bump rubber
>>A<< 9. Upper spring pad
10. Dust cover
>>B<< 11. Coil spring
>>A<< 12. Lower spring pad
<> 13. Shock absorber

DISASSEMBLY SERVICE POINTS

<<A>> SELF-LOCKING NUT REMOVAL

CAUTION

- To hold the coil spring securely, install special tool arm set (MB991239) evenly, and so that the space between both arms of the special tool will be maximum within the installation range.
- Do not use an impact wrench to tighten the bolt of special tool spring compressor body (MB991237). It will break the special tool.




AC001070AB

1. Use following special tools to compress the coil spring.
 - MB991237: Spring Compressor Body
 - MB991239: Arm Set

⚠ WARNING


Do not use an impact wrench to remove the self-locking nut. Vibration of the impact wrench will cause special tools (MB991237 and MB991239) to slip and cause personal injury.




2. While holding the piston rod, remove the self-locking nut.

<> SHOCK ABSORBER DISPOSAL**⚠ WARNING**


Wear goggles when drilling to protect your eyes from flying metal debris.



The gas must be discharged from the shock absorber before discarding it. Place the shock absorber horizontally with its piston rod extended. Then drill a hole of approximately 3 mm in diameter at the location shown in the illustration and discharge the gas.

REASSEMBLY SERVICE POINTS**>>A<< UPPER SPRING PAD/LOWER SPRING PAD INSTALLATION****<UPPER SPRING PAD>**


Align the stepped section of the spring upper pad with the upper end of the coil spring, and install the spring upper pad.

**<LOWER SPRING PAD>**

Align the stepped section of the spring lower pad with the stepped section of the spring seat of the shock absorber, and install the spring lower pad.

>>B<< COIL SPRING INSTALLATION**⚠ CAUTION**


Do not use an impact wrench to tighten the bolt of special tool spring compressor body (MB991237). It will break the special tool.



1. Use following special tools to compress the coil spring, and install it to the lower spring pad.
 - MB991237: Spring Compressor Body

- MB991239: Arm Set

2. Align the end of the coil spring with the stepped section of the lower spring pad.

>>C<< BRACKET ASSEMBLY INSTALLATION

Install the rear shock absorber insulator so that the axis of the lower bushing inner pipe of the shock absorber and the line between the rear shock absorber insulator mounting bolts are straight when looking from above.

>>D<< SELF-LOCKING NUT INSTALLATION

1. Temporarily tighten the self-locking nut.

CAUTION

Do not use an impact wrench to tighten the self-locking nut, otherwise the self-locking nut will be damaged.

2. Remove the special tools, and then tighten the self-locking nut to 25 ± 5 N·m.


STABILIZER BAR

REMOVAL AND INSTALLATION

M1341003000236

Post-installation Operation

- Press the dust cover with your finger to check that there are no cracks or damage in the dust cover.



Removal steps


>>A<< 1. Stabilizer link
2. Fixture

Removal steps (Continued)

>>A<< 3. Bushing
>>A<< 4. Stabilizer bar

AC301224AB

INSTALLATION SERVICE POINT


>>A<< STABILIZER BAR/BUSHING/FIXTURE
INSTALLATION

Install the stabilizer bar, the bushings and the fixtures so that the stoppers come inboard of the bushings.

INSPECTION

M1341001400272

- Check the bushings for wear and deterioration.
- Check the stabilizer bar for deterioration or damage.
- Check all bolts for condition and straightness.

STABILIZER LINK BALL JOINT TURNING
TORQUE CHECK

- After shaking the ball joint stud several times, install the nut to the stud and use special tool preload socket (MB990326) to measure the turning torque of the ball joint.

Standard value: 1.7 – 3.1 N·m

- If the measured value exceeds the standard value, replace the stabilizer link.

- If the measured value is lower than the standard value, check that the ball joint turns smoothly without excessive play. If so, it is possible to re-use that ball joint.

STABILIZER LINK BALL JOINT DUST COVER
CHECK


- Check the dust cover for cracks or damage by pushing it with your finger.
- If the dust cover is cracked or damaged, replace the stabilizer link.

NOTE: Cracks or damage of the dust cover may cause damage to the ball joint. When it is damaged during service work, replace the dust cover (Refer to P.34-24).

STABILIZER LINK BALL JOINT DUST
COVER REPLACEMENT

M1341010900220

Only when the dust cover is damaged accidentally during service work, replace the dust cover as follows:



- Remove the clip ring and the dust cover.
- Apply specified grease to the inside of a new dust cover.
- Wrap plastic tape around the stabilizer link stud, and then install the dust cover to the stabilizer link.
- Secure the dust cover by the clip ring.
- Check the dust cover for cracks or damage by pushing it with finger.

Specified grease: Multipurpose grease SAE J310, NLGI No.2 or equivalent

REAR SUSPENSION CROSMEMBER

REMOVAL AND INSTALLATION


M1341006800219

Pre-removal Operation

- Main Muffler, Centre Exhaust Pipe Removal (Refer to GROUP 15, Exhaust pipe and Main Muffler P.15-13).
- Control Link, Upper Arm, Lower Arm Removal (Refer to P.34-8).
- Stabilizer Bar Removal (Refer to P.34-23).
- Fuel Filler Neck Protector Removal (Refer to GROUP 13B, Fuel Tank P.13C-7).

Post-installation Operation

- Fuel Filler Neck Protector Installation (Refer to GROUP 13B, Fuel Tank P.13C-11).
- Stabilizer Bar Installation (Refer to P.34-23).
- Control Link, Upper Arm, Lower Arm Installation (Refer to P.34-8).
- Main Muffler, Centre Exhaust Pipe Installation (Refer to GROUP 15, Exhaust pipe and Main Muffler P.15-13).
- Rear Wheel Alignment Check and Adjustment (Refer to P.34-7).



AC107129 AB

Removal steps

1. Dynamic damper <4WD>
2. Differential support arm connecting bolt <4WD>
3. Rear suspension crossmember
4. Differential support arm <4WD>
5. Plug

INSPECTION

M1341006900067

- Check the crossmember for cracks or deformation.
- Check all bolts for condition and straightness.

NOTES