

GROUP 55A

HEATER, AIR CONDITIONER AND VENTILATION

CONTENTS

GENERAL INFORMATION	55A-3	COMPRESSOR DRIVE BELT ADJUSTMENT	55A-49
SERVICE SPECIFICATIONS.....	55A-3	SIMPLE INSPECTION OF THE A/C PRESSURE SENSOR	55A-50
LUBRICANTS	55A-3	CHARGING	55A-50
SPECIAL TOOLS.....	55A-4	CORRECTING LOW REFRIGERANT LEVEL IN CASE THE SERVICE CAN IN USED	55A-52
TROUBLESHOOTING	55A-5	DISCHARGING SYSTEM	55A-53
DIAGNOSIS TROUBLESHOOTING FLOW	55A-5	REFILLING OF OIL IN THE A/C SYSTEM	55A-53
SYMPTOM CHART.....	55A-5	PERFORMANCE TEST	55A-53
SYMPTOM PROCEDURES	55A-5	REFRIGERANT LEAK REPAIR PROCEDURE	55A-54
CHECK AT ECU TERMINAL	55A-48	COMPRESSOR NOISE CHECK.....	55A-55
ON-VEHICLE SERVICE.....	55A-49	POWER RELAY CHECK.....	55A-55
SIGHT GLASS REFRIGERANT LEVEL TEST.....	55A-49	IDLE-UP OPERATION CHECK.....	55A-57
MAGNETIC CLUTCH TEST	55A-49	CLEAN AIR FILTER REPLACEMENT PROCEDURE	55A-57

Continued on next page

WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

⚠ WARNING

- *Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver and passenger (from rendering the SRS inoperative).*
- *Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.*
- *MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B - Supplemental Restraint System (SRS) before beginning any service or maintenance of any component of the SRS or any SRS-related component.*

NOTE

The SRS includes the following components: SRS air bag control unit, SRS warning light, front impact sensors, air bag module, clock spring, and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by an asterisk (*).

HEATER CONTROL ASSEMBLY AND A/C SWITCH	55A-58	EVAPORATOR ASSEMBLY	55A-67
REMOVAL AND INSTALLATION	55A-58	REMOVAL AND INSTALLATION	55A-67
INSPECTION	55A-59	INSPECTION	55A-68
DISASSEMBLY AND REASSEMBLY	55A-60		
HEATER UNIT, HEATER CORE, BLOWER ASSEMBLY AND EVAPORATOR UNIT	55A-61	COMPRESSOR ASSEMBLY AND TENSION PULLEY	55A-69
REMOVAL AND INSTALLATION	55A-61	REMOVAL AND INSTALLATION	55A-69
HEATER UNIT	55A-63	INSPECTION	55A-70
DISASSEMBLY AND REASSEMBLY	55A-63	DISASSEMBLY AND REASSEMBLY	55A-71
BLOWER ASSEMBLY	55A-64	INSPECTION	55A-73
DISASSEMBLY AND REASSEMBLY	55A-64		
BLOWER MOTOR, RESISTOR AND OUTSIDE/INSIDE AIR SELECTION DAMPER CONTROL MOTOR	55A-65	CONDENSER AND CONDENSER FAN MOTOR	55A-74
REMOVAL AND INSTALLATION	55A-65	REMOVAL AND INSTALLATION	55A-74
INSPECTION	55A-66	INSPECTION	55A-76
		REFRIGERANT LINE	55A-77
		REMOVAL AND INSTALLATION	55A-77
		VENTILATORS	55A-79
		REMOVAL AND INSTALLATION	55A-79

GENERAL INFORMATION

M1552000100555

The heater and A/C system incorporating the heater and cooling units has reduced ventilation resistance to increase air volume and reduce noise. The manual A/C is installed for LHD-Invite model.

GENERAL SPECIFICATION

Item	Specification	
Heater unit type	Two-layer full blow air mix method	
Heater control type	Rotary type	
A/C switch type	Push button type	
Compressor type	Standard type	MSC90CA
	Large capacity type	MSC105CA
Cooling output	5.5 kW	
Heating output	5.0 kW	

SERVICE SPECIFICATIONS

M1552000300399

Item	Standard value	
Idle speed r/min	2000-Non-Turbo	750 ± 50
	2400	700 ± 50
Idle-up speed r/min	850 ± 50	
Resistor (for blower motor) Ω	LO	2.54
	ML	1.24
	MH	0.6
Air gap (magnetic clutch) mm	0.3 – 0.5	
A/C refrigerant temperature switch operating temperature °C	Less than 2 ohms	Slightly below 150°C
	No continuity	150°C or more





LUBRICANTS

M1552000400363

Item	Specified lubricant	Quantity
Compressor refrigerant unit lubricant	MSC105CA	SUN PAG 56
	MSC90CA	SUN PAG 56
Each connection of refrigerant line	SUN PAG 56	As required
Refrigerant	R134a (HFC-134a)	550 ± 20 g

SPECIAL TOOLS

M1552000600475

Tool	Tool number	Name	Application
 B991367	MB991367	Special spanner	Armature mounting nut of compressor removal and installation
 B991386	MB991386	Pin	
A  B  C  D  DO NOT USE MB991223AZ	MB991223 A:MB991219 B:MB991220 C:MB991221 D:MB991222	Harness set A: Test harness B: LED harness C: LED harness adapter D: Probe	Continuity check and voltage measurement at harness wire or connector A: For checking connector pin contact pressure B: For checking power supply circuit C: For checking power supply circuit D: For connecting a locally sourced tester
 MB992006	MB992006	Extra fine probe	Continuity check and voltage measurement at harness wire or connector

TROUBLESHOOTING

DIAGNOSIS TROUBLESHOOTING FLOW

M1552009600353

Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points [P.00-6](#).

SYMPTOM CHART

M1552009900439

NOTE: Refer to GROUP 14, Trouble shooting for the condenser fan.

Symptom	Inspection Procedure	Reference Page
When the ignition switch is "ON" the A/C does not operate.	1	P.55A-5
Inside/outside air selection is not possible.	2	P.55A-6
When the A/C is operating, temperature inside the passenger compartment does not decrease (cool air is not emitted).	3	P.55A-9
Blower fan and motor do not turn.	4	P.55A-26
Blower air amount cannot be changed.	5	P.55A-34
The A/C indicator flashes.	6	P.55A-37
Defogger function does not operate.	7	P.55A-38
Defogger Timer function does not operate.	8	P.55A-44
Malfunction of the A/C-ECU power supply system.	9	P.55A-45
Condenser Fan does not operate.	10	Refer to GROUP 14 P.14-3

SYMPTOM PROCEDURES

Inspection Procedure 1: When the Ignition Switch is "ON" the A/C does not Operate.

COMMENTS ON TROUBLE SYMPTOM

The blower system or the compressor system may be defective if there is no cool air coming from the spit hole.

TROUBLESHOOTING HINTS

- Malfunction of blower motor
- Malfunction of A/C compressor

DIAGNOSIS PROCEDURE

Check that the blower motor operation when the blower switch is moved to the "HI" position.

- (1) Turn the ignition switch to the "ON" position.
- (2) Turn the blower switch to the "HI" position.


Q: Does the blower motor operate when the blower switch is moved to the "HI" position?

YES : Refer to Inspection procedure 3 "When the A/C is operating, temperature inside the passenger compartment does not decrease (cool air not emitted) [P.55A-9](#)."

NO : Refer to Inspection procedure 4 "Blower fan and motor do not turn [P.55A-26](#)."

Inspection Procedure 2: Outside/Inside Air Selection is not possible.

Outside/Inside Air Selection Damper Control Motor Circuit



Wire colour code
 B : Black LG : Light green G : Green L : Blue
 W : White Y : Yellow SB : Sky blue BR : Brown
 O : Orange GR : Grey R : Red P : Pink V : Violet
 W3Z03E01AA
 AC606568AB

COMMENTS ON TROUBLE SYMPTOM

If the outside/inside air selection damper motor does not operate normally, the outside/inside air selection damper motor system may be defective.

TROUBLESHOOTING HINTS

- Malfunction of the outside/inside air selection damper motor
- Damaged the wiring harness or connectors
- Malfunction of the manual A/C control panel (A/C-ECU)

DIAGNOSIS PROCEDURE

STEP 1. Check the rear window defogger and A/C operations.


Q: Do the rear window defogger and A/C work normally?

YES : Go to Step 2.

NO : Refer to Inspection procedure 9


"Malfunction of the A/C-ECU power supply system [P.55A-45](#)."

STEP 2. Voltage measurement at the C-311 outside/inside air selection damper control motor connector.



- (1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the "ON" position.



(3) Measure the voltage between terminal 7 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 3.

STEP 3. Connector check: C-311 outside/inside air selection damper control motor connector




Q: Is the check result normal?


YES : Go to Step 4.

NO : Repair the connector.


STEP 4. Check the wiring harness between C-311 outside/inside air selection damper control motor connector terminal No.7 and the ignition switch (IG2).



NOTE:



Connectors: C-203, C-205
Junction Block (Front View)



Prior to the wiring harness inspection, check intermediate connector C-10, junction block connectors C-205 and C-203, and repair if necessary.

- Check the outside/inside air selection damper control motor power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Repair the wiring harness.

STEP 5. Check the outside/inside air selection damper control motor



Refer to [P.55A-66](#).

Q: Does outside/inside air selection damper control motor work normally?

YES : Go to Step 6.

NO : Replace the outside/inside air selection damper control motor.

STEP 6. Connector check: C-311 outside/inside air selection damper control motor connector and C-06 A/C-ECU





Q: Is the check result normal?

YES : Go to Step 7.

NO : Repair the connector.

STEP 7. Check the wiring harness between C-311 outside/inside air selection damper control motor connector (terminals 6 and 4) and A/C-ECU C-06 (terminals 2 and 3).



NOTE: Prior to the wiring harness inspection, check intermediate connector C-10, and repair if necessary.


- Check the outside/inside air selection damper control motor earth line for open or short circuit.

Q: Is the check result normal?

YES : Replace the manual A/C control panel (A/C-ECU).

NO : Repair the wiring harness.

Inspection Procedure 3: When the A/C is Operating, Temperature Inside the Passenger Compartment does not Decrease (Cool Air is not Emitted).



COMMENTS ON TROUBLE SYMPTOM

If cool air is not distributed when the A/C switch is on, the air thermo sensor or the A/C compressor relay system may be defective.

TROUBLESHOOTING HINTS

- Improper amount of refrigerant
- Malfunction of the air thermo sensor
- Malfunction of the A/C pressure sensor

- Malfunction of the A/C compressor relay
- Malfunction of the A/C refrigerant temperature switch
- Malfunction of the magnetic clutch
- Malfunction of the manual A/C control panel (A/C-ECU)
- Damaged the wiring harness or connectors
- Malfunction of the engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Check the rear window defogger and outside/inside air selection damper control motor operation.

Q: Do the rear window defogger and outside/inside air selection damper control motor work normally?

YES : Go to Step 2.

NO : Refer to Inspection procedure 9

"Malfunction of the A/C-ECU power supply system [P.55A-45](#)."

STEP 2. Check the blower motor operation.

Q: Does the blower motor work normally?

YES : Go to Step 3.

NO : Refer to Inspection procedure 4 "Blower fan and motor do not turn [P.55A-26](#)."

STEP 3. Check the A/C compressor.



Check the A/C compressor for compressor oil leaks.

Q: Is the check result satisfactory?

YES : Go to Step 4.



NO : Replace the A/C compressor or the expansion valve.

STEP 4. Voltage measurement at the B-27 A/C compressor connector.





(1) Disconnect the connector, and measure at the wiring harness side.


(2) Turn the ignition switch to the "ON" position.



(3) Disconnect engine-ECU connector C-134, and earth terminal 8. <2000-Non-Turbo>



(4) Disconnect engine-ECU or engine-A/T-ECU connector C-139, and earth terminal 8. <2400>



(5) Measure the voltage between terminal 1 and body earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 18.

NO : Go to Step 5.

STEP 5. Check the A/C compressor relay continuity.


Refer to [P.55A-55](#).

Q: Is the A/C compressor relay in good condition?


YES : Go to Step 6.

NO : Replace the A/C compressor relay.

STEP 6. Voltage measurement at B-18X A/C compressor relay connector.



(1) Remove the relay, and measure at the relay box side.
(2) Turn the ignition switch to the "ON" position.




(3) Measure the voltage between terminal 3 and body earth.

OK: System voltage



Q: Is the check result normal?

YES : Go to Step 9.

NO : Go to Step 7.

STEP 7. Connector check: B-18X A/C
compressor relay connector


NOTE:

Connectors: C-203, C-205
Junction Block (Front View)

Q: Is the check result normal?

YES : Go to Step 8.

NO : Repair the connector.

STEP 8. Check the wiring harness between B-18X
A/C compressor relay connector terminal No.3
and the ignition switch (IG2).

Prior to the wiring harness inspection, check intermediate connector C-106, junction block connectors C-203 and C-205, and repair if necessary.


- Check the A/C compressor relay power supply line for open circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Repair the wiring harness.

STEP 9. Voltage measurement at B-18X A/C compressor relay connector.



(1) Remove the relay, and measure at the junction block side.



(2) Measure the voltage between terminal 4 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 12.

NO : Go to Step 10.

STEP 10. Connector check: B-18X A/C compressor relay connector




Q: Is the check result normal?


YES : Go to Step 11.

NO : Repair the connector.


STEP 11. Check the wiring harness between B-18X A/C compressor relay connector terminal No.4 and the battery.



STEP 12. Connector check: B-18X A/C compressor relay connector and B-27 A/C compressor connector



NOTE:





Prior to the wiring harness inspection, check intermediate connector A-14, and repair if necessary.

- Check the A/C compressor relay power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Repair the wiring harness.




Q: Is the check result normal?





YES : Go to Step 13.

NO : Repair the connector.

STEP 13. Check the wiring harness between B-18X A/C compressor relay connector terminal No.1 and B-27 A/C compressor connector terminal No.1.



STEP 14. Connector check: C-134 engine-ECU connector and B-18X A/C compressor relay connector



- Check the A/C compressor power supply line for open circuit.

Q: Is the check result normal?

YES <2000-Non-Turbo> : Go to Step 14.

YES <2400> : Go to Step 16.



NO : Repair the wiring harness.

Q: Is the check result normal?

YES : Go to Step 15.

NO : Repair the connector.

STEP 15. Check the wiring harness between C-134 engine-ECU connector terminal No.8 and B-18X A/C compressor relay connector terminal No.2.





- Check the A/C compressor relay earth line for open or short circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Repair the wiring harness.

STEP 16. Connector check: C-139 engine-ECU or engine-A/T-ECU connector and B-18X A/C compressor relay connector





Q: Is the check result normal?

YES : Go to Step 17.

NO : Repair the connector.

STEP 17. Check the wiring harness between C-139 engine-ECU or engine-A/T-ECU connector terminal No.8 and B-18X A/C compressor relay connector terminal No.2.




- Check the A/C compressor relay earth line for open or short circuit.

Q: Is the check result normal?



YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Repair the wiring harness.



STEP 18. Voltage measurement at C-06 A/C-ECU connector.




- Disconnect A/C-ECU connector C-06, and measure at the wiring harness side.
- Turn the ignition switch to the "ON" position.



- Disconnect engine-ECU connector C-134, and earth terminal 8. <2000-Non-Turbo>



(4) Disconnect engine-ECU or engine-A/T-ECU connector C-139, and earth terminal 8. <2400>



(5) Measure the voltage between terminal 7 and body earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 21.

NO : Go to Step 19.

STEP 19. Connector check: B-18X A/C compressor relay connector and C-06 A/C-ECU connector





Q: Is the check result normal?

YES : Go to Step 20.

NO : Repair the connector.

STEP 20. Check the wiring harness between B-18X A/C compressor relay connector terminal No.1 and C-06 A/C-ECU connector terminal No.7.



NOTE: Prior to the wiring harness inspection, check intermediate connector C-104, and repair if necessary.


- Check the A/C compressor relay output line for open or short circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Repair the wiring harness.

STEP 21. Voltage measurement at C-06 A/C-ECU connector.



- (1) Disconnect the connector, and measure at the wiring harness side.
- (2) Turn the ignition switch to the "ON" position.
- (3) Turn the blower switch to the "ON" position.




- (4) Measure the voltage between terminal 8 and body earth.

OK: System voltage

Q: Is the check result normal?


YES : Go to Step 24.

NO : Go to Step 22.

STEP 22. Connector check: C-11 resistor connector and C-06 A/C-ECU connector**Q: Is the check result normal?**

YES : Go to Step 23.

NO : Repair the connector.

STEP 23. Check the wiring harness between C-11 resistor connector terminal No.4 and C-06 A/C-ECU connector terminal No.8.**Q: Is the check result normal?**YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#))

NO : Repair the wiring harness.

STEP 24. Check the magnetic clutch operation.
Refer to [P.55A-49](#).**Q: Can the sound of the magnetic clutch (click) be heard?**

YES : Go to Step 25.

NO : Replace the compressor magnet clutch.

STEP 25. Check the refrigerant temperature switch.Refer to [P.55A-73](#).**Q: Is the refrigerant temperature switch operating properly?**

YES : Go to Step 26.


NO : Replace the refrigerant temperature switch.

STEP 26. Check the air thermo sensor.Refer to [P.55A-68](#).**Q: Is the air thermo sensor in good condition?**

YES : Go to Step 27.

NO : Replace the air thermo sensor.

STEP 27. Connector check: C-10 intermediate connector and C-06 A/C-ECU connector




Q: Is the check result normal?

YES : Go to Step 28.

NO : Repair the connector.

STEP 28. Check the wiring harness between C-10 air thermo sensor connector (terminals 1, 3, 4 and 5) and C-06 A/C-ECU connector (terminals 14, 16 and 13).



- Check the air thermo sensor output and earth line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 29.

NO : Repair the wiring harness.

STEP 29. Check the refrigerant level.

Refer to [P.55A-49](#).

Q: Is the refrigerant level correct?

YES : Go to Step 30.

NO : Correct the refrigerant level (Refer to On-vehicle Service [P.55A-50](#)).

STEP 30. Check the A/C pressure sensor operation.



Refer to [P.55A-50](#).

Q: Is the A/C pressure sensor operating properly?

YES : Go to Step 31.

NO : Replace the A/C pressure sensor.

STEP 31. Connector check: A-02 A/C pressure sensor connector and C-06 A/C-ECU connector





Q: Is the check result normal?


YES : Go to Step 32.

NO : Repair the connector.

STEP 32. Check the wiring harness between A-02 A/C pressure sensor connector terminal No.2 and C-06 A/C-ECU connector terminal No.15.



NOTE:

*Prior to the wiring harness inspection, check intermediate connector C-116, and repair if necessary.*

- Check the A/C pressure sensor output line for open or short circuit.



Q: Is the check result normal?

YES <2000-Non-Turbo> : Go to Step 33.

YES <2400> : Go to Step 36.

NO : Repair the wiring harness.

**STEP 33. Connector check: C-134, C-135
engine-ECU connector and C-06 A/C-ECU
connector**





Q: Is the check result normal?

YES : Go to Step 34.

NO : Repair the connector.

**STEP 34. Check the wiring harness between
C-134 engine-ECU connector terminal No.24 and
C-06 A/C-ECU connector terminal No.5.**



NOTE: Prior to the wiring harness inspection, check intermediate connector C-104, and repair if necessary.


- Check the communication line for open or short circuit.

Q: Is the check result normal?



YES : Go to Step 35.

NO : Repair the wiring harness.

STEP 35. Check the wiring harness between C-135 engine-ECU connector terminal No.45 and C-06 A/C-ECU connector terminal No.4.



STEP 36. Connector check: C-141 engine-ECU or engine-A/T-ECU connector and C-06 A/C-ECU connector



NOTE: Prior to the wiring harness inspection, check intermediate connector C-104, and repair if necessary.

- Check the communication line for open or short circuit.


Q: Is the check result normal?

YES : Replace the manual A/C control panel (A/C-ECU) or engine-ECU.
NO : Repair the wiring harness.




Q: Is the check result normal?

YES : Go to Step 37.
NO : Repair the connector.

STEP 37. Check the wiring harness between C-141 engine-ECU or engine-A/T-ECU connector terminal No.78 and C-06 A/C-ECU connector terminal No.5.



STEP 38. Check the wiring harness between C-141 engine-ECU or engine-A/T-ECU connector terminal No.69 and C-06 A/C-ECU connector terminal No.4.



NOTE: Prior to the wiring harness inspection, check intermediate connector C-104, and repair if necessary.

- Check the communication line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 38.

NO : Repair the wiring harness.

NOTE: Prior to the wiring harness inspection, check intermediate connector C-104, and repair if necessary.


- Check the communication line for open or short circuit.

Q: Is the check result normal?

YES : Replace the manual A/C control panel (A/C-ECU), engine-ECU <M/T> or engine-A/T-ECU <A/T>.

NO : Repair the wiring harness.

Inspection Procedure 4: Blower Fan and Motor do not Turn.

**COMMENTS ON TROUBLE SYMPTOM**

If the blower fan and motor does not turn when the blower switch is operated, the blower switch may be defective.

TROUBLESHOOTING HINTS

- Malfunction of the blower relay
- Malfunction of the blower switch
- Damaged the wiring harness or connectors
- Malfunction of the blower motor

DIAGNOSIS PROCEDURE**STEP 1. Check that the blower motor operates when the blower switch is moved to the "4 (HI)" position.**


- (1) Turn the ignition switch to the "ON" position.
- (2) Turn the blower switch to the "4 (HI)" position.

Q: Does the blower motor operate when the blower switch is moved to the "4 (HI)" position?


YES : Refer to Inspection procedure 5 "Blower air amount cannot be changed [P.55A-34](#)."

NO : Go to Step 2.

STEP 2. Resistance measurement at the C-12 blower motor connector.



(1) Disconnect the connector, and measure at the wiring harness side.



(2) Measure the resistance between terminal 2 and body earth.


OK: 2 ohm or less

Q: Is the check result normal?

YES : Go to Step 5.

NO : Go to Step 3.

STEP 3. Connector check: C-12 blower motor connector




Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair the connector.

STEP 4. Check the wiring harness between C-12 blower motor connector terminal No.2 and body earth.




- Check the blower motor earth line for open circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent

malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-6).

NO : Repair the wiring harness.

STEP 5. Voltage measurement at C-12 blower motor connector.

- (1) Disconnect the connector, and measure at the wiring harness side.
- (2) Turn the ignition switch to the "ON" position.
- (3) Turn the blower switch to the "4 (HI)" position.



- (4) Measure the voltage between terminal 1 and body earth.


OK: System voltage

Q: Is the check result normal?
 YES : Go to Step 21.
 NO : Go to Step 6.


STEP 6. Check the blower relay continuity.

Refer to P.55A-55.

Q: Is the blower relay continuity in good condition?
 YES : Go to Step 7.
 NO : Replace the blower relay.

STEP 7. Voltage measurement at C-207 blower relay connector.


- (1) Remove the relay, and measure at the junction block side.
- (2) Turn the ignition switch to the "ON" position.



- (3) Measure the voltage between terminal 1 and earth.


OK: System voltage

Q: Is the check result normal?
 YES : Go to Step 10.
 NO : Go to Step 8.

STEP 8. Connector check: C-207 blower relay connector

Q: Is the check result normal?
 YES : Go to Step 9.
 NO : Repair the connector.

STEP 9. Check the wiring harness between C-207 blower relay connector terminal No.1 and the ignition switch (IG2).




NOTE: Prior to the wiring harness inspection, check junction block connector C-203, and repair if necessary.

- Check the blower relay power supply line for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).
NO : Repair the wiring harness.

STEP 10. Resistance measurement at C-207 blower relay connector.



- (1) Remove the relay, and measure at the junction block side.




- (2) Measure the resistance Continuity between terminal 3 and body earth.

OK: 2 ohm or less

Q: Is the check result normal?

YES : Go to Step 13.
NO : Go to Step 11.


STEP 11. Connector check: C-207 blower relay connector.



Q: Is the check result normal?

YES : Go to Step 12.
NO : Repair the connector.

STEP 12. Check the wiring harness between C-207 blower relay connector terminal No.3 and earth.




NOTE: Prior to the wiring harness inspection, check junction block connectors C-205, and repair if necessary.

- Check the blower relay earth wires for open circuit.


Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).
NO : Repair the wiring harness.

STEP 13. Voltage measurement at C-207 blower relay connector.



- (1) Remove the relay, and measure at the junction block side.




- (2) Measure the voltage between terminal 5 and body earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 16.
NO : Go to Step 14.


STEP 14. Connector check: C-207 blower relay connector




Q: Is the check result normal?

YES : Go to Step 15.
NO : Repair the connector.

STEP 15. Check the wiring harness between C-207 blower relay connector terminal No.5 and fusible link (1).



NOTE:



Prior to the wiring harness inspection, check intermediate connectors C-116 and junction block connector C-204, and repair if necessary.

- Check the blower relay power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Repair the wiring harness.

STEP 16. Check the blower switch continuity.



Refer to [P.55A-59](#).

Q: Is the blower switch continuity in good condition?

YES : Go to Step 17.

NO : Replace the blower switch.

STEP 17. Connector check: C-08 blower switch connector and C-207 blower relay connector





Q: Is the check result normal?

YES : Go to Step 18.

NO : Repair the connector.

STEP 18. Check the wiring harness between C-08 blower switch connector terminal No.2 and C-207 blower relay connector terminal No.4.



NOTE: Prior to the wiring harness inspection, check junction block connectors C-203, and repair if necessary.


- Check the blower relay output line for open circuit.

Q: Is the check result normal?

YES : Go to Step 19.

NO : Repair the wiring harness.

STEP 19. Connector check: C-12 blower motor connector and C-08 blower switch connector




Q: Is the check result normal?

YES : Go to Step 20.

NO : Repair the connector.

STEP 20. Check the wiring harness between C-12 blower motor connector terminal No.1 and C-08 blower switch connector terminal No.6.



- Check the blower motor power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Repair the wiring harness.


STEP 21. Check the blower fan and motor operation.
Refer to [P.55A-66](#).

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Replace the blower motor.

Inspection Procedure 5: Blower Air Amount cannot be Changed.

**COMMENTS ON TROUBLE SYMPTOM**

If the blower air amount can not be changed when the blower switch is operated, the blower switch may be defective.

TROUBLESHOOTING HINTS

- Malfunction of the resistor
- Damaged the wiring harness or connectors
- Malfunction of the blower switch

DIAGNOSIS PROCEDURE**STEP 1. Check that the blower motor operates when the blower switch is moved to the "4 (HI)" position.**

- (1) Turn the ignition switch to the "ON" position.
- (2) Turn the blower switch to the "4 (HI)" position.

Q: Does the blower motor operate when the blower switch is moved to the "4 (HI)" position?

YES : Go to STEP 2.

NO : Refer to Inspection procedure 4 "Blower fan and motor do not turn [P.55A-26](#)."

STEP 2. Check the blower switch continuity.

Refer to [P.55A-59](#).

Q: Is the blower switch continuity in good condition?

YES : Go to Step 3.

NO : Replace the blower switch.

STEP 3. Check the resistor resistance value.


Refer to P.55A-66.

Q: Is the measured value at the standard value?

YES : Go to Step 4.

NO : Replace the resistor.

STEP 4. Connector check: C-08 blower switch connector and C-11 resistor connector




Q: Is the check result normal?

YES : Go to Step 5.

NO : Repair the connector.

STEP 5. Check the wiring harness between C-08 blower switch connector (terminals 1, 4 and 5) and C-11 resistor connector (terminals 4, 1 and 3).




- Check the blower switch output line for open circuit.

Q: Is the check result normal?


YES : Go to Step 6.

NO : Repair the wiring harness.

STEP 6. Connector check: C-11 resistor connector and C-12 blower motor connector**Q: Is the check result normal?**

YES : Go to Step 7.

NO : Repair the connector.

STEP 7. Check the wiring harness between C-12 blower motor connector (terminal 1) and C-11 resistor connector (terminal 2).

- Check the blower motor power supply line for open circuit.


Q: Is the check result normal?

YES : No action to be taken.

NO : Repair the wiring harness.

Inspection Procedure 6: The A/C Indicator Flashes.

A/C Pressure Sensor and Air Thermo Sensor Circuit



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
 BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet

W3Z03E05AA
AC606576AB

COMMENTS ON TROUBLE SYMPTOM

If the A/C indicator flashes then the possible causes may be due to a defective A/C pressure system or insufficient refrigerant gas.

TROUBLESHOOTING HINTS

- Malfunction of the A/C pressure sensor
- Malfunction of the air thermo sensor
- Malfunction of the manual A/C control panel (A/C-ECU)

DIAGNOSIS PROCEDURE

STEP 1. Check the A/C pressure sensor operation.

Refer to [P.55A-50](#).

Q: Is the A/C pressure sensor operating properly?

YES : Go to Step 2.

NO : Replace the A/C pressure sensor.

STEP 2. Check the air thermo sensor.

Refer to [P.55A-68](#).

Q: Is the air thermo sensor in good condition?

YES : Go to Step 3.

NO : Replace the air thermo sensor.

STEP 3. Check the refrigerant level.


Refer to [P.55A-49](#).

Q: Is the refrigerant level correct?

YES : Replace the manual A/C control panel (A/C-ECU).

NO : Correct the refrigerant level (Refer to [P.55A-54](#)).

Inspection Procedure 7: Rear Window Defogger Function does not Operate.

W5Z55E000A
AC606577AB**COMMENTS ON TROUBLE SYMPTOM**

If the rear window defogger does not operate when the rear window defogger switch is turned on, the rear window defogger relay system may be defective.

TROUBLESHOOTING HINTS

- Malfunction of the rear window defogger relay
- Malfunction of the rear window defogger
- Damaged the wiring harness or connectors
- Malfunction of the manual A/C control panel (A/C-ECU)

DIAGNOSIS PROCEDURE**STEP 1. Check the A/C and outside/inside air selection damper control motor operation.**


Q: Do the A/C and outside/inside air selection damper control motor work normally?

YES : Go to Step 2.


NO : Refer to Inspection procedure 9

"Malfunction of the A/C-ECU Power Supply system [P.55A-45](#)."

STEP 2. Voltage measurement at rear window defogger connector F-04.



- (1) Disconnect the connector, and measure at the wiring harness side.
- (2) Turn the ignition switch to the "ON" position.
- (3) Turn the rear window defogger switch to the "ON" position. (operate for approx. 11 minutes)



- (4) Measure the voltage between terminal 1 and body earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 14.
NO : Go to Step 3.


STEP 3. Check the rear window defogger relay continuity.

Refer to P.55A-55.


Q: Is the Rear Window Defogger relay continuity in good condition?

YES : Go to Step 4.
NO : Replace the rear window defogger relay.

STEP 4. Voltage measurement at rear window defogger relay connector C-206.



- (1) Remove the relay, and measure at the junction block side.




- (2) Measure the voltage between terminal 5 and body earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 7.
NO : Go to Step 5.



STEP 5. Connector check: C-206 rear window defogger relay connector




Q: Is the check result normal?

YES : Go to Step 6.
NO : Repair the connector.

STEP 6. Check the wiring harness between C-206 rear window defogger relay connector terminal No.5 and the fusible link (1).



NOTE:



Prior to the wiring harness inspection, check intermediate connector C-116 and junction block connector C-204, and repair if necessary.


- Check the rear window defogger relay power supply line for open circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Repair the wiring harness.

STEP 7. Voltage measurement at rear window defogger relay connector C-206.



- (1) Remove the relay, and measure at the junction block side.
- (2) Turn the ignition switch to the "ON" position.



- (3) Measure the voltage between terminal 1 and earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 10.

NO : Go to Step 8.

STEP 8. Connector check: C-206 rear window defogger relay connector




Q: Is the check result normal?

YES : Go to Step 9.

NO : Repair the connector.

STEP 9. Check the wiring harness between C-206 rear window defogger relay connector terminal No.1 and ignition switch (IG2).



NOTE: Prior to the wiring harness inspection, check junction block connector C-203, and repair if necessary.



- Check the rear window defogger relay power supply line for open circuit.

Q: Is the check result normal?

YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction P.00-6).

NO : Repair the wiring harness.

STEP 10. Connector check: C-206 rear window defogger relay connector and C-06 A/C-ECU connector.





Q: Is the check result normal?

YES : Go to Step 11.

NO : Repair the connector.

STEP 11. Check the wiring harness between C-206 rear window defogger relay connector terminal No.3 and C-06 A/C-ECU connector terminal No.1.



NOTE: Prior to the wiring harness inspection, check junction block connector C-205, and repair if necessary.



- Check the rear window defogger relay earth line for open or short circuit.

Q: Is the check result normal?

YES : Go to Step 12.

NO : Repair the wiring harness.

STEP 12. Connector check: C-206 rear window defogger relay connector and F-04 rear window defogger connector





Q: Is the check result normal?

YES : Go to Step 13.

NO : Repair the connector.

STEP 13. Check the wiring harness between C-206 rear window defogger relay connector terminal No.4 and F-04 rear window defogger connector terminal No.1.



NOTE: Prior to the wiring harness inspection, check junction block connector C-209, and repair if necessary.


- Check the rear window defogger relay output line for open circuit.

Q: Is the check result normal?


YES : Replace the manual A/C control panel (A/C-ECU).

NO : Repair the wiring harness.

STEP 14. Resistance measurement at rear window defogger connector F-01.



- (1) Disconnect the connector, and measure at the wiring harness side.



- (2) Measure the resistance value between terminal 1 and earth.


OK: 2 ohm or less

Q: Is the check result normal?

YES : Go to Step 17.

NO : Go to Step 15.

STEP 15. Connector check: F-01 rear window defogger connector




Q: Is the check result normal?

YES : Go to Step 16.

NO : Repair the connector.

STEP 16. Check the wiring harness between F-01 rear window defogger connector terminal No.1 and earth.



- Check the rear window defogger earth line for open circuit.

Q: Is the check result normal?

YES : Check that the rear window defogger system works normally.

NO : Repair the wiring harness.

STEP 17. Check the rear window defogger.
Refer to GROUP 54A, Rear window defogger P.54A-96.

Q: Does the rear window defogger work normally?

YES : Replace the manual A/C control panel (A/C-ECU).

NO : Repair the rear window defogger.

Inspection Procedure 8: Defogger Timer Function does not Operate.

COMMENTS ON TROUBLE SYMPTOM

Turn ON the rear window defogger switch. If the defogger does not shut off after roughly 11 minutes then the defogger timer is malfunctioning.

TROUBLESHOOTING HINTS

- Malfunction of the manual A/C control panel (A/C-ECU)

DIAGNOSIS PROCEDURE

Check the performance of the rear window defogger timer operations.


- (1) Turn the ignition switch to the "ON" position.
- (2) Turn the rear window defogger switch to the "ON" position (operate for approx. 11 minutes)

Q: Does the rear window defogger timer function work normally?

YES : Intermittent malfunction

NO : Replace the manual A/C control panel (A/C-ECU).

Inspection Procedure 9: Malfunction of the A/C-ECU Power Supply System.



W3Z03E07AA
AC606580AB

COMMENTS ON TROUBLE SYMPTOM


The A/C-ECU power system may be defective if the A/C, defogger, and outside/inside air selection damper motor all do not operate normally.

TROUBLESHOOTING HINTS

- Damaged the wiring harness or connectors
- Malfunction of the manual A/C control panel (A/C-ECU)


DIAGNOSIS PROCEDURE

STEP 1. Voltage measurement at A/C-ECU connector C-06.



- (1) Disconnect the connector, and measure at the wiring harness side.

(2) Turn the ignition switch to the "ON" position.



(3) Measure the voltage between terminal 10 and body earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 4.

NO : Go to Step 2.

STEP 2. Connector check: C-06 A/C-ECU connector





Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair the connector.

STEP 3. Check the wiring harness between C-06 A/C-ECU connector terminal No.10 and the ignition switch (IG2).



NOTE: Prior to the wiring harness inspection, check junction block connectors C-203 and C-205, and repair if necessary.


- Check the A/C-ECU power supply line for open circuit.

Q: Is the check result normal?


YES : The trouble can be an intermittent malfunction (Refer to GROUP 00, How to Cope with Intermittent Malfunction [P.00-6](#)).

NO : Repair the wiring harness.

STEP 4. Resistance measurement at the C-06 A/C-ECU connector.



(1) Disconnect the connector, and measure at the wiring harness side.




(2) Measure the resistance between terminal 12 and body earth.

OK: 2 ohm or less

Q: Is the check result normal?

YES : Replace the manual A/C control panel (A/C-ECU).
NO : Go to Step 5.


STEP 5. Connector check: C-06 A/C-ECU connector



Q: Is the check result normal?

YES : Go to Step 6.
NO : Repair or replace the connector.

STEP 6. Check the wiring harness between C-06 A/C-ECU connector terminal No.12 and the earth.



- Check the A/C-ECU earth line for open circuit.


Q: Is the check result normal?

YES : Replace the manual A/C control panel (A/C-ECU).
NO : Repair the wiring harness.

CHECK AT ECU TERMINAL

M1552010300464

<C-06>



AC300861AB


Terminal No.	Check item	Checking requirement	Normal condition
1	Rear defogger switch	Defogger switch: ON	0 V
		Defogger switch: OFF	System voltage
2	Inside/outside air changeover damper motor (outside air)	When the damper is moved to the inside air recirculation position	0 V
		When the damper is moved to the outside air inside air intake position	System voltage
3	Inside/outside air changeover damper motor (inside air)	When the damper is moved to the inside air recirculation position	System voltage
		When the damper is moved to the outside air inside air intake position	0 V
4	Output to the engine-A/T-ECU (A/C1)	A/C stopped	0 V
		• A/C switch: ON • Blower switch: ON	System voltage
5	Output to the engine-A/T-ECU (A/C2)	When the A/C is under low load	System voltage
		When the A/C is under high load	0 V
6	Power supply to the A/C illumination	Lighting switch: ON	System voltage
7	-	-	-
8	Blower switch (lo)	blower switch: lo	System voltage
9	-	-	-
10	Power supply to the ignition switch (IG2)	Ignition switch: ON	System voltage
11	Earth to the A/C illumination	Always	0 V
12	Earth	Always	0 V
13	Air thermo sensor (outlet side)	Sensor probe temperature 25°C (1.5 kΩ)	2.2 V
14	Air thermo sensor (inlet side)	Sensor probe temperature 25°C (1.5 kΩ)	2.2 V
15	-	-	-
16	Earth to the air thermo sensor	Always	0 V

ON-VEHICLE SERVICE

SIGHT GLASS REFRIGERANT LEVEL
TEST

1. Start the engine.
2. Operate the air-conditioner, and then set the temperature to maximum cooling.
3. Hold the engine speed at 1,500 r/min.

M1552008400572



4. Check the refrigerant level (bubble state) through the sight glass.

CAUTION

Use the low-pressure service valve.

Items	State
Insufficient	Many bubbles are seen. If refrigerant is extremely low, it appears white.
Sufficient or excess refrigerant	No bubbles are seen.

NOTE:

- (1) If insufficient, replenish the refrigerant as follows.
 - a. Replenish until bubbles disappear from the sight glass.
 - b. After the bubbles disappear from the sight glass, replenish 100 g of refrigerant.


- (2) If excessive, replenish the refrigerant as follows.

- a. Drain the refrigerant until bubbles can be seen through the sight glass.
- b. Replenish until bubbles disappear from the sight glass.
- c. After the bubbles disappear from the sight glass, replenish 100 g of refrigerant.

MAGNETIC CLUTCH TEST

M1552008500386

1. Disconnect the magnetic clutch connector to the magnetic clutch.



2. Connect positive battery voltage directly to the connector for the magnetic clutch.
3. If the magnetic clutch is normal, there will be a "click." If the pulley and armature do not make contact ("click"), there is a malfunction.

COMPRESSOR DRIVE BELT
ADJUSTMENT



M1552001000498

- <2000-Non-Turbo> Refer to GROUP 11, On-vehicle Service – Drive Belt Tension Check [P.11A-7](#).
- <2400> Refer to GROUP 11E, On-vehicle Service – Drive Belt Tension Check [P.11E-7](#).

SIMPLE INSPECTION OF THE A/C
PRESSURE SENSOR

M1552014700088

1. Assemble a manifold gauge onto the high pressure service valve.
2. Turn ON the engine and then turn ON the A/C switch.




3. Check to see that the voltage between the A/C pressure sensor terminal No.2 and body earth reflects the specifications of the Figure.

NOTE: The allowance shall be defined as \pm five percents.

CHARGING

M1552001200340



1. With the handles turned back all the way (valve closed), install the adaptor valve to the low-pressure side of the gauge manifold.
2. Connect the charging hose (blue) to the adaptor valve.
3. Connect the quick joint (for low-pressure) to the charging hose (blue).

CAUTION

- Use tools that are suited to R134a.
- To install the quick joint, press section when connecting, run your hand along the hose while pressing to ensure that there are no bends in the hose.

4. Connect the quick joint (for low-pressure) to the low-pressure service valve.

NOTE: The low-pressure service valve should be connected to the flexible suction hose.

5. Close the high and low-pressure valves of the gauge manifold.

CAUTION


Be sure to connect the power plug of the vacuum pump to the vacuum pump adapter, and then connect the power plug of the adapter to a 100-V outlet.

6. Install the vacuum pump adaptor to the vacuum pump.
7. Connect the charging hose (yellow) to the R-134a connection port of the vacuum pump adaptor.
8. Tighten the adaptor valve handle (valve open).
9. Open the low-pressure valve of the gauge manifold.
10. Turn the power switch of the vacuum pump to the ON position.

NOTE: Even if the vacuum pump power switch is turned ON, the vacuum pump will not operate because of the power supply connection in step (6).

CAUTION

Do not operate the compressor for evacuation.




11. Turn the vacuum pump adaptor switch to the R134a side to start the vacuum pump.

12. Evacuate to a vacuum reading of 100 kPa or higher (takes approx. 10 minutes).

CAUTION

Do not operate the compressor in the vacuum condition; damage may occur.


13. Loosen the valve of the adapter valve fully (valve closed), and turn off the vacuum pump adapter switch. Then leave it for five minutes.
14. Check the system for proper sealing (negative pressure should not decrease).



15. Connect the service can valve to the service can with the handle loosened fully (valve closed).
16. Turn the handle of the adaptor valve back all the way (valve closed), remove it from the gauge manifold and install the service can.
17. Tighten the handle of the charging valve (valve closed) to puncture the service can.

CAUTION

If the service can is inverted, liquid refrigerant may be drawn into the compressor damaging it by liquid compression. Keep the service can upright to ensure that refrigerant is charged in gas state.



18. Turn the handle of the charging valve back (valve open) and tighten the handle of the adaptor valve (valve open) to charge the system with refrigerant.
19. If the refrigerant is not drawn in, turn the handle of the adaptor valve back all the way (valve closed).
20. Check for gas leaks using a leak detector. If a gas leak is detected, re-tighten the connections, and then repeat the charging procedure from evacuation in step (11).

CAUTION

The leak detector for R-134a should be used.

21. Start the engine.
22. Operate the A/C and set to the lowest temperature (MAX. COOL).
23. Fix the engine speed at 1,500 r/min.

CAUTION

If the service can is inverted, liquid refrigerant may be drawn into the compressor damaging it by liquid compression. Keep the service can upright to ensure that refrigerant is charged in gas state.


24. Tighten the handle of the adaptor valve (valve open) to charge the required volume of refrigerant.

25. After charging with refrigerant, turn the handle of the adaptor valve back all the way (valve closed).
26. Tighten the charging valve handle (valve closed). Remove the quick joint (for low-pressure) from the low-pressure service valve.
27. Remove the service can.


NOTE: If the service can is not emptied completely, keep the handles of the charging valve and adaptor valve closed for the next charging.

CORRECTING LOW REFRIGERANT LEVEL IN CASE THE SERVICE CAN IS USED

M1552014600081



1. Install the charge valve with the handle turned all the way back (valve open) to the service can.
2. Install the adaptor valve with the handle turned all the way back (valve close) to the charging valve.
3. Connect the charging hose (blue) to the adaptor valve.
4. Connect the charging hose (blue) to the quick joint (for low-pressure).
5. Tighten the handle of the charge valve (valve close), and pierce the service can.
6. Turn the handle of the adaptor valve to bleed the air.



7. Install the quick joint (for low-pressure) to the low-pressure service valve.

NOTE: The low-pressure service valve should be connected to the suction hose.

8. Start the engine.
9. Operate the A/C and set at the lowest temperature (MAX. COOL).
10. Fix the engine speed at 1,500 r/min.
11. Tighten the handle of the adaptor valve (valve open), and replenish refrigerant while checking the quantity through the sight glass.
12. After replenishing is completed, turn the handle of the adaptor valve all the way back (valve close), and remove the quick joint.

NOTE: When there is remainder of refrigerant in the service can, keep it for next use with the charge value and the valve of the adaptor valve being closed.

DISCHARGING SYSTEM

Use the refrigerant recovery unit to discharge refrigerant gas front the system.

NOTE: Refer to the Refrigerant Recovery and Recycling Unit instruction Manual for operation of the unit.

REFILLING OF OIL IN THE A/C SYSTEM

Too little oil will provide inadequate compressor lubrication and cause a compressor failure. Too much oil will increase discharge air temperature.

When a compressor is installed at the factory, it contains 120 mL <MSC90CA> or 140mL <MSC105CA> of compressor oil. While the A/C system is in operation, the oil is carried through the entire system by the refrigerant. Some of this oil will be trapped and retained in various parts of the system.

When the following system components are changed, it is necessary to add oil to the system to replace the oil being removed with the component.

Compressor oil: SUN PAG 56

Quantity

Evaporator: 60 mL

Condenser: 15 mL


Flexible suction hose: 10 mL

Receiver: 10 mL

PERFORMANCE TEST

M1552001400333

1. The vehicles to be tested should be in a place that is not in direct sunlight.



AC001388AB

2. Close the high and low-pressure valve of the gauge manifold.
3. Connect the charging hose (blue) to the low-pressure valve and connect the charging hose (red) to the high-pressure valve of the gauge manifold.

CAUTION

- To connect the quick joint, press section A firmly against the service valve until a click is heard.
- When connecting, run your hand along the hose while pressing to ensure that there are no bends in the hose.

4. Install the quick joint (for low-pressure) to the charging hose (blue), and connect the quick joint (for high-pressure) to the charging hose (red).


NOTE: The high-pressure service valve is on the A/C pipe and the low-pressure service valve is on the suction hose.

5. Connect the quick joint (for low-pressure) to the low-pressure service valve and connect the quick joint (for high-pressure) to the high-pressure service valve.
6. Start the engine.
7. Set the A/C controls as follows:
 - A/C switch: A/C – ON position

- Mode selection: FACE position
- Temperature control: MAXIMUM COOLING position
- Air selection: RECIRCULATION position
- Blower switch: "4" (Fast) position

8. Adjust engine speed to 1,500 r/min with A/C clutch engaged.

9. Engine should be warmed up with doors and windows opened.



10. Insert a thermometer in the centre air outlet and operate the engine for 20 minutes.

NOTE: If the clutch cycles, take the reading before the clutch disengages.

11. Note the discharge air temperature.

Performance Temperature Chart

Garage ambient temperature °C	20	25	30	35
Discharge air temperature °C	8.0 – 11.0	12.0 – 16.0	17.0 – 21.0	22.5 – 27.5
Compressor high pressure kPa	740 – 840	950 – 1,050	1,160 – 1,300	1,360 – 1,550
Compressor low pressure kPa	150 – 190	190 – 240	240 – 300	300 – 375

REFRIGERANT LEAK REPAIR PROCEDURE

M1552001500266

LOST CHARGE

If the system has lost all charge due to a leak:

1. Evacuate the system (Refer to [P.55A-53](#)).
2. Charge the system with approximately 550 g of refrigerant.
3. Check for leaks.
4. Discharge the system.
5. Repair leaks.

CAUTION

Replacement filter-drier units must be sealed while in storage. The drier used in these units will saturate water quickly upon exposure to the atmosphere. When installing a drier, have all tools and supplies ready for quick assembly to avoid keeping the system open any longer than necessary.

6. Replace receiver drier.
7. Evacuate and charge system.

LOW CHARGE

If the system has not lost all of its refrigerant charge; locate and repair all leaks. If it is necessary to increase the system pressure to find the leak (because of an especially low charge) add refrigerant. If it is possible to repair the leak without discharging the refrigerant system, use the procedure for correcting low refrigerant level.

HANDLING TUBING AND FITTINGS

Kinks in the refrigerant tubing or sharp bends in the refrigerant hose lines will greatly reduce the capacity of the entire system. High pressures are produced in the system when it is operating. Extreme care must be exercised to make sure that all connections are pressure tight. Dirt and moisture can enter the system when it is opened for repair or replacement of lines or components. The following precautions must be observed. The system must be completely discharged before opening any fitting or connection in the refrigeration system. Open fittings with caution even after the system has been discharged. If any pressure is noticed as a fitting is loosened, allow trapped pressure to bleed off very slowly.

Never attempt to rebend formed lines to fit. Use the correct line for the installation you are servicing. A good rule for the flexible hose lines is keep the radius of all bends at least 10 times the diameter of the hose.

Sharper bends will reduce the flow of refrigerant. The flexible hose lines should be routed so that they are at least 80 mm from the exhaust manifold. It is good practice to inspect all flexible hose lines at least once a year to make sure they are in good condition and properly routed.

On standard plumbing fittings with O-rings, these O-rings are not reusable.

COMPRESSOR NOISE CHECK

M1552008700261

You must first know the conditions when the noise occurs. These conditions are: weather, vehicle speed, in gear or neutral, engine temperature or any other special conditions.

Noises that develop during A/C operation can often be misleading. For example: what sounds like a failed front bearing or connecting rod, may be caused by loose bolts, nuts, mounting brackets, or a loose clutch assembly. Verify accessory drive belt tension (power steering or alternator).

Improper accessory drive belt tension can cause a misleading noise when the compressor is engaged and little or no noise when the compressor is disengaged.

Drive belts are speed-sensitive. That is, at different engine speeds, and depending upon belt tension, belts can develop unusual noises that are often mistaken for mechanical problems within the compressor.

ADJUSTMENT


1. Select a quiet area for testing. Duplicate conditions as much as possible. Switch the compressor on and off several times to clearly identify compressor noise. To duplicate high ambient conditions (high head pressure), restrict air flow through the condenser. Install a manifold gauge set to make sure discharge pressure doesn't exceed 2,070 kPa.
2. Tighten all compressor mounting bolts, clutch mounting bolt, and compressor drive belt. Check to assure clutch coil is tight (no rotation or wobble).
3. Check refrigerant hoses for rubbing or interference that can cause unusual noises.
4. Check refrigerant charge (Refer to P.55A-49).

5. Recheck compressor noise as in Step 1.
6. If noise still exists, loosen compressor mounting bolts and retighten. Repeat Step 1.
7. If noise continues, replace compressor and repeat Step 1.



POWER RELAY CHECK

M1552008800398

BLOWER RELAY CONTINUITY CHECK



Battery voltage	Tester connection	Specified condition
Not applied	4 – 5	Open circuit
• Connect terminal 1 to the positive battery terminal	4 – 5	Less than 2 ohms
• Connect terminal 3 to the negative battery terminal		

**A/C COMPRESSOR RELAY CONTINUITY
CHECK****FAN CONTROL RELAY CONTINUITY
CHECK**

Battery voltage	Tester connection	Specified condition
Not applied	1 – 4	Open circuit
<ul style="list-style-type: none"> • Connect terminal 3 to the positive battery terminal • Connect terminal 2 to the negative battery terminal 	1 – 4	Less than 2 ohms

Battery voltage	Tester connection	Specified condition
Not applied	2 – 4	Open circuit
<ul style="list-style-type: none"> • Connect terminal 1 to the positive battery terminal • Connect terminal 3 to the negative battery terminal 	2 – 4	Less than 2 ohms

IDLE-UP OPERATION CHECK

M1552001600531

1. Before inspection and adjustment, set vehicle in the following condition:
 - Engine coolant temperature: 80 – 90 °C
 - Lamps, electric cooling fan and accessories: Set to OFF
 - Transmission: Neutral ("N" or "P" for vehicles with A/T)
 - Steering wheel: Straightforward
2. Check whether or not the idle speed is the standard value.

Refer to GROUP 11A, On-vehicle Service – Basic Idle Speed Adjustment [P.11A-12](#).

<2000-Non-Turbo>

Refer to GROUP 11E, On-vehicle Service – Basic Idle Speed Adjustment [P.11E-13](#). <2400>

Standard value:

750 ± 50 r/min <2000-Non-Turbo>

700 ± 50 r/min <2400>

3. When the A/C is running after turning the A/C switch to ON, and the blower switch to the 3(MH) or 4(HI) position, check to be sure that the idle speed is at the standard value.


Standard value: 850 ± 50 r/min

NOTE: It is not necessary to make an adjustment, because the idling speed is automatically adjusted by the ISC system. If, however, a deviation from the standard value occurs for some reason, check the ISC system.

CLEAN AIR FILTER REPLACEMENT
PROCEDURE

M1552020100256

1. Remove the glove box. (Refer to GROUP 52A, Instrument Panel [P.52A-2](#).)





2. Remove the two screws as shown, and replace the clean air filter.
3. Install the glove box.

HEATER CONTROL ASSEMBLY AND A/C SWITCH

REMOVAL AND INSTALLATION

M1552002400314

**NOTE**

← : Clip position

AC106926AE

Removal steps

- >>B<< 1. Air mixing door control cable connection
- >>A<< 2. Mode selection damper cable connection


Removal steps (Continued)

- 3. Knob
- 4. Centre panel
- 5. Manual A/C control panel assembly

INSTALLATION SERVICE POINT

**>>A<< BLOWER VENT CHANGEOVER
DAMPER CABLE**


1. Set the heater control assembly's blower vent changeover knob to the DEF position.



2. Set the heater unit's blower vent changeover damper relay to the DEF position (turn the damper relay to the left until it stops) and install the cable.
3. Set the mode locator to the heater unit case and secure with a clip.

**>>B<< AIR MIX DOOR CABLE
CONNECTION**

1. Turn the heater control assembly's temperature adjustment knob all the way to the HOT side.




2. Set the heater unit's air mix door lever to the MAX HOT position (turn the damper lever as the left illustration) and attach the cable.
3. Set the mode locator to the heater unit case and secure with a clip.

INSPECTION

M1552014300682


BLOWER SWITCH CONTINUITY CHECK




Switch position	Tester connection	Specified condition
0 (OFF)	1 – 2, 2 – 4, 2 – 5, 2 – 6	Open circuit
1 (LO)	1 – 2	Less than 2 ohms
2 (ML)	2 – 4	Less than 2 ohms
3 (MH)	2 – 5	Less than 2 ohms
4 (HI)	2 – 6	Less than 2 ohms

DISASSEMBLY AND REASSEMBLY

M1552014200157

**Disassembly steps**

1. Switch panel
2. Rear window defogger switch
3. A/C switch
4. Inside/outside air selection switch
- <<A>> 5. Mode selection damper control cable
- <<A>> 6. Air mixing damper control cable
7. Blower switch assembly
8. Manual A/C control panel (A/C-ECU)

DISASSEMBLY SERVICE POINT**<<A>> BLOW VENT CHANGEOVER
DAMPER CABLE AND AIR MIX DAMPER
CABLE REMOVAL**

Insert a flat-tipped screwdriver into the clip through the inside of the control base and prize out the clip claw to disconnect the cables.

HEATER UNIT, HEATER CORE, BLOWER ASSEMBLY AND EVAPORATOR UNIT

REMOVAL AND INSTALLATION



M1552011600639

WARNING

When removing and installing the heater unit, do not let it bump against the SRS-ECU or the components.

Pre-removal and Post-installation Operation

- Refrigerant draining and Refilling (Refer to Charging P.55A-50 and Discharging P.55A-53).
- Engine coolant Draining and Refilling (Refer to GROUP 14, On vehicles service P.14-17).
- Instrument Panel Removal and Installation (Refer to GROUP 52A, Instrument Panel P.52A-2).
- Air cleaner cover and air flow sensor assembly Removal and Installation (Refer to GROUP 15, Air cleaner P.15-6 <2000-Non-Turbo> or P.15-8 <2400>).



Removal steps

1. Intake duct
2. Joint duct

Removal steps (Continued)

3. Blower assembly
4. Foot duct <front passenger's side>

AC200906AE

Removal steps (Continued)

<<A>>	5. Heater hose connection
<<A>>	6. Liquid pipe B connection
	7. Flexible suction hose connection
	8. O-ring
	9. Centre duct
	10. Foot duct <driver's side>
	11. Heater unit

REMOVAL SERVICE POINT**<<A>> FLEXIBLE SUCTION HOSE AND
LIQUID PIPE B DISCONNECTION**** CAUTION**


As the compressor oil and receiver are highly moisture absorbent, use a non-porous material to plug the hose and nipples.

To prevent the entry of dust or other foreign bodies, plug the dismantled hose and the nipples of the expansion valves.

HEATER UNIT

DISASSEMBLY AND REASSEMBLY

M1551005400194



AC106930AE

Disassembly steps


1. Evaporator cover
2. Heater core
3. Expansion valve
4. Joint
5. O-ring

Disassembly steps (Continued)

6. Evaporator
7. Air thermo sensor clip
8. Air thermo sensor
9. Heater case

BLOWER ASSEMBLY**DISASSEMBLY AND REASSEMBLY**

M1551005500168



AC301387AB

Disassembly steps

1. Outside/inside air selection damper control motor
2. Hose


Disassembly steps (Continued)

3. Blower motor
4. Clean air filter
5. Blower case

BLOWER MOTOR, RESISTOR AND OUTSIDE/INSIDE AIR SELECTION DAMPER CONTROL MOTOR

REMOVAL AND INSTALLATION

M1551002800665



AC200968AB

Outside/inside air selection damper control motor removal steps

- Glove box (Refer to GROUP 52A, Instrument Panel or Instrument Panel [P.52A-2.](#))
- 3. Outside/inside air selection damper control motor

Blower motor removal

1. Blower motor


Resistor removal steps

- Glove box (Refer to GROUP 52A, Instrument Panel or Instrument Panel [P.52A-2.](#))
- 2. Resistor

INSPECTION

REGISTER CHECK

M1551006300703




Use an ohmmeter to measure the resistance between the terminals. Check that the measured value is at the standard value.

Standard value:

Measurement terminal	Standard value (Ω)
Between terminals 2 and 4 (LO)	2.54
Between terminals 1 and 2 (ML)	1.24
Between terminals 2 and 3 (MH)	0.6


BLOWER FAN AND MOTOR CHECK



When battery voltage is applied between the terminals, check that the motor operates. Also, check that there is no abnormal noise.

OUTSIDE/INSIDE AIR SELECTION DAMPER CONTROL MOTOR CHECK

CAUTION



Cut off the battery voltage when the damper is in the inside/outside air position.

Lever position	Battery connection	Lever operation
At the inside position	<ul style="list-style-type: none"> Connect terminal 7 to the positive battery terminal Connect terminal 4 to the negative battery terminal 	The lever moves from the inside position to the outside position
At the outside position	<ul style="list-style-type: none"> Connect terminal 7 to the positive battery terminal Connect terminal 6 to the negative battery terminal 	The lever moves from the outside position to the inside position


EVAPORATOR ASSEMBLY

REMOVAL AND INSTALLATION

M1552003600708

Pre-removal and Post-installation Operation

- Refrigerant draining and Refilling (Refer to Charging P.55A-50 and Discharging P.55A-53).
- Air cleaner cover and air flow sensor assembly Removal and Installation (Refer to GROUP 15, Air cleaner P.15-6 <2000-Non-Turbo> or P.15-8 <2400>).



Removal steps

<<A>> 1. Flexible suction hose connection
<<A>> 2. Liquid pipe B connection
<<A>> 3. Expansion valve cover
<<A>> 4. Expansion valve
<<A>> 5. Joint
<<A>> 6. O-ring
• Glove box (Refer to GROUP 52A, Instrument Panel P.52A-2).

Removal steps (Continued)

7. Joint duct
8. Foot duct <front passenger's side>
9. Front floor console lower side cover
10. Evaporator cover
11. Air thermo sensor clip
12. Air thermo sensor
13. Evaporator

REMOVAL SERVICE POINT

<<A>> FLEXIBLE SUCTION HOSE AND
LIQUID PIPE B DISCONNECTION**CAUTION**


As the compressor oil and receiver are highly moisture absorbent, use a non-porous material to plug the hose and nipples.

To prevent the entry of dust or other foreign bodies, plug the dismantled hose and the nipples of the expansion valves.

INSPECTION

AIR THERMO SENSOR INSPECTION

M1552014300693



INLET SIDE

Measure the resistance between connector terminals 1 and 3 under at least two different temperatures. The resistance values should generally match those in the graph.

NOTE: The temperature at the check should not exceed the range in the graph.

OUTLET SIDE

Measure the resistance between connector terminals 4 and 5 under at least two different temperatures. The resistance values should generally match those in the graph.

NOTE: The temperature at the check should not exceed the range in the graph.

COMPRESSOR ASSEMBLY AND TENSION PULLEY

REMOVAL AND INSTALLATION


M1552004100438

Pre-removal Operation

- Refrigerant Discharging (Refer to P.55A-53).

Post-installation Operation

- Drive Belt Tension Adjustment (Refer to GROUP 11, On-vehicles Service – Drive Belt Tension Check P.11A-7 <2000-Non-Turbo> or GROUP 11E, On-vehicles Service – Drive Belt Tension Check P.11E-7 <2400>).
- Refrigerant Charging (Refer to P.55A-50).



AC309480AE

Removal steps

<<A>> 1. Flexible suction hose connection
<<A>> 2. Flexible discharge hose connection
<<A>> 3. O-ring

Removal steps (Continued)

<> 4. Drive belt
<<C>> 5. A/C compressor
>>A<< 6. A/C compressor bracket

REMOVAL SERVICE POINTS

<<A>> FLEXIBLE SUCTION HOSE AND FLEXIBLE DISCHARGE HOSE DISCONNECTION


CAUTION

As the compressor oil and receiver are highly moisture absorbent, use a non-porous material to plug the hose and nipples.

To prevent the entry of dust or other foreign bodies, plug the dismantled hoses and compressor nipples.

<> DRIVE BELT REMOVAL


The following operations will be needed due to the introduction of the serpentine drive system with the drive belt auto-tensioner.



1. Securely insert the spindle handle or ratchet handle with a 12.7 mm insertion angle into the jig hole of the auto-tensioner.
2. Rotate the auto-tensioner anti-clockwise and align hole A with hole B.

CAUTION

To reuse the drive belt, draw an arrow indicating the rotating direction (clockwise) on the back of the belt using chalk, etc.



3. Insert an L-shaped hexagon wrench, etc. into the hole to fix and then remove the drive belt.

<<C>> A/C COMPRESSOR REMOVAL

Take care not to spill any compressor oil when removing the compressor.

INSTALLATION SERVICE POINT

>>A<< A/C COMPRESSOR INSTALLATION

If a new compressor is installed, first adjust the amount of oil according to the procedures described below, and then install the compressor.

1. Measure the amount (X mL) of oil within the removed compressor.
2. Drain (from the new compressor) the amount of oil calculated according to the following formula, and then install the new compressor.

New compressor oil amount = 120 mL<MSC90CA> or 140 mL<MSC105CA>

$$120 \text{ mL} - X \text{ mL} = Y \text{ mL} \text{ <MSC90CA>} \text{ or } 140 \text{ mL} - X \text{ mL} = Y \text{ mL} \text{ <MSC105CA>}$$

NOTE: Y mL indicates the amount of oil in the refrigerant line, the condenser, the evaporator, etc.

NOTE: When replacing the following parts at the same times as the compressor, subtract the rated oil amount of the each part from Y mL and discharge from the new compressor.


Quantity:

- Evaporator: 60 mL
- Condenser: 15 mL
- Suction hose: 10 mL
- Receiver: 10 mL

INSPECTION

M1552014300701


COMPRESSOR MAGNETIC CLUTCH OPERATION CHECK



Connect the compressor connector terminal to the battery positive (+) terminal and earth the battery's negative (-) terminal to the compressor unit. At that time, the magnetic clutch should make a definite operating sound.

DISASSEMBLY AND REASSEMBLY

M1552004600671



AC100630AB

**A/C refrigerant temperature
switch disassembly steps**

1. Snap ring
2. A/C refrigerant temperature switch
3. O-ring

**Magnetic clutch disassembly
steps**


>>D<< • Air gap adjustment
<<A>> >>C<< 4. Self-locking nut

**Magnetic clutch disassembly
steps (Continued)**

>>B<<	5. Armature
	6. Snap ring
	7. Rotor
>>A<<	8. Snap ring
	9. Field core
	10. Shim
	11. A/C compressor

DISASSEMBLY SERVICE POINT

<<A>> SELF-LOCKING NUT REMOVAL




Use the special tools to remove the self-locking nut.

- Special spanner (MB991367)
- Pin (MB991386)


REASSEMBLY SERVICE POINTS

>>A<< FIELD CORE ATTACHMENT




Line up the pin hole on the compressor unit with the field core projection and attach.

>>B<< SNAP RING INSTALLATION




Using snap ring pliers, fit the snap ring so that the snap ring's tapered part is on the outside.

>>C<< SELF-LOCKING NUT
INSTALLATION

Use the special tools to install the self-locking nut.

- Special spanner (MB991367)
- Pin (MB991386)

>>D<< AIR GAP ADJUSTMENT



Check that the clutch air gap is inside the standard value. If outside the standard value, use a shim to adjust the gap.


Standard value: 0.3 – 0.5 mm

INSPECTION


M1552014301265

A/C REFRIGERANT TEMPERATURE
SWITCH**CAUTION**

Do not heat more than necessary.



1. Dip the metal part of the A/C refrigerant temperature switch into engine oil and increase the oil temperature using a gas burner or similar.



2. When the oil temperature reaches the standard value, check that voltage is supplied between the terminals.

Standard value:

Item	Temperature
Less than 2 ohms	Slightly below 150°C
No continuity	150°C or more

NOTE: When the oil temperature is 150°C or more and there is no continuity, the resistance will not be 2 ohms or lower until the oil temperature reduces to 120°C or less.


CONDENSER AND CONDENSER FAN MOTOR

REMOVAL AND INSTALLATION


M1552006700533

Pre-removal and Post-installation Operation

- Refrigerant draining and Refilling (Refer to Charging P.55A-50 and Discharging P.55A-53).
- Air cleaner cover and air flow sensor assembly Removal and Installation (Refer to GROUP 15, Air cleaner P.15-6 <2000-Non-Turbo> or P.15-8 <2400>).



AC300948AI



AC309387AD

<<A>>

Condenser removal steps

- <<A>> 1. Liquid pipe A connection
- <<A>> 2. Flexible discharge hose connection
- <<A>> 3. O-ring
- >>A<< 4. Condenser assembly
- >>A<< 5. Receiver
- >>A<< 6. Clamp
- >>A<< 7. O-ring
- >>A<< 8. Condenser

Fan shroud assembly removal steps

- 9. Fan shroud assembly
- 10. Fan
- 11. Fan motor
- 12. Heat protector
- 13. Fan shroud
- 14. Air guide panel

Air guide panel removal steps

- Front bumper (Refer to 51, Front bumper P.51-3).

REMOVAL SERVICE POINT

<<A>> LIQUID PIPE A/FLEXIBLE SUCTION HOSE DISCONNECTION

CAUTION

As the compressor oil and receiver are highly moisture absorbent, use a non-porous material to plug the hose and nipples.

To prevent the entry of dust or other foreign bodies, plug the dismantled hose and condenser assembly nipples.

INSTALLATION SERVICE POINT

>>A<< CONDENSER ASSEMBLY INSTALLATION

When replacing the condenser, refill it with a specified amount of compressor oil and install it. (to the vehicle).



Compressor oil: SUN PAG 56

Quantity: 15 mL

INSPECTION

M1552014301760

CONDENSER FAN MOTOR CHECK



Check to be sure that the condenser fan motor operates when battery voltage is applied to terminal 2 and terminal 1 earthed.



REFRIGERANT LINE

REMOVAL AND INSTALLATION

M1552006400770

Pre-removal and Post-installation Operation

- Refrigerant Draining and Refilling (Refer to Charging and Discharging P.55A-50).
- Air cleaner cover and air flow sensor assembly Removal and Installation (Refer to GROUP 15, Air cleaner P.15-6 <2000-Non-Turbo> or P.15-8 <2400>).
- Radiator Grille Removal and Installation (Refer to GROUP 51, Radiator Grille P.51-10).



<<A>> 1. A/C pressure sensor

<<A>> 2. Flexible discharge hose

<<A>> 3. Liquid pipe A

<<A>> >>A<< 4. Flexible suction hose

Removal steps

<<A>>

Removal steps (Continued)

5. Liquid pipe B

6. Evaporator cover

7. O-ring

AC309406AC

REMOVAL SERVICE POINT**<<A>> A/C PRESSURE SENSOR/HOSE/PIPE DISCONNECTION****⚠ CAUTION**

As the compressor oil and receiver are highly moisture absorbent, use a non-porous material to plug the hose and nipples.

To prevent the entry of other foreign bodies, plug the condenser, compressor, and expansion valve nipples.

INSTALLATION SERVICE POINT**>>A<< FLEXIBLE SUCTION HOSE
INSTALLATION**

When replacing the suction hose, refill them with a specified amount of compressor oil, and then install them.


Compressor oil: SUN PAG 56

Quantity: Suction hose: 10 cm³

VENTILATORS

REMOVAL AND INSTALLATION

M1553001600590



AC106927AB

**Defroster nozzle and distribution
duct removal steps**

- Instrument panel (Refer to GROUP 52A, Instrument Panel [P.52A-2.](#))
- 1. Side defroster duct
- 2. Defroster nozzle
- 3. Distribution duct

**Foot duct and rear heater duct
removal steps**


- Under cover (Refer to GROUP 52A, Instrument Panel [P.52A-2.](#))
- 4. Foot duct <driver's side>
- 5. Rear heater duct A <driver's side>
- 6. Rear heater duct B upper side <driver's side>

**Foot duct and rear heater duct
removal steps (Continued)**

- Glove box (Refer to GROUP 52A, Instrument Panel [P.52A-2](#).)
- 7. Foot duct <front passenger's side>
- 10. Rear heater duct A <front passenger's side>
- Floor carpet
- Front seat assembly (Refer to GROUP 52A, Front seat assembly [P.52A-21](#)).

**Foot duct and rear heater duct
removal steps (Continued)**

- Front floor console (Refer to GROUP 52A, Floor console [P.52A-8](#)).
- 11. Rear heater duct B lower side <driver's side>
- 12. Rear heater duct B <front passenger's side>



AC101905AG

**Rear ventilation duct removal
steps**

- Rear bumper assembly (Refer to GROUP 51, Rear bumper [P.51-6](#)).
- 13. Rear ventilation duct