

GROUP 17

ENGINE AND EMISSION CONTROL

CONTENTS

ENGINE CONTROL	17-3	DIAGNOSTIC FUNCTION	17-12
GENERAL INFORMATION	17-3	DIAGNOSTIC TROUBLE CODE CHART ..	17-15
ENGINE CONTROL SYSTEM DIAGNOSIS	17-4	DIAGNOSTIC TROUBLE CODE	
INTRODUCTION	17-4	PROCEDURES	17-16
TROUBLESHOOTING STRATEGY	17-4	SYMPTOM CHART	17-38
SYMPTOM CHART	17-4	SYMPTOM PROCEDURES	17-39
SYMPTOM PROCEDURES	17-4	DATA LIST REFERENCE TABLE	17-58
SPECIAL TOOL	17-8	ECM TERMINAL VOLTAGE REFERENCE	
ACCELERATOR PEDAL	17-9	CHART FOR CRUISE CONTROL SYSTEM	
REMOVAL AND INSTALLATION	17-9	OPERATION	17-59
CRUISE CONTROL*	17-11	SPECIAL TOOLS	17-60
GENERAL INFORMATION	17-11	ON-VEHICLE SERVICE	17-62
CRUISE CONTROL SYSTEM		CRUISE CONTROL SYSTEM	
DIAGNOSIS	17-12	OPERATION CHECK	17-62
INTRODUCTION TO CRUISE CONTROL		CRUISE CONTROL SYSTEM	
SYSTEM DIAGNOSIS	17-12	COMPONENT CHECK	17-64
DIAGNOSTIC TROUBLESHOOTING		CRUISE CONTROL SWITCH*	17-65
STRATEGY	17-12	REMOVAL AND INSTALLATION	17-65

Continued on next page

WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

⚠ WARNING

- *Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver and passenger (from rendering the SRS inoperative).*
- *Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.*
- *MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B - Supplemental Restraint System (SRS) before beginning any service or maintenance of any component of the SRS or any SRS-related component.*

NOTE

The SRS includes the following components: SRS air bag control unit, SRS warning light, front impact sensors, air bag module, side-airbag module, curtain air bag module, side impact sensors, seat belt pre-tensioners, clock spring, and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by an asterisk (*).

EMISSION CONTROL MFI	17-66	ENGINE COOLANT TEMPERATURE SENSOR CHECK	17-79
GENERAL INFORMATION	17-66	INTAKE AIR TEMPERATURE SENSOR CHECK	17-79
SERVICE SPECIFICATIONS	17-66	FUEL TANK DIFFERENTIAL PRESSURE SENSOR CHECK	17-80
DIAGNOSIS	17-66	EVAPORATIVE EMISSION VENTILATION SOLENOID CHECK	17-80
SPECIAL TOOLS	17-67	EXHAUST GAS RECIRCULATION (EGR) SYSTEM	17-80
VACUUM HOSES	17-68	GENERAL INFORMATION (EXHAUST GAS RECIRCULATION SYSTEM)	17-80
VACUUM HOSE ROUTING	17-68	COMPONENT LOCATION	17-81
VACUUM CIRCUIT DIAGRAM	17-70	EGR VALVE (STEPPER MOTOR) CHECK	17-81
VACUUM HOSE INSTALLATION	17-71	MASS AIRFLOW SENSOR CHECK	17-83
VACUUM HOSE CHECK	17-71	ENGINE COOLANT TEMPERATURE SENSOR CHECK	17-83
POSITIVE CRANKCASE VENTILATION SYSTEM	17-72	CRANKSHAFT POSITION SENSOR CHECK	17-83
GENERAL INFORMATION (POSITIVE CRANKCASE VENTILATION SYSTEM) . .	17-72	REMOVAL AND INSTALLATION <2.4L ENGINE>	17-84
COMPONENT LOCATION	17-73	REMOVAL AND INSTALLATION <3.0L ENGINE>	17-86
POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM CHECK	17-74	EVAPORATIVE EMISSION CANISTER AND FUEL TANK PRESSURE RELIEF VALVE	17-87
POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM CHECK	17-74	REMOVAL AND INSTALLATION	17-87
EVAPORATIVE EMISSION CONTROL SYSTEM	17-75	INSPECTION	17-88
GENERAL INFORMATION (EVAPORATIVE EMISSION SYSTEM) . .	17-75	CATALYTIC CONVERTER	17-89
COMPONENT LOCATION	17-76	REMOVAL AND INSTALLATION	17-89
PURGE CONTROL SYSTEM CHECK (PURGE FLOW CHECK)	17-77		
EVAPORATIVE EMISSION PURGE SOLENOID CHECK	17-78		
MASS AIRFLOW SENSOR CHECK	17-79		
BAROMETRIC PRESSURE SENSOR CHECK	17-79		

ENGINE CONTROL

GENERAL INFORMATION


For the accelerator system, the electronic throttle valve control system, disposing of the accelerator cable, is adopted.

This system determines the amount of pressure applied to the accelerator pedal using the built-in accelerator pedal position sensor of the accelerator pedal assembly to control the throttle valve angle electrically.

M1171000101311

- A resin arm is employed to reduce weight.
- The aluminum pedal pad has been adopted to enhance the sporty image <some models>.

CONSTRUCTION DIAGRAM



AC901627 AB

ENGINE CONTROL SYSTEM DIAGNOSIS**INTRODUCTION**

If there is a malfunction in the engine control system, the accelerator pedal or throttle body may be faulty.

M1171002000340

TROUBLESHOOTING STRATEGY

M1171002100370

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find an engine control system fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify that the malfunction is eliminated.

SYMPTOM CHART

M1171002200418

Symptom	Inspection procedure	Reference page
Throttle valve will not fully open or close	1	P.17-4
Accelerator pedal operation not smooth (over acceleration)	2	P.17-6

SYMPTOM PROCEDURES**Inspection Procedure 1: Throttle Valve will not Fully Open or Close****COMMENT**

The throttle body or accelerator pedal position sensor (APP sensor) is suspected.

TROUBLESHOOTING HINTS (The most likely causes for this case:)

- Malfunction of the throttle body.
- Malfunction of the APP sensor.
- Malfunction of the engine control module (ECM).

DIAGNOSIS**Required Special Tools:**

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
- MB991824: Vehicle Communication Interface (V.C.I.)
- MB991827: M.U.T.-III USB Cable
- MB991910: M.U.T.-III Main Harness A

STEP 1. Using scan tool MB991958, read the MFI system diagnostic trouble code.**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Ensure that the ignition switch is at the "LOCK" (OFF) position.
- (2) Start up the personal computer.
- (3) Connect special tool MB991827 to special tool MB991824 and the personal computer.
- (4) Connect special tool MB991910 to special tool MB991824.
- (5) Connect special tool MB991910 to the data link connector.
- (6) Turn the power switch of special tool MB991824 to the "ON" position.

NOTE: When special tool MB991824 is energized, special tool MB991824 indicator light will be illuminated in a green color.

- (7) Start the M.U.T.-III system on the personal computer.
- (8) Turn the ignition switch to the "ON" position.
- (9) Check for MFI system diagnostic trouble code (Refer to GROUP 13A, Diagnostic Function – How to Read and Erase Diagnostic Trouble Codes [P.13A-11](#) <2.4L Engine> or (Refer to GROUP 13B, Diagnostic Function – How to Read and Erase Diagnostic Trouble Codes [P.13B-11](#)) <3.0L Engine>.
- (10) Turn the ignition switch to the "LOCK" (OFF) position, and then remove scan tool MB991958 in the reverse order of installation.

Q: Is any DTC set?


YES : Repair MFI system (Refer to GROUP 13A, Diagnostic Trouble Code Chart [P.13A-49](#) <2.4L Engine> or (Refer to GROUP 13B, Diagnostic Trouble Code Chart [P.13B-50](#)) <3.0L Engine>. Then go to Step 2.

NO : Go to Step 2.

STEP 2. Retest the system.**Q: Does the throttle valve fully open and close?**

YES : The procedure is complete.

NO : Return to Step 1.



Inspection Procedure 2: Accelerator Pedal Operation not Smooth (Over Acceleration)

COMMENT

The accelerator pedal, its installation condition or the APP sensor is suspected.

TROUBLESHOOTING HINTS (The most likely causes for this case:)

- Malfunction of the accelerator pedal.
- Incorrectly installed accelerator pedal.
- Malfunction of the APP sensor.

DIAGNOSIS**Required Special Tools:**

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A

STEP 1. Check if the accelerator pedal is installed correctly.**Q: Is the accelerator pedal installed correctly?**

YES : Go to Step 2.

NO : Remove and reinstall the accelerator pedal (Refer to [P.17-9](#)). Then go to Step 3.

STEP 2. Using scan tool MB991958, read the MFI system diagnostic trouble code.**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Ensure that the ignition switch is at the "LOCK" (OFF) position.
- (2) Start up the personal computer.
- (3) Connect special tool MB991827 to special tool MB991824 and the personal computer.
- (4) Connect special tool MB991910 to special tool MB991824.
- (5) Connect special tool MB991910 to the data link connector.
- (6) Turn the power switch of special tool MB991824 to the "ON" position.

NOTE: When special tool MB991824 is energized, special tool MB991824 indicator light will be illuminated in a green color.

- (7) Start the M.U.T.-III system on the personal computer.
- (8) Turn the ignition switch to the "ON" position.
- (9) Check for MFI system diagnostic trouble code (Refer to GROUP 13A, Diagnostic Function – How to Read and Erase Diagnostic Trouble Codes [P.13A-11](#) <2.4L Engine> or (Refer to GROUP 13B, Diagnostic Function – How to Read and Erase Diagnostic Trouble Codes [P.13B-11](#)) <3.0L Engine>.
- (10) Turn the ignition switch to the "LOCK" (OFF) position, and then remove scan tool MB991958 in the reverse order of installation.

Q: Is any DTC set?


YES : Repair MFI system (Refer to GROUP 13A, Diagnostic Trouble Code Chart [P.13A-49](#) <2.4L Engine> or (Refer to GROUP 13B, Diagnostic Trouble Code Chart [P.13B-50](#)) <3.0L Engine>. Then go to Step 3.

NO : Go to Step 3.

STEP 3. Retest the system.**Q: Does the accelerator pedal work normally?**







YES : The procedure is complete.

NO : Return to Step 1.



SPECIAL TOOL

M1171000600164

Tool	Tool number and name	Supersession	Application
a  MB991824	MB991958 a. MB991824 b. MB991827 c. MB991910 d. MB991911 e. MB991914 f. MB991825 g. MB991826	MB991824-KIT <i>NOTE: g: MB991826 M.U.T.-III trigger harness is not necessary when pushing V.C.I. ENTER key.</i>	CAUTION For vehicles with CAN communication, use M.U.T.-III main harness A to send simulated vehicle speed. If you connect M.U.T.-III main harness B or C instead, the CAN communication does not function correctly. Checking diagnostic trouble codes
b  MB991827	M.U.T.-III sub assembly		
c  MB991910	a. Vehicle communication interface (V.C.I.) b. M.U.T.-III USB cable c. M.U.T.-III main harness A (Vehicles with CAN communication system)		
d  MB991911	d. M.U.T.-III main harness B (Vehicles without CAN communication system)		
e  MB991914	e. M.U.T.-III main harness C (for Chrysler models only)		
f  MB991825	f. M.U.T.-III measurement adapter g. M.U.T.-III trigger harness		
g  MB991826 MB991958			


ACCELERATOR PEDAL

REMOVAL AND INSTALLATION

M1171003001249

Pre-removal and Post-installation Operation

Bottom Cover Assembly (driver's seat) Removal and Installation (Refer to GROUP 52A, Instrument Panel Assembly [P.52A-2](#)).


<Vehicles without aluminum pedal pad>

AC610167AD

Removal steps

1. Accelerator pedal position sensor connector
2. Accelerator pedal assembly

<Vehicles with aluminum pedal pad>



AC806114AB

Removal steps

1. Accelerator pedal pad

Removal steps (Continued)

2. Accelerator pedal position sensor connector
3. Accelerator pedal assembly

CRUISE CONTROL






GENERAL INFORMATION

By using the cruise control system, the driver can drive at preferred speeds in a range of approximately 40 to 160 km/h (25 to 100 mph) without depressing the accelerator pedal.

M1172000101660

For this cruise control system, in conjunction with the electronic throttle valve control system, the engine control module (ECM) electronically controls the throttle valve.

CONSTRUCTION DIAGRAM



AC03167 AB

CRUISE CONTROL SYSTEM DIAGNOSIS

INTRODUCTION TO CRUISE CONTROL SYSTEM DIAGNOSIS

M1172003300370

The cruise control system allows driving without stepping on the accelerator pedal by setting a random speed between 40 km/h (25 mph) and 160 km/h (100 mph). Malfunctions in this system can be investigated by the following methods.

Cruise control system diagnostic trouble codes

The cruise control system consists of the engine control module (ECM), control switches and sensors. The switches and sensors monitor the state of the vehicle. The ECM controls the throttle valve opening angle in the throttle body in accordance with the input signals from the switches and sensors. If the ECM detects a malfunction on any of those components, the ECM estimates where the problem may be occurring, and will set a diagnostic trouble code. Diagnostic trouble codes cover the cruise control switch, stoplight switch and ECM.

DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1172002000860

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will check most of the possible causes of an cruise control system malfunction.

1. Gather information from the customer.
2. Verify that the condition described by the customer exists.
3. Check the vehicle for any cruise control system DTC. (Refer to [P.17-12](#), Diagnostic Function – How to Read Diagnostic Trouble Codes).
4. If you can verify the condition but no cruise control system DTCs are set, the malfunction may be intermittent. (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions [P.00-15](#)).


5. If you can verify the condition but there are no cruise control system DTCs, find the fault. (Refer to [P.17-38](#), Symptom Chart).
6. If there is an cruise control system DTC, record the number of the code, then erase the code. (Refer to [P.17-12](#), Diagnostic Function – How to Erase Diagnostic Trouble Codes).
7. Re-create the cruise control system DTC set conditions to see if the same cruise control system DTC will set again. (Refer to [P.17-12](#), Diagnostic Function – How to Read Diagnostic Trouble Codes).
 - If the same cruise control system DTC sets again, perform the diagnostic procedures for the set code. (Refer to [P.17-15](#), Diagnostic Trouble Code Chart).


DIAGNOSTIC FUNCTION

M1172004900483

HOW TO READ DIAGNOSTIC TROUBLE CODES

1. Turn the ignition switch to the "ON" position while press the "COAST/SET" switch. Then, within one second, release the "COAST/SET" switch and press the "ACC/RES" switch.





2. Read a DTC by observing the flash display pattern of the "CRUISE" indicator light in the combination meter.

DIAGNOSTIC RESULT DISPLAY METHOD WHEN USING THE "CRUISE" INDICATOR LIGHT

When the diagnostic trouble code number 23 is output	When no diagnostic trouble code is output
<p>12V</p> <p>0V</p> <p>Pause time: 3 s</p> <p>Ten digit</p> <p>Digit division: 2 s</p> <p>First digit</p> <p>AC703915AB</p>	<p>12V</p> <p>0V</p> <p>0.25 s</p> <p>Continuous ON and OFF signals at intervals of 0.25 s</p> <p>AC703916AB</p>

NOTE: Other on-board diagnostic items are also output as voltage waveforms corresponding to diagnostic trouble code numbers.


HOW TO ERASE DIAGNOSTIC TROUBLE CODES

Disconnect the negative (-) battery cable.

HOW TO CONNECT THE SCAN TOOL (M.U.T.-III).

Required Special Tools:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
- MB991824: Vehicle Communication Interface (V.C.I.)
- MB991827: M.U.T.-III USB Cable
- MB991910: M.U.T.-III Main Harness A


⚠ CAUTION

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

1. Start up the personal computer.
2. Connect special tool MB991827 to special tool MB991824 and the personal computer.
3. Connect special tool MB991910 to special tool MB991824.
4. Connect special tool MB991910 to the data link connector.
5. Turn the power switch of special tool MB991824 to the "ON" position.

NOTE: When special tool MB991824 is energized, special tool MB991824 indicator light will be illuminated in green color.

6. Start the M.U.T.-III system on the personal computer.

NOTE: Disconnecting scan tool MB991958 is the reverse of the connecting sequence, making sure that the ignition switch is at the "LOCK" (OFF) position.

HOW TO READ DATA LIST

Required Special Tools:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A

1. Connect scan tool MB991958 to the data link connector.
2. Turn the ignition switch to the "ON" position.
3. Select "System Select" from the start-up screen.
4. Select "From 2006 MY" of "Model Year." When the "Vehicle Information" is displayed, check the contents.
5. Select "AUTO CRUISE" from "System List", and press the "OK" button.

NOTE: When the "Loading Option Setup" list is displayed, check the applicable item.

6. Select the "MITSUBISHI."
7. Select the "Data List."

NOTE: When the "Data List Reference Table" button is selected, the service data reference table is displayed, and the normal values can be checked.

8. Choose an appropriate item.

HOW TO DIAGNOSE THE CAN BUS LINE

Required Special Tools:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
- MB991824: V.C.I.
- MB991827: M.U.T.-III USB Cable
- MB991910: M.U.T.-III Main Harness A

1. Connect scan tool MB991958 to the data link connector.
2. Turn the ignition switch to the "ON" position.
3. Select the "CAN Bus Diagnosis" from the start-up screen.
4. When the vehicle information is displayed, confirm that it matches the vehicle whose CAN bus lines will be diagnosed.
 - If they match, go to step 8.
 - If not, go to step 5.
5. Select the "view vehicle information" button.
6. Enter the vehicle information and select the "OK" button.
7. When the vehicle information is displayed, confirm again that it matches the vehicle which whose CAN bus lines will be diagnosed.
 - If they match, go to step 8.
 - If not, go to step 5.
8. Press the "OK" button.
9. When the optional equipment screen is displayed, choose the one which the vehicle is fitted with, and then select the "OK" button.

DIAGNOSTIC TROUBLE CODE CHART

M1172002200950


Check according to the inspection chart that is appropriate for the diagnostic trouble code.

Diagnostic trouble code number	Inspection item	Reference page
15	Cruise control switch system	P.17-16
22	Stoplight switch system	P.17-29
23	ECM and its related components	P.17-36



DIAGNOSTIC TROUBLE CODE PROCEDURES


DTC 15: Cruise Control Switch System.

Cruise Control Switch Circuit



AC709996 AB





CIRCUIT OPERATION

This circuit judges the signals of each switch ("ON/OFF", "CANCEL", "COAST/SET" and "ACC/RES") of the cruise control switch. The ECM detects the state of the cruise control switch by sensing the voltages shown below.

- When all switches are released: 4.7 – 5.0 volts
- When the "ON/OFF" switch is pressed: 0 – 0.5 volt
- When the "CANCEL" switch is pressed: 1.0 – 1.8 volts
- When the "COAST/SET" switch is pressed: 2.3 – 3.0 volts
- When the "ACC/RES" switch is pressed: 3.5 – 4.2 volts

DTC SET CONDITIONS

Check Condition

- The "CRUISE" indicator light illuminates.

Judgment Criteria

- This DTC is set when the ECM terminal voltage is different from the standard value.
- Or, this DTC is set when the "COAST/SET" switch or "ACC/RES" switch is stuck to ON.


TROUBLESHOOTING HINTS (THE MOST LIKELY CAUSES FOR THIS CASE:)

- Damaged harness or connector.
- Malfunction of the cruise control switch.
- Malfunction of the clock spring.
- Malfunction of the ECM.

DIAGNOSTIC PROCEDURE

Required Special Tools:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A
- MB991223: Harness Set
- MB992006: Extra Fine Probe
- MB992110: Power Plant ECU Check Harness



STEP 1. Using scan tool MB991958, check the data list item 86: Main switch, item 92: Set switch, item 91: Resume switch and item 75: Cancel switch.

⚠ CAUTION

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#)).
 - Item 75: Cancel switch.
 - When "CANCEL" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "CANCEL" switch is released, the display on scan tool MB991958 should be "OFF".
 - Item 86: Main switch.
 - When "ON/OFF" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "ON/OFF" switch is pressed again, the display on scan tool MB991958 should be "OFF".
 - Item 91: Resume switch.
 - When "ACC/RES" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "ACC/RES" switch is released, the display on scan tool MB991958 should be "OFF".
 - Item 92: Set switch.
 - When "COAST/SET" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "COAST/SET" switch is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 25.

NO : Go to Step 2.


STEP 2. Measure the power supply voltage at cruise control switch connector C-201 by backprobing.

- (1) Remove the cruise control switch from the steering wheel with the cruise control switch connector connected (Refer to [P.17-65](#)).
- (2) Connect the negative (–) battery terminal that was disconnected when the driver's air bag module was removed.
- (3) Do not disconnect cruise control switch connector C-201.
- (4) Turn the ignition switch to the "ON" position.
- (5) Do not operate the cruise control switch.
- (6) Measure the power supply voltage between cruise control switch connector C-201 terminal number 3 and body ground by backprobing.

Q: Is the measured voltage between 4.7 and 5.0 volts?



YES : Go to Step 14.

NO : Go to Step 3.



STEP 3. Measure the power supply voltage at ECM connector B-11.

- (1) Disconnect all the connectors from the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>.
- (2) Connect special tool MB992110 between the ECM and the body-side harness connector.
- (3) Turn the ignition switch to the "ON" position.
- (4) Do not operate the cruise control switch.



- (5) Measure the power supply voltage between special tool 48-pin connector terminal number 107 (ECM connector B-11 terminal number 107) and body ground.

Q: Is the measured voltage between 4.7 and 5.0 volts?

YES : Go to Step 10.
NO : Go to Step 4.

STEP 4. Check ECM connector B-11 for loose, corroded or damaged terminals, or terminals pushed back in the connector.


Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Are the connector and terminals in good condition?

YES : Go to Step 5.
NO : Repair or replace the damaged connector. Then go to Step 26.

STEP 5. Check the harness wire for short circuit to body ground between the ECM connector B-11 terminal number 107 and the cruise control switch connector C-201 terminal number 3.

- (1) Disconnect ECM connector B-11 and measure at the harness connector side [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>.
- (2) Turn the ignition switch to the "LOCK" (OFF) position.
- (3) Measure the continuity between ECM connector B-11 terminal number 107 and body ground.



Q: Is the measured continuity open circuit?

YES : Go to Step 24.
NO : Go to Step 6.

STEP 6. Check intermediate connector C-34, cruise control switch connector C-201, and clock spring connectors C-202 and C-204, for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Are the connectors and terminals in good condition?

YES : Go to Step 7.
NO : Repair or replace the damaged connector. Then go to Step 26.

STEP 7. Check the harness wire between ECM connector B-11 terminal number 107 and clock spring connector C-204 terminal number 5, and between clock spring connector C-202 terminal number 2 and cruise control switch connector C-201 terminal number 3, for damage. Check harness wire for short circuit and damage.

Q: Are the harness wires in good condition?

YES : Go to Step 8.
NO : Repair or replace the damaged harness wire. Then go to Step 26.

STEP 8. Check the clock spring.

Refer to GROUP 52B, Air Bag Modules and Clock Spring Inspection [P.52B-439](#).

Q: Is the clock spring in good condition?

YES : Go to Step 9.
NO : Replace the clock spring (Refer to GROUP 52B, Air Bag Modules and Clock Spring [P.52B-439](#)). Then go to Step 26.

STEP 9. Check the cruise control switch.

Refer to [P.17-64](#).

Q: Is the cruise control switch operating properly?

YES : Go to Step 13.

NO : Replace the cruise control switch (Refer to [P.17-65](#).)
Then go to Step 26.

STEP 10. Check ECM connector B-11, intermediate connector C-34, cruise control switch connector C-201, and clock spring connectors C-202 and C-204, for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Are the connectors and terminals in good condition?

YES : Go to Step 11.

NO : Repair or replace the damaged connector. Then go to Step 26.

STEP 11. Check the harness wire between ECM connector B-11 terminal number 107 and clock spring connector C-204 terminal number 5, and between clock spring connector C-202 terminal number 2 and cruise control switch connector C-201 terminal number 3, for damage.
Check harness wire for open circuit and damage.

Q: Are the harness wires in good condition?

YES : Go to Step 12.

NO : Repair or replace the damaged harness wire. Then go to Step 26.

STEP 12. Check the clock spring.

Refer to GROUP 52B, Air Bag Modules and Clock Spring Inspection [P.52B-447](#).

Q: Is the clock spring in good condition?

YES : Go to Step 13.

NO : Replace the clock spring (Refer to GROUP 52B, Air Bag Modules and Clock Spring [P.52B-439](#)). Then go to Step 26.

STEP 13. Using scan tool MB991958, check data list item 75: Cancel switch, item 86: Main switch, item 91: Resume switch and item 92: Set switch.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#).)
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#).)
 - Item 75: Cancel switch.
 - When "CANCEL" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "CANCEL" switch is released, the display on scan tool MB991958 should be "OFF".
 - Item 86: Main switch.
 - When "ON/OFF" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "ON/OFF" switch is pressed again, the display on scan tool MB991958 should be "OFF".
 - Item 91: Resume switch.
 - When "ACC/RES" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "ACC/RES" switch is released, the display on scan tool MB991958 should be "OFF".
 - Item 92: Set switch.
 - When "COAST/SET" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "COAST/SET" switch is released, the display on scan tool MB991958 should be "OFF".


Q: Is the switch operating properly?

YES : Go to Step 25.

NO : Go to Step 14.

STEP 14. Measure the ground voltage at cruise control switch connector C-201 by backprobing.

- (1) Remove the cruise control switch from the steering wheel with the cruise control switch connector connected (Refer to [P.17-65](#).)
- (2) Connect the negative (–) battery terminal that was disconnected when the driver's air bag module was removed.
- (3) Do not disconnect cruise control switch connector C-201.
- (4) Turn the ignition switch to the "ON" position.
- (5) Press and hold the "ON/OFF" switch, and measure the ground voltage between cruise control switch connector C-201 terminal number 2 and body ground by backprobing.




Q: Is the measured voltage 0.5 volt or less?

YES : Go to Step 20.

NO : Go to Step 15.

STEP 15. Measure the ground voltage at ECM connector B-11.

- (1) Disconnect all the connectors from the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>.
- (2) Connect special tool MB992110 between the ECM and the body-side harness connector.
- (3) Turn the ignition switch to the "ON" position.
- (4) Press and hold the "ON/OFF" switch, and measure the ground voltage between special tool 48-pin connector terminal number 95 (ECM connector B-11 terminal number 95) and body ground.



Q: Is the measured voltage 0.5 volt or less?

YES : Go to Step 17.
NO : Go to Step 16.

STEP 16. Check ECM connector B-11 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Are the connector and terminals in good condition?

YES : Go to Step 24.
NO : Repair or replace the damaged connector. Then go to Step 26.

STEP 17. Check intermediate connector C-34, cruise control switch connector C-201, and clock spring connectors C-202 and C-204, for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Are the connectors and terminals in good condition?

YES : Go to Step 18.
NO : Repair or replace the damaged connector. Then go to Step 26.

STEP 18. Check the harness wire between cruise control switch connector C-201 terminal number 2 and clock spring connector C-202 terminal number 3, and between clock spring connector C-204 terminal number 4 and ECM connector B-11 terminal number 95, for damage.

Check harness wire for open circuit and damage.

Q: Are the harness wires in good condition?

YES : Go to Step 19.
NO : Repair or replace the damaged harness wire. Then go to Step 26.

STEP 19. Check the clock spring.

Refer to GROUP 52B, Air Bag Modules and Clock Spring Inspection [P.52B-447](#).

Q: Is the clock spring in good condition?

YES : Go to Step 24.

NO : Replace the clock spring (Refer to GROUP 52B, Air Bag Modules and Clock Spring [P.52B-439](#)). Then go to Step 26.

STEP 20. Check ECM connector B-11, intermediate connector C-34, cruise control switch connector C-201, and clock spring connectors C-202 and C-204, for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Are the connectors and terminals in good condition?

YES : Go to Step 21.

NO : Repair or replace the damaged connector. Then go to Step 26.

STEP 21. Check the harness wire between cruise control switch connector C-201 terminal number 2 and clock spring connector C-202 terminal number 3, and between clock spring connector C-204 terminal number 4 and ECM connector B-11 terminal number 95, for damage.

Check harness wire for short circuit and damage.

Q: Are the harness wires in good condition?

YES : Go to Step 22.

NO : Repair or replace the damaged harness wire. Then go to Step 26.

STEP 22. Check the clock spring.

Refer to GROUP 52B, Air Bag Modules and Clock Spring Inspection [P.52B-447](#).

Q: Is the clock spring in good condition?

YES : Go to Step 23.

NO : Replace the clock spring (Refer to GROUP 52B, Air Bag Modules and Clock Spring [P.52B-439](#)). Then go to Step 26.

STEP 23. Check the cruise control switch.

Refer to [P.17-64](#).

Q: Is the cruise control switch operating properly?

YES : Go to Step 24.

NO : Replace the cruise control switch (Refer to [P.17-65](#).) Then go to Step 26.

STEP 24. Using scan tool MB991958, check data list item 75: Cancel switch, item 86: Main switch, item 91: Resume switch and item 92: Set switch.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#).)
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#).)
 - Item 75: Cancel switch.
 - When "CANCEL" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "CANCEL" switch is released, the display on scan tool MB991958 should be "OFF".
 - Item 86: Main switch.
 - When "ON/OFF" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "ON/OFF" switch is pressed again, the display on scan tool MB991958 should be "OFF".
 - Item 91: Resume switch.
 - When "ACC/RES" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "ACC/RES" switch is released, the display on scan tool MB991958 should be "OFF".
 - Item 92: Set switch.
 - When "COAST/SET" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "COAST/SET" switch is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 25.

NO : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 26.

STEP 25. Read the cruise control system DTC.

- (1) Disconnect the negative (-) battery terminal, to erase the DTC of the cruise control system.
- (2) Connect the negative (-) battery terminal.
- (3) Turn the ignition switch to the "ON" position, and press the "ON/OFF" switch to turn the cruise control system to ON (turn on the "CRUISE" indicator light.)
- (4) After turning the cruise control system to ON, when 2 minutes or more has elapsed without operating the cruise control switches, read the DTC of the cruise control system (Refer to [P.17-12](#).)

Q: Is DTC 15 set?

YES : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 26.

NO : It can be assumed that this malfunction is intermittent (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunction [P.00-15](#).)

STEP 26. Using scan tool MB991958, check data list item 75: Cancel switch, item 86: Main switch, item 91: Resume switch and item 92: Set switch.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#).)
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#).)
 - Item 75: Cancel switch.
 - When "CANCEL" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "CANCEL" switch is released, the display on scan tool MB991958 should be "OFF".
 - Item 86: Main switch.
 - When "ON/OFF" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "ON/OFF" switch is pressed again, the display on scan tool MB991958 should be "OFF".
 - Item 91: Resume switch.
 - When "ACC/RES" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "ACC/RES" switch is released, the display on scan tool MB991958 should be "OFF".
 - Item 92: Set switch.
 - When "COAST/SET" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "COAST/SET" switch is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 27.

NO : Return to Step 2.

STEP 27. Read the cruise control system DTC.

- (1) Disconnect the negative (-) battery terminal, to erase the DTC of the cruise control system.
- (2) Connect the negative (-) battery terminal.
- (3) Turn the ignition switch to the "ON" position, and press the "ON/OFF" switch to turn the cruise control system to ON (turn on the "CRUISE" indicator light.)
- (4) After turning the cruise control system to ON, when 2 minutes or more has elapsed without operating the cruise control switches, read the DTC of the cruise control system (Refer to [P.17-12](#).)


Q: Is DTC 15 set?

YES : Return to Step 1.



NO : The procedure is complete.

DTC 22: Stoplight Switch System.

Stoplight Switch System Circuit



ACA03181AB



CIRCUIT OPERATION

- For the stoplight switch, two switches, a stoplight switch for the stoplight illumination and a brake switch exclusively for the cruise control system, are incorporated to improve the reliability.
- As for the stoplight switch, when the brake pedal is depressed/released, the stoplight switch ON/OFF signal is transmitted from the ETACS-ECU to the ECM via CAN bus line.
- As for the brake switch, the ECM connector B-11 terminal number 108 monitor the state of the brake switch. The brake switch turn ON/OFF when the brake pedal is depressed/released, and the input signal to the ECM connector B-11 terminal number 108 changes. According to this change, the ECM judges the state of the brake switch.

DTC SET CONDITIONS

Check Condition

- The "CRUISE" indicator light illuminates.

Judgment Criteria

- Open/short in stoplight switch circuit.
- Open circuit in the brake switch circuit (between ECM connector B-11 terminal number 108 and body ground.)
- Malfunction of CAN bus line.

TROUBLESHOOTING HINTS (THE MOST LIKELY CAUSES FOR THIS CASE:)

- Malfunction of CAN bus system.
- Damaged harness or connector.
- Malfunction of the fuse No.2 at the ETACS-ECU.
- Malfunction of the stoplight switch.
- Malfunction of the stoplight relay.
- Malfunction of the ETACS-ECU.
- Malfunction of the ECM.

DIAGNOSTIC PROCEDURE

Required Special Tools:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A
- MB991223: Harness Set
- MB992006: Extra Fine Probe

CAUTION

If there is any problem in the CAN bus lines, an incorrect DTC may be set. Prior to this diagnosis, diagnose the CAN bus lines (Refer to GROUP 54C, Trouble code diagnosis P.54C-11.)

STEP 1. Using scan tool MB991958, diagnose the CAN bus line.**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to diagnose the CAN bus line (Refer to [P.17-12](#)).

Q: Is the check result satisfactory?

YES : Go to Step 2.

NO : Repair the CAN bus lines (Refer to GROUP 54C, Diagnosis – CAN Bus Diagnostics Chart [P.54C-19](#)). Then go to Step 12.



STEP 2. Using scan tool MB991958, check the data list item 74: Brake light switch.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#)).
 - Item 74: Brake light switch.
 - When the brake pedal is depressed, the display on scan tool MB991958 should be "ON".
 - When the brake pedal is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 6.

NO : Go to Step 3.

STEP 3. Check the stoplight operation.

Check the stoplight operation.

OK:

Brake pedal depressed: Stoplight will illuminate

Brake pedal not depressed: Stoplight does not illuminate

Q: Is the stoplight operating properly?

YES : Go to Step 4.

NO : Check the stoplight system (Refer to GROUP 54A, Rear Combination Lamp, Symptom Procedures – Inspection Procedure 3 [P.54A-258](#)). Then go to Step 12 .

STEP 4. Using scan tool MB991958, check the ETACS system data list item 290: Brake light switch.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for ETACS system (Refer to GROUP 54A, Data List Reference Table [P.54A-798](#)).
 - Item 290: Brake light switch.
 - When the brake pedal is depressed, the display on scan tool MB991958 should be "ON".
 - When the brake pedal is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 5.

NO : Replace the ETACS-ECU (Refer to GROUP 54A, ETACS-ECU [P.54A-847](#)). Then go to Step 12.

STEP 5. Using scan tool MB991958, check the data list item 74: Brake light switch.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#)).
 - Item 74: Brake light switch.
 - When the brake pedal is depressed, the display on scan tool MB991958 should be "ON".
 - When the brake pedal is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 6.

YES : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 12.

**STEP 6. Using scan tool MB991958, check the data list
item 89: Normally closed brake switch.**

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#)).
 - Item 89: Normally closed brake switch.
 - When the brake pedal is depressed, the display on scan tool MB991958 should be "ON".
 - When the brake pedal is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 11.

NO : Go to Step 7.

STEP 7. Check ECM connector B-11 and stoplight switch connector C-124 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Are the connectors and terminals in good condition?

YES : Go to Step 8.

NO : Repair or replace the damaged connector. Then go to Step 12.


STEP 8. Check the harness wire between ECM connector B-11 terminal number 108 and stoplight switch connector C-124 terminal number 3, and between stoplight switch connector C-124 terminal number 4 and body ground, for damage.

Check harness wire for open/short circuit and damage.

Q: Are the harness wires in good condition?

YES : Go to Step 9.

NO : Repair or replace the damaged harness wire. Then go to Step 12.



STEP 9. Check the stoplight switch.

Refer to GROUP 35A, Brake Pedal, Inspection – Stoplight Switch Check [P.35A-27](#).

Q: Is the stoplight switch operating properly?

YES : Go to Step 10.

NO : Replace the stoplight switch (Refer to GROUP 35A, Brake Pedal [P.35A-26](#).) Then go to Step 12.

**STEP 10. Using scan tool MB991958, check the data list
item 89: Normally closed brake switch.**

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#)).
 - Item 89: Normally closed brake switch.
 - When the brake pedal is depressed, the display on scan tool MB991958 should be "ON".
 - When the brake pedal is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 11.

NO : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 12.

STEP 11. Read the cruise control system DTC.

- (1) Disconnect the negative (-) battery terminal, to erase the DTC of the cruise control system.
- (2) Connect the negative (-) battery terminal.
- (3) Turn the ignition switch to the "ON" position, and press the "ON/OFF" switch to turn the cruise control system to ON (turn on the "CRUISE" indicator light.)
- (4) With the cruise control switches not operated, depress the brake pedal for several seconds, and then read the DTC of the cruise control system (Refer to [P.17-12](#).)

Q: Is DTC 22 set?

YES : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 12.

NO : It can be assumed that this malfunction is intermittent (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunction [P.00-15](#).)

STEP 12. Using scan tool MB991958, check the data list item 74: Brake light switch, item 89: Normally closed brake switch.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#).)
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#).)
 - Item 74: Brake light switch.
 - When the brake pedal is depressed, the display on scan tool MB991958 should be "ON."
 - When the brake pedal is released, the display on scan tool MB991958 should be "OFF."
 - Item 89: Normally closed brake switch.
 - When the brake pedal is depressed, the display on scan tool MB991958 should be "ON."
 - When the brake pedal is released, the display on scan tool MB991958 should be "OFF."

Q: Is the switch operating properly?

YES : Go to Step 13.

NO : Return to Step 2.

STEP 13. Read the cruise control system DTC.

- (1) Disconnect the negative (–) battery terminal, to erase the DTC of the cruise control system.
- (2) Connect the negative (–) battery terminal.
- (3) Turn the ignition switch to the "ON" position, and press the "ON/OFF" switch to turn the cruise control system to ON (turn on the "CRUISE" indicator light.)
- (4) With the cruise control switches not operated, depress the brake pedal for several seconds, and then read the DTC of the cruise control system (Refer to [P.17-12](#).)

Q: Is DTC P22 set?

YES : Return to Step 1.

NO : The procedure is complete.

DTC 23: ECM and Its Related Component**DTC SET CONDITIONS**

This DTC is set when there is failure in the ECM and its related components.

TROUBLESHOOTING HINTS (THE MOST LIKELY CAUSES FOR THIS CASE:)

- Malfunction of the MFI system.
- Malfunction of the ECM.

DIAGNOSIS**Required Special Tools:**

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
- MB991824: V.C.I.
- MB991827: M.U.T.-III USB Cable
- MB991910: M.U.T.-III Main Harness A

STEP 1. Using scan tool MB991958, read the MFI system diagnostic trouble code.**CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Check for MFI system diagnostic trouble code (Refer to GROUP 13A, Diagnostic Function – How to Read and Erase Diagnostic Trouble Codes [P.13A-11](#)) <2.4L Engine> or (Refer to GROUP 13B, Diagnostic Function – How to Read and Erase Diagnostic Trouble Codes [P.13B-11](#)) <3.0L Engine>.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.
- (5) Disconnect scan tool MB991958.

Q: Is any DTC set?

YES : Diagnose the MFI system (Refer to GROUP 13A, Diagnostic Trouble Code Chart [P.13A-49](#)) <2.4L Engine> or (Refer to GROUP 13B, Diagnostic Trouble Code Chart [P.13B-50](#)) <3.0L Engine>. Then go to Step 3.

NO : Go to Step 2.



STEP 2. Read the cruise control system diagnostic trouble code.

- (1) Erase diagnostic trouble code. (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position, and press the "ON/OFF" switch to turn the cruise control system to ON (turn on the "CRUISE" indicator light).
- (3) After turning the cruise control system to ON, when 2 minutes or more has elapsed without operating the cruise control switches, read the diagnostic trouble code of the cruise control system (Refer to [P.17-12](#)).

Q: Is DTC 23 set?

YES : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 3.

NO : It can be assumed that this malfunction is intermittent (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions [P.00-15](#)).

STEP 3. Read the cruise control system diagnostic trouble code.

- (1) Erase diagnostic trouble code. (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position, and press the "ON/OFF" switch to turn the cruise control system to ON (turn on the "CRUISE" indicator light).
- (3) After turning the cruise control system to ON, when 2 minutes or more has elapsed without operating the cruise control switches, read the diagnostic trouble code of the cruise control system (Refer to [P.17-12](#)).

Q: Is DTC 23 set?

YES : Return to Step 1.

NO : The procedure is complete.

SYMPTOM CHART

M1172002302113

Symptom	Inspection procedure number	Reference page
Scan tool communication with ECM is not possible <2.4L Engine>.	-	GROUP 13A, Symptom Procedures – Inspection Procedure 1 P.13A-719 .
Scan tool communication with ECM is not possible <3.0L Engine>.	-	GROUP 13B, Symptom Procedures – Inspection Procedure 1 P.13B-748 .
When the brake pedal is depressed, cruise control is not cancelled.	1	P.17-39
When the selector lever is moved to "N" position, cruise control is not cancelled.	2	P.17-41
When the "CANCEL" switch is pressed, cruise control is not cancelled.	3	P.17-45
Cruise control cannot be set (No response "COAST/SET" switch and "ACC/RES" switch is pressed.)	4	P.17-46
Hunting (repeated acceleration and deceleration) occurs at the set vehicle speed.	5	P.17-52
When "ON/OFF" switch is turned "ON", "CRUISE" indicator light inside combination meter does not illuminate (However, cruise control system is normal).	6	P.17-55

SYMPTOM PROCEDURES

Inspection Procedure 1: When the Brake Pedal is Depressed, Cruise Control System is not Cancelled.**COMMENT**

- Malfunction of CAN bus line.
- The stoplight switch circuit is suspected.

TROUBLESHOOTING HINTS (THE MOST LIKELY CAUSES FOR THIS CASE:)

- Malfunction of CAN bus system.
- Damaged harness or connector.
- Malfunction of the stoplight switch.
- Malfunction of the ETACS-ECU
- Malfunction of the ECM.

DIAGNOSTIC PROCEDURE**Required Special Tools:**

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A

CAUTION

If there is any problem in the CAN bus lines, an incorrect DTC may be set. Prior to this diagnosis, diagnose the CAN bus lines (Refer to GROUP 54C, Trouble code diagnosis P.54C-11.)

STEP 1. Using scan tool MB991958, diagnose the CAN bus line.**CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958 to the data link connector (Refer to P.17-12).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to diagnose the CAN bus line (Refer to P.17-12).

Q: Is the check result satisfactory?

YES : Go to Step 2.

NO : Repair the CAN bus lines (Refer to GROUP 54C, Diagnosis – CAN Bus Diagnostics Chart P.54C-19). Then go to Step 4.



STEP 2. Using scan tool MB991958, check the data list item 74: Brake light switch, item 89: Normally closed brake switch.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#)).
 - Item 74: Brake light switch.
 - When the brake pedal is depressed, the display on scan tool MB991958 should be "ON".
 - When the brake pedal is released, the display on scan tool MB991958 should be "OFF".
 - Item 89: Normally closed brake switch.
 - When the brake pedal is depressed, the display on scan tool MB991958 should be "ON".
 - When the brake pedal is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 3.

NO : Repair the stoplight switch system (Refer to [P.17-29](#), Diagnostic Trouble Code Procedures – DTC 22: Stoplight Switch System.) Then go to Step 4 .

STEP 3. Check the symptom.

Q: When the brake pedal is depressed, is the cruise control cancelled?

YES : It can be assumed that this malfunction is intermittent (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions [P.00-15](#)).

NO : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 4.

STEP 4. Check the symptom.

Q: When the brake pedal is depressed, is the cruise control cancelled?

YES : The procedure is complete.

NO : Return to Step 1.

Inspection Procedure 2: When the Selector Lever is Moved to "N" Position, cruise Control System is not Cancelled.

CIRCUIT OPERATION

When the selector lever is operated, the selector lever position signal from the transmission range switch is sent to the TCM. ECM receives the selector lever position signal from the TCM via the CAN bus line.

COMMENT

- Malfunction of CAN bus line.
- Malfunction of CVT system <2.4L Engine> or A/T system <3.0L Engine>.
- The transmission range switch circuit is suspected.

TROUBLESHOOTING HINTS (THE MOST LIKELY CAUSES FOR THIS CASE:)

- Malfunction of CAN bus system.
- Damaged harness or connector.
- Malfunction of CVT system <2.4L Engine>.
- Malfunction of A/T system <3.0L Engine>.
- Malfunction of the transmission range switch.
- Malfunction of the TCM.
- Malfunction of the ECM.


DIAGNOSTIC PROCEDURE

Required Special Tools:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A

CAUTION

If there is any problem in the CAN bus lines, an incorrect DTC may be set. Prior to this diagnosis, diagnose the CAN bus lines (Refer to GROUP 54C, Trouble code diagnosis [P.54C-11.](#))



STEP 1. Using scan tool MB991958, diagnose the CAN bus line.

⚠ CAUTION

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to diagnose the CAN bus line (Refer to [P.17-12](#)).

Q: Is the check result satisfactory?

YES : Go to Step 2 <2.4L Engine>.

YES : Go to Step 4 <3.0L Engine>.

NO : Repair the CAN bus lines (Refer to GROUP 54C, Diagnosis – CAN Bus Diagnostics Chart [P.54C-19](#)). Then go to Step 8.

STEP 2. Using scan tool MB991958, check the CVT system data list item 49: Transmission range switch <2.4L Engine>.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for CVT system (Refer to GROUP 23A, Diagnosis – Diagnostic Function [P.23A-13](#).)
 - Item 49: Transmission range switch.

Q: Is the switch operating properly?

YES : Go to Step 3.

NO : Repair the CVT system (Refer to GROUP 23A, Diagnosis, Diagnostic Trouble Code Procedures – DTC P0705: Malfunction of Transmission Range Switch [P.23A-34](#).) Then go to Step 8.

STEP 3. Using scan tool MB991958, read the CVT system DTC <2.4L Engine>.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for CVT system DTC (Refer to GROUP 23A, Diagnosis – Diagnostic Function [P.23A-13](#).)

Q: Is any DTC set?

YES : Diagnose the CVT system (Refer to GROUP 23A, Diagnosis – Diagnostic Trouble Code Chart [P.23A-27](#)). Then go to Step 8.

NO : Go to Step 6.

STEP 4. Using scan tool MB991958, check the A/T system data list item 54: Transmission range switch <3.0L Engine>.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for A/T system (Refer to GROUP 23C, Automatic Transaxle Diagnosis – Diagnostic Function [P.23C-20](#).)
 - Item 54: Transmission range switch.

Q: Is the switch operating properly?

YES : Go to Step 5.

NO : Repair the A/T system (Refer to GROUP 23C, Automatic Transaxle Diagnosis, Diagnostic Trouble Code Procedures – DTC P0705: Malfunction of Transmission Range Switch [P.23C-36](#).) Then go to Step 8.

STEP 5. Using scan tool MB991958, read the A/T system DTC <3.0L Engine>.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for A/T system DTC (Refer to GROUP 23C, Automatic Transaxle Diagnosis – Diagnostic Function [P.23C-20](#)).

Q: Is any DTC set?

YES : Repair the A/T system (Refer to GROUP 23C, Automatic Transaxle Diagnosis – Diagnostic Trouble Code Chart [P.23C-29](#)). Then go to Step 8.

NO : Go to Step 6.

**STEP 6. Using scan tool MB991958, check data list item 88:
Neutral switch.**

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#).)
 - Item 88: Neutral switch.
 - When selector lever is at the "P" and "N" position, the display on scan tool MB991958 should be "ON."
 - When selector lever is other than "P" and "N" position, the display on scan tool MB991958 should be "OFF."

Q: Is the switch operating properly?

YES : Go to Step 7.

NO : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 8.

STEP 7. Check the symptom.**Q: When the selector lever is moved to "N" position, is the cruise control cancelled?**

YES : It can be assumed that this malfunction is intermittent (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions [P.00-15](#)).

NO : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 8.

STEP 8. Check the symptom.**Q: When the selector lever is moved to "N" position, is the cruise control cancelled?**

YES : The procedure is complete.

NO : Return to Step 1.

Inspection Procedure 3: When the "CANCEL" Switch is Set to ON, Cruise Control System is not Cancelled.**COMMENT**

The cause is probably an open-circuit in the output circuit inside the "CANCEL" switch.

TROUBLESHOOTING HINTS (THE MOST LIKELY CAUSES FOR THIS CASE:)

- Malfunction of the cruise control switch.
- Malfunction of the ECM.

DIAGNOSTIC PROCEDURE**Required Special Tools:**

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A

STEP 1. Using scan tool MB991958, check the data list item 75: Cancel switch.**CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#)).
 - Item 75: Cancel switch.
 - When the "CANCEL" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When the "CANCEL" switch is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 2.

NO : Repair the cruise control switch system (Refer to [P.17-16](#), Diagnosis Code Procedures – DTC 15: Cruise Control Switch System.) Then go to Step 3 .

**STEP 2. Check the symptom.****Q: When the "CANCEL" switch is pressed, is the cruise control cancelled?**

YES : It can be assumed that this malfunction is intermittent (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions [P.00-15](#)).

NO : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 3.

STEP 3. Check the symptom.

Q: When the "CANCEL" switch is pressed, is the cruise control cancelled?

YES : The procedure is complete.

NO : Return to Step 1.

Inspection Procedure 4: Cruise Control cannot be Set (No Response "COAST/SET" Switch and "ACC/RES" Switch is Pressed).

COMMENT

The fail-safe function is probably canceling cruise control system. In this case, checking the cruise control system, MFI system, CVT system <2.4L Engine> or A/T system <3.0L Engine>, ASC system <vehicles with ASC> and CAN bus line system for DTCs. The scan tool MB991958 can also be used to check if the circuits of each input switch are normal or not by checking the data list.

NOTE: Press the cruise control switches one by one securely. Otherwise, the cruise control system may not be started.

TROUBLESHOOTING HINTS (THE MOST LIKELY CAUSES FOR THIS CASE:)

- Malfunction of the CAN bus line system.
- Malfunction of the MFI system.
- Malfunction of the CVT system <2.4L Engine>.
- Malfunction of the A/T system <3.0L Engine>.
- Malfunction of the ASC system <vehicles with ASC>.
- Malfunction of the cruise control switch.
- Malfunction of the stoplight switch.
- Malfunction of the transmission range switch.
- Malfunction of the TCM.
- Malfunction of the ECM.

DIAGNOSTIC PROCEDURE

Required Special Tools:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
 - MB991824: V.C.I.
 - MB991827: M.U.T.-III USB Cable
 - MB991910: M.U.T.-III Main Harness A

CAUTION

If there is any problem in the CAN bus lines, an incorrect DTC may be set. Prior to this diagnosis, diagnose the CAN bus lines (Refer to GROUP 54C, Trouble code diagnosis P.54C-11.)

STEP 1. Using scan tool MB991958, diagnose the CAN bus line.**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to diagnose the CAN bus line (Refer to [P.17-12](#)).

Q: Is the check result satisfactory?

YES : Go to Step 2.

NO : Repair the CAN bus lines (Refer to GROUP 54C, Diagnosis – CAN Bus Diagnostics Chart [P.54C-19](#)). Then go to Step 12.



STEP 2. Using scan tool MB991958, check for ECM option coding data.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#).)
- (2) Turn the ignition switch to the "ON" position.
- (3) Check for ECM option coding data (Refer to GROUP 00, Precautions Before Service – Coding List [P.00-44](#).)

Q: Is the cruise control item of the ECM option coding data enabled?

YES : Go to Step 3.

NO : Set the ECM option coding data again. (Refer to GROUP 00, Precautions Before Service – Coding List [P.00-44](#).) Then go to Step 12.

STEP 3. Using scan tool MB991958, read the MFI system DTC.

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.54C-19](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for MFI system DTC
(Refer to GROUP 13A, MFI Diagnosis – Diagnostic Function [P.13A-11](#)) <2.4L Engine> or (Refer to GROUP 13B, MFI Diagnosis – Diagnostic Function [P.13B-11](#)) <3.0L Engine>.

Q: Is any DTC set?

YES : Repair the MFI system (Refer to GROUP 13A, MFI Diagnosis – Diagnostic Trouble Code Chart [P.13A-49](#)) <2.4L Engine> or (Refer to GROUP 13B, MFI Diagnosis – Diagnostic Trouble Code Chart [P.13B-50](#)) <3.0L Engine>. Then go to Step 12.

NO : Go to Step 4 <2.4L Engine>.

NO : Go to Step 5 <3.0L Engine>.

STEP 4. Using scan tool MB991958, read the CVT system DTC <2.4L Engine>.

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for CVT system DTC
(Refer to GROUP 23A, Diagnosis – Diagnostic Function [P.23A-13](#)).

Q: Is any DTC set?

YES : Repair the CVT system (Refer to GROUP 23A, Diagnosis – Diagnostic Trouble Code Chart [P.23A-27](#)). Then go to Step 12.

NO : Go to Step 6.

STEP 5. Using scan tool MB991958, read the A/T system DTC <3.0L Engine>.

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for A/T system DTC
(Refer to GROUP 23C, Automatic Transaxle Diagnosis – Diagnostic Function [P.23C-20](#)).

Q: Is any DTC set?

YES : Repair the A/T system (Refer to GROUP 23C, Automatic Transaxle Diagnosis – Diagnostic Trouble Code Chart [P.23C-166](#)). Then go to Step 12.

NO : Go to Step 6 <vehicles with ASC>.

NO : Go to Step 7 <vehicles without ASC>.

**STEP 6. Using scan tool MB991958, read for ASC system
DTC <vehicles with ASC>.**

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for ASC system DTC
(Refer to GROUP 35C, Diagnosis – Diagnostic Function
[P.35C-9](#).)

Q: Is any DTC set?

YES : Repair the ASC system (Refer to GROUP 35C,
Diagnosis – Diagnostic Trouble Code Chart
[P.35C-20](#)) . Then go to Step 12.

NO : Go to Step 7.

STEP 7. Read the cruise control system DTC.

- (1) Disconnect the negative (–) battery terminal, to erase the DTC of the cruise control system.
- (2) Connect the negative (–) battery terminal.
- (3) Turn the ignition switch to the "ON" position, and press the "ON/OFF" switch to turn the cruise control system to ON (turn on the "CRUISE" indicator light).
- (4) After turning the cruise control system to ON, when 2 minutes or more has elapsed without operating the cruise control switches, read the DTC of the cruise control system (Refer to [P.17-12](#)).

Q: Is any DTC set?

YES : Repair the cruise control system (Refer to [P.17-15](#),
Diagnostic Trouble Code Chart). Then go to Step 12.

NO : Go to Step 8.

STEP 8. Using scan tool MB991958, check the data list

item 75: Cancel switch, item 86: Main switch, item 91: Resume switch and item 92: Set switch.

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#)).
 - Item 75: Cancel switch.
 - When "CANCEL" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "CANCEL" switch is released, the display on scan tool MB991958 should be "OFF".
 - Item 86: Main switch.
 - When "ON/OFF" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "ON/OFF" switch is pressed again, the display on scan tool MB991958 should be "OFF".
 - Item 91: Resume switch.
 - When "ACC/RES" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "ACC/RES" switch is released, the display on scan tool MB991958 should be "OFF".
 - Item 92: Set switch.
 - When "COAST/SET" switch is pressed, the display on scan tool MB991958 should be "ON".
 - When "COAST/SET" switch is released, the display on scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 9.

NO : Repair the cruise control switch system (Refer to [P.17-16](#), Diagnosis Code Procedures – DTC 15: Cruise Control Switch System.) Then go to Step 12 .

**STEP 9. Using scan tool MB991958, check the data list
item 74: Brake light switch, item 89: Normally closed brake
switch.**

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise
control system (Refer to [P.17-12](#)).
 - Item 74: Brake light switch.
 - When the brake pedal is depressed, the display on
scan tool MB991958 should be "ON".
 - When the brake pedal is released, the display on
scan tool MB991958 should be "OFF".
 - Item 89: Normally closed brake switch.
 - When the brake pedal is depressed, the display on
scan tool MB991958 should be "ON".
 - When the brake pedal is released, the display on
scan tool MB991958 should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 10.

NO : Repair the stoplight switch system (Refer to [P.17-29](#),
Diagnostic Trouble Code Procedures – DTC 22:
Stoplight Switch System.) Then go to Step 12 .

**STEP 10. Using scan tool MB991958, check the data list
item 88: Neutral switch.**

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise
control system (Refer to [P.17-12](#)).
 - Item 88: Neutral switch.
 - When the selector lever is moved to "N" or "P" posi-
tion, the display on scan tool MB991958 should be
"ON".
 - When the selector lever is moved to other than "N"
or "P" position, the display on scan tool MB991958
should be "OFF".

Q: Is the switch operating properly?

YES : Go to Step 11.

NO : Repair the CVT system (Refer to GROUP 23A,
Diagnosis – Diagnostic Trouble Code Procedures –
DTC P0705: Malfunction of Transmission Range
Switch [P.23A-34](#)) <2.4L Engine> or A/T system
(Refer to GROUP 23C, Automatic Transaxle
Diagnosis – Diagnostic Trouble Code Procedures –
DTC P0705: Transmission Range Switch System
[P.23C-36](#)) <3.0L Engine>. Then go to Step 12.

STEP 11. Check the symptom.

Q: Can cruise control be set?

YES : It can be assumed that this malfunction is intermittent (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunction [P.00-15](#)).

NO : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 12.

STEP 12. Check the symptom.

Q: Can auto-cruise control be set?

YES : The procedure is complete.

NO : Return to Step 1.

Inspection Procedure 5: Hunting (Repeated Acceleration and Deceleration) Occurs at the Set Vehicle Speed.**COMMENT**

- The secondary pulley speed sensor signal (vehicle speed signal) <2.4L Engine>, output shaft speed sensor signal (vehicle speed signal) <3.0L Engine>, or the throttle body is suspected.
- The secondary pulley speed sensor signal (vehicle speed signal) <2.4L Engine> or output shaft speed sensor signal (vehicle speed signal) <3.0L Engine> is transmitted from the TCM to the ECM via the CAN bus line.

NOTE: When the vehicle is driven with the low-speed gear in the sport mode, hunting occurs easily, however, this is not a failure.

TROUBLESHOOTING HINTS (THE MOST LIKELY CAUSES FOR THIS CASE:)


- Malfunction of the CAN bus line system.
- Malfunction of the secondary pulley speed sensor <2.4L Engine>.
- Malfunction of the output shaft speed sensor <3.0L Engine>.
- Malfunction of the CVT system <2.4L Engine>.
- Malfunction of the A/T system <3.0L Engine>.
- Malfunction of the throttle body.
- Malfunction of the ECM.

DIAGNOSTIC PROCEDURE**Required Special Tools:**

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
- MB991824: V.C.I.
- MB991827: M.U.T.-III USB Cable
- MB991910: M.U.T.-III Main Harness A

 CAUTION

If there is any problem in the CAN bus lines, an incorrect diagnostic trouble code (DTC) may be set. Prior to this diagnosis, diagnose the CAN bus lines (Refer to GROUP 54C, Trouble code diagnosis [P.54C-11](#).)



STEP 1. Using scan tool MB991958, diagnose the CAN bus line.**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to diagnose the CAN bus line (Refer to [P.17-12](#)).

Q: Is the check result satisfactory?

YES : Go to Step 2 <2.4L Engine>.

YES : Go to Step 3 <3.0L Engine>.

NO : Repair the CAN bus lines (Refer to GROUP 54C, Diagnosis – CAN Bus Diagnostics Chart [P.54C-19](#)). Then go to Step 7.

STEP 2. Using scan tool MB991958, read the CVT system DTC <2.4L Engine>.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for CVT system DTC (Refer to GROUP 23A, Diagnosis – Diagnostic Function [P.23A-13](#)).

Q: Is any DTC set?

YES : Repair the CVT system (Refer to GROUP 23A, Diagnosis – Diagnostic Trouble Code Chart [P.23A-27](#)). Then go to Step 7.

NO : Go to Step 4.

STEP 3. Using scan tool MB991958, read the A/T system DTC <3.0L Engine>.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for A/T system DTC (Refer to GROUP 23C, Automatic Transaxle Diagnosis – Diagnostic Function [P.23C-20](#)).

Q: Is any DTC set?

YES : Repair the A/T system (Refer to GROUP 23C, Automatic Transaxle Diagnosis – Diagnostic Trouble Code Chart [P.23C-166](#)). Then go to Step 7.

NO : Go to Step 4.

STEP 4. Using scan tool MB991958, read the MFI system DTC.

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.54C-19](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for MFI system DTC
(Refer to GROUP 13A, MFI Diagnosis – Diagnostic Function [P.13A-11](#)) <2.4L Engine> or (Refer to GROUP 13B, MFI Diagnosis – Diagnostic Function [P.13B-11](#)) <3.0L Engine>.

Q: Is any DTC set?

YES : Repair the MFI system (Refer to GROUP 13A, MFI Diagnosis – Diagnostic Trouble Code Chart [P.13A-49](#)) <2.4L Engine> or (Refer to GROUP 13B, MFI Diagnosis – Diagnostic Trouble Code Chart [P.13B-50](#)) <3.0L Engine>. Then go to Step 7.

NO : Go to Step 5.

STEP 5. Using scan tool MB991958, check the data list item 4: vehicle speed signal.

- (1) Connect scan tool MB991958 to the data link connector
(Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to data reading mode for cruise control system (Refer to [P.17-12](#)).
 - Item 4: Vehicle speed signal.
 - When road test the vehicles, check the display on scan tool MB991958 and speedometer.

Q: Is the check result satisfactory?

YES : Go to Step 6.

NO : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 7.

STEP 6. Check the symptom.

Q: Does hunting occur?

YES : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 7.

NO : It can be assumed that this malfunction is intermittent (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions [P.00-15](#)).

STEP 7. Check the symptom.

Q: Does hunting occur?

YES : Return to Step 1.

NO : The procedure is complete.

Inspection Procedure 6: When "ON/OFF" Switch is Turned ON, "CRUISE" Indicator Light Inside Combination Meter does not Illuminate (However, Cruise Control System is Normal).

CIRCUIT OPERATION

- The ECM detects "ON/OFF" switch ON signal to illuminate the "CRUISE" indicator light within the combination meter.
- The "CRUISE" indicator light illuminate signal is transmitted from the ECM to the combination meter via CAN bus line.

COMMENT

- The CAN bus line between the ECM and the ETACS-ECU and between the ETACS-ECU and the combination meter may be defective.
- The combination meter, ETACS-ECU or ECM may also be defective.

TROUBLESHOOTING HINTS

- Malfunction of CAN bus system.
- Damaged harness or connector.
- Malfunction of the combination meter.
- Malfunction of the ETACS-ECU
- Malfunction of the ECM


DIAGNOSTIC PROCEDURE

Required Special Tools:

- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
- MB991824: V.C.I.
- MB991827: M.U.T.-III USB Cable
- MB991910: M.U.T.-III Main Harness A

⚠ CAUTION

If there is any problem in the CAN bus lines, an incorrect DTC may be set. Prior to this diagnosis, diagnose the CAN bus lines (Refer to GROUP 54C, Trouble code diagnosis [P.54C-11.](#))



STEP 1. Using scan tool MB991958, diagnose the CAN bus line.

⚠ CAUTION

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to diagnose the CAN bus line (Refer to [P.17-12](#)).

Q: Is the check result satisfactory?

YES : Go to Step 2

NO : Repair the CAN bus lines (Refer to GROUP 54C, Diagnosis – CAN Bus Diagnostics Chart [P.54C-19](#)). Then go to Step 6.

STEP 2. Using scan tool MB991958, read the MFI system DTC.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.54C-19](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for MFI system DTC (Refer to GROUP 13A, MFI Diagnosis – Diagnostic Function [P.13A-11](#)) <2.4L Engine> or (Refer to GROUP 13B, MFI Diagnosis – Diagnostic Function [P.13B-11](#)) <3.0L Engine>.

Q: Is DTC U0141 set?

YES : Repair the MFI system (Refer to GROUP 13A, MFI Diagnosis, Diagnostic Trouble Code Procedures – DTC U0141: ETACS-ECU Time Out [P.13A-714](#)) <2.4L Engine> or (Refer to GROUP 13B, MFI Diagnosis, Diagnostic Trouble Code Procedures – DTC U0141: ETACS-ECU Time Out [P.13B-735](#)) <3.0L Engine>. Then go to Step 6.

NO : Go to Step 3.

STEP 3. Using scan tool MB991958, read the ETACS system DTC.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check for ETACS system DTC (Refer to GROUP 54A, ETACS, Troubleshooting – Diagnostic Function [P.54A-753](#)).

Q: Is DTC U0155 set?

YES : Repair the ETACS system (Refer to GROUP 54A, ETACS, Troubleshooting, Diagnostic Trouble Code Procedures – DTC U0155: Combination Meter-ECU CAN Communication Time Out [P.54A-773](#).) Then go to Step 6.

NO : Go to Step 4.

STEP 4. Using scan tool MB991958, check the combination meter system actuator test item 7: Cruise indicator 1.

- (1) Connect scan tool MB991958 to the data link connector (Refer to [P.17-12](#)).
- (2) Turn the ignition switch to the "ON" position.
- (3) Set scan tool MB991958 to check the actuator test for combination meter system item 7: indicator 1 (Refer to GROUP 54A, Combination Meter, Troubleshooting – Actuator Test Table [P.54A-107](#).)

Q: Is the check result satisfactory?

YES : Go to Step 5.

NO : Repair the combination meter system (Refer to GROUP 54A, Combination Meter, Troubleshooting, Symptom Procedures – Inspection Procedure 5: The combination meter light does not illuminate normally or the multi information display is not displayed normally [P.54A-87](#).) Then go to Step 6.

STEP 5. Check the symptom.

Q: When the "ON/OFF" switch is turned ON, is the "CRUISE" indicator light illuminated?

YES : It can be assumed that this malfunction is intermittent (Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions [P.00-15](#)).

NO : Replace the ECM [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>. Then go to Step 6.

STEP 6. Check the symptom.

Q: When the "ON/OFF" switch is turned ON, is the "CRUISE" indicator light illuminated?

YES : The procedure is complete.

NO : Return to Step 1.

DATA LIST REFERENCE TABLE

M1172002402109

CAUTION

- Driving tests always need two persons: one driver and one observer.
- When shifting the selector lever to "D" range apply the brakes should be applied so that the vehicle does not move forward.

Scan tool display	Item number	Inspection item	Inspection requirement		Normal condition
Brake light switch	74	Stoplight switch (for stoplight circuit)	Ignition switch: "ON"	Brake pedal: Depressed	ON
				Brake pedal: Released	OFF
Cancel code	57	Cancel code	Ignition switch: "ON"		The cancel code, which set when the cruise control system was cancelled at the last time.
Cancel switch	75	Cruise control switch ("CANCEL" switch)	Ignition switch: "ON"	"CANCEL" switch: Pressed	ON
				"CANCEL" switch: Released	OFF
Cruise switch	81	Cruise control system operation	Cruise control system: active		ON
			Cruise control system: Inactive		OFF
Main switch	86	Cruise control switch ("ON/OFF" switch)	Ignition switch: "ON"	"ON/OFF" switch: Pressed	ON
				"ON/OFF" switch: Pressed again	OFF
Neutral switch	88	Transmission range switch	Ignition switch: "ON"	Selector lever: "N" or "P" position	ON
				Selector lever: Other than "N" or "P" position	OFF
Normally closed brake switch	89	Stoplight switch (for Cruise control circuit)	Ignition switch: "ON"	Brake pedal: Depressed	ON
				Brake pedal: Released	OFF
Resume switch	91	Cruise control switch ("ACC/RES" switch)	Ignition switch: "ON"	"ACC/RES" switch: Pressed	ON
				"ACC/RES" switch: Released	OFF
Set switch	92	Cruise control switch ("COAST/SET" switch)	Ignition switch: "ON"	"COAST/SET" switch: Pressed	ON
				"COAST/SET" switch: Released	OFF
Vehicle speed	4	Vehicle speed signal	Road test the vehicle		The speedometer and scan tool MB991958 display the same value.

ECM TERMINAL VOLTAGE REFERENCE CHART
FOR CRUISE CONTROL SYSTEM OPERATION


M1172006000129

Required Special Tool:

- MB992110: Power plant ECU check harness


Use special tool MB992110, check the ECM terminal voltage.

1. Disconnect the all ECM connectors, and connect special tool (MB992110) in between [Refer to GROUP 13A, Engine Control Module (ECM) [P.13A-887](#)] <2.4L Engine> or [Refer to GROUP 13B, Engine Control Module (ECM) [P.13B-904](#)] <3.0L Engine>.
2. Measure the voltages between the check connector terminals of special tool (MB992044) and ground terminals (ECM connector B-11 terminal 81 or 93).




Special tool - Power plant ECU check harness (MB992110) connector: Component side

48-Pin connector
(ECM connector B-11)



64-Pin connector
(ECM connector B-10)














AC703944AB

Terminal number	Check item	Check condition		Normal condition
107	Cruise control switch power supply	Ignition switch: "ON"	All switches: Released	4.7 - 5.0 V
			"ON/OFF" switch: Pressed	0 - 0.5 V
			"CANCEL" switch: Pressed	1.0 - 1.8 V
			"COAST/SET" switch: Pressed	2.3 - 3.0 V
			"ACC/RES" switch: Pressed	3.5 - 4.2 V
108	Stoplight switch (brake switch)	Ignition switch: "ON"	Depress the brake pedal.	Battery positive voltage
			Release the brake pedal.	1V or less

SPECIAL TOOLS

M1172000601870

Tool	Tool number and name	Supersession	Application
a  MB991824	MB991958 a. MB991824 b. MB991827 c. MB991910 d. MB991911 e. MB991914 f. MB991825 g. MB991826 M.U.T.-III sub assembly	MB991824-KIT <i>NOTE: g: MB991826 M.U.T.-III trigger harness is not necessary when pushing V.C.I. ENTER key.</i>	CAUTION For vehicles with CAN communication, use M.U.T.-III main harness A to send simulated vehicle speed. If you connect M.U.T.-III main harness B or C instead, the CAN communication does not function correctly. Checking data list
b  MB991827			
c  MB991910			
d  MB991911			
e  MB991914			
f  MB991825			
g  MB991826 MB991958			

Tool	Tool number and name	Supersession	Application
   	MB991223 a. MB991219 b. MB991220 c. MB991221 d. MB991222 Harness set a. Test harness b. LED harness c. LED harness adaptor d. Probe	General service tools	Checking the continuity and measuring the voltage at the harness connector
	MB992006 Extra fine probe	General service tool	Continuity check and voltage measurement at harness wire or connector for loose, corroded or damaged terminals, or terminals pushed back in the connector.
	MB992110 Power plant ECU check harness	–	Measuring the terminal voltage at the ECM




ON-VEHICLE SERVICE

CRUISE CONTROL SYSTEM OPERATION CHECK

M1172001600193

CRUISE CONTROL "ON/OFF" SWITCH CHECK

1. Turn the ignition switch to the "ON" position.
2. Check that the "CRUISE" indicator light within the combination meter illuminates when the "ON/OFF" switch is pressed (cruise control system: ON).
3. Press the "ON/OFF" switch again (cruise control system: OFF), and check that the "CRUISE" indicator light within the combination meter goes out.



CRUISE CONTROL SETTING


1. Start the engine.
2. Press the "ON/OFF" switch (cruise control system: ON, "CRUISE" indicator light: illuminated).
3. Drive at the desired speed, above approximately 40 km/h (25 mph).
4. Press the "COAST/SET" switch.
5. Check to be sure that when the "COAST/SET" switch is released the speed is the constant speed.

NOTE: If the vehicle speed decreases to approximately 15 km/h (9 mph) below the set speed because of climbing a hill for example, it is normal for the cruise control to be cancelled. When the vehicle speed becomes low-speed limit [approximately 40 km/h (25 mph)] or less, driving at constant speed will be cancelled even if the vehicle speed does not decrease 15 km/h (9 mph) or more.

SPEED-INCREASE SETTING

1. Start the engine.
2. Press the "ON/OFF" switch (cruise control system: ON, "CRUISE" indicator light: illuminated).
3. Set to the desired speed, above approximately 40 km/h (25 mph).
4. Press the "ACC/RES" switch.
5. Check to be sure that acceleration continues while the "ACC/RES" switch is pressed, and that the speed at the time it was released becomes the constant driving speed.

NOTE: Acceleration can be continued even if the vehicle speed has passed the high-speed limit [approximately 160 km/h (100 mph)]. But the constant driving speed when the "ACC/RES" switch is released will be recorded as the high-speed limit.




SPEED-REDUCTION SETTING

1. Start the engine.
2. Press the "ON/OFF" switch (cruise control system: ON, "CRUISE" indicator light: illuminated).
3. Set to the desired speed, above approximately 40 km/h (25 mph).
4. Press the "COAST/SET" switch.
5. Check to be sure that deceleration continues while the "COAST/SET" switch is pressed, and that the speed at the time it was released becomes the constant driving speed.

NOTE: When the vehicle speed reaches the low limit [approximately 40 km/h (25 mph)] during deceleration, the cruise control will be cancelled.

RETURN TO THE SET SPEED BEFORE CANCELLATION AND CRUISE CONTROL CANCELLATION

1. Start the engine.
2. Press the "ON/OFF" switch (cruise control system: ON, "CRUISE" indicator light: illuminated).
3. Set to the desired speed, above approximately 40 km/h (25 mph).
4. When any of the following operations are performed while at constant speed during cruise control, check if normal driving is resumed and deceleration occurs.




- (1) The "CANCEL" switch is pressed.
- (2) The brake pedal is depressed.
5. At a vehicle speed of approximately 40 km/h (25 mph) or higher, check if when the "ACC/RES" switch is pressed, the vehicle speed returns to the speed before cruise control driving was cancelled, and constant speed driving occurs.
6. When the "ON/OFF" switch is pressed again (cruise control system: OFF) while driving at constant speed, check if normal driving is resumed and deceleration occurs.

CRUISE CONTROL SYSTEM COMPONENT CHECK

M1172001701847

CRUISE CONTROL SWITCH CHECK



1. Remove the cruise control switch (Refer to [P.17-65.](#).)
2. Measure the resistance between terminal number 2 and terminal number 3 when each of the "ON/OFF", "CANCEL", "COAST/SET" and "ACC/RES" switches is pressed. If the values measured at the time each switch is pressed correspond to those in the table below, the resistance values are correct.

Terminal connector of tester	Switch position	Specified condition
2 – 3	All switches are released.	Open circuit
	"ON/OFF" switch is pressed	Continuity (less than 2 ohms)
	"CANCEL" switch is pressed	202.5 - 208 Ω
	"COAST/SET" switch is pressed	610.5 - 624.5 Ω
	"ACC/RES" switch is pressed	1838 - 1877 Ω

3. Check that the cruise control switch illuminates when a positive battery terminal is connected to the connector terminal number 4, and terminal number 1 is grounded.

STOPLIGHT SWITCH CHECK

Refer to GROUP 35A, Brake Pedal, Inspection – Stoplight Switch Check [P.35A-27](#).

TRANSMISSION RANGE SWITCH CHECK

Refer to GROUP 23A, On-vehicle Service – Essential Service [P.23A-138](#) <2.4L Engine>.

Refer to GROUP 23C, On-vehicle Service – Essential Service [P.23C-269](#) <3.0L Engine>.

**THROTTLE ACTUATOR CONTROL MOTOR
CHECK**

Refer to GROUP 13A, On-vehicle Service – Throttle Actuator Control Motor Check [P.13A-877](#) <2.4L Engine>.


Refer to GROUP 13B, On-vehicle Service – Throttle Actuator Control Motor Check [P.13B-895](#) <3.0L Engine>.

CRUISE CONTROL SWITCH**REMOVAL AND INSTALLATION**

M1172007600953

WARNING

Before removing the driver's air bag module assembly, refer to GROUP 52B, Service Precautions [P.52B-25](#) and Driver's Air Bag Module and Clock Spring [P.52B-439](#).



AC707853AC

Removal steps

1. Driver's air bag module (Refer to GROUP 52B, Air Bag Modules and Clock Spring [P.52B-439](#)).
2. Cruise control switch

EMISSION CONTROL <MFI>

GENERAL INFORMATION

M1173000101061

The emission control system consists of the following subsystems:

- Positive crankcase ventilation system
- Evaporative emission system
- Exhaust emission control system

SERVICE SPECIFICATIONS

M1173000301270

Item	Standard value
Emission control system	
EGR valve (Stepper Motor) connector resistance [at 20°C (68°F)] Ω	20 – 24
Evaporative emission purge solenoid coil resistance [at 20°C (68°F)] Ω	22 – 26
Evaporative emission ventilation solenoid coil resistance [at 20°C (68°F)] Ω	17 – 21
Purge flow cm^3/s (SCFH) [at 80 – 95°C (176 – 205°F) with sudden revving]	20 (2.5)



DIAGNOSIS

M1173000700220

SYMPTOM	PROBABLE CAUSE	REMEDY
Engine will not start or hard to start	Vacuum hose disconnected or damaged	Repair or replace
	The EGR valve (Stepper Motor) is not closed.	Repair or replace
	Malfunction of the evaporative emission purge solenoid	Repair or replace
Rough idle or engine stalls	The EGR valve (Stepper Motor) is not closed.	Repair or replace
	Vacuum hose disconnected or damaged.	Repair or replace
	Malfunction of the positive crankcase ventilation valve	Replace
	Malfunction of the purge control system	Check the system; If there is a problem, check its component parts.
Engine hesitates or poor acceleration	Malfunction of the exhaust gas recirculation system	Check the system; If there is a problem, check its component parts.
Excessive oil consumption	Positive crankcase ventilation line clogged	Check positive crankcase ventilation system
Poor fuel mileage	Malfunction of the exhaust gas recirculation system	Check the system; If there is a problem, check its component parts.

SPECIAL TOOLS

M1173000600900


Tool	Tool number and name	Supersession	Application
	MB995061 Purge flow indicator	MLR6890A Part of MIT280220	Inspection of purge control system
	MB991658 Test harness set	Tool not available	Inspection of EGR valve (Stepper Motor)

VACUUM HOSES

VACUUM HOSE ROUTING


M1173000902123

<2.4L Engine>



AKA00467 AB

<3.0L Engine>




AK900405 AB

VACUUM CIRCUIT DIAGRAM


M1173007101404

<2.4L Engine>



AK800610 AB

<3.0 Engine>



AK900406 AB

VACUUM HOSE INSTALLATION

M1173007200408

1. When connecting the vacuum hoses, they should be securely inserted onto the nipples.
2. Connect the hoses correctly, using the VACUUM HOSE ROUTING diagram as a guide.

VACUUM HOSE CHECK

M1173007300728

1. Using the VACUUM HOSE ROUTING diagram as a guide, check that the vacuum hoses are correctly connected.
2. Check the connection condition of the vacuum hoses which can be removed, loosened, clogged possibly. And then check whether there are no folded and damaged vacuum hoses.

POSITIVE CRANKCASE VENTILATION SYSTEM

GENERAL INFORMATION (POSITIVE CRANKCASE VENTILATION SYSTEM)

M1173005001207

The positive crankcase ventilation (PCV) system prevents the escape of blow-by gases from inside the crankcase into the atmosphere.

Fresh air is sent from the air cleaner into the crankcase through the breather hose to be mixed with the blow-by gas inside the crankcase.


The blow-by gas inside the crankcase is drawn into the intake manifold through the PCV valve.

The PCV valve is designed to lift the plunger according to the intake manifold vacuum so as to regulate the flow of blow-by gas properly.

In other words, the blow-by gas flow is regulated during low load engine operation to maintain engine stability, while the flow is increased during high load operation to improve the ventilation performance.


SYSTEM DIAGRAM

<2.4L Engine>



AK604161 AB



<3.0L Engine>



AK700056 AB

COMPONENT LOCATION


M1173007400844



POSITIVE CRANKCASE VENTILATION (PCV)
SYSTEM CHECK


M1173001101149

1. Remove the ventilation hose from the positive crankcase ventilation (PCV) valve.
2. Remove the PCV valve from the rocker cover.
3. Reinstall the PCV valve at the ventilation hose.
4. Start the engine and run at idle.
5. Place a finger at the opening of the PCV valve and check that vacuum of the intake manifold is felt.
NOTE: At this moment, the plunger in the PCV valve moves back and forth.
6. If vacuum is not felt, clean the PCV valve or replace it.
7. Apply a small amount of new engine oil to the O-ring on the PCV valve, and tighten to the specified torque.

Specified torque: $2.5 \pm 0.4 \text{ N}\cdot\text{m}$ ($22 \pm 3 \text{ in-lb}$)POSITIVE CRANKCASE VENTILATION (PCV)
SYSTEM CHECK

M1173001201049

1. Remove the ventilation hose from the positive crankcase ventilation (PCV) valve.
2. Remove the PCV valve from the rocker cover.
3. Hold the PCV valve with the vacuum side down. Insert a thin rod, and using light pressure, depress the end of the PCV valve spring by 5 – 10 mm (0.2 – 0.3 inch). Release pressure on the rod to see if the PCV valve spring will lift the rod to its original position.
4. If the rod returns quickly to its original position, the PCV valve is OK. If the stick does not return quickly, clean or replace the PCV valve.
5. Apply a small amount of new engine oil to the O-ring on the PCV valve, and tighten to the specified torque.

Specified torque: $2.5 \pm 0.4 \text{ N}\cdot\text{m}$ ($22 \pm 3 \text{ in-lb}$)

EVAPORATIVE EMISSION CONTROL SYSTEM

GENERAL INFORMATION (EVAPORATIVE EMISSION SYSTEM)

M1173005101947

The evaporative emission (EVAP) system prevents fuel vapors generated in the fuel tank from escaping into the atmosphere.

Fuel vapors from the fuel tank flow through the vapor pipe/hose to be stored temporarily in the EVAP canister.


When the vehicle is in operation, fuel vapors stored in the EVAP canister flow through the EVAP purge solenoid, purge port and intake manifold plenum to the combustion chamber.

When the engine coolant temperature is low or when the intake air quantity is small (when the engine is at idle, for example), the engine control module (ECM) brings the EVAP purge solenoid into the OFF state to shut off the fuel vapor flow to the intake manifold plenum. This ensures driveability when the engine is cold or running under low load and also stabilizes the emission level.

An EVAP ventilation solenoid is provided between the EVAP canister and atmosphere to monitor for OBD-II EVAP leaks. This solenoid is normally OFF. However, it turns ON when monitoring the OBD-II EVAP leaks and shuts off the atmosphere flow to the EVAP canister. Then the fuel tank differential pressure sensor monitors the fuel vapor pressure to detect OBD-II EVAP leaks.

When the fuel tank inner pressure increases due to the fuel supply, air is released to the atmosphere from the fuel tank through the EVAP canister and air filter. When the inner pressure of the fuel tank decreases, air is supplied to the fuel tank through the air filter and EVAP canister.



SYSTEM DIAGRAM




AKA00468 AB

COMPONENT LOCATION


M1173007501048





PURGE CONTROL SYSTEM CHECK (PURGE FLOW CHECK)

M1173001401593



Required Special Tool:

MB995061: Purge Flow Indicator

1. Disconnect the purge hose from the evaporative emission (EVAP) purge solenoid, and connect special tool MB995061 between the EVAP purge solenoid and the purge hose.
2. Before inspection, set the vehicle in the following conditions:
 - Engine coolant temperature: 80 – 95°C (176 – 203°F)
 - Lights, electric cooling fan and accessories: OFF
 - Transaxle: P range

NOTE: Vehicles for Canada, the headlight, taillight, etc. remain lit even when the lighting switch is in "OFF" position but this is no problem for checks.

3. Run the engine at idle for more than four minutes.
4. Check the purge flow volume when engine is revved suddenly several times.


Standard value: Momentarily 20 cm³/s (2.5 SCFH) or more.

5. If the purge flow volume is less than the standard value, check it again with the vacuum hose disconnected from the EVAP canister. If the purge flow volume is less than the standard value, check the vacuum port and the vacuum hose for clogging. Also check the EVAP purge solenoid. If the purge flow volume is at the standard value, replace the EVAP canister.


EVAPORATIVE EMISSION PURGE SOLENOID CHECK

M1173001701044

1. Disconnect the vacuum hose from the evaporative emission (EVAP) purge solenoid.
2. Disconnect the harness connector.
3. Connect a hand vacuum pump to nipple (A) of the EVAP purge solenoid (refer to the illustration at left).
4. As described in the chart below, check airtightness by applying a vacuum with voltage applied directly from the battery to the EVAP purge solenoid valve and without applying voltage.



BATTERY POSITIVE VOLTAGE	NORMAL CONDITION
Applied	Vacuum leaks
Not applied	Vacuum maintained



5. Measure the resistance between the terminals of the EVAP purge solenoid.
- Standard value: 22 – 26 Ω [at 20°C (68°F)]**
6. Replace the solenoid if resistance is out of specification.

MASS AIRFLOW SENSOR CHECK

M1173050400224

<2.4L Engine>

To inspect these parts, refer to GROUP 13A, Multiport Fuel Injection (MFI) <2.4L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13A-49](#).

<3.0L Engine>

To inspect these parts, refer to GROUP 13B, Multiport Fuel Injection (MFI) <3.0L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13B-50](#).

BAROMETRIC PRESSURE SENSOR CHECK

M1173008000377

<2.4L Engine>

To inspect the sensor, refer to GROUP 13A, Multiport Fuel Injection (MFI) <2.4L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13A-49](#).

<3.0L Engine>

To inspect the sensor, refer to GROUP 13B, Multiport Fuel Injection (MFI) <3.0L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13B-50](#).

ENGINE COOLANT TEMPERATURE SENSOR CHECK

M1173008100783

<2.4L Engine>

To inspect the sensor, refer to GROUP 13A, Multiport Fuel Injection (MFI) <2.4L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13A-49](#).

<3.0L Engine>

To inspect the sensor, refer to GROUP 13B, Multiport Fuel Injection (MFI) <3.0L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13B-50](#).

INTAKE AIR TEMPERATURE SENSOR CHECK

M1173008200423

<2.4L Engine>

To inspect the sensor, refer to GROUP 13A, Multiport Fuel Injection (MFI) <2.4L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13A-49](#).

<3.0L Engine>

To inspect the sensor, refer to GROUP 13B, Multiport Fuel Injection (MFI) <3.0L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13B-50](#).

FUEL TANK DIFFERENTIAL PRESSURE SENSOR
CHECK

M1173007700317

To inspect the sensor, refer to GROUP 13C, Fuel Supply – Fuel Tank – Fuel Tank Inspection – Fuel Tank Differential Pressure Sensor Check [P.13C-27](#).

EVAPORATIVE EMISSION VENTILATION
SOLENOID CHECK

M1173007800273

Refer to Emission Control – Evaporative Emission Canister and Fuel Tank Pressure Relief Valve – Inspection – Evaporative Emission Ventilation Solenoid Check [P.17-88](#).

EXHAUST GAS RECIRCULATION (EGR) SYSTEM

GENERAL INFORMATION (EXHAUST GAS RECIRCULATION SYSTEM)

M1173005201085


The exhaust gas recirculation system (EGR) lowers the nitrogen oxides (NOx) emission level. When the air/fuel mixture combustion temperature is high, a large quantity of NOx is generated in the combustion chamber. Therefore, this system recirculates part of exhaust gas from the exhaust port of the cylinder head to the combustion chamber through the intake manifold to decrease the air/fuel mixture combustion temperature, resulting in reduction of NOx. The EGR flow rate is controlled by the EGR valve (Stepper Motor) for driveability quality.

OPERATION

When the engine coolant temperature is low, when the engine is at idle or when a wide open throttle operation is performed, the EGR valve (Stepper Motor) is kept closed, achieving no EGR. After warming up the engine, the EGR valve (Stepper Motor) can be opened by the engine control module (ECM). The ECM monitors the EGR system and illuminates the Malfunction Indicator Lamp (SERVICE ENGINE SOON or Check Engine Lamp) to indicate that there is a malfunction.


SYSTEM DIAGRAM

<2.4L Engine>



AK502987AE



<3.0L Engine>



AK700125AB

COMPONENT LOCATION

M1173007600688



EGR VALVE (STEPPER MOTOR) CHECK

M1173050200576

Required Special Tool:
MB991658: Test Harness Set

Checking the Operation Sound

1. Check that the operation sound of the stepper motor can be heard from the EGR valve when the ignition switch is turned ON (without starting the engine).
2. If the operation sound cannot be heard, inspect the drive circuit of the stepper motor.

NOTE: If the operation sound is not heard, and the circuit is normal, either the stepper motor or the ECM may have failed.

Checking the Coil Resistance





1. Remove the EGR valve.
2. Measure the resistance between terminal No. 2 and either terminal No. 1 or terminal No. 3 of the connector at the EGR valve.

Standard value: 20 – 24 Ω [at 20°C (68°F)]

3. If the resistance is not within the standard, replace the EGR valve.
4. Measure the resistance between terminal No. 5 and either terminal No. 6 or terminal No. 4 of the connector at the EGR valve.

Standard value: 20 – 24 Ω [at 20°C (68°F)]

5. If the resistance is not within the standard, replace the EGR valve.




3. Connect the battery positive (+) terminal to terminal No. 2.

CAUTION

Connecting battery voltage to the EGR valve for a long time could damage the coil.

4. Connect terminals 1 and 3 to the negative (-) terminal of the battery, in order to test whether the stepper motor vibrates (with a slight shudder), indicating that the stepper motor is operating.



5. Connect the battery positive (+) terminal to terminal No. 5.

CAUTION

Connecting battery voltage to the EGR valve for a long time could damage the coil.

6. Connect terminals 4 and 6 to the negative (-) terminal of the battery, in order to test whether the stepper motor vibrates (with a slight shudder), indicating that the stepper motor is operating.
7. If vibrations can be felt as a result of the test, the stepper motor is determined to be normal.

MASS AIRFLOW SENSOR CHECK

M1173050400235

<2.4L Engine>

To inspect these parts, refer to GROUP 13A, Multiport Fuel Injection (MFI) <2.4L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13A-49](#).

<3.0L Engine>

To inspect these parts, refer to GROUP 13B, Multiport Fuel Injection (MFI) <3.0L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13B-50](#).

ENGINE COOLANT TEMPERATURE SENSOR CHECK

M1173008100794

<2.4L Engine>

To inspect the sensor, refer to GROUP 13A, Multiport Fuel Injection (MFI) <2.4L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13A-49](#).

<3.0L Engine>

To inspect the sensor, refer to GROUP 13B, Multiport Fuel Injection (MFI) <3.0L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13B-50](#).

CRANKSHAFT POSITION SENSOR CHECK

M1173008300420

<2.4L Engine>

To inspect the sensor, refer to GROUP 13A, Multiport Fuel Injection (MFI) <2.4L Engine> Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13A-49](#).

<3.0L Engine>

To inspect the sensor, refer to GROUP 13B, Multiport Fuel Injection (MFI) <3.0L Engine> – Multiport Fuel Injection (MFI) Diagnosis – Diagnostic Trouble Code Chart [P.13B-50](#).

REMOVAL AND INSTALLATION <2.4L ENGINE>


M1173010501145

Pre-removal Operation

- Engine Coolant Draining (Refer to GROUP 14, On-vehicle Service – Engine Coolant Change [P.14-26](#)).
- Air Cleaner Intake Hose and Air Cleaner Assembly Removal (Refer to GROUP 15, Air Cleaner <2.4L Engine>[P.15-4](#)).
- Oil Filler Tube Assembly Removal (Refer to GROUP 23A, Transaxle Assembly [P.23A-152](#)).

Post-installation Operation

- Oil Filler Tube Assembly Installation (Refer to GROUP 23A, Transaxle Assembly [P.23A-152](#)).
- Air Cleaner Intake Hose and Air Cleaner Assembly Installation (Refer to GROUP 15, Air Cleaner <2.4L Engine>[P.15-4](#)).
- Engine Coolant Refilling (Refer to GROUP 14, On-vehicle Service – Engine Coolant Change [P.14-26](#)).



AC605404AC

Removal steps

1. EGR valve connector connection
2. EGR valve
- >>B<< 3. EGR valve gasket
- >>A<< 4. EGR valve pipe
- >>A<< 5. EGR pipe gasket
- >>A<< 6. EGR pipe gasket
7. Water hose connection
- >>A<< 8. EGR support stay A




Removal steps (Continued)

- >>A<< 9. EGR support stay B
- >>A<< 10. Throttle body assembly (Refer to GROUP 13A, Throttle Body Assembly [P.13A-885](#))
- >>A<< 11. EGR pipe gasket
- >>A<< 12. EGR inlet pipe

INSTALLATION SERVICE POINTS

>>A<< EGR PIPE GASKET/EGR VALVE SUPPORT/EGR SUPPORT STAY B/EGR SUPPORT STAY A/ EGR PIPE GASKET/EGR VALVE PIPE INSTALLATION


1. Temporarily tighten each part so that the protrusion of each gasket is positioned as illustrated



2. Tighten mounting bolts to the specified torque in the order of number shown in the figure.

Tightening torque: $20 \pm 2 \text{ N}\cdot\text{m} (15 \pm 1 \text{ ft-lb})$

>>B<< EGR VALVE GASKET INSTALLATION



Install the EGR valve gasket so that its shaded portion is set as shown in the figure.

REMOVAL AND INSTALLATION <3.0L ENGINE>


M1173010501305

Pre-removal Operation

- Engine Coolant Draining (Refer to GROUP 14, On-vehicle Service – Engine Coolant Change [P.14-26](#)).
- Air Cleaner Intake Hose and Air Cleaner Assembly Removal (Refer to GROUP 15, Air Cleaner <3.0L Engine>[P.15-5](#)).

Post-installation Operation

- Air Cleaner Intake Hose and Air Cleaner Assembly Installation (Refer to GROUP 15, Air Cleaner <3.0L Engine>[P.15-5](#)).
- Engine Coolant Refilling (Refer to GROUP 14, On-vehicle Service – Engine Coolant Change [P.14-26](#)).



AC704202AB

Removal steps

1. EGR valve connector connection
2. Water hose
3. Water hose


Removal steps (Continued)

4. EGR valve
- >>A<< 5. EGR valve gasket

INSTALLATION SERVICE POINT

>>A<< EGR VALVE GASKET INSTALLATION


Install the EGR valve gasket as shown in the illustration.



EVAPORATIVE EMISSION CANISTER AND FUEL TANK PRESSURE RELIEF VALVE

REMOVAL AND INSTALLATION

M1173004800605



AC704203AB

Removal steps

1. Evaporative emission canister protector
2. Evaporative emission ventilation solenoid connector connection
3. Fuel vapor tube assembly
4. Fuel purge pipe assembly connection
5. Vent hose A connection

Removal steps (Continued)

6. Evaporative emission canister and bracket assembly
7. Evaporative emission canister bracket
8. Evaporative emission canister and evaporative emission ventilation solenoid assembly

Removal steps (Continued)




9. Vent hose A
10. Vent hose B connection
11. Air filter
12. Air filter bracket
 - Rear axle driveshaft (LH) <AWD>
(Refer to GROUP 27B, DriveShaft Assembly [P.27B-23](#))
13. Vent hose B
14. Vent pipe

INSPECTION

M1173004900260

EVAPORATIVE EMISSION VENTILATION SOLENOID CHECK

1. Connect a hand vacuum pump to nipple (A) of the evaporative emission canister and evaporative emission ventilation solenoid assembly.
2. Connect a plug to nipple (B) of the evaporative emission canister and evaporative emission ventilation solenoid assembly.



3. Check air tightness by applying a vacuum with voltage applied directly from the battery to the evaporative emission ventilation solenoid and without applying voltage.

Battery voltage	Normal condition
Applied	Vacuum maintained
Not applied	Vacuum leaks

4. Measure the resistance between the terminals of the solenoid.

Standard value: 17 – 21 Ω [at 20°C (68°F)]

CATALYTIC CONVERTER

REMOVAL AND INSTALLATION

- The catalytic converter is integrated with the center exhaust pipe. The removal and installation is the same as the center exhaust pipe (Refer to GROUP 15, Exhaust Pipe and Main Muffler [P.15-22](#)) <2.4L Engine>.
- The catalytic converter is integrated with the exhaust manifold and center exhaust pipe. The removal and installation is the same as the exhaust manifold and center exhaust pipe (Refer to GROUP 15, Exhaust Manifold [P.15-18](#)) and (Refer to GROUP 15, Exhaust Pipe and Main Muffler [P.15-25](#)) <3.0L Engine>.

M1173003901840

NOTES