

# ENGINE CONTROL SYSTEM

## SECTION EC

### CONTENTS

<b>TRUBLE DIAGNOSIS - INDEX</b> .....	7	Two Trip Detection Logic .....	44
Alphabetical & P No. Index for DTC .....	7	Emission-related Diagnostic Information .....	45
<b>PRECAUTIONS</b> .....	14	NVIS (Nissan Vehicle Immobilizer System -	
Supplemental Restraint System (SRS) "AIR		NATS) .....	60
BAG" and "SEAT BELT PRE-TENSIONER" .....	14	Malfunction Indicator (MI) .....	60
Precautions for On Board Diagnostic (OBD)		OBD System Operation Chart (Models with Euro-	
System of Engine .....	14	OBD System) .....	64
Engine Fuel & Emission Control System .....	15	CONSULT-II .....	70
Precautions .....	16	Generic Scan Tool (GST) .....	84
Wiring Diagrams and Trouble Diagnosis .....	17	<b>TRUBLE DIAGNOSIS - INTRODUCTION</b> .....	86
<b>PREPARATION</b> .....	18	Introduction .....	86
Special Service Tools .....	18	Work Flow .....	88
Commercial Service Tools .....	18	<b>TRUBLE DIAGNOSIS - BASIC INSPECTION</b> .....	90
<b>ENGINE AND EMISSION CONTROL OVERALL</b>		Basic Inspection .....	90
<b>SYSTEM</b> .....	20	<b>TRUBLE DIAGNOSIS - GENERAL</b>	
Engine Control Component Parts Location .....	20	<b>DESCRIPTION</b> .....	103
Circuit Diagram .....	24	DTC Inspection Priority Chart .....	103
System Diagram .....	25	Fail-safe Chart .....	104
Vacuum Hose Drawing .....	26	Symptom Matrix Chart .....	105
System Chart .....	27	CONSULT-II Reference Value in Data Monitor	
<b>ENGINE AND EMISSION BASIC CONTROL</b>		Mode .....	109
<b>SYSTEM DESCRIPTION</b> .....	28	Major Sensor Reference Graph in Data Monitor	
Multiport Fuel Injection (MFI) System .....	28	Mode .....	111
Electronic Ignition (EI) System .....	30	ECM Terminals and Reference Value .....	114
Air Conditioning Cut Control .....	31	<b>TRUBLE DIAGNOSIS - SPECIFICATION VALUE</b> ..	122
Fuel Cut Control (at no load & high engine		Description .....	122
speed) .....	32	Testing Condition .....	122
Evaporative Emission System .....	32	Inspection Procedure .....	122
Positive Crankcase Ventilation .....	35	Diagnostic Procedure .....	123
<b>BASIC SERVICE PROCEDURE</b> .....	36	<b>TRUBLE DIAGNOSIS FOR INTERMITTENT</b>	
Fuel Pressure Release .....	36	<b>INCIDENT</b> .....	126
Fuel Pressure Check .....	37	Description .....	126
Fuel Pressure Regulator Check .....	37	Diagnostic Procedure .....	126
Injector .....	38	<b>TRUBLE DIAGNOSIS FOR POWER SUPPLY</b> .....	127
How to Check Idle Speed and Ignition Timing .....	40	Main Power Supply and Ground Circuit .....	127
Idle Air Volume Learning .....	41	<b>DTC P0100 MASS AIR FLOW SENSOR (MAFS)</b> .....	134
<b>ON BOARD DIAGNOSTIC SYSTEM</b>		Component Description .....	134
<b>DESCRIPTION</b> .....	44	CONSULT-II Reference Value in Data Monitor	
Introduction .....	44	Mode .....	134

# CONTENTS (Cont'd)

On Board Diagnosis Logic.....	134	<b>DTC P0132 (BANK 1), P0152 (BANK 2) HO2S1 (FRONT) (RICH SHIFT MONITORING)</b> .....	176
Possible Cause.....	135	Component Description .....	176
DTC Confirmation Procedure .....	135	CONSULT-II Reference Value in Data Monitor Mode .....	176
Wiring Diagram .....	137	On Board Diagnosis Logic.....	176
Diagnostic Procedure .....	138	Possible Cause.....	177
<b>DTC P0110 INTAKE AIR TEMPERATURE SENSOR</b> .....	141	DTC Confirmation Procedure .....	177
Component Description .....	141	Overall Function Check .....	178
On Board Diagnosis Logic.....	141	Diagnostic Procedure .....	178
Possible Cause.....	141	<b>DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)</b> .....	184
DTC Confirmation Procedure .....	141	Component Description .....	184
Wiring Diagram .....	143	CONSULT-II Reference Value in Data Monitor Mode .....	184
Diagnostic Procedure .....	144	On Board Diagnosis Logic.....	184
<b>DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)</b> .....	146	Possible Cause.....	185
Component Description .....	146	DTC Confirmation Procedure .....	185
On Board Diagnosis Logic.....	146	Overall Function Check .....	186
Possible Cause.....	147	Wiring Diagram .....	187
DTC Confirmation Procedure .....	147	Diagnostic Procedure .....	189
Wiring Diagram .....	148	<b>DTC P0134 (BANK 1), P0154 (BANK 2) HO2S1 (FRONT) (HIGH VOLTAGE)</b> .....	197
Diagnostic Procedure .....	149	Component Description .....	197
<b>DTC P0120 THROTTLE POSITION SENSOR</b> .....	151	CONSULT-II Reference Value in Data Monitor Mode .....	197
Description .....	151	On Board Diagnosis Logic.....	197
CONSULT-II Reference Value in Data Monitor Mode .....	151	Possible Cause.....	198
On Board Diagnosis Logic.....	152	DTC Confirmation Procedure .....	198
Possible Cause.....	152	Wiring Diagram .....	199
DTC Confirmation Procedure .....	152	Diagnostic Procedure .....	201
Wiring Diagram .....	154	<b>DTC P0135 (BANK 1), P0155 (BANK 2) HO2S1 HEATER (FRONT)</b> .....	205
Diagnostic Procedure .....	155	Description .....	205
<b>DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)</b> .....	158	CONSULT-II Reference Value in Data Monitor Mode .....	205
Component Description .....	158	On Board Diagnosis Logic.....	205
CONSULT-II Reference Value in Data Monitor Mode .....	158	Possible Cause.....	205
On Board Diagnosis Logic.....	158	DTC Confirmation Procedure .....	206
Possible Cause.....	159	Wiring Diagram .....	207
DTC Confirmation Procedure .....	159	Diagnostic Procedure .....	209
Overall Function Check .....	160	<b>DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)</b> .....	212
Wiring Diagram .....	161	Component Description .....	212
Diagnostic Procedure .....	163	CONSULT-II Reference Value in Data Monitor Mode .....	212
<b>DTC P0131 (BANK 1), P0151 (BANK 2) HO2S1 (FRONT) (LEAN SHIFT MONITORING)</b> .....	168	On Board Diagnosis Logic.....	212
Component Description .....	168	Possible Cause.....	213
CONSULT-II Reference Value in Data Monitor Mode .....	168	DTC Confirmation Procedure .....	213
On Board Diagnosis Logic.....	168	Overall Function Check .....	214
Possible Cause.....	169	Wiring Diagram .....	216
DTC Confirmation Procedure .....	169	Diagnostic Procedure .....	218
Overall Function Check .....	170		
Diagnostic Procedure .....	170		

# CONTENTS (Cont'd)

<b>DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)</b> .....	223
Component Description .....	223
CONSULT-II Reference Value in Data Monitor .....	
Mode .....	223
On Board Diagnosis Logic.....	223
Possible Cause.....	224
DTC Confirmation Procedure .....	224
Overall Function Check .....	225
Wiring Diagram.....	227
Diagnostic Procedure .....	229
<b>DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)</b> .....	234
Component Description .....	234
CONSULT-II Reference Value in Data Monitor .....	
Mode .....	234
On Board Diagnosis Logic.....	234
Possible Cause.....	235
DTC Confirmation Procedure .....	235
Overall Function Check .....	236
Wiring Diagram.....	238
Diagnostic Procedure .....	240
<b>DTC P0140 (BANK 1), P0160 (BANK 2) HO2S2 (REAR) (HIGH VOLTAGE)</b> .....	245
Component Description .....	245
CONSULT-II Reference Value in Data Monitor .....	
Mode .....	245
On Board Diagnosis Logic.....	245
Possible Cause.....	246
DTC Confirmation Procedure .....	246
Overall Function Check .....	246
Wiring Diagram.....	248
Diagnostic Procedure .....	250
<b>DTC P0141 (BANK 1), P0161 (BANK 2) HO2S2 HEATER (REAR)</b> .....	254
Description .....	254
CONSULT-II Reference Value in Data Monitor .....	
Mode .....	254
On Board Diagnosis Logic.....	254
Possible Cause.....	254
DTC Confirmation Procedure .....	255
Wiring Diagram.....	256
Diagnostic Procedure .....	258
<b>DTC P0171 (BANK 1), P0174 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (LEAN)</b> .....	261
On Board Diagnosis Logic.....	261
Possible Cause.....	261
DTC Confirmation Procedure .....	261
Wiring Diagram.....	263
Diagnostic Procedure .....	265
<b>DTC P0172 (BANK 1), P0175 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (RICH)</b> .....	269
On Board Diagnosis Logic.....	269
Possible Cause.....	269
DTC Confirmation Procedure .....	269
Wiring Diagram.....	271
Diagnostic Procedure .....	273
<b>DTC P0180 FUEL TANK TEMPERATURE SENSOR</b> .....	276
Component Description .....	276
On Board Diagnosis Logic.....	276
Possible Cause.....	276
DTC Confirmation Procedure .....	277
Wiring Diagram.....	278
Diagnostic Procedure .....	279
<b>DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE</b> .....	281
On Board Diagnosis Logic.....	281
Possible Cause.....	281
DTC Confirmation Procedure .....	282
Diagnostic Procedure .....	282
<b>DTC P0325 KNOCK SENSOR (KS)</b> .....	289
Component Description .....	289
On Board Diagnosis Logic.....	289
Possible Cause.....	289
DTC Confirmation Procedure .....	289
Wiring Diagram.....	291
Diagnostic Procedure .....	292
<b>DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (POS)</b> .....	295
Component Description .....	295
CONSULT-II Reference Value in Data Monitor .....	
Mode .....	295
On Board Diagnosis Logic.....	295
Possible Cause.....	295
DTC Confirmation Procedure .....	296
Wiring Diagram.....	297
Diagnostic Procedure .....	298
<b>DTC P0340 CAMSHAFT POSITION SENSOR (CMPS) (PHASE)</b> .....	303
Component Description .....	303
On Board Diagnosis Logic.....	303
Possible Cause.....	303
DTC Confirmation Procedure .....	303
Wiring Diagram.....	305
Diagnostic Procedure .....	306
<b>DTC P0420 (BANK 1), P0430 (BANK 2) THREE WAY CATALYST FUNCTION</b> .....	309
On Board Diagnosis Logic.....	309
Possible Cause.....	309
DTC Confirmation Procedure .....	310
Overall Function Check .....	310
Diagnostic Procedure .....	311

# CONTENTS (Cont'd)

<b>DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)</b> .....	314	DTC Confirmation Procedure .....	345
Description .....	314	Wiring Diagram .....	347
CONSULT-II Reference Value in Data Monitor		Diagnostic Procedure .....	348
Mode .....	314	<b>DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)</b> .....	351
On Board Diagnosis Logic.....	315	System Description.....	351
Possible Cause.....	315	CONSULT-II Reference Value in Data Monitor	
DTC Confirmation Procedure .....	315	Mode .....	352
Wiring Diagram .....	316	On Board Diagnosis Logic.....	352
Diagnostic Procedure .....	317	Possible Cause.....	353
<b>DTC P0500 VEHICLE SPEED SENSOR (VSS)</b> .....	320	Overall Function Check .....	353
Component Description .....	320	Wiring Diagram .....	355
On Board Diagnosis Logic.....	320	Diagnostic Procedure .....	357
Possible Cause.....	320	Main 12 Causes of Overheating.....	368
DTC Confirmation Procedure .....	320	<b>DTC P1320 IGNITION SIGNAL</b> .....	369
Overall Function Check .....	321	Component Description .....	369
Wiring Diagram .....	322	On Board Diagnosis Logic.....	369
Diagnostic Procedure .....	323	Possible Cause.....	369
<b>DTC P0505 IDLE AIR CONTROL VALVE (IACV) - AUXILIARY AIR CONTROL (AAC) VALVE</b> .....	324	DTC Confirmation Procedure .....	369
Description .....	324	Wiring Diagram .....	371
CONSULT-II Reference Value in Data Monitor		Diagnostic Procedure .....	374
Mode .....	325	<b>DTC P1335 CRANKSHAFT POSITION SENSOR (CKPS) (REF)</b> .....	380
On Board Diagnosis Logic.....	325	Component Description .....	380
Possible Cause.....	325	CONSULT-II Reference Value in Data Monitor	
DTC Confirmation Procedure .....	325	Mode .....	380
Wiring Diagram .....	327	On Board Diagnosis Logic.....	380
Diagnostic Procedure .....	328	Possible Cause.....	381
<b>DTC P0510 CLOSED THROTTLE POSITION SWITCH</b> .....	333	DTC Confirmation Procedure .....	381
Component Description .....	333	Wiring Diagram .....	383
CONSULT-II Reference Value in Data Monitor		Diagnostic Procedure .....	384
Mode .....	333	<b>DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (POS) (COG)</b> .....	387
On Board Diagnosis Logic.....	333	Component Description .....	387
Possible Cause.....	333	CONSULT-II Reference Value in Data Monitor	
DTC Confirmation Procedure .....	334	Mode .....	387
Overall Function Check .....	334	On Board Diagnosis Logic.....	387
Wiring Diagram .....	336	Possible Cause.....	387
Diagnostic Procedure .....	337	DTC Confirmation Procedure .....	388
<b>DTC P0605 ECM</b> .....	341	Wiring Diagram .....	389
Component Description .....	341	Diagnostic Procedure .....	390
On Board Diagnosis Logic.....	341	<b>DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE</b> .....	395
Possible Cause.....	341	Component Description .....	395
DTC Confirmation Procedure .....	341	On Board Diagnosis Logic.....	395
Diagnostic Procedure .....	342	Possible Cause.....	395
<b>DTC P1131 SWIRL CONTROL VALVE CONTROL SOLENOID VALVE</b> .....	344	DTC Confirmation Procedure .....	395
Description .....	344	Wiring Diagram .....	396
CONSULT-II Reference Value in Data Monitor		Diagnostic Procedure .....	397
Mode .....	345	<b>DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH</b> .....	398
On Board Diagnosis Logic.....	345	Component Description .....	398
Possible Cause.....	345		

# CONTENTS (Cont'd)

CONSULT-II Reference Value in Data Monitor	
Mode .....	398
On Board Diagnosis Logic.....	398
Possible Cause.....	398
DTC Confirmation Procedure .....	398
Overall Function Check .....	399
Wiring Diagram.....	400
Diagnostic Procedure .....	401
<b>ABSOLUTE PRESSURE SENSOR</b> .....	404
Component Description .....	404
Wiring Diagram.....	405
Diagnostic Procedure .....	406
<b>INTAKE AIR TEMPERATURE SENSOR</b> .....	410
Component Description .....	410
Wiring Diagram.....	411
Diagnostic Procedure .....	412
<b>HEATED OXYGEN SENSOR 1 (FRONT)</b> .....	415
Component Description .....	415
CONSULT-II Reference Value in Data Monitor	
Mode .....	415
Wiring Diagram.....	416
Diagnostic Procedure .....	418
<b>HEATED OXYGEN SENSOR 1 HEATER (FRONT)</b> .....	424
Description .....	424
CONSULT-II Reference Value in Data Monitor	
Mode .....	424
Wiring Diagram.....	425
Diagnostic Procedure .....	427
<b>HEATED OXYGEN SENSOR 2 (REAR)</b> .....	431
Component Description .....	431
CONSULT-II Reference Value in Data Monitor	
Mode .....	431
Wiring Diagram.....	432
Diagnostic Procedure .....	434
<b>HEATED OXYGEN SENSOR 2 HEATER (REAR)</b> .....	440
Description .....	440
CONSULT-II Reference Value in Data Monitor	
Mode .....	440
Wiring Diagram.....	441
Diagnostic Procedure .....	443
<b>FUEL TANK TEMPERATURE SENSOR</b> .....	447
Component Description .....	447
Wiring Diagram.....	448
Diagnostic Procedure .....	449
<b>CRANKSHAFT POSITION SENSOR (CKPS)</b>	
<b>(POS)</b> .....	451
Component Description .....	451
CONSULT-II Reference Value in Data Monitor	
Mode .....	451
Wiring Diagram.....	452
Diagnostic Procedure .....	453
<b>EVAP CANISTER PURGE VOLUME CONTROL</b>	
<b>SOLENOID VALVE</b> .....	459
Description .....	459
CONSULT-II Reference Value in Data Monitor	
Mode .....	459
Wiring Diagram .....	460
Diagnostic Procedure .....	461
<b>VEHICLE SPEED SENSOR (VSS)</b> .....	465
Component Description .....	465
Wiring Diagram .....	466
Diagnostic Procedure .....	467
<b>IDLE AIR CONTROL VALVE (IACV) - AUXILIARY</b>	
<b>AIR CONTROL (AAC) VALVE</b> .....	469
Description .....	469
CONSULT-II Reference Value in Data Monitor	
Mode .....	470
Wiring Diagram .....	471
Diagnostic Procedure .....	472
<b>CLOSED THROTTLE POSITION SWITCH</b> .....	477
Component Description .....	477
Wiring Diagram .....	478
Diagnostic Procedure .....	479
<b>A/T COMMUNICATION LINE</b> .....	482
System Description.....	482
Wiring Diagram .....	483
Diagnostic Procedure .....	484
<b>SWIRL CONTROL VALVE CONTROL SOLENOID</b>	
<b>VALVE</b> .....	486
Description .....	486
CONSULT-II Reference Value in Data Monitor	
Mode .....	487
Wiring Diagram .....	488
Diagnostic Procedure .....	489
<b>IGNITION SIGNAL</b> .....	495
Component Description .....	495
Wiring Diagram .....	496
Diagnostic Procedure .....	499
<b>A/T DIAGNOSIS COMMUNICATION LINE</b> .....	506
Component Description .....	506
Wiring Diagram .....	507
Diagnostic Procedure .....	508
<b>PARK/NEUTRAL POSITION (PNP) SWITCH</b> .....	510
Component Description .....	510
CONSULT-II Reference Value in Data Monitor	
Mode .....	510
Wiring Diagram .....	511
Diagnostic Procedure .....	512
<b>VARIABLE INDUCTION AIR CONTROL SYSTEM</b>	
<b>(VIAS)</b> .....	517
Description .....	517
Wiring Diagram .....	519
Diagnostic Procedure .....	520

# CONTENTS (Cont'd)

<b>INJECTOR</b> .....	523	Wiring Diagram .....	544
Component Description .....	523	Diagnostic Procedure .....	545
CONSULT-II Reference Value in Data Monitor		<b>REFRIGERANT PRESSURE SENSOR</b> .....	548
Mode .....	523	Description .....	548
Wiring Diagram .....	524	Wiring Diagram .....	549
Diagnostic Procedure .....	525	Diagnostic Procedure .....	550
<b>START SIGNAL</b> .....	529	<b>ELECTRICAL LOAD SIGNAL</b> .....	552
CONSULT-II Reference Value in Data Monitor		Wiring Diagram .....	552
Mode .....	529	Diagnostic Procedure .....	554
Wiring Diagram .....	530	<b>MI &amp; DATA LINK CONNECTORS</b> .....	558
Diagnostic Procedure .....	531	Wiring Diagram .....	558
<b>FUEL PUMP</b> .....	533	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	559
System Description .....	533	Fuel Pressure Regulator .....	559
Component Description .....	533	Idle Speed and Ignition Timing .....	559
CONSULT-II Reference Value in Data Monitor		Mass Air Flow Sensor .....	559
Mode .....	533	Engine Coolant Temperature Sensor .....	559
Wiring Diagram .....	534	Heated Oxygen Sensor 1 Heater (front) .....	559
Diagnostic Procedure .....	535	Fuel Pump .....	559
<b>ELECTRONIC CONTROLLED ENGINE MOUNT</b> .....	539	IACV-AAC Valve .....	559
System Description .....	539	Injector .....	559
CONSULT-II Reference Value in Data Monitor		Resistor .....	559
Mode .....	539	Throttle Position Sensor .....	560
Wiring Diagram .....	540	Calculated Load Value .....	560
Diagnostic Procedure .....	541	Intake Air Temperature Sensor .....	560
<b>POWER STEERING OIL PRESSURE SWITCH</b> .....	543	Heated Oxygen Sensor 2 Heater (rear) .....	560
Component Description .....	543	Crankshaft Position Sensor (REF) .....	560
CONSULT-II Reference Value in Data Monitor		Fuel Tank Temperature Sensor .....	560
Mode .....	543	Camshaft Position Sensor (PHASE) .....	560

# TROUBLE DIAGNOSIS — INDEX

*Alphabetical & P No. Index for DTC*

## Alphabetical & P No. Index for DTC

NFEC0001

Check if the vehicle is a model with Euro-OBD (E-OBD) system or not by the "Type approval number" on the identification plate. Refer to GI-40, "IDENTIFICATION PLATE".

Type approval number	Model
Available	With Euro-OBD system
Not available (blank).	Without Euro-OBD system

### MODELS WITH EURO-OBD SYSTEM

NFEC0001S03

#### Alphabetical Index for DTC

NFEC0001S0301

Items (CONSULT-II screen terms)	DTC*1	Reference page
Unable to access ECM	—	EC-104
AIR TEMP SEN/CIRC	P0110	EC-141
A/T 1ST GR FNCTN	P0731	AT-144
A/T 2ND GR FNCTN	P0732	AT-150
A/T 3RD GR FNCTN	P0733	AT-156
A/T 4TH GR FNCTN	P0734	AT-162
A/T DIAG COMM LINE	P1605	EC-395
ATF TEMP SEN/CIRC	P0710	AT-128
CMP SEN/CIRCUIT	P0340	EC-303
CLOSED TP SW/CIRC	P0510	EC-333
COOLANT T SEN/CIRC*3	P0115	EC-146
CKP SENSOR (COG)	P1336	EC-387
CKP SEN/CIRCUIT	P0335	EC-295
CKP SEN (REF)/CIRC	P1335	EC-380
CYL 1 MISFIRE	P0301	EC-281
CYL 2 MISFIRE	P0302	EC-281
CYL 3 MISFIRE	P0303	EC-281
CYL 4 MISFIRE	P0304	EC-281
CYL 5 MISFIRE	P0305	EC-281
CYL 6 MISFIRE	P0306	EC-281
ECM	P0605	EC-341
ENGINE SPEED SIG	P0725	AT-139
ENG OVER TEMP	P1217	EC-351
FUEL SYS-LEAN/BK1	P0171	EC-261
FUEL SYS-LEAN/BK2	P0174	EC-261
FUEL SYS-RICH/BK1	P0172	EC-269
FUEL SYS-RICH/BK2	P0175	EC-269
FUEL TEMP SEN/CIRC	P0180	EC-276
HO2S1 (B1)	P0130	EC-158
HO2S1 (B1)	P0131	EC-168

## TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC (Cont'd)

Items (CONSULT-II screen terms)	DTC*1	Reference page
HO2S1 (B1)	P0132	EC-176
HO2S1 (B1)	P0133	EC-184
HO2S1 (B1)	P0134	EC-197
HO2S1 (B2)	P0150	EC-158
HO2S1 (B2)	P0151	EC-168
HO2S1 (B2)	P0152	EC-176
HO2S1 (B2)	P0153	EC-184
HO2S1 (B2)	P0154	EC-197
HO2S1 HTR (B1)	P0135	EC-205
HO2S1 HTR (B2)	P0155	EC-205
HO2S2 (B1)	P0137	EC-212
HO2S2 (B1)	P0138	EC-223
HO2S2 (B1)	P0139	EC-234
HO2S2 (B1)	P0140	EC-245
HO2S2 (B2)	P0157	EC-212
HO2S2 (B2)	P0158	EC-223
HO2S2 (B2)	P0159	EC-234
HO2S2 (B2)	P0160	EC-245
HO2S2 HTR (B1)	P0141	EC-254
HO2S2 HTR (B2)	P0161	EC-254
IACV/AAC VLV/CIRC	P0505	EC-324
KNOCK SEN/CIRC-B1	P0325	EC-289
L/PRES SOL/CIRC	P0745	AT-176
MAF SEN/CIRCUIT*3	P0100	EC-134
MULTI CYL MISFIRE	P0300	EC-281
NATS MALFUNCTION	P1610 - P1615*2	EL-291
<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	<b>P0000</b>	—
O/R CLTCH SOL/CIRC	P1760	AT-201
P-N POS SW/CIRCUIT	P1706	EC-398
PNP SW/CIRC	P0705	AT-122
PURG VOLUME CONT/V	P0443	EC-314
SFT SOL A/CIRC*3	P0750	AT-182
SFT SOL B/CIRC*3	P0755	AT-187
SWIRL CONT SOL/V	P1131	EC-344
TCC SOLENOID/CIRC	P0740	AT-171
TP SEN/CIRC A/T*3	P1705	AT-192

# TROUBLE DIAGNOSIS — INDEX

*Alphabetical & P No. Index for DTC (Cont'd)*

Items (CONSULT-II screen terms)	DTC*1	Reference page
TRTL POS SEN/CIRC*3	P0120	EC-151
TW CATALYST SYS-B1	P0420	EC-309
TW CATALYST SYS-B2	P0430	EC-309
VEH SPEED SEN/CIRC*4	P0500	EC-320
VEH SPD SEN/CIR A/T*4	P0720	AT-134

\*1: 1st trip DTC No. is the same as DTC No.

\*2: This DTC is displayed with CONSULT-II only.

\*3: When the fail-safe operation occurs, the MI illuminates.

\*4: The MI illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

**NOTE:**

Regarding A33 models, "-B1" and "BK1" indicate bank 1 and "-B2" and "BK2" indicate bank 2.

## P No. Index for DTC

NFEC0001S0302

DTC*1	Items (CONSULT-II screen terms)	Reference page
—	Unable to access ECM	EC-104
<b>P0000</b>	<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	—
P0100	MAF SEN/CIRCUIT*3	EC-134
P0110	AIR TEMP SEN/CIRC	EC-141
P0115	COOLANT T SEN/CIRC*3	EC-146
P0120	THRTL POS SEN/CIRC*3	EC-151
P0130	HO2S1 (B1)	EC-158
P0131	HO2S1 (B1)	EC-168
P0132	HO2S1 (B1)	EC-176
P0133	HO2S1 (B1)	EC-184
P0134	HO2S1 (B1)	EC-197
P0135	HO2S1 HTR (B1)	EC-205
P0137	HO2S2 (B1)	EC-212
P0138	HO2S2 (B1)	EC-223
P0139	HO2S2 (B1)	EC-234
P0140	HO2S2 (B1)	EC-245
P0141	HO2S2 HTR (B1)	EC-254
P0150	HO2S1 (B2)	EC-158
P0151	HO2S1 (B2)	EC-168
P0152	HO2S1 (B2)	EC-176
P0153	HO2S1 (B2)	EC-184
P0154	HO2S1 (B2)	EC-197
P0155	HO2S1 HTR (B2)	EC-205
P0157	HO2S2 (B2)	EC-212

## TROUBLE DIAGNOSIS — INDEX

*Alphabetical & P No. Index for DTC (Cont'd)*

DTC*1	Items (CONSULT-II screen terms)	Reference page
P0158	HO2S2 (B2)	EC-223
P0159	HO2S2 (B2)	EC-234
P0160	HO2S2 (B2)	EC-245
P0161	HO2S2 HTR (B2)	EC-254
P0171	FUEL SYS-LEAN/BK1	EC-261
P0172	FUEL SYS-RICH/BK1	EC-269
P0174	FUEL SYS-LEAN/BK2	EC-261
P0175	FUEL SYS-RICH/BK2	EC-269
P0180	FUEL TEMP SEN/CIRC	EC-276
P0300	MULTI CYL MISFIRE	EC-281
P0301	CYL 1 MISFIRE	EC-281
P0302	CYL 2 MISFIRE	EC-281
P0303	CYL 3 MISFIRE	EC-281
P0304	CYL 4 MISFIRE	EC-281
P0305	CYL 5 MISFIRE	EC-281
P0306	CYL 6 MISFIRE	EC-281
P0325	KNOCK SEN/CIRC-B1	EC-289
P0335	CKP SEN/CIRCUIT	EC-295
P0340	CMP SEN/CIRCUIT	EC-303
P0420	TW CATALYST SYS-B1	EC-309
P0430	TW CATALYST SYS-B2	EC-309
P0443	PURG VOLUME CONT/V	EC-314
P0500	VEH SPEED SEN/CIRC*4	EC-320
P0505	IACV/AAC VLV/CIRC	EC-324
P0510	CLOSED TP SW/CIRC	EC-333
P0605	ECM	EC-341
P0705	PNP SW/CIRC	AT-122
P0710	ATF TEMP SEN/CIRC	AT-128
P0720	VEH SPD SEN/CIR A/T*4	AT-134
P0725	ENGINE SPEED SIG	AT-139
P0731	A/T 1ST GR FNCTN	AT-144
P0732	A/T 2ND GR FNCTN	AT-150
P0733	A/T 3RD GR FNCTN	AT-156
P0734	A/T 4TH GR FNCTN	AT-162
P0740	TCC SOLENOID/CIRC	AT-171
P0745	L/PRESS SOL/CIRC	AT-176
P0750	SFT SOL A/CIRC*3	AT-182

## TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC (Cont'd)

DTC*1	Items (CONSULT-II screen terms)	Reference page
P0755	SFT SOL B/CIRC*3	AT-187
P1131	SWIRL CONT SOL/V	EC-344
P1217	ENG OVER TEMP	EC-351
P1335	CKP SEN (REF)/CIRC	EC-380
P1336	CKP SENSOR (COG)	EC-387
P1605	A/T DIAG COMM LINE	EC-395
P1610 - P1615*2	NATS MALFUNCTION	EL-291
P1705	TP SEN/CIRC A/T*3	AT-192
P1706	P-N POS SW/CIRCUIT	EC-398
P1760	O/R CLTCH SOL/CIRC	AT-201

\*1: 1st trip DTC No. is the same as DTC No.

\*2: This DTC is displayed with CONSULT-II only.

\*3: When the fail-safe operation occurs, the MI illuminates.

\*4: The MI illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

**NOTE:**

Regarding A33 models, "-B1" and "BK1" indicate bank 1 and "-B2" and "BK2" indicate bank 2.

## TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC (Cont'd)

### MODELS WITHOUT EURO-OBD SYSTEM

=NFEC0001S04

#### Alphabetical Index for DTC

NFEC0001S0401

X: Applicable    —: Not applicable

Items (CONSULT-II screen terms)	DTC		Reference page
	CONSULT-II	ECM*1	
Unable to access ECM	—	—	EC-104
CMP SEN/CIRCUIT	P0340	0340	EC-303
COOLANT T SEN/CIRC	P0115	0115	EC-146
CKP SENSOR (COG)	P1336	1336	EC-387
CKP SEN (REF) CIRC	P1335	1335	EC-380
ECM	P0605	0605	EC-341
ENG OVER TEMP	P1217	1217	EC-351
HO2S1 (B1)	P0130	0130	EC-158
IGN SIGNAL-PRIMARY	P1320	1320	EC-369
KNOCK SEN/CIRC-B1	P0325	0325	EC-289
MAF SEN/CIRCUIT	P0100	0100	EC-134
NATS MALFUNCTION	P1610 - P1615	—	EL-291
<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	<b>P0000</b>	<b>0000</b>	—
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	No DTC	Flashing*2	EC-61
THRTL POS SEN/CIRC	P0120	0120	EC-151

**NOTE:**

Regarding A33 models, “-B1” indicates bank 1 and “-B2” indicates bank 2.

\*1: In Diagnostic Test Mode II (Self-diagnostic results).

\*2: While engine is running.

#### P No. Index for DTC

NFEC0001S0402

X: Applicable    —: Not applicable

DTC		Items (CONSULT-II screen terms)	Reference page
CONSULT-II	ECM*1		
—	—	Unable to access ECM	EC-104
No DTC	Flashing*2	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	EC-61
<b>P0000</b>	<b>0000</b>	<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	—
P0100	0100	MAF SEN/CIRCUIT	EC-134
P0115	0115	COOLANT T SEN/CIRC	EC-146
P0120	0120	THRTL POS SEN/CIRC	EC-151
P0130	0130	HO2S1 (B1)	EC-158
P0325	0325	KNOCK SEN/CIRC-B1	EC-289

## TROUBLE DIAGNOSIS — INDEX

*Alphabetical & P No. Index for DTC (Cont'd)*

DTC		Items (CONSULT-II screen terms)	Reference page
CONSULT-II	ECM*1		
P0340	0340	CMP SEN/CIRCUIT	EC-303
P0605	0605	ECM	EC-341
P1217	1217	ENG OVER TEMP	EC-351
P1320	1320	IGN SIGNAL-PRIMARY	EC-369
P1335	1335	CKP SEN (REF)/CIRC	EC-380
P1336	1336	CKP SENSOR (COG)	EC-387
P1610 - P1615	—	NATS MALFUNCTION	EL-291

**NOTE:**

Regarding A33 models, “-B1” indicates bank 1 and “-B2” indicates bank 2.

\*1: In Diagnostic Test Mode II (Self-diagnostic results).

\*2: While engine is running.

## PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

### Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NFEC0871

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL A33 is as follows (The composition varies according to the destination and optional equipment.):

- For a frontal collision  
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision  
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

#### WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified with yellow harness connector (and with yellow harness protector or yellow insulation tape before the harness connectors).

### Precautions for On Board Diagnostic (OBD) System of Engine

NFEC0003

The ECM has an on board diagnostic system. It will light up the malfunction indicator (MI) to warn the driver of a malfunction causing emission deterioration.

#### CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MI to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MI to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to EL section, "Description", "HARNES CONNECTOR".
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MI to light up due to the short circuit.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM before returning the vehicle to the customer.

# PRECAUTIONS

## Engine Fuel & Emission Control System

NFEC0004

### BATTERY


- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

### ECM

- Do not disassemble ECM.
- Do not turn diagnosis mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value.  
The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

### WIRELESS EQUIPMENT

- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
  - 1) Keep the antenna as far away as possible from the ECM.
  - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls.  
Do not let them run parallel for a long distance.
  - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
  - 4) Be sure to ground the radio to vehicle body.



### ENGINE CONTROL PARTS HANDLING

- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor or crankshaft position sensor.



### WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.

### FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.






### ECM HARNESS HANDLING

- Securely connect ECM harness connectors.  
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in) away from adjacent harnesses to prevent an ECM system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.

SEF242XC

## PRECAUTIONS

### Precautions




### Precautions

NFEC0005


- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- When connecting ECM harness connector, fasten it securely with a lever as far as it will go as shown at left.
- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Before replacing ECM, perform “ECM Terminals and Reference Value” inspection and make sure ECM functions properly. Refer to EC-114.
- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure” or “Overall Function Check”. The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.

## PRECAUTIONS

Precautions (Cont'd)



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



- Regarding model A33, "Bank 1 (B1)" indicates cylinders number 1, 3, 5 and "Bank 2 (B2)" indicates cylinders number 2, 4, 6 as shown in the figure.

## Wiring Diagrams and Trouble Diagnosis

NFEC0006

When you read Wiring diagrams, refer to the following:

- GI-11, "HOW TO READ WIRING DIAGRAMS"
- EL-9, "POWER SUPPLY ROUTING" for power distribution circuit

When you perform trouble diagnosis, refer to the following:



- GI-32, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"
- GI-21, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT"

## PREPARATION

Special Service Tools




### Special Service Tools

NFEC0007

Tool number Tool name	Description
KV10117100 Heated oxygen sensor 1 (front) wrench Heated oxygen sensor 2 (rear) wrench	 <p style="text-align: right;">Loosening or tightening front and heated oxygen sensor 2 (rear)s with 22 mm (0.87 in) hexagon nut</p> <p style="text-align: left;">NT379</p>
KV10117600 Fuel pressure check adapter	 <p style="text-align: right;">Checking fuel pressure with pressure gauge</p> <p style="text-align: left;">NT777</p>


### Commercial Service Tools

NFEC0008

Tool name	Description
Fuel filler cap adapter	 <p style="text-align: right;">Checking fuel tank vacuum relief valve opening pressure</p> <p style="text-align: left;">NT653</p>
Socket wrench	 <p style="text-align: center;"> <span style="display: inline-block; text-align: center;">   <b>19 mm</b>                      (0.75 in)                 </span> <span style="display: inline-block; text-align: center; margin-left: 20px;">   <b>More than</b>  <b>32 mm</b>                      (1.26 in)                 </span> </p> <p style="text-align: right;">Removing and installing engine coolant temperature sensor</p> <p style="text-align: left;">NT705</p>
Oxygen sensor thread cleaner	 <p style="text-align: right;">                     Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown below.  <b>a: 18 mm dia. with pitch 1.5 mm for Zirconia Oxygen Sensor</b>  <b>b: 12 mm dia. with pitch 1.25 mm for Titania Oxygen Sensor</b> </p> <p style="text-align: left;">NT778</p>

# PREPARATION

Commercial Service Tools (Cont'd)


Tool name	Description
Anti-seize lubricant (Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)	 <p data-bbox="933 268 1428 324">Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.</p> <p data-bbox="391 515 454 537">NT779</p>

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Engine Control Component Parts Location

## Engine Control Component Parts Location







NFEC0009



SEC121C

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM







Engine Control Component Parts Location (Cont'd)



SEF981X

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM




Engine Control Component Parts Location (Cont'd)



SEC122C

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Engine Control Component Parts Location (Cont'd)




SEF982X

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Circuit Diagram

## Circuit Diagram

NFC0010




MEC211D

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Diagram

## System Diagram

NFEC0011




SEC123C

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Vacuum Hose Drawing

## Vacuum Hose Drawing

NFEC0012



**NOTE:**

Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

SEC124C

Refer to "System Diagram", EC-25 for Vacuum Control System.

# ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Chart

## System Chart

NFEC0013

Input (Sensor)	ECM Function	Output (Actuator)
<ul style="list-style-type: none"> <li>● Camshaft position sensor (PHASE)</li> <li>● Crankshaft position sensor (REF)</li> <li>● Mass air flow sensor</li> <li>● Engine coolant temperature sensor</li> <li>● Heated oxygen sensor 1 (front)</li> <li>● Ignition switch</li> <li>● Throttle position sensor</li> <li>● Closed throttle position switch *3</li> <li>● Park/neutral position (PNP) switch</li> <li>● Air conditioner switch</li> <li>● Knock sensor</li> <li>● Intake air temperature sensor</li> <li>● Absolute pressure sensor</li> <li>● Battery voltage</li> <li>● Power steering oil pressure switch</li> <li>● Vehicle speed sensor</li> <li>● Fuel tank temperature sensor *1</li> <li>● Crankshaft position sensor (POS)</li> <li>● Heated oxygen sensor 2 (rear) *2</li> <li>● TCM (Transmission control module)</li> <li>● Refrigerant pressure sensor</li> <li>● Electrical load</li> </ul>	Fuel injection & mixture ratio control	Injectors
	Electronic ignition system	Power transistor
	Idle air control system	IACV-AAC valve
	Fuel pump control	Fuel pump relay
	On board diagnostic system	MI (On the instrument panel)
	Swirl control valve control	Swirl control valve control solenoid valve
	Power valve control	VIAS control solenoid valve
	Heated oxygen sensor 1 heater (front) control	Heated oxygen sensor 1 heater (front)
	Heated oxygen sensor 2 heater (rear) control	Heated oxygen sensor 2 heater (rear)
	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
	Air conditioning cut control	Air conditioner relay
	Cooling fan control	Cooling fan relays

\*1: These sensors are not used to control the engine system.

\*2: This sensor is not used to control the engine system under normal conditions.

\*3: This switch will operate in place of the throttle position sensor if the sensor malfunctions.

# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System

## Multiport Fuel Injection (MFI) System

### DESCRIPTION

#### Input/Output Signal Chart

NFEC0014

NFEC0014S01

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed (POS signal)	Fuel injection & mixture ratio control	Injectors
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Camshaft position sensor (PHASE)	Piston position		
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Heated oxygen sensor 1 (front)	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position Throttle valve idle position		
Park/neutral position (PNP) switch	Gear position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Air conditioner switch	Air conditioner operation		
Knock sensor	Engine knocking condition		
Battery	Battery voltage		
Absolute pressure sensor	Ambient air barometric pressure		
Power steering oil pressure switch	Power steering operation		
Heated oxygen sensor 2 (rear)*1	Density of oxygen in exhaust gas		

\*1: Under normal conditions, this sensor is not for engine control operation.

### Basic Multiport Fuel Injection System

NFEC0014S02

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the crankshaft position sensor and the mass air flow sensor.

### Various Fuel Injection Increase/Decrease Compensation

NFEC0014S03

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.

#### <Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from "N" to "D"
- High-load, high-speed operation

#### <Fuel decrease>


- During deceleration
- During high engine speed operation

# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System (Cont'd)

## Mixture Ratio Feedback Control (Closed loop control)

NFEC0014S04



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (Manifold) can then better reduce CO, HC and NOx emissions. This system uses a heated oxygen sensor 1 (front) in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about the heated oxygen sensor 1 (front), refer to EC-158. This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 (rear) is located downstream of the three way catalyst (Manifold). Even if the switching characteristics of the heated oxygen sensor 1 (front) shift, the air-fuel ratio is controlled to stoichiometric by the signal from the heated oxygen sensor 2 (rear).

## Open Loop Control

NFEC0014S05

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of heated oxygen sensor 1 (front) or its circuit
- Insufficient activation of heated oxygen sensor 1 (front) at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from "N" to "D"
- When starting the engine

## Mixture Ratio Self-learning Control

NFEC0014S06

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the heated oxygen sensor 1 (front). This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot film) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the heated oxygen sensor 1 (front) indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.


"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System (Cont'd)

## Fuel Injection Timing

NFEC0014S07



Two types of systems are used.

### Sequential Multiport Fuel Injection System

NFEC0014S0701

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

### Simultaneous Multiport Fuel Injection System

NFEC0014S0702

Fuel is injected simultaneously into all six cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The six injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

### Fuel Shut-off

NFEC0014S08

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

## Electronic Ignition (EI) System

### DESCRIPTION

NFEC0015

### Input/Output Signal Chart

NFEC0015S01


Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed (POS signal)	Ignition timing control	Power transistor
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Camshaft position sensor (PHASE)	Piston position		
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position Throttle valve idle position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage		

# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Electronic Ignition (EI) System (Cont'd)

## System Description

NFEC0015S02



The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

e.g., N: 1,800 rpm, Tp: 1.50 msec  
A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

## Air Conditioning Cut Control

### DESCRIPTION

NFEC0016

### Input/Output Signal Chart

NFEC0016S01

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Throttle position sensor	Throttle valve opening angle		
Crankshaft position sensor (POS)	Engine speed (POS signal)		
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Vehicle speed sensor	Vehicle speed		
Refrigerant pressure sensor	Refrigerant pressure		
Power steering oil pressure switch	Power steering operation		

## System Description

NFEC0016S02

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.

# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Air Conditioning Cut Control (Cont'd)

- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.
- When refrigerant pressure is excessively low or high.

## Fuel Cut Control (at no load & high engine speed)

### DESCRIPTION

#### Input/Output Signal Chart

NFEC0017

NFEC0017S01

Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed sensor	Vehicle speed	Fuel cut control	Injectors
Park/neutral position (PNP) switch	Neutral position		
Throttle position sensor	Throttle position		
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (POS)	Engine speed (POS signal)		
Crankshaft position sensor (REF)	Engine speed (REF signal)		

If the engine speed is above 1,800 rpm with no load (for example, in neutral and engine speed over 1,800 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.


#### NOTE:

This function is different from deceleration control listed under “Multiport Fuel Injection (MFI) System”, EC-28.

## Evaporative Emission System

### DESCRIPTION

NFEC0018



SEF988X


The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank. The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine

# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Evaporative Emission System (Cont'd)

operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases.

EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.



## INSPECTION


### EVAP Canister

NFEC0019

NFEC0019S01

Check EVAP canister as follows:

1. Block port B. Blow air through port A orally. Check that air flows freely through port C with check valve resistance.
2. Block port A. Blow air through port B orally. Check that air flows freely through port C.



### Fuel Tank Vacuum Relief Valve (Built into fuel filler cap)

NFEC0019S03

1. Wipe clean valve housing.
2. Check valve opening pressure and vacuum.

#### Pressure:

15.3 - 20.0 kPa (0.1530 - 0.2001 bar, 0.156 - 0.204 kg/cm<sup>2</sup>, 2.22 - 2.90 psi)


#### Vacuum:

-6.0 to -3.4 kPa (-0.0598 to -0.0343 bar, -0.061 to -0.035 kg/cm<sup>2</sup>, -0.87 to -0.50 psi)

3. If out of specification, replace fuel filler cap as an assembly.

### CAUTION:

Use only a genuine fuel filler cap as a replacement.



### Evaporative Emission (EVAP) Canister Purge Volume Control Solenoid Valve

NFEC0019S05

Refer to EC-314 and EC-459.

### Fuel Tank Temperature Sensor

NFEC0019S06

Refer to EC-276 and EC-447.

### Checking EVAP Vapor Lines

NFEC0019S11


1. Visually inspect vapor lines for leaks, cracks, damage, loose connections, chafing and deterioration.
2. Inspect vacuum relief valve of fuel tank filler cap for clogging, sticking, etc. Refer to next page.

# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Evaporative Emission System (Cont'd)

## EVAPORATIVE EMISSION LINE DRAWING

NFEC0020




**NOTE:**

Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

SEC125C

# ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Positive Crankcase Ventilation



## Positive Crankcase Ventilation

### DESCRIPTION

NFEC0021

This system returns blow-by gas to the intake manifold.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.


During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.




### INSPECTION

NFEC0022

#### PCV (Positive Crankcase Ventilation) Valve

NFEC0022S01


With engine running at idle, remove PCV valve ventilation hose from PCV valve; if the valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.








#### PCV Valve Ventilation Hose

NFEC0022S02

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



# BASIC SERVICE PROCEDURE



## Fuel Pressure Release

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger. NFEC0023

### WITH CONSULT-II


NFEC0023S01

1. Turn ignition switch "ON".
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch "OFF".

### WITHOUT CONSULT-II

NFEC0023S02


1. Remove fuel pump fuse located in fuse box.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch "OFF".
5. Reinstall fuel pump fuse after servicing fuel system.



## Fuel Pressure Check

NFEC0024

- When reconnecting fuel line, always use new clamps.
  - Make sure that clamp screw does not contact adjacent parts.
  - Use a torque driver to tighten clamps.
  - Use Pressure Gauge to check fuel pressure.
  - Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
1. Release fuel pressure to zero.
  2. Disconnect tube joint between fuel pressure regulator and injector tube and set fuel pressure check adapter (J44321).



3. Install pressure gauge to the fuel pressure check adapter as shown in the figure.
4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge.

### At idling:


#### With vacuum hose connected

Approximately 235 kPa (2.35 bar, 2.4 kg/cm<sup>2</sup>, 34 psi)

#### With vacuum hose disconnected

Approximately 294 kPa (2.94 bar, 3.0 kg/cm<sup>2</sup>, 43 psi)

If results are unsatisfactory, perform Fuel Pressure Regulator Check.




## Fuel Pressure Regulator Check

NFEC0025

1. Stop engine and disconnect fuel pressure regulator vacuum hose from vacuum gallery.
2. Plug vacuum gallery with a blind cap.
3. Connect variable vacuum source to fuel pressure regulator.


## BASIC SERVICE PROCEDURE

### Fuel Pressure Regulator Check (Cont'd)



4. Start engine and read indication of fuel pressure gauge as vacuum is changed.

**Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.**




### Injector

#### REMOVAL AND INSTALLATION


NFEC0026

1. Release fuel pressure to zero.
2. Remove intake manifold collector. Refer to EM-18, "TIMING CHAIN".
3. Remove fuel tube assemblies in numerical sequence as shown in the figure at left.
4. Expand and remove clips securing fuel injectors.
5. Extract fuel injectors straight from fuel tubes.
  - **Be careful not to damage injector nozzles during removal.**
  - **Do not bump or drop fuel injectors.**
  - **Do not disassemble or adjust fuel injectors.**
6. Carefully install O-rings, including the one used with the pressure regulator.
  - **Lubricate O-rings with a smear of engine oil.**
  - **Be careful not to damage O-rings with service tools, finger nails or clips. Do not expand or twist O-rings. If stretched, do not insert them into fuel tubes immediately after stretching.**
  - **Discard old clips; replace with new ones.**
7. Position clips in grooves on fuel injectors.
  - **Make sure that protrusions of fuel injectors are aligned with cutouts of clips after installation.**




# BASIC SERVICE PROCEDURE

Injector (Cont'd)



8. Align protrusions of fuel tubes with those of fuel injectors. Insert fuel injectors straight into fuel tubes.
9. After properly inserting fuel injectors, check to make sure that fuel tube protrusions are engaged with those of fuel injectors, and that flanges of fuel tubes are engaged with clips.



10. Tighten fuel tube assembly mounting nuts in numerical sequence (indicated in the figure at left) and in two stages.

: Tightening torque N·m (kg-m, ft-lb)

1st stage:

9.3 - 10.8 (1.0 - 1.1, 6.9 - 7.9)

2nd stage:

20.6 - 26.5 (2.1 - 2.7, 16 - 19)


11. Install all parts removed in reverse order of removal.

**CAUTION:**

After properly connecting fuel tube assembly to injector and fuel hose, check connection for fuel leakage.

## BASIC SERVICE PROCEDURE

### How to Check Idle Speed and Ignition Timing



### How to Check Idle Speed and Ignition Timing


NFEC0607

#### IDLE SPEED

NFEC0607S01

- Using CONSULT-II

Check idle speed in "DATA MONITOR" mode with CONSULT-II.




#### IGNITION TIMING

NFEC0607S02

Any of following two methods may be used.


- Method A

- Attach timing light to loop wire as shown.
- Check ignition timing.




- Method B

- Remove No. 1 ignition coil.



- Connect No. 1 ignition coil and No. 1 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.
- Check ignition timing.






## BASIC SERVICE PROCEDURE

Idle Air Volume Learning (Cont'd)

3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic "PRE-CONDITIONING" (previously mentioned) are in good order.
5. Turn ignition switch "OFF" and wait at least 10 seconds.
6. Start the engine and let it idle for at least 30 seconds.
7. Select "IDLE AIR VOL LEARN" in "WORK SUPPORT" mode.
8. Touch "START" and wait 20 seconds.
9. Make sure that "CMPLT" is displayed on CONSULT-II screen. If "INCMP" is displayed, "Idle Air Volume Learning" will not be carried out successfully. In this case, find the cause of the problem by referring to the NOTE below.
10. Rev up the engine two or three times. Make sure that idle speed and ignition timing are within specifications.

ITEM	SPECIFICATION	
Idle speed	VQ20DE	M/T: 675±50 rpm A/T: 700±50 rpm (in "P" or "N" position)
	VQ30DE	M/T: 625±50 rpm A/T: 700±50 rpm (in "P" or "N" position)
Ignition timing	VQ20DE	M/T: 9°±5° BTDC A/T: 9°±5° BTDC (in "P" or "N" position)
	VQ30DE	M/T: 15°±5° BTDC A/T: 15°±5° BTDC (in "P" or "N" position)



### ⊗ Without CONSULT-II

NFEC0642S0302

1. Turn ignition switch "ON" and wait at least 1 second.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic "PRE-CONDITIONING" (previously mentioned) are in good order.
5. Turn ignition switch "OFF" and wait at least 10 seconds.
6. Start the engine and let it idle for at least 30 seconds.
7. Disconnect throttle position sensor harness connector (brown), then reconnect it within 5 seconds.
8. Wait 20 seconds.
9. Make sure that idle speed is within specifications. If not, the result will be incomplete. In this case, find the cause of the problem by referring to the NOTE below.
10. Rev up the engine two or three times. Make sure that idle speed and ignition timing are within specifications.

## BASIC SERVICE PROCEDURE

Idle Air Volume Learning (Cont'd)

ITEM	SPECIFICATION	
Idle speed	VQ20DE	M/T: 675±50 rpm A/T: 700±50 rpm (in "P" or "N" position)
	VQ30DE	M/T: 625±50 rpm A/T: 700±50 rpm (in "P" or "N" position)
Ignition timing	VQ20DE	M/T: 9°±5° BTDC A/T: 9°±5° BTDC (in "P" or "N" position)
	VQ30DE	M/T: 15°±5° BTDC A/T: 15°±5° BTDC (in "P" or "N" position)

### NOTE:

If idle air volume learning cannot be performed successfully, proceed as follows:

- 1) Check that throttle valve is fully closed.
- 2) Check PCV valve operation.
- 3) Check that downstream of throttle valve is free from air leakage.
- 4) Adjust closed throttle position switch and reset memory. (Refer to Basic Inspection, EC-90.)
- 5) When the above three items check out OK, engine component parts and their installation condition are questionable. Check and eliminate the cause of the problem. It is useful to perform "TROUBLE DIAGNOSIS — SPECIFICATION VALUE", EC-122.
- 6) If any of the following conditions occur after the engine has started, eliminate the cause of the problem and perform "Idle air volume learning" all over again:
  - Engine stalls.
  - Erroneous idle.
  - Blown fuses related to the IACV-AAC valve system.

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Introduction

## Introduction

NFEC0029

### MODELS WITH EURO-OBD SYSTEM

NFEC0029S02

The ECM has an on board diagnostic system which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Diagnostic Trouble Code (DTC)	Mode 3 of ISO 15031-5
Freeze Frame data	Mode 2 of ISO 15031-5
System Readiness Test (SRT) code	Mode 1 of ISO 15031-5
1st Trip Diagnostic Trouble Code (1st Trip DTC)	Mode 7 of ISO 15031-5
1st Trip Freeze Frame data	
Test values and Test limits	Mode 6 of ISO 15031-5
Calibration ID	Mode 9 of ISO 15031-5

The above information can be checked using procedures listed in the table below.

X: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	Test value
CONSULT-II	X	X	X	X	X	—
GST	X	X*1	X	—	X	X

\*1: 1st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

The malfunction indicator (MI) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to EC-104.)

### MODELS WITHOUT EURO-OBD SYSTEM

NFEC0029S01

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Diagnostic Trouble Code (DTC)
Freeze Frame data
1st Trip Diagnostic Trouble Code (1st Trip DTC)
1st Trip Freeze Frame data

The above information can be checked using procedures listed in the table below.

X: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data
CONSULT-II	X	X	X	X
ECM	X	X*1	—	—

\*1: When the DTC and the 1st trip DTC appear on the display simultaneously, it is difficult to clearly distinguish one from the other.

## Two Trip Detection Logic

NFEC0030

### MODELS WITH EURO-OBD SYSTEM

NFEC0030S01

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MI will not light up at this stage <1st trip>.

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MI lights up. The MI lights up at the same time when the DTC is stored <2nd trip>.

The “trip” in the “Two Trip Detection Logic” means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MI, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

*Two Trip Detection Logic (Cont'd)*

X: Applicable —: Not applicable

Items	MI				DTC		1st trip DTC	
	1st trip		2nd trip		1st trip displaying	2nd trip displaying	1st trip displaying	2nd trip displaying
	Blinking	Lighting up	Blinking	Lighting up				
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	X	—	—	—	—	—	X	—
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0306 is being detected	—	—	X	—	—	X	—	—
Fail-safe items (Refer to EC-104.)	—	X	—	—	X*1	—	X*1	—
Except above	—	—	—	X	—	X	X	—

\*1: Except "ECM".

## MODELS WITHOUT EURO-OBD SYSTEM

NFEC0030S02

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory. <2nd trip> The "trip" in the "Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation. When the ECM enters the fail-safe mode (Refer to EC-104), the DTC is stored in the ECM memory even in the 1st trip.

## Emission-related Diagnostic Information

NFEC0031

### MODELS WITH EURO-OBD SYSTEM

NFEC0031S09

#### DTC and 1st Trip DTC

NFEC0031S0901

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed. If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MI will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MI lights up. In other words, the DTC is stored in the ECM memory and the MI lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MI during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in "How to Erase Emission-related Diagnostic Information". Refer to EC-56.

For malfunctions in which 1st trip DTCs are displayed, refer to EC-54. These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-II.

1st trip DTC is specified in Mode 7 of ISO 15031-5. 1st trip DTC detection occurs without lighting up the MI and therefore does not warn the driver of a problem. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in "Work Flow" procedure Step II, refer to page EC-88. Then perform "DTC Confirmation Procedure" or "Overall Function Check" to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.

#### How to read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

 **With CONSULT-II**

 **With GST**

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

CONSULT-II or GST (Generic Scan Tool) Examples: P0340, P1320, P0705, P0750, etc.

These DTCs are prescribed by ISO 15031-6.

(CONSULT-II also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, Mode II and GST do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

DTC display	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">MAF SEN/CIRCUIT [P0100]</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="height: 20px;"></td> <td></td> </tr> </tbody> </table>	SELF DIAG RESULTS		DTC RESULTS	TIME	MAF SEN/CIRCUIT [P0100]	0			1st trip DTC display	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">MAF SEN/CIRCUIT [P0100]</td> <td style="text-align: center;">1t</td> </tr> <tr> <td style="height: 20px;"></td> <td></td> </tr> </tbody> </table>	SELF DIAG RESULTS		DTC RESULTS	TIME	MAF SEN/CIRCUIT [P0100]	1t		
	SELF DIAG RESULTS																		
	DTC RESULTS	TIME																	
	MAF SEN/CIRCUIT [P0100]	0																	
SELF DIAG RESULTS																			
DTC RESULTS	TIME																		
MAF SEN/CIRCUIT [P0100]	1t																		

SEF992X

### Freeze Frame Data and 1st Trip Freeze Frame Data

NFEC0031S0902

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, absolute throttle position, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For details, see EC-75.

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MI on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0306 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175
2		Except the above items (Includes A/T related items)
3	1st trip freeze frame data	

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in "How to Erase Emission-related Diagnostic Information". Refer to EC-56.

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

*Emission-related Diagnostic Information (Cont'd)*

## System Readiness Test (SRT) Code

NFEC0031S0903

System Readiness Test (SRT) code is specified in Mode 1 of ISO 15051-5.

As part of an emissions test for Inspection & Maintenance (I/M), certain states require the status of SRT be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "INCMP", use the information in this Service Manual to set the SRT to "CMPLT".

In most cases the ECM will automatically complete its self-diagnosis cycle during normal usage, and the SRT status will indicate "CMPLT" for each application system. Once set as "CMPLT", the SRT status remains "CMPLT" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern; the SRT will indicate "INCMP" for these items.

### NOTE:

The SRT will also indicate "INCMP" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "CMPLT" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "INCMP" for one or more of the SRT items the vehicle is returned to the customer untested.

### NOTE:

If MI is "ON" during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "CMPLT" for all test items. Therefore, it is important to check SRT ("CMPLT") and DTC (No DTCs) before the inspection.

## SRT Item

NFEC0031S0907

The table below shows required self-diagnostic items to set the SRT to "CMPLT".

SRT item (CONSULT-II indication)	Performance Priority*1	Required self-diagnostic items to set the SRT to "CMPLT"	Corresponding DTC No.
CATALYST	3	Three way catalyst function	P0420, P0430
HO2S	3	Heated oxygen sensor 1 (front) (circuit)	P0130, P0150
		Heated oxygen sensor 1 (front) (lean shift monitoring)	P0131, P0151
		Heated oxygen sensor 1 (front) (rich shift monitoring)	P0132, P0152
		Heated oxygen sensor 1 (front) (response monitoring)	P0133, P0153
		Heated oxygen sensor 1 (front) (high voltage)	P0134, P0154
		Heated oxygen sensor 2 (rear) (min. voltage monitoring)	P0137, P0157
		Heated oxygen sensor 2 (rear) (max. voltage monitoring)	P0138, P0158
		Heated oxygen sensor 2 (rear) (response monitoring)	P0139, P0159
HO2S HTR	3	Heated oxygen sensor 1 heater (front)	P0135, P0155
		Heated oxygen sensor 2 heater (rear)	P0141, P0161

\*1: If completion of several SRTs is required, perform driving patterns (DTC confirmation procedure), one by one based on the priority for models with CONSULT-II.

## SRT Set Timing

NFEC0031S0908

SRT is set as "CMPLT" after self-diagnosis has been performed one or more times. Completion of SRT is done regardless of whether the result is OK or NG. The set timing is different between OK and NG results and is shown in the table below.

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

Self-diagnosis result		Example						
		Diagnosis	Ignition cycle					
			← ON →	OFF	← ON →	OFF	← ON →	OFF
All OK	Case 1	P0400	OK (1)	— (1)	OK (2)	— (2)		
		P0402	OK (1)	— (1)	— (1)	OK (2)		
		P1402	OK (1)	OK (2)	— (2)	— (2)		
		SRT of EGR	“CMPLT”	“CMPLT”	“CMPLT”	“CMPLT”		
	Case 2	P0400	OK (1)	— (1)	— (1)	— (1)		
		P0402	— (0)	— (0)	OK (1)	— (1)		
		P1402	OK (1)	OK (2)	— (2)	— (2)		
		SRT of EGR	“INCMP”	“INCMP”	“CMPLT”	“CMPLT”		
NG exists	Case 3	P0400	OK	OK	—	—		
		P0402	—	—	—	—		
		P1402	NG	—	NG	NG (Consecutive NG)		
		(1st trip) DTC	1st trip DTC	—	1st trip DTC	DTC (= MI “ON”)		
		SRT of EGR	“INCMP”	“INCMP”	“INCMP”	“CMPLT”		

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is NG.

—: Self-diagnosis is not carried out.

When all SRT related self-diagnoses showed OK results in a single cycle (Ignition OFF-ON-OFF), the SRT will indicate “CMPLT”. → Case 1 above

When all SRT related self-diagnoses showed OK results through several different cycles, the SRT will indicate “CMPLT” at the time the respective self-diagnoses have at least one OK result. → Case 2 above

If one or more SRT related self-diagnoses showed NG results in 2 consecutive cycles, the SRT will also indicate “CMPLT”. → Case 3 above

The table above shows that the minimum number of cycles for setting SRT as “INCMP” is one (1) for each self-diagnosis (Case 1 & 2) or two (2) for one of self-diagnoses (Case 3). However, in preparation for the state emissions inspection, it is unnecessary of each self-diagnosis to be executed twice (Case 3) for the following reasons:

- The SRT will indicate “CMPLT” at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires “CMPLT” of the SRT only with OK self-diagnosis results.
- When, during SRT driving pattern, 1st trip DTC (NG) is detected prior to “CMPLT” of SRT, the self-diagnosis memory must be erased from ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate “INCMP”.

### NOTE:

SRT can be set as “CMPLT” together with the DTC(s). Therefore, DTC check must always be carried out prior to the state emission inspection even though the SRT indicates “CMPLT”.


### SRT Service Procedure

If a vehicle has failed the state emissions inspection due to one or more SRT items indicating “INCMP”, review the flowchart diagnostic sequence on the next page.

NFEC0031S0909

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

*Emission-related Diagnostic Information (Cont'd)*



SEF573XB

\*1 EC-45

\*2 EC-49

\*3 EC-50

## How to Display SRT Code

### With CONSULT-II

NFEC0031S0910

Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-II.

For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT-II screen; for items whose SRT codes are not set, "INCMP" is displayed as shown below.

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

---

1 SELECT SYSTEM	
2 CATALYST	INCOMP
3 HO2S HTR	CMPLT
4 HO2S	CMPLT

SEC183C

### **With GST**

Selecting Mode 1 with GST (Generic Scan Tool)

### **How to Set SRT Code**

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions. NFEC0031S0911

### **With CONSULT-II**

Perform corresponding DTC Confirmation Procedure one by one based on "Performance Priority" in the table on EC-47.

### **Without CONSULT-II**

The most efficient driving pattern in which SRT codes can be properly set is explained on the next page. The driving pattern should be performed one or more times to set all SRT codes.


# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

## Driving Pattern

=NFEC0031S0912

**Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.**



SEC184C

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

### Emission-related Diagnostic Information (Cont'd)

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.

Zone A refers to the range where the time required, for the diagnosis under normal conditions\*, is the shortest.

Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

\*: Normal conditions refer to the following:

- Sea level
  - Flat road
  - Ambient air temperature: 20 - 30°C (68 - 86°F)
  - Diagnosis is performed as quickly as possible under normal conditions.
- Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- **The engine is started at the engine coolant temperature of –10 to 35°C (14 to 95°F) (where the voltage between the ECM terminal 70 and ground is 3.0 - 4.3V).**
- **The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminal 70 and ground is lower than 1.4V).**
- **The engine is started at the fuel tank temperature of warmer than 0°C (32°F) (where the voltage between the ECM terminal 92 and ground is less than 4.1V).**

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

Pattern 3:

- The driving pattern outlined in \*2 must be repeated at least 3 times.

Pattern 4:


- Tests are performed after the engine has been operated for at least 17 minutes.
- The accelerator pedal must be held very steady during steady-state driving.
- If the accelerator pedal is moved, the test must be conducted all over again.

\*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

\*2: Operate the vehicle in the following driving pattern.

- 1) Decelerate vehicle to 0 km/h (0 MPH) and let engine idle.
- 2) Repeat driving pattern shown below at least 10 times.

- **During acceleration, hold the accelerator pedal as steady as possible.**



\*3: Checking the vehicle speed with GST is advised.

### Suggested Transmission Gear Position for A/T Models

Set the selector lever in the "D" position with the overdrive switch turned ON.

### Suggested upshift speeds for M/T models

Shown below are suggested vehicle speeds for shifting into a higher gear. These suggestions relate to fuel economy and vehicle performance. Actual upshift speeds will vary according to road conditions, the weather and individual driving habits.

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

*Emission-related Diagnostic Information (Cont'd)*

Gear change	For normal acceleration in low altitude areas [less than 1,219 m (4,000 ft)]:		For quick acceleration in low altitude areas and high altitude areas [over 1,219 m (4,000 ft)]:
	ACCEL shift point km/h (MPH)	CRUISE shift point km/h (MPH)	km/h (MPH)
1st to 2nd	21 (13)	21 (13)	24 (15)
2nd to 3rd	37 (23)	26 (16)	40 (25)
3rd to 4th	53 (33)	44 (27)	64 (40)
4th to 5th	63 (39)	58 (36)	72 (45)

### Suggested Maximum Speed in Each Gear

Downshift to a lower gear if the engine is not running smoothly, or if you need to accelerate. Do not exceed the maximum suggested speed (shown below) in any gear. For level road driving, use the highest gear suggested for that speed. Always observe posted speed limits and drive according to the road conditions to ensure safe operation. Do not over-rev the engine when shifting to a lower gear as it may cause engine damage or loss of vehicle control.

Gear	km/h (MPH)
1st	50 (30)
2nd	89 (55)
3rd	128 (80)
4th	—
5th	—

### Test Value and Test Limit (GST Only — not Applicable to CONSULT-II)

NFEC0031S0904

The following is the information specified in Mode 6 of ISO 15031-5. The test value is a parameter used to determine whether a system/circuit diagnostic test is “OK” or “NG” while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items (26 test items).

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

X: Applicable —: Not applicable

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
CATALYST	Three way catalyst function (bank 1)	01H	01H	Max.	X
	Three way catalyst function (bank 2)	03H	02H	Max.	X

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
O2 SENSOR	Heated oxygen sensor 1 (front) (bank 1)	09H	04H	Max.	X
		0AH	84H	Min.	X
		0BH	04H	Max.	X
		0CH	04H	Max.	X
		0DH	04H	Max.	X
	Heated oxygen sensor 1 (front) (bank 2)	11H	05H	Max.	X
		12H	85H	Min.	X
		13H	05H	Max.	X
		14H	05H	Max.	X
		15H	05H	Max.	X
	Heated oxygen sensor 2 (rear) (bank 1)	19H	86H	Min.	X
		1AH	86H	Min.	X
		1BH	06H	Max.	X
		1CH	06H	Max.	X
	Heated oxygen sensor 2 (rear) (bank 2)	21H	87H	Min.	X
		22H	87H	Min.	X
23H		07H	Max.	X	
24H		07H	Max.	X	
O2 SENSOR HEATER	Heated oxygen sensor 1 heater (front) (bank 1)	29H	08H	Max.	X
		2AH	88H	Min.	X
	Heated oxygen sensor 1 heater (front) (bank 2)	2BH	09H	Max.	X
		2CH	89H	Min.	X
	Heated oxygen sensor 2 heater (rear) (bank 1)	2DH	0AH	Max.	X
		2EH	8AH	Min.	X
	Heated oxygen sensor 2 heater (rear) (bank 2)	2FH	0BH	Max.	X
		30H	8BH	Min.	X

### Emission-related Diagnostic Information Items

X: Applicable —: Not applicable NFEC0031S0905

Items (CONSULT-II screen terms)	DTC*1	SRT code	Test value/ Test limit (GST only)	1st trip DTC*1	Reference page
<b>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</b>	<b>P0000</b>	—	—	—	—
MAF SEN/CIRCUIT	P0100	—	—	X	EC-134
AIR TEMP SEN/CIRC	P0110	—	—	X	EC-141
COOLANT T SEN/CIRC	P0115	—	—	X	EC-146
THRTL POS SEN/CIRC	P0120	—	—	X	EC-151

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

*Emission-related Diagnostic Information (Cont'd)*

Items (CONSULT-II screen terms)	DTC*1	SRT code	Test value/ Test limit (GST only)	1st trip DTC*1	Reference page
HO2S1 (B1)	P0130	X	X	X*2	EC-158
HO2S1 (B1)	P0131	X	X	X*2	EC-168
HO2S1 (B1)	P0132	X	X	X*2	EC-176
HO2S1 (B1)	P0133	X	X	X*2	EC-184
HO2S1 (B1)	P0134	X	X	X*2	EC-197
HO2S1 HTR (B1)	P0135	X	X	X*2	EC-205
HO2S2 (B1)	P0137	X	X	X*2	EC-212
HO2S2 (B1)	P0138	X	X	X*2	EC-223
HO2S2 (B1)	P0139	X	X	X*2	EC-234
HO2S2 (B1)	P0140	X	X	X*2	EC-245
HO2S2 HTR (B1)	P0141	X	X	X*2	EC-254
HO2S1 (B2)	P0150	X	X	X*2	EC-158
HO2S1 (B2)	P0151	X	X	X*2	EC-168
HO2S1 (B2)	P0152	X	X	X*2	EC-176
HO2S1 (B2)	P0153	X	X	X*2	EC-184
HO2S1 (B2)	P0154	X	X	X*2	EC-197
HO2S1 HTR (B2)	P0155	X	X	X*2	EC-205
HO2S2 (B2)	P0157	X	X	X*2	EC-212
HO2S2 (B2)	P0158	X	X	X*2	EC-223
HO2S2 (B2)	P0159	X	X	X*2	EC-234
HO2S2 (B2)	P0160	X	X	X*2	EC-245
HO2S2 HTR (B2)	P0161	X	X	X*2	EC-254
FUEL SYS-LEAN/BK1	P0171	—	—	X	EC-261
FUEL SYS-RICH/BK1	P0172	—	—	X	EC-269
FUEL SYS-LEAN/BK2	P0174	—	—	X	EC-261
FUEL SYS-RICH/BK2	P0175	—	—	X	EC-269
FUEL TEMP SEN/CIRC	P0180	—	—	X	EC-276
MULTI CYL MISFIRE	P0300	—	—	X	EC-281
CYL 1 MISFIRE	P0301	—	—	X	EC-281
CYL 2 MISFIRE	P0302	—	—	X	EC-281
CYL 3 MISFIRE	P0303	—	—	X	EC-281
CYL 4 MISFIRE	P0304	—	—	X	EC-281
CYL 5 MISFIRE	P0305	—	—	X	EC-281
CYL 6 MISFIRE	P0306	—	—	X	EC-281
KNOCK SEN/CIRC-B1	P0325	—	—	—	EC-289
CKP SEN/CIRCUIT	P0335	—	—	X	EC-295
CMP SEN/CIRCUIT	P0340	—	—	X	EC-303

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

### Emission-related Diagnostic Information (Cont'd)

Items (CONSULT-II screen terms)	DTC*1	SRT code	Test value/ Test limit (GST only)	1st trip DTC*1	Reference page
TW CATALYST SYS-B1	P0420	X	X	X*2	EC-309
TW CATALYST SYS-B2	P0430	X	X	X*2	EC-309
PURG VOLUME CONT/V	P0443	—	—	X	EC-314
VEH SPEED SEN/CIRC	P0500	—	—	X	EC-320
IACV/AAC VLV/CIRC	P0505	—	—	X	EC-324
CLOSED TP SW/CIRC	P0510	—	—	X	EC-333
ECM	P0605	—	—	X	EC-341
PNP SW/CIRC	P0705	—	—	X	AT-122
ATF TEMP SEN/CIRC	P0710	—	—	X	AT-128
VEH SPD SEN/CIR AT	P0720	—	—	X	AT-134
ENGINE SPEED SIG	P0725	—	—	X	AT-139
A/T 1ST GR FNCTN	P0731	—	—	X	AT-144
A/T 2ND GR FNCTN	P0732	—	—	X	AT-150
A/T 3RD GR FNCTN	P0733	—	—	X	AT-156
A/T 4TH GR FNCTN	P0734	—	—	X	AT-162
TCC SOLENOID/CIRC	P0740	—	—	X	AT-171
L/PRESS SOL/CIRC	P0745	—	—	X	AT-176
SFT SOL A/CIRC	P0750	—	—	X	AT-182
SFT SOL B/CIRC	P0755	—	—	X	AT-187
SWIRL CONT SOL/V	P1131	—	—	X	EC-344
ENG OVER TEMP	P1217	—	—	X	EC-351
CKP SEN (REF)/CIRC	P1335	—	—	X	EC-380
CKP SENSOR (COG)	P1336	—	—	X	EC-387
A/T DIAG COMM LINE	P1605	—	—	X	EC-395
TP SEN/CIRC A/T	P1705	—	—	X	AT-192
P-N POS SW/CIRCUIT	P1706	—	—	X	EC-398
O/R CLTCH SOL/CIRC	P1760	—	—	X	AT-201

\*1: 1st trip DTC No. is the same as DTC No.

\*2: These are not displayed with GST.

**NOTE:**

Regarding A33 models, “-B1” and “BK1” indicate bank 1 and “-B2” and “BK2” indicate bank 2.

### How to Erase Emission-related Diagnostic Information

#### How to Erase DTC (Ⓟ With CONSULT-II)

NFEC0031S0906

**NOTE:**

If the DTC is not for A/T related items (see EC-7), skip steps 2 through 4.

- 1) If the ignition switch stays “ON” after repair work, be sure to turn ignition switch “OFF” once. Wait at least 10 seconds and then turn it “ON” (engine stopped) again.
- 2) Turn CONSULT-II “ON” and touch “A/T”.
- 3) Touch “SELF-DIAG RESULTS”.
- 4) Touch “ERASE”. [The DTC in the TCM (Transmission control module) will be erased.] Then touch “BACK” twice.

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION


*Emission-related Diagnostic Information (Cont'd)*

- 5) Touch "ENGINE".
  - 6) Touch "SELF-DIAG RESULTS".
  - 7) Touch "ERASE". (The DTC in the ECM will be erased.)
- If DTCs are displayed for both ECM and TCM (Transmission control module), they need to be erased individually from the ECM and TCM (Transmission control module).


### How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.

SELECT SYSTEM
ENGINE
A/T



SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER





SELF-DIAG RESULTS	
DTC RESULTS	TIME
SHIFT SOLENOID/V A	

2. Turn CONSULT-II "ON", and touch "A/T".

3. Touch "SELF-DIAG RESULTS".

4. Touch "ERASE". (The DTC in the TCM will be erased.)



SELECT SYSTEM
ENGINE
A/T

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
DATA MONITOR (SPEC)
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SELF DIAG RESULTS	
DTC RESULTS	TIME
SFT SOL A/CIRC [P0750]	0

5. Touch "ENGINE".

6. Touch "SELF-DIAG RESULTS".

7. Touch "ERASE". (The DTC in the ECM will be erased.)

SEF823YA

The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

### How to Erase DTC (GST) With GST

#### NOTE:

**If the DTC is not for A/T related items (see EC-7), skip step 2.**

- 1) If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
- 2) Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
- 3) Select Mode 4 with GST (Generic Scan Tool).

The emission related diagnostic information in the ECM can be erased by selecting Mode 4 with GST.

- **If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.**
- **The following data are cleared when the ECM memory is erased.**
  - 1) Diagnostic trouble codes
  - 2) 1st trip diagnostic trouble codes
  - 3) Freeze frame data
  - 4) 1st trip freeze frame data

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

- 5) System readiness test (SRT) codes
- 6) Test values
- 7) Distance traveled while MI is activated
- 8) Others

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

### MODELS WITHOUT EURO-OBd SYSTEM

NFEC0031S10

#### DTC and 1st Trip DTC

NFEC0031S1001

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory. In other words, the DTC is stored in the ECM memory when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For fail-safe items, the DTC is stored in the ECM memory even in the 1st trip.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in "How to Erase Emission-related Diagnostic Information", EC-59

When a (1st trip) DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in "Work Flow" procedure Step II, refer to EC-88. Then perform "DTC Confirmation Procedure" or "Overall Function Check" to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.

#### How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

##### Without CONSULT-II

ECM displays the DTC by a set of four digit numbers with MI illumination in the diagnostic test mode II (Self-diagnostic results). Example: 0100, 0115, 0340, 1335, etc.

##### With CONSULT-II

CONSULT-II displays the DTC in "SELF-DIAG RESULTS" mode. Examples: P0100, P0115, P0340, P1335, etc.

(CONSULT-II also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, ECM in the diagnostic test mode II (Self-diagnostic results) does not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, the use of CONSULT-II (if available) is recommended.**

A sample CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in the SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>MAF SEN/CIRCUIT [P0100]</td> <td style="text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>	SELF DIAG RESULTS		DTC RESULTS	TIME	MAF SEN/CIRCUIT [P0100]	0					<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>MAF SEN/CIRCUIT [P0100]</td> <td style="text-align: center;">1t</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>	SELF DIAG RESULTS		DTC RESULTS	TIME	MAF SEN/CIRCUIT [P0100]	1t				
SELF DIAG RESULTS																						
DTC RESULTS	TIME																					
MAF SEN/CIRCUIT [P0100]	0																					
SELF DIAG RESULTS																						
DTC RESULTS	TIME																					
MAF SEN/CIRCUIT [P0100]	1t																					
DTC display		1st trip DTC display																				

SEF992X

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

## Freeze Frame Data and 1st Trip Freeze Frame Data

NFEC0031S1002

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, throttle valve opening, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II. For details, see EC-75.

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM.

If freeze frame data is stored in the ECM memory and another freeze frame data occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in "How to Erase Emission-related Diagnostic Information", EC-59.

## How to Erase Emission-related Diagnostic Information

NFEC0031S1003

### How to Erase DTC (Ⓜ With CONSULT-II)

- 1) If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
- 2) Touch "ENGINE".
- 3) Touch "SELF-DIAG RESULTS".
- 4) Touch "ERASE". (The DTC in the ECM will be erased.)

### How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" again.

SELECT SYSTEM
ENGINE

2. Turn **CONSULT-II** "ON" and touch "ENGINE".



SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
DATA MONITOR (SPEC)
ACTIVE TEST
ECM PART NUMBER

3. Touch "SELF-DIAG RESULTS".



SELF DIAG RESULTS	
DTC RESULTS	TIME
COOLANT T SEN/CIRC [P0115]	0

4. Touch "ERASE". (The DTC in the ECM will be erased.)

SEC074C

The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

### How to Erase DTC (ⓧ Without CONSULT-II)

- 1) If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
- 2) Change the diagnostic test mode from Mode II to Mode I by using the data link connector. (See EC-62.)

The emission related diagnostic information in the ECM can be erased by changing the diagnostic test mode.

- If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.
- Erasing the emission-related diagnostic information using CONSULT-II is easier and quicker than switching the diagnostic test mode using the data link connector.
- The following data are cleared when the ECM memory is erased.

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

- 1) Diagnostic trouble codes
- 2) 1st trip diagnostic trouble codes
- 3) Freeze frame data
- 4) 1st trip freeze frame data
- 5) Others

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

### NVIS (Nissan Vehicle Immobilizer System — NATS)

NFEC0649

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION [P1610]	0


SEF515Y

- If the security indicator lights up with the ignition switch in the “ON” position or “NATS MALFUNCTION” is displayed on “SELF-DIAG RESULTS” screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to “NVIS (Nissan Vehicle Immobilizer System — NATS)” in EL section.
- Confirm no self-diagnostic results of NVIS (NATS) is displayed before touching “ERASE” in “SELF-DIAG RESULTS” mode with CONSULT-II.
- When replacing ECM, initialization of NVIS (NATS) system and registration of all NVIS (NATS) ignition key IDs must be carried out with CONSULT-II using NATS program card. Therefore, be sure to receive all keys from vehicle owner. Regarding the procedures of NVIS (NATS) initialization and NVIS (NATS) ignition key ID registration, refer to CONSULT-II operation manual, IVIS/NVIS.

### Malfunction Indicator (MI)

#### DESCRIPTION

NFEC0032



The MI is located on the instrument panel.

1. The MI will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
- If the MI does not light up, refer to EL-145, WARNING LAMPS or see EC-558.
2. When the engine is started, the MI should go off.  
If the MI remains on, the ECM's CPU is malfunctioning.

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

*Malfunction Indicator (MI) (Cont'd)*

## On Board Diagnostic System Function

=NFEC0032S01

The on board diagnostic system has the following four functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in ON position  Engine stopped 	BULB CHECK	This function checks the MI bulb for damage (blown, open circuit, etc.). If the MI does not come on, check MI circuit. (See EC-558.)
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When the ECM's CPU is malfunctioning, the MI will light up to inform the driver that a malfunction has been detected.
Mode II	Ignition switch in ON position  Engine stopped 	SELF-DIAGNOSTIC RESULTS	This function allows DTCs and 1st trip DTCs to be read.
	Engine running 	HEATED OXYGEN SENSOR 1 MONITOR (FRONT)	This function allows the fuel mixture condition (lean or rich), monitored by heated oxygen sensor 1 (front), to be read.

### MI Flashing without DTC

If the ECM is in Diagnostic Test Mode II, MI may flash when engine is running. In this case, check ECM diagnostic test mode following "How to Switch Diagnostic Test Modes", EC-62.

NFEC0032S0102

How to switch the diagnostic test (function) modes, and details of the above functions are described later. (Refer to EC-63.)

The following emission-related diagnostic information is cleared when the ECM memory is erased.


- 1) Diagnostic trouble codes
- 2) 1st trip diagnostic trouble codes
- 3) Freeze frame data
- 4) 1st trip freeze frame data
- 5) System readiness test (SRT) code
- 6) Test values
- 7) Distance traveled while MI is activated
- 8) Others

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator (MI) (Cont'd)

## How to Switch Diagnostic Test Modes

NFEC0032S07



- Switching the modes is not possible when the engine is running.
- When ignition switch is turned off during diagnosis, power to ECM will drop after approx. 10 seconds. The diagnosis will automatically return to Diagnostic Test Mode I.

SEF994XB

\*1 EC-558

\*3 EC-558

\*4 EC-104

\*2 EC-61

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

*Malfunction Indicator (MI) (Cont'd)*

## Diagnostic Test Mode I — Bulb Check


In this mode, the MI on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to EL-145, "WARNING LAMPS" or see EC-558. NFEC0032S03

## Diagnostic Test Mode I — Malfunction Warning

MI	Condition
ON	When the ECM's CPU is malfunctioning.
OFF	No malfunction.

## Diagnostic Test Mode II — Self-diagnostic Results

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MI. A DTC will be used as an example for how to read a code. NFEC0032S08



A particular DTC can be identified by the number of four-digit numeral flashes. The "zero" is indicated by the number of ten flashes. The length of time the 1000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-second)-OFF (0.6-second) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-second ON and 0.3-second OFF cycle.

A change from one digit numeral to another occurs at an interval of 1.0 second OFF. In other words, the latter numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one DTC to another occurs at an interval of 1.8 second off.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC "0000" refers to no malfunction. (See TROUBLE DIAGNOSIS — INDEX, EC-7.)

### How to Erase Diagnostic Test Mode II (Self-diagnostic results)

The DTC can be erased from the backup memory in the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "How to Switch Diagnostic Test Modes", EC-62.) NFEC0032S0801

- If the battery is disconnected, the DTC will be lost from the backup memory after approx. 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator (MI) (Cont'd)

### Diagnostic Test Mode II — Heated Oxygen Sensor 1 Monitor (front)

=NFEC0032S09

In this mode, the MI displays the condition of the fuel mixture (lean or rich) which is monitored by the heated oxygen sensor 1 (front).

MI	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

\*: Maintains conditions just before switching to open loop.

To check the heated oxygen sensor 1 (front) function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MI comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.


ECM will start heated oxygen sensor 1 (front) (B1) monitoring.

#### How to Switch Monitored Sensor from Bank 1 to Bank 2 or Vice Versa

NFEC0032S0901

● The following procedure should be performed while the engine is running.

1. Connect CHK and IGN terminals of data link connector with a suitable harness.
2. Wait at least 2 seconds.
3. Disconnect the suitable harness between CHK and IGN terminals of data link connector.



SEF134MD

### OBD System Operation Chart (Models with Euro-OBD System)

#### RELATIONSHIP BETWEEN MI, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

NFEC0650

NFEC0650S01

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MI will come on. For details, refer to "Two Trip Detection Logic" on EC-44.
- The MI will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The "TIME" in "SELF-DIAGNOSTIC RESULTS"

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Models with Euro-OBD System) (Cont'd)

mode of CONSULT-II will count the number of times the vehicle is driven.

- The 1st trip DTC is not displayed when the self-diagnosis results in "OK" for the 2nd trip.

### SUMMARY CHART

NFEC0650S02

Items	Fuel Injection System	Misfire	Other
MI (goes off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)

For details about patterns "B" and "C" under "Fuel Injection System" and "Misfire", see EC-67.

For details about patterns "A" and "B" under "Other", see EC-69.

\*1: Clear timing is at the moment OK is detected.

\*2: Clear timing is when the same malfunction is detected in the 2nd trip.



## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Models with Euro-OBD System) (Cont'd)

### EXPLANATION FOR DRIVING PATTERNS FOR “MISFIRE <EXHAUST QUALITY DETERIORATION>”, “FUEL INJECTION SYSTEM”

NFEC0650S04

#### Driving Pattern B

NFEC0650S0401

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MI will go off when the B counter reaches 3. (\*2 in EC-66)

#### Driving Pattern C

NFEC0650S0402

Driving pattern C means the vehicle operation as follows:

1) The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data)  $\pm 375$  rpm

Calculated load value: (Calculated load value in the freeze frame data)  $\times (1 \pm 0.1)$  [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), “T” should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), “T” should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)


- The C counter will be cleared when the malfunction is detected regardless of driving pattern C.
- The C counter will be counted up when driving pattern C is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD System Operation Chart (Models with Euro-OBD System) (Cont'd)

## RELATIONSHIP BETWEEN MI, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

NFEC0650S05



- \*1: When the same malfunction is detected in two consecutive trips, MI will light up.
- \*2: MI will go off after vehicle is driven 3 times (pattern B) without any malfunctions.
- \*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.
- \*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- \*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.
- \*6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.
- \*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION


OB D System Operation Chart (Models with Euro-OB D System) (Cont'd)

### EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

NFEC0650S06

#### Driving Pattern A

NFEC0650S0601



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

#### Driving Pattern B

NFEC0650S0602



Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MI will go off when the B counter reaches 3 (\*2 in EC-68).

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II




## CONSULT-II

### CONSULT-II INSPECTION PROCEDURE


=NFEC0034

NFEC0034S01


1. Turn ignition switch OFF.
2. Connect CONSULT-II to data link connector, which is located under drivers side dash panel.



3. Turn ignition switch ON.
4. Touch "START".



5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.

**For further information, see the CONSULT-II Operation Manual.**

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

## ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

Models with Euro-OBD System

NFEC0034S02

NFEC0034S0201

Item		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOSTIC RESULTS		DATA MONITOR	DATA MONITOR (SPEC)	ACTIVE TEST	DTC & SRT CONFIRMATION	
			DTC*1	FREEZE FRAME DATA*2				SRT STATUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS INPUT	Crankshaft position sensor (POS)		X	X	X	X			
	Crankshaft position sensor (REF)		X		X	X			
	Mass air flow sensor		X		X	X			
	Engine coolant temperature sensor		X	X	X	X	X		
	Heated oxygen sensor 1 (front)		X		X	X		X	X
	Heated oxygen sensor 2 (rear)		X		X	X		X	X
	Vehicle speed sensor		X	X	X	X			
	Throttle position sensor		X		X	X			
	Fuel tank temperature sensor		X		X	X			
	Absolute pressure sensor				X	X			
	Intake air temperature sensor		X		X	X			
	Knock sensor		X						
	Ignition switch (start signal)				X	X			
	Closed throttle position switch		X		X	X			
	Closed throttle position switch (throttle position sensor signal)				X	X			
	Air conditioner switch				X	X			
	Park/neutral position (PNP) switch		X		X	X			
	Power steering oil pressure switch				X	X			
	Battery voltage				X	X			
	Ambient air temperature switch				X	X			
Load signal				X	X				

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Item		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOSTIC RESULTS		DATA MONI-TOR	DATA MONI-TOR (SPEC)	ACTIVE TEST	DTC & SRT CONFIRMATION	
			DTC*1	FREEZE FRAME DATA*2				SRT STATUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS OUTPUT	Injectors				X	X	X		
	Power transistor (Ignition timing)				X	X	X		
	IACV-AAC valve		X		X	X	X		
	EVAP canister purge volume control solenoid valve		X		X	X	X		X
	Air conditioner relay				X	X			
	Fuel pump relay	X			X	X	X		
	Cooling fan		X		X	X	X		
	Heated oxygen sensor 1 heater (front)		X		X	X		X	
	Heated oxygen sensor 2 heater (rear)		X		X	X		X	
	Swirl control valve control solenoid valve		X		X	X	X		
	Electronic controlled engine mount				X	X	X		
	Calculated load value			X	X	X			

X: Applicable

\*1: This item includes 1st trip DTCs.

\*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to EC-46.

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

## Models without Euro-OBd System

NFEC0034S0202

Item		DIAGNOSTIC TEST MODE						
		WORK SUPPORT	SELF-DIAGNOSTIC RESULTS		DATA MONITOR	DATA MONITOR (SPEC)	ACTIVE TEST	
			DTC*1	FREEZE FRAME DATA*2				
ENGINE CONTROL COMPONENT PARTS	INPUT	Crankshaft position sensor (POS)		X	X	X	X	
		Crankshaft position sensor (REF)		X	X	X	X	
		Mass air flow sensor		X		X	X	
		Engine coolant temperature sensor		X	X	X	X	X
		Heated oxygen sensor 1 (front)		X		X	X	
		Heated oxygen sensor 2 (rear)				X	X	
		Vehicle speed sensor			X	X	X	
		Throttle position sensor		X	X	X	X	
		Fuel tank temperature sensor				X	X	
		Absolute pressure sensor				X	X	
		Intake air temperature sensor			X	X	X	
		Knock sensor		X				
		Ignition switch (start signal)				X	X	
		Closed throttle position switch (throttle position sensor signal)				X	X	
		Air conditioner switch				X	X	
		Park/neutral position (PNP) switch				X	X	
		Power steering oil pressure switch				X	X	
		Battery voltage				X	X	
		Ambient air temperature switch				X	X	
		Load signal				X	X	

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Item		DIAGNOSTIC TEST MODE					
		WORK SUPPORT	SELF-DIAGNOSTIC RESULTS		DATA MONITOR	DATA MONITOR (SPEC)	ACTIVE TEST
			DTC*1	FREEZE FRAME DATA*2			
ENGINE CONTROL COMPONENT PARTS	OUTPUT	Injectors			X	X	X
	Power transistor (Ignition timing)		X (Ignition signal)		X	X	X
	IACV-AAC valve				X	X	X
	EVAP canister purge volume control solenoid valve				X	X	X
	Air conditioner relay				X	X	
	Fuel pump relay	X			X	X	X
	Cooling fan		X		X	X	X
	Heated oxygen sensor 1 heater (front)				X	X	
	Heated oxygen sensor 2 heater (rear)				X	X	
	Swirl control valve control solenoid valve				X	X	X
	VIAS control solenoid valve				X	X	X
	Electronic controlled engine mount				X	X	X
	Calculated load value			X	X	X	

X: Applicable

\*1: This item includes 1st trip DTCs.

\*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to EC-59.

### FUNCTION

NFEC0034S03

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*1
Data monitor	Input/Output data in the ECM can be read.
Data monitor (spec)	Input/Output specifications of the basic fuel schedule, AFM, A/F feedback control value and the other data monitor items can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
DTC confirmation	The status of system monitoring tests and the self-diagnosis status/result can be confirmed.
ECM part number	ECM part numbers can be read.

\*1 The following emission-related diagnostic information is cleared when the ECM memory is erased.

- 1) Diagnostic trouble codes
- 2) 1st trip diagnostic trouble codes
- 3) Freeze frame data
- 4) 1st trip freeze frame data
- 5) System readiness test (SRT) codes
- 6) Test values
- 7) Distance traveled while MI is activated.

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

8) Others

## WORK SUPPORT MODE

NFEC0034S04

WORK ITEM	CONDITION	USAGE
TP SW/TP SEN IDLE POSI ADJ	<ul style="list-style-type: none"> <li>FOLLOW THE BASIC INSPECTION INSTRUCTION IN THE SERVICE MANUAL.</li> </ul>	When adjusting the idle throttle position
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> <li>FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING.</li> <li>CRANK A FEW TIMES AFTER ENGINE STALLS.</li> </ul>	When releasing fuel pressure from fuel line
IDLE AIR VOL LEARN	<ul style="list-style-type: none"> <li>THE IDLE AIR VOLUME THAT KEEPS THE ENGINE WITHIN THE SPECIFIED RANGE IS MEMORIZED IN ECM.</li> </ul>	When learning the idle air volume
SELF-LEARNING CONT	<ul style="list-style-type: none"> <li>THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT.</li> </ul>	When clear the coefficient of self-learnign control value
TARGET IDLE RPM ADJ*	<ul style="list-style-type: none"> <li>IDLE CONDITION</li> </ul>	When setting target idle speed
TARGET IGNITION TIMING ADJ*	<ul style="list-style-type: none"> <li>IDLE CONDITION</li> </ul>	When adjusting target ignition timing After adjustment, confirm target ignition timing with a timing light.

\*: This function is not necessary in the usual service procedure.

## SELF-DIAGNOSTIC MODE

NFEC0034S05

### DTC and 1st Trip DTC

Regarding items of "DTC and 1st trip DTC", refer to "TROUBLE DIAGNOSIS — INDEX" (See EC-7.)

NFEC0034S0501

### Freeze Frame Data and 1st Trip Freeze Frame Data

NFEC0034S0502

Freeze frame data item*1	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> <li>The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to "TROUBLE DIAGNOSIS — INDEX", EC-7.)</li> </ul>
FUEL SYS-B1*2	<ul style="list-style-type: none"> <li>"Fuel injection system status" at the moment a malfunction is detected is displayed.</li> <li>One mode in the following is displayed. "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop</li> </ul>
FUEL SYS-B2*2	
CAL/LD VALUE [%]	<ul style="list-style-type: none"> <li>The calculated load value at the moment a malfunction is detected is displayed.</li> </ul>
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> <li>The engine coolant temperature at the moment a malfunction is detected is displayed.</li> </ul>
S-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> <li>"Short-term fuel trim" at the moment a malfunction is detected is displayed.</li> <li>The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.</li> </ul>
S-FUEL TRIM-B2 [%]	
L-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> <li>"Long-term fuel trim" at the moment a malfunction is detected is displayed.</li> <li>The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.</li> </ul>
L-FUEL TRIM-B2 [%]	
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> <li>The engine speed at the moment a malfunction is detected is displayed.</li> </ul>
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> <li>The vehicle speed at the moment a malfunction is detected is displayed.</li> </ul>
ABSOL TH-P/S [%] or [degree]	<ul style="list-style-type: none"> <li>The throttle valve opening at the moment a malfunction is detected is displayed.</li> </ul>

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Freeze frame data item*1	Description
B/FUEL SCHDL [msec]	● The base fuel schedule at the moment a malfunction is detected is displayed.
INT/A TEMP SE [°C] or [°F]	● The intake air temperature at the moment a malfunction is detected is displayed.

\*1: The items are the same as those of 1st trip freeze frame data.

\*2: Regarding A33 model, “-B1” indicates bank 1 and “-B2” indicates bank 2.

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

## DATA MONITOR MODE

=NFEC0034S06

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
ENG SPEED [rpm]	○	○	<ul style="list-style-type: none"> <li>Indicates the engine speed computed from the REF signal (120° signal) of the crankshaft position sensor (REF).</li> </ul>	
CKPS-RPM (POS) [rpm]	○		<ul style="list-style-type: none"> <li>Indicates the engine speed computed from the POS signal (1° signal) of the crankshaft position sensor (POS).</li> </ul>	<ul style="list-style-type: none"> <li>Accuracy becomes poor if engine speed drops below the idle rpm.</li> <li>If the signal is interrupted while the engine is running, an abnormal value may be indicated.</li> </ul>
POS COUNT	○		<ul style="list-style-type: none"> <li>Indicates the number of signal plate (Flywheel/Drive Plate) cogs (tooth) during one revolution of the engine.</li> </ul>	
MAS A/F SE-B1 [V]	○	○	<ul style="list-style-type: none"> <li>The signal voltage of the mass air flow sensor is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> </ul>
COOLAN TEMP/S [°C] or [°F]	○	○	<ul style="list-style-type: none"> <li>The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.</li> </ul>
HO2S1 (B1) [V]	○	○	<ul style="list-style-type: none"> <li>The signal voltage of the heated oxygen sensor 1 (front) is displayed.</li> </ul>	
HO2S1 (B2) [V]	○	○		
HO2S2 (B1) [V]	○	○	<ul style="list-style-type: none"> <li>The signal voltage of the heated oxygen sensor 2 (rear) is displayed.</li> </ul>	
HO2S2 (B2) [V]	○	○		
HO2S1 MNTR (B1) [RICH/LEAN]	○		<ul style="list-style-type: none"> <li>Display of heated oxygen sensor 1 (front) signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture.</li> </ul>	<ul style="list-style-type: none"> <li>After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins.</li> <li>When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.</li> </ul>
HO2S1 MNTR (B2) [RICH/LEAN]	○			
HO2S2 MNTR (B1) [RICH/LEAN]	○		<ul style="list-style-type: none"> <li>Display of heated oxygen sensor 2 (rear) signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> </ul>
HO2S2 MNTR (B2) [RICH/LEAN]	○			
VHCL SPEED SE [km/h] or [mph]	○	○	<ul style="list-style-type: none"> <li>The vehicle speed computed from the vehicle speed sensor signal is displayed.</li> </ul>	
BATTERY VOLT [V]	○	○	<ul style="list-style-type: none"> <li>The power supply voltage of ECM is displayed.</li> </ul>	
THRTL POS SEN [V]	○	○	<ul style="list-style-type: none"> <li>The throttle position sensor signal voltage is displayed.</li> </ul>	
FUEL T/TMP SE [°C] or [°F]	○		<ul style="list-style-type: none"> <li>The fuel temperature judged from the fuel tank temperature sensor signal voltage is displayed.</li> </ul>	

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
INT/A TEMP SE [°C] or [°F]	○	○	<ul style="list-style-type: none"> <li>The intake air temperature determined by the signal voltage of the intake air temperature sensor is indicated.</li> </ul>	
START SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the starter signal.</li> </ul>	<ul style="list-style-type: none"> <li>After starting the engine, [OFF] is displayed regardless of the starter signal.</li> </ul>
CLSD THL/P SW [ON/OFF]	○		<ul style="list-style-type: none"> <li>Indicates mechanical contact [ON/OFF] condition of the closed throttle position switch.</li> </ul>	
CLSD THL POS [ON/OFF]	○	○	<ul style="list-style-type: none"> <li>Indicates idle position [ON/OFF] computed by ECM according to the throttle position sensor signal.</li> </ul>	
AIR COND SIG [ON/OFF]	○	○	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.</li> </ul>	
P/N POSI SW [ON/OFF]	○	○	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal.</li> </ul>	
PW/ST SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> <li>[ON/OFF] condition of the power steering oil pressure switch determined by the power steering oil pressure signal is indicated.</li> </ul>	
AMB TEMP SW [ON/OFF]	○		<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the ambient air temperature switch signal.</li> </ul>	
IGNITION SW [ON/OFF]	○		<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from ignition switch.</li> </ul>	
INJ PULSE-B1 [msec]		○	<ul style="list-style-type: none"> <li>Indicates the actual fuel injection pulse width compensated by ECM according to the input signals.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain computed value is indicated.</li> </ul>
INJ PULSE-B2 [msec]				
B/FUEL SCHDL [msec]		○	<ul style="list-style-type: none"> <li>"Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction.</li> </ul>	
IGN TIMING [BTDC]		○	<ul style="list-style-type: none"> <li>Indicates the ignition timing computed by ECM according to the input signals.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> </ul>
IACV-AAC/V [step]		○	<ul style="list-style-type: none"> <li>Indicates the IACV-AAC valve control value computed by ECM according to the input signals.</li> </ul>	
PURG VOL C/V [%]			<ul style="list-style-type: none"> <li>Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals.</li> <li>The opening becomes larger as the value increases.</li> </ul>	
A/F ALPHA-B1 [%]		○	<ul style="list-style-type: none"> <li>The mean value of the air-fuel ratio feedback correction factor per cycle is indicated.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is stopped, a certain value is indicated.</li> <li>This data also includes the data for the air-fuel ratio learning control.</li> </ul>
A/F ALPHA-B2 [%]		○		
AIR COND RLY [ON/OFF]		○	<ul style="list-style-type: none"> <li>The air conditioner relay control condition (determined by ECM according to the input signal) is indicated.</li> </ul>	

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
FUEL PUMP RLY [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates the fuel pump relay control condition determined by ECM according to the input signals.</li> </ul>	
COOLING FAN [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates the control condition of the cooling fan (determined by ECM according to the input signal). HIGH ... High speed operation LOW ... Low speed operation OFF ... Stop</li> </ul>	
HO2S1 HTR (B1) [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of heated oxygen sensor 1 heater (front) determined by ECM according to the input signals.</li> </ul>	
HO2S1 HTR (B2) [ON/OFF]				
HO2S2 HTR (B1) [ON/OFF]			<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition of heated oxygen sensor 2 heater (rear) determined by ECM according to the input signals.</li> </ul>	
HO2S2 HTR (B2) [ON/OFF]				
CAL/LD VALUE [%]			<ul style="list-style-type: none"> <li>"Calculated load value" indicates the value of the current airflow divided by peak airflow.</li> </ul>	
ABSOL TH·P/S [%]			<ul style="list-style-type: none"> <li>"Absolute throttle position sensor" indicates the throttle opening computed by ECM according to the signal voltage of the throttle position sensor.</li> </ul>	
MASS AIRFLOW [g·m/s]			<ul style="list-style-type: none"> <li>Indicates the mass airflow computed by ECM according to the signal voltage of the mass airflow sensor.</li> </ul>	
ABSOL PRES/SE [V]	○		<ul style="list-style-type: none"> <li>The signal voltage of the absolute pressure sensor is displayed.</li> </ul>	
SWRL CONT S/V [ON/OFF]			<ul style="list-style-type: none"> <li>The control condition of the swirl control valve control solenoid valve (determined by ECM according to the input signals) is indicated.</li> <li>ON ... Swirl control valve is closed.</li> <li>OFF ... Swirl control valve is opened.</li> </ul>	
LOAD SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> <li>Indicates [ON/OFF] condition from the electrical load signal and/or lighting switch.</li> <li>ON ... rear defogger is operating and/or lighting switch is on.</li> <li>OFF ... rear defogger is not operating and lighting switch is not on.</li> </ul>	
TRVL AFTER MIL [km] or [Mile]			<ul style="list-style-type: none"> <li>Distance traveled while MI is activated</li> </ul>	
FPCM DR VOLT [V]			<ul style="list-style-type: none"> <li>This item is not available. A certain value is indicated.</li> </ul>	

## ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
VIAS S/V [ON/OFF]			<ul style="list-style-type: none"> <li>The control condition of the VIAS control solenoid valve (determined by ECM according to the input signal) is indicated.</li> <li>OFF ... VIAS control solenoid valve is not operating.</li> <li>ON ... VIAS control solenoid valve is operating.</li> </ul>	
ENGINE MOUNT [IDLE/TRVL]			<ul style="list-style-type: none"> <li>The control condition of the electronic controlled engine mount (computed by ECM according to the input signals) is indicated.</li> <li>IDLE ... Idle condition</li> <li>TRVL ... Driving condition</li> </ul>	
IDL A/V LEAN			<ul style="list-style-type: none"> <li>Display the condition of idle air volume learning</li> <li>YET ... Idle air volume learning has not been performed yet.</li> <li>CMPLT ... Idle air volume learning has already been performed successfully.</li> <li>INCOMP ... Idle air volume learning has not been performed successfully.</li> </ul>	
Voltage [V]			<ul style="list-style-type: none"> <li>Voltage measured by the voltage probe.</li> </ul>	
Frequency [msec] or [Hz] or [%]			<ul style="list-style-type: none"> <li>Pulse width, frequency or duty cycle measured by the pulse probe.</li> </ul>	<ul style="list-style-type: none"> <li>Only “#” is displayed if item is unable to be measured.</li> <li>Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.</li> </ul>

**NOTE:**

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.
- Regarding A33 model, “-B1” indicates bank 1 and “-B2” indicates bank 2.

### DATA MONITOR (SPEC) MODE

NFEC0034S11

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
MAS A/F SE-B1 [V]	○	○	<ul style="list-style-type: none"> <li>The signal voltage of the mass air flow sensor specification is displayed.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is running, specification range is indicated.</li> </ul>
B/FUEL SCHDL [msec]		○	<ul style="list-style-type: none"> <li>“Base fuel schedule” indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is running, specification range is indicated.</li> </ul>
A/F ALPHA-B1 [%]		○	<ul style="list-style-type: none"> <li>Indicates the mean value of the air-fuel ratio feedback correction factor per cycle.</li> </ul>	<ul style="list-style-type: none"> <li>When the engine is running, specification range is indicated.</li> <li>This data also includes the data for the air-fuel ratio learning control.</li> </ul>
A/F ALPHA-B2 [%]		○		

**NOTE:**

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.
- Regarding A33 model, “B1” indicates bank 1 and “B2” indicates bank 2.

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

## ACTIVE TEST MODE

NFEC0034S07

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change the amount of fuel injection using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Fuel injectors</li> <li>● Heated oxygen sensor 1 (front)</li> </ul>
IACV-AAC/V OPENING	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine.</li> <li>● Change the IACV-AAC valve opening percent using CONSULT-II.</li> </ul>	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● IACV-AAC valve</li> </ul>
ENG COOLANT TEMP	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Change the engine coolant temperature using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Engine coolant temperature sensor</li> <li>● Fuel injectors</li> </ul>
IGNITION TIMING	<ul style="list-style-type: none"> <li>● Engine: Return to the original trouble condition</li> <li>● Timing light: Set</li> <li>● Retard the ignition timing using CONSULT-II.</li> </ul>	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> <li>● Adjust initial ignition timing</li> </ul>
POWER BALANCE	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine.</li> <li>● A/C switch "OFF"</li> <li>● Shift lever "N"</li> <li>● Cut off each injector signal one at a time using CONSULT-II.</li> </ul>	Engine runs rough or dies.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Compression</li> <li>● Injectors</li> <li>● Power transistor</li> <li>● Spark plugs</li> <li>● Ignition coils</li> </ul>
COOLING FAN	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Turn the cooling fan "ON" and "OFF" using CONSULT-II.</li> </ul>	Cooling fan moves and stops.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Cooling fan motor</li> <li>● Cooling fan relay</li> </ul>
FUEL PUMP RELAY	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Turn the fuel pump relay "ON" and "OFF" using CONSULT-II and listen to operating sound.</li> </ul>	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Fuel pump relay</li> </ul>
PURG VOL CONT/V	<ul style="list-style-type: none"> <li>● Engine: After warming up, run engine at 1,500 rpm.</li> <li>● Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II.</li> </ul>	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Solenoid valve</li> </ul>
SWIRL CONT SOL VALVE	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Turn solenoid valve "ON" and "OFF" with CONSULT-II and listen for operating sound.</li> </ul>	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Solenoid valve</li> </ul>
VIAS SOL VALVE	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Turn solenoid valve "ON" and "OFF" with CONSULT-II and listen for operating sound.</li> </ul>	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Solenoid valve</li> </ul>
ENGINE MOUNTING	<ul style="list-style-type: none"> <li>● Engine: After warming up, run engine at idle speed.</li> <li>● Gear position: "D" range (Vehicle stopped)</li> <li>● Turn electronic controlled engine mount "IDLE" and "RAVEL" with the CONSULT-II.</li> </ul>	Body vibration changes according to the electronic controlled engine mount condition.	<ul style="list-style-type: none"> <li>● Harness and connector</li> <li>● Electronic controlled engine mount</li> </ul>

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

## DTC & SRT CONFIRMATION MODE

### SRT STATUS Mode

NFEC0034S12

For details, refer to "SYSTEM READINESS TEST (SRT) CODE", EC-47.

### SRT Work Support Mode


NFEC0034S1202

This mode enables a technician to drive a vehicle to set the SRT while monitoring the SRT status.

### DTC Work Support Mode

NFEC0034S1203

Test mode	Test item	Condition	Reference page
HO2S1	HO2S1 (B1) P0130	Refer to corresponding trouble diagnosis for DTC.	EC-158
	HO2S1 (B1) P0131		EC-168
	HO2S1 (B1) P0132		EC-176
	HO2S1 (B1) P0133		EC-184
	HO2S1 (B2) P0150		EC-158
	HO2S1 (B2) P0151		EC-168
	HO2S1 (B2) P0152		EC-176
	HO2S1 (B2) P0153		EC-184
HO2S2	HO2S2 (B1) P0137		EC-212
	HO2S2 (B1) P0138		EC-223
	HO2S2 (B1) P0139		EC-234
	HO2S2 (B2) P0157		EC-212
	HO2S2 (B2) P0158		EC-223
	HO2S2 (B2) P0159		EC-234




## REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

NFEC0034S10

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

- 1) "AUTO TRIG" (Automatic trigger):
  - The malfunction will be identified on the CONSULT-II screen in real time. In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM. At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at left, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed. The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.
- 2) "MANU TRIG" (Manual trigger):
  - DTC/1st trip DTC and malfunction item will not be displayed



# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION


CONSULT-II (Cont'd)

automatically on CONSULT-II screen even though a malfunction is detected by ECM.

DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:


- 1) "AUTO TRIG"
  - While trying to detect the DTC/1st trip DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
  - While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.  
When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to GI-22, "Incident Simulation Tests".
- 2) "MANU TRIG"
  - If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



SEF720X

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

## Generic Scan Tool (GST)



## Generic Scan Tool (GST)

=NFEC0866


### DESCRIPTION

NFEC0866S01

Generic Scan Tool (OBDII scan tool) complying with ISO15031-4 has 8 different functions explained on the next page.

ISO9141 is used as the protocol.



The name "GST" or "Generic Scan Tool" is used in this service manual.



### GST INSPECTION PROCEDURE


NFEC0866S02

1. Turn ignition switch OFF.
2. Connect "GST" to data link connector, which is located under the driver side dash panel.



3. Turn ignition switch ON.
4. Enter the program according to instruction on the screen or in the operation manual.

(\*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.




**For further information, see the GST Operation Manual of the tool maker.**

# ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

*Generic Scan Tool (GST) (Cont'd)*

<b>FUNCTION</b>		
Diagnostic test mode		Function
MODE 1	READINESS TESTS	This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, distance traveled while MI is activated and system status information.
MODE 2	(FREEZE DATA)	This mode gains access to emission-related data value which were stored by ECM during the freeze frame. (For details, refer to "Freeze Frame Data", EC-46.)
MODE 3	DTCs	This mode gains access to emission-related power train trouble codes which were stored by ECM.
MODE 4	CLEAR DIAG INFO	This mode can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> <li>● Clear number of diagnostic trouble codes (MODE 1)</li> <li>● Clear diagnostic trouble codes (MODE 3)</li> <li>● Clear trouble code for freeze frame data (MODE 1)</li> <li>● Clear freeze frame data (MODE 2)</li> <li>● Reset status of system monitoring test (MODE 1)</li> <li>● Clear on board monitoring test results (MODE 6 and 7)</li> </ul>
MODE 6	(ON BOARD TESTS)	This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
MODE 7	(ON BOARD TESTS)	This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.
MODE 8	—	This mode is not applicable on this vehicle.
MODE 9	(CALIBRATION ID)	This mode enables the off-board (External test equipment) to request specific vehicle information such as Vehicle Identification Number (VIN) and Calibration IDs.

# TROUBLE DIAGNOSIS — INTRODUCTION



KEY POINTS	
<b>WHAT</b> .....	Vehicle & engine model
<b>WHEN</b> .....	Date, Frequencies
<b>WHERE</b> .....	Road conditions
<b>HOW</b> .....	Operating conditions, Weather conditions, Symptoms

SEF907L

## Introduction

NFEC0036

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the "Work Flow" on EC-88.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on next page should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

## DIAGNOSTIC WORKSHEET

NFEC0036S01

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.




# TROUBLE DIAGNOSIS — INTRODUCTION

Work Flow

## Work Flow

NFEC0651



SEF510ZD

\*1 EC-104

\*2 If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.

\*3 If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.

\*4 If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to "TROUBLE DIAGNOSIS FOR POWER SUPPLY", EC-127.

\*5 If malfunctioning part cannot be

detected, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.

\*6 EC-51

\*7 EC-122

# TROUBLE DIAGNOSIS — INTRODUCTION

Work Flow (Cont'd)

## DESCRIPTION FOR WORK FLOW

NFEC0651S01

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-86.
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II or GST) the (1st trip) DTC and the (1st trip) freeze frame data, then erase the DTC and the data. (Refer to EC-56, EC-59.) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126. Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-105.) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126. If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the (1st trip) DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II or GST. During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126. In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the (1st trip) DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed refer to "Basic Inspection", EC-90. If CONSULT-II is available, perform "DATA MONITOR (SPEC)" mode with CONSULT-II and proceed to the "TROUBLE DIAGNOSIS — SPECIFICATION VALUE". (Refer to EC-122.) (If malfunction is detected, proceed to "REPAIR/REPLACE".) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-105.)
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-109, EC-114. The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to GI-24, "Circuit Inspection". Repair or replace the malfunction parts. If malfunctioning part cannot be detected, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. P0000] is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM and TCM (Transmission control module). (Refer to EC-56, EC-59.)

# TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection

## Basic Inspection


NFEC0038


**Precaution:**

**Perform Basic Inspection without electrical or mechanical loads applied;**

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear window defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

**On vehicles equipped with daytime light systems, set lighting switch to the 1st position to light only small lamps.**

<b>1</b>	<b>INSPECTION START</b>
<p>1. Check service records for any recent repairs that may indicate a related problem, or a current need for scheduled maintenance.</p> <p>2. Open engine hood and check the following:</p> <ul style="list-style-type: none"> <li>● Harness connectors for improper connections</li> <li>● Vacuum hoses for splits, kinks and improper connections</li> <li>● Wiring for improper connections, pinches and cuts</li> <li>● Air cleaner clogging</li> <li>● Hoses and ducts for leaks</li> </ul>	
	
SEF983U	
▶ GO TO 2.	


<b>2</b>	<b>CHECK THROTTLE DRUM OPERATION</b>
<p>Confirm that throttle drum is in contact with the stopper.</p>	
	
<b>OK or NG</b>	
OK (With CONSULT-II) ▶	GO TO 5.
OK (Without CONSULT-II) ▶	GO TO 9.
NG ▶	GO TO 3.

## TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

<b>3</b>	<b>CHECK ACCELERATOR WIRE INSTALLATION</b>	
Check accelerator wire for slack.		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	Adjust accelerator wire. Refer to FE-3, "Adjusting Accelerator Wire".

<b>4</b>	<b>CHECK THROTTLE VALVE OPERATION</b>	
1. Remove intake air ducts. 2. Check throttle valve operation when moving throttle drum by hand.		
<b>OK or NG</b>		
OK	▶	Retighten the throttle drum fixing nuts.
NG	▶	Clean the throttle body and throttle valve.

<b>5</b>	<b>CHECK THROTTLE POSITION SWITCH CLOSED POSITION</b>							
<p>📖 <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Select "CLSD THL/P SW" in "DATA MONITOR" mode with CONSULT-II.</li> <li>3. Read "CLSD THL/P SW" signal under the following conditions. <ul style="list-style-type: none"> <li>• Insert a 0.05 mm (0.0020 in) and 0.15 mm (0.0059 in) feeler gauge alternately between stopper and throttle drum as shown in the figure and check the signal.</li> </ul> </li> </ol>								
								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITOR</th> <th style="text-align: center;">NO DTC</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">CLSD THL/P SW</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	CLSD THL/P SW	ON
DATA MONITOR								
MONITOR	NO DTC							
CLSD THL/P SW	ON							
<p>"CLSD THL/P SW" signal should remain "ON" while inserting 0.05 mm (0.0020 in) feeler gauge. "CLSD THL/P SW" signal should remain "OFF" while inserting 0.15 mm (0.0059 in) feeler gauge.</p> <p style="text-align: center;"><b>OK or NG</b></p>								
OK	▶	GO TO 8.						
NG	▶	GO TO 6.						

SEC017C

SEF173Y


## TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

### 6 ADJUSTMENT THROTTLE POSITION SWITCH CLOSED POSITION-I


#### Ⓟ With CONSULT-II

1. Loosen throttle position sensor fixing bolts.
2. Insert 0.05 mm (0.0020 in) feeler gauge between stopper and throttle drum as shown in the figure.



SEC017C

3. Turn throttle position sensor body counterclockwise until "CLSD THL/P SW" signal switches to "OFF".



SEC018C

DATA MONITOR	
MONITOR	NO DTC
CLSD THL/P SW	OFF


SEF305Y



GO TO 7.

## TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

7		ADJUSTMENT THROTTLE POSITION SWITCH CLOSED POSITION-II
<p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"><li>Temporarily tighten sensor body fixing bolts as follows.<ul style="list-style-type: none"><li>Gradually move the sensor body clockwise and stop it when “CLSD THL/P SW” signal switches from “OFF” to “ON”, then temporarily tighten sensor body fixing bolts.</li></ul></li></ol>		
 <p>The diagram shows a side view of the throttle position sensor assembly. A curved arrow on the left indicates the clockwise direction, and a straight arrow below it indicates the counter-clockwise direction. The sensor body is shown with several bolts and a central shaft.</p>		
<p>SEC018C</p> <ol style="list-style-type: none"><li>Make sure two or three times that the signal is “ON” when the throttle valve is closed and “OFF” when it is opened.</li><li>Remove 0.05 mm (0.0020 in) feeler gauge then insert 0.15 mm (0.0059 in) feeler gauge.</li><li>Make sure two or three times that the signal remains “OFF” when the throttle valve is closed.</li><li>Tighten throttle position sensor.</li><li>Check the “CLSD THL/P SW” signal again. <b>The signal remains “OFF” while closing throttle valve.</b></li></ol>		
<b>OK or NG</b>		
OK	▶	GO TO 8.
NG	▶	GO TO 6.

## TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)


### 8 RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY

⑧ With CONSULT-II

**NOTE:**

Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.

1. Remove feeler gauge.
2. Start engine.
3. Warm up engine to normal operating temperature.
4. Select "CLSD THL POS" in "DATA MONITOR" mode.
5. Stop engine. (Turn ignition switch "OFF".)
6. Turn ignition switch "ON" and wait at least 5 seconds.



SEF864V

7. Turn ignition switch "OFF" and wait at least 10 seconds.
8. Repeat steps 6 and 7 until "CLSD THL POS" signal changes to "ON".



DATA MONITOR	
MONITOR	NO DTC
CLSD THL POS	ON

SEF061Y

▶ GO TO 13.

# TROUBLE DIAGNOSIS — BASIC INSPECTION

*Basic Inspection (Cont'd)*

<b>9</b>	<b>CHECK THROTTLE POSITION SWITCH CLOSED POSITION</b>	
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Disconnect closed throttle position switch harness connector.</li> <li>2. Check continuity between closed throttle position switch terminals <b>4</b> and <b>5</b> under the following conditions.</li> </ol>		
 <p style="text-align: center;">DISCONNECT Throttle position switch connector</p>		
SEF711X		
<ul style="list-style-type: none"> <li>• Insert the 0.05 mm (0.0020 in) and 0.15 mm (0.0059 in) feeler gauge alternately between the stopper and throttle drum as shown in the figure.</li> </ul>		
 <p style="text-align: center;">Feeler gauge</p>		
SEC017C		
<p>“Continuity should exist” while inserting 0.05 mm (0.0020 in) feeler gauge.          “Continuity should not exist” while inserting 0.15 mm (0.0059 in) feeler gauge.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 12.
NG	▶	GO TO 10.


## TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

### 10 ADJUSTMENT THROTTLE POSITION SWITCH CLOSED POSITION-I


⊗ Without CONSULT-II

1. Loosen throttle position sensor fixing bolts.
2. Insert 0.05 mm (0.0020 in) feeler gauge between stopper and throttle drum as shown in the figure.




SEC017C

3. Turn throttle position sensor body counterclockwise until continuity does not exist.



SEF711X




SEC018C




GO TO 11.

# TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

<b>11</b>	<b>ADJUSTMENT THROTTLE POSITION SWITCH CLOSED POSITION-II</b>	
<p>⊗ <b>Without CONSULT-II</b></p> <p>1. Temporarily tighten sensor body fixing bolts as follows.</p> <ul style="list-style-type: none"> <li>● <b>Gradually move the sensor body clockwise and stop it when the continuity comes to exist, then temporarily tighten sensor body fixing bolts.</b></li> </ul>		
		
SEC018C		
<p>2. Make sure two or three times that the continuity exists when the throttle valve is closed and continuity does not exist when it is opened.</p> <p>3. Remove 0.05 mm (0.0020 in) feeler gauge then insert 0.15 mm (0.0059 in) feeler gauge.</p> <p>4. Make sure two or three times that the continuity does not exist when the throttle valve is closed.</p> <p>5. Tighten throttle position sensor.</p> <p>6. Check the continuity again.</p> <p style="color: blue;"><b>Continuity does not exist while closing the throttle valve.</b></p>		
<b>OK or NG</b>		
OK	▶	GO TO 12.
NG	▶	GO TO 10.

<b>12</b>	<b>RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY</b>	
<p>⊗ <b>Without CONSULT-II</b></p> <p><b>NOTE:</b></p> <p><b>Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.</b></p>		
<p>1. Remove feeler gauge.</p> <p>2. Reconnect throttle position switch harness connector.</p> <p>3. Start engine.</p> <p>4. Warm up engine to normal operating temperature.</p> <p>5. Stop engine. (Turn ignition switch "OFF".)</p> <p>6. Turn ignition switch "ON" and wait at least 5 seconds.</p>		
		
SEF864V		
<p>7. Turn ignition switch "OFF" and wait at least 10 seconds.</p> <p>8. Repeat steps 6 and 7, 20 times.</p>		
▶ GO TO 13.		

## TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

<b>13</b>	<b>CHECK (1ST TRIP) DTC</b>	
1. Start engine and warm it up to normal operating temperature. 2. Rev (2,000 to 3,000 rpm) two or three times. 3. Make sure no (1st trip) DTC is displayed with CONSULT-II or GST.		
<b>OK or NG</b>		
OK	▶	GO TO 15.
NG	▶	GO TO 14.

<b>14</b>	<b>REPAIR MALFUNCTION</b>	
Repair or replace components as necessary according to corresponding "Diagnostic Procedure".		
▶ GO TO 13.		

<b>15</b>	<b>CHECK TARGET IDLE SPEED</b>	
<b>Ⓜ With CONSULT-II</b> 1. Start engine and warm it up to normal operating temperature. 2. Select "ENG SPEED" in "DATA MONITOR" mode with CONSULT-II. 3. Check idle speed. <b>M/T: 625±50 rpm (VQ30DE engine)</b> <b>M/T: 675±50 rpm (VQ20DE engine)</b> <b>A/T: 700±50 rpm (in "P" or "N" position)</b>		
<b>ⓧ Without CONSULT-II</b> 1. Start engine and warm it up to normal operating temperature. 2. Check idle speed. <b>M/T: 625±50 rpm (VQ30DE engine)</b> <b>M/T: 675±50 rpm (VQ20DE engine)</b> <b>A/T: 700±50 rpm (in "P" or "N" position)</b>		
<b>OK or NG</b>		
OK	▶	GO TO 25.
NG	▶	GO TO 16.

<b>16</b>	<b>PERFORM IDLE AIR VOLUME LEARNING</b>	
Refer to "Idle Air Volume Learning", EC-41.		
<b>Which is the result CMPLT or INCMP?</b>		
<b>CMPLT or INCMP</b>		
CMPLT	▶	GO TO 17.
INCMP	▶	1. Follow the construction of "Idle Air Volume Learning". 2. GO TO 16.

## TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

<b>17</b>	<b>CHECK TARGET IDLE SPEED AGAIN</b>	
<p><b>Ⓟ With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Select "ENG SPEED" in "DATA MONITOR" mode with CONSULT-II.</li> <li>3. Check idle speed. <ul style="list-style-type: none"> <li><b>M/T: 625±50 rpm (VQ30DE engine)</b></li> <li><b>M/T: 675±50 rpm (VQ20DE engine)</b></li> <li><b>A/T: 700±50 rpm (in "P" or "N" position)</b></li> </ul> </li> </ol>		
<p><b>ⓧ Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Check idle speed. <ul style="list-style-type: none"> <li><b>M/T: 625±50 rpm (VQ30DE engine)</b></li> <li><b>M/T: 675±50 rpm (VQ20DE engine)</b></li> <li><b>A/T: 700±50 rpm (in "P" or "N" position)</b></li> </ul> </li> </ol> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 23.
NG (Models with Euro-OBD system)	▶	GO TO 19.
NG (Models without Euro-OBD system)	▶	GO TO 18.

<b>18</b>	<b>CHECK IACV-AAC VALVE CIRCUIT FOR OPEN AND SHORT</b>	
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Check IACV-AAC valve circuit for open and short. Refer to "Diagnostic Procedure", EC-472.</li> </ol> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 19.
NG	▶	<ol style="list-style-type: none"> <li>1. Repair or replace.</li> <li>2. GO TO 20.</li> </ol>

<b>19</b>	<b>REPLACE IACV-AAC VALVE</b>	
Replace IACV-AAC valve.		
	▶	GO TO 20.


<b>20</b>	<b>PERFORM IDLE AIR VOLUME LEARNING</b>	
Refer to "Idle Air Volume Learning", EC-41. <b>Which is the result CMPLT or INCMP?</b> <p style="text-align: center;"><b>CMPLT or INCMP</b></p>		
CMPLT	▶	GO TO 21.
INCMP	▶	<ol style="list-style-type: none"> <li>1. Follow the construction of "Idle Air Volume Learning".</li> <li>2. GO TO 16.</li> </ol>

## TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

<b>21</b>	<b>CHECK TARGET IDLE SPEED AGAIN</b>	
<p><b>Ⓜ With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Select "ENG SPEED" in "DATA MONITOR" mode with CONSULT-II.</li> <li>3. Check idle speed. <ul style="list-style-type: none"> <li><b>M/T: 625±50 rpm (VQ30DE engine)</b></li> <li><b>M/T: 675±50 rpm (VQ20DE engine)</b></li> <li><b>A/T: 700±50 rpm (in "P" or "N" position)</b></li> </ul> </li> </ol>		
<p><b>ⓧ Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Check idle speed. <ul style="list-style-type: none"> <li><b>M/T: 625±50 rpm (VQ30DE engine)</b></li> <li><b>M/T: 675±50 rpm (VQ20DE engine)</b></li> <li><b>A/T: 700±50 rpm (in "P" or "N" position)</b></li> </ul> </li> </ol> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶▶	GO TO 23.
NG	▶▶	GO TO 22.

<b>22</b>	<b>CHECK ECM FUNCTION</b>	
<ol style="list-style-type: none"> <li>1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is rarely the case.)</li> <li>2. Perform initialization of NVIS (NATS) system and registration of NVIS (NATS) ignition key IDs. Refer to "NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)", EC-60.</li> </ol>		
		▶▶ GO TO 16.


<b>23</b>	<b>CHECK IGNITION TIMING</b>	
<ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Check ignition timing at idle using a timing light.</li> </ol>		
		
<p><b>Ignition timing:</b></p> <ul style="list-style-type: none"> <li><b>M/T 15°±5° BTDC (VQ30DE engine)</b></li> <li><b>M/T 9°±5° BTDC (VQ20DE engine)</b></li> <li><b>A/T 15°±5° BTDC (in "P" or "N" position) (VQ30DE engine)</b></li> <li><b>A/T 9°±5° BTDC (in "P" or "N" position) (VQ20DE engine)</b></li> </ul> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶▶	GO TO 31.
NG	▶▶	GO TO 24.

SEF572X

## TROUBLE DIAGNOSIS — BASIC INSPECTION

*Basic Inspection (Cont'd)*

<b>24</b>	<b>CHECK TIMING CHAIN INSTALLATION</b>	
Check timing chain installation. Refer to EM-28, "Installation".		
<b>OK or NG</b>		
OK	▶	GO TO 22.
NG	▶	1. Repair the timing chain installation. 2. GO TO 16.

<b>25</b>	<b>CHECK IGNITION TIMING</b>	
<p>1. Start engine and let it idle. 2. Check ignition timing at idle using a timing light.</p>		
		
SEF572X		
<p><b>Ignition timing:</b>  <b>M/T 15°±5° BTDC (VQ30DE engine)</b>  <b>M/T 9°±5° BTDC (VQ20DE engine)</b>  <b>A/T 15°±5° BTDC (in "P" or "N" position) (VQ30DE engine)</b>  <b>A/T 9°±5° BTDC (in "P" or "N" position) (VQ20DE engine)</b></p>		
<b>OK or NG</b>		
OK	▶	GO TO 31.
NG	▶	GO TO 26.

<b>26</b>	<b>PERFORM IDLE AIR VOLUME LEARNING</b>	
Refer to "Idle Air Volume Learning", EC-41.		
<b>Which is the result CMPLT or INCMP?</b>		
<b>CMPLT or INCMP</b>		
CMPLT	▶	GO TO 27.
INCMP	▶	1. Follow the construction of "Idle Air volume Learning". 2. GO TO 26.

## TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

<b>27</b>	<b>CHECK TARGET IDLE SPEED AGAIN</b>	
<p><b>Ⓟ With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Select "ENG SPEED" in "DATA MONITOR" mode with CONSULT-II.</li> <li>3. Check idle speed.               <ul style="list-style-type: none"> <li><b>M/T: 625±50 rpm (VQ30DE engine)</b></li> <li><b>M/T: 675±50 rpm (VQ20DE engine)</b></li> <li><b>A/T: 700±50 rpm (in "P" or "N" position)</b></li> </ul> </li> </ol>		
<p><b>ⓧ Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Check idle speed.               <ul style="list-style-type: none"> <li><b>M/T: 625±50 rpm (VQ30DE engine)</b></li> <li><b>M/T: 675±50 rpm (VQ20DE engine)</b></li> <li><b>A/T: 700±50 rpm (in "P" or "N" position)</b></li> </ul> </li> </ol> <p style="text-align: right;"><b>OK or NG</b></p>		
OK	▶	GO TO 29.
NG	▶	GO TO 28.

<b>28</b>	<b>CHECK ECM FUNCTION</b>	
<ol style="list-style-type: none"> <li>1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is rarely the case.)</li> <li>2. Perform initialization of NVIS (NATS) system and registration of NVIS (NATS) ignition key IDs. Refer to "NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)", EC-60.</li> </ol>		
	▶	GO TO 26.

<b>29</b>	<b>CHECK IGNITION TIMING AGAIN</b>	
<p>Check ignition timing again. Refer to Test No. 25.</p> <p style="text-align: right;"><b>OK or NG</b></p>		
OK	▶	GO TO 31.
NG	▶	GO TO 30.

<b>30</b>	<b>CHECK TIMING CHAIN INSTALLATION</b>	
<p>Check timing chain installation. Refer to EM-28, "Installation".</p> <p style="text-align: right;"><b>OK or NG</b></p>		
OK	▶	GO TO 28.
NG	▶	<ol style="list-style-type: none"> <li>1. Repair the timing chain installation.</li> <li>2. GO TO 26.</li> </ol>

<b>31</b>	<b>ERASE UNNECESSARY DTC</b>	
<p>After this inspection, unnecessary DTC No. might be displayed. Erase the stored memory in ECM and TCM (Transmission control module). Refer to "How to Erase Emission-Related Diagnostic Information", EC-56 and AT-38, "HOW TO ERASE DTC".</p>		
	▶	<b>INSPECTION END</b>

# TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

*DTC Inspection Priority Chart*

## DTC Inspection Priority Chart

NFEC0652

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> <li>● P0100 Mass air flow sensor</li> <li>● P0110 Intake air temperature sensor</li> <li>● P0115 Engine coolant temperature sensor</li> <li>● P0120 Throttle position sensor</li> <li>● P0180 Fuel tank temperature sensor</li> <li>● P0325 Knock sensor</li> <li>● P0335 P1336 Crankshaft position sensor (POS)</li> <li>● P0340 Camshaft position sensor (PHASE)</li> <li>● P0500 Vehicle speed sensor</li> <li>● P0605 ECM</li> <li>● P1320 Ignition signal</li> <li>● P1335 Crankshaft position sensor (REF)</li> <li>● P1605 A/T diagnosis communication line</li> <li>● P1706 Park/Neutral position (PNP) switch</li> </ul>
2	<ul style="list-style-type: none"> <li>● P0130-P0134, P0150-P0154 Heated oxygen sensor 1 (front)</li> <li>● P0135 P0155 Heated oxygen sensor 1 heater (front)</li> <li>● P0137-P0140, P0157-P0160 Heated oxygen sensor 2 (rear)</li> <li>● P0141 P0161 Heated oxygen sensor 2 heater (rear)</li> <li>● P0443 EVAP canister purge volume control solenoid valve</li> <li>● P0510 Closed throttle position switch</li> <li>● P0705-P0755 P1705 P1760 A/T related sensors, solenoid valves and switches</li> </ul>
3	<ul style="list-style-type: none"> <li>● P0171 P0172 P0174 P0175 Fuel injection system function</li> <li>● P0306 - P0300 Misfire</li> <li>● P0420 P0430 Three way catalyst function</li> <li>● P0505 IACV-AAC valve</li> <li>● P0731-P0734 A/T function</li> <li>● P1131 Swirl control valve control solenoid valve</li> </ul>

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Fail-safe Chart

### Fail-safe Chart

=NFEC0653

The ECM enters fail-safe mode, if any of the following malfunctions is detected due to the open or short circuit. When the ECM enters the fail-safe mode of ECM, the MI illuminates.

DTC No.	Detected items	Engine operating condition in fail-safe mode	
P0100	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.	
P0115	Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
		Condition	Engine coolant temperature decided (CONSULT-II display)
		Just as ignition switch is turned ON or Start	40°C (104°F)
		More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)	
P0120	Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
		Condition	Driving condition
		When engine is idling	Normal
	When accelerating	Poor acceleration	
P1335	Crankshaft position sensor (REF) circuit	Compression TDC signal (120° signal) is controlled by camshaft position sensor (PHASE) signal and crankshaft position sensor (POS) signal. Ignition timing will be delayed 0° to 2°.	
Unable to access ECM	ECM	<b>ECM fail-safe activating condition</b> The computing function of the ECM was judged to be malfunctioning. When the fail-safe system activates (i.e., if the ECM detects a malfunction condition in the CPU of ECM), the MI on the instrument panel lights to warn the driver. However it is not possible to access ECM and DTC cannot be confirmed. <b>Engine control with fail-safe</b> When ECM fail-safe is operating, fuel injection, ignition timing, fuel pump operation, IACV-AAC valve operation and cooling fan operation are controlled under certain limitations.	
		ECM fail-safe operation	
		<b>Engine speed</b>	<b>Engine speed will not rise more than 3,000 rpm</b>
		Fuel injection	Simultaneous multiport fuel injection system
		Ignition timing	Ignition timing is fixed at the preset valve
		Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls
		IACV-AAC valve	Full open
		Cooling fans	Cooling fan relay "ON" (High speed condition) when engine is running, and "OFF" when engine stalls.
		Replace ECM, if ECM fail-safe condition is confirmed.	

# TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart

## Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

NFEC0041

NFEC0041S01

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP: HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	EC-533
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			EC-37
	Injector circuit	1	1	2	3	2		2	2			2			EC-523
	Evaporative emission system														EC-32
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		EC-35
	Incorrect idle speed adjustment						1	1	1	1		1			EC-90
	IACV-AAC valve circuit	1	1	2	3	3	2	2	2	2		2		2	EC-324, 469
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-90
	Ignition circuit	1	1		2	2		2	2			2			EC-369, EC-495
Main power supply and ground circuit											2				EC-127
Air conditioner circuit		2	2	3	3	3	3	3	3	3		3		2	HA section

1 - 6: The numbers refer to the order of inspection.  
(continued on next page)

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

		SYMPTOM												Reference page		
		HARD/NO START/RESTART (EXCP: HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA		
Engine control	Crankshaft position sensor (REF) circuit	2	2												EC-380	
	Crankshaft position sensor (POS) circuit															EC-295, 451, 387
	Camshaft position sensor (PHASE) circuit	3													EC-303	
	Mass air flow sensor circuit	1			2										EC-134	
	Heated oxygen sensor 1 (front) circuit														EC-158, 415	
	Engine coolant temperature sensor circuit	1	1	2	3	2	3	2	2	3		2			EC-146	
	Throttle position sensor circuit						2				2				EC-151	
	Incorrect throttle position sensor adjustment		3	1		1	1	1	1	1			1		EC-90	
	Vehicle speed sensor circuit		2	3		3									EC-320, 465	
	Knock sensor circuit			2									3		EC-289	
	ECM	2	2	3	3	3	3	3	3	3	3				EC-104, 341	
	Start signal circuit	2														EC-529
	Park/Neutral position switch circuit			3		3							3		EC-398, 510	
	Power steering oil pressure switch circuit		2												EC-543	
	Electronic controlled engine mount control circuit							3	3						EC-539	
Electrical load signal circuit														EC-552		

1 - 6: The numbers refer to the order of inspection.  
(continued on next page)

# TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

## SYSTEM — ENGINE MECHANICAL & OTHER

NFEC0041S02

		SYMPTOM												Reference section		
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA		
Fuel	Fuel tank	5	5												FE section	
	Fuel piping			5	5	5		5	5		5					
	Vapor lock															
	Valve deposit															
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	5		5					
Air	Air duct														—	
	Air cleaner															
	Air leakage from air duct (Mass air flow sensor — throttle body)		5	5		5		5	5		5					
	Throttle body, Throttle wire	5			5		5			5				FE section		
	Air leakage from intake manifold/Collector/Gasket													—		
Cranking	Battery	1	1	1		1		1	1			1		1	EL section	
	Alternator circuit															
	Starter circuit	3														
	Flywheel/Drive plate	6												EM section		
	PNP switch	4												AT section		

1 - 6: The numbers refer to the order of inspection.  
(continued on next page)

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

		SYMPTOM													Reference section
		HARD/NO START/RESTART (EXCP: HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Engine	Cylinder head	5	5	5	5	5		5	5			5			EM section
	Cylinder head gasket										4	5	3		
	Cylinder block												4		
	Piston														
	Piston ring														
	Connecting rod	6	6	6	6	6		6	6			6			
	Bearing														
	Crankshaft														
Valve mechanism	Timing chain														EM section
	Camshaft	5	5	5	5	5		5	5			5			
	Intake valve												3		
	Exhaust valve														
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	5	5	5	5	5	5	5		5				FE section	
	Three way catalyst														
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	5	5	5	5	5		5	5			5		MA, EM, LC section	
	Oil level (Low)/Filthy oil													LC section	
Cooling	Radiator/Hose/Radiator filler cap														EC section
	Thermostat									5					
	Water pump														
	Water gallery	5	5	5	5	5		5	5		4	5			
	Cooling fan									5					
	Coolant level (low)/Contaminated coolant													MA section	

1 - 6: The numbers refer to the order of inspection.

# TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

	SYMPTOM													Reference section
	HARD/NO START/RESTART (EXCP: HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
NVIS (NISSAN Vehicle Immobilizer System — NATS)	1	1												EC-60 or EL section

1 - 6: The numbers refer to the order of inspection.

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0042

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- \* Specification data may not be directly related to their components signals/values/operations.

i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

- If the real-time diagnosis results are NG and the on board diagnostic system results are OK when diagnosing the mass air flow sensor, first check to see if the fuel pump control circuit is normal.

MONITOR ITEM	CONDITION		SPECIFICATION
ENG SPEED CKPS-RPM (POS)	<ul style="list-style-type: none"> <li>● Tachometer: Connect</li> <li>● Run engine and compare tachometer indication with the CONSULT-II value.</li> </ul>		Almost the same speed as the CONSULT-II value.
POS COUNT	<ul style="list-style-type: none"> <li>● Engine: Running</li> </ul>		179 - 181
MAS A/F SE-B1	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: "OFF"</li> <li>● Shift lever: "N"</li> <li>● No-load</li> </ul>	Idle	1.2 - 1.8V
		2,500 rpm	1.6 - 2.2V
COOLAN TEMP/S	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> </ul>		More than 70°C (158°F)
HO2S1 (B1) HO2S1 (B2)	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> </ul>	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)			LEAN ↔ RICH Changes more than 5 times during 10 seconds.
HO2S2 (B1) HO2S2 (B2)	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> </ul>	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)			LEAN ↔ RICH

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

CONSULT-II Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	CONDITION		SPECIFICATION
VHCL SPEED SE	● Turn drive wheels and compare speedometer indication with the CONSULT-II value		Almost the same speed as the CONSULT-II value
BATTERY VOLT	● Ignition switch: ON (Engine stopped)		11 - 14V
THRTL POS SEN	● Engine: After warming up, idle the engine	Throttle valve: fully closed	0.15 - 0.85V
	● Engine: After warming up ● Ignition switch: ON (Engine stopped)	Throttle valve: fully opened	3.5 - 4.7V
START SIGNAL	● Ignition switch: ON → START → ON		OFF → ON → OFF
CLSD THL/P SW CLSD THL POS	● Engine: After warming up, idle the engine	Throttle valve: Idle position	ON
		Throttle valve: Slightly open	OFF
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: "OFF"	OFF
		Air conditioner switch: "ON" (Compressor operates.)	ON
P/N POSI SW	● Ignition switch: ON	Shift lever: "P" or "N" (A/T models) Neutral (M/T models)	ON
		Except above	OFF
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel in neutral position (forward direction)	OFF
		The steering wheel is turned	ON
AMB TEMP SW	● Ignition switch: ON ● Compare ambient air temperature with the following:	Below 19°C (66°F)	OFF
		Above 25°C (77°F)	ON
IGNITION SW	● Ignition switch: ON → OFF → ON		ON → OFF → ON
INJ PULSE-B2 INJ PULSE-B1	● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load	Idle	2.4 - 3.2 msec
		2,000 rpm	1.9 - 2.8 msec
B/FUEL SCHDL	● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load	Idle	2.0 - 3.2 msec
		2,000 rpm	1.4 - 2.6 msec
IGN TIMING	● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load	Idle	9°±5° BTDC (VQ20DE) 15°±5° BTDC (VQ30DE)
		2,000 rpm	More than 25° BTDC
IACV-AAC/V	● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load	Idle	2 - 10 step
		2,000 rpm	—
PURG VOL C/V	● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load	Idle	0 %
		2,000 rpm	—
A/F ALPHA-B2 A/F ALPHA-B1	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	54 - 155%
AIR COND RLY	● Air conditioner switch: OFF → ON		OFF → ON

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

*CONSULT-II Reference Value in Data Monitor Mode (Cont'd)*

MONITOR ITEM	CONDITION	SPECIFICATION	
FUEL PUMP RLY	<ul style="list-style-type: none"> <li>● Ignition switch is turned to ON (Operates for 5 seconds)</li> <li>● Engine running and cranking</li> </ul>	ON	
	Except as shown above	OFF	
COOLING FAN	<ul style="list-style-type: none"> <li>● After warming up engine, idle the engine.</li> <li>● Air conditioner switch: "OFF"</li> </ul>	Engine coolant temperature is 94°C (201°F) or less	OFF
		Engine coolant temperature is between 95°C (203°F) and 104°C (219°F)	Low
		Engine coolant temperature is 105°C (221°F) or more	HIGH
HO2S1 HTR (B1)	● Engine speed: Below 3,600 rpm	ON	
HO2S1 HTR (B2)	● Engine speed: Above 3,600 rpm	OFF	
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Engine speed: Above 3,600 rpm</li> </ul>	OFF	
	● Engine speed: Below 3,600 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more]	ON	
CAL/LD VALUE	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: "OFF"</li> <li>● Shift lever: "N"</li> <li>● No-load</li> </ul>	Idle	14.0 - 33.0%
		2,500 rpm	12.0 - 25.0%
ABSOL TH·P/S	● Engine: After warming up	Throttle valve: fully closed	0.0%
	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Ignition switch: ON (Engine stopped)</li> </ul>	Throttle valve: fully opened	Approx. 80%
MASS AIRFLOW	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: "OFF"</li> <li>● Shift lever: "N"</li> <li>● No-load</li> </ul>	Idle	2.0 - 6.0 g·m/s
		2,500 rpm	7.0 - 20.0 g·m/s
ABSOL PRES/SE	● Ignition switch: ON		Approx. 4.4V
SWRL CONT S/V	● Engine speed: Idle	Engine coolant temperature is between 15°C (59°F) to 50°C (122°F).	ON
		Engine coolant temperature is above 50°C (122°F).	OFF
ENGINE MOUNT	● Engine: Running	Idle	"IDLE"
		2,000 rpm	"TRVL"

### Major Sensor Reference Graph in Data Monitor Mode

The following are the major sensor reference graphs in "DATA MONITOR" mode.

NFEC0043

#### THRTL POS SEN, ABSOL TH·P/S, CLSD THL POS


Below is the data for "THRTL POS SEN", "ABSOL TH·P/S" and "CLSD THL POS" when depressing the accelerator pedal with the ignition switch "ON".

NFEC0043S01

The signal of "THRTL POS SEN" and "ABSOL TH·P/S" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Major Sensor Reference Graph in Data Monitor Mode (Cont'd)




### ENG SPEED, MAS A/F SE-B1, THRTL POS SEN, HO2S2 (B1), HO2S1 (B1), INJ PULSE-B1

NFEC0043S02


Below is the data for “ENG SPEED”, “MAS A/F SE-B1”, “THRTL POS SEN”, “HO2S2 (B1)”, “HO2S1 (B1)” and “INJ PULSE-B1” when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.

Each value is for reference, the exact value may vary.




# TROUBLE DIAGNOSIS — GENERAL DESCRIPTION


Major Sensor Reference Graph in Data Monitor Mode (Cont'd)




- "THRTL POS SEN" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "HO2S1 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.






- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

SEF242YC

# TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value



## ECM Terminals and Reference Value

NFEC0044

### PREPARATION

NFEC0044S01

1. ECM is located behind the instrument lower cover. For this inspection, remove instrument lower cover.
2. Remove ECM harness protector.
3. Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.
  - Open harness securing clip to make testing easier.
  - Use extreme care not to touch 2 pins at one time.
  - Data is for comparison and may not be exact.

## ECM HARNESS CONNECTOR TERMINAL LAYOUT

NFEC0044S02

101	102	1	2	3	4	5	6	7	8	9	10			58	59	60	61	62	63	64	65	66	67	109	110							
103	104	11	12	13	14	15	16	17	18	19	39	40	41	42	43	44	45	46	47	48	68	69	70	71	72	73	74	75	76	111	112	
105	106	20	21	22	23	24	25	26	27	28	29	49	50	51	52	53	54	55	56	57	77	78	79	80	81	82	83	84	85	86	113	114
107	108	30	31	32	33	34	35	36	37	38											87	88	89	90	91	92	93	94	95	115	116	



SEF970W

### ECM INSPECTION TABLE

NFEC0044S03



Specification data are reference values and are measured between each terminal and ground.

#### CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.





## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

*ECM Terminals and Reference Value (Cont'd)*

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	PU/R	EVAP canister purge volume control sole- noid valve	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)  
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is about 2,000 rpm (More than 100 seconds after starting engine).</li> </ul>	BATTERY VOLTAGE (11 - 14V)  
2	R/L	Heated oxygen sensor 1 heater (front) (bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm.</li> </ul>	0 - 1.0V
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is above 3,600 rpm.</li> </ul>	BATTERY VOLTAGE (11 - 14V)
3	OR/L	Heated oxygen sensor 1 heater (front) (bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm.</li> </ul>	0 - 1.0V
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is above 3,600 rpm.</li> </ul>	BATTERY VOLTAGE (11 - 14V)
4	R/L	Heated oxygen sensor 2 heater (rear) (bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm.</li> <li>● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more.</li> </ul>	0 - 1.0V
			<b>[Ignition switch "ON"]</b> <ul style="list-style-type: none"> <li>● Engine stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is above 3,600 rpm.</li> </ul>	BATTERY VOLTAGE (11 - 14V)
5	P/B	Heated oxygen sensor 2 heater (rear) (bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is below 3,600 rpm.</li> <li>● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more.</li> </ul>	0 - 1.0V
			<b>[Ignition switch "ON"]</b> <ul style="list-style-type: none"> <li>● Engine stopped</li> </ul> <b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is above 3,600 rpm.</li> </ul>	BATTERY VOLTAGE (11 - 14V)
6 7 8 17	W/PU Y/B Y GY/L	IACV-AAC valve	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Idle speed</li> </ul>	0.1 - 14V
16	Y/G	VIAS control solenoid valve	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Idle speed</li> </ul>	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Engine speed is above 5,000 rpm.</li> </ul>	0 - 1.0V

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
21 22 23 30 31 32	Y/R G/R L/R GY PU/W GY/R	Ignition signal No. 1 Ignition signal No. 2 Ignition signal No. 3 Ignition signal No. 4 Ignition signal No. 5 Ignition signal No. 6	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	0 - 0.2V★  SEF399T
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Engine speed is 2,500 rpm.</li> </ul>	0.1 - 0.3V★  SEF645T
25	W/G	Tachometer	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	9 - 11V★  SEF579X
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Engine speed is 2,500 rpm.</li> </ul>	9 - 11V★  SEF580X
26	W/B	ECM relay (Self shutt-off)	<b>[Engine is running]</b> <b>[Ignition switch "OFF"]</b> <ul style="list-style-type: none"> <li>• For a few seconds after turning ignition switch "OFF"</li> </ul>	0 - 1.5V
			<b>[Ignition switch "OFF"]</b> <ul style="list-style-type: none"> <li>• A few seconds passed after turning ignition switch "OFF"</li> </ul>	BATTERY VOLTAGE (11 - 14V)
27	B/R	Air conditioner relay	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>• Both A/C switch and blower switch are "ON" (Compressor is operating).</li> </ul>	0 - 1.0V
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>• A/C switch is "OFF".</li> </ul>	BATTERY VOLTAGE (11 - 14V)
28	B/P	Fuel pump relay	<b>[Ignition switch "ON"]</b> <ul style="list-style-type: none"> <li>• For 1 second after turning ignition switch "ON"</li> </ul>	0 - 1.5V
			<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>• 1 second passed after turning ignition switch "ON".</li> </ul>	BATTERY VOLTAGE (11 - 14V)


## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

*ECM Terminals and Reference Value (Cont'd)*

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
29	G	Swirl control valve control solenoid valve	<b>[Engine is running]</b> ● Idle speed ● Engine coolant temperature is between 15 to 50°C (59 to 122°F).	0 - 1.0V
			<b>[Engine is running]</b> ● Idle speed ● Engine coolant temperature is above 50°C (122°F).	BATTERY VOLTAGE (11 - 14V)
34	LG	Cooling fan relay (High)	<b>[Engine is running]</b> ● Cooling fan is operating at high speed.	0 - 1.0V
			<b>[Engine is running]</b> ● Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
35	BR/R	Cooling fan relay (Low)	<b>[Engine is running]</b> ● Cooling fan is operating.	0 - 1.0V
			<b>[Engine is running]</b> ● Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
36	Y	A/T signal No. 3	<b>[Engine is running]</b> ● Idle speed	Approximately 0 - 5V Output voltage fluctuates periodically.
37	LG	A/T signal No. 5	<b>[Engine is running]</b> ● Idle speed	Approximately 0 - 5V Output voltage fluctuates periodically.
38	LG/B	MI	<b>[Ignition switch "ON"]</b>	0 - 1.0V
			<b>[Engine is running]</b> ● Idle speed	BATTERY VOLTAGE (11 - 14V)
42	BR/W	Start signal	<b>[Ignition switch "ON"]</b>	Approximately 0V
			<b>[Ignition switch "START"]</b>	9 - 12V
43	R	Ignition switch	<b>[Ignition switch "OFF"]</b>	0V
			<b>[Ignition switch "ON"]</b>	BATTERY VOLTAGE (11 - 14V)
44	G/OR (A/T) G/W (M/T)	PNP switch	<b>[Ignition switch "ON"]</b> ● Gear position is "Neutral position" (M/T models). ● Gear position is "P" or "N" (A/T models).	Approximately 0V
			<b>[Ignition switch "ON"]</b> ● Except the above gear position	BATTERY VOLTAGE (11 - 14V)
45	G/B	Air conditioner switch signal	<b>[Engine is running]</b> ● Both A/C switch and blower switch are "ON".	Approximately 0V
			<b>[Engine is running]</b> ● A/C switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
46	W/L	Ambient air temperature switch signal	<b>[Engine is running]</b> ● Idle speed ● Ambient air temperature is above 25°C (77°F). ● Air conditioner is operating.	0V
			<b>[Engine is running]</b> ● Idle speed ● Ambient air temperature is above 25°C (77°F). ● Air conditioner is not operating.	Approximately 5V

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION




ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Power steering oil pressure switch	<b>[Engine is running]</b> ● Steering wheel is being turned.	0 - 1.0V
			<b>[Engine is running]</b> ● Steering wheel is not being turned.	BATTERY VOLTAGE (11 - 14V)
48	B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Engine ground
49	W	Electronic controlled engine mount-1	<b>[Engine is running]</b> ● Idle speed	0 - 1.0V
			<b>[Engine is running]</b> ● Except the above	BATTERY VOLTAGE (11 - 14V)
50	W/R	Electronic controlled engine mount-2	<b>[Engine is running]</b> ● Idle speed	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> ● Except the above	0 - 1.0V
51	PU	A/C cut signal	<b>[Engine is running]</b> ● Air conditioner is operating.	0 - 0.5V
52	W/G	Electrical load signal	<b>[Engine is running]</b> ● Rear window defogger: ON ● Hi-beam headlamp: ON	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> ● Electrical load: OFF	0V
56	GY/L	Throttle position switch (Closed position)	<b>[Engine is running]</b> ● Accelerator pedal fully released	BATTERY VOLTAGE (11 - 14V)
			<b>[Engine is running]</b> ● Accelerator pedal depressed	Approximately 0V
57	B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Engine ground
58	B	Sensors' ground	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	Approximately 0V
60	BR/W	A/T diagnosis communication line	<b>[Engine is running]</b> ● Idle speed	Approximately 0 - 2.0V Output voltage fluctuates periodically.
61	W	Mass air flow sensor	<b>[Engine is running]</b> ● Warm-up condition ● Idle speed	1.2 - 1.8V
			<b>[Engine is running]</b> ● Warm-up condition ● Engine speed is 2,500 rpm.	1.6 - 2.2V
62	W	Heated oxygen sensor 1 (front) (bank 2)	<b>[Engine is running]</b> ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change) 

SEF059V

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

*ECM Terminals and Reference Value (Cont'd)*

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
63	W	Heated oxygen sensor 1 (front) (bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed is 2,000 rpm.</li> </ul>	0 - Approximately 1.0V (Periodically change)  SEF059V
64	Y/G	Intake air temperature sensor	<b>[Engine is running]</b>	Approximately 0 - 4.8V Output voltage varies with intake air temperature.
65 75	W W	Crankshaft position sensor (REF)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 2.3V★ (AC voltage)  SEF581X
66 76	W W	Camshaft position sensor (PHASE)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 4.2V★ (AC voltage)  SEF582X
67	W/L	Power supply for ECM (Buck-up)	<b>[Ignition switch "OFF"]</b>	BATTERY VOLTAGE (11 - 14V)
68	BR	A/T signal No. 1	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Idle speed</li> </ul>	Approximately 0 - 5V Output voltage fluctuates periodically.
69	GY	Data link connector	<b>[Ignition switch "ON"]</b> <ul style="list-style-type: none"> <li>● CONSULT-II is turned "ON".</li> </ul>	Approximately 0V
70	Y	Engine coolant temperature sensor	<b>[Engine is running]</b>	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.
71	W	Heated oxygen sensor 2 (rear) (bank 2)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed is 2,000 rpm.</li> </ul>	0 - Approximately 1.0V
72	W	Heated oxygen sensor 2 (rear) (bank 1)	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Engine speed is 2,000 rpm.</li> </ul>	0 - Approximately 1.0V
73	B	Mass air flow sensor ground	<b>[Engine is running]</b> <ul style="list-style-type: none"> <li>● Warm-up condition</li> <li>● Idle speed</li> </ul>	Approximately 0V

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
77	GY	A/T signal No. 2	<b>[Engine is running]</b> ● Idle speed	Approximately 0 - 5V Output voltage fluctuates periodically.
78	OR	A/T signal No. 4	<b>[Engine is running]</b> ● Idle speed	Approximately 0 - 5V Output voltage fluctuates periodically.
80	W	Absolute pressure sensor	<b>[Ignition switch "ON"]</b>	Approximately 4.4V
81	W	Refrigerant pressure sensor	<b>[Engine is running]</b> ● <b>Warm-up condition</b> ● Both A/C switch and blower switch are "ON". (Compressor operates.)	0.36 - 3.88V
82	W	Throttle position sensor signal output	<b>[Engine is running]</b> ● <b>Warm-up condition</b> ● Accelerator pedal fully released	Approximately 0.4V
			<b>[Ignition switch "ON"]</b> ● Accelerator pedal fully depressed	Approximately 4V
85	W	Crankshaft position sensor (POS)	<b>[Engine is running]</b> ● Idle speed	Approximately 2.4V  SEF057V
			<b>[Engine is running]</b> ● Engine speed is 2,000 rpm.	Approximately 2.3V  SEF058V
86	P/L	Vehicle speed sensor	<b>[Engine is running]</b> ● Jack up front wheels. ● In 1st gear position ● 10 km/h (6 MPH)	Approximately 2.5V  SEF583X
			<b>[Engine is running]</b> ● Jack up front wheels. ● In 2nd gear position ● 30 km/h (19 MPH)	Approximately 2.0V  SEF584X

## TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

*ECM Terminals and Reference Value (Cont'd)*

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
91	L/W	Throttle position sensor	<b>[Engine is running]</b> ● Warm-up condition ● Accelerator pedal fully released	0.15 - 0.85V
			<b>[Ignition switch "ON"]</b> ● Accelerator pedal fully depressed	3.5 - 4.7V
92	P/L	Fuel tank temperature sensor	<b>[Engine is running]</b>	Approximately 0 - 4.8V Output voltage varies with fuel tank temperature.
93	W	Knock sensor	<b>[Engine is running]</b> ● Idle speed	Approximately 2.5V
95	BR	Data link connector	<b>[Ignition switch "ON"]</b> ● CONSULT-II is turned "ON".	Approximately 0V
101 102 103 104 105 107	R/B L/W R/W PU/R R/Y R/L	Injector No. 1 Injector No. 5 Injector No. 2 Injector No. 6 Injector No. 3 Injector No. 4	<b>[Engine is running]</b> ● Idle speed	BATTERY VOLTAGE (11 - 14V)
106 108	B B	ECM ground	<b>[Engine is running]</b> ● Idle speed	Engine ground
110 112	R/G R/G	Power supply for ECM	<b>[Ignition switch "ON"]</b>	BATTERY VOLTAGE (11 - 14V)
111	R	Sensors' power supply	<b>[Ignition switch "ON"]</b>	Approximately 5V
115	OR	Data link connector	<b>[Ignition switch "ON"]</b> ● CONSULT-II is turned "ON".	Approximately 2 - 11V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

# TROUBLE DIAGNOSIS — SPECIFICATION VALUE

Description

## Description

The specification (SP) value indicates the tolerance of the value that is displayed in “DATA MONITOR (SPEC)” mode of CONSULT-II during normal operation of the Engine Control System. When the value in “DATA MONITOR (SPEC)” mode is within the SP value, the Engine Control System is confirmed OK. When the value in “DATA MONITOR (SPEC)” mode is NOT within the SP value, the Engine Control System may have one or more malfunctions. NFEC0872

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:


- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

## Testing Condition

- Vehicle driven distance: More than 5,000 km (3,107 miles)
- Barometric pressure: 98.3 - 104.3 kPa (0.9836 - 1.0435 bar, 1.003 - 1.064 kg/cm<sup>2</sup>, 14.25 - 15.12 psi)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Transmission: Warmed-up\*1
- Electrical load: Not applied\*2
- Engine speed: Idle

\*1: For A/T or CVT models, after the engine is warmed up to normal operating temperature, drive vehicle until “FLUID TEMP SE” (A/T or CVT fluid temperature sensor signal) indicates less than 0.9V. For M/T models, drive vehicle for 5 minutes after the engine is warmed up to normal operating temperature.

\*2: Rear window defogger switch, air conditioner switch, lighting switch are “OFF”. Cooling fans are not operating. Steering wheel is straight ahead. NFEC0873



## Inspection Procedure

### NOTE:

Perform “DATA MONITOR (SPEC)” mode in maximum scale display. NFEC0874


1. Perform “Basic Inspection”, EC-90.
2. Confirm that the testing conditions indicated above are met.
3. Select “B/FUEL SCHDL”, “A/F ALPHA-B1/B2” and “MAS A/F SE-B1” in “DATA MONITOR (SPEC)” mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to “Diagnostic Procedure”, EC-123.

# TROUBLE DIAGNOSIS — SPECIFICATION VALUE

Diagnostic Procedure

NFEC0875

## Diagnostic Procedure




Not necessary when open loop at low engine coolant temperature.

(Go to next page.)

SEF613ZA

# TROUBLE DIAGNOSIS — SPECIFICATION VALUE

Diagnostic Procedure (Cont'd)



SEF768Z



## TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

Description

### Description

NFEC0654

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

### COMMON I/I REPORT SITUATIONS

NFEC0654S01

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "[1t]".
III	The symptom described by the customer does not recur.
IV	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for PXXXX does not indicate the problem area.

### Diagnostic Procedure

NFEC0655

<b>1</b>	<b>INSPECTION START</b>
Erase (1st trip) DTCs. Refer to "How to Erase Emission-related Diagnostic Information", EC-56, EC-59.	
▶	GO TO 2.

<b>2</b>	<b>CHECK GROUND TERMINALS</b>
Check ground terminals for corroding or loose connection. Refer to GI-27, "GROUND INSPECTION".	
<b>OK or NG</b>	
OK	▶ GO TO 3.
NG	▶ Repair or replace.

<b>3</b>	<b>SEARCH FOR ELECTRICAL INCIDENT</b>
Perform GI-22, "Incident Simulation Tests".	
<b>OK or NG</b>	
OK	▶ <b>INSPECTION END</b>
NG	▶ Repair or replace.



# TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit


## Main Power Supply and Ground Circuit WIRING DIAGRAM

NFEC0047

EC-MAIN-01



REFER TO THE FOLLOWING.  
 M19, E89 - FUSE BLOCK-JUNCTION BOX (J/B)





MEC834C

# TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

EC-MAIN-02



MEC717C

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
26	W/B	ECM RELAY (SELF-SHUTOFF)	ENGINE RUNNING FOR A FEW SECONDS AFTER TURNING IGN OFF	0 - 1.5V
			A FEW SECONDS PASSED AFTER TURNING IGN OFF	BATTERY VOLTAGE
43	R	IGN	IGN OFF	0V
			IGN ON	BATTERY VOLTAGE
48	B	ECM GROUND	ENGINE RUNNING AT IDLE SPEED	ENGINE GROUND
57	B			
67	W/L	POWER SUPPLY (BACK-UP)	IGN OFF	BATTERY VOLTAGE
106	B	ECM GROUND	ENGINE RUNNING AT IDLE SPEED	ENGINE GROUND
108	B			
110	R/G	POWER SUPPLY FOR ECM	IGN ON	BATTERY VOLTAGE
112	R/G			

SEF366Z


# TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

## DIAGNOSTIC PROCEDURE

NFEC0049

<b>1</b>	<b>INSPECTION START</b>	
Start engine. <b>Is engine running?</b>		
<b>Yes or No</b>		
Yes	▶	GO TO 9.
No	▶	GO TO 2.

<b>2</b>	<b>CHECK ECM POWER SUPPLY CIRCUIT-I</b>	
1. Turn ignition switch "OFF" and then "ON". 2. Check voltage between ECM terminal 43 and ground with CONSULT-II or tester.		
		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	GO TO 3.



SEF291X

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>	
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● Fuse block (J/B) connector M19, E89</li> <li>● 10A fuse</li> <li>● Harness for open or short between ECM and ignition switch</li> </ul>		
▶ Repair harness or connectors.		

<b>4</b>	<b>CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I</b>	
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminals 48, 57, 106, 108 and engine ground. Refer to WIRING DIAGRAM. <b>Continuity should exist.</b>		
4. Also check harness for short to power.		
<b>OK or NG</b>		
OK	▶	GO TO 5.
NG	▶	Repair open circuit or short to power in harness or connectors.

## TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

5	<b>CHECK POWER SUPPLY-II</b>
<p>1. Disconnect ECM relay.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Battery</p> <p style="margin-left: 100px;">ECM relay</p> </div>	
<p>2. Check voltage between ECM relay terminals 2, 6 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="margin-left: 150px;">Voltage: Battery voltage</p> <p style="margin-left: 150px;">OK or NG</p> </div>	
OK	▶ GO TO 7.
NG	▶ GO TO 6.

SEF589PB

SEF292X


6	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● 15A fuses</li> <li>● Harness for open or short between ECM relay and battery</li> </ul>	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

7	<b>CHECK OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>
<p>1. Check harness continuity between ECM terminal 26 and ECM relay terminal 1. <b>Continuity should exist.</b></p> <p>2. Also check harness for short to ground and short to power.</p>	
<b>OK or NG</b>	
OK (Models with Euro-OBD system)	▶ Go to "IGNITION SIGNAL", EC-495.
OK (Models without Euro-OBD system)	▶ Go to "DTC P1320 IGNITION SIGNAL", EC-369.
NG	▶ GO TO 8.


8	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between ECM relay and ECM</li> </ul>	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

## TROUBLE DIAGNOSIS FOR POWER SUPPLY

*Main Power Supply and Ground Circuit (Cont'd)*



9	<b>CHECK ECM POWER SUPPLY CIRCUIT-II</b>
<p>1. Stop engine. 2. Check voltage between ECM terminal 67 and ground with CONSULT-II or tester.</p>	
 <p style="margin-left: 200px;"><b>Voltage: Battery voltage</b></p>	
SEF293X	
<b>OK or NG</b>	
OK	▶ GO TO 11.
NG	▶ GO TO 10.

10	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between ECM and fuse</li> </ul>	
▶ Repair harness or connectors.	

11	<b>CHECK ECM POWER SUPPLY CIRCUIT-III</b>
<p>1. Turn ignition switch "ON" and then "OFF". 2. Check voltage between ECM terminals 110, 112 and ground with CONSULT-II or tester.</p>	
 <p style="margin-left: 200px;"><b>Voltage:</b> After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop approximately 0V.</p>	
SEF294X	
<b>OK or NG</b>	
OK	▶ GO TO 17.
NG (Battery voltage does not exist.)	▶ GO TO 12.
NG (Battery voltage exists for more than a few seconds.)	▶ GO TO 14.

## TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

12	<b>CHECK ECM POWER SUPPLY CIRCUIT-IV</b>
<p>1. Disconnect ECM relay.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Battery</p> <p style="margin-left: 100px;">ECM relay</p> </div>	
<p>2. Check voltage between ECM relay terminal 3 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Voltage: Battery voltage</p> </div>	
<p>OK or NG</p>	
OK	▶ GO TO 14.
NG	▶ GO TO 13.

SEF589PB

SEF295X


13	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness for open or short between ECM relay and 15A fuse</li> </ul>	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

14	<b>CHECK HARNESS CONTINUITY BETWEEN ECM RELAY AND ECM FOR OPEN AND SHORT</b>
<p>1. Check harness continuity between ECM terminals 110, 112 and ECM relay terminal 5. Refer to WIRING DIAGRAM. <b>Continuity should exist.</b></p> <p>2. Also check harness for short to ground and short to power.</p>	
<p>OK or NG</p>	
OK	▶ GO TO 16.
NG	▶ GO TO 15.

15	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between ECM and ECM relay</li> </ul>	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

## TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)


<b>16</b>	<b>CHECK ECM RELAY</b>							
<p>1. Apply 12V direct current between ECM relay terminals 1 and 2.                  2. Check continuity between relay terminals 3 and 5, 6 and 7.</p>								
								
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Continuity</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>OFF</td> <td style="text-align: center;">No</td> </tr> </tbody> </table>			Condition	Continuity	12V direct current supply between terminals 1 and 2	Yes	OFF	No
Condition	Continuity							
12V direct current supply between terminals 1 and 2	Yes							
OFF	No							
SEF296X								
<b>OK or NG</b>								
OK	▶	GO TO 17.						
NG	▶	Replace ECM relay.						

<b>17</b>	<b>CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect ECM harness connector.                  3. Check harness continuity between ECM terminals 48, 57, 106, 108 and engine ground.                  Refer to WIRING DIAGRAM.  <b>Continuity should exist.</b>                  4. Also check harness for short to power.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 18.
NG	▶	Repair open circuit or short to power in harness or connectors.

<b>18</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

## DTC P0100 MASS AIR FLOW SENSOR (MAFS)

### Component Description



### Component Description

NFEC0050

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0051

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: "OFF"</li> <li>● Shift lever: "N"</li> <li>● No-load</li> </ul>	Idle	1.2 - 1.8V
		2,500 rpm	1.6 - 2.2V
CAL/LD VALUE	ditto	Idle	14.0 - 33.0%
		2,500 rpm	12.0 - 25.0%
MASS AIRFLOW	ditto	Idle	2.0 - 6.0 g·m/s
		2,500 rpm	7.0 - 20.0 g·m/s

### On Board Diagnosis Logic

NFEC0053

Malfunction is detected when

**(Malfunction A)** an excessively high voltage from the sensor is sent to ECM when engine is not running,

**(Malfunction B)** an excessively low voltage from the sensor is sent to ECM when engine is running,

**(Malfunction C)** a voltage from the sensor is constantly approx. 1.0V when engine is running.

### FAIL-SAFE MODE

NFEC0053S02

When the malfunction B is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

# DTC P0100 MASS AIR FLOW SENSOR (MAFS)

Possible Cause

## Possible Cause

NFEC0426

### MALFUNCTION A

NFEC0426S01

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Mass air flow sensor

### MALFUNCTION B OR C

NFEC0426S02

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Intake air leaks
- Mass air flow sensor

## DTC Confirmation Procedure

NFEC0054

Perform "PROCEDURE FOR MALFUNCTION A" first.

If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B AND C".

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

2

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

## PROCEDURE FOR MALFUNCTION A

NFEC0054S01

### With CONSULT-II

NFEC0054S0101

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 6 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-138.

### With GST

NFEC0054S0103

Follow the procedure "With CONSULT-II" above.

### No Tools

NFEC0054S0102

- 1) Turn ignition switch "ON", and wait at least 6 seconds.
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-138.

3

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

## PROCEDURE FOR MALFUNCTION B AND C

NFEC0054S02

### With CONSULT-II

NFEC0054S0201

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait 5 seconds at most.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-138.

### With GST

NFEC0054S0203

Follow the procedure "With CONSULT-II" above.

## DTC P0100 MASS AIR FLOW SENSOR (MAFS)

DTC Confirmation Procedure (Cont'd)

---



### No Tools

NFEC0054S0202

- 1) Start engine and wait 5 seconds at most.
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-138.

# DTC P0100 MASS AIR FLOW SENSOR (MAFS)

Wiring Diagram

## Wiring Diagram

=NFEC0056

### EC-MAFS-01




: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC

(L) : LHD MODELS

(R) : RHD MODELS

\*1 SB : (L)

R/G : (R)



MEC835C

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**  
DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
61	W	MASS AIR FLOW SENSOR	ENGINE RUNNING AT IDLE SPEED UNDER WARM-UP CONDITION	1.2 - 1.8V
			ENGINE RUNNING AT 2,500 RPM UNDER WARM-UP CONDITION	1.6 - 2.2V
73	B	MASS AIR FLOW SENSOR GROUND	ENGINE RUNNING AT IDLE SPEED UNDER WARM-UP CONDITION	APPROX. 0V
111	R	SENSORS' POWER SUPPLY	IGN ON	APPROX. 5V

SEF650XB

# DTC P0100 MASS AIR FLOW SENSOR (MAFS)


Diagnostic Procedure

## Diagnostic Procedure

=NFEC0057



<b>1</b>	<b>INSPECTION START</b>						
Which malfunction (A, B or C) is duplicated?							
<table border="1"><thead><tr><th>MALFUNCTION</th><th>Type</th></tr></thead><tbody><tr><td>A</td><td>I</td></tr><tr><td>B and/or C</td><td>II</td></tr></tbody></table>		MALFUNCTION	Type	A	I	B and/or C	II
MALFUNCTION	Type						
A	I						
B and/or C	II						
MTBL0399							
<b>Type I or Type II</b>							
Type I	▶ GO TO 3.						
Type II	▶ GO TO 2.						

<b>2</b>	<b>CHECK INTAKE SYSTEM</b>
Check the following for connection.	
<ul style="list-style-type: none"><li>● Air duct</li><li>● Vacuum hoses</li><li>● Intake air passage between air duct to intake manifold collector</li></ul>	
<b>OK or NG</b>	
OK	▶ GO TO 3.
NG	▶ Reconnect the parts.

<b>3</b>	<b>RETIGHTEN GROUND SCREWS</b>
<ol style="list-style-type: none"><li>1. Turn ignition switch "OFF".</li><li>2. Loosen and retighten engine ground screws.</li></ol>	
 <p>The diagram shows a top-down view of an engine block. A label 'Engine ground' points to a screw on the top surface of the engine. Another label 'Oil filler cap' points to a circular cap on the side of the engine block.</p>	
SEF255X	
	▶ GO TO 4.

## DTC P0100 MASS AIR FLOW SENSOR (MAFS)

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK MAFS POWER SUPPLY CIRCUIT</b>						
<p>1. Disconnect mass air flow sensor (MAFS) harness connector.</p> <div style="text-align: center;">  <p>Mass air flow sensor harness connector</p> </div> <p style="text-align: right;">SEC139C</p> <p>2. Turn ignition switch "ON".</p> <p>3. Check voltage between MAFS terminals 2, 4 and ground with CONSULT-II or tester.</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="text-align: center;">  </div> <table border="1" style="margin-left: 20px;"> <thead> <tr> <th style="text-align: center;">Terminal</th> <th style="text-align: center;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">Approximately 5</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">Battery voltage</td> </tr> </tbody> </table> </div> <p style="text-align: right;">SEF297X</p> <p style="text-align: center;"><b>OK or NG</b></p>		Terminal	Voltage	2	Approximately 5	4	Battery voltage
Terminal	Voltage						
2	Approximately 5						
4	Battery voltage						
OK	▶ GO TO 6.						
NG	▶ GO TO 5.						


<b>5</b>	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness for open or short between ECM relay and mass air flow sensor</li> <li>● Harness for open or short between mass air flow sensor and ECM</li> </ul> <p style="text-align: center;">▶ Repair harness or connectors.</p>	

<b>6</b>	<b>CHECK MAFS GROUND CIRCUIT FOR OPEN AND SHORT</b>
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between MAFS terminal 3 and ECM terminal 73. Refer to Wiring Diagram. <b>Continuity should exist.</b></p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 7.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

## DTC P0100 MASS AIR FLOW SENSOR (MAFS)

Diagnostic Procedure (Cont'd)

<b>7</b>	<b>CHECK MAFS INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Check harness continuity between MAFS terminal 1 and ECM terminal 61. Refer to Wiring Diagram. <b>Continuity should exist.</b></p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 8.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.



<b>8</b>	<b>CHECK MASS AIR FLOW SENSOR</b>											
<p>1. Reconnect harness connectors disconnected.</p> <p>2. Start engine and warm it up to normal operating temperature.</p> <p>3. Check voltage between ECM terminal 61 (Mass air flow sensor signal) and ground.</p>												
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Voltage V</th> </tr> </thead> <tbody> <tr> <td>Ignition switch "ON" (Engine stopped.)</td> <td style="text-align: center;">Approx. 1.0</td> </tr> <tr> <td>Idle (Engine is warmed-up to normal operating temperature.)</td> <td style="text-align: center;">1.2 - 1.8</td> </tr> <tr> <td>2,500 rpm (Engine is warmed-up to normal operating temperature.)</td> <td style="text-align: center;">1.6 - 2.2</td> </tr> <tr> <td>Idle to about 4,000 rpm*</td> <td style="text-align: center;">1.2 - 1.8 to Approx. 4.0</td> </tr> </tbody> </table> <p style="font-size: small;">*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.</p>	Condition	Voltage V	Ignition switch "ON" (Engine stopped.)	Approx. 1.0	Idle (Engine is warmed-up to normal operating temperature.)	1.2 - 1.8	2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 2.2	Idle to about 4,000 rpm*	1.2 - 1.8 to Approx. 4.0
Condition	Voltage V											
Ignition switch "ON" (Engine stopped.)	Approx. 1.0											
Idle (Engine is warmed-up to normal operating temperature.)	1.2 - 1.8											
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 2.2											
Idle to about 4,000 rpm*	1.2 - 1.8 to Approx. 4.0											
<p>4. If the voltage is out of specification, disconnect MAFS harness connector and connect it again. Then repeat above check.</p> <p style="text-align: right;">SEF298X</p> <p style="text-align: center;"><b>OK or NG</b></p>												
OK	▶	GO TO 9.										
NG	▶	Replace mass air flow sensor.										

<b>9</b>	<b>CHECK MAFS SHIELD CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect joint connector-18.</p> <p>3. Check the following.</p> <ul style="list-style-type: none"> <li>● Continuity between joint connector terminal 1 and ground Refer to Wiring Diagram.</li> <li>● Joint connector-18 (Refer to EL-377, "HARNESS LAYOUT".) <b>Continuity should exist.</b></li> </ul> <p>4. Also check harness for short to power.</p> <p>5. Then reconnect joint connector-18.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 10.
NG	▶	Repair open circuit or short to power in harness or connectors.

<b>10</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

# DTC P0110 INTAKE AIR TEMPERATURE SENSOR

Component Description



## Component Description

NFEC0656

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.

### <Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
80 (176)	1.23	0.27 - 0.38

\*: These data are reference values and are measured between ECM terminal 64 (Intake air temperature sensor) and ground.

### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

## On Board Diagnosis Logic

NFEC0657

Malfunction is detected when

**(Malfunction A)** an excessively low or high voltage from the sensor is sent to ECM,

**(Malfunction B)** rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.

## Possible Cause

NFEC0658

- Harness or connectors (The sensor circuit is open or shorted.)
- Intake air temperature sensor

## DTC Confirmation Procedure

NFEC0659

Perform "PROCEDURE FOR MALFUNCTION A" first. If 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

## DTC P0110 INTAKE AIR TEMPERATURE SENSOR

DTC Confirmation Procedure (Cont'd)

3	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

### PROCEDURE FOR MALFUNCTION A

#### With CONSULT-II

NFEC0659S01

NFEC0659S0101

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-144.

#### With GST

NFEC0659S0102

Follow the procedure "With CONSULT-II" above.

5	DATA MONITOR	
	MONITOR	NO DTC
	COOLAN TEMP/S	XXX °C
VHCL SPEED SE		XXX km/h

SEF176Y

### PROCEDURE FOR MALFUNCTION B

NFEC0659S02

#### CAUTION:

Always drive vehicle at a safe speed.

#### TESTING CONDITION:

This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

#### With CONSULT-II

NFEC0659S0201

- 1) Wait until engine coolant temperature is less than 90°C (194°F).
  - a) Turn ignition switch "ON".
  - b) Select "DATA MONITOR" mode with CONSULT-II.
  - c) Check the engine coolant temperature.
  - d) If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch "OFF" and cool down engine.
    - Perform the following steps before engine coolant temperature is above 90°C (194°F).
- 2) Turn ignition switch "ON".
- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Start engine.
- 5) Hold vehicle speed at more than 70 km/h (43 MPH) for 100 consecutive seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-144.

#### With GST

NFEC0659S0202

Follow the procedure "With CONSULT-II" above.




# DTC P0110 INTAKE AIR TEMPERATURE SENSOR

Wiring Diagram

## Wiring Diagram

NFEC0660

### EC-IATS-01





MEC991C

# DTC P0110 INTAKE AIR TEMPERATURE SENSOR

Diagnostic Procedure

## Diagnostic Procedure

NFEC0661

<b>1</b>	<b>CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect intake air temperature sensor harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF258X</p> <p>3. Turn ignition switch "ON".                  4. Check voltage between terminal 1 and ground.</p> <div style="text-align: center;">  <p style="text-align: center;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">SEF301X</p> </div>		
OK	▶	GO TO 3.
NG	▶	GO TO 2.



<b>2</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors E8, F17</li> <li>● Harness for open or short between ECM and intake air temperature sensor</li> </ul>		
▶		Repair harness or connectors.

<b>3</b>	<b>CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Check harness continuity between sensor terminal 2 and engine ground.                  Refer to Wiring Diagram.  <b>Continuity should exist.</b></p> <p>3. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 5.
NG	▶	GO TO 4.

## DTC P0110 INTAKE AIR TEMPERATURE SENSOR

Diagnostic Procedure (Cont'd)



<b>4</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors E8, F17</li> <li>● Harness for open or short between ECM and intake air temperature sensor</li> <li>● Harness for open or short between TCM (Transmission Control Module) and intake air temperature sensor</li> </ul>	
▶	Repair open circuit or short to power in harness or connectors.

<b>5</b>	<b>CHECK INTAKE AIR TEMPERATURE SENSOR</b>						
Check resistance between intake air temperature sensor terminals 1 and 2 as shown in the figure.							
	<p><b>&lt;Reference data&gt;</b></p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Temperature °C (°F)</th> <th style="text-align: center;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">20 (68)</td> <td style="text-align: center;">2.1 - 2.9</td> </tr> <tr> <td style="text-align: center;">80 (176)</td> <td style="text-align: center;">0.27 - 0.38</td> </tr> </tbody> </table>	Temperature °C (°F)	Resistance kΩ	20 (68)	2.1 - 2.9	80 (176)	0.27 - 0.38
Temperature °C (°F)	Resistance kΩ						
20 (68)	2.1 - 2.9						
80 (176)	0.27 - 0.38						
							
SEF302X							
<b>OK or NG</b>							
OK	▶ GO TO 6.						
NG	▶ Replace intake air temperature sensor.						

<b>6</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

## Component Description



## Component Description

NFEC0069

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

### <Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

\*: These data are reference values and are measured between ECM terminal 70 (Engine coolant temperature sensor) ground.

### CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

## On Board Diagnosis Logic

NFEC0070

Malfunction is detected when an excessively high or low voltage from the sensor is sent to ECM.

### FAIL-SAFE MODE

NFEC0070S02

When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or Start	40°C (104°F)
	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)	

# DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Possible Cause

## Possible Cause

NFEC0429

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Engine coolant temperature sensor

3	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

## DTC Confirmation Procedure

NFEC0071

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### WITH CONSULT-II

NFEC0071S01

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-149.

### WITH GST

NFEC0071S03

Follow the procedure "WITH CONSULT-II" above.

### NO TOOLS

NFEC0071S02

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-149.




# DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Wiring Diagram

## Wiring Diagram

NFEC0072

### EC-ECTS-01





MEC721C

# DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0073



<b>1</b>	<b>CHECK ECTS POWER SUPPLY CIRCUIT</b>		
<p>1. Turn ignition switch "OFF".                  2. Disconnect engine coolant temperature sensor (ECTS) harness connector.</p> <div style="text-align: center;">  <p>Engine coolant temperature sensor harness connector</p> </div> <p style="text-align: right;">SEF259X</p> <p>3. Turn ignition switch "ON".                  4. Check voltage between ECTS terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="margin-left: 200px;"><b>Voltage: Approximately 5V</b></p> </div> <p style="text-align: right;">SEF585X</p> <p style="text-align: center;"><b>OK or NG</b></p>			
OK	▶	GO TO 2.	
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	

<b>2</b>	<b>CHECK ECTS GROUND CIRCUIT FOR OPEN AND CIRCUIT</b>		
<p>1. Turn ignition switch "OFF".                  2. Check harness continuity between ECTS terminal 2 and engine ground.                  Refer to Wiring Diagram.  <span style="color: blue;"><b>Continuity should exist.</b></span>                  3. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>			
OK	▶	GO TO 4.	
NG	▶	GO TO 3.	

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>		
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness for open or short between ECM and engine coolant temperature sensor</li> <li>● Harness for open or short between TCM (Transmission Control Module) and engine coolant temperature sensor</li> </ul>			
	▶	Repair open circuit or short to power in harness or connectors.	

# DTC P0115 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK ENGINE COOLANT TEMPERATURE SENSOR</b>								
<p>Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.</p>									
	<p><b>&lt;Reference data&gt;</b></p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">Temperature °C (°F)</th> <th style="text-align: center;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">20 (68)</td> <td style="text-align: center;">2.1 - 2.9</td> </tr> <tr> <td style="text-align: center;">50 (122)</td> <td style="text-align: center;">0.68 - 1.00</td> </tr> <tr> <td style="text-align: center;">90 (194)</td> <td style="text-align: center;">0.236 - 0.260</td> </tr> </tbody> </table>	Temperature °C (°F)	Resistance kΩ	20 (68)	2.1 - 2.9	50 (122)	0.68 - 1.00	90 (194)	0.236 - 0.260
Temperature °C (°F)	Resistance kΩ								
20 (68)	2.1 - 2.9								
50 (122)	0.68 - 1.00								
90 (194)	0.236 - 0.260								
									
SEF304X									
<b>OK or NG</b>									
OK	▶ GO TO 5.								
NG	▶ Replace engine coolant temperature sensor.								

<b>5</b>	<b>CHECK INTERMITTENT INCIDENT</b>
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.</p>	
▶	<b>INSPECTION END</b>

# DTC P0120 THROTTLE POSITION SENSOR

Description

## Description


NFEC0074

### COMPONENT DESCRIPTION

NFEC0074S01

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.



## CONSULT-II Reference Value in Data Monitor Mode

NFEC0075

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL POS SEN	<ul style="list-style-type: none"> <li>Engine: After warming up, idle the engine</li> </ul> Throttle valve: fully closed	0.15 - 0.85V
	<ul style="list-style-type: none"> <li>Engine: After warming up</li> <li>Ignition switch: ON (Engine stopped)</li> </ul> Throttle valve: fully opened	3.5 - 4.7V
ABSOL TH-P/S	<ul style="list-style-type: none"> <li>Engine: After warming up, idle the engine</li> </ul> Throttle valve: fully closed	0.0%
	<ul style="list-style-type: none"> <li>Engine: After warming up</li> <li>Ignition switch: ON (Engine stopped)</li> </ul> Throttle valve: fully opened	Approx. 80%

## DTC P0120 THROTTLE POSITION SENSOR

On Board Diagnosis Logic

### On Board Diagnosis Logic

Malfunction is detected when an excessively low or high voltage from the sensor is sent to ECM. NFEC0077

### FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MIL lights up. NFEC0077S02

Detected items	Engine operating condition in fail-safe mode	
Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
	Condition	Driving condition
	When engine is idling	Normal
When accelerating	Poor acceleration	

### Possible Cause

- Harness or connectors  
(The throttle position sensor circuit is open or shorted.)
  - Throttle position sensor
- NFEC0430

### DTC Confirmation Procedure

#### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test. NFEC0078

#### CAUTION:

Always drive vehicle at a safe speed.

#### TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 10V at idle.
- This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

## DTC P0120 THROTTLE POSITION SENSOR

DTC Confirmation Procedure (Cont'd)

2	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm
	VHCL SPEED SE	XXX km/h
	P/N POSI SW	OFF

SEF065Y

### WITH CONSULT-II

NFEC0078S01

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and maintain the following conditions for at least 5 consecutive seconds.

Vehicle speed	More than 5 km/h (3 MPH)
Selector lever	Suitable position except "P" or "N" position

- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-155.

### WITH GST

NFEC0078S05

Follow the procedure "WITH CONSULT-II" above.

### NO TOOLS

NFEC0078S04

- 1) Start engine and maintain the following conditions for at least 5 consecutive seconds.

Vehicle speed	More than 5 km/h (3 MPH)
Selector lever	Suitable position except "P" or "N" position

- 2) Turn ignition switch "OFF" and wait at least 10 seconds.
- 3) Turn ignition switch "ON" and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-155.





# DTC P0120 THROTTLE POSITION SENSOR

Wiring Diagram

## Wiring Diagram

NFEC0079

### EC-TPS-01



MEC837C

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
91	L/W	THROTTLE POSITION SENSOR	ENGINE RUNNING UNDER WARM-UP CONDITION WITH ACCELERATOR PEDAL FULLY RELEASED	0.15 - 0.85V
111	R	SENSORS' POWER SUPPLY	IGN ON WITH ACCELERATOR PEDAL FULLY DEPRESSED	APPROX. 5V
58	B	SENSORS' GROUND	ENGINE RUNNING AT IDLE SPEED UNDER WARM-UP CONDITION	APPROX. 0V

SEF652XB

# DTC P0120 THROTTLE POSITION SENSOR


Diagnostic Procedure

## Diagnostic Procedure

NFEC0080

### 1 RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.




SEF255X

▶ GO TO 2.


### 2 CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect throttle position sensor harness connector.



SEC001C

2. Turn ignition switch "ON".
3. Check voltage between throttle position sensor terminal 3 and ground with CONSULT-II or tester.



Voltage: Approximately 5V

SEF306X

OK or NG

OK ▶ GO TO 3.

NG ▶ Repair open circuit or short to ground or short to power in harness or connectors.

## DTC P0120 THROTTLE POSITION SENSOR

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT</b>	
1. Turn ignition switch "OFF". 2. Check harness continuity between sensor terminal 1 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b> 3. Also check harness for short to power.		
<b>OK or NG</b>		
OK	▶	GO TO 5.
NG	▶	GO TO 4.

<b>4</b>	<b>DETECT MALFUNCTIONING PART</b>	
Check the following. <ul style="list-style-type: none"> <li>● Harness for open or short between ECM and throttle position sensor</li> <li>● Harness for open or short between TCM (Transmission Control Module) and throttle position sensor</li> </ul>		
		▶ Repair open circuit or short to power in harness or connectors.

<b>5</b>	<b>CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 91 and throttle position sensor terminal 2. Refer to Wiring Diagram. <b>Continuity should exist.</b> 3. Also check harness for short to ground and short to power.		
<b>OK or NG</b>		
OK (With CONSULT-II)	▶	GO TO 6.
OK (Without CONSULT-II)	▶	GO TO 7.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

<b>6</b>	<b>CHECK THROTTLE POSITION SENSOR</b>											
ⓘ <b>With CONSULT-II</b> 1. Start engine and warm it up to normal operating temperature. 2. Stop engine (ignition switch OFF). 3. Turn ignition switch ON. 4. Select "DATA MONITOR" mode with CONSULT-II. 5. Check voltage of "THRTL POS SEN" under the following conditions. <b>Voltage measurement must be made with throttle position sensor installed in vehicle.</b>												
<table border="1" style="margin: 0 auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: left;">MONITOR</th> <th style="text-align: left;">NO DTC</th> </tr> </thead> <tbody> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	ENG SPEED	XXX rpm	COOLAN TEMP/S	XXX °C	THRTL POS SEN	XXX V
DATA MONITOR												
MONITOR	NO DTC											
ENG SPEED	XXX rpm											
COOLAN TEMP/S	XXX °C											
THRTL POS SEN	XXX V											
<table border="1" style="margin: 0 auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Throttle valve conditions</th> <th style="text-align: center;">THRTL POS SEN</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Completely closed (a)</td> <td style="text-align: center;">0.15 - 0.85V</td> </tr> <tr> <td style="text-align: center;">Partially open</td> <td style="text-align: center;">Between (a) and (b)</td> </tr> <tr> <td style="text-align: center;">Completely open (b)</td> <td style="text-align: center;">3.5 - 4.7V</td> </tr> </tbody> </table>			Throttle valve conditions	THRTL POS SEN	Completely closed (a)	0.15 - 0.85V	Partially open	Between (a) and (b)	Completely open (b)	3.5 - 4.7V		
Throttle valve conditions	THRTL POS SEN											
Completely closed (a)	0.15 - 0.85V											
Partially open	Between (a) and (b)											
Completely open (b)	3.5 - 4.7V											
SEF062Y												
<b>OK or NG</b>												
OK	▶	GO TO 9.										
NG	▶	GO TO 8.										

## DTC P0120 THROTTLE POSITION SENSOR

Diagnostic Procedure (Cont'd)

<b>7</b>	<b>CHECK THROTTLE POSITION SENSOR</b>									
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Stop engine (ignition switch OFF).</li> <li>3. Turn ignition switch ON.</li> <li>4. Check voltage between ECM terminal 91 (Throttle position sensor signal) and ground.  <b>Voltage measurement must be made with throttle position sensor installed in vehicle.</b></li> </ol>										
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Throttle valve conditions</th> <th style="width: 40%;">Voltage</th> </tr> </thead> <tbody> <tr> <td>Completely closed (a)</td> <td style="text-align: center;">0.15 - 0.85V</td> </tr> <tr> <td>Partially open</td> <td style="text-align: center;">Between (a) and (b)</td> </tr> <tr> <td>Completely open (b)</td> <td style="text-align: center;">3.5 - 4.7V</td> </tr> </tbody> </table>			Throttle valve conditions	Voltage	Completely closed (a)	0.15 - 0.85V	Partially open	Between (a) and (b)	Completely open (b)	3.5 - 4.7V
Throttle valve conditions	Voltage									
Completely closed (a)	0.15 - 0.85V									
Partially open	Between (a) and (b)									
Completely open (b)	3.5 - 4.7V									
MTBL0231										
<b>OK or NG</b>										
OK	▶	GO TO 9.								
NG	▶	GO TO 8.								


<b>8</b>	<b>ADJUST CLOSED THROTTLE POSITION SWITCH</b>									
Adjust closed throttle position switch. Refer to "Basic Inspection", EC-90.										
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 40%;">Items</th> <th style="width: 60%;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table>			Items	Specifications	Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)	Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF	Target idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)
Items	Specifications									
Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)									
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF									
Target idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)									
MTBL0623										
<b>OK or NG</b>										
OK	▶	GO TO 9.								
NG	▶	Replace throttle position sensor. To adjust it, perform "Basic Inspection", EC-90.								

<b>9</b>	<b>CHECK THROTTLE POSITION SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT</b>	
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Disconnect joint connector-18</li> <li>3. Check the following <ul style="list-style-type: none"> <li>● Continuity between joint connector terminal 2 and ground</li> <li>● Joint connector (Refer to EL-377, "HARNES LAYOUT".)  <b>Continuity should exist.</b></li> <li>● Also check harness for short to power.</li> <li>● Then reconnect joint connector-18.</li> </ul> </li> </ol>		
<b>OK or NG</b>		
OK	▶	GO TO 10.
NG	▶	Repair open circuit or short to to power in harness or connectors.

<b>10</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

## DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)


### Component Description



### Component Description

NFEC0086

The heated oxygen sensor 1 (front) is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 (front) has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 (front) signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.




### CONSULT-II Reference Value in Data Monitor Mode

NFEC0087

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.



### On Board Diagnosis Logic

NFEC0089

Under the condition in which the heated oxygen sensor 1 (front) signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.

Malfunction is detected when the voltage from the sensor is constantly approx. 0.3V.

# DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)

Possible Cause

## Possible Cause

NFEC0432

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Heated oxygen sensor 1 (front)

5	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: center;">HO2S1 (B1) P0130</td> </tr> <tr> <td colspan="2" style="text-align: center; height: 40px;">OUT OF CONDITION</td> </tr> <tr> <td colspan="2" style="text-align: center;">MONITOR</td> </tr> <tr> <td style="text-align: center;">ENG SPEED</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td style="text-align: center;">B/FUEL SCHDL</td> <td style="text-align: center;">XXX msec</td> </tr> <tr> <td style="text-align: center;">THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">VHCL SPEED SE</td> <td style="text-align: center;">XXX km/h</td> </tr> </table>	HO2S1 (B1) P0130		OUT OF CONDITION		MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	THRTL POS SEN	XXX V	VHCL SPEED SE	XXX km/h
HO2S1 (B1) P0130															
OUT OF CONDITION															
MONITOR															
ENG SPEED	XXX rpm														
B/FUEL SCHDL	XXX msec														
THRTL POS SEN	XXX V														
VHCL SPEED SE	XXX km/h														

SEF825Y

## DTC Confirmation Procedure

NFEC0662

### CAUTION:

**Always drive vehicle at a safe speed.**

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

**Before performing the following procedure, confirm that battery voltage is more than 11V at idle.**

### WITH CONSULT-II

NFEC0662S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "HO2S1 (B1) P0130/HO2S1 (B2) P0150" of "HO2S1 (B1)/(B2)" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 3) Touch "START".
- 4) Let it idle for at least 3 minutes.

### NOTE:

**Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 4.**

- 5) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 10 to 60 seconds.)

ENG SPEED	1,400 - 2,400 rpm (A/T) 1,600 - 2,600 rpm (M/T)
Vehicle speed	More than 64 km/h (40 MPH)
B/FUEL SCHDL	2.0 - 10 msec
Selector lever	Suitable position

**If "TESTING" is not displayed after 5 minutes, retry from step 2.**

- 6) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-163.

5	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: center;">HO2S1 (B1) P0130</td> </tr> <tr> <td colspan="2" style="text-align: center; height: 40px;">TESTING</td> </tr> <tr> <td colspan="2" style="text-align: center;">MONITOR</td> </tr> <tr> <td style="text-align: center;">ENG SPEED</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td style="text-align: center;">B/FUEL SCHDL</td> <td style="text-align: center;">XXX msec</td> </tr> <tr> <td style="text-align: center;">THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">VHCL SPEED SE</td> <td style="text-align: center;">XXX km/h</td> </tr> </table>	HO2S1 (B1) P0130		TESTING		MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	THRTL POS SEN	XXX V	VHCL SPEED SE	XXX km/h
HO2S1 (B1) P0130															
TESTING															
MONITOR															
ENG SPEED	XXX rpm														
B/FUEL SCHDL	XXX msec														
THRTL POS SEN	XXX V														
VHCL SPEED SE	XXX km/h														


SEF826Y

5	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: center;">HO2S1 (B1) P0130</td> </tr> <tr> <td colspan="2" style="text-align: center; height: 100px;">COMPLETED</td> </tr> </table>	HO2S1 (B1) P0130		COMPLETED	
HO2S1 (B1) P0130					
COMPLETED					

SEF645Y

## DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)

### Overall Function Check



### Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 (front) circuit. During this check, a 1st trip DTC might not be confirmed. NFEC0663

#### ⊗ WITHOUT CONSULT-II NFEC0663S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 63 (HO2S1 bank 1 signal) or 62 (HO2S1 bank 2 signal) and engine ground.
- 3) Check the following with engine speed held at 2,000 rpm constant under no load.
  - The voltage does not remain in the range of 0.2 - 0.4V.
- 4) If NG, go to "Diagnostic Procedure", EC-163.

# DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)

Wiring Diagram

## Wiring Diagram



**BANK 1**

=NFEC0092

NFEC0092S01

**EC-O2S1B1-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC296D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
63	W	HEATED OXYGEN SENSOR 1 (FRONT) (BANK 1)	ENGINE RUNNING AT 2,000 RPM AFTER WARMING UP TO NORMAL OPERATING TEMPERATURE	0 - APPROX. 1.0V 

SEF854YC

# DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)






Wiring Diagram (Cont'd)

## BANK 2

NFEC0092S02

### EC-O2S1B2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC297D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
62	W	HEATED OXYGEN SENSOR 1 (FRONT) (BANK 2)	ENGINE RUNNING AT 2,000 RPM AFTER WARMING UP TO NORMAL OPERATING TEMPERATURE	0 - APPROX. 1.0V 

SEF855YC

# DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)


Diagnostic Procedure

## Diagnostic Procedure

NFEC0093


### 1 INSPECTION START

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.





SEF255X

3. Make sure HO2S1 (front) harness protector color, and disconnect corresponding heated oxygen sensor 1 (front) harness connector.



HO2S1 (front) (bank 1): Black  
HO2S1 (front) (bank 2): Blue

SEF505YA



SEF902XA

▶ GO TO 2.

## DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)

Diagnostic Procedure (Cont'd)

2	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>															
<p>1. Disconnect ECM harness connector.                      2. Check harness continuity between ECM terminal and HO2S1 (front) terminal as follows.                      Refer to Wiring Diagram.</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 15%;">DTC</th> <th colspan="2" style="width: 60%;">Terminals</th> <th rowspan="2" style="width: 25%;">Bank</th> </tr> <tr> <th style="width: 20%;">ECM</th> <th style="width: 20%;">Sensor</th> </tr> </thead> <tbody> <tr> <td>P0130</td> <td style="text-align: center;">63</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0150</td> <td style="text-align: center;">62</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>			DTC	Terminals		Bank	ECM	Sensor	P0130	63	1	1	P0150	62	1	2
DTC	Terminals			Bank												
	ECM	Sensor														
P0130	63	1	1													
P0150	62	1	2													
MTBL0484																
<p><b>Continuity should exist.</b></p> <p>3. Check harness continuity between ECM terminal or HO2S1 (front) terminal and ground as follows.                      Refer to Wiring Diagram.</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 15%;">DTC</th> <th colspan="2" style="width: 60%;">Terminals</th> <th rowspan="2" style="width: 25%;">Bank</th> </tr> <tr> <th style="width: 20%;">ECM or Sensor</th> <th style="width: 20%;">Ground</th> </tr> </thead> <tbody> <tr> <td>P0130</td> <td style="text-align: center;">63 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0150</td> <td style="text-align: center;">62 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>			DTC	Terminals		Bank	ECM or Sensor	Ground	P0130	63 or 1	Ground	1	P0150	62 or 1	Ground	2
DTC	Terminals			Bank												
	ECM or Sensor	Ground														
P0130	63 or 1	Ground	1													
P0150	62 or 1	Ground	2													
MTBL0485																
<p><b>Continuity should not exist.</b></p> <p>4. Also check harness for short to power.</p>																
<b>OK or NG</b>																
OK (With CONSULT-II)	▶	GO TO 3.														
OK (Without CONSULT-II)	▶	GO TO 4.														
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.														

# DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)

Diagnostic Procedure (Cont'd)

## 3 CHECK HEATED OXYGEN SENSOR 1 (FRONT)

### With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

### 6. Check the following.

- "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.

Bank 1  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R


Bank 2  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B2) R-L-R-L-R-L-R-L-R-L-R

R means HO2S1 MNTR (B1)/(B2) indicates RICH  
 L means HO2S1 MNTR (B1)/(B2) indicates LEAN

SEF647YA

- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Trigger	ENG SPEED	HO2S1 (B1)
	rpm	V
XXX	XXX	XXX



- Maximum voltage should be over 0.6V at least one time.
- Minimum voltage should be below 0.30V at least one time.

SEF648Y

### CAUTION:


Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.


OK or NG

OK	▶	GO TO 6.
NG	▶	GO TO 5.

## DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT)</b>	
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Stop engine and set ECM in diagnostic test mode-II [Heated oxygen sensor 1 monitor (front)].</li> <li>3. Set voltmeter probes between ECM terminal 63 (HO2S1 bank 1 signal) or 62 (HO2S1 bank 2 signal) and engine ground.</li> <li>4. Check the following with engine speed held at 2,000 rpm constant under no load.</li> </ol>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 45%;">  <p>63: Bank 1 62: Bank 2</p> </div> <div style="width: 50%;"> <ul style="list-style-type: none"> <li>● The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.</li> <li>● The maximum voltage is over 0.6V at least one time.</li> <li>● The minimum voltage is below 0.3V at least one time.</li> <li>● The voltage never exceeds 1.0V.</li> </ul> <p>1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V</p> </div> </div>		
SEF967XA		
<b>CAUTION:</b>		
<p><b>Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</b></p>		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

<b>5</b>	<b>REPLACE HEATED OXYGEN SENSOR 1 (FRONT)</b>	
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 1 (front) harness protector color.</li> </ol>		
		
<p>HO2S1 (front) (bank 1): Black HO2S1 (front) (bank 2): Blue</p>		
SEF505YA		
<b>CAUTION:</b>		
<p><b>Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant. Refer to "Commercial Service Tools", EC-18.</b></p>		
▶		Replace malfunctioning heated oxygen sensor 1 (front).

## DTC P0130 (BANK 1), P0150 (BANK 2) HO2S1 (FRONT) (CIRCUIT)


Diagnostic Procedure (Cont'd)

<b>6</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) SHIELD CIRCUIT FOR OPEN AND SHORT</b>	
1. Turn ignition switch "OFF".		
2. Disconnect joint connector-17 or joint connector-18.		
3. Check the following.		
● Continuity between joint connector terminal 1 or 2 and ground		
● Joint connector (Refer to EL-377, "HARNES LAYOUT".)		
<b>Continuity should exist.</b>		
4. Also check harness for short to power.		
5. Then reconnect joint connector-17 or joint connector-18.		
<b>OK or NG</b>		
OK	▶	GO TO 7.
NG	▶	Repair open circuit or short to power in harness or connectors.

<b>7</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
	▶	<b>INSPECTION END</b>

# DTC P0131 (BANK 1), P0151 (BANK 2) HO2S1 (FRONT) (LEAN SHIFT MONITORING)


## Component Description



## Component Description

NFEC0664

The heated oxygen sensor 1 (front) is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 (front) has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 (front) signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.




## CONSULT-II Reference Value in Data Monitor Mode

NFEC0665

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.



## On Board Diagnosis Logic

NFEC0666

To judge the malfunction, the output from the heated oxygen sensor 1 (front) is monitored to determine whether the "rich" output is sufficiently high and whether the "lean" output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.

Malfunction is detected when the maximum and minimum voltage from the sensor are not reached to the specified voltages.

# DTC P0131 (BANK 1), P0151 (BANK 2) HO2S1 (FRONT) (LEAN SHIFT MONITORING)

Possible Cause

## Possible Cause

NFEC0667

- Heated oxygen sensor 1 (front)
- Heated oxygen sensor 1 heater (front)
- Fuel pressure
- Injectors
- Intake air leaks

## DTC Confirmation Procedure

NFEC0668

### CAUTION:

Always drive vehicle at a safe speed.

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

- Always perform at a temperature above  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ).
- Before performing following procedure, confirm that battery voltage is more than 11V at idle.

### WITH CONSULT-II

NFEC0668S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and wait at least 10 seconds.
- 3) Turn ignition switch "ON" and select "HO2S1 (B1) P0131/HO2S1 (B2) P0151" of "HO2S1 (B1)/(B2)" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 4) Touch "START".
- 5) Start engine and let it idle for at least 3 minutes.

### NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.

- 6) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 50 seconds or more.)

ENG SPEED	1,200 - 2,600 rpm (A/T) 1,800 - 2,600 rpm (M/T)
Vehicle speed	Less than 100 km/h (62 MPH)
B/FUEL SCHDL	3 - 9 msec (A/T) 2.5 - 9 msec (M/T)
Selector lever	Suitable position

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-170.


6	HO2S1 (B1) P0131
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V
VHCL SPEED SE	XXX km/h
SEF827Y	

6	HO2S1 (B1) P0131
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V
VHCL SPEED SE	XXX km/h
SEF828Y	

6	HO2S1 (B1) P0131
COMPLETED	
SEF651Y	

# DTC P0131 (BANK 1), P0151 (BANK 2) HO2S1 (FRONT) (LEAN SHIFT MONITORING)

## Overall Function Check



## Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 (front) circuit. During this check, a 1st trip DTC might not be confirmed. NFEC0669

### WITH GST NFEC0669S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Set voltmeter probes between ECM terminal 63 (HO2S1 bank 1 signal) or 62 (HO2S1 bank 2 signal) and engine ground.
- 3) Check one of the following with engine speed held at 2,000 rpm constant under no load.
  - The maximum voltage is over 0.6V at least one time.
  - The minimum voltage is over 0.1V at least one time.
- 4) If NG, go to "Diagnostic Procedure", EC-170.

## Diagnostic Procedure

NFEC0670

<b>1</b>	<b>RETIGHTEN GROUND SCREWS</b>
<p>1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.</p> <p>Engine ground</p> <p>Oil filler cap</p> <p style="text-align: right;"><small>SEF255X</small></p>	
▶	GO TO 2.

<b>2</b>	<b>RETIGHTEN HEATED OXYGEN SENSOR 1 (FRONT)</b>
<p>Loosen and retighten corresponding heated oxygen sensor 1 (front). <b>Tightening torque:</b> <b>40 - 60 N·m (4.1 - 6.1 kg·m, 30 - 44 ft·lb)</b></p>	
▶	GO TO 3.

# DTC P0131 (BANK 1), P0151 (BANK 2) HO2S1 (FRONT) (LEAN SHIFT MONITORING)

Diagnostic Procedure (Cont'd)


<b>3</b>	<b>CLEAR THE SELF-LEARNING DATA</b>									
<p><b>Ⓟ With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.</li> <li>3. Clear the self-learning control coefficient by touching "CLEAR".</li> </ol> <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse;"> <tr> <th colspan="2" style="padding: 2px;">WORK SUPPORT</th> </tr> <tr> <td style="padding: 2px;">SELF-LEARNING CONT</td> <td style="padding: 2px;">B1 100%</td> </tr> <tr> <td style="padding: 2px;"></td> <td style="padding: 2px;">B2 100%</td> </tr> <tr> <td colspan="2" style="padding: 2px; text-align: center;">CLEAR</td> </tr> </table> </div> <p style="text-align: right; margin-right: 20px;">SEF652Y</p> <ol style="list-style-type: none"> <li>4. Run engine for at least 10 minutes at idle speed.  <b>Is the 1st trip DTC P0171 or P0174 detected?</b>  <b>Is it difficult to start engine?</b></li> </ol>			WORK SUPPORT		SELF-LEARNING CONT	B1 100%		B2 100%	CLEAR	
WORK SUPPORT										
SELF-LEARNING CONT	B1 100%									
	B2 100%									
CLEAR										
<p><b>ⓧ Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Turn ignition switch "OFF".</li> <li>3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.</li> <li>4. Stop engine and reconnect mass air flow sensor harness connector.</li> <li>5. Make sure 1st trip DTC P0100 is displayed.</li> <li>6. Erase the 1st trip DTC memory. Refer to "How to Erase Emission-related Diagnostic Information", EC-56.</li> <li>7. Make sure DTC P0000 is displayed.</li> <li>8. Run engine for at least 10 minutes at idle speed.  <b>Is the 1st trip DTC P0171 or P0174 detected?</b>  <b>Is it difficult to start engine?</b></li> </ol> <p style="text-align: center; margin: 10px 0;"><b>Yes or No</b></p>										
Yes	▶	Perform trouble diagnosis for DTC P0171, P0174. Refer to EC-261.								
No	▶	GO TO 4.								

# DTC P0131 (BANK 1), P0151 (BANK 2) HO2S1 (FRONT) (LEAN SHIFT MONITORING)

Diagnostic Procedure (Cont'd)

## 4 CHECK HEATED OXYGEN SENSOR 1 HEATER (FRONT)


1. Stop engine.
2. Check heated oxygen sensor 1 (front) harness protector color.



HO2S1 (front) (bank 1): Black  
HO2S1 (front) (bank 2): Blue

SEF505YA

3. Disconnect HO2S1 (front) harness connector.
4. Check resistance between HO2S1 (front) terminals as follows.



Terminals	Resistance
2 and 3	2.3 - 4.3Ω at 25°C (77°F)
1 and 2 1 and 3	∞Ω (Continuity should not exist.)

SEF310X

**CAUTION:**

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

OK or NG

OK (With CONSULT-II) ▶	GO TO 5.
OK (Without CONSULT-II) ▶	GO TO 6.
NG ▶	GO TO 7.

# DTC P0131 (BANK 1), P0151 (BANK 2) HO2S1 (FRONT) (LEAN SHIFT MONITORING)

Diagnostic Procedure (Cont'd)

## 5 CHECK HEATED OXYGEN SENSOR 1 (FRONT)

### With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

### 6. Check the following.

- "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.

Bank 1  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R


Bank 2  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B2) R-L-R-L-R-L-R-L-R-L-R

R means HO2S1 MNTR (B1)/(B2) indicates RICH  
 L means HO2S1 MNTR (B1)/(B2) indicates LEAN

SEF647YA

- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Trigger	ENG SPEED	HO2S1 (B1)
	rpm	V
XXX	XXX	XXX



- Maximum voltage should be over 0.6V at least one time.
- Minimum voltage should be below 0.30V at least one time.

SEF648Y

### CAUTION:


Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.


OK or NG

OK	▶	GO TO 8.
NG	▶	GO TO 7.

# DTC P0131 (BANK 1), P0151 (BANK 2) HO2S1 (FRONT) (LEAN SHIFT MONITORING)

Diagnostic Procedure (Cont'd)

<b>6</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT)</b>	
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Stop engine and set ECM in diagnostic test mode-II [Heated oxygen sensor 1 monitor (front)].</li> <li>3. Set voltmeter probes between ECM terminal 63 (HO2S1 bank 1 signal) or 62 (HO2S1 bank 2 signal) and engine ground.</li> <li>4. Check the following with engine speed held at 2,000 rpm constant under no load.</li> </ol>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 45%;">  <p>63: Bank 1 62: Bank 2</p> </div> <div style="width: 50%;"> <ul style="list-style-type: none"> <li>● The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.</li> <li>● The maximum voltage is over 0.6V at least one time.</li> <li>● The minimum voltage is below 0.3V at least one time.</li> <li>● The voltage never exceeds 1.0V.</li> </ul> <p>1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V</p> </div> </div>		
SEF967XA		
<b>CAUTION:</b>		
<p>Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 8.
NG	▶	GO TO 7.

<b>7</b>	<b>REPLACE HEATED OXYGEN SENSOR 1 (FRONT)</b>	
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 1 (front) harness protector color.</li> </ol>		
		
<p>HO2S1 (front) (bank 1): Black HO2S1 (front) (bank 2): Blue</p>		
SEF505YA		
<b>CAUTION:</b>		
<p>Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.</p>		
▶		Replace malfunctioning heated oxygen sensor 1 (front).

# DTC P0131 (BANK 1), P0151 (BANK 2) HO2S1 (FRONT) (LEAN SHIFT MONITORING)


Diagnostic Procedure (Cont'd)

8	CHECK HEATED OXYGEN SENSOR 1 (FRONT) SHIELD CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect joint connector-17 or joint connector-18.</p> <p>3. For circuit, refer to "DTC P0130/P0150 HO2S1 (FRONT) (BANK 1)/(BANK 2) (CIRCUIT)", EC-158.</p> <p>4. Check the following.</p> <ul style="list-style-type: none"><li>● Continuity between joint connector terminal 1 or 2 and ground</li><li>● Joint connector (Refer to EL-377, "HARNES LAYOUT".) <b>Continuity should exist.</b></li></ul> <p>5. Also check harness for short to power.</p> <p>6. Then reconnect joint connector-17 or joint connector-18.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 9.
NG	▶ Repair open circuit or short to power in harness or connectors.

9	CHECK INTERMITTENT INCIDENT
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.</p> <p>For circuit, refer to "DTC P0130/P0150 HO2S1 (FRONT) (BANK 1)/(BANK 2) (CIRCUIT)", EC-158.</p>	
▶ <b>INSPECTION END</b>	

# DTC P0132 (BANK 1), P0152 (BANK 2) HO2S1 (FRONT) (RICH SHIFT MONITORING)


## Component Description



## Component Description

NFEC0671

The heated oxygen sensor 1 (front) is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 (front) has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 (front) signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.




## CONSULT-II Reference Value in Data Monitor Mode

NFEC0672

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 (B1) HO2S1 (B2)		0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.



## On Board Diagnosis Logic

NFEC0673

To judge the malfunction, the output from the heated oxygen sensor 1 (front) is monitored to determine whether the "rich" output is sufficiently high. The "lean" output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.

Malfunction is detected when the maximum and minimum voltages from the sensor are beyond the specified voltages.

# DTC P0132 (BANK 1), P0152 (BANK 2) HO2S1 (FRONT) (RICH SHIFT MONITORING)

Possible Cause

## Possible Cause

NFEC0674

- Heated oxygen sensor 1 (front)
- Fuel pressure
- Injectors
- Heated oxygen sensor 1 heater (front)

## DTC Confirmation Procedure

NFEC0675

### CAUTION:

Always drive vehicle at a safe speed.

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

- Always perform at a temperature above  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

### WITH CONSULT-II

NFEC0675S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "HO2S1 (B1) P0132/HO2S1 (B2) P0152" of "HO2S1 (B1)/(B2)" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 4) Touch "START".
- 5) Start engine and let it idle for at least 3 minutes.

### NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.

- 6) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 50 seconds or more.)

ENG SPEED	1,200 - 2,600 rpm (A/T) 1,800 - 2,600 rpm (M/T)
Vehicle speed	Less than 100 km/h (62 MPH)
B/FUEL SCHDL	3 - 9 msec (A/T) 2.5 - 9 msec (M/T)
Selector lever	Suitable position

If "TESTING" is not displayed after 5 minutes, retry from step 2.

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-178.


6	HO2S1 (B1) P0132
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V
VHCL SPEED SE	XXX km/h
	SEF829Y

6	HO2S1 (B1) P0132
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
THRTL POS SEN	XXX V
VHCL SPEED SE	XXX km/h
	SEF830Y

6	HO2S1 (B1) P0132
COMPLETED	
	SEF655Y

# DTC P0132 (BANK 1), P0152 (BANK 2) HO2S1 (FRONT) (RICH SHIFT MONITORING)

## Overall Function Check



## Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 (front) circuit. During this check, a 1st trip DTC might not be confirmed. NFEC0676

### WITH GST

- 1) Start engine and warm it up to normal operating temperature. NFEC0676S01
- 2) Set voltmeter probes between ECM terminal 63 (HO2S1 bank 1 signal) or 62 (HO2S1 bank 2 signal) and engine ground.
- 3) Check one of the following with engine speed held at 2,000 rpm constant under no load.
  - The maximum voltage is below 0.8V at least one time.
  - The minimum voltage is below 0.35V at least one time.
- 4) If NG, go to "Diagnostic Procedure", EC-178.

## Diagnostic Procedure

NFEC0677


<b>1</b>	<b>RETIGHTEN GROUND SCREWS</b>
<ol style="list-style-type: none"><li>1. Turn ignition switch "OFF".</li><li>2. Loosen and retighten engine ground screws.</li></ol> <p>Engine ground</p> <p>Oil filler cap</p> <p>SEF255X</p>	
▶ GO TO 2.	

<b>2</b>	<b>RETIGHTEN HEATED OXYGEN SENSOR 1 (FRONT)</b>
Loosen and retighten corresponding heated oxygen sensor 1 (front). <b>Tightening torque:</b> <b>40 - 60 N·m (4.1 - 6.1 kg·m, 30 - 44 ft·lb)</b>	
▶ GO TO 3.	

# DTC P0132 (BANK 1), P0152 (BANK 2) HO2S1 (FRONT) (RICH SHIFT MONITORING)



Diagnostic Procedure (Cont'd)

<b>3</b>	<b>CLEAR THE SELF-LEARNING DATA</b>									
<p><b>Ⓜ With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.</li> <li>3. Clear the self-learning control coefficient by touching "CLEAR".</li> </ol> <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse; width: 150px; margin: 0 auto;"> <tr> <th colspan="2" style="padding: 2px;">WORK SUPPORT</th> </tr> <tr> <td style="padding: 2px;">SELF-LEARNING CONT</td> <td style="padding: 2px;">B1 100%</td> </tr> <tr> <td style="padding: 2px;"></td> <td style="padding: 2px;">B2 100%</td> </tr> <tr> <td colspan="2" style="padding: 2px; text-align: center;">CLEAR</td> </tr> </table> </div> <p style="text-align: right; margin-right: 20px;">SEF652Y</p> <ol style="list-style-type: none"> <li>4. Run engine for at least 10 minutes at idle speed.  <b>Is the 1st trip DTC P0172 or P0175 detected?</b>  <b>Is it difficult to start engine?</b></li> </ol>			WORK SUPPORT		SELF-LEARNING CONT	B1 100%		B2 100%	CLEAR	
WORK SUPPORT										
SELF-LEARNING CONT	B1 100%									
	B2 100%									
CLEAR										
<p><b>ⓧ Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Turn ignition switch "OFF".</li> <li>3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.</li> <li>4. Stop engine and reconnect mass air flow sensor harness connector.</li> <li>5. Make sure 1st trip DTC P0100 is displayed.</li> <li>6. Erase the 1st trip DTC memory. Refer to "How to Erase Emission-related Diagnostic Information", EC-56.</li> <li>7. Make sure DTC P0000 is displayed.</li> <li>8. Run engine for at least 10 minutes at idle speed.  <b>Is the 1st trip DTC P0172 or P0175 detected?</b>  <b>Is it difficult to start engine?</b></li> </ol> <p style="text-align: center; margin: 10px 0;"><b>Yes or No</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; padding: 2px;">Yes</td> <td style="width: 5%; text-align: center; padding: 2px;">▶</td> <td style="padding: 2px;">Perform trouble diagnosis for DTC P0172, P0175. Refer to EC-269.</td> </tr> <tr> <td style="padding: 2px;">No</td> <td style="text-align: center; padding: 2px;">▶</td> <td style="padding: 2px;">GO TO 4.</td> </tr> </table>			Yes	▶	Perform trouble diagnosis for DTC P0172, P0175. Refer to EC-269.	No	▶	GO TO 4.		
Yes	▶	Perform trouble diagnosis for DTC P0172, P0175. Refer to EC-269.								
No	▶	GO TO 4.								

<b>4</b>	<b>CHECK HEATED OXYGEN SENSOR (FRONT) CONNECTOR FOR WATER</b>							
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 1 (front) harness protector color.</li> </ol> <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: center; margin: 10px 0;">         HO2S1 (front) (bank 1): Black          HO2S1 (front) (bank 2): Blue       </p> <p style="text-align: right; margin-right: 20px;">SEF505YA</p> <ol style="list-style-type: none"> <li>3. Disconnect heated oxygen sensor 1 (front) harness connector.</li> <li>4. Check connectors for water.  <b>Water should not exist.</b></li> </ol> <p style="text-align: center; margin: 10px 0;"><b>OK or NG</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; padding: 2px;">OK</td> <td style="width: 5%; text-align: center; padding: 2px;">▶</td> <td style="padding: 2px;">GO TO 5.</td> </tr> <tr> <td style="padding: 2px;">NG</td> <td style="text-align: center; padding: 2px;">▶</td> <td style="padding: 2px;">Repair or replace harness or connectors.</td> </tr> </table>			OK	▶	GO TO 5.	NG	▶	Repair or replace harness or connectors.
OK	▶	GO TO 5.						
NG	▶	Repair or replace harness or connectors.						

# DTC P0132 (BANK 1), P0152 (BANK 2) HO2S1 (FRONT) (RICH SHIFT MONITORING)

Diagnostic Procedure (Cont'd)

5	CHECK HEATED OXYGEN SENSOR 1 HEATER (FRONT)						
<p>Check resistance between HO2S1 (front) terminals as follows.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Terminals</th> <th>Resistance</th> </tr> </thead> <tbody> <tr> <td>2 and 3</td> <td>2.3 - 4.3Ω at 25°C (77°F)</td> </tr> <tr> <td>1 and 2 1 and 3</td> <td>∞Ω (Continuity should not exist.)</td> </tr> </tbody> </table> </div> </div>		Terminals	Resistance	2 and 3	2.3 - 4.3Ω at 25°C (77°F)	1 and 2 1 and 3	∞Ω (Continuity should not exist.)
Terminals	Resistance						
2 and 3	2.3 - 4.3Ω at 25°C (77°F)						
1 and 2 1 and 3	∞Ω (Continuity should not exist.)						
SEF310X							
<p><b>CAUTION:</b>            Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p>							
<b>OK or NG</b>							
OK (With CONSULT-II)	▶ GO TO 6.						
OK (Without CONSULT-II)	▶ GO TO 7.						
NG	▶ GO TO 8.						

# DTC P0132 (BANK 1), P0152 (BANK 2) HO2S1 (FRONT) (RICH SHIFT MONITORING)

Diagnostic Procedure (Cont'd)

## 6 CHECK HEATED OXYGEN SENSOR 1 (FRONT)

**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

6. Check the following.
  - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.

Bank 1  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R


Bank 2  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B2) R-L-R-L-R-L-R-L-R-L-R

R means HO2S1 MNTR (B1)/(B2) indicates RICH  
 L means HO2S1 MNTR (B1)/(B2) indicates LEAN

SEF647YA

- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Trigger	ENG SPEED	HO2S1 (B1)
	rpm	V
XXX	XXX	XXX



- Maximum voltage should be over 0.6V at least one time.
- Minimum voltage should be below 0.30V at least one time.

SEF648Y

**CAUTION:**


Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.


OK or NG

OK	▶	GO TO 9.
NG	▶	GO TO 8.

# DTC P0132 (BANK 1), P0152 (BANK 2) HO2S1 (FRONT) (RICH SHIFT MONITORING)

Diagnostic Procedure (Cont'd)

<b>7</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT)</b>	
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Stop engine and set ECM in diagnostic test mode-II [Heated oxygen sensor 1 monitor (front)].</li> <li>3. Set voltmeter probes between ECM terminal 63 (HO2S1 bank 1 signal) or 62 (HO2S1 bank 2 signal) and engine ground.</li> <li>4. Check the following with engine speed held at 2,000 rpm constant under no load.</li> </ol>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 45%;">  <p>63: Bank 1 62: Bank 2</p> </div> <div style="width: 50%;"> <ul style="list-style-type: none"> <li>● The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.</li> <li>● The maximum voltage is over 0.6V at least one time.</li> <li>● The minimum voltage is below 0.3V at least one time.</li> <li>● The voltage never exceeds 1.0V.</li> </ul> <p>1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V</p> </div> </div>		
SEF967XA		
<b>CAUTION:</b>		
<p><b>Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</b></p>		
<b>OK or NG</b>		
OK	▶	GO TO 9.
NG	▶	GO TO 8.

<b>8</b>	<b>REPLACE HEATED OXYGEN SENSOR 1 (FRONT)</b>	
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 1 (front) harness protector color.</li> </ol>		
		
<p>HO2S1 (front) (bank 1): Black HO2S1 (front) (bank 2): Blue</p>		
SEF505YA		
<b>CAUTION:</b>		
<p><b>Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.</b></p>		
▶		Replace malfunctioning heated oxygen sensor 1 (front).

# DTC P0132 (BANK 1), P0152 (BANK 2) HO2S1 (FRONT) (RICH SHIFT MONITORING)


Diagnostic Procedure (Cont'd)

9	CHECK HEATED OXYGEN SENSOR 1 (FRONT) SHIELD CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect joint connector-17 or joint connector-18. For circuit, refer to "DTC P0130/P0150 HO2S1 (FRONT) (BANK 1)/(BANK 2) (CIRCUIT)", EC-158.</p> <p>3. Check the following.</p> <ul style="list-style-type: none"><li>● Continuity between joint connector terminal 1 or 2 and ground</li><li>● Joint connector (Refer to EL-377, "HARNES LAYOUT".) <b>Continuity should exist.</b></li></ul> <p>4. Also check harness for short to power.</p> <p>5. Then reconnect joint connector-17 or joint connector-18.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 10.
NG	▶ Repair open circuit or short to power in harness or connectors.

10	CHECK INTERMITTENT INCIDENT
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126. For circuit, refer to P0130/P0150 HO2S1 (FRONT) (BANK 1)/(BANK 2) (CIRCUIT)", EC-158.</p>	
▶ <b>INSPECTION END</b>	

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)


## Component Description



## Component Description

NFEC0678

The heated oxygen sensor 1 (front) is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 (front) has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 (front) signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.




## CONSULT-II Reference Value in Data Monitor Mode

NFEC0679

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	<ul style="list-style-type: none"> <li>Engine: After warming up</li> </ul>	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.



## On Board Diagnosis Logic

NFEC0680

To judge the malfunction of heated oxygen sensor 1 (front), this diagnosis measures response time of heated oxygen sensor 1 (front) signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and heated oxygen sensor 1 (front) temperature index. Judgment is based on whether the compensated time [heated oxygen sensor 1 (front) cycling time index] is inordinately long or not.

Malfunction is detected when the response of the voltage signal from the sensor takes more than the specified time.

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)

Possible Cause

---

## Possible Cause

NFEC0681

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Heated oxygen sensor 1 (front)
- Heated oxygen sensor 1 heater (front)
- Fuel pressure
- Injectors
- Intake air leaks
- Exhaust gas leaks
- PCV valve
- Mass air flow sensor

## DTC Confirmation Procedure

NFEC0682

### **CAUTION:**

Always drive vehicle at a safe speed.

### **NOTE:**

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### **TESTING CONDITION:**

- Always perform at a temperature above  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)

DTC Confirmation Procedure (Cont'd)

6	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: center;">HO2S1 (B1) P0133</td> </tr> <tr> <td colspan="2" style="text-align: center; height: 40px;">OUT OF CONDITION</td> </tr> <tr> <td colspan="2" style="text-align: center;">MONITOR</td> </tr> <tr> <td style="text-align: center;">ENG SPEED</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td style="text-align: center;">B/FUEL SCHDL</td> <td style="text-align: center;">XXX msec</td> </tr> <tr> <td style="text-align: center;">THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">VHCL SPEED SE</td> <td style="text-align: center;">XXX km/h</td> </tr> </table>	HO2S1 (B1) P0133		OUT OF CONDITION		MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	THRTL POS SEN	XXX V	VHCL SPEED SE	XXX km/h	SEF831Y
HO2S1 (B1) P0133																
OUT OF CONDITION																
MONITOR																
ENG SPEED	XXX rpm															
B/FUEL SCHDL	XXX msec															
THRTL POS SEN	XXX V															
VHCL SPEED SE	XXX km/h															

6	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: center;">HO2S1 (B1) P0133</td> </tr> <tr> <td colspan="2" style="text-align: center; height: 40px;">TESTING</td> </tr> <tr> <td colspan="2" style="text-align: center;">MONITOR</td> </tr> <tr> <td style="text-align: center;">ENG SPEED</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td style="text-align: center;">B/FUEL SCHDL</td> <td style="text-align: center;">XXX msec</td> </tr> <tr> <td style="text-align: center;">THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">VHCL SPEED SE</td> <td style="text-align: center;">XXX km/h</td> </tr> </table>	HO2S1 (B1) P0133		TESTING		MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	THRTL POS SEN	XXX V	VHCL SPEED SE	XXX km/h	SEF832Y
HO2S1 (B1) P0133																
TESTING																
MONITOR																
ENG SPEED	XXX rpm															
B/FUEL SCHDL	XXX msec															
THRTL POS SEN	XXX V															
VHCL SPEED SE	XXX km/h															

6	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: center;">HO2S1 (B1) P0133</td> </tr> <tr> <td colspan="2" style="text-align: center; height: 100px;">COMPLETED</td> </tr> </table>	HO2S1 (B1) P0133		COMPLETED		SEF658Y
HO2S1 (B1) P0133						
COMPLETED						

## WITH CONSULT-II

NFEC0682S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "HO2S1 (B1) P0133/HO2S1 (B2) P0153" of "HO2S1 (B1)/(B2)" in "DTC WORK SUPPORT" mode with CONSULT-II.
- 4) Touch "START".
- 5) Start engine and let it idle for at least 3 minutes.

### NOTE:

**Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.**

- 6) When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 40 to 50 seconds.)

ENG SPEED	1,200 - 2,800 rpm (A/T) 1,800 - 3,100 rpm (M/T)
Vehicle speed	More than 80 km/h (50 MPH)
B/FUEL SCHDL	3 - 9 msec (A/T) 2.5 - 9 msec (M/T)
Selector lever	Suitable position

**If "TESTING" is not displayed after 5 minutes, retry from step 2.**

- 7) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-189.

## Overall Function Check

NFEC0683

Use this procedure to check the overall function of the heated oxygen sensor 1 (front) circuit. During this check, a 1st trip DTC might not be confirmed.

## WITH GST

NFEC0683S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and set ECM in diagnostic test mode-II [Heated oxygen sensor monitor (front)]
- 3) Start engine and check the following with engine speed head of a constant 2,000 rpm under no load.
  - MI comes on more than five times within 10 seconds.
- 4) If NG, go to "Diagnostic Procedure", EC-189.

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)

Wiring Diagram

## Wiring Diagram



**BANK 1**

NFEC0684

NFEC0684S01

**EC-O2S1B1-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC296D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
63	W	HEATED OXYGEN SENSOR 1 (FRONT) (BANK 1)	ENGINE RUNNING AT 2,000 RPM AFTER WARMING UP TO NORMAL OPERATING TEMPERATURE	0 - APPROX. 1.0V 

SEF854YC

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)



Wiring Diagram (Cont'd)

## BANK 2

NFEC0684S02

### EC-O2S1B2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC297D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
62	W	HEATED OXYGEN SENSOR 1 (FRONT) (BANK 2)	ENGINE RUNNING AT 2,000 RPM AFTER WARMING UP TO NORMAL OPERATING TEMPERATURE	0 - APPROX. 1.0V 


SEF855YC

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)


Diagnostic Procedure

## Diagnostic Procedure

NFEC0685

<b>1</b>	<b>RETIGHTEN GROUND SCREWS</b>
<p>1. Turn ignition switch "OFF".                  2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF255X</p>	
▶ GO TO 2.	

<b>2</b>	<b>RETIGHTEN HEATED OXYGEN SENSOR 1 (FRONT)</b>
<p>Loosen and retighten corresponding heated oxygen sensor 1 (front).  <b>Tightening torque:</b>  <b>40 - 60 N·m (4.1 - 6.1 kg·m, 30 - 44 ft·lb)</b></p>	
▶ GO TO 3.	

<b>3</b>	<b>CHECK FOR EXHAUST AIR LEAK</b>
<p>1. Start engine and run it at idle.                  2. Listen for an exhaust air leak before three way catalyst (Manifold).</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF099P</p>	
<b>OK or NG</b>	
OK	▶ GO TO 4.
NG	▶ Repair or replace.

<b>4</b>	<b>CHECK FOR INTAKE AIR LEAK</b>
<p>Listen for an intake air leak after the mass air flow sensor.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 5.
NG	▶ Repair or replace.




# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)

Diagnostic Procedure (Cont'd)

5	CLEAR THE SELF-LEARNING DATA									
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.</li> <li>3. Clear the self-learning control coefficient by touching "CLEAR".</li> </ol>										
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">WORK SUPPORT</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">SELF-LEARNING CONT</td> <td style="text-align: center;">B1 100%</td> </tr> <tr> <td style="text-align: center;"> </td> <td style="text-align: center;">B2 100%</td> </tr> <tr> <td colspan="2" style="text-align: center;">CLEAR</td> </tr> </tbody> </table>			WORK SUPPORT		SELF-LEARNING CONT	B1 100%		B2 100%	CLEAR	
WORK SUPPORT										
SELF-LEARNING CONT	B1 100%									
	B2 100%									
CLEAR										
SEF652Y										
<ol style="list-style-type: none"> <li>4. Run engine for at least 10 minutes at idle speed.</li> </ol> <p><b>Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?</b>  <b>Is it difficult to start engine?</b></p>										
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Turn ignition switch "OFF".</li> <li>3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.</li> <li>4. Stop engine and reconnect mass air flow sensor harness connector.</li> <li>5. Make sure 1st trip DTC P0100 is displayed.</li> <li>6. Erase the 1st trip DTC memory. Refer to "How to Erase Emission-related Diagnostic Information", EC-56.</li> <li>7. Make sure DTC P0000 is displayed.</li> <li>8. Run engine for at least 10 minutes at idle speed.</li> </ol> <p><b>Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?</b>  <b>Is it difficult to start engine?</b></p> <p style="text-align: center;"><b>Yes or No</b></p>										
Yes	▶	Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to EC-261, EC-269.								
No	▶	GO TO 6.								

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)

Diagnostic Procedure (Cont'd)

<b>6</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) HARNESS PROTECTOR COLOR</b>
<p>1. Turn ignition switch "OFF".                  2. Check heated oxygen sensor 1 (front) harness protector.</p>	
 <p>HO2S1 (front)</p> <p>HO2S1 (front) harness protector color</p>	
<p>HO2S1 (front) (bank 1): Black                  HO2S1 (front) (bank 2): Blue</p>	
<p>3. Disconnect corresponding heated oxygen sensor 1 (front) harness connector.</p>	
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>Heated oxygen sensor 1 (front) (bank 2) harness connector</p> <p>Front</p> </div> <div style="text-align: center;">  <p>Heated oxygen sensor 1 (front) (bank 1) harness connector</p> </div> </div>	
<p>▶ GO TO 7.</p>	

SEF505YA

SEF902XA

<b>7</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>														
<p>1. Disconnect ECM harness connector.                  2. Check harness continuity between ECM terminal and HO2S1 (front) terminal as follows. Refer to Wiring Diagram.</p>															
<table border="1" style="margin: auto;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0133</td> <td>63</td> <td>1</td> <td>1</td> </tr> <tr> <td>P0153</td> <td>62</td> <td>1</td> <td>2</td> </tr> </tbody> </table>		DTC	Terminals		Bank	ECM	Sensor	P0133	63	1	1	P0153	62	1	2
DTC	Terminals		Bank												
	ECM	Sensor													
P0133	63	1	1												
P0153	62	1	2												
<p><b>Continuity should exist.</b></p>															
<p>3. Check harness continuity between ECM terminal or HO2S1 (front) terminal and ground as follows. Refer to Wiring Diagram.</p>															
<table border="1" style="margin: auto;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or Sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0133</td> <td>63 or 1</td> <td>Ground</td> <td>1</td> </tr> <tr> <td>P0153</td> <td>62 or 1</td> <td>Ground</td> <td>2</td> </tr> </tbody> </table>		DTC	Terminals		Bank	ECM or Sensor	Ground	P0133	63 or 1	Ground	1	P0153	62 or 1	Ground	2
DTC	Terminals		Bank												
	ECM or Sensor	Ground													
P0133	63 or 1	Ground	1												
P0153	62 or 1	Ground	2												
<p><b>Continuity should not exist.</b></p>															
<p>4. Also check harness for short to power.</p>															
<b>OK or NG</b>															
OK	▶ GO TO 8.														
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.														

MTBL0486

MTBL0487

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)


Diagnostic Procedure (Cont'd)

<b>8</b>	<b>CHECK HEATED OXYGEN SENSOR 1 HEATER (FRONT)</b>							
Check resistance between HO2S1 (front) terminals as follows.								
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Terminals</th> <th>Resistance</th> </tr> </thead> <tbody> <tr> <td>2 and 3</td> <td>2.3 - 4.3Ω at 25°C (77°F)</td> </tr> <tr> <td>1 and 2 1 and 3</td> <td>∞Ω (Continuity should not exist.)</td> </tr> </tbody> </table>	Terminals	Resistance	2 and 3	2.3 - 4.3Ω at 25°C (77°F)	1 and 2 1 and 3	∞Ω (Continuity should not exist.)
Terminals	Resistance							
2 and 3	2.3 - 4.3Ω at 25°C (77°F)							
1 and 2 1 and 3	∞Ω (Continuity should not exist.)							
SEF310X								
<b>CAUTION:</b> Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.								
<b>OK or NG</b>								
OK	▶ GO TO 9.							
NG	▶ GO TO 13.							

<b>9</b>	<b>CHECK MASS AIR FLOW SENSOR</b>										
<ol style="list-style-type: none"> <li>1. Reconnect harness connectors disconnected.</li> <li>2. Start engine and warm it up to normal operating temperature.</li> <li>3. Check voltage between ECM terminal 61 (Mass air flow sensor signal) and ground.</li> </ol>											
	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Condition</th> <th>Voltage V</th> </tr> </thead> <tbody> <tr> <td>Ignition switch "ON" (Engine stopped.)</td> <td>Approx. 1.0</td> </tr> <tr> <td>Idle (Engine is warmed-up to normal operating temperature.)</td> <td>1.2 - 1.8</td> </tr> <tr> <td>2,500 rpm (Engine is warmed-up to normal operating temperature.)</td> <td>1.6 - 2.2</td> </tr> <tr> <td>Idle to about 4,000 rpm*</td> <td>1.2 - 1.8 to Approx. 4.0</td> </tr> </tbody> </table> <p style="font-size: small;">*: Check for linear voltage rise in response to engine being increased to about 4,000 rpm.</p>	Condition	Voltage V	Ignition switch "ON" (Engine stopped.)	Approx. 1.0	Idle (Engine is warmed-up to normal operating temperature.)	1.2 - 1.8	2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 2.2	Idle to about 4,000 rpm*	1.2 - 1.8 to Approx. 4.0
Condition	Voltage V										
Ignition switch "ON" (Engine stopped.)	Approx. 1.0										
Idle (Engine is warmed-up to normal operating temperature.)	1.2 - 1.8										
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 2.2										
Idle to about 4,000 rpm*	1.2 - 1.8 to Approx. 4.0										
SEF298X											
4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Then repeat above check.											
<b>OK or NG</b>											
OK	▶ GO TO 10.										
NG	▶ Replace mass air flow sensor.										

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)

Diagnostic Procedure (Cont'd)

10 CHECK PCV VALVE	
<p>1. Install all removed parts. 2. Start engine and let it idle. 3. Remove PCV valve ventilation hose from PCV valve. 4. Make sure that a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.</p>  <p style="text-align: right;">SEC137A</p>	
<b>OK or NG</b>	
OK (With CONSULT-II) ▶	GO TO 11.
OK (Without CONSULT-II) ▶	GO TO 12.
NG ▶	Replace PCV valve.

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)

Diagnostic Procedure (Cont'd)

## 11 CHECK HEATED OXYGEN SENSOR 1 (FRONT)

**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

6. Check the following.
  - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below.

Bank 1  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R


Bank 2  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B2) R-L-R-L-R-L-R-L-R-L-R

R means HO2S1 MNTR (B1)/(B2) indicates RICH  
 L means HO2S1 MNTR (B1)/(B2) indicates LEAN

SEF647YA

- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Trigger	ENG SPEED	HO2S1 (B1)
	rpm	V
XXX	XXX	XXX



- Maximum voltage should be over 0.6V at least one time.
- Minimum voltage should be below 0.30V at least one time.

SEF648Y

**CAUTION:**


Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.


OK or NG

OK	▶	GO TO 14.
NG	▶	GO TO 13.

# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)

Diagnostic Procedure (Cont'd)

<b>12</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT)</b>
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Stop engine and set ECM in diagnostic test mode-II [Heated oxygen sensor 1 monitor (front)].</li> <li>3. Set voltmeter probes between ECM terminal 63 (HO2S1 bank 1 signal) or 62 (HO2S1 bank 2 signal) and engine ground.</li> <li>4. Check the following with engine speed held at 2,000 rpm constant under no load.</li> </ol>	
<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;">  <p>63: Bank 1 62: Bank 2</p> </div> <div style="flex: 2; padding-left: 20px;"> <ul style="list-style-type: none"> <li>The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.</li> <li>The maximum voltage is over 0.6V at least one time.</li> <li>The minimum voltage is below 0.3V at least one time.</li> <li>The voltage never exceeds 1.0V.</li> </ul> <p>1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V</p> </div> </div>	
SEF967XA	
<b>CAUTION:</b>	
<p><b>Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</b></p>	
<b>OK or NG</b>	
OK	▶ GO TO 14.
NG	▶ GO TO 13.

<b>13</b>	<b>REPLACE HEATED OXYGEN SENSOR 1 (FRONT)</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 1 (front) harness protector color.</li> </ol>	
	
<p>HO2S1 (front) (bank 1): Black HO2S1 (front) (bank 2): Blue</p>	
SEF505YA	
▶	Replace malfunctioning heated oxygen sensor 1 (front).

<b>14</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) SHIELD CIRCUIT FOR OPEN AND SHORT</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Disconnect joint connector-17 or joint connector-18.</li> <li>3. Check the following. <ul style="list-style-type: none"> <li>Continuity between joint connector terminal 1 or 2 and ground</li> <li>Joint connector (Refer to EL-377, "HARNES LAYOUT".)</li> </ul> <p style="margin-left: 20px;"><b>Continuity should exist.</b></p> </li> <li>4. Also check harness for short to power.</li> <li>5. Then reconnect joint connector-17 or joint connector-18.</li> </ol>	
<b>OK or NG</b>	
OK	▶ GO TO 15.
NG	▶ Repair open circuit or short to power in harness or connectors.


# DTC P0133 (BANK 1), P0153 (BANK 2) HO2S1 (FRONT) (RESPONSE MONITORING)

Diagnostic Procedure (Cont'd)

<b>15</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# DTC P0134 (BANK 1), P0154 (BANK 2) HO2S1 (FRONT) (HIGH VOLTAGE)


Component Description



## Component Description

NFEC0686

The heated oxygen sensor 1 (front) is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 (front) has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 (front) signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.




## CONSULT-II Reference Value in Data Monitor Mode

NFEC0687

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	<ul style="list-style-type: none"> <li>Engine: After warming up</li> </ul>	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.



## On Board Diagnosis Logic

NFEC0688

To judge the malfunction, the diagnosis checks that the heated oxygen sensor 1 (front) output is not inordinately high. Malfunction is detected when an excessively high voltage from the sensor is sent to ECM.

# DTC P0134 (BANK 1), P0154 (BANK 2) HO2S1 (FRONT) (HIGH VOLTAGE)

Possible Cause

## Possible Cause

NFEC0689

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Heated oxygen sensor 1 (front)

5	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm
	COOLAN TEMP/S	XXX °C

SEF174Y

## DTC Confirmation Procedure

NFEC0690

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### Ⓟ WITH CONSULT-II

NFEC0690S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 10 seconds.
- 3) Turn ignition switch "ON".
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Restart engine and let it idle for 25 seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-201.

### Ⓢ WITH GST

NFEC0690S02

- 1) Start engine and warm it up to normal operating temperature.
  - 2) Turn ignition switch "OFF" and wait at least 10 seconds.
  - 3) Restart engine and let it idle for 25 seconds.
  - 4) Turn ignition switch "OFF" and wait at least 10 seconds.
  - 5) Restart engine and let it idle for 25 seconds.
  - 6) Select "MODE 3" with GST.
  - 7) If DTC is detected, go to "Diagnostic Procedure", EC-201.
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

# DTC P0134 (BANK 1), P0154 (BANK 2) HO2S1 (FRONT) (HIGH VOLTAGE)

Wiring Diagram

## Wiring Diagram



**BANK 1**

NFEC0691

NFEC0691S01

**EC-O2S1B1-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC296D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
63	W	HEATED OXYGEN SENSOR 1 (FRONT) (BANK 1)	ENGINE RUNNING AT 2,000 RPM AFTER WARMING UP TO NORMAL OPERATING TEMPERATURE	0 - APPROX. 1.0V 

SEF854YC

# DTC P0134 (BANK 1), P0154 (BANK 2) HO2S1 (FRONT) (HIGH VOLTAGE)



Wiring Diagram (Cont'd)

## BANK 2

NFEC0691S02

### EC-O2S1B2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC297D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
62	W	HEATED OXYGEN SENSOR 1 (FRONT) (BANK 2)	ENGINE RUNNING AT 2,000 RPM AFTER WARMING UP TO NORMAL OPERATING TEMPERATURE	0 - APPROX. 1.0V 

SEF855YC

# DTC P0134 (BANK 1), P0154 (BANK 2) HO2S1 (FRONT) (HIGH VOLTAGE)


Diagnostic Procedure

## Diagnostic Procedure

NFEC0692

### 1 INSPECTION START



1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 1 (front) harness protector color.



HO2S1 (front) (bank 1): Black  
HO2S1 (front) (bank 2): Blue

SEF505YA

3. Disconnect corresponding heated oxygen sensor 1 (front) harness connector.



SEF902XA

▶ GO TO 2.

### 2 RETIGHTEN HEATED OXYGEN SENSOR 1 (FRONT)

Loosen and retighten corresponding heated oxygen sensor 1 (front).

**Tightening torque:**

**40 - 60 N·m (4.1 - 6.1 kg·m, 30 - 44 ft·lb)**

▶ GO TO 3.

## DTC P0134 (BANK 1), P0154 (BANK 2) HO2S1 (FRONT) (HIGH VOLTAGE)

Diagnostic Procedure (Cont'd)

3	CHECK HEATED OXYGEN SENSOR 1 (FRONT) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT															
<p>1. Disconnect ECM harness connector.                      2. Check harness continuity between ECM terminal and HO2S1 (front) terminal as follows.                      Refer to Wiring Diagram.</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 15%;">DTC</th> <th colspan="2" style="width: 60%;">Terminals</th> <th rowspan="2" style="width: 25%;">Bank</th> </tr> <tr> <th style="width: 20%;">ECM</th> <th style="width: 20%;">Sensor</th> </tr> </thead> <tbody> <tr> <td>P0134</td> <td style="text-align: center;">63</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0154</td> <td style="text-align: center;">62</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>			DTC	Terminals		Bank	ECM	Sensor	P0134	63	1	1	P0154	62	1	2
DTC	Terminals			Bank												
	ECM	Sensor														
P0134	63	1	1													
P0154	62	1	2													
MTBL0488																
<p><b>Continuity should exist.</b></p> <p>3. Check harness continuity between ECM terminal or HO2S1 (front) terminal and ground as follows.                      Refer to Wiring Diagram.</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 15%;">DTC</th> <th colspan="2" style="width: 60%;">Terminals</th> <th rowspan="2" style="width: 25%;">Bank</th> </tr> <tr> <th style="width: 20%;">ECM or Sensor</th> <th style="width: 20%;">Ground</th> </tr> </thead> <tbody> <tr> <td>P0134</td> <td style="text-align: center;">63 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0154</td> <td style="text-align: center;">62 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>			DTC	Terminals		Bank	ECM or Sensor	Ground	P0134	63 or 1	Ground	1	P0154	62 or 1	Ground	2
DTC	Terminals			Bank												
	ECM or Sensor	Ground														
P0134	63 or 1	Ground	1													
P0154	62 or 1	Ground	2													
MTBL0489																
<p><b>Continuity should not exist.</b></p> <p>4. Also check harness for short to power.</p>																
<b>OK or NG</b>																
OK	▶	GO TO 4.														
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.														

4	CHECK HEATED OXYGEN SENSOR 1 (FRONT) CONNECTOR FOR WATER	
<p>1. Disconnect heated oxygen sensor 1 (front) harness connector.                      2. Check connectors for water.  <b>Water should not exist.</b></p>		
<b>OK or NG</b>		
OK (With CONSULT-II)	▶	GO TO 5.
OK (Without CONSULT-II)	▶	GO TO 6.
NG	▶	Repair or replace harness or connectors.

# DTC P0134 (BANK 1), P0154 (BANK 2) HO2S1 (FRONT) (HIGH VOLTAGE)

Diagnostic Procedure (Cont'd)

## 5 CHECK HEATED OXYGEN SENSOR 1 (FRONT)

**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

6. Check the following.
  - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown left:

Bank 1  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R


Bank 2  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B2) R-L-R-L-R-L-R-L-R-L-R

R means HO2S1 MNTR (B1)/(B2) indicates RICH  
 L means HO2S1 MNTR (B1)/(B2) indicates LEAN

SEF647YA

- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Trigger	ENG SPEED	HO2S1 (B1)
	rpm	V
XXX	XXX	XXX



- Maximum voltage should be over 0.6V at least one time.
- Minimum voltage should be below 0.30V at least one time.

SEF648Y

**CAUTION:**


Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.


OK or NG

OK	▶	GO TO 8.
NG	▶	GO TO 7.

# DTC P0134 (BANK 1), P0154 (BANK 2) HO2S1 (FRONT) (HIGH VOLTAGE)

Diagnostic Procedure (Cont'd)

<b>6</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT)</b>	
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Stop engine and set ECM in diagnostic test mode-II [Heated oxygen sensor 1 monitor (front)].</li> <li>3. Set voltmeter probes between ECM terminal 63 (HO2S1 bank 1 signal) or 62 (HO2S1 bank 2 signal) and engine ground.</li> <li>4. Check the following with engine speed held at 2,000 rpm constant under no load.</li> </ol>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 30%;">  <p>63: Bank 1 62: Bank 2</p> </div> <div style="width: 65%;"> <ul style="list-style-type: none"> <li>● The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.</li> <li>● The maximum voltage is over 0.6V at least one time.</li> <li>● The minimum voltage is below 0.3V at least one time.</li> <li>● The voltage never exceeds 1.0V.</li> </ul> <p>1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V</p> </div> </div>		
SEF967XA		
<b>CAUTION:</b>		
<p><b>Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</b></p>		
<b>OK or NG</b>		
OK	▶	GO TO 8.
NG	▶	GO TO 7.

<b>7</b>	<b>REPLACE HEATED OXYGEN SENSOR 1 (FRONT)</b>	
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 1 (front) harness protector color.</li> </ol>		
		
<p>HO2S1 (front) (bank 1): Black HO2S1 (front) (bank 2): Blue</p>		
SEF505YA		
<b>CAUTION:</b>		
<p><b>Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.</b></p>		
▶		Replace malfunctioning heated oxygen sensor 1 (front).

<b>8</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

## DTC P0135 (BANK 1), P0155 (BANK 2) HO2S1 HEATER (FRONT)

Description

### Description

NFEC0693

#### SYSTEM DESCRIPTION

NFEC0693S01

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 1 heater (front) control	Heated oxygen sensors 1 heater (front)
Crankshaft position sensor (REF)			

The ECM performs ON/OFF control of the heated oxygen sensor 1 heater (front) corresponding to the engine speed.

#### OPERATION

NFEC0693S02

Engine speed rpm	Heated oxygen sensors 1 heater (front)
Above 3,600	OFF
Below 3,600	ON

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0694

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1)	● Engine speed: Below 3,600 rpm	ON
HO2S1 HTR (B2)	● Engine speed: Above 3,600 rpm	OFF

### On Board Diagnosis Logic

NFEC0695

Malfunction is detected when the current amperage in the heated oxygen sensor 1 heater (front) circuit is out of the normal range. [An improper voltage drop signal is sent to ECM through the heated oxygen sensor 1 heater (front).]

### Possible Cause

NFEC0696

- Harness or connectors [The heated oxygen sensor 1 heater (front) circuit is open or shorted.]
- Heated oxygen sensor 1 heater (front)

## DTC P0135 (BANK 1), P0155 (BANK 2) HO2S1 HEATER (FRONT)

### DTC Confirmation Procedure

2	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

### DTC Confirmation Procedure

NFEC0697

#### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

#### Ⓜ WITH CONSULT-II

NFEC0697S01

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 6 seconds at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-209.

#### Ⓜ WITH GST

NFEC0697S02

- 1) Start engine and run it for at least 6 seconds at idle speed.
  - 2) Turn ignition switch "OFF" and wait at least 10 seconds.
  - 3) Start engine and run it for at least 6 seconds at idle speed.
  - 4) Select "MODE 3" with GST.
  - 5) If DTC is detected, go to "Diagnostic Procedure", EC-209.
- When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.

# DTC P0135 (BANK 1), P0155 (BANK 2) HO2S1 HEATER (FRONT)

Wiring Diagram

## Wiring Diagram



**BANK 1**

NFEC0698

NFEC0698S01

**EC-O2H1B1-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC298D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**  
DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
3	OR/L	HEATED OXYGEN SENSOR 1 HEATER (FRONT) (BANK 1)	ENGINE RUNNING BELOW 3,600 RPM	0 - 1.0V
			ENGINE RUNNING ABOVE 3,600 RPM	BATTERY VOLTAGE

SEF655XE

# DTC P0135 (BANK 1), P0155 (BANK 2) HO2S1 HEATER (FRONT)



Wiring Diagram (Cont'd)

## BANK 2

NFEC0698S02

### EC-O2H1B2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC299D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
2	R/L	HEATED OXYGEN SENSOR 1 HEATER (FRONT) (BANK 2)	ENGINE RUNNING BELOW 3,600 RPM	0 - 1.0V
			ENGINE RUNNING ABOVE 3,600 RPM	BATTERY VOLTAGE





SEF656XE

# DTC P0135 (BANK 1), P0155 (BANK 2) HO2S1 HEATER (FRONT)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0699

<b>1</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) POWER SUPPLY CIRCUIT</b>
<p>1. Turn ignition switch "OFF".                  2. Check heated oxygen sensor 1 (front) harness protector color.</p> <div style="text-align: center;">  <p>HO2S1 (front)</p> <p>HO2S1 (front) harness protector color</p> </div> <p style="text-align: center;">HO2S1 (front) (bank 1): Black                  HO2S1 (front) (bank 2): Blue</p> <p>3. Disconnect corresponding heated oxygen sensor 1 (front) harness connector.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>Heated oxygen sensor 1 (front) (bank 2) harness connector</p> <p>Front</p> </div> <div style="text-align: center;">  <p>Heated oxygen sensor 1 (front) (bank 1) harness connector</p> </div> </div> <p>4. Turn ignition switch "ON".                  5. Check voltage between HO2S1 (front) terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p><b>Voltage: Battery voltage</b></p> <p>OK or NG</p> </div>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

SEF505YA

SEF902XA

SEF311X

<b>2</b>	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● Fuse block (J/B) connector M19</li> <li>● 15A fuse</li> <li>● Harness for open or short between heated oxygen sensor 1 (front) and fuse</li> </ul>	
▶	Repair harness or connectors.

## DTC P0135 (BANK 1), P0155 (BANK 2) HO2S1 HEATER (FRONT)


Diagnostic Procedure (Cont'd)

<b>3</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>															
<p>1. Turn ignition switch "OFF".                  2. Disconnect ECM harness connector.                  3. Check harness continuity between ECM terminal and HO2S1 (front) terminal as follows.                  Refer to Wiring Diagram.</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0135</td> <td style="text-align: center;">3</td> <td style="text-align: center;">3</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0155</td> <td style="text-align: center;">2</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>			DTC	Terminals		Bank	ECM	Sensor	P0135	3	3	1	P0155	2	3	2
DTC	Terminals			Bank												
	ECM	Sensor														
P0135	3	3	1													
P0155	2	3	2													
MTBL0490																
<p><b>Continuity should exist.</b></p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>																
OK	▶	GO TO 4.														
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.														

<b>4</b>	<b>CHECK HEATED OXYGEN SENSOR 1 HEATER (FRONT)</b>							
<p>Check resistance between HO2S1 (front) terminals as follows.</p>								
SEF310X								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th>Terminals</th> <th>Resistance</th> </tr> </thead> <tbody> <tr> <td>2 and 3</td> <td>2.3 - 4.3Ω at 25°C (77°F)</td> </tr> <tr> <td>1 and 2 1 and 3</td> <td>∞Ω (Continuity should not exist.)</td> </tr> </tbody> </table>			Terminals	Resistance	2 and 3	2.3 - 4.3Ω at 25°C (77°F)	1 and 2 1 and 3	∞Ω (Continuity should not exist.)
Terminals	Resistance							
2 and 3	2.3 - 4.3Ω at 25°C (77°F)							
1 and 2 1 and 3	∞Ω (Continuity should not exist.)							
<p><b>CAUTION:</b>                  Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p> <p style="text-align: center;"><b>OK or NG</b></p>								
OK	▶	GO TO 6.						
NG	▶	GO TO 5.						

## DTC P0135 (BANK 1), P0155 (BANK 2) HO2S1 HEATER (FRONT)


Diagnostic Procedure (Cont'd)

<b>5</b>	<b>REPLACE HEATED OXYGEN SENSOR 1 (FRONT)</b>
<p>1. Turn ignition switch "OFF".</p> <p>2. Check heated oxygen sensor 1 (front) harness protector color.</p>	
 <p>The diagram shows a cross-section of the HO2S1 (front) sensor and its harness protector. The sensor is labeled 'HO2S1 (front)' and the harness protector is labeled 'HO2S1 (front) harness protector color'.</p>	
<p>HO2S1 (front) (bank 1): Black HO2S1 (front) (bank 2): Blue</p>	
<p>SEF505YA</p>	
<p><b>CAUTION:</b> Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.</p>	
<p>▶ Replace malfunctioning heated oxygen sensor 1 (front).</p>	

<b>6</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
<p>▶ <b>INSPECTION END</b></p>	

## DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)

### Component Description



### Component Description

NFEC0700

The heated oxygen sensor 2 (rear), after three way catalyst (Manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 (front) are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2 (rear).

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.


Under normal conditions the heated oxygen sensor 2 (rear) is not used for engine control operation.

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0701

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> <li>Engine: After warming up</li> </ul>	Revving engine from idle up to 2,000 rpm	LEAN ↔ RICH



### On Board Diagnosis Logic

NFEC0702

The heated oxygen sensor 2 (rear) has a much longer switching time between rich and lean than the heated oxygen sensor 1 (front). The oxygen storage capacity before the three way catalyst (Manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2 (rear), ECM monitors whether the minimum voltage of sensor is sufficiently low during the various driving condition such as fuel-cut.

Malfunction is detected when the minimum voltage from the sensor is not reached to the specified voltage.

# DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)

Possible Cause

## Possible Cause

NFEC0703

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Heated oxygen sensor 2 (rear)
- Fuel pressure
- Injectors

<b>8</b>	<b>HO2S2 (B1) P0137</b>
COND1: OUT OF CONDITION	
COND2: INCOMPLETE	
COND3: INCOMPLETE	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

SEF833Y

<b>8</b>	<b>HO2S2 (B1) P0137</b>
COND1: TESTING	
COND2: INCOMPLETE	
COND3: INCOMPLETE	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

SEF834Y

<b>8</b>	<b>HO2S2 (B1) P0137</b>
COND1: COMPLETED	
COND2: INCOMPLETE	
COND3: INCOMPLETE	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

SEF835Y

## DTC Confirmation Procedure

NFEC0759

### CAUTION:

Always drive vehicle at a safe speed.

### NOTE:

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in “Procedure for COND1”.

### Ⓜ WITH CONSULT-II

NFEC0759S01

Procedure for COND1

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch “OFF” and wait at least 10 seconds.
- 3) Turn ignition switch “ON” and select “HO2S2 (B1) P0137/ HO2S2 (B2) P0157” of “HO2S2 (B1)/(B2)” in “DTC WORK SUPPORT” mode with CONSULT-II.
- 4) Touch “START”.
- 5) Start engine and let it idle for at least 30 seconds.
- 6) Rev engine up to 2,000 rpm 2 or 3 times quickly under no load. If “COMPLETED” appears on CONSULT-II screen, go to step 2 in “Procedure for COND3”. If “COMPLETED” does not appear on CONSULT-II screen, go to the following step.
- 7) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 8) When the following conditions are met, “TESTING” will be displayed at “COND1” on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 60 seconds.)

ENG SPEED	1,500 - 3,600 rpm
Vehicle speed	Above 70 km/h (43 MPH)
COOLAN TEMP/S	70 - 105°C (158 - 221°F)
Selector lever	Suitable position

### NOTE:

- If “TESTING” is not displayed after 5 minutes, retry from step 2 in “Procedure for COND1”.
- If “COMPLETED” already appears at “COND2” on CONSULT-II screen before “Procedure for COND2” is

# DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)

DTC Confirmation Procedure (Cont'd)

conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

1	HO2S2 (B1) P0137
	COND1: COMPLETED
	COND2: COMPLETED
	COND3: INCOMPLETE
	MONITOR
	ENG SPEED      XXX rpm
	B/FUEL SCHDL    XXX msec
	COOLAN TEMP/S    XXX °C
	VHCL SPEED SE    XXX km/h

SEF836Y

### Procedure for COND2

- 1) While driving, release accelerator pedal completely with "OD" OFF (A/T models only) from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED". (It will take approximately 4 seconds.)

### NOTE:


If "COMPLETED" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

1	HO2S (B1) P0137
	COMPLETED
	SELF-DIAG RESULTS

SEF661Y

### Procedure for COND3

- 1) Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
- 2) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to "Diagnostic Procedure", EC-218.



## Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 2 (rear) circuit. During this check, a 1st trip DTC might not be confirmed.

### WITH GST

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminal 72 (HO2S2 bank 1 signal) or 71 (HO2S2 bank 2 signal) and engine ground.
- 4) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**The voltage should be below 0.54V at least once during this procedure.**  
**If the voltage can be confirmed in step 4, step 5 is not necessary.**
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "OD" OFF (A/T).  
**The voltage should be below 0.54V at least once during this procedure.**

**DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)**

*Overall Function Check (Cont'd)*

---

- 6) If NG, go to "Diagnostic Procedure", EC-218.

# DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)

Wiring Diagram

## Wiring Diagram



=NFEC0706

NFEC0706S01

### BANK 1

### EC-O2S2B1-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



MEC300D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**  
 DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
72	W	HEATED OXYGEN SENSOR 2 (REAR) (BANK 1)	ENGINE RUNNING FROM IDLE UP TO 2,000 RPM UNDER WARM-UP CONDITION	0 - APPROX. 1.0V

SEF657XE

# DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)




Wiring Diagram (Cont'd)

## BANK 2

NFEC0706S02

### EC-O2S2B2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC301D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
71	W	HEATED OXYGEN SENSOR 2 (REAR) (BANK 2)	ENGINE RUNNING FROM IDLE UP TO 2,000 RPM UNDER WARM-UP CONDITION	0 - APPROX. 1.0V


SEF658XE

# DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)

Diagnostic Procedure

## Diagnostic Procedure



NFEC0707

<b>1</b>	<b>RETIGHTEN GROUND SCREWS</b>
<p>1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF255X</p>	
<p>▶ GO TO 2.</p>	

<b>2</b>	<b>CLEAR THE SELF-LEARNING DATA</b>								
<p> <b>With CONSULT-II</b></p> <p>1. Start engine and warm it up to normal operating temperature. 2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II. 3. Clear the self-learning control coefficient by touching "CLEAR".</p> <div style="text-align: center;"> <table border="1" style="border-collapse: collapse; width: 150px;"> <tr> <th colspan="2" style="text-align: center;">WORK SUPPORT</th> </tr> <tr> <td style="text-align: center;">SELF-LEARNING CONT</td> <td style="text-align: center;">B1 100%</td> </tr> <tr> <td></td> <td style="text-align: center;">B2 100%</td> </tr> <tr> <td colspan="2" style="text-align: center;">CLEAR</td> </tr> </table> </div> <p style="text-align: right;">SEF652Y</p> <p>4. Run engine for at least 10 minutes at idle speed. <b>Is the 1st trip DTC P0172 or P0175 detected?</b> <b>Is it difficult to start engine?</b></p>		WORK SUPPORT		SELF-LEARNING CONT	B1 100%		B2 100%	CLEAR	
WORK SUPPORT									
SELF-LEARNING CONT	B1 100%								
	B2 100%								
CLEAR									
<p> <b>Without CONSULT-II</b></p> <p>1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch "OFF". 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed. 4. Stop engine and reconnect mass air flow sensor harness connector. 5. Make sure 1st trip DTC P0100 is displayed. 6. Erase the 1st trip DTC memory. Refer to "How to Erase Emission-related Diagnostic Information", EC-56. 7. Make sure DTC P0000 is displayed. 8. Run engine for at least 10 minutes at idle speed. <b>Is the 1st trip DTC P0172 or P0175 detected?</b> <b>Is it difficult to start engine?</b></p> <p style="text-align: center;"><b>Yes or No</b></p>									
Yes	▶ Perform trouble diagnosis for DTC P0172, P0175. Refer to EC-269.								
No	▶ GO TO 3.								

# DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)

Diagnostic Procedure (Cont'd)

3	CHECK HEATED OXYGEN SENSOR 2 (REAR) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT														
<p>1. Turn ignition switch "OFF".                      2. Check heated oxygen sensor 2 (rear) harness protector color.</p> <div style="text-align: center;">  <p>HO2S2 (rear) harness protector color</p> <p>HO2S2 (rear) (bank 1): White                      HO2S2 (rear) (bank 2): Red</p> </div> <p style="text-align: right;">SEF154Z</p>															
<p>3. Disconnect corresponding heated oxygen sensor 2 (rear) harness connector.</p> <div style="text-align: center;">  <p>Heated oxygen sensor 2 (rear) (bank 2) harness connector      Heated oxygen sensor 2 (rear) (bank 1) harness connector</p> <p style="text-align: right;">Front</p> </div> <p style="text-align: right;">SEF467WB</p>															
<p>4. Disconnect ECM harness connector.                      5. Check harness continuity between ECM terminal and HO2S2 (rear) terminal as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0137</td> <td style="text-align: center;">72</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0157</td> <td style="text-align: center;">71</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0491</p>		DTC	Terminals		Bank	ECM	Sensor	P0137	72	1	1	P0157	71	1	2
DTC	Terminals		Bank												
	ECM	Sensor													
P0137	72	1	1												
P0157	71	1	2												
<p style="color: blue;"><b>Continuity should exist.</b></p> <p>6. Check harness continuity between ECM terminal or HO2S2 (rear) terminal and ground as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or Sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0137</td> <td style="text-align: center;">72 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0157</td> <td style="text-align: center;">71 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0492</p>		DTC	Terminals		Bank	ECM or Sensor	Ground	P0137	72 or 1	Ground	1	P0157	71 or 1	Ground	2
DTC	Terminals		Bank												
	ECM or Sensor	Ground													
P0137	72 or 1	Ground	1												
P0157	71 or 1	Ground	2												
<p style="color: blue;"><b>Continuity should not exist.</b></p> <p>7. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>															
OK	▶	GO TO 4.													
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.													

## DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)


Diagnostic Procedure (Cont'd)

4	CHECK HEATED OXYGEN SENSOR 2 (REAR) GROUND CIRCUIT FOR OPEN AND SHORT	
1. Check harness continuity between HO2S2 (rear) terminal 4 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b>		
2. Also check harness for short to power.		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 5.
OK (Without CONSULT-II)	▶	GO TO 6.
NG	▶	Repair open circuit or short to power in harness or connectors.


5	CHECK HEATED OXYGEN SENSOR 2 (REAR)	
<b>Ⓟ With CONSULT-II</b>		
1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.		
2. Stop vehicle with engine running.		
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.		
4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$ .		
(Reference data)		
SEF066Y		
"HO2S2 (B1)/(B2)" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "HO2S2 (B1)/(B2)" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.		
<b>CAUTION:</b> Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.		
OK or NG		
OK	▶	GO TO 9.
NG	▶	GO TO 8.

# DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)

Diagnostic Procedure (Cont'd)

<b>6</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)-I</b>
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.</li> <li>2. Stop vehicle with engine running.</li> <li>3. Set voltmeter probes between ECM terminal 72 (HO2S2 bank 1 signal) or 71 (HO2S2 bank 2 signal) and engine ground.</li> <li>4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times. (Depress and release accelerator pedal as soon as possible.)</li> </ol>	
	
SEF313XB	
<b>OK or NG</b>	
OK	▶ GO TO 9.
NG	▶ GO TO 7.

<b>7</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)-II</b>
<p>Idle vehicle for 10 minutes, then check voltage between the same terminals as in Test No. 6; or check voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "OD" OFF (A/T).  <b>The voltage should go below 0.54V at least once during this procedure.</b></p> <p><b>CAUTION:</b>  <b>Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</b></p>	
<b>OK or NG</b>	
OK	▶ GO TO 9.
NG	▶ GO TO 8.

<b>8</b>	<b>REPLACE HEATED OXYGEN SENSOR 2 (REAR)</b>
<ol style="list-style-type: none"> <li>1. Stop vehicle and turn ignition switch OFF.</li> <li>2. Check heated oxygen sensor 2 (rear) harness protector color.</li> </ol>	
	
<p>HO2S2 (rear) (bank 1): White          HO2S2 (rear) (bank 2): Red</p>	
SEF154Z	
<p><b>CAUTION:</b>  <b>Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.</b></p>	
▶	Replace malfunctioning heated oxygen sensor 2 (rear).


## DTC P0137 (BANK 1), P0157 (BANK 2) HO2S2 (REAR) (MIN. VOLTAGE MONITORING)

Diagnostic Procedure (Cont'd)

<b>9</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) SHIELD CIRCUIT FOR OPEN AND SHORT</b>	
1. Turn ignition switch "OFF". 2. Disconnect joint connector-17. 3. Check the following. <ul style="list-style-type: none"><li>● Continuity between joint connector terminal 1 and ground</li><li>● Joint connector (Refer to EL-377, "HARNESS LAYOUT".) <b>Continuity should exist.</b></li></ul>		
4. Also check harness for short to power. 5. Then reconnect joint connector-17.		
<b>OK or NG</b>		
OK	▶	GO TO 10.
NG	▶	Repair open circuit or short to power in harness or connectors.
<b>10</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
	▶	<b>INSPECTION END</b>

# DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)

Component Description



## Component Description

NFEC0708

The heated oxygen sensor 2 (rear), after three way catalyst (Manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 (front) are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2 (rear).

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.


Under normal conditions the heated oxygen sensor 2 (rear) is not used for engine control operation.

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0709

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	● Engine: After warming up	Revsing engine from idle up to 2,000 rpm	LEAN ↔ RICH



## On Board Diagnosis Logic

NFEC0710

The heated oxygen sensor 2 (rear) has a much longer switching time between rich and lean than the heated oxygen sensor 1 (front). The oxygen storage capacity before the three way catalyst (Manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2 (rear), ECM monitors whether the maximum voltage of the sensor is sufficiently high during the various driving condition such as fuel-cut.

Malfunxion is detected when the maximum voltage from the sensor is not reached to the specified voltage.

# DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)

Possible Cause

## Possible Cause

NFEC0711

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Heated oxygen sensor 2 (rear)
- Fuel pressure
- Injectors
- Intake air leaks

<b>8</b>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: center;">HO2S2 (B1) P0138</td> </tr> <tr> <td>COND1:</td> <td>OUT OF CONDITION</td> </tr> <tr> <td>COND2:</td> <td>INCOMPLETE</td> </tr> <tr> <td>COND3:</td> <td>INCOMPLETE</td> </tr> <tr> <td colspan="2" style="text-align: center;">MONITOR</td> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>VHCL SPEED SE</td> <td>XXX km/h</td> </tr> </table>	HO2S2 (B1) P0138		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	COOLAN TEMP/S	XXX °C	VHCL SPEED SE	XXX km/h
HO2S2 (B1) P0138																			
COND1:	OUT OF CONDITION																		
COND2:	INCOMPLETE																		
COND3:	INCOMPLETE																		
MONITOR																			
ENG SPEED	XXX rpm																		
B/FUEL SCHDL	XXX msec																		
COOLAN TEMP/S	XXX °C																		
VHCL SPEED SE	XXX km/h																		

SEF837Y

<b>8</b>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: center;">HO2S2 (B1) P0138</td> </tr> <tr> <td>COND1:</td> <td>TESTING</td> </tr> <tr> <td>COND2:</td> <td>INCOMPLETE</td> </tr> <tr> <td>COND3:</td> <td>INCOMPLETE</td> </tr> <tr> <td colspan="2" style="text-align: center;">MONITOR</td> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>VHCL SPEED SE</td> <td>XXX km/h</td> </tr> </table>	HO2S2 (B1) P0138		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	COOLAN TEMP/S	XXX °C	VHCL SPEED SE	XXX km/h
HO2S2 (B1) P0138																			
COND1:	TESTING																		
COND2:	INCOMPLETE																		
COND3:	INCOMPLETE																		
MONITOR																			
ENG SPEED	XXX rpm																		
B/FUEL SCHDL	XXX msec																		
COOLAN TEMP/S	XXX °C																		
VHCL SPEED SE	XXX km/h																		

SEF838Y

<b>8</b>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: center;">HO2S2 (B1) P0138</td> </tr> <tr> <td>COND1:</td> <td>COMPLETED</td> </tr> <tr> <td>COND2:</td> <td>INCOMPLETE</td> </tr> <tr> <td>COND3:</td> <td>INCOMPLETE</td> </tr> <tr> <td colspan="2" style="text-align: center;">MONITOR</td> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>VHCL SPEED SE</td> <td>XXX km/h</td> </tr> </table>	HO2S2 (B1) P0138		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	COOLAN TEMP/S	XXX °C	VHCL SPEED SE	XXX km/h
HO2S2 (B1) P0138																			
COND1:	COMPLETED																		
COND2:	INCOMPLETE																		
COND3:	INCOMPLETE																		
MONITOR																			
ENG SPEED	XXX rpm																		
B/FUEL SCHDL	XXX msec																		
COOLAN TEMP/S	XXX °C																		
VHCL SPEED SE	XXX km/h																		

SEF839Y

## DTC Confirmation Procedure

NFEC0760

### CAUTION:

Always drive vehicle at a safe speed.

### NOTE:

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in “Procedure for COND1”.

### Ⓜ WITH CONSULT-II

NFEC0760S01

Procedure for COND1

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch “OFF” and wait at least 10 seconds.
- 3) Turn ignition switch “ON” and select “HO2S2 (B1) P0138/HO2S2 (B2) P0158” of “HO2S2 (B1)/(B2)” in “DTC WORK SUPPORT” mode with CONSULT-II.
- 4) Touch “START”.
- 5) Start engine and let it idle for at least 30 seconds.
- 6) Rev engine up to 2,000 rpm 2 or 3 times quickly under no load. If “COMPLETED” appears on CONSULT-II screen, go to step 2 in “Procedure for COND3”. If “COMPLETED” does not appear on CONSULT-II screen, go to the following step.
- 7) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 8) When the following conditions are met, “TESTING” will be displayed at “COND1” on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 60 seconds.)

ENG SPEED	1,500 - 3,600 rpm
Vehicle speed	Above 70 km/h (43 MPH)
COOLAN TEMP/S	70 - 105°C (158 - 221°F)
Selector lever	Suitable position

### NOTE:

- If “TESTING” is not displayed after 5 minutes, retry from step 2 in “Procedure for COND1”.
- If “COMPLETED” already appears at “COND2” on CONSULT-II screen before “Procedure for COND2” is

# DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)

DTC Confirmation Procedure (Cont'd)

conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

1	HO2S2 (B1) P0138
	COND1: COMPLETED
	COND2: COMPLETED
	COND3: INCOMPLETE
	MONITOR
	ENG SPEED      XXX rpm
	B/FUEL SCHDL    XXX msec
	COOLAN TEMP/S    XXX °C
	VHCL SPEED SE    XXX km/h

SEF840Y

### Procedure for COND2

- 1) While driving, release accelerator pedal completely with "OD" OFF (A/T models only) from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen is turned to "COMPLETED". (It will take approximately 4 seconds.)

### NOTE:


If "COMPLETED" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

1	HO2S2 (B1) P0138
	COMPLETED
	SELF-DIAG RESULTS

SEF665Y

### Procedure for COND3

- 1) Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
- 2) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".  
If "NG" is displayed, refer to "Diagnostic Procedure", EC-229.



## Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 2 (rear) circuit. During this check, a 1st trip DTC might not be confirmed.

### WITH GST

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminal 72 (HO2S2 bank 1 signal) or 71 (HO2S2 bank 2 signal) and engine ground.
- 4) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**The voltage should be above 0.56V at least once during this procedure.**  
**If the voltage can be confirmed in step 4, step 5 is not necessary.**
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "OD" OFF (A/T).  
**The voltage should be above 0.56V at least once during this procedure.**

**DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)**

*Overall Function Check (Cont'd)*

---

6) If NG, go to "Diagnostic Procedure", EC-229.

# DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)

Wiring Diagram

## Wiring Diagram



**BANK 1**

=NFEC0714

NFEC0714S01

**EC-O2S2B1-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC300D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
72	W	HEATED OXYGEN SENSOR 2 (REAR) (BANK 1)	ENGINE RUNNING FROM IDLE UP TO 2,000 RPM UNDER WARM-UP CONDITION	0 - APPROX. 1.0V

SEF657XE

# DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)



Wiring Diagram (Cont'd)

## BANK 2

NFEC0714S02

### EC-O2S2B2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC301D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
71	W	HEATED OXYGEN SENSOR 2 (REAR) (BANK 2)	ENGINE RUNNING FROM IDLE UP TO 2,000 RPM UNDER WARM-UP CONDITION	0 - APPROX. 1.0V


SEF658XE

# DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)

Diagnostic Procedure

## Diagnostic Procedure



NFEC0715

<b>1</b>	<b>RETIGHTEN GROUND SCREWS</b>
<p>1. Turn ignition switch "OFF".</p> <p>2. Loosen and retighten engine ground screws.</p>	
	
SEF255X	
▶ GO TO 2.	

<b>2</b>	<b>CLEAR THE SELF-LEARNING DATA</b>								
<p> <b>With CONSULT-II</b></p> <p>1. Start engine and warm it up to normal operating temperature.</p> <p>2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.</p> <p>3. Clear the self-learning control coefficient by touching "CLEAR".</p>									
<table border="1" style="margin: auto;"> <tr> <th colspan="2" style="text-align: center;">WORK SUPPORT</th> </tr> <tr> <td style="text-align: center;">SELF-LEARNING CONT</td> <td style="text-align: center;">B1 100%</td> </tr> <tr> <td></td> <td style="text-align: center;">B2 100%</td> </tr> <tr> <td colspan="2" style="text-align: center;">CLEAR</td> </tr> </table>		WORK SUPPORT		SELF-LEARNING CONT	B1 100%		B2 100%	CLEAR	
WORK SUPPORT									
SELF-LEARNING CONT	B1 100%								
	B2 100%								
CLEAR									
SEF652Y									
<p>4. Run engine for at least 10 minutes at idle speed.</p> <p><b>Is the 1st trip DTC P0171 or P0174 detected?</b></p> <p><b>Is it difficult to start engine?</b></p>									
<p> <b>Without CONSULT-II</b></p> <p>1. Start engine and warm it up to normal operating temperature.</p> <p>2. Turn ignition switch "OFF".</p> <p>3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.</p> <p>4. Stop engine and reconnect mass air flow sensor harness connector.</p> <p>5. Make sure 1st trip DTC P0100 is displayed.</p> <p>6. Erase the 1st trip DTC memory. Refer to "How to Erase Emission-related Diagnostic Information", EC-56.</p> <p>7. Make sure DTC P0000 is displayed.</p> <p>8. Run engine for at least 10 minutes at idle speed.</p> <p><b>Is the 1st trip DTC P0171 or P0174 detected?</b></p> <p><b>Is it difficult to start engine?</b></p>									
<b>Yes or No</b>									
Yes	▶ Perform trouble diagnosis for DTC P0171, P0174. Refer to EC-261.								
No	▶ GO TO 3.								

# DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>														
<p>1. Turn ignition switch "OFF".</p> <p>2. Check heated oxygen sensor 2 (rear) harness protector color.</p> <div style="text-align: center; margin: 10px 0;">  <p style="margin-top: 10px;">HO2S2 (rear) (bank 1): White HO2S2 (rear) (bank 2): Red</p> </div> <p style="text-align: right;">SEF154Z</p>															
<p>3. Disconnect corresponding heated oxygen sensor 2 (rear) harness connector.</p> <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right;">SEF467WB</p>															
<p>4. Disconnect ECM harness connector.</p> <p>5. Check harness continuity between ECM terminal and HO2S2 (rear) terminal as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0138</td> <td style="text-align: center;">72</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0158</td> <td style="text-align: center;">71</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0493</p>		DTC	Terminals		Bank	ECM	Sensor	P0138	72	1	1	P0158	71	1	2
DTC	Terminals		Bank												
	ECM	Sensor													
P0138	72	1	1												
P0158	71	1	2												
<p style="color: blue;"><b>Continuity should exist.</b></p> <p>6. Check harness continuity between ECM terminal or HO2S2 (rear) terminal and ground as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or Sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0138</td> <td style="text-align: center;">72 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0158</td> <td style="text-align: center;">71 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0494</p>		DTC	Terminals		Bank	ECM or Sensor	Ground	P0138	72 or 1	Ground	1	P0158	71 or 1	Ground	2
DTC	Terminals		Bank												
	ECM or Sensor	Ground													
P0138	72 or 1	Ground	1												
P0158	71 or 1	Ground	2												
<p style="color: blue;"><b>Continuity should not exist.</b></p> <p>7. Also check harness for short to power.</p> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p>															
OK	▶	GO TO 4.													
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.													

# DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)


Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) GROUND CIRCUIT FOR OPEN AND SHORT</b>	
1. Check harness continuity between HO2S2 (rear) terminal 4 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b>		
2. Also check harness for short to power.		
<b>OK or NG</b>		
OK (With CONSULT-II)	▶	GO TO 5.
OK (Without CONSULT-II)	▶	GO TO 6.
NG	▶	Repair open circuit or short to power in harness or connectors.


<b>5</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)</b>	
<b>Ⓟ With CONSULT-II</b>		
1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes. 2. Stop vehicle with engine running. 3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II. 4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$ .		
(Reference data)		
SEF066Y		
"HO2S2 (B1)/(B2)" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "HO2S2 (B1)/(B2)" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.		
<b>CAUTION:</b> Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.		
<b>OK or NG</b>		
OK	▶	GO TO 9.
NG	▶	GO TO 8.

# DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)

Diagnostic Procedure (Cont'd)

<b>6</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)-I</b>	
<p>⊗ <b>Without CONSULT</b></p> <ol style="list-style-type: none"> <li>1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.</li> <li>2. Stop vehicle with engine running.</li> <li>3. Set voltmeter probes between ECM terminal 72 (HO2S2 bank 1 signal) or 71 (HO2S2 bank 2 signal) and engine ground.</li> <li>4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times. (Depress and release accelerator pedal as soon as possible.)</li> </ol>		
		
<p>The voltage should be above 0.56V at least once during this procedure.</p>		
SEF313XB		
<b>OK or NG</b>		
OK	▶	GO TO 9.
NG	▶	GO TO 7.

<b>7</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)-II</b>	
<p>Idle vehicle for 10 minutes, then check voltage between the same terminals as in Test No. 6; or check voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "OD" OFF (A/T).  <b>The voltage should go below 0.54V at least once during this procedure.</b></p> <p><b>CAUTION:</b>  <b>Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</b></p>		
<b>OK or NG</b>		
OK	▶	GO TO 9.
NG	▶	GO TO 8.

<b>8</b>	<b>REPLACE HEATED OXYGEN SENSOR 2 (REAR)</b>	
<ol style="list-style-type: none"> <li>1. Stop vehicle and turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 2 (rear) harness protector color.</li> </ol>		
		
<p>HO2S2 (rear) (bank 1): White          HO2S2 (rear) (bank 2): Red</p>		
SEF154Z		
<p><b>CAUTION:</b>  <b>Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.</b></p>		
▶		Replace malfunctioning heated oxygen sensor 2 (rear).

# DTC P0138 (BANK 1), P0158 (BANK 2) HO2S2 (REAR) (MAX. VOLTAGE MONITORING)


Diagnostic Procedure (Cont'd)

<b>9</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) SHIELD CIRCUIT FOR OPEN AND SHORT</b>	
1. Turn ignition switch "OFF". 2. Disconnect joint connector-17. 3. Check the following. <ul style="list-style-type: none"><li>• Continuity between joint connector terminal 1 and ground</li><li>• Joint connector (Refer to EL-377, "HARNES LAYOUT".) <b>Continuity should exist.</b></li></ul>		
4. Also check harness for short to power. 5. Then reconnect joint connector-17.		
<b>OK or NG</b>		
OK	▶	GO TO 10.
NG	▶	Repair open circuit or short to power in harness or connectors.

<b>10</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
	▶	<b>INSPECTION END</b>

# DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)

## Component Description



## Component Description

NFEC0716

The heated oxygen sensor 2 (rear), after three way catalyst (Manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 (front) are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2 (rear).

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.


Under normal conditions the heated oxygen sensor 2 (rear) is not used for engine control operation.

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0717

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> <li>Engine: After warming up</li> </ul>	Revsing engine from idle up to 2,000 rpm	LEAN ↔ RICH



## On Board Diagnosis Logic

NFEC0718

The heated oxygen sensor 2 (rear) has a much longer switching time between rich and lean than the heated oxygen sensor 1 (front). The oxygen storage capacity before the three way catalyst (Manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2 (rear), ECM monitors whether the switching response of the sensor's voltage is faster than specified during the various driving condition such as fuel-cut.

Malfunction is detected when it takes more time for the sensor to respond between rich and lean than the specified time.

# DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)

Possible Cause

## Possible Cause

NFEC0719

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Heated oxygen sensor 2 (rear)
- Fuel pressure
- Injectors
- Intake air leaks

<b>8</b>	<b>HO2S2 (B1) P0139</b>
COND1: OUT OF CONDITION	
COND2: INCOMPLETE	
COND3: INCOMPLETE	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

SEF841Y

<b>8</b>	<b>HO2S2 (B1) P0139</b>
COND1: TESTING	
COND2: INCOMPLETE	
COND3: INCOMPLETE	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

SEF842Y

<b>8</b>	<b>HO2S2 (B1) P0139</b>
COND1: COMPLETED	
COND2: INCOMPLETE	
COND3: INCOMPLETE	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

SEF843Y

## DTC Confirmation Procedure

NFEC0761

### CAUTION:

Always drive vehicle at a safe speed.

### NOTE:

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If “DTC Confirmation Procedure ” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in “Procedure for COND1”.

### Ⓜ WITH CONSULT-II

NFEC0761S01

Procedure for COND1

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch “OFF” and wait at least 10 conds.
- 3) Turn ignition switch “ON” and select “HO2S2 (B1) P0139/ HO2S2 (B2) P0159” of “HO2S2 (B1)/(B2)” in “DTC WORK SUPPORT” mode with CONSULT-II.
- 4) Touch “START”.
- 5) Start engine and let it idle for at least 30 seconds.
- 6) Rev engine up to 2,000 rpm 2 or 3 times quickly under no load. If “COMPLETED” appears on CONSULT-II screen, go to step 2 in “Procedure for COND3”. If “COMPLETED” does not appear on CONSULT-II screen, go to the following step.
- 7) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 8) When the following conditions are met, “TESTING” will be displayed at “COND1” on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 60 seconds.)

ENG SPEED	1,500 - 3,600 rpm
Vehicle speed	Above 70 km/h (43 MPH)
COOLAN TEMP/S	70 - 105°C (158 - 221°F)
Selector lever	Suitable position

### NOTE:

- If “TESTING” is not displayed after 5 minutes, retry from step 2 in “Procedure for COND1”.
- If “COMPLETED” already appears at “COND2” on CONSULT-II screen before “Procedure for COND2” is

# DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)

DTC Confirmation Procedure (Cont'd)

conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

1	HO2S2 (B1) P0139	
	COND1:	COMPLETED
	COND2:	COMPLETED
	COND3:	INCOMPLETE
	MONITOR	
	ENG SPEED	XXX rpm
	B/FUEL SCHDL	XXX msec
	COOLAN TEMP/S	XXX °C
	VHCL SPEED SE	XXX km/h
	SEF844Y	

### Procedure for COND2

- 1) While driving, release accelerator pedal completely with "OD" OFF (A/T models only) from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED". (It will take approximately 4 seconds.)


### NOTE:

If "COMPLETED" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

1	HO2S2 (B1) P0139	
	COMPLETED	
	SELF-DIAG RESULTS	
SEF668Y		

### Procedure for COND3

- 1) Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
- 2) Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".  
If "NG" is displayed, refer to "Diagnostic Procedure", EC-240.



## Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 2 (rear) circuit. During this check, a 1st trip DTC might not be confirmed.

### WITH GST

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminal 72 (HO2S2 bank 1 signal) or 71 (HO2S2 bank 2 signal) and engine ground.
- 4) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**The voltage should change at more than 0.06V for 1 second during this procedure.**  
**If the voltage can be confirmed in step 4, step 5 is not necessary.**
- 5) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "OD" OFF (A/T).  
**The voltage should change at more than 0.06V for 1 second during this procedure.**

**DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)**

*Overall Function Check (Cont'd)*

---

- 6) If NG, go to "Diagnostic Procedure", EC-240.

# DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)

Wiring Diagram

## Wiring Diagram



=NFEC0722

**BANK 1**

NFEC0722S01

**EC-O2S2B1-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC300D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
72	W	HEATED OXYGEN SENSOR 2 (REAR) (BANK 1)	ENGINE RUNNING FROM IDLE UP TO 2,000 RPM UNDER WARM-UP CONDITION	0 - APPROX. 1.0V

SEF657XE

# DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)



Wiring Diagram (Cont'd)

## BANK 2

NFEC0722S02

### EC-O2S2B2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC301D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
71	W	HEATED OXYGEN SENSOR 2 (REAR) (BANK 2)	ENGINE RUNNING FROM IDLE UP TO 2,000 RPM UNDER WARM-UP CONDITION	0 - APPROX. 1.0V


SEF658XE

# DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0723

<b>1</b>	<b>RETIGHTEN GROUND SCREWS</b>
<p>1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF255X</p>	
▶ GO TO 2.	


<b>2</b>	<b>CLEAR THE SELF-LEARNING DATA</b>								
<p> <b>With CONSULT-II</b></p> <p>1. Start engine and warm it up to normal operating temperature. 2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II. 3. Clear the self-learning control coefficient by touching "CLEAR".</p> <div style="text-align: center;"> <table border="1" style="border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: center;">WORK SUPPORT</th> </tr> <tr> <td style="text-align: center;">SELF-LEARNING CONT</td> <td style="text-align: center;">B1 100%</td> </tr> <tr> <td></td> <td style="text-align: center;">B2 100%</td> </tr> <tr> <td colspan="2" style="text-align: center;">CLEAR</td> </tr> </table> </div> <p style="text-align: right;">SEF652Y</p> <p>4. Run engine for at least 10 minutes at idle speed. <b>Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?</b> <b>Is it difficult to start engine?</b></p>		WORK SUPPORT		SELF-LEARNING CONT	B1 100%		B2 100%	CLEAR	
WORK SUPPORT									
SELF-LEARNING CONT	B1 100%								
	B2 100%								
CLEAR									
<p> <b>Without CONSULT-II</b></p> <p>1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch "OFF". 3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed. 4. Stop engine and reconnect mass air flow sensor harness connector. 5. Make sure 1st trip DTC No. 0100 is displayed. 6. Erase the 1st trip DTC memory. Refer to "How to Erase Emission-related Diagnostic Information", EC-56. 7. Make sure DTC No. 0000 is displayed. 8. Run engine for at least 10 minutes at idle speed. <b>Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?</b> <b>Is it difficult to start engine?</b></p> <p style="text-align: center;"><b>Yes or No</b></p>									
Yes	▶ Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to EC-261, EC-269.								
No	▶ GO TO 3.								

# DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)

Diagnostic Procedure (Cont'd)

## 3 CHECK HEATED OXYGEN SENSOR 2 (REAR) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Check heated oxygen sensor 2 (rear) harness protector color.



HO2S2 (rear) (bank 1): White  
HO2S2 (rear) (bank 2): Red

SEF154Z

3. Disconnect corresponding heated oxygen sensor 2 (rear) harness connector.



SEF467WB

4. Disconnect ECM harness connector.
5. Check harness continuity between ECM terminal and HO2S2 (rear) terminal as follows. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0139	72	1	1
P0159	71	1	2

MTBL0495

**Continuity should exist.**

6. Check harness continuity between ECM terminal or HO2S2 (rear) terminal and ground as follows. Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM or Sensor	Ground	
P0139	72 or 1	Ground	1
P0159	71 or 1	Ground	2

MTBL0496

**Continuity should not exist.**

7. Also check harness for short to power.

**OK or NG**

OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

## DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)


Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) GROUND CIRCUIT FOR OPEN AND SHORT</b>	
1. Check harness continuity between HO2S2 (rear) terminal 4 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b>		
2. Also check harness for short to power.		
<b>OK or NG</b>		
OK (With CONSULT-II)	▶	GO TO 5.
OK (Without CONSULT-II)	▶	GO TO 6.
NG	▶	Repair open circuit or short to power in harness or connectors


<b>5</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)</b>	
<b>Ⓟ With CONSULT-II</b>		
1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes. 2. Stop vehicle with engine running. 3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II. 4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$ .		
(Reference data)		
SEF066Y		
"HO2S2 (B1)/(B2)" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "HO2S2 (B1)/(B2)" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.		
<b>CAUTION:</b> Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.		
<b>OK or NG</b>		
OK	▶	GO TO 9.
NG	▶	GO TO 8.

# DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)

Diagnostic Procedure (Cont'd)

<b>6</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)-I</b>
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.</li> <li>2. Stop vehicle with engine running.</li> <li>3. Set voltmeter probes between ECM terminal 72 (HO2S2 bank 1 signal) or 71 (HO2S2 bank 2 signal) and engine ground.</li> <li>4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times. (Depress and release accelerator pedal as soon as possible.)</li> </ol>	
	
<p>The voltage should be above 0.56V at least once during this procedure.</p>	
SEF313XB	
<b>OK or NG</b>	
OK	▶ GO TO 9.
NG	▶ GO TO 7.

<b>7</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)-II</b>
<p>Idle vehicle for 10 minutes, then check voltage between the same terminals as in Test No. 6; or check voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "OD" OFF (A/T).  <b>The voltage should go below 0.54V at least once during this procedure.</b></p> <p><b>CAUTION:</b>          Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p>	
<b>OK or NG</b>	
OK	▶ GO TO 9.
NG	▶ GO TO 8.

<b>8</b>	<b>REPLACE HEATED OXYGEN SENSOR 2 (REAR)</b>
<ol style="list-style-type: none"> <li>1. Stop vehicle and turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 2 (rear) harness protector color.</li> </ol>	
	
<p>HO2S2 (rear) (bank 1): White          HO2S2 (rear) (bank 2): Red</p>	
SEF154Z	
<p><b>CAUTION:</b>          Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.</p>	
▶ Replace malfunctioning heated oxygen sensor 2 (rear).	

## DTC P0139 (BANK 1), P0159 (BANK 2) HO2S2 (REAR) (RESPONSE MONITORING)


Diagnostic Procedure (Cont'd)

<b>9</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) SHIELD CIRCUIT FOR OPEN AND SHORT</b>	
1. Turn ignition switch "OFF". 2. Disconnect joint connector-17. 3. Check the following. <ul style="list-style-type: none"><li>● Continuity between joint connector terminal 1 and ground</li><li>● Joint connector (Refer to EL-377, "HARNESS LAYOUT".) <b>Continuity should exist.</b></li></ul>		
4. Also check harness for short to power. 5. Then reconnect joint connector-17.		
<b>OK or NG</b>		
OK	▶	GO TO 10.
NG	▶	Repair open circuit or short to power in harness or connectors.

<b>10</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

# DTC P0140 (BANK 1), P0160 (BANK 2) HO2S2 (REAR) (HIGH VOLTAGE)

*Component Description*



## Component Description

NFEC0724

The heated oxygen sensor 2 (rear), after three way catalyst (Manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 (front) are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2 (rear).

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.


Under normal conditions the heated oxygen sensor 2 (rear) is not used for engine control operation.

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0725

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	<ul style="list-style-type: none"> <li>Engine: After warming up</li> </ul>	Reving engine from idle up to 2,000 rpm	LEAN ↔ RICH



## On Board Diagnosis Logic

NFEC0726

The heated oxygen sensor 2 (rear) has a much longer switching time between rich and lean than the heated oxygen sensor 1 (front). The oxygen storage capacity before the three way catalyst (Manifold) causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2 (rear), ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.

Malfunction is detected when an excessively high voltage from the sensor is sent to ECM.


# DTC P0140 (BANK 1), P0160 (BANK 2) HO2S2 (REAR) (HIGH VOLTAGE)

Possible Cause

## Possible Cause

NFEC0727

- Harness or connectors  
(The sensor circuit is open or shorted.)
- Heated oxygen sensor 2 (rear)



## DTC Confirmation Procedure

NFEC0728

### CAUTION:

Always drive vehicle at a safe speed.

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.


### WITH CONSULT-II

NFEC0728S01

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 3) Stop vehicle with engine running.
- 4) Let engine idle for 1 minute.
- 5) Maintain the following conditions for at least 5 consecutive seconds.

ENG SPEED	1,300 - 3,100 rpm
VHCL SPEED SE	64 - 130 km/h (40 - 80 MPH)
B/FUEL SCHDL	0.5 - 6.4 msec
COOLAN TEMP/S	70 - 100°C (158 - 212°F)
Selector lever	Suitable position

- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-250.



## Overall Function Check

NFEC0729

Use this procedure to check the overall function of the heated oxygen sensor 2 (rear) circuit. During this check, a 1st trip DTC might not be confirmed.

### WITH GST

NFEC0729S01

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeter probes between ECM terminal 72 (HO2S2 bank 1 signal) or 71 (HO2S2 bank 2 signal) and engine ground.

## DTC P0140 (BANK 1), P0160 (BANK 2) HO2S2 (REAR) (HIGH VOLTAGE)

*Overall Function Check (Cont'd)*

---

- 4) Check the voltage when racing up to 4,000 rpm under no load at least 10 times.  
(Depress and release accelerator pedal as soon as possible.)  
**The voltage should be below 1.4V during this procedure.**
- 5) If NG, go to "Diagnostic Procedure", EC-250.

# DTC P0140 (BANK 1), P0160 (BANK 2) HO2S2 (REAR) (HIGH VOLTAGE)

Wiring Diagram

## Wiring Diagram


=NFEC0730

NFEC0730S01

### BANK 1

### EC-O2S2B1-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC




REFER TO EL-POWER.

HEATED OXYGEN SENSOR 2 (REAR) (BANK 1) (F24)

JOINT CONNECTOR-17 (F47)

ECM (F48)



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC300D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:** DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
72	W	HEATED OXYGEN SENSOR 2 (REAR) (BANK 1)	ENGINE RUNNING FROM IDLE UP TO 2,000 RPM UNDER WARM-UP CONDITION	0 - APPROX. 1.0V

SEF657XE

# DTC P0140 (BANK 1), P0160 (BANK 2) HO2S2 (REAR) (HIGH VOLTAGE)



Wiring Diagram (Cont'd)

## BANK 2

NFEC0730S02

### EC-O2S2B2-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC301D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
71	W	HEATED OXYGEN SENSOR 2 (REAR) (BANK 2)	ENGINE RUNNING FROM IDLE UP TO 2,000 RPM UNDER WARM-UP CONDITION	0 - APPROX. 1.0V

SEF658XE

# DTC P0140 (BANK 1), P0160 (BANK 2) HO2S2 (REAR) (HIGH VOLTAGE)


Diagnostic Procedure

## Diagnostic Procedure

NFEC0731


### 1 INSPECTION START

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.



SEF255X


3. Check heated oxygen sensor 2 (rear) harness protector color.



HO2S2 (rear) (bank 1): White  
HO2S2 (rear) (bank 2): Red

SEF154Z

4. Disconnect corresponding heated oxygen sensor 2 (rear) harness connector.



SEF467WB

5. Disconnect ECM harness connector.



GO TO 2.

## DTC P0140 (BANK 1), P0160 (BANK 2) HO2S2 (REAR) (HIGH VOLTAGE)

Diagnostic Procedure (Cont'd)

<b>2</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>																													
<p>1. Check harness continuity between ECM terminal and HO2S2 (rear) terminal as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0140</td> <td style="text-align: center;">72</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0160</td> <td style="text-align: center;">71</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL0497</p> <p><b>Continuity should exist.</b></p> <p>2. Check harness continuity between ECM terminal or HO2S2 (rear) terminal and ground as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or Sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0140</td> <td style="text-align: center;">72 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0160</td> <td style="text-align: center;">71 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">2</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL0498</p> <p><b>Continuity should not exist.</b></p> <p>3. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>			DTC	Terminals		Bank	ECM	Sensor	P0140	72	1	1	P0160	71	1	2	DTC	Terminals		Bank	ECM or Sensor	Ground	P0140	72 or 1	Ground	1	P0160	71 or 1	Ground	2
DTC	Terminals			Bank																										
	ECM	Sensor																												
P0140	72	1	1																											
P0160	71	1	2																											
DTC	Terminals		Bank																											
	ECM or Sensor	Ground																												
P0140	72 or 1	Ground	1																											
P0160	71 or 1	Ground	2																											
OK	▶	GO TO 3.																												
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.																												

<b>3</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) GROUND CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Check harness continuity between HO2S2 (rear) terminal 4 and engine ground. Refer to Wiring Diagram.</p> <p><b>Continuity should exist.</b></p> <p>2. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to power in harness or connectors.

<b>4</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) CONNECTORS FOR WATER</b>	
<p>Check heated oxygen sensor 2 (rear) connector and harness connector for water.</p> <p><b>Water should not exist.</b></p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK (With CONSULT-II)	▶	GO TO 5.
OK (Without CONSULT-II)	▶	GO TO 6.
NG	▶	Repair or replace harness or connectors.

# DTC P0140 (BANK 1), P0160 (BANK 2) HO2S2 (REAR) (HIGH VOLTAGE)

Diagnostic Procedure (Cont'd)


<b>5</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)</b>
<p><b>Ⓜ With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.</li> <li>2. Stop vehicle with engine running.</li> <li>3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.</li> <li>4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to <math>\pm 25\%</math>.</li> </ol>	
(Reference data)	
SEF066Y	
<p>"HO2S2 (B1)/(B2)" should be above 0.56V at least once when the "FUEL INJECTION" is +25%.          "HO2S2 (B1)/(B2)" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.</p> <p><b>CAUTION:</b>          Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p>	
OK or NG	
OK	▶ GO TO 9.
NG	▶ GO TO 8.

<b>6</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)-I</b>
<p><b>⊗ Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.</li> <li>2. Stop vehicle with engine running.</li> <li>3. Set voltmeter probes between ECM terminal 72 (HO2S2 bank 1 signal) or 71 (HO2S2 bank 2 signal) and engine ground.</li> <li>4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times. (Depress and release accelerator pedal as soon as possible.)</li> </ol>	
<p>The voltage should be above 0.56V at least once during this procedure.</p>	
SEF313XB	
OK or NG	
OK	▶ GO TO 9.
NG	▶ GO TO 7.

# DTC P0140 (BANK 1), P0160 (BANK 2) HO2S2 (REAR) (HIGH VOLTAGE)

Diagnostic Procedure (Cont'd)

<b>7</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR)-II</b>	
<p>Idle vehicle for 10 minutes, then check voltage between the same terminals as in Test No. 6; or check voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "OD" OFF (A/T).  <b>The voltage should go below 0.54V at least once during this procedure.</b></p> <p><b>CAUTION:</b>  <b>Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</b></p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 9.
NG	▶	GO TO 8.

<b>8</b>	<b>REPLACE HEATED OXYGEN SENSOR 2 (REAR)</b>	
<p>1. Stop vehicle and turn ignition switch "OFF".                  2. Check heated oxygen sensor 2 (rear) harness protector color.</p> <div style="text-align: center;">  <p>The diagram shows a heated oxygen sensor (HO2S2) with a long wire harness. The sensor end is labeled 'HO2S2 (rear)'. The harness end is labeled 'HO2S2 (rear) harness protector color'. Below the diagram, it specifies: HO2S2 (rear) (bank 1): White; HO2S2 (rear) (bank 2): Red.</p> </div> <p style="text-align: right;">SEF154Z</p> <p><b>CAUTION:</b>  <b>Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.</b></p>		
▶		Replace malfunctioning heated oxygen sensor 2 (rear).

<b>9</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) SHIELD CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect joint connector-17.                  3. Check the following.</p> <ul style="list-style-type: none"> <li>● Continuity between joint connector terminal 1 and ground</li> <li>● Joint connector                      (Refer to EL-377, "HARNESS LAYOUT".)  <b>Continuity should exist.</b></li> </ul> <p>4. Also check harness for short to power.                  5. Then reconnect joint connector-17.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 10.
NG	▶	Repair open circuit or short to power in harness or connectors.

<b>10</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

## DTC P0141 (BANK 1), P0161 (BANK 2) HO2S2 HEATER (REAR)

Description

### Description

NFEC0732

#### SYSTEM DESCRIPTION

NFEC0732S01

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 2 heater (rear) control	Heated oxygen sensor 2 heater (rear)
Crankshaft position sensor (REF)			

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater (rear) corresponding to the engine speed.

#### OPERATION

NFEC0732S02

Engine speed rpm	Heated oxygen sensor 2 heater (rear)
Above 3,600	OFF
Below 3,600	ON

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0733

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Engine is running above 3,600 rpm.</li> </ul>	OFF
	<ul style="list-style-type: none"> <li>● Engine is running below 3,600 rpm after driving for 2 minutes at a speed of 70 km/h (43 MPH) or more.</li> </ul>	ON

### On Board Diagnosis Logic

NFEC0734

Malfunction is detected when the current amperage in the heated oxygen sensor 2 heater (rear) circuit is out of the normal range. [An improper voltage drop signal is sent to ECM through the heated oxygen sensor 2 heater (rear).]


### Possible Cause

NFEC0735

- Harness or connectors  
[The heated oxygen sensor 2 heater (rear) circuit is open or shorted.]
- Heated oxygen sensor 2 heater (rear)

## DTC P0141 (BANK 1), P0161 (BANK 2) HO2S2 HEATER (REAR)

DTC Confirmation Procedure



### DTC Confirmation Procedure

NFEC0736

#### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

#### WITH CONSULT-II

NFEC0736S01

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine.
- 3) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 4) Stop vehicle and let engine idle for at least 6 seconds.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-258.

#### WITH GST

NFEC0736S02

- 1) Start engine.
  - 2) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
  - 3) Stop vehicle and let engine idle for at least 6 seconds.
  - 4) Turn ignition switch "OFF" and wait at least 10 seconds.
  - 5) Start engine.
  - 6) Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
  - 7) Stop vehicle and let engine idle for at least 6 seconds.
  - 8) Select "MODE 3" with GST.
  - 9) If DTC is detected, go to "Diagnostic Procedure", EC-258.
- When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.

# DTC P0141 (BANK 1), P0161 (BANK 2) HO2S2 HEATER (REAR)

Wiring Diagram

## Wiring Diagram



NFEC0737

NFEC0737S01

**BANK 1**

**EC-O2H2B1-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC302D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:** DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
5	P/B	HEATED OXYGEN SENSOR 2 HEATER (REAR) (BANK 1)	IGN ON	BATTERY VOLTAGE
			ENGINE RUNNING ABOVE 3,600 RPM	
			ENGINE RUNNING BELOW 3,600 RPM AFTER DRIVING FOR 2 MINUTES AT A SPEED OF 70 KM/H (43 MPH) OR MORE	0 - 1.0V

SEF659XE



# DTC P0141 (BANK 1), P0161 (BANK 2) HO2S2 HEATER (REAR)

Wiring Diagram (Cont'd)

## BANK 2

NFEC0737S02

### EC-O2H2B2-01



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC303D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
4	R/L	HEATED OXYGEN SENSOR 2 HEATER (REAR) (BANK 2)	IGN ON	BATTERY VOLTAGE
			ENGINE RUNNING ABOVE 3,600 RPM	
			ENGINE RUNNING BELOW 3,600 RPM AFTER DRIVING FOR 2 MINUTES AT A SPEED OF 70 KM/H (43 MPH) OR MORE	0 - 1.0V




SEF660XE

# DTC P0141 (BANK 1), P0161 (BANK 2) HO2S2 HEATER (REAR)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0738

<b>1</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Check heated oxygen sensor 2 (rear) harness protector color.</p> <div style="text-align: center;">  <p>HO2S2 (rear) HO2S2 (rear) harness protector color</p> <p>HO2S2 (rear) (bank 1): White                      HO2S2 (rear) (bank 2): Red</p> </div> <p style="text-align: right;">SEF154Z</p> <p>3. Disconnect corresponding heated oxygen sensor 2 (rear) harness connector.</p> <div style="text-align: center;">  <p>Heated oxygen sensor 2 (rear) (bank 2) harness connector                      Heated oxygen sensor 2 (rear) (bank 1) harness connector</p> <p style="text-align: right;">Front</p> </div> <p style="text-align: right;">SEF467WB</p> <p>4. Turn ignition switch "ON".                  5. Check voltage between HO2S2 (rear) terminal 3 and ground.</p> <div style="text-align: center;">  <p style="text-align: right;"><b>Voltage: Battery voltage</b></p> </div> <p style="text-align: right;">SEF314X</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 3.
NG	▶	GO TO 2.

<b>2</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● Fuse block (J/B) connector M19</li> <li>● 15A fuse</li> <li>● Harness for open or short between heated oxygen sensor 2 (rear) and fuse</li> </ul>		
▶		Repair harness or connectors.

## DTC P0141 (BANK 1), P0161 (BANK 2) HO2S2 HEATER (REAR)

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>														
<p>1. Turn ignition switch "OFF".                  2. Disconnect ECM harness connector.                  3. Check harness continuity between ECM terminal and HO2S2 (rear) terminal as follows.                  Refer to Wiring Diagram.</p>															
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0141</td> <td style="text-align: center;">5</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0161</td> <td style="text-align: center;">4</td> <td style="text-align: center;">2</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>		DTC	Terminals		Bank	ECM	Sensor	P0141	5	2	1	P0161	4	2	2
DTC	Terminals		Bank												
	ECM	Sensor													
P0141	5	2	1												
P0161	4	2	2												
MTBL0499															
<p><b>Continuity should exist.</b></p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>															
OK	▶ GO TO 4.														
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.														

<b>4</b>	<b>CHECK HEATED OXYGEN SENSOR 2 HEATER (REAR)</b>
<p>Check the resistance between HO2S2 (rear) terminals as follows.</p>	
SEF315X	
<p><b>CAUTION:</b>                  Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

<b>5</b>	<b>REPLACE HEATED OXYGEN SENSOR 2 (REAR)</b>
<p>Check heated oxygen sensor 2 (rear) harness protector color.</p>	
<p>HO2S2 (rear) (bank 1): White                  HO2S2 (rear) (bank 2): Red</p>	
SEF154Z	
<p><b>CAUTION:</b>                  Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.</p>	
▶	Replace malfunctioning heated oxygen sensor 2 (rear).

## DTC P0141 (BANK 1), P0161 (BANK 2) HO2S2 HEATER (REAR)

Diagnostic Procedure (Cont'd)

6	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	INSPECTION END

# DTC P0171 (BANK 1), P0174 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

On Board Diagnosis Logic

## On Board Diagnosis Logic

NFEC0739

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensor 1 (front). The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and light up the MI (2 trip detection logic).


Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensor 1 (front)	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Injectors

Malfunction is detected when fuel injection system does not operate properly, the amount of mixture ratio compensation is too large. (The mixture ratio is too lean.)

## Possible Cause

NFEC0740

- Intake air leaks
- Heated oxygen sensor 1 (front)
- Injectors
- Exhaust gas leaks
- Incorrect fuel pressure
- Lack of fuel
- Mass air flow sensor



## DTC Confirmation Procedure

NFEC0741

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.


### WITH CONSULT-II

NFEC0741S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 10 seconds.
- 3) Turn ignition switch "ON" and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT-II.
- 6) Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-265.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
- 8) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-265. If engine does not start, check exhaust and intake air leak visually.

# DTC P0171 (BANK 1), P0174 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

DTC Confirmation Procedure (Cont'd)



## WITH GST

NFEC0741S02

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 10 seconds.
- 3) Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
- 4) Stop engine and reconnect mass air flow sensor harness connector.
- 5) Select "MODE 7" with GST. Make sure 1st trip DTC P0100 is detected.
- 6) Select "MODE 4" with GST and erase the 1st trip DTC P0100.
- 7) Start engine again and let it idle for at least 10 minutes.
- 8) Select "MODE 7" with GST. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-265.
- 9) If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
- 10) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-265. If engine does not start, check exhaust and intake air leak visually.

# DTC P0171 (BANK 1), P0174 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

Wiring Diagram

## Wiring Diagram



**BANK 1**

NFEC0742

NFEC0742S01

**EC-FUELRH-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC304D

# DTC P0171 (BANK 1), P0174 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (LEAN)




Wiring Diagram (Cont'd)

## BANK 2

NFEC0742S02

### EC-FUELLH-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)


MEC305D

# DTC P0171 (BANK 1), P0174 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0743

<b>1</b>	<b>CHECK EXHAUST AIR LEAK</b>		
<p>1. Start engine and run it at idle.                  2. Listen for an exhaust air leak before three way catalyst (Manifold).</p>			
			
SEF099P			
<b>OK or NG</b>			
OK	▶	GO TO 2.	
NG	▶	Repair or replace.	

<b>2</b>	<b>CHECK FOR INTAKE AIR LEAK</b>		
Listen for an intake air leak after the mass air flow sensor.			
<b>OK or NG</b>			
OK	▶	GO TO 3.	
NG	▶	Repair or replace.	

<b>3</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) CIRCUIT FOR OPEN AND SHORT</b>																
<p>1. Turn ignition switch "OFF".                  2. Disconnect corresponding heated oxygen sensor 1 (front) harness connector.                  3. Disconnect ECM harness connector.                  4. Check harness continuity between ECM terminal and HO2S1 (front) terminal as follows.                  Refer to Wiring Diagram.</p>																	
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0171</td> <td style="text-align: center;">63</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0174</td> <td style="text-align: center;">62</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>				DTC	Terminals		Bank	ECM	Sensor	P0171	63	1	1	P0174	62	1	2
DTC	Terminals		Bank														
	ECM	Sensor															
P0171	63	1	1														
P0174	62	1	2														
MTBL0500																	
<p style="color: blue;"><b>Continuity should exist.</b></p> <p>5. Check harness continuity between ECM terminal or HO2S1 (front) terminal and ground as follows.                  Refer to Wiring Diagram.</p>																	
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or Sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0172</td> <td style="text-align: center;">63 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0175</td> <td style="text-align: center;">62 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>				DTC	Terminals		Bank	ECM or Sensor	Ground	P0172	63 or 1	Ground	1	P0175	62 or 1	Ground	2
DTC	Terminals		Bank														
	ECM or Sensor	Ground															
P0172	63 or 1	Ground	1														
P0175	62 or 1	Ground	2														
MTBL0501																	
<p style="color: blue;"><b>Continuity should not exist.</b></p> <p>6. Also check harness for short to power.</p>																	
<b>OK or NG</b>																	
OK	▶	GO TO 4.															
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.															

# DTC P0171 (BANK 1), P0174 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK FUEL PRESSURE</b>	
<p>1. Release fuel pressure to zero. Refer to EC-36.                  2. Install fuel pressure gauge and check fuel pressure. Refer to EC-37.</p> <p style="margin-left: 20px;"><b>At idling:</b>                  When fuel pressure regulator valve vacuum hose is connected.  <b>235 kPa (2.35 bar, 2.4 kg/cm<sup>2</sup>, 34 psi)</b>                  When fuel pressure regulator valve vacuum hose is disconnected.  <b>294 kPa (2.94 bar, 3.0 kg/cm<sup>2</sup>, 43 psi)</b></p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

<b>5</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Fuel pump and circuit (Refer to EC-533.)</li> <li>● Fuel pressure regulator (Refer to EC-37.)</li> <li>● Fuel lines (Refer to MA-20, "Checking Fuel Lines".)</li> <li>● Fuel filter for clogging</li> </ul>		
		▶ Repair or replace.

<b>6</b>	<b>CHECK MASS AIR FLOW SENSOR</b>	
<p> <b>With CONSULT-II</b></p> <p>1. Install all removed parts.                  2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.  <b>2.0 - 6.0 g-m/sec: at idling</b>  <b>7.0 - 20.0 g-m/sec: at 2,500 rpm</b></p>		
<p> <b>With GST</b></p> <p>1. Install all removed parts.                  2. Check mass air flow sensor signal in MODE 1 with GST.  <b>2.0 - 6.0 g-m/sec: at idling</b>  <b>7.0 - 20.0 g-m/sec: at 2,500 rpm</b></p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 7.
NG	▶	Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-134.

# DTC P0171 (BANK 1), P0174 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

Diagnostic Procedure (Cont'd)

## 7 CHECK FUNCTION OF INJECTORS


- Ⓟ With CONSULT-II**
1. Start engine.
  2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step

SEF070Y

3. Make sure that each circuit produces a momentary engine speed drop.

- ⓧ Without CONSULT-II**
1. Start engine.
  2. Listen to each injector operating sound.



MEC703B


Clicking noise should be heard.

OK or NG

OK	▶	GO TO 8.
NG	▶	Perform trouble diagnosis for "INJECTORS", EC-523.

# DTC P0171 (BANK 1), P0174 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (LEAN)

Diagnostic Procedure (Cont'd)

8 CHECK INJECTOR	
<ol style="list-style-type: none"><li>1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.</li><li>2. Turn ignition switch "OFF".</li><li>3. Disconnect injector harness connectors on bank 2 (for DTC P0171), bank 1 (for DTC P0174).</li><li>4. Remove injector gallery assembly. Refer to EC-38. Keep fuel hose and all injectors connected to injector gallery. The injector harness connectors on bank 1 (for DTC P0171), bank 2 (for DTC P0174) should remain connected.</li><li>5. Disconnect all ignition coil harness connectors.</li><li>6. Prepare pans or saucers under each injector.</li><li>7. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.</li></ol>	
	
<b>Fuel should be sprayed evenly for each injector.</b>	
SEF595Q	
<b>OK or NG</b>	
OK	▶ GO TO 9.
NG	▶ Replace injectors from which fuel does not spray out. Always replace O-ring with new ones.

9 CHECK INTERMITTENT INCIDENT	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
	▶ <b>INSPECTION END</b>

# DTC P0172 (BANK 1), P0175 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (RICH)

On Board Diagnosis Logic

## On Board Diagnosis Logic

NFEC0744

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensor 1 (front). The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and light up the MI (2 trip detection logic).


Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensor 1 (front)	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Injectors

Malfunction is detected when fuel injection system does not operate properly, the amount of mixture ratio compensation is too large. (The mixture ratio is too rich.)

## Possible Cause

NFEC0745

- Heated oxygen sensor 1 (front)
- Injectors
- Exhaust gas leaks
- Incorrect fuel pressure
- Mass air flow sensor



## DTC Confirmation Procedure

NFEC0746

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.


### WITH CONSULT-II

NFEC0746S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 10 seconds.
- 3) Turn ignition switch "ON" and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT-II.
- 6) Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0172, P0175 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-273.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
- 8) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-273. If engine does not start, remove ignition plugs and check for fouling, etc.

# DTC P0172 (BANK 1), P0175 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (RICH)

DTC Confirmation Procedure (Cont'd)



## WITH GST

NFEC0746S02

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 10 seconds.
- 3) Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
- 4) Stop engine and reconnect mass air flow sensor harness connector.
- 5) Select "MODE 7" with GST. Make sure 1st trip DTC P0100 is detected.
- 6) Select "MODE 4" with GST and erase the 1st trip DTC P0100.
- 7) Start engine again and let it idle for at least 10 minutes.
- 8) Select "MODE 7" with GST. The 1st trip DTC P0172 or P0175 should be detected at this stage, if a malfunction exists. If so, go to "Diagnostic Procedure", EC-273.
- 9) If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
- 10) Crank engine while depressing accelerator pedal. If engine starts, go to "Diagnostic Procedure", EC-273. If engine does not start, check exhaust and intake air leak visually.

# DTC P0172 (BANK 1), P0175 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (RICH)

Wiring Diagram

## Wiring Diagram



**BANK 1**

NFEC0747

NFEC0747S01

**EC-FUELRH-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)



MEC304D

# DTC P0172 (BANK 1), P0175 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (RICH)




Wiring Diagram (Cont'd)

## BANK 2

NFEC0747S02

### EC-FUELLH-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)


MEC305D

# DTC P0172 (BANK 1), P0175 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (RICH)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0748

<b>1</b>	<b>CHECK EXHAUST AIR LEAK</b>		
<p>1. Start engine and run it at idle.                  2. Listen for an exhaust air leak before three way catalyst (Manifold).</p>			
			
SEF099P			
<b>OK or NG</b>			
OK	▶	GO TO 2.	
NG	▶	Repair or replace.	

<b>2</b>	<b>CHECK FOR INTAKE AIR LEAK</b>		
Listen for an intake air leak after the mass air flow sensor.			
<b>OK or NG</b>			
OK	▶	GO TO 3.	
NG	▶	Repair or replace.	

<b>3</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) CIRCUIT FOR OPEN AND SHORT</b>																
<p>1. Turn ignition switch "OFF".                  2. Disconnect corresponding heated oxygen sensor 1 (front) harness connector.                  3. Disconnect ECM harness connector.                  4. Check harness continuity between ECM terminal and HO2S1 (front) terminal as follows.                  Refer to Wiring Diagram.</p>																	
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>P0172</td> <td style="text-align: center;">63</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0175</td> <td style="text-align: center;">62</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>				DTC	Terminals		Bank	ECM	Sensor	P0172	63	1	1	P0175	62	1	2
DTC	Terminals		Bank														
	ECM	Sensor															
P0172	63	1	1														
P0175	62	1	2														
MTBL0502																	
<p style="color: blue;"><b>Continuity should exist.</b></p> <p>5. Check harness continuity between ECM terminal or HO2S1 (front) terminal and ground as follows.                  Refer to Wiring Diagram.</p>																	
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">DTC</th> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or Sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td>P0172</td> <td style="text-align: center;">63 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">1</td> </tr> <tr> <td>P0175</td> <td style="text-align: center;">62 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>				DTC	Terminals		Bank	ECM or Sensor	Ground	P0172	63 or 1	Ground	1	P0175	62 or 1	Ground	2
DTC	Terminals		Bank														
	ECM or Sensor	Ground															
P0172	63 or 1	Ground	1														
P0175	62 or 1	Ground	2														
MTBL0503																	
<p style="color: blue;"><b>Continuity should not exist.</b></p> <p>6. Also check harness for short to power.</p>																	
<b>OK or NG</b>																	
OK	▶	GO TO 4.															
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.															

## DTC P0172 (BANK 1), P0175 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (RICH)

Diagnostic Procedure (Cont'd)


<b>4</b>	<b>CHECK FUEL PRESSURE</b>	
<p>1. Release fuel pressure to zero. Refer to EC-36.                  2. Install fuel pressure gauge and check fuel pressure. Refer to EC-37.</p> <p style="margin-left: 20px;"><b>At idling:</b>                  When fuel pressure regulator valve vacuum hose is connected.                  235 kPa (2.34 bar, 2.4 kg/cm<sup>2</sup>, 34 psi)                  When fuel pressure regulator valve vacuum hose is disconnected.                  294 kPa (2.94 bar, 3.0 kg/cm<sup>2</sup>, 43 psi)</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

<b>5</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Fuel pump and circuit (Refer to EC-533.)</li> <li>● Fuel pressure regulator (Refer to EC-37.)</li> </ul>		
		▶ Repair or replace.

<b>6</b>	<b>CHECK MASS AIR FLOW SENSOR</b>	
<p> <b>With CONSULT-II</b></p> <p>1. Install all removed parts.                  2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.                  2.0 - 6.0 g-m/sec: at idling                  7.0 - 20.0 g-m/sec: at 2,500 rpm</p>		
<p> <b>With GST</b></p> <p>1. Install all removed parts.                  2. Check mass air flow sensor signal in MODE 1 with GST.                  2.0 - 6.0 g-m/sec: at idling                  7.0 - 20.0 g-m/sec: at 2,500 rpm</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 7.
NG	▶	Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-134.

# DTC P0172 (BANK 1), P0175 (BANK 2) FUEL INJECTION SYSTEM FUNCTION (RICH)

Diagnostic Procedure (Cont'd)

<b>7</b>	<b>CHECK FUNCTION OF INJECTORS</b>																				
<p><b>Ⓟ With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>Start engine.</li> <li>Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.</li> </ol>																					
<table border="1" style="margin: auto;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>POWER BALANCE</td><td></td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>MAS AIF SE-B1</td><td>XXX V</td></tr> <tr><td>IACV-AAC/V</td><td>XXX step</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table>		ACTIVE TEST		POWER BALANCE		MONITOR		ENG SPEED	XXX rpm	MAS AIF SE-B1	XXX V	IACV-AAC/V	XXX step								
ACTIVE TEST																					
POWER BALANCE																					
MONITOR																					
ENG SPEED	XXX rpm																				
MAS AIF SE-B1	XXX V																				
IACV-AAC/V	XXX step																				
<p>3. Make sure that each circuit produces a momentary engine speed drop.</p>																					
<p><b>ⓧ Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>Start engine.</li> <li>Listen to each injector operating sound.</li> </ol>																					
																					
<p><b>Clicking noise should be heard.</b></p>																					
<p><b>OK or NG</b></p>																					
OK	▶ GO TO 8.																				
NG	▶ Perform trouble diagnosis for "INJECTORS", EC-523.																				

SEF070Y



MEC703B

<b>8</b>	<b>CHECK INJECTOR</b>
<ol style="list-style-type: none"> <li>Remove injector assembly. Refer to EC-38. Keep fuel hose and all injectors connected to injector gallery.</li> <li>Confirm that the engine is cooled down and there are no fire hazards near the vehicle.</li> <li>Disconnect injector harness connectors bank 2 (for DTC P0172), bank 1 (for P0175). The injector harness connectors on bank 1 (for P0172), bank 2 (for P0175) should remain connected.</li> <li>Disconnect all ignition coil harness connectors.</li> <li>Prepare pans or saucers under each injectors.</li> <li>Crank engine for about 3 seconds. Make sure fuel does not drip from injector.</li> </ol>	
<p><b>OK or NG</b></p>	
OK (Does not drip.)	▶ GO TO 9.
NG (Drips.)	▶ Replace the injectors from which fuel is dripping. Always replace O-ring with new one.

<b>9</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# DTC P0180 FUEL TANK TEMPERATURE SENSOR

## Component Description



## Component Description

NFEC0749

The fuel tank temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

### <Reference data>

Fuel temperature °C (°F)	Voltage* V	Resistance kΩ
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

\*: These data are reference values and are measured between ECM terminal 92 (Fuel tank temperature sensor) and ground.

### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**

## On Board Diagnosis Logic

NFEC0750

Malfunction is detected when an excessively high or low voltage is sent to ECM, rationally incorrect voltage is sent to ECM, compared with the voltage signals from engine coolant temperature sensor and intake air temperature sensor.

## Possible Cause

NFEC0751

- Harness or connectors (The sensor circuit is open or shorted.)
- Fuel tank temperature sensor

# DTC P0180 FUEL TANK TEMPERATURE SENSOR

DTC Confirmation Procedure

## DTC Confirmation Procedure

NFEC0752

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

3

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

### WITH CONSULT-II

NFEC0752S01

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 10 seconds.  
If the result is NG, go to "Diagnostic Procedure", EC-279.  
If the result is OK, go to following step.
- 4) Check "COOLAN TEMP/S" value.  
If "COOLAN TEMP/S" is less than 60°C (140°F), the result will be OK.  
If "COOLAN TEMP/S" is above 60°C (140°F), go to the following step.
- 5) Cool engine down until "COOLAN TEMP/S" is less than 60°C (140°F).
- 6) Wait at least 10 seconds.
- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-279.

### WITH GST

NFEC0752S02

Follow the procedure "With CONSULT-II" above.



# DTC P0180 FUEL TANK TEMPERATURE SENSOR

Wiring Diagram

## Wiring Diagram

NFEC0753

### EC-FTTS-01





MEC045D

# DTC P0180 FUEL TANK TEMPERATURE SENSOR

Diagnostic Procedure

## Diagnostic Procedure

NFEC0754


<b>1</b>	<b>CHECK FUEL TANK TEMPERATURE SENSOR POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect fuel level sensor unit and fuel pump harness connector.</p> <div style="text-align: center;"> <p><b>View with rear seat removed</b></p>  <p>Fuel level sensor unit and fuel pump harness connector</p> </div> <p style="text-align: right;">SEF263X</p> <p>3. Turn ignition switch "ON".                  4. Check voltage between fuel level sensor unit and fuel pump terminal 4 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p><b>Voltage: Approximately 5V</b></p> </div> <p style="text-align: right;">SEF586X</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 3.
NG	▶	GO TO 2.

<b>2</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors B3, M6 or B2, M2</li> <li>● Harness connectors M81, F49</li> <li>● Harness for open or short between ECM and fuel level sensor unit and fuel pump</li> </ul> <p style="text-align: right;">▶ Repair harness or connector.</p>		

<b>3</b>	<b>CHECK FUEL TANK TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Check harness continuity between fuel level sensor unit and fuel pump terminal 5 and body ground. Refer to Wiring Diagram.  <span style="color: blue;"><b>Continuity should exist.</b></span>                  3. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to power in harness or connectors.

## DTC P0180 FUEL TANK TEMPERATURE SENSOR

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK FUEL TANK TEMPERATURE SENSOR</b>	
<p>1. Remove fuel level sensor unit.                  2. Check resistance between fuel level sensor unit and fuel pump terminals 4 and 5 by heating with hot water or heat gun as shown in the figure.</p>		
		
SEF587X		
<b>OK or NG</b>		
OK	▶	GO TO 5.
NG	▶	Replace fuel level sensor unit.

<b>5</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

# DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

On Board Diagnosis Logic

## On Board Diagnosis Logic

NFEC0755

When a misfire occurs, engine speed will fluctuate (vary). If the engine speed fluctuates enough to cause the CKP sensor (POS) signal to vary, ECM can determine that a misfire is occurring.

Sensor	Input Signal to ECM	ECM function
Crankshaft position sensor (POS)	Engine speed	On board diagnosis of misfire

The misfire detection logic consists of the following two conditions.

### 1. One Trip Detection Logic (Three Way Catalyst Damage)

On the first trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MI will blink.

When a misfire condition occurs, the ECM monitors the CKP sensor (POS) signal every 200 engine revolutions for a change.

When the misfire condition decreases to a level that will not damage the TWC, the MI will turn off.

If another misfire condition occurs that can damage the TWC on a second trip, the MI will blink.

When the misfire condition decreases to a level that will not damage the TWC, the MI will remain on.

If another misfire condition occurs that can damage the TWC, the MI will begin to blink again.

### 2. Two Trip Detection Logic (Exhaust quality deterioration)

For misfire conditions that will not cause damage to the TWC (but will affect vehicle emissions), the MI will only light when the misfire is detected on a second trip. During this condition, the ECM monitors the CKP sensor (POS) signal every 1,000 engine revolutions.

A misfire malfunction can be detected on any one cylinder or on-multiple cylinders.

Malfunction is detected when multiple cylinders misfire, No. 1 cylinder misfires, No. 2 cylinder misfires, No. 3 cylinder misfires, No. 4 cylinder misfires, No. 5 cylinder misfires and No. 6 cylinder misfires.

## Possible Cause

NFEC0756

- Improper spark plug
- Insufficient compression
- Incorrect fuel pressure
- The injector circuit is open or shorted
- Injectors
- Intake air leak
- The ignition secondary circuit is open or shorted
- Lack of fuel
- Drive plate or flywheel
- Heated oxygen sensor 1 (front)

# DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

DTC Confirmation Procedure

<b>4</b>	<b>DATA MONITOR</b>	
	<b>MONITOR</b>	<b>NO DTC</b>
	ENG SPEED	XXX rpm
	COOLANTEMP/S	XXX °C
	VHCL SPEED SE	XXX km/h
	P/N POSI SW	OFF
	B/FUEL SCHDL	XXX msec

SEF213Y

## DTC Confirmation Procedure

NFEC0757

### CAUTION:

**Always drive vehicle at a safe speed.**

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### WITH CONSULT-II

NFEC0757S01

- 1) Turn ignition switch "ON", and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Turn ignition switch "OFF" and wait at least 10 seconds.
- 4) Start engine again and drive at 1,500 to 3,000 rpm for at least 3 minutes.

**Hold the accelerator pedal as steady as possible.**

### NOTE:

**Refer to the freeze frame data for the test driving conditions.**

- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-282.

### WITH GST

NFEC0757S02

Follow the procedure "With CONSULT-II" above.

## Diagnostic Procedure


NFEC0758


<b>1</b>	<b>CHECK FOR INTAKE AIR LEAK</b>	
<ol style="list-style-type: none"> <li>1. Start engine and run it at idle speed.</li> <li>2. Listen for the sound of the intake air leak.</li> </ol>		
<b>OK or NG</b>		
OK	▶	GO TO 2.
NG	▶	Discover air leak location and repair.

<b>2</b>	<b>CHECK FOR EXHAUST SYSTEM CLOGGING</b>	
<ol style="list-style-type: none"> <li>1. Stop engine and visually check exhaust tube, three way catalyst (Manifold) and muffler for dents.</li> </ol>		
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	Repair or replace it.

# DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE


Diagnostic Procedure (Cont'd)


<b>3</b>	<b>PERFORM POWER BALANCE TEST</b>																
<p><b>Ⓟ With CONSULT-II</b>                  1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.</p>																	
<table border="1" style="margin: auto;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><th colspan="2">POWER BALANCE</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>MAS A/F SE-B1</td><td>XXX V</td></tr> <tr><td>IACV-AAC/V</td><td>XXX step</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table>		ACTIVE TEST		POWER BALANCE		MONITOR		ENG SPEED	XXX rpm	MAS A/F SE-B1	XXX V	IACV-AAC/V	XXX step				
ACTIVE TEST																	
POWER BALANCE																	
MONITOR																	
ENG SPEED	XXX rpm																
MAS A/F SE-B1	XXX V																
IACV-AAC/V	XXX step																
SEF190Y																	
2. Is there any cylinder which does not produce a momentary engine speed drop?																	
<p><b>ⓧ Without CONSULT-II</b>                  When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?</p>																	
																	
SEF281XA																	
<b>Yes or No</b>																	
Yes	▶ GO TO 4.																
No	▶ GO TO 7.																

<b>4</b>	<b>CHECK INJECTOR</b>
Does each injector make an operating sound at idle?	
	
MEC703B	
<b>Yes or No</b>	
Yes	▶ GO TO 5.
No	▶ Check injector(s) and circuit(s). Refer to EC-523.

# DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

Diagnostic Procedure (Cont'd)

<b>5</b>	<b>CHECK IGNITION SPARK</b>	
<p>1. Disconnect ignition wire from spark plug.                  2. Connect a known good spark plug to the ignition wire.                  3. Place end of spark plug against a suitable ground and crank engine.                  4. Check for spark.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF575Q</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 6.
NG	▶	Check ignition coil, power transistor and their circuits. Refer to "IGNITION SIGNAL", EC-495.

<b>6</b>	<b>CHECK SPARK PLUGS</b>	
<p>Remove the spark plugs and check for fouling, etc.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF156I</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 7.
NG	▶	Repair or replace spark plug(s) with standard type one(s). For spark plug type, refer to MA-15, "ENGINE MAINTENANCE".

<b>7</b>	<b>CHECK COMPRESSION PRESSURE</b>	
<p>Check compression pressure. Refer to EM-11, "Measurement of Compression Pressure".</p> <p><b>Standard:</b>                  1,275 kPa (12.75 bar, 13.0 kg/cm<sup>2</sup>, 185 psi)/300 rpm</p> <p><b>Minimum:</b>                  981 kPa (9.81 bar, 10.0 kg/cm<sup>2</sup>, 142 psi)/300 rpm</p> <p><b>Difference between each cylinder:</b>                  98 kPa (0.98 bar, 1.0 kg/cm<sup>2</sup>, 14 psi)/300 rpm</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 8.
NG	▶	Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

# DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

Diagnostic Procedure (Cont'd)

<b>8</b>	<b>CHECK FUEL PRESSURE</b>	
<p>1. Install all removed parts.</p> <p>2. Release fuel pressure to zero. Refer to EC-36.</p> <p>3. Install fuel pressure gauge and check fuel pressure. Refer to EC-37.</p> <p style="margin-left: 20px;"><b>At idle:</b> <b>Approx. 235 kPa (2.35 bar, 2.4 kg/cm<sup>2</sup>, 34 psi)</b></p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 10.
NG	▶	GO TO 9.

<b>9</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Fuel pump and circuit (Refer to EC-533.)</li> <li>● Fuel pressure regulator (Refer to EC-37.)</li> <li>● Fuel lines (Refer to MA-20, "Checking Fuel Lines".)</li> <li>● Fuel filter for clogging</li> </ul>		
		▶ Repair or replace.

<b>10</b>	<b>CHECK IGNITION TIMING</b>									
<p>Check the following items. Refer to "Basic Inspection", EC-90.</p> <table border="1" style="width: 100%; margin-left: 20px; border-collapse: collapse;"> <thead> <tr> <th style="width: 40%;">Items</th> <th style="width: 60%;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL0623</p> <p style="text-align: center;"><b>OK or NG</b></p>			Items	Specifications	Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)	Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF	Target idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)
Items	Specifications									
Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)									
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF									
Target idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)									
OK (With CONSULT-II)	▶	GO TO 11.								
OK (Without CONSULT-II)	▶	GO TO 12.								
NG	▶	Follow the "Basic Inspection".								

# DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

Diagnostic Procedure (Cont'd)

## 11 CHECK HEATED OXYGEN SENSOR 1 (FRONT) (B1)/(B2)

**With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
3. Hold engine speed at 2,000 rpm under no load during the following steps.
4. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

5. Check the following.
  - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown left:

Bank 1  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R


Bank 2  
 cycle           | 1 | 2 | 3 | 4 | 5 |  
 HO2S1 MNTR (B2) R-L-R-L-R-L-R-L-R-L-R

R means HO2S1 MNTR (B1)/(B2) indicates RICH  
 L means HO2S1 MNTR (B1)/(B2) indicates LEAN

SEF647YA

- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.30V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Trigger	ENG SPEED	HO2S1 (B1)
	rpm	V
XXX	XXX	XXX



- Maximum voltage should be over 0.6V at least one time.
- Minimum voltage should be below 0.30V at least one time.

SEF648Y

**CAUTION:**


Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.


OK or NG

OK	▶	GO TO 14.
NG	▶	GO TO 13.

# DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

Diagnostic Procedure (Cont'd)

<b>12</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) (B1)/(B2)</b>	
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Stop engine and set ECM in diagnostic test mode-II [Heated oxygen sensor 1 monitor (front)].</li> <li>3. Set voltmeter probes between ECM terminal 63 (HO2S1 bank 1 signal) or 62 (HO2S1 bank 2 signal) and engine ground.</li> <li>4. Check the following with engine speed held at 2,000 rpm constant under no load.</li> </ol>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 45%;">  <p>63: Bank 1 62: Bank 2</p> </div> <div style="width: 50%;"> <ul style="list-style-type: none"> <li>● The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.</li> <li>● The maximum voltage is over 0.6V at least one time.</li> <li>● The minimum voltage is below 0.3V at least one time.</li> <li>● The voltage never exceeds 1.0V.</li> </ul> <p>1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V</p> </div> </div>		
SEF967XA		
<b>CAUTION:</b>		
<p><b>Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</b></p>		
<b>OK or NG</b>		
OK	▶	GO TO 14.
NG	▶	GO TO 13.

<b>13</b>	<b>REPLACE HEATED OXYGEN SENSOR 1 (FRONT)</b>	
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 1 (front) harness protector color.</li> </ol>		
		
<p>HO2S1 (front) (bank 1): Black HO2S1 (front) (bank 2): Blue</p>		
SEF505YA		
▶		Replace malfunctioning heated oxygen sensor 1 (front).

## DTC P0300 - P0306 NO. 6 - 1 CYLINDER MISFIRE, MULTIPLE CYLINDER MISFIRE

Diagnostic Procedure (Cont'd)

<b>14</b>	<b>CHECK MASS AIR FLOW SENSOR</b>	
<p> <b>With CONSULT-II</b>            Check mass air flow sensor signal in "DATA MONITOR" mode with CONSULT-II.  <b>2.0 - 6.0 g-m/sec: at idling</b>  <b>7.0 - 20.0 g-m/sec: at 2,500 rpm</b></p>		
<p> <b>With GST</b>            Check mass air flow sensor signal in MODE 1 with GST.  <b>2.0 - 6.0 g-m/sec: at idling</b>  <b>7.0 - 20.0 g-m/sec: at 2,500 rpm</b></p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 15.
NG	▶	Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to EC-134.

<b>15</b>	<b>CHECK SYMPTOM MATRIX CHART</b>	
<p>Check items on the rough idle symptom in "Symptom Matrix Chart", EC-105.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 16.
NG	▶	Repair or replace.


<b>16</b>	<b>ERASE THE 1ST TRIP DTC</b>	
<p>Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to EC-56.            Some tests may cause a 1st trip DTC to be set.</p>		
	▶	GO TO 17.

<b>17</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.</p>		
	▶	<b>INSPECTION END</b>

## DTC P0325 KNOCK SENSOR (KS)

Component Description



### Component Description

NFEC0185

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM. **Freeze frame data will not be stored in the ECM for the knock sensor. The MI will not light for knock sensor malfunction. The knock sensor has one trip detection logic.**

### On Board Diagnosis Logic

NFEC0187

Malfunction is detected when an excessively low or high voltage from the knock sensor is sent to ECM.

### Possible Cause

NFEC0491

- Harness or connectors  
(The knock sensor circuit is open or shorted.)
- Knock sensor

2

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

### DTC Confirmation Procedure

NFEC0188

#### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

#### TESTING CONDITION:

**Before performing the following procedure, confirm that battery voltage is more than 10V at idle.**

#### WITH CONSULT-II

NFEC0188S01

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II
- 2) Start engine and run it for at least 5 seconds at idle speed.
- 3) If DTC is detected, go to "Diagnostic Procedure", EC-292.

#### WITH GST

NFEC0188S04

Follow the procedure "WITH CONSULT-II" above.

#### NO TOOLS

NFEC0188S03

- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

## **DTC P0325 KNOCK SENSOR (KS)**

*DTC Confirmation Procedure (Cont'd)*

---

- 4) If DTC is detected, go to "Diagnostic Procedure", EC-292.



# DTC P0325 KNOCK SENSOR (KS)

Wiring Diagram

## Wiring Diagram

=NFEC0189

EC-KS-01



MEC736C

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
93	W	KNOCK SENSOR	ENGINE RUNNING AT IDLE SPEED	APPROX. 2.5V


SEF663XB

## DTC P0325 KNOCK SENSOR (KS)

Diagnostic Procedure

### Diagnostic Procedure

NFEC0190


1	CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-I
<p>1. Turn ignition switch "OFF".                      2. Disconnect ECM harness connector.                      3. Check resistance between ECM terminal 93 and engine ground.</p> <p><b>NOTE:</b>                      It is necessary to use an ohmmeter which can measure more than 10 MΩ.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="text-align: left;"> <p><b>Resistance:</b>                      Approximately 500 - 620 kΩ                      [at 25°C (77°F)]</p> </div> </div>	
SEF321X	
<p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 5.
NG	▶ GO TO 2.


2	CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT-II
<p>1. Disconnect knock sensor harness connector.                      2. Check harness continuity between ECM terminal 93 and knock sensor terminal 1. Refer to Wiring Diagram.  <span style="color: blue;">Continuity should exist.</span>                      3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connector F8, F131</li> <li>● Harness for open or short between ECM and knock sensor</li> </ul>	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

## DTC P0325 KNOCK SENSOR (KS)

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK KNOCK SENSOR</b>		
<p>Check resistance between knock sensor terminal 1 and ground.</p> <p><b>NOTE:</b> It is necessary to use an ohmmeter which can measure more than 10 MΩ.</p>			
			
SEF322X			
<p><b>CAUTION:</b> Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.</p> <p style="text-align: center;"><b>OK or NG</b></p>			
OK		▶	GO TO 8.
NG		▶	Replace knock sensor.

<b>5</b>	<b>RETIGHTEN GROUND SCREWS</b>		
<p>Loose and retighten engine ground screws.</p>			
			
SEF255X			
		▶	GO TO 6.

<b>6</b>	<b>CHECK KNOCK SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT</b>		
<ol style="list-style-type: none"> <li>1. Disconnect harness connectors F8, F131.</li> <li>2. Check harness continuity between harness connector F8 terminal 2 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b></li> <li>3. Also check harness for short to power.</li> </ol>			
<b>OK or NG</b>			
OK		▶	GO TO 8.
NG		▶	GO TO 7.

<b>7</b>	<b>DETECT MALFUNCTIONING PART</b>		
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F8, F131</li> <li>● Joint connectors-18</li> <li>● Harness for open or short between harness connector F8 and engine ground</li> </ul>			
		▶	Repair open circuit or short to power in harness or connectors.


## DTC P0325 KNOCK SENSOR (KS)

Diagnostic Procedure (Cont'd)

<b>8</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Component Description



## Component Description

NFEC0762

The crankshaft position sensor (POS) is located on the oil pan facing the gear teeth (cogs) of the signal plate (flywheel). It detects the crankshaft position signal (1° signal).

The sensor consists of a permanent magnet, core and coil.

When engine is running, the gap between the sensor and the gear teeth (cogs) will periodically change. Permeability near the sensor also changes.

Due to the permeability change, the magnetic flux near the core is changed. Therefore, the voltage signal generated in the coil is changed.

The ECM receives the voltage signal and detects the crankshaft position signal (1° signal).

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0763

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CKPS-RPM (POS)	<ul style="list-style-type: none"><li>● Tachometer: Connect</li><li>● Run engine and compare tachometer indication with the CONSULT-II value.</li></ul>	Almost the same speed as the CONSULT-II value.

## On Board Diagnosis Logic

NFEC0764

Malfunction is detected when 1° signal is not entered to ECM for the first few seconds during engine cranking, or 1° signal is not entered to ECM during engine running.

## Possible Cause

NFEC0765

- Harness or connectors  
[The crankshaft position sensor (POS) circuit is open or shorted.]
- Crankshaft position sensor (POS)
- Starter motor (Refer to EL section.)
- Starting system circuit (Refer to EL section.)
- Dead (Weak) battery

# DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (POS)

## DTC Confirmation Procedure

2	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

## DTC Confirmation Procedure

NFEC0766

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V.

### Ⓜ WITH CONSULT-II

NFEC0766S01

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- 2) Crank engine for at least two seconds.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-298.

### Ⓜ WITH GST

NFEC0766S02

Follow the procedure "With CONSULT-II" above.

# DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Wiring Diagram



## Wiring Diagram

NFEC0767

### EC-POS-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC

◁ L ▷ : LHD MODELS  
 ◁ R ▷ : RHD MODELS  
 \*1 SB : ◁ L ▷  
 R/G : ◁ R ▷



MEC850C



# DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Wiring Diagram (Cont'd)

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:


DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
85	W	CRANKSHAFT POSITION SENSOR (POS)	ENGINE RUNNING AT IDLE SPEED UNDER WARM-UP CONDITION	APPROX. 2.4V 
			ENGINE RUNNING AT 2,000 RPM	APPROX. 2.3V 

SEF856Y



## Diagnostic Procedure

NFEC0768

<b>1</b>	<b>RETIGHTEN GROUND SCREWS</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Loosen and retighten engine ground screws.</li> </ol>	
	
SEF255X	
▶	GO TO 2.

## DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Diagnostic Procedure (Cont'd)

<b>2</b>	<b>CHECK CKPS (POS) POWER SUPPLY CIRCUIT</b>	
1. Disconnect harness connectors F25, F171.		
		
SEF511WB		
2. Check voltage between harness connector F25 terminal 4 and ground with CONSULT-II or tester.		
		
SEF323X		
3. Also check harness for short to ground and short to power.		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	GO TO 3.


<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>	
Check the following.		
<ul style="list-style-type: none"> <li>● Harness connectors F25, F171</li> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between ECM and crankshaft position sensor (POS)</li> <li>● Harness for open or short between ECM relay and crankshaft position sensor (POS)</li> </ul>		
▶		Repair open circuit or short to ground or short to power in harness or connectors.


<b>4</b>	<b>CHECK CKPS (POS) GROUND CIRCUIT FOR OPEN AND SHORT</b>	
1. Check harness continuity between harness connector F25 terminal 2 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b>		
2. Also check harness for short to power.		
<b>OK or NG</b>		
OK	▶	GO TO 5.
NG	▶	Repair open circuit or short to power in harness or connectors.

## DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Diagnostic Procedure (Cont'd)


<b>5</b>	<b>CHECK CKPS (POS) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
	<ol style="list-style-type: none"> <li>1. Disconnect ECM harness connector.</li> <li>2. Check harness continuity between ECM terminal 85 and harness connector F25 terminal 1. Refer to Wiring Diagram. <b>Continuity should exist.</b></li> <li>3. Also check harness for short to ground and short to power.</li> </ol> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶	GO TO 6.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.


<b>6</b>	<b>CHECK CKPS (POS) SUB-HARNESS CIRCUIT FOR OPEN AND SHORT</b>									
	<ol style="list-style-type: none"> <li>1. Disconnect CKPS (POS) harness connector.</li> </ol> <div style="text-align: center;">  <p style="margin-left: 100px;">Crankshaft position sensor (POS) harness connector</p> <p style="margin-left: 150px;">Oil pan</p> </div> <p style="text-align: right;">SEF367Q</p> <ol style="list-style-type: none"> <li>2. Check harness continuity between CKPS (POS) terminals and harness connector F171 terminals as follows.</li> </ol> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="border: none;">CKPS (POS) terminal</th> <th style="border: none;">Harness connector F171 terminal</th> </tr> </thead> <tbody> <tr> <td style="border: none;">1</td> <td style="border: none;">2</td> </tr> <tr> <td style="border: none;">2</td> <td style="border: none;">1</td> </tr> <tr> <td style="border: none;">3</td> <td style="border: none;">4</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0352</p> <p><b>Continuity should exist.</b></p> <ol style="list-style-type: none"> <li>3. Also check harness for short to ground and short to power.</li> </ol> <p style="text-align: center;"><b>OK or NG</b></p>		CKPS (POS) terminal	Harness connector F171 terminal	1	2	2	1	3	4
CKPS (POS) terminal	Harness connector F171 terminal									
1	2									
2	1									
3	4									
OK	▶	GO TO 7.								
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.								

<b>7</b>	<b>CHECK CKPS (POS) INSTALLATION</b>	
	<p>Check that CKPS (POS) and HO2S1 bank 2 harness clamp are installed correctly as shown below.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Crankshaft position sensor (POS)</p> <p style="margin-left: 100px;">Heated oxygen sensor 1 (front) (bank 2) harness clamp</p> <p style="margin-left: 100px;"><b>8.4 - 10.8 N·m</b> <b>(0.86 - 1.10 kg-m,</b> <b>74.6 - 95.5 in-lb)</b></p> </div> <p style="text-align: right;">SEM222FE</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶	GO TO 8.
NG	▶	Install CKPS (POS) correctly.

## DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Diagnostic Procedure (Cont'd)

<b>8</b>	<b>CHECK CRANKSHAFT POSITION SENSOR (POS)-I</b>	
<ol style="list-style-type: none"> <li>1. Disconnect crankshaft position sensor (POS) harness connector.</li> <li>2. Loosen the fixing bolt of the sensor.</li> <li>3. Remove the sensor.</li> <li>4. Visually check the sensor for chipping.</li> </ol>		
		
SEF587P		
<b>OK or NG</b>		
OK	▶	GO TO 9.
NG	▶	Replace crankshaft position sensor (POS).

<b>9</b>	<b>CHECK CRANKSHAFT POSITION SENSOR (POS)-II</b>									
<ol style="list-style-type: none"> <li>1. Reconnect disconnected harness connectors.</li> <li>2. Turn ignition switch "ON".</li> <li>3. Check voltage between ECM terminal 85 and ground by briefly touching the sensor core with a flat-bladed screwdrivers.</li> </ol>										
										
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th>ECM terminal</th> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">85</td> <td style="text-align: center;">Contacted</td> <td style="text-align: center;">Approximately 5V</td> </tr> <tr> <td style="text-align: center;">Pulled away</td> <td style="text-align: center;">Approximately 0V</td> </tr> </tbody> </table>			ECM terminal	Condition	Voltage	85	Contacted	Approximately 5V	Pulled away	Approximately 0V
ECM terminal	Condition	Voltage								
85	Contacted	Approximately 5V								
	Pulled away	Approximately 0V								
<p style="text-align: center;"><b>There should be a steady 5V as the flat-bladed screwdriver is drawn away slowly.</b></p>										
SEF324X										
<b>OK or NG</b>										
OK	▶	GO TO 10.								
NG	▶	Replace crankshaft position sensor (POS).								

<b>10</b>	<b>CHECK CKPS (POS) SHIELD CIRCUIT FOR OPEN AND SHORT</b>	
<ol style="list-style-type: none"> <li>1. Disconnect harness connectors F25, F171.</li> <li>2. Check harness continuity between harness connector F25 terminal 3 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b></li> <li>3. Also check harness for short to power.</li> </ol>		
<b>OK or NG</b>		
OK	▶	GO TO 12.
NG	▶	GO TO 11.


## **DTC P0335 CRANKSHAFT POSITION SENSOR (CKPS) (POS)**

*Diagnostic Procedure (Cont'd)*

<b>11</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"><li>● Harness connectors F25, F171</li><li>● Joint connector-18</li><li>● Harness for open or short between harness connector F25 and engine ground</li></ul>	
▶	Repair open circuit or short to power in harness or connectors.
<b>12</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

## DTC P0340 CAMSHAFT POSITION SENSOR (CMPS) (PHASE)

Component Description



### Component Description

NFEC0197

The camshaft position sensor (PHASE) is located on the engine front cover facing the camshaft sprocket. It detects the cylinder No. signal.

The sensor consists of a permanent magnet, core and coil.

When engine is running, the gap between the sensor and the camshaft sprocket will periodically change. Permeability near the sensor also changes.

Due to the permeability change, the magnetic flux near the core is changed. Therefore, the voltage signal generated in the coil is changed.

The ECM receives the voltage signal and detects the cylinder No. signal.

### On Board Diagnosis Logic

NFEC0199

Malfunction is detected when

**(Malfunction A)** the cylinder No. signal is not sent to ECM for the first few seconds during engine cranking,

**(Malfunction B)** the cylinder No. signal is not sent to ECM during engine running,

**(Malfunction C)** the cylinder No. signal is not in the normal pattern during engine running.

### Possible Cause

NFEC0494

- Harness or connectors  
[The camshaft position sensor (PHASE) circuit is open or shorted.]
- Camshaft position sensor (PHASE)
- Starter motor (Refer to SC section.)
- Starting system circuit (Refer to SC section.)
- Dead (Weak) battery

### DTC Confirmation Procedure

NFEC0200

NOTE:

- Perform "PROCEDURE FOR MALFUNCTION A" first. If 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B AND C".
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

## DTC P0340 CAMSHAFT POSITION SENSOR (CMPS) (PHASE)

DTC Confirmation Procedure (Cont'd)

<b>2</b>	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm
	VHCL SPEED SE	XXX km/h
	P/N POSI SW	OFF

SEF065Y

### PROCEDURE FOR MALFUNCTION A

 **With CONSULT-II**

NFEC0200S01

NFEC0200S0101

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Crank engine for at least 2 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-306.

 **With GST**

NFEC0200S0103

Follow the procedure "With CONSULT-II" above.

 **No Tools**

NFEC0200S0102

- 1) Crank engine for at least 2 seconds.
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-306.

<b>3</b>	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

### PROCEDURE FOR MALFUNCTION B AND C

 **With CONSULT-II**

NFEC0200S02

NFEC0200S0201

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-306.

 **With GST**

NFEC0200S0203

Follow the procedure "With CONSULT-II" above.

 **No Tools**

NFEC0200S0202

- 1) Start engine and run it for at least 2 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-306.




# DTC P0340 CAMSHAFT POSITION SENSOR (CMPS) (PHASE)


Diagnostic Procedure

## Diagnostic Procedure

NFEC0202

<b>1</b>	<b>CHECK STARTING SYSTEM</b>	
Turn ignition switch to "START" position. <b>Does the engine turn over?</b> <b>Does the starter motor operate?</b>		
<b>Yes or No</b>		
Yes	▶	GO TO 2.
No	▶	Check starting system. (Refer to SC-12, "STARTING SYSTEM".)


<b>2</b>	<b>RETIGHTEN GROUND SCREWS</b>	
1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.		
 <p>The diagram shows a top-down view of the engine block. A label 'Engine ground' points to several screws on the top surface of the engine. Another label 'Oil filler cap' points to a circular cap on the side of the engine block.</p>		
SEF255X		
▶		GO TO 3.


<b>3</b>	<b>CHECK CMPS (PHASE) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector and CMPS (PHASE) harness connector.		
 <p>The diagram shows a close-up of the engine area. A label 'Oil filler cap' points to a cap on the engine. Another label 'Camshaft position sensor (PHASE) harness connector' points to a multi-pin electrical connector on the engine block.</p>		
SEF274P		
3. Check harness continuity between CMPS (PHASE) terminal 2 and ECM terminals 66, 76. Refer to Wiring Diagram. <b>Continuity should exist.</b>		
4. Also check harness for short to ground and short to power.		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

## DTC P0340 CAMSHAFT POSITION SENSOR (CMPS) (PHASE)

*Diagnostic Procedure (Cont'd)*

<b>4</b>	<b>CHECK CMPS (PHASE) GROUND CIRCUIT FOR OPEN AND SHORT</b>	
1. Check harness continuity between CMPS (PHASE) terminal 1 and engine ground. <b>Continuity should exist.</b> 2. Also check harness for short to power.		
<b>OK or NG</b>		
OK	▶	GO TO 5.
NG	▶	Repair open circuit or short to power in harness or connector.

<b>5</b>	<b>CHECK CAMSHAFT POSITION SENSOR (PHASE)-I</b>	
1. Loosen the fixing bolt of the camshaft position sensor (PHASE). 2. Remove the CMPS (PHASE). 3. Visually check the CMPS (PHASE) for chipping.		
		
SEF583P		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	Replace camshaft position sensor (PHASE).

<b>6</b>	<b>CHECK CAMSHAFT POSITION SENSOR (PHASE)-II</b>	
Check resistance between CMPS (PHASE) terminals 1 and 2 as shown below.		
		
<b>Resistance:</b> Approximately 1,440 - 1,760 $\Omega$ at 20°C (68°F) (HITACHI make) Approximately 2,090 - 2,550 $\Omega$ at 20°C (68°F) (MITSUBISHI make)		
SEF325X		
<b>OK or NG</b>		
OK	▶	GO TO 7.
NG	▶	Replace camshaft position sensor (PHASE).

## DTC P0340 CAMSHAFT POSITION SENSOR (CMPS) (PHASE)


Diagnostic Procedure (Cont'd)

<b>7</b>	<b>CHECK CMPS (PHASE) SHIELD CIRCUIT FOR OPEN AND SHORT</b>	
1. Turn ignition switch "OFF". 2. Disconnect joint connector-18. 3. Check the following. <ul style="list-style-type: none"><li>● Continuity between joint connector terminal 1 and ground</li><li>● Joint connector (Refer to EL-377, "HARNES LAYOUT".) <b>Continuity should exist.</b></li></ul>		
4. Also check harness for short to power. 5. Then reconnect joint connector-18.		
<b>OK or NG</b>		
OK	▶	GO TO 8.
NG	▶	Repair open circuit or short to power in harness or connectors.

<b>8</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

# DTC P0420 (BANK 1), P0430 (BANK 2) THREE WAY CATALYST FUNCTION

On Board Diagnosis Logic



## On Board Diagnosis Logic

NFEC0783

The ECM monitors the switching frequency ratio of heated oxygen sensor 1 (front) and heated oxygen sensors 2 (rear).

A three way catalyst (Manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2 (rear). As oxygen storage capacity decreases, the heated oxygen sensor 2 (rear) switching frequency will increase.

When the frequency ratio of heated oxygen sensor 1 (front) and heated oxygen sensor 2 (rear) approaches a specified limit value, the three way catalyst (Manifold) malfunction is diagnosed.

Malfunction is detected when three way catalyst (Manifold) does not operate properly, three way catalyst (Manifold) does not have enough oxygen storage capacity.

## Possible Cause

NFEC0784

- Three way catalyst (Manifold)
- Exhaust tube
- Intake air leaks
- Injectors
- Injector leaks
- Spark plug
- Improper ignition timing

# DTC P0420 (BANK 1), P0430 (BANK 2) THREE WAY CATALYST FUNCTION

Possible Cause (Cont'd)

<b>4</b>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: center;">SRT WORK SUPPORT</th> </tr> <tr> <td style="padding: 2px;">CATALYST</td> <td style="padding: 2px;">INCMP</td> </tr> <tr> <td style="padding: 2px;">HO2S HTR</td> <td style="padding: 2px;">CMPLT</td> </tr> <tr> <td style="padding: 2px;">HO2S</td> <td style="padding: 2px;">INCMP</td> </tr> <tr> <td style="padding: 2px;">EGR SYSTEM</td> <td style="padding: 2px;">INCMP</td> </tr> <tr> <th colspan="2" style="text-align: center;">MONITOR</th> </tr> <tr> <td style="padding: 2px;">ENG SPEED</td> <td style="padding: 2px;">XXX rpm</td> </tr> <tr> <td style="padding: 2px;">MAS A/F SE B1</td> <td style="padding: 2px;">XXX V</td> </tr> <tr> <td style="padding: 2px;">B/FUEL SCHDL</td> <td style="padding: 2px;">XXX msec</td> </tr> <tr> <td style="padding: 2px;">A/F ALPHA-B1</td> <td style="padding: 2px;">XXX V</td> </tr> <tr> <td style="padding: 2px;">COOLAN TEMP/S</td> <td style="padding: 2px;">XXX °C</td> </tr> <tr> <td style="padding: 2px;">HO2S1 (B1)</td> <td style="padding: 2px;">XXX V</td> </tr> </table>	SRT WORK SUPPORT		CATALYST	INCMP	HO2S HTR	CMPLT	HO2S	INCMP	EGR SYSTEM	INCMP	MONITOR		ENG SPEED	XXX rpm	MAS A/F SE B1	XXX V	B/FUEL SCHDL	XXX msec	A/F ALPHA-B1	XXX V	COOLAN TEMP/S	XXX °C	HO2S1 (B1)	XXX V
SRT WORK SUPPORT																									
CATALYST	INCMP																								
HO2S HTR	CMPLT																								
HO2S	INCMP																								
EGR SYSTEM	INCMP																								
MONITOR																									
ENG SPEED	XXX rpm																								
MAS A/F SE B1	XXX V																								
B/FUEL SCHDL	XXX msec																								
A/F ALPHA-B1	XXX V																								
COOLAN TEMP/S	XXX °C																								
HO2S1 (B1)	XXX V																								



SEF847Y

<b>6</b>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: center;">SRT WORK SUPPORT</th> </tr> <tr> <td style="padding: 2px;">CATALYST</td> <td style="padding: 2px;">CMPLT</td> </tr> <tr> <td style="padding: 2px;">HO2S HTR</td> <td style="padding: 2px;">CMPLT</td> </tr> <tr> <td style="padding: 2px;">HO2S</td> <td style="padding: 2px;">INCMP</td> </tr> <tr> <td style="padding: 2px;">EGR SYSTEM</td> <td style="padding: 2px;">INCMP</td> </tr> <tr> <th colspan="2" style="text-align: center;">MONITOR</th> </tr> <tr> <td style="padding: 2px;">ENG SPEED</td> <td style="padding: 2px;">XXX rpm</td> </tr> <tr> <td style="padding: 2px;">MAS A/F SE B1</td> <td style="padding: 2px;">XXX V</td> </tr> <tr> <td style="padding: 2px;">B/FUEL SCHDL</td> <td style="padding: 2px;">XXX msec</td> </tr> <tr> <td style="padding: 2px;">A/F ALPHA-B1</td> <td style="padding: 2px;">XXX V</td> </tr> <tr> <td style="padding: 2px;">COOLAN TEMP/S</td> <td style="padding: 2px;">XXX °C</td> </tr> <tr> <td style="padding: 2px;">HO2S1 (B1)</td> <td style="padding: 2px;">XXX V</td> </tr> </table>	SRT WORK SUPPORT		CATALYST	CMPLT	HO2S HTR	CMPLT	HO2S	INCMP	EGR SYSTEM	INCMP	MONITOR		ENG SPEED	XXX rpm	MAS A/F SE B1	XXX V	B/FUEL SCHDL	XXX msec	A/F ALPHA-B1	XXX V	COOLAN TEMP/S	XXX °C	HO2S1 (B1)	XXX V
SRT WORK SUPPORT																									
CATALYST	CMPLT																								
HO2S HTR	CMPLT																								
HO2S	INCMP																								
EGR SYSTEM	INCMP																								
MONITOR																									
ENG SPEED	XXX rpm																								
MAS A/F SE B1	XXX V																								
B/FUEL SCHDL	XXX msec																								
A/F ALPHA-B1	XXX V																								
COOLAN TEMP/S	XXX °C																								
HO2S1 (B1)	XXX V																								

SEF848Y

<b>7</b>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2" style="text-align: center;">SELF DIAG RESULTS</th> </tr> <tr> <th style="width: 70%;">DTC RESULTS</th> <th style="width: 30%;">TIME</th> </tr> <tr> <td style="padding: 5px; text-align: center;">NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</td> <td></td> </tr> <tr> <td style="height: 40px;"></td> <td></td> </tr> <tr> <td style="height: 40px;"></td> <td></td> </tr> </table>	SELF DIAG RESULTS		DTC RESULTS	TIME	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.					
SELF DIAG RESULTS											
DTC RESULTS	TIME										
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.											

SEF560X



## DTC Confirmation Procedure

NFEC0785

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### WITH CONSULT-II

NFEC0785S01

### TESTING CONDITION:

- Open engine hood before conducting the following procedure.
- Do not hold engine speed for more than the specified minutes below.

- 1) Turn ignition switch "ON".
- 2) Select "DTC & SRT CONFIRMATION" then "SRT WORK SUPPORT" mode with CONSULT-II.
- 3) Start engine.
- 4) Rev engine up to 3,000±500 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely.
- 5) Wait 5 seconds at idle.
- 6) Rev engine up to 2,500±500 rpm and maintain it until "INCMP" of CATALYST changes to "CMPLT" (It will take approximately 5 minutes).  
If not "CMPLT", stop engine and cool it down to less than 70°C (158°F) and then retest from step 1.
- 7) Select "SELF-DIAG RESULTS" mode with CONSULT-II.
- 8) Confirm that the 1st trip DTC is not detected.  
If the 1st trip DTC is detected, go to "Diagnostic Procedure", EC-311.

## Overall Function Check

NFEC0786

Use this procedure to check the overall function of the three way catalyst (Manifold). During this check, a 1st trip DTC might not be confirmed.

### CAUTION:

**Always drive vehicle at a safe speed.**

### WITH GST

NFEC0786S01

- 1) Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2) Stop vehicle with engine running.
- 3) Set voltmeters probes between ECM terminals 63 (HO2S1 bank 1 signal), 62 (HO2S1 bank 2 signal) and engine ground, and ECM terminals 72 (HO2S2 bank 1 signal), 71 (HO2S2 bank 2 signal) and engine ground.
- 4) Keep engine speed at 2,000 rpm constant under no load.
- 5) Make sure that the voltage switching frequency (high & low) between ECM terminals 72 and engine ground, or 71 and engine ground is very less than that of ECM terminals 63 and engine ground, or 62 and engine ground.

**Switching frequency ratio = A/B**

**A: Heated oxygen sensor 2 (rear) voltage switching frequency**

# DTC P0420 (BANK 1), P0430 (BANK 2) THREE WAY CATALYST FUNCTION

Overall Function Check (Cont'd)

**B: Heated oxygen sensor 1 (front) voltage switching frequency**

**This ratio should be less than 0.75.**

If the ratio is greater than above, it means three way catalyst (Manifold) does not operate properly. Go to "Diagnostic Procedure", EC-311.


**NOTE:**

If the voltage at ECM terminal 62 or 63 does not switch periodically more than 5 times within 10 seconds at step 5, perform trouble diagnosis for "DTC P0133, P0153" first. (See EC-184.)

## Diagnostic Procedure

NFEC0787

<b>1</b>	<b>CHECK EXHAUST SYSTEM</b>	
Visually check exhaust tubes and muffler for dent.		
<b>OK or NG</b>		
OK	▶	GO TO 2.
NG	▶	Repair or replace.

<b>2</b>	<b>CHECK EXHAUST AIR LEAK</b>	
1. Start engine and run it at idle. 2. Listen for an exhaust air leak before the three way catalyst (Manifold).		
		
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	Repair or replace.


SEF099P

<b>3</b>	<b>CHECK INTAKE AIR LEAK</b>	
Listen for an intake air leak after the mass air flow sensor.		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	Repair or replace.

# DTC P0420 (BANK 1), P0430 (BANK 2) THREE WAY CATALYST FUNCTION


Diagnostic Procedure (Cont'd)

4	<b>CHECK IGNITION TIMING</b>	
Check the following items. Refer to "Basic Inspection", EC-90.		
	Items	Specifications
	Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)
	Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF
	Target idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)
MTBL0623		
<b>OK or NG</b>		
OK	▶	GO TO 5.
NG	▶	Follow the "Basic Inspection".

5	<b>CHECK INJECTORS</b>	
1. Refer to WIRING DIAGRAM for Injectors, EC-524. 2. Stop engine and then turn ignition switch "ON". 3. Check voltage between ECM terminals 101, 102, 103, 104, 105, 107 and ground with CONSULT-II or tester.		
		
<b>Battery voltage should exist.</b>		
SEF331X		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	Perform "Diagnostic Procedure" under "INJECTOR", EC-525.

# DTC P0420 (BANK 1), P0430 (BANK 2) THREE WAY CATALYST FUNCTION

Diagnostic Procedure (Cont'd)

6		CHECK IGNITION SPARK
<ol style="list-style-type: none"><li>1. Turn ignition switch "OFF".</li><li>2. Disconnect ignition coil assembly from rocker cover.</li><li>3. Connect a known-good spark plug to the ignition coil assembly.</li><li>4. Place end of spark plug against a suitable ground and crank engine.</li><li>5. Check for spark.</li></ol>		
		
SEF575Q		
<b>OK or NG</b>		
OK	▶	GO TO 7.
NG	▶	Check ignition coil with power transistor and their circuit. Refer to "IGNITION SIGNAL", EC-495.

7		CHECK INJECTOR
<ol style="list-style-type: none"><li>1. Turn ignition switch "OFF".</li><li>2. Remove injector assembly. Refer to EC-38. Keep fuel hose and all injectors connected to injector gallery.</li><li>3. Disconnect all ignition coil harness connectors.</li><li>4. Turn ignition switch "ON". Make sure fuel does not drip from injector.</li></ol>		
<b>OK or NG</b>		
OK (Does not drip.)	▶	GO TO 8.
NG (Drips.)	▶	Replace the injector(s) from which fuel is dripping.

8		CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
Trouble is fixed.	▶	<b>INSPECTION END</b>
Trouble is not fixed.	▶	Replace three way catalyst (Manifold).

# DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

Description


## Description SYSTEM DESCRIPTION

NFEC0788

NFEC0788S01

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed (POS signal)	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Throttle position switch	Closed throttle position		
Heated oxygen sensor 1 (front)	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Fuel tank temperature sensor	Fuel temperature in fuel tank		
Vehicle speed sensor	Vehicle speed		

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.



### COMPONENT DESCRIPTION

NFEC0788S02

The EVAP canister purge volume control solenoid valve uses an ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0789

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	● Engine: After warming up ● Air conditioner switch "OFF" ● Shift lever: "N" ● No-load Idle (Vehicle stopped)	0%
	2,000 rpm	—

# DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

On Board Diagnosis Logic

## On Board Diagnosis Logic

Malfunction is detected when an improper voltage signal is sent to ECM through the valve. NFEC0790

## Possible Cause

- Harness or connectors  
(The valve circuit is open or shorted.)
  - EVAP canister purge volume control solenoid valve
- NFEC0791

3	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

## DTC Confirmation Procedure

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test. NFEC0792

### TESTING CONDITION:

**Before performing the following procedure, confirm battery voltage is more than 11V at idle.**

#### WITH CONSULT-II

- 1) Turn ignition switch "ON".
  - 2) Select "DATA MONITOR" mode with CONSULT-II.
  - 3) Start engine and let it idle for at least 13 seconds.
  - 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-317.
- NFEC0792S01

#### WITH GST

Follow the procedure "WITH CONSULT-II" above. NFEC0792S02


# DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

Wiring Diagram



## Wiring Diagram

NFEC0793

EC-PGC/V-01



: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC002D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
1	PU/R	EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE	ENGINE RUNNING AT IDLE SPEED	BATTERY VOLTAGE (V) 
			ENGINE RUNNING AT 2,000 RPM (MORE THAN 100 SECONDS AFTER STARTING ENGINE)	BATTERY VOLTAGE (V) 



SEF858Y

# DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0794

<b>1</b>	<b>CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect EVAP canister purge volume control solenoid valve harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF266X</p> <p>3. Turn ignition switch "ON".                  4. Check voltage between EVAP canister purge volume control solenoid valve terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="text-align: right;"><b>Voltage: Battery voltage</b></p> </div> <p style="text-align: right;">SEF333X</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 3.
NG	▶	GO TO 2.

<b>2</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● Fuse block (J/B) connector M19</li> <li>● 15A fuse</li> <li>● Harness for open or short between EVAP canister purge volume control solenoid valve and fuse</li> </ul>		
▶		Repair harness or connectors.

# DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between ECM terminal 1 and EVAP canister purge volume control solenoid valve terminal 1. Refer to Wiring Diagram.  <span style="color: blue;">Continuity should exist.</span></p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK (With CONSULT-II)	▶	GO TO 4.
OK (Without CONSULT-II)	▶	GO TO 5.
NG	▶	Repair open circuit or short to ground and short to power in harness or connectors.

<b>4</b>	<b>CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION</b>																					
<p>Ⓟ <b>With CONSULT-II</b></p> <p>1. Start engine.</p> <p>2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.</p>																						
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>PURG VOL CONT/V</td><td>XXX %</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>A/F ALPHA-B1</td><td>XX %</td></tr> <tr><td>A/F ALPHA-B2</td><td>XX %</td></tr> <tr><td>HO2S1 MNTR (B1)</td><td>LEAN</td></tr> <tr><td>HO2S1 MNTR (B2)</td><td>LEAN</td></tr> <tr><td>THRTL POS SEN</td><td>X. XX V</td></tr> <tr><td> </td><td> </td></tr> </table>			ACTIVE TEST		PURG VOL CONT/V	XXX %	MONITOR		ENG SPEED	XXX rpm	A/F ALPHA-B1	XX %	A/F ALPHA-B2	XX %	HO2S1 MNTR (B1)	LEAN	HO2S1 MNTR (B2)	LEAN	THRTL POS SEN	X. XX V		
ACTIVE TEST																						
PURG VOL CONT/V	XXX %																					
MONITOR																						
ENG SPEED	XXX rpm																					
A/F ALPHA-B1	XX %																					
A/F ALPHA-B2	XX %																					
HO2S1 MNTR (B1)	LEAN																					
HO2S1 MNTR (B2)	LEAN																					
THRTL POS SEN	X. XX V																					
SEF677Y																						
<b>OK or NG</b>																						
OK	▶	GO TO 6.																				
NG	▶	GO TO 5.																				


# DTC P0443 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE (CIRCUIT)

Diagnostic Procedure (Cont'd)

## 5 CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

### ④ With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.




Condition PURG VOL CONT/V value	Air passage continuity between A and B
100.0%	Yes
0.0%	No

SEF334X

### ⊗ Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.



Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No

SEF335X

**OK or NG**

OK	▶	GO TO 6.
NG	▶	Replace EVAP canister purge volume control solenoid valve.


## 6 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.

	▶	<b>INSPECTION END</b>
--	---	-----------------------

## DTC P0500 VEHICLE SPEED SENSOR (VSS)

### Component Description



### Component Description

The vehicle speed sensor is installed in the transaxle. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM. =NFEC0795

### On Board Diagnosis Logic

Malfunction is detected when the almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven. NFEC0796

### Possible Cause

- Harness or connector  
(The vehicle speed sensor circuit is open or shorted.)
  - Vehicle speed sensor
- NFEC0797

### DTC Confirmation Procedure

#### **CAUTION:**

Always drive vehicle at a safe speed. NFEC0798

#### **NOTE:**

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

#### **TESTING CONDITION:**

Steps 1 and 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

#### **WITH CONSULT-II**

- 1) Start engine (TCS switch "OFF").
  - 2) Read "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.  
If NG, go to "Diagnostic Procedure", EC-323.  
If OK, go to following step.
  - 3) Select "DATA MONITOR" mode with CONSULT-II.
  - 4) Warm engine up to normal operating temperature.
- NFEC0798S01

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
B/FUEL SCHDL	XXX msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	XXX km/h

SEF196Y

## DTC P0500 VEHICLE SPEED SENSOR (VSS)

DTC Confirmation Procedure (Cont'd)

- 5) Maintain the following conditions for at least 10 consecutive seconds.

ENG SPEED	1,400 - 6,000 rpm (A/T) 1,900 - 6,000 rpm (M/T)
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	4 - 8 msec (A/T) 4.8 - 9 msec (M/T)
Selector lever	Suitable position
PW/ST SIGNAL	OFF

- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-323.

### Overall Function Check

NFEC0799

Use this procedure to check the overall function of the vehicle speed sensor circuit. During this check, a 1st trip DTC might not be confirmed.

#### WITH GST

NFEC0799S01

- 1) Lift up drive wheels.
- 2) Start engine.
- 3) Read vehicle speed sensor signal in "MODE 1" with GST. The vehicle speed sensor on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
- 4) If NG, go to "Diagnostic Procedure", EC-323.




# DTC P0500 VEHICLE SPEED SENSOR (VSS)

Wiring Diagram

## Wiring Diagram



NFEC0800

### EC-VSS-01



REFER TO THE FOLLOWING.

- (M15) -SUPER
- MULTIPLE JUNCTION (SMJ)
- (M19) -FUSE BLOCK-JUNCTION BOX (J/B)



MEC003D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
86	P/L	VEHICLE SPEED SENSOR	VEHICLE DRIVING AT 10 KM/H (6 MPH) IN 1ST GEAR POSITION UNDER LIFTED UP CONDITION	APPROX. 2.0V 
			VEHICLE DRIVING AT 30 KM/H (19 MPH) IN 2ND GEAR POSITION UNDER LIFTED UP CONDITION	APPROX. 2.5V 

SEF859Y

# DTC P0500 VEHICLE SPEED SENSOR (VSS)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0801

1	CHECK VEHICLE SPEED SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector and combination meter harness connector. 3. Check harness continuity between ECM terminal 86 and combination meter terminal 32. Refer to Wiring Diagram. <b>Continuity should exist.</b> 4. Also check harness for short to ground and short to power. <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"><li>● Harness connectors M46, F44</li><li>● Harness for open or short between ECM and combination meter</li></ul>	
	▶ Repair open circuit or short to ground or short to power in harness or connectors.

3	CHECK SPEEDOMETER FUNCTION
Make sure that speedometer functions properly. <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	CHECK SPEEDOMETER CIRCUIT FOR OPEN AND SHORT
Check the following. <ul style="list-style-type: none"><li>● Harness connectors M15, E81</li><li>● Harness for open or short between combination meter and ABS actuator and electric unit</li></ul> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ Check combination meter and ABS actuator and electric unit. Refer to EL or BR section.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

5	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
	▶ <b>INSPECTION END</b>

# DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Description


## Description SYSTEM DESCRIPTION

NFEC0802

NFEC0802S01

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed (POS signal)	Idle air control	IACV-AAC valve
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Park/neutral position (PNP) switch	Park/neutral position		
Air conditioner switch	Air conditioner operation		
Power steering oil pressure switch	Power steering load signal		
Battery	Battery voltage		
Vehicle speed sensor	Vehicle speed		
Ambient air temperature switch	Ambient air temperature		
Intake air temperature sensor	Intake air temperature		
Absolute pressure sensor	Ambient barometric pressure		

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which by-passes the throttle valve via IACV-AAC valve. The IACV-AAC valve changes the opening of the air by-pass passage to control the amount of auxiliary air. This valve is actuated by a step motor built into the valve, which moves the valve in the axial direction in steps corresponding to the ECM output signals. One step of IACV-AAC valve movement causes the respective opening of the air by-pass passage. (i.e. when the step advances, the opening is enlarged.) The opening of the valve is varied to allow for optimum control of the engine idling speed. The crankshaft position sensor (POS) detects the actual engine speed and sends a signal to the ECM. The ECM then controls the step position of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner, power steering and cooling fan operation).



## COMPONENT DESCRIPTION IACV-AAC Valve

NFEC0802S02

NFEC0802S0201

The IACV-AAC valve is operated by a step motor for centralized control of auxiliary air supply. This motor has four winding phases and is actuated by the output signals of ECM which turns ON and OFF two windings each in sequence. Each time the IACV-AAC valve opens or closes to change the auxiliary air quantity, the ECM sends a pulse signal to the step motor. When no change in the auxiliary air quantity is needed, the ECM does not issue the pulse signal. A certain voltage signal is issued so that the valve remains at that particular opening.

# DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

CONSULT-II Reference Value in Data Monitor Mode

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0803

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
IACV-AAC/V	<ul style="list-style-type: none"><li>● Engine: After warming up</li><li>● Air conditioner switch: "OFF"</li><li>● Shift lever: "N"</li><li>● No-load</li></ul> Idle	2 - 10 step
	2,000 rpm	—

## On Board Diagnosis Logic

NFEC0804

Malfunction is detected when

**(Malfunction A)** the IACV-AAC valve does not operate properly,  
**(Malfunction B)** the IACV-AAC valve does not operate properly.

## Possible Cause

NFEC0805

### MALFUNCTION A

NFEC0805S01

- Harness or connectors  
(The IACV-AAC valve circuit is open.)
- IACV-AAC valve

### MALFUNCTION B

NFEC0805S02

- Harness or connectors  
(The IACV-AAC valve circuit is shorted.)
- Air control valve (Power steering)
- IACV-AAC valve

## DTC Confirmation Procedure

NFEC0806

### NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.
- **If the engine idle speed is out of the specified value, perform "Idle air Volume Learning", EC-41, before conducting "DTC Confirmation Procedure". For the target idle speed, refer to the "Service Data and Specifications (SDS)", EC-559.**
- Perform "PROCEDURE FOR MALFUNCTION A" first. If 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

# DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

DTC Confirmation Procedure (Cont'd)

<b>2</b>	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

## PROCEDURE FOR MALFUNCTION A

NFEC0806S01

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch "ON".

#### With CONSULT-II

NFEC0806S0101

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and let it idle.
- 4) Keep engine speed at 2,500 rpm for three seconds, then let it idle for three seconds.

**Do not rev engine to more than 3,000 rpm.**

- 5) Perform step 4 once more.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-328.

#### With GST

NFEC0806S0102

Follow the procedure "With CONSULT-II" above.

<b>4</b>	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm
	COOLAN TEMP/S	XXX °C

SEF174Y

## PROCEDURE FOR MALFUNCTION B

NFEC0806S02

### TESTING CONDITION:

- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.
- Always perform the test at a temperature above -10°C (14°F).

#### With CONSULT-II

NFEC0806S0201

- 1) Open engine hood.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Turn ignition switch "OFF" and wait at least 10 seconds.
- 4) Turn ignition switch "ON" again and select "DATA MONITOR" mode with CONSULT-II
- 5) Start engine and run it for at least 1 minute at idle speed.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-328.

#### With GST

NFEC0806S0202




Follow the procedure "With CONSULT-II" above.

# DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Wiring Diagram

## Wiring Diagram

NFE0807



MEC004D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**  
DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
6	W/PU	IACV-AAC VALVE	ENGINE RUNNING AT IDLE SPEED	0.1 - 14V
7	Y/B			
8	Y			
17	GY/L			



SEF625XB

# DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Diagnostic Procedure

## Diagnostic Procedure

NFEC0808


<b>1</b>	<b>CHECK IACV-AAC VALVE POWER SUPPLY CIRCUIT</b>	<p>1. Stop engine. 2. Disconnect IACV-AAC valve harness connector.</p> <div style="text-align: center;"> <p>View with intake air duct removed</p>  <p>IACV-AAC valve</p> </div> <p>3. Turn ignition switch "ON". 4. Check voltage between IACV-AAC valve terminals 2, 5 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p>Voltage: Battery voltage</p> </div> <p style="text-align: right;">SEC008C</p>
		SEF343X
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	GO TO 2.

<b>2</b>	<b>DETECT MALFUNCTIONING PART</b>	<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between IACV-AAC valve and ECM relay</li> </ul> <p style="text-align: center;">▶ Repair harness or connectors.</p>
----------	-----------------------------------	--

# DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>CHECK IACV-AAC VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>											
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Disconnect ECM harness connector.</li> <li>3. Check harness continuity between ECM terminals and IACV-AAC valve terminals as follows. Refer to Wiring Diagram.</li> </ol>												
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">ECM terminal</th> <th style="padding: 5px;">IACV-AAC valve terminal</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; padding: 5px;">6</td> <td style="text-align: center; padding: 5px;">1</td> </tr> <tr> <td style="text-align: center; padding: 5px;">7</td> <td style="text-align: center; padding: 5px;">4</td> </tr> <tr> <td style="text-align: center; padding: 5px;">8</td> <td style="text-align: center; padding: 5px;">3</td> </tr> <tr> <td style="text-align: center; padding: 5px;">17</td> <td style="text-align: center; padding: 5px;">6</td> </tr> </tbody> </table>			ECM terminal	IACV-AAC valve terminal	6	1	7	4	8	3	17	6
ECM terminal	IACV-AAC valve terminal											
6	1											
7	4											
8	3											
17	6											
MTBL0354												
<p><b>Continuity should exist.</b></p> <ol style="list-style-type: none"> <li>4. Also check harness for short to ground and short to power.</li> </ol>												
<b>OK or NG</b>												
OK	▶	GO TO 4.										
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.										

<b>4</b>	<b>CHECK AIR CONTROL VALVE (POWER STEERING) OPERATION-I</b>	
<ol style="list-style-type: none"> <li>1. Reconnect ECM harness connector and IACV-AAC valve harness connector.</li> <li>2. Disconnect vacuum hose connected to air control valve (Power steering) at intake air duct.</li> <li>3. Start engine and let it idle.</li> <li>4. Check vacuum hose for vacuum existence.</li> </ol>		
		
SEF971X		
<p><b>Vacuum slightly exists or does not exist.</b></p>		
<b>OK or NG</b>		
OK	▶	GO TO 5.
NG	▶	Replace air control valve (Power steering).

# DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE


Diagnostic Procedure (Cont'd)


<b>5</b>	<b>CHECK AIR CONTROL VALVE (POWER STEERING) OPERATION-II</b>	
<p>Check vacuum hose for vacuum existence when steering wheel is turned.</p>		
<p><b>Vacuum should exist.</b></p>		
<p><b>OK or NG</b></p>		
OK	▶	GO TO 8.
NG	▶	GO TO 6.

<b>6</b>	<b>CHECK VACUUM PORT</b>	
<ol style="list-style-type: none"> <li>1. Stop engine.</li> <li>2. Disconnect vacuum hose connected to air control valve (Power steering) at vacuum port.</li> <li>3. Blow air into vacuum port.</li> <li>4. Check that air flows freely.</li> </ol>		
<p><b>OK or NG</b></p>		
OK	▶	GO TO 7.
NG	▶	Repair or clean vacuum port.

# DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE


Diagnostic Procedure (Cont'd)

7	CHECK VACUUM HOSES AND TUBES
<p>1. Disconnect vacuum hoses between air control valve (Power steering) and vacuum port, air control valve (Power steering) and intake air duct.</p> <p>2. Check the hoses and tubes for crack, clogging, improper connection or disconnection.</p>	
	
SEF109L	
<b>OK or NG</b>	
OK	▶ GO TO 8.
NG	▶ Repair hoses or tubes.

8	CHECK IACV-AAC VALVE-I
<p>1. Disconnect IACV-AAC valve harness connector.</p> <p>2. Check resistance between IACV-AAC valve terminal 2 and terminals 1, 3, terminal 5 and terminals 4, 6.</p>	
	
<p><b>Resistance:</b> Approximately 22Ω [at 20°C (68°F)]</p>	
SEF344X	
<b>OK or NG</b>	
OK	▶ GO TO 9.
NG	▶ Replace IACV-AAC valve assembly.

# DTC P0505 IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Diagnostic Procedure (Cont'd)

<b>9</b>	<b>CHECK IACV-AAC VALVE-II</b>	
<ol style="list-style-type: none"> <li>1. Reconnect IACV-AAC valve harness connector and ECM harness connector.</li> <li>2. Turn ignition switch "ON" and "OFF", and ensure the IACV-AAC valve makes operating sound according to the ignition switch position.</li> </ol>		
<p>View with intake air duct removed</p>  <p>IACV-AAC valve</p>		
SEC009C		
<b>OK or NG</b>		
OK	▶	GO TO 11.
NG	▶	GO TO 10.


<b>10</b>	<b>REPLACE IACV-AAC VALVE</b>	
<ol style="list-style-type: none"> <li>1. Replace IACV-AAC valve assembly.</li> <li>2. Perform "Idle Air Volume Learning", EC-41.</li> </ol> <p style="text-align: center; color: blue;"><b>Is the result CMPLT or INCMP?</b></p>		
<b>CMPLT or INCMP</b>		
CMPLT	▶	<b>INSPECTION END</b>
INCMP	▶	Follow the construction of "Idle Air Volume Learning".

<b>11</b>	<b>CHECK TARGET IDLE SPEED</b>	
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Reconnect all harness connectors and vacuum hoses.</li> <li>3. Start engine and warm it up to normal operating temperature.</li> <li>4. Also warm up transmission to normal operating temperature. <ul style="list-style-type: none"> <li>● For A/T models with CONSULT-II, drive vehicle until "FLUID TEMP SE" in "DATA MONITOR" mode of "A/T" system indicates less than 0.9V.</li> <li>● For A/T models without CONSULT-II and M/T models, drive vehicle for 10 minutes.</li> </ul> </li> <li>5. Stop vehicle with engine running.</li> <li>6. Check target idle speed. <ul style="list-style-type: none"> <li><b>M/T: 625±50 rpm (VQ30DE engine models)</b></li> <li><b>M/T: 675±50 rpm (VQ20DE engine models)</b></li> <li><b>A/T: 700±50 rpm (in "P" or "N" position)</b></li> </ul> </li> </ol>		
<b>OK or NG</b>		
OK	▶	GO TO 12.
NG	▶	Perform "Idle Air Volume Learning", EC-41.

<b>12</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶ <b>INSPECTION END</b>		

## DTC P0510 CLOSED THROTTLE POSITION SWITCH

Component Description



### Component Description

NFEC0809

A closed throttle position switch and wide open throttle position switch are built into the throttle position sensor unit. The wide open throttle position switch is used only for A/T control.

When the throttle valve is in the closed position, the closed throttle position switch sends a voltage signal to the ECM. The ECM only uses this signal to open or close the EVAP canister purge volume control solenoid valve when the throttle position sensor is malfunctioning.

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0810

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION	
CLSD THL/P SW	● Engine: After warming up, idle the engine	Throttle valve: Idle position	ON
		Throttle valve: Slightly open	OFF

### On Board Diagnosis Logic

NFEC0811

Malfunction is detected when battery voltage from the closed throttle position switch is sent to ECM with the throttle valve opened.

### Possible Cause

NFEC0812

- Harness or connectors (The closed throttle position switch circuit is shorted.)
- Closed throttle position switch
- Throttle position sensor

# DTC P0510 CLOSED THROTTLE POSITION SWITCH

## DTC Confirmation Procedure

<b>4</b>	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm
	COOLAN TEMP/S	XXX °C
	CLSD THL/P SW	ON

SEF197Y

<b>6</b>	DATA MONITOR	
	MONITOR	NO DTC
	COOLAN TEMP/S	XXX °C
	VHCL SPEED SE	XXX km/h
	THRTL POS SEN	XXX V

SEF198Y

## DTC Confirmation Procedure

NFEC0813

**CAUTION:**  
Always drive vehicle at a safe speed.

**NOTE:**  
If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### WITH CONSULT-II

NFEC0813S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then start engine.
- 3) Select "CLSD THL/P SW" in "DATA MONITOR" mode.  
If "CLSD THL/P SW" is not available, go to step 5.
- 4) Check the signal under the following conditions.


Condition	Signal indication
Throttle valve: Idle position	ON
Throttle valve: Slightly open	OFF

If the result is NG, go to "Diagnostic Procedure", EC-337.  
If OK, go to following step.

- 5) Select "DATA MONITOR" mode with CONSULT-II.
- 6) Drive the vehicle for at least 5 consecutive seconds under the following condition.

THRTL POS SEN	More than 2.5V
VHCL SPEED SE	More than 5 km/h (3 MPH)
Selector lever	Suitable position
Driving location	Driving vehicle uphill (Increased engine load) will help maintain the driving conditions required for this test.

- 7) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-337.



## Overall Function Check

NFEC0814

Use this procedure to check the overall function of the closed throttle position switch circuit. During this check, a 1st trip DTC might not be confirmed.

### WITH GST

NFEC0814S01

- 1) Start engine and warm it up to normal operating temperature.
- 2) Check the voltage between ECM terminal 56 (Closed throttle position switch signal) and ground under the following conditions.

**At idle: Battery voltage**

## **DTC P0510 CLOSED THROTTLE POSITION SWITCH**

*Overall Function Check (Cont'd)*

---

**At 2,000 rpm: Approximately 0V**



- 3) If NG, go to "Diagnostic Procedure", EC-337.

# DTC P0510 CLOSED THROTTLE POSITION SWITCH

Wiring Diagram

## Wiring Diagram

=NFEC0815



MEC005D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**  
**CAUTION:**  
 DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
5	R/G	THROTTLE POSITION SWITCH (CLOSED POSITION)	ENGINE RUNNING WITH ACCELERATOR PEDAL FULLY RELEASED UNDER WARM-UP CONDITION	BATTERY VOLTAGE
			IGN ON WITH ACCELERATOR PEDAL DEPRESSED	APPROX. 0V



SEF626XC

# DTC P0510 CLOSED THROTTLE POSITION SWITCH

Diagnostic Procedure

## Diagnostic Procedure

NFEC0816

<b>1</b>	<b>CHECK CLOSED THROTTLE POSITION SWITCH POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect throttle position switch harness connector.</p> <div style="text-align: center;">  </div> <p>3. Turn ignition switch "ON".                  4. Check voltage between throttle position switch terminal 5 and engine ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="margin-left: 100px;"><b>Voltage: Battery voltage</b></p> </div> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 3.
NG	▶	GO TO 2.

SEC001C

SEF346X

<b>2</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between throttle position switch and ECM relay</li> <li>● Harness for open or short between throttle position switch and ECM</li> </ul>		
▶		Repair harness or connectors.

<b>3</b>	<b>CHECK CLOSED THROTTLE POSITION SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect ECM harness connector.                  3. Check harness continuity between ECM terminal 56 and throttle position switch terminal 4.                  Refer to Wiring Diagram.  <b>Continuity should exist.</b>                  4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

## DTC P0510 CLOSED THROTTLE POSITION SWITCH



Diagnostic Procedure (Cont'd)

4	<b>CHECK IGNITION TIMING AND ENGINE IDLE SPEED</b>							
Check the following items. Refer to "Basic Inspection", EC-90.								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Items</th> <th style="width: 70%;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)</td> </tr> <tr> <td>Idle speed</td> <td>M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table>			Items	Specifications	Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)	Idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)
Items	Specifications							
Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)							
Idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)							
MTBL0625								
Models with CONSULT-II	▶	GO TO 6.						
Models without CONSULT-II	▶	GO TO 6.						

5	<b>CHECK THROTTLE POSITION SWITCH</b>							
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Turn ignition switch "OFF".</li> <li>3. Turn ignition switch "ON".</li> <li>4. Select "DATA MONITOR" mode with CONSULT-II.</li> <li>5. Check indication of "CLSD THL/P SW" under the following conditions. Measurement must be made with throttle position switch installed in vehicle.</li> </ol>								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Throttle valve conditions</th> <th style="width: 50%;">CLSD THL/P SW</th> </tr> </thead> <tbody> <tr> <td>Completely closed</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Partially open or completely open</td> <td style="text-align: center;">OFF</td> </tr> </tbody> </table>			Throttle valve conditions	CLSD THL/P SW	Completely closed	ON	Partially open or completely open	OFF
Throttle valve conditions	CLSD THL/P SW							
Completely closed	ON							
Partially open or completely open	OFF							
MTBL0355								
<b>OK or NG</b>								
OK (With CONSULT-II)	▶	GO TO 8.						
OK (Without CONSULT-II)	▶	GO TO 9.						
NG	▶	GO TO 7.						

## DTC P0510 CLOSED THROTTLE POSITION SWITCH

Diagnostic Procedure (Cont'd)


6	CHECK THROTTLE POSITION SWITCH							
<p>1. Start engine and warm it up to normal operating temperature.                      2. Turn ignition switch "OFF".                      3. Disconnect closed throttle position switch harness connector.                      4. Check continuity between closed throttle position switch terminals 4 and 5 under the following conditions.                      Resistance measurement must be made with throttle position switch installed in vehicle.</p>								
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 20%;">  </div> <div style="width: 30%;">  </div> <div style="width: 40%;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="width: 70%;">Throttle valve conditions</th> <th style="width: 30%;">Continuity</th> </tr> </thead> <tbody> <tr> <td>Completely closed</td> <td>Yes</td> </tr> <tr> <td>Partially open or completely open</td> <td>No</td> </tr> </tbody> </table> </div> </div>			Throttle valve conditions	Continuity	Completely closed	Yes	Partially open or completely open	No
Throttle valve conditions	Continuity							
Completely closed	Yes							
Partially open or completely open	No							
SEC010C								
<b>OK or NG</b>								
OK (With CONSULT-II)	▶	GO TO 8.						
OK (Without CONSULT-II)	▶	GO TO 9.						
NG	▶	GO TO 7.						

7	ADJUST THROTTLE POSITION SWITCH									
Check the following items. Refer to "Basic Inspection", EC-90.										
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 40%;">Items</th> <th style="width: 60%;">Specifications</th> </tr> </thead> <tbody> <tr> <td>Ignition timing</td> <td>9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)</td> </tr> <tr> <td>Closed throttle position switch idle position adjustment</td> <td>Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF</td> </tr> <tr> <td>Target idle speed</td> <td>M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)</td> </tr> </tbody> </table>			Items	Specifications	Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)	Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF	Target idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)
Items	Specifications									
Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)									
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF									
Target idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)									
MTBL0623										
<b>Is it possible to adjust closed throttle position switch?</b>										
<b>Yes or No</b>										
Yes (With CONSULT-II)	▶	GO TO 9.								
Yes (Without CONSULT-II)	▶	GO TO 9.								
No	▶	Replace throttle position switch.								

## DTC P0510 CLOSED THROTTLE POSITION SWITCH

Diagnostic Procedure (Cont'd)


<b>8</b>	<b>CHECK THROTTLE POSITION SENSOR</b>									
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Stop engine (ignition switch OFF).</li> <li>3. Turn ignition switch ON.</li> <li>4. Select "DATA MONITOR" mode with CONSULT-II.</li> <li>5. Check voltage of "THRTL POS SEN" under the following conditins.</li> </ol> <p><b>Voltage measurement must be made with throttle position sensor installed in vehicle.</b></p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Throttle valve conditions</th> <th style="text-align: center;">THRTL POS SEN</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Completely closed (a)</td> <td style="text-align: center;">0.15 - 0.85V</td> </tr> <tr> <td style="text-align: center;">Partially open</td> <td style="text-align: center;">Between (a) and (b)</td> </tr> <tr> <td style="text-align: center;">Completely open (b)</td> <td style="text-align: center;">3.5 - 4.7V</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">MTBL0230</p> <p style="text-align: center;"><b>OK or NG</b></p>			Throttle valve conditions	THRTL POS SEN	Completely closed (a)	0.15 - 0.85V	Partially open	Between (a) and (b)	Completely open (b)	3.5 - 4.7V
Throttle valve conditions	THRTL POS SEN									
Completely closed (a)	0.15 - 0.85V									
Partially open	Between (a) and (b)									
Completely open (b)	3.5 - 4.7V									
OK	▶	GO TO 10.								
NG	▶	Replace throttle position sensor.								

<b>9</b>	<b>CHECK THROTTLE POSITION SENSOR</b>									
<ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Stop engine (ignition switch OFF).</li> <li>3. Turn ignition switch ON.</li> <li>4. Check voltage between ECM terminal 91 (Throttle position sensor signal) and ground.</li> </ol> <p><b>Voltage measurement must be made with throttle position sensor installed in vehicle.</b></p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 40%;">  </div> <div style="width: 55%;"> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Throttle valve conditions</th> <th style="text-align: center;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Completely closed (a)</td> <td style="text-align: center;">0.15 - 0.85V</td> </tr> <tr> <td style="text-align: center;">Partially open</td> <td style="text-align: center;">Between (a) and (b)</td> </tr> <tr> <td style="text-align: center;">Completely open (b)</td> <td style="text-align: center;">3.5 - 4.7V</td> </tr> </tbody> </table> <p style="text-align: right; margin-right: 20px;">SEF348X</p> <p style="text-align: center;"><b>OK or NG</b></p> </div> </div>			Throttle valve conditions	Voltage	Completely closed (a)	0.15 - 0.85V	Partially open	Between (a) and (b)	Completely open (b)	3.5 - 4.7V
Throttle valve conditions	Voltage									
Completely closed (a)	0.15 - 0.85V									
Partially open	Between (a) and (b)									
Completely open (b)	3.5 - 4.7V									
OK	▶	GO TO 10.								
NG	▶	Replace throttle position sensor.								

<b>10</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

## DTC P0605 ECM

Component Description



### Component Description

The ECM consists of a microcomputer and connector for signal input and output and for power supply. The unit controls the engine. NFEC0271

### On Board Diagnosis Logic

Malfunction is detected when ECM calculation function is malfunctioning. NFEC0272


### Possible Cause

- ECM NFEC0518

### DTC Confirmation Procedure

#### NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test. NFEC0273



#### WITH CONSULT-II

- 1) Turn ignition switch “ON”. NFEC0273S01
- 2) Select “DATA MONITOR” mode with CONSULT-II.
- 3) Start engine.
- 4) Run engine for at least 30 seconds at idle speed.
- 5) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-342.

#### WITH GST

Follow the procedure “WITH CONSULT-II” above. NFEC0273S03

## DTC P0605 ECM

DTC Confirmation Procedure (Cont'd)



### NO TOOLS

NFEC0273S02

- 1) Turn ignition switch "ON".
- 2) Start engine and wait at least 30 seconds.
- 3) Turn ignition switch "OFF" and wait at least 10 seconds.
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 5) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-342.

## Diagnostic Procedure

NFEC0274

<b>1</b>	<b>INSPECTION START</b>	
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Select "SELF DIAG RESULTS" mode with CONSULT-II.</li> <li>3. Touch "ERASE".</li> <li>4. <b>Perform "DTC Confirmation Procedure".</b> See EC-341.</li> <li>5. Is the 1st trip DTC P0605 displayed again?</li> </ol>		
<p> <b>With GST</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Select MODE 4 with GST.</li> <li>3. Touch "ERASE".</li> <li>4. <b>Perform "DTC Confirmation Procedure".</b> See EC-341.</li> <li>5. Is the 1st trip DTC P0605 displayed again?</li> </ol>		
<p> <b>No Tools</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Erase the Diagnostic Test Mode II (Self-diagnostic results) memory. Refer to "How to Erase Emission-related Diagnostic Information", EC-56, EC-59.</li> <li>3. <b>Perform "DTC Confirmation Procedure".</b> See EC-341.</li> <li>4. Is the 1st trip DTC 0605 displayed again?</li> </ol> <p style="text-align: center;"><b>Yes or No</b></p>		
	Yes [With NVIS (NATS) system]	GO TO 2.
	Yes [Without NVIS (NATS) system]	GO TO 3.
	No	<b>INSPECTION END</b>

<b>2</b>	<b>REPLACE ECM</b>	
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Replace ECM.</li> <li>3. Perform initialization of NVIS (NATS) system and registration of all NVIS (NATS) ignition key IDs. Refer to "NVIS (Nissan Vehicle Immobilizer System — NATS)", EC-60.</li> <li>4. Perform "Idle Air Volume Learning", EC-41. <b>Which is the result CMPLT or INCMP?</b></li> </ol> <p style="text-align: center;"><b>CMPLT or INCMP</b></p>		
	CMPLT	<b>INSPECTION END</b>
	INCMP	Follow the construction of "Idle Air Volume Learning".

## DTC P0605 ECM

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>REPLACE ECM</b>
1. Turn ignition switch "OFF". 2. Replace ECM. 3. Perform "Idle Air Volume Learning", EC-41. <b>Which is the result CMPLT or INCMP?</b>	
<b>CMPLT or INCMP</b>	
CMPLT	▶ <b>INSPECTION END</b>
INCMP	▶ Follow the construction of "Idle Air Volume Learning".

# DTC P1131 SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Description

## Description SYSTEM DESCRIPTION

NFEC0823

NFEC0823S01

Sensor	Input Signal to ECM	ECM function	Actuator
Throttle position sensor	Throttle position	Swirl control valve control	Swirl control valve control solenoid valve ↓ Vacuum signal Swirl control valve actuator ↓ Swirl control valve
Ignition switch	Start signal		
Crankshaft position sensor (POS)	Engine speed (POS signal)		
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		

This system has a swirl control valve in the intake passage of each cylinder.

While idling and during low engine speed operation, the swirl control valve closes. Thus the velocity of the air in the intake passage increases, promoting the vaporization of the fuel and producing a swirl in the combustion chamber.


Because of this operation, this system tends to increase the burning speed of the gas mixture, improve fuel consumption, and increase the stability in running conditions.

Also, except when idling and during low engine speed operation, this system opens the swirl control valve. In this condition, this system tends to increase power by improving intake efficiency via reduction of intake flow resistance, intake flow.

The solenoid valve controls swirl control valve's shut/open condition. This solenoid valve is operated by the ECM.


Throttle position sensor (Idle position)	Engine speed	Swirl control valve control solenoid valve	Swirl control valve
ON	Below 3,200 rpm	ON	Closed
OFF	Less than 3,200 rpm	ON	Closed
	More than 3,600 rpm	OFF	Open

When engine coolant temperature is below 10°C (50°F) and above 55°C (131°F), swirl control valve is kept open regardless of above condition.



# DTC P1131 SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Description (Cont'd)



## COMPONENT DESCRIPTION

NFEC0823S02

### Swirl Control Valve Control Solenoid Valve

NFEC0823S0201

The swirl control valve control solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the solenoid valve is bypassed to apply intake manifold vacuum to the swirl control valve actuator. This operation closes the swirl control valve. When the ECM sends an OFF signal, the vacuum signal is cut and the swirl control valve opens.

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0824

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
SWRL CONT S/V	● Engine speed: Idle	ON
		OFF

## On Board Diagnosis Logic

NFEC0825

Malfunction is detected when an improper voltage signal is sent to ECM through swirl control valve control solenoid valve.

## Possible Cause

NFEC0826

- Harness or connectors  
(The swirl control valve control solenoid valve circuit is open or shorted.)
- Swirl control valve control solenoid valve

## DTC Confirmation Procedure

NFEC0827

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

## DTC P1131 SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

DTC Confirmation Procedure (Cont'd)

2	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

### WITH CONSULT-II

NFEC0827S04

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.  
If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-348.

### WITH GST

NFEC0827S05

Follow the procedure "With CONSULT-II" above.

# DTC P1131 SWIRL CONTROL VALVE CONTROL SOLENOID VALVE



Wiring Diagram

## Wiring Diagram

=NFEC0828


### EC-SWL/V-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)



MEC007D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
29	G	SWIRL CONTROL VALVE CONTROL SOLENOID VALVE	ENGINE RUNNING AT IDLE SPEED WITH ENGINE COOLANT TEMPERATURE BETWEEN 15°C (59°F) AND 50°C (122°F).	0 - 1V
			ENGINE RUNNING AT IDLE SPEED WITH ENGINE COOLANT TEMPERATURE ABOVE 55°C (131°F).	BATTERY VOLTAGE

SEF627XB

# DTC P1131 SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure

## Diagnostic Procedure



NFEC0829

<b>1</b>	<b>INSPECTION START</b>	
Do you have CONSULT-II?		
<b>Yes or No</b>		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

<b>2</b>	<b>CHECK SWIRL CONTROL VALVE CONTROL SOLENOID VALVE CIRCUIT</b>																			
<p>④ <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Select "SWIRL CONT SOL/V" in "ACTIVE TEST" mode with CONSULT-II.</li> <li>3. Touch "ON" and "OFF" on CONSULT-II screen.</li> </ol>																				
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <td style="width: 60%;">SWIRL CONT SOL/V</td> <td style="text-align: center;">OFF</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td style="text-align: center;">ENG SPEED</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td style="text-align: center;">IACV-AAC/V</td> <td style="text-align: center;">XXX step</td> </tr> <tr> <td> </td> <td> </td> </tr> </table>			ACTIVE TEST		SWIRL CONT SOL/V	OFF	MONITOR		ENG SPEED	XXX rpm	IACV-AAC/V	XXX step								
ACTIVE TEST																				
SWIRL CONT SOL/V	OFF																			
MONITOR																				
ENG SPEED	XXX rpm																			
IACV-AAC/V	XXX step																			
SEF069Y																				
4. Make sure that clicking sound is heard from the swirl control valve control solenoid valve.																				
<b>OK or NG</b>																				
OK	▶	GO TO 6.																		
NG	▶	GO TO 3.																		

# DTC P1131 SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>CHECK SWIRL CONTROL VALVE CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect swirl control valve control solenoid valve harness connector.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Intake manifold collector</p> <p style="margin-left: 100px;">Swirl control valve control solenoid valve</p> </div> <p style="text-align: right;">SEF272X</p> <p>3. Turn ignition switch "ON".                  4. Check voltage between swirl control valve control solenoid valve terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Voltage: Battery voltage</p> <p style="margin-left: 100px;">OK or NG</p> </div> <p style="text-align: right;">SEF619X</p>		
OK	▶	GO TO 5.
NG	▶	GO TO 4.

<b>4</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● 15A fuse</li> <li>● Harness for open or short between swirl control valve control solenoid valve and fuse</li> </ul>		
▶		Repair harness or connectors.

<b>5</b>	<b>CHECK SWIRL CONTROL VALVE CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect ECM harness connector.                  3. Check harness continuity between ECM terminal 29 and swirl control valve control solenoid valve terminal 2. Refer to Wiring Diagram.  <b>Continuity should exist.</b>                  4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 6.
NG	▶	Repair open circuit, short to ground or short to power in harness connectors.


# DTC P1131 SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)

## 6 CHECK SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

**Ⓟ With CONSULT-II**

1. Reconnect the disconnected harness connectors.
2. Start engine and let it idle.
3. Remove vacuum hose connected to swirl control valve actuator.
4. Select "SWIRL CONT SOL/V" in "ACTIVE TEST" mode with CONSULT-II.
5. Touch "ON" and "OFF" on CONSULT-II screen.
6. Check vacuum existence and operation delay time under the following conditions.




SWIRL CONT SOL/V	Vacuum
ON	should exist.
OFF	should not exist.

**Operation takes less than 1 second.**

SEF046Y

**ⓧ Without CONSULT-II**

1. Reconnect ECM harness connector.
2. Remove vacuum hose connected to swirl control valve actuator.
3. Start engine and let it idle.
4. Apply 12V of direct current between swirl control valve control solenoid valve terminals 1 and 2.
5. Check vacuum existence and operation delay time under the following conditions.



Condition	Vacuum
12V direct current supply	Should exist.
No supply	Should not exist.

**Operation takes less than 1 second.**

SEF047Y

**OK or NG**

OK	▶	GO TO 7.
NG	▶	Replace intake manifold collector assembly.

## 7 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.

	▶	<b>INSPECTION END</b>
--	---	-----------------------

# DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

System Description

## System Description

NFEC0554

### COOLING FAN CONTROL

NFEC0554S01

Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed sensor	Vehicle speed	Cooling fan control	Cooling fan relay(s)
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner "ON" signal		
Ignition switch	Start signal		
Refrigerant pressure sensor	Refrigerant pressure		


The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF].

### OPERATION

NFEC0554S02

#### VQ20DE Engine Models

NFEC0554S0203




## DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

CONSULT-II Reference Value in Data Monitor Mode

### VQ30DE Engine Models

NFEC0554S0204



### CONSULT-II Reference Value in Data Monitor Mode

NFEC0555

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates)	ON
COOLING FAN	● After warming up engine, idle the engine. ● Air conditioner switch: OFF	Engine coolant temperature is 94°C (201°F) or less	OFF
		Engine coolant temperature is between 95°C (203°F) and 104°C (219°F)	LOW
		Engine coolant temperature is 105°C (221°F) or more	HIGH

### On Board Diagnosis Logic

NFEC0557

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

Malfunction is detected when cooling fan does not operate properly (Overheat), cooling fan system does not operate properly (Overheat) and engine coolant was not added to the system using the proper filling method.

# DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Possible Cause

## Possible Cause

NFEC0563


- Harness or connectors  
(The cooling fan circuit is open or shorted.)
- Cooling fan
- Radiator hose
- Radiator
- Radiator cap
- Water pump
- Thermostat

For more information, refer to "MAIN 12 CAUSES OF OVERHEATING", EC-368.

### CAUTION:

When a malfunction is indicated, be sure to replace the coolant following the procedure in the MA-16, "Changing Engine Coolant". Also, replace the engine oil.

- 1) Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to MA-14, "Engine Coolant Mixture Ratio".
- 2) After refilling coolant, run engine to ensure that no water-flow noise is emitted.



## Overall Function Check

NFEC0558

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

### WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

### WITH CONSULT-II

NFEC0558S01




ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLANT TEMP/S	XXX °C

SEF111X

- 1) Check the coolant level in the reservoir tank and radiator.  
**Allow engine to cool before checking coolant level.**  
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-357.
- 2) Confirm whether the customer filled the coolant or not. If the customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-357.
- 3) Turn ignition switch "ON".
- 4) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
- 5) If the results are NG, go to "Diagnostic Procedure", EC-357.

## DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Overall Function Check (Cont'd)



### ⊗ WITHOUT CONSULT-II

NFEC0558S03

- 1) Check the coolant level in the reservoir tank and radiator.  
**Allow engine to cool before checking coolant level.**  
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-357.
- 2) Confirm whether the customer filled the coolant or not. If the customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-357.
- 3) Start engine.  
**Be careful not to overheat engine.**
- 4) Set temperature control lever to full cold position.
- 5) Turn air conditioner switch "ON".
- 6) Turn blower fan switch "ON".
- 7) Run engine at idle for a few minutes with the air conditioner operating.  
**Be careful not to overheat engine.**
- 8) Make sure the cooling fans are operating at low speeds.
- 9) Turn ignition switch "OFF".
- 10) Turn air conditioner switch and blower fan switch "OFF".
- 11) Disconnect engine coolant temperature sensor harness connector.
- 12) Connect 150Ω resistor to engine coolant temperature sensor harness connector.
- 13) Restart engine and make sure the cooling fans are operating at high speed.  
**Be careful not to overheat engine.**
- 14) If NG, go to "Diagnostic Procedure", EC-357.

# DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)


Wiring Diagram

## Wiring Diagram

NFEC0559


### EC-COOL/F-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



NEXT PAGE

- L : LHD MODELS
- R : RHD MODELS
- \*1 3: L
- 4: R
- \*2 7: L
- 9: R



REFER TO THE FOLLOWING.  
E83 - FUSE BLOCK-JUNCTION BOX (J/B)

101	102	1	2	3	4	5	6	7	8	9	10	58	59	60	61	62	63	64	65	66	67	109	110									
103	104	11	12	13	14	15	16	17	18	19	39	40	41	42	43	44	45	46	47	48	68	69	70	71	72	73	74	75	76	111	112	
105	106	20	21	22	23	24	25	26	27	28	29	49	50	51	52	53	54	55	56	57	77	78	79	80	81	82	83	84	85	86	113	114
107	108	30	31	32	33	34	35	36	37	38		87	88	89	90	91	92	93	94	95											115	116




MEC848C

# DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Wiring Diagram (Cont'd)

EC-COOL/F-02



MEC849C

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**  
DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
34	LG	COOLING FAN RELAY (HIGH)	ENGINE RUNNING WITH COOLING FAN NOT OPERATING	BATTERY VOLTAGE
			ENGINE RUNNING WITH COOLING FAN OPERATING AT HIGH SPEED	0 - 1.0V
35	BR/R	COOLING FAN RELAY (LOW)	ENGINE RUNNING WITH COOLING FAN NOT OPERATING	BATTERY VOLTAGE
			ENGINE RUNNING WITH COOLING FAN OPERATING AT LOW SPEED	0 - 1.0V

SEF630XB

# DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Diagnostic Procedure

## Diagnostic Procedure


NFEC0560

<b>1</b>	<b>INSPECTION START</b>	
Do you have CONSULT-II?		
<b>Yes or No</b>		
Yes	▶	GO TO 2.
No	▶	GO TO 4.

<b>2</b>	<b>CHECK COOLING FAN LOW SPEED OPERATION</b>	
----------	--	--

④ **With CONSULT-II**

1. Disconnect cooling fan relays-2 and -3.



SEC006C

2. Turn ignition switch "ON".
3. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.

ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLANT TEMP/S	XXX °C

SEF646X

4. Make sure that cooling fans-1 and -2 operate at low speed.

**OK or NG**

OK	▶	GO TO 3.
NG	▶	Check cooling fan low speed control circuit. (Go to PROCEDURE A, EC-363.)

## DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Diagnostic Procedure (Cont'd)

3	CHECK COOLING FAN HIGH SPEED OPERATION																				
<p>Ⓟ <b>With CONSULT-II</b></p> <ol style="list-style-type: none"><li>1. Turn ignition switch "OFF".</li><li>2. Reconnect cooling fan relays-2 and -3.</li><li>3. Turn ignition switch "ON".</li><li>4. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.</li></ol>																					
<table border="1" style="margin: auto; border-collapse: collapse;"><thead><tr><th colspan="2" style="text-align: center;">ACTIVE TEST</th></tr><tr><th style="text-align: center;">COOLING FAN</th><th style="text-align: center;">OFF</th></tr><tr><th colspan="2" style="text-align: center;">MONITOR</th></tr><tr><th style="text-align: center;">COOLAN TEMP/S</th><th style="text-align: center;">XXX °C</th></tr></thead><tbody><tr><td> </td><td> </td></tr><tr><td> </td><td> </td></tr><tr><td> </td><td> </td></tr><tr><td> </td><td> </td></tr><tr><td> </td><td> </td></tr><tr><td> </td><td> </td></tr></tbody></table>		ACTIVE TEST		COOLING FAN	OFF	MONITOR		COOLAN TEMP/S	XXX °C												
ACTIVE TEST																					
COOLING FAN	OFF																				
MONITOR																					
COOLAN TEMP/S	XXX °C																				
<p>5. Make sure that cooling fans-1 and -2 operate at high speed.</p>																					
<b>OK or NG</b>																					
OK	▶ GO TO 6.																				
NG	▶ Check cooling fan high speed control circuit. (Go to PROCEDURE B, EC-366.)																				

SEF111X


# DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Diagnostic Procedure (Cont'd)

## 4 CHECK COOLING FAN LOW SPEED OPERATION


⊗ Without CONSULT-II

1. Disconnect cooling fan relays-2 and -3.



SEC006C

2. Start engine and let it idle.
3. Set temperature lever at full cold position.
4. Turn air conditioner switch "ON".
5. Turn blower fan switch "ON".
6. Make sure that cooling fans-1 and -2 operate at low speed.




SEC163BA


OK or NG

OK	▶	GO TO 5.
NG	▶	Check cooling fan low speed control circuit. (Go to PROCEDURE A, EC-363.)

## DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Diagnostic Procedure (Cont'd)


<b>5</b>	<b>CHECK COOLING FAN HIGH SPEED OPERATION</b>	
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Reconnect cooling fan relays-2 and -3.</li> <li>3. Turn air conditioner switch and blower fan switch "OFF".</li> <li>4. Disconnect engine coolant temperature sensor harness connector.</li> <li>5. Connect 150Ω resistor to engine coolant temperature sensor harness connector.</li> <li>6. Restart engine and make sure that cooling fans-1 and -2 operate at high speed.</li> </ol>		
		
MEC475B		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	Check cooling fan high speed control circuit. (Go to PROCEDURE B, EC-366.)


<b>6</b>	<b>CHECK COOLING SYSTEM FOR LEAK</b>	
<p>Apply pressure to the cooling system with a tester, and check if the pressure drops.</p> <p style="color: blue;"><b>Testing pressure: 157 kPa (1.57 bar, 1.6 kg/cm<sup>2</sup>, 23 psi)</b></p> <p><b>CAUTION:</b> Higher than the specified pressure may cause radiator damage.</p>		
		
SLC754A		
<b>Pressure should not drop.</b>		
<b>OK or NG</b>		
OK	▶	GO TO 8.
NG	▶	GO TO 7.

<b>7</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following for leak.</p> <ul style="list-style-type: none"> <li>● Hose</li> <li>● Radiator</li> <li>● Water pump (Refer to LC-12, "Water Pump".)</li> </ul>		
▶ Repair or replace.		

## DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)



Diagnostic Procedure (Cont'd)

8		CHECK RADIATOR CAP
Apply pressure to cap with a tester and check radiator cap relief pressure.		
		
<b>Radiator cap relief pressure:</b> 59 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm <sup>2</sup> , 9 - 14 psi)		
SLC755A		
<b>OK or NG</b>		
OK	▶	GO TO 9.
NG	▶	Replace radiator cap.

9		CHECK THERMOSTAT
1. Remove thermostat. 2. Check valve seating condition at normal room temperatures. <b>It should seat tightly.</b> 3. Check valve opening temperature and valve lift.		
		
<b>Valve opening temperature:</b> 82°C (180°F) [standard]		
<b>Valve lift:</b> More than 8.6 mm/95°C (0.339 in/203°F)		
4. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to LC-16, "Thermostat".		
SLC343		
<b>OK or NG</b>		
OK	▶	GO TO 10.
NG	▶	Replace thermostat.

## DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Diagnostic Procedure (Cont'd)

10	CHECK ENGINE COOLANT TEMPERATURE SENSOR								
<p>1. Remove engine coolant temperature sensor.                      2. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.</p>									
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p><b>&lt;Reference data&gt;</b></p> <table border="1" style="border-collapse: collapse; margin: auto;"> <thead> <tr> <th style="text-align: center;">Temperature °C (°F)</th> <th style="text-align: center;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">20 (68)</td> <td style="text-align: center;">2.1 - 2.9</td> </tr> <tr> <td style="text-align: center;">50 (122)</td> <td style="text-align: center;">0.68 - 1.00</td> </tr> <tr> <td style="text-align: center;">90 (194)</td> <td style="text-align: center;">0.236 - 0.260</td> </tr> </tbody> </table> </div> <div style="text-align: center;">  </div> </div>		Temperature °C (°F)	Resistance kΩ	20 (68)	2.1 - 2.9	50 (122)	0.68 - 1.00	90 (194)	0.236 - 0.260
Temperature °C (°F)	Resistance kΩ								
20 (68)	2.1 - 2.9								
50 (122)	0.68 - 1.00								
90 (194)	0.236 - 0.260								
SEF304X									
<b>OK or NG</b>									
OK	▶ GO TO 11.								
NG	▶ Replace engine coolant temperature sensor.								


11	CHECK MAIN 12 CAUSES
If the cause cannot be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-368.	
	▶ <b>INSPECTION END</b>

# DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Diagnostic Procedure (Cont'd)

## PROCEDURE A


=NFEC0560S01

1	CHECK COOLING FAN POWER SUPPLY CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect cooling fan relay-1. 3. Turn ignition switch "ON". 4. Check voltage between cooling fan relay-1 terminals 1, 3, 6 and ground with CONSULT-II or tester.</p> <div data-bbox="335 436 734 739"></div> <p data-bbox="957 560 1276 593">Voltage: Battery voltage</p> <p data-bbox="1372 739 1468 772">SEF590X</p> <p data-bbox="734 784 861 817">OK or NG</p>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"><li>● 15A fuse</li><li>● 40A fusible links</li><li>● Harness for open or short between cooling fan relay-1 and fuse</li><li>● Harness for open or short between cooling fan relay-1 and battery</li></ul>	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

## DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Diagnostic Procedure (Cont'd)

3	<b>CHECK COOLING FAN GROUND CIRCUIT FOR OPEN AND SHORT</b>
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector.</p> <div style="text-align: center; margin: 10px 0;">  </div> <p>3. Check harness continuity between cooling fan relay-1 terminal 5 and cooling fan motor-1 terminal 2, cooling fan motor-1 terminal 3 and body ground. Refer to Wiring Diagram.  <b>Continuity should exist.</b></p> <p>4. Also check harness for short to ground and short to power.</p> <p>5. Check harness continuity between cooling fan relay-1 terminal 7 and cooling fan motor-2 terminal 2, cooling fan motor-2 terminal 3 and body ground. Refer to Wiring Diagram.  <b>Continuity should exist.</b></p> <p>6. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.


SEC007C


4	<b>CHECK COOLING FAN OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>
<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 35 and cooling fan relay-1 terminal 2. Refer to Wiring Diagram.  <b>Continuity should exist.</b></p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors E8, F17</li> <li>● Harness for open or short between cooling fan relay-1 and ECM</li> </ul>	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

# DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Diagnostic Procedure (Cont'd)

<b>6</b>	<b>CHECK COOLING FAN RELAY-1</b>	
Check continuity between cooling fan relay-1 terminals 3 and 5, 6 and 7 under the following conditions.		
		
SEF591X		
<b>OK or NG</b>		
OK	▶	GO TO 7.
NG	▶	Replace cooling fan relay.

<b>7</b>	<b>CHECK COOLING FAN MOTORS-1 AND -2</b>	
Supply battery voltage between the following terminals and check operation.		
		
SEF592X		
<b>OK or NG</b>		
OK	▶	GO TO 8.
NG	▶	Replace cooling fan motors.


<b>8</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", <a href="#">EC-126</a> .	
▶ <b>INSPECTION END</b>	

# DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Diagnostic Procedure (Cont'd)

## PROCEDURE B

NFEC0560S02

<b>1</b>	<b>CHECK COOLING FAN POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect cooling fan relays-2 and -3.                  3. Turn ignition switch "ON".                  4. Check voltage between cooling fan relays-2 and -3 terminals 1, 3 and ground with CONSULT-II or tester.</p>		
		
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	GO TO 2.

SEF593X

<b>2</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness for open or short between cooling fan relays-2 and -3 and fuse</li> <li>● Harness for open or short between cooling fan relays-2 and -3 and fusible link</li> </ul>		
▶		Repair harness or connectors.

<b>3</b>	<b>CHECK COOLING FAN GROUND CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector.                  3. Check harness continuity between cooling fan relay-2 terminal 5 and cooling fan motor-1 terminal 1, cooling fan relay-2 terminal 7 and cooling fan motor-1 terminal 4, cooling fan relay-2 terminal 6 and body ground. Refer to Wiring Diagram.  <span style="color: blue;"><b>Continuity should exist.</b></span>                  4. Also check harness for short to ground and short to power.                  5. Check harness continuity between cooling fan relay-3 terminal 5 and cooling fan motor-2 terminal 1, cooling fan relay-3 terminal 7 and cooling fan motor-2 terminal 4, cooling fan relay-3 terminal 6 and body ground. Refer to Wiring Diagram.  <span style="color: blue;"><b>Continuity should exist.</b></span>                  6. Also check harness for short to ground and short to power.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

<b>4</b>	<b>CHECK COOLING FAN OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Disconnect ECM harness connector.                  2. Check harness continuity between ECM terminal 34 and cooling fan relay-2 terminal 2, cooling fan relay-3 terminal 2. Refer to Wiring Diagram.  <span style="color: blue;"><b>Continuity should exist.</b></span>                  3. Also check harness for short to ground and short to power.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

# DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

Diagnostic Procedure (Cont'd)

## 5 DETECT MALFUNCTIONING PART


Check the following.

- Harness connectors E8, E17
- Harness for open or short between cooling fan relays-2 and -3 and ECM

▶ Repair open circuit or short to ground or short to power in harness or connectors.

## 6 CHECK COOLING FAN RELAYS-2 AND -3

Check continuity between cooling fan relay-2, -3 terminals 3 and 5, 6 and 7 under the following conditions.



Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

SEF591X


**OK or NG**

OK ▶ GO TO 7.

NG ▶ Replace cooling fan relays.

## 7 CHECK COOLING FAN MOTORS

Supply battery voltage between the following terminals and check operation.



	Speed	Terminals	
		(+)	(-)
Cooling fan motor-1	Low	2	3
	High	1, 2	3, 4
Cooling fan motor-2	Low	2	3
	High	1, 2	3, 4

SEF592X

**OK or NG**

OK ▶ GO TO 8.

NG ▶ Replace cooling fan motors.

## 8 CHECK INTERMITTENT INCIDENT

1. Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.

▶ **INSPECTION END**

## DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)

### Main 12 Causes of Overheating

### Main 12 Causes of Overheating

NFEC0561

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> <li>● Blocked radiator</li> <li>● Blocked condenser</li> <li>● Blocked radiator grille</li> <li>● Blocked bumper</li> </ul>	<ul style="list-style-type: none"> <li>● Visual</li> </ul>	No blocking	—
	2	<ul style="list-style-type: none"> <li>● Coolant mixture</li> </ul>	<ul style="list-style-type: none"> <li>● Coolant tester</li> </ul>	50 - 50% coolant mixture	See MA-13, "RECOMMENDED FLUIDS AND LUBRICANTS".
	3	<ul style="list-style-type: none"> <li>● Coolant level</li> </ul>	<ul style="list-style-type: none"> <li>● Visual</li> </ul>	Coolant up to MAX level in reservoir tank and radiator filler neck	See MA-16, "Changing Engine Coolant".
	4	<ul style="list-style-type: none"> <li>● Radiator cap</li> </ul>	<ul style="list-style-type: none"> <li>● Pressure tester</li> </ul>	59 - 98 kPa (0.59 - 1.0 bar, 0.6 - 1.0 kg/cm <sup>2</sup> , 9 - 14 psi) (Limit)	See LC-11, "System Check".
ON*2	5	<ul style="list-style-type: none"> <li>● Coolant leaks</li> </ul>	<ul style="list-style-type: none"> <li>● Visual</li> </ul>	No leaks	See LC-11, "System Check".
ON*2	6	<ul style="list-style-type: none"> <li>● Thermostat</li> </ul>	<ul style="list-style-type: none"> <li>● Touch the upper and lower radiator hoses</li> </ul>	Both hoses should be hot	See LC-16, "Thermostat" and LC-18, "Radiator".
ON*1	7	<ul style="list-style-type: none"> <li>● Cooling fan</li> </ul>	<ul style="list-style-type: none"> <li>● CONSULT-II</li> </ul>	Operating	See trouble diagnosis for DTC P1217 (EC-351).
OFF	8	<ul style="list-style-type: none"> <li>● Combustion gas leak</li> </ul>	<ul style="list-style-type: none"> <li>● Color checker chemical tester 4 Gas analyzer</li> </ul>	Negative	—
ON*3	9	<ul style="list-style-type: none"> <li>● Coolant temperature gauge</li> </ul>	<ul style="list-style-type: none"> <li>● Visual</li> </ul>	Gauge less than 3/4 when driving	—
		<ul style="list-style-type: none"> <li>● Coolant overflow to reservoir tank</li> </ul>	<ul style="list-style-type: none"> <li>● Visual</li> </ul>	No overflow during driving and idling	See MA-16, "Changing Engine Coolant".
OFF*4	10	<ul style="list-style-type: none"> <li>● Coolant return from reservoir tank to radiator</li> </ul>	<ul style="list-style-type: none"> <li>● Visual</li> </ul>	Should be initial level in reservoir tank	See MA-15, "ENGINE MAINTENANCE".
OFF	11	<ul style="list-style-type: none"> <li>● Cylinder head</li> </ul>	<ul style="list-style-type: none"> <li>● Straight gauge feeler gauge</li> </ul>	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-40, "Inspection".
	12	<ul style="list-style-type: none"> <li>● Cylinder block and pistons</li> </ul>	<ul style="list-style-type: none"> <li>● Visual</li> </ul>	No scuffing on cylinder walls or piston	See EM-60, "Inspection".

\*1: Turn the ignition switch ON.

\*2: Engine running at 3,000 rpm for 10 minutes.

\*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

\*4: After 60 minutes of cool down time.

For more information, refer to LC-23, "OVERHEATING CAUSE ANALYSIS".


## Component Description

NFEC0830

### IGNITION COIL & POWER TRANSISTOR

NFEC0830S01

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.



## On Board Diagnosis Logic

NFEC0831

Malfunction is detected when the ignition signal in the primary circuit is not sent to ECM during engine cranking or running.

## Possible Cause

NFEC0832

- Harness or connectors (The ignition primary circuit is open or shorted.)
- Power transistor unit built into ignition coil
- Condenser
- Crankshaft position sensor (REF)
- Crankshaft position sensor (REF) circuit

<b>3</b>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> </table>	DATA MONITOR		MONITOR	NO DTC	ENG SPEED	XXX rpm
DATA MONITOR							
MONITOR	NO DTC						
ENG SPEED	XXX rpm						

SEF058Y

## DTC Confirmation Procedure

NFEC0833

### NOTE:

- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.
- If DTC P1320 is displayed with DTC P0340, P1335 or P1336, perform trouble diagnosis for DTC P0340, P1335 or P1336 first. Refer to EC-303, EC-380 or EC-387.

### WITH CONSULT-II

NFEC0833S01

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.

## DTC P1320 IGNITION SIGNAL

DTC Confirmation Procedure (Cont'd)

---

- 3) Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-374.

### **WITHOUT CONSULT-II**

NFEC0833S03

- 1) Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-374.

# DTC P1320 IGNITION SIGNAL

Wiring Diagram

## Wiring Diagram

NFEC0834

### EC-IGN/SG-01

— : DETECTABLE LINE FOR DTC  
 — : NON-DETECTABLE LINE FOR DTC

REFER TO EL-POWER.

⬡ : LHD MODELS



⬢ : RHD MODELS

\*1 SB : ⬡

R/G : ⬢

\*2 R : ⬡

W/G : ⬢



101	102	1	2	3	4	5	6	7	8	9	10					58	59	60	61	62	63	64	65	66	67	109	110								
103	104	11	12	13	14	15	16	17	18	19					39	40	41	42	43	44	45	46	47	48	68	69	70	71	72	73	74	75	76	111	112
105	106	20	21	22	23	24	25	26	27	28	29				49	50	51	52	53	54	55	56	57	77	78	79	80	81	82	83	84	85	86	113	114
107	108	30	31	32	33	34	35	36	37	38															87	88	89	90	91	92	93	94	95	115	116



MEC050D





## DTC P1320 IGNITION SIGNAL

Wiring Diagram (Cont'd)

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN THE ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
21	Y/R	IGNITION SIGNAL NO. 1	ENGINE RUNNING AT IDLE SPEED UNDER THE WARM UP CONDITION	0 - 0.2V ★ 
22	G/R	IGNITION SIGNAL NO. 2		
23	L/R	IGNITION SIGNAL NO. 3		
30	GY	IGNITION SIGNAL NO. 4	ENGINE RUNNING AT 2,500 RPM	0 - 0.2V ★ 
31	PU/W	IGNITION SIGNAL NO. 5		
32	GY/R	IGNITION SIGNAL NO. 6		

★ : AVERAGE VOLTAGE FOR PULSE SIGNAL (ACUTUAL PULSE SIGNAL CAN BE CONFIRMED BY OSCILLOSCOPE.)

SEF860Y

## Diagnostic Procedure


NFEC0835


<b>1</b>	<b>CHECK ENGINE START</b>
Turn ignition switch "OFF", and restart engine. <b>Is engine running?</b>	
<b>Yes or No</b>	
Yes (With CONSULT-II) ►	GO TO 2.
Yes (Without CONSULT-II) ►	GO TO 12.
No ►	GO TO 3.

<b>2</b>	<b>SEARCH FOR MALFUNCTIONING CIRCUIT</b>																
<p> <b>With CONSULT-II</b></p> <p>1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.</p> <p>2. Search for circuit which does not produce a momentary engine speed drop.</p>																	
<table border="1"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>POWER BALANCE</td> <td></td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>MAS A/F SE-B1</td> <td>XXX V</td> </tr> <tr> <td>IACV-AAC/V</td> <td>XXX step</td> </tr> <tr> <td></td> <td></td> </tr> <tr> <td></td> <td></td> </tr> </tbody> </table>		ACTIVE TEST		POWER BALANCE		MONITOR		ENG SPEED	XXX rpm	MAS A/F SE-B1	XXX V	IACV-AAC/V	XXX step				
ACTIVE TEST																	
POWER BALANCE																	
MONITOR																	
ENG SPEED	XXX rpm																
MAS A/F SE-B1	XXX V																
IACV-AAC/V	XXX step																
SEF190Y																	
►	GO TO 12.																

## DTC P1320 IGNITION SIGNAL


Diagnostic Procedure (Cont'd)

<b>3</b>	<b>CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I</b>	
<p>1. Turn ignition switch ON. 2. Check voltage between ECM terminals 110, 112 and ground with CONSULT-II or tester.</p>		
 <p style="text-align: right;">Voltage: Battery voltage</p> <p style="text-align: right;">SEF366X</p>		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	Go to TROUBLE DIAGNOSIS FOR POWER SUPPLY, EC-127.


<b>4</b>	<b>CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II</b>	
<p>1. Turn ignition switch OFF. 2. Disconnect condenser harness connector.</p>		
 <p style="text-align: right;">Voltage: Battery voltage</p> <p style="text-align: right;">SEF275X</p>		
<p>3. Turn ignition switch ON. 4. Check voltage between condenser terminal 1 and ground with CONSULT-II or tester.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 10.
NG	▶	GO TO 5.

## DTC P1320 IGNITION SIGNAL

Diagnostic Procedure (Cont'd)

<b>5</b>	<b>CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III</b>	
<p>1. Turn ignition switch OFF. 2. Disconnect ECM relay.</p>		
		
<p>3. Check harness continuity between ECM relay terminal 7 and condenser terminal 1. Refer to Wiring Diagram. <b>Continuity should exist.</b></p> <p>4. Also check harness for short to ground and short to power.</p>		
SEF589PB		
<b>OK or NG</b>		
OK	▶	GO TO 7.
NG	▶	GO TO 6.


<b>6</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F18, E15</li> <li>● Harness for open or short between ECM relay and condenser</li> </ul>		
▶ Repair open circuit or short to ground or short to power in harness or connectors.		

<b>7</b>	<b>CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV</b>	
<p>Check voltage between ECM relay terminal 6 and ground with CONSULT-II or tester.</p>		
		
SEF368X		
<b>OK or NG</b>		
OK	▶	GO TO 9.
NG	▶	GO TO 8.


<b>8</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● 15A fuse</li> <li>● Harness for open and short between ECM relay and fuse</li> </ul>		
▶ Repair or replace harness or connectors.		

## DTC P1320 IGNITION SIGNAL

Diagnostic Procedure (Cont'd)




9	<b>CHECK ECM RELAY</b>								
1. Apply 12V direct current between ECM relay terminals 1 and 2. 2. Check continuity between ECM relay terminals 3 and 5, 6 and 7.									
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Condition</th> <th style="width: 40%;">Continuity</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>OFF</td> <td style="text-align: center;">No</td> </tr> </tbody> </table>	Condition	Continuity	12V direct current supply between terminals 1 and 2	Yes	OFF	No	SEF296X
Condition	Continuity								
12V direct current supply between terminals 1 and 2	Yes								
OFF	No								
<b>OK or NG</b>									
OK	▶	GO TO 17.							
NG	▶	Replace ECM relay.							

10	<b>CHECK CONDENSER GROUND CIRCUIT FOR OPEN AND SHORT</b>		
1. Turn ignition switch OFF. 2. Check harness continuity between condenser terminal 2 and engine ground. Refer to Wiring Diagram. <span style="color: blue;">Continuity should exist.</span> 3. Also check harness for short to power.			
<b>OK or NG</b>			
OK	▶	GO TO 11.	
NG	▶	Repair open circuit or short to power in harness or connectors.	

11	<b>CHECK CONDENSER</b>		
Check resistance between condenser terminals 1 and 2.			
		<b>Resistance: Above 1MΩ at 25°C (77°F)</b>	
			SEF369X
<b>OK or NG</b>			
OK	▶	GO TO 12.	
NG	▶	Replace condenser.	

## DTC P1320 IGNITION SIGNAL

Diagnostic Procedure (Cont'd)

<b>12</b>	<b>CHECK IGNITION COIL POWER SUPPLY CIRCUIT-V</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch OFF.</li> <li>2. Reconnect harness connectors disconnected.</li> <li>3. Disconnect ignition coil harness connector.</li> </ol>	
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>Oil filler cap</p> <p>Ignition coil (Bank 2) harness connector</p> </div> <div style="text-align: center;">  <p>Ignition coil (Bank 1) harness connector</p> <p>Intake manifold collector</p> </div> </div> <p style="text-align: right;">SEF274XA</p>	
<ol style="list-style-type: none"> <li>4. Turn ignition switch ON.</li> <li>5. Check voltage between ignition coil terminal 3 and ground with CONSULT-II or tester.</li> </ol>	
 <p style="margin-left: 100px;">Voltage: Battery voltage</p>	
OK or NG	
OK	▶ GO TO 14.
NG	▶ GO TO 13.


<b>13</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the harness for open or short between ignition coil and harness connector F18.	
▶	Repair or replace harness or connectors.

<b>14</b>	<b>CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch OFF.</li> <li>2. Check harness continuity between ignition coil terminal 2 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b></li> <li>3. Also check harness for short to power.</li> </ol>	
OK or NG	
OK	▶ GO TO 15.
NG	▶ Repair open circuit or short to power in harness or connectors.

## DTC P1320 IGNITION SIGNAL

Diagnostic Procedure (Cont'd)


<b>15</b>	<b>CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminals 21, 22, 23, 30, 31, 32 and ignition coil terminal 1. Refer to Wiring Diagram.  <span style="color: blue;">Continuity should exist.</span></p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 16.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

<b>16</b>	<b>CHECK IGNITION COIL WITH POWER TRANSISTOR</b>									
<p>Check resistance between ignition coil terminals 2 and 3.</p> <div style="display: flex; align-items: center;">  <table border="1" style="margin-left: 20px; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Terminals</th> <th style="text-align: center;">Resistance</th> <th style="text-align: center;">Result</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">2 and 3</td> <td style="text-align: center;">Not 0Ω</td> <td style="text-align: center;">OK</td> </tr> <tr> <td style="text-align: center;">0Ω</td> <td style="text-align: center;">NG</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-top: 10px;">SEF371X</p> <p style="text-align: center;"><b>OK or NG</b></p>			Terminals	Resistance	Result	2 and 3	Not 0Ω	OK	0Ω	NG
Terminals	Resistance	Result								
2 and 3	Not 0Ω	OK								
	0Ω	NG								
OK	▶	GO TO 17.								
NG	▶	Replace ignition coil with power transistor.								

<b>17</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.</p>		
▶		<b>INSPECTION END</b>

## DTC P1335 CRANKSHAFT POSITION SENSOR (CKPS) (REF)

### Component Description



### Component Description

NFEC0573

The crankshaft position sensor (REF) is located on the oil pan (upper) facing the crankshaft pulley. It detects the TDC (Top Dead Center) signal (120° signal).

The sensor consists of a permanent magnet, core and coil.

When engine is running, the gap between the sensor and the crankshaft pulley will periodically change. Permeability near the sensor also changes.

Due to the permeability change, the magnetic flux near the core is changed. Therefore, the voltage signal generated in the coil is changed.

The ECM receives the voltage signal and detects the TDC signal (120° signal).

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0574

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CKPS-RPM (POS)	<ul style="list-style-type: none"> <li>● Tachometer: Connect</li> <li>● Run engine and compare tachometer indication with the CONSULT-II value.</li> </ul>	Almost the same speed as the CONSULT-II value.
ENG SPEED		

### On Board Diagnosis Logic

NFEC0576

Malfunction is detected when

**(Malfunction A)** 120° signal is not entered to ECM for the first few seconds during engine cranking,

**(Malfunction B)** 120° signal is not entered to ECM during engine running,

**(Malfunction C)** 120° signal cycle excessively changes during engine running.

### FAIL-SAFE MODE

NFEC0576S01

When the ECM enters the fail-safe mode, the MI illuminates.

Detected items	Engine operating condition in fail-safe mode
Crankshaft position sensor (REF) circuit	Compression TDC signal (120° signal) is controlled by camshaft position sensor (PHASE) signal and crankshaft position sensor (POS) signal. Ignition timing will be delayed 0° to 2°.

# DTC P1335 CRANKSHAFT POSITION SENSOR (CKPS) (REF)

Possible Cause

## Possible Cause

NFEC0577

- Harness or connectors  
(The crankshaft position sensor (REF) circuit is open or shorted.)
- Crankshaft position sensor (REF)
- Starter motor (Refer to SC section.)
- Starting system circuit (Refer to SC section.)
- Dead (Weak) battery

## DTC Confirmation Procedure

NFEC0578

### NOTE:

- Perform “PROCEDURE FOR MALFUNCTION A” first. If 1st trip DTC cannot be confirmed, perform “PROCEDURE FOR MALFUNCTION B AND C”.
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

## PROCEDURE FOR MALFUNCTION A

NFEC0578S01

### With CONSULT-II

NFEC0578S0101

- 1) Turn ignition switch “ON”.
- 2) Select “DATA MONITOR” mode with CONSULT-II.
- 3) Crank engine for at least 2 seconds.
- 4) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-384.

### With GST

NFEC0578S0103

Follow the procedure “With CONSULT-II” above.

### No Tools

NFEC0578S0102

- 1) Crank engine for at least 2 seconds.
- 2) Turn ignition switch “OFF”, wait at least 10 seconds and then turn “ON”.
- 3) Perform “Diagnostic Test Mode II (Self-diagnostic results)” with ECM.
- 4) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-384.

2	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm
	VHCL SPEED SE	XXX km/h
	P/N POSI SW	OFF

SEF065Y

3	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

## PROCEDURE FOR MALFUNCTION B AND C

NFEC0578S02

### With CONSULT-II

NFEC0578S0201

- 1) Turn ignition switch “ON”.
- 2) Select “DATA MONITOR” mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed.
- 4) If 1st trip DTC is detected, go to “Diagnostic Procedure”, EC-384.

### With GST

NFEC0578S0203

Follow the procedure “With CONSULT-II” above.

## DTC P1335 CRANKSHAFT POSITION SENSOR (CKPS) (REF)

DTC Confirmation Procedure (Cont'd)

---



### No Tools

NFEC0578S0202

- 1) Start engine and run it for at least 2 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-384.




# DTC P1335 CRANKSHAFT POSITION SENSOR (CKPS) (REF)

Wiring Diagram

## Wiring Diagram

=NFE0579

EC-REF-01



MEC047D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
65 75	W W	CRANKSHAFT POSITION SENSOR (REF)	ENGINE RUNNING AT IDLE SPEED UNDER WARM-UP CONDITION	APPROX. 2.3V★ (AC VOLTAGE) (V)  10 ms

★ : AVERAGE VOLTAGE FOR PULSE SIGNAL (ACTUAL PULSE SIGNAL CAN BE CONFIRMED BY OSCILLOSCOPE.)


SEF861Y


# DTC P1335 CRANKSHAFT POSITION SENSOR (CKPS) (REF)

Diagnostic Procedure

## Diagnostic Procedure

=NFEC0580

<b>1</b>	<b>RETIGHTEN GROUND SCREWS</b>	
<p>1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.</p>		
 <p>The diagram shows a top-down view of an engine block. A circular oil filler cap is on the right. Several ground screws are attached to the engine block. One screw is highlighted with a red circle and a line pointing to the label 'Engine ground'. Another screw is labeled 'Oil filler cap'.</p>		
SEF255X		
▶		GO TO 2.

<b>2</b>	<b>CHECK CKPS (REF) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Disconnect CKPS (REF) harness connector.</p>		
 <p>The diagram shows the crankshaft pulley on the right. A harness connector is attached to the pulley. A line points from the label 'Crankshaft pulley' to the pulley. Another line points from the label 'Crankshaft position sensor (REF) harness connector' to the connector.</p>		
SEF591PA		
<p>2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminals 65, 75 and CKPS (REF) terminal 2. Refer to Wiring Diagram. <b>Continuity should exist.</b> 4. Also check harness for short to ground and short to power.</p>		
<b>OK or NG</b>		
OK ▶		GO TO 4.
NG ▶		GO TO 3.


<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F43, F191</li> <li>● Harness for open or short between crankshaft position sensor (REF) and ECM</li> </ul>		
▶		Repair open circuit or short to ground or short to power in harness or connectors.


## DTC P1335 CRANKSHAFT POSITION SENSOR (CKPS) (REF)

*Diagnostic Procedure (Cont'd)*

<b>4</b>	<b>CHECK CKPS (REF) GROUND CIRCUIT FOR OPEN AND SHORT</b>	
1. Turn ignition switch "OFF". 2. Check harness continuity between CKPS (REF) terminal 1 and engine ground. <b>Continuity should exist.</b> 3. Also check harness for short to power.		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

<b>5</b>	<b>DETECT MALFUNCTIONING PART</b>	
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors F43, F191</li> <li>● Harness for open or short between crankshaft position sensor (REF) and engine ground</li> </ul>		
▶		Repair open circuit or short to power in harness or connector.

<b>6</b>	<b>CHECK CKPS (REF)-I</b>	
1. Loosen the fixing bolts and remove the CKPS (REF). 2. Visually check the CKPS (REF) for chipping.		
		
SEF585P		
<b>OK or NG</b>		
OK	▶	GO TO 7.
NG	▶	Replace crankshaft position sensor (REF).

<b>7</b>	<b>CHECK CKPS (REF)-II</b>	
Check resistance between CKPS (REF) terminals 1 and 2.		
		
<b>Resistance: Approximately</b> <b>470 - 570 Ω</b> <b>[AT 20°C (68°F)]</b>		
SEF350X		
<b>OK or NG</b>		
OK	▶	GO TO 8.
NG	▶	Replace crankshaft position sensor (REF).

## DTC P1335 CRANKSHAFT POSITION SENSOR (CKPS) (REF)

Diagnostic Procedure (Cont'd)


8	<b>CHECK CKPS (REF) SHIELD CIRCUIT FOR OPEN AND SHORT</b>
1. Turn ignition switch "OFF". 2. Disconnect harness connectors F43, F191. 3. Check harness continuity between harness connector F43 terminal 4 and engine ground. <b>Continuity should exist.</b> 4. Also check harness for short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 10.
NG	▶ GO TO 9.

9	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"><li>● Harness connectors F43, F191</li><li>● Joint connector-18</li><li>● Harness for open or short between harness connector F43 and engine ground</li></ul>	
▶	Repair open circuit or short to power in harness or connectors.

10	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (POS) (COG)

Component Description



## Component Description

NFEC0292

The crankshaft position sensor (POS) is located on the oil pan facing the gear teeth (cogs) of the signal plate (flywheel). It detects the crankshaft position signal (1° signal).

The sensor consists of a permanent magnet, core and coil.

When engine is running, the gap between the sensor and the gear teeth (cogs) will periodically change. Permeability near the sensor also changes.

Due to the permeability change, the magnetic flux near the core is changed. Therefore, the voltage signal generated in the coil is changed.

The ECM receives the voltage signal and detects the crankshaft position signal (1° signal).

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0581

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CKPS-RPM (POS)	<ul style="list-style-type: none"><li>● Tachometer: Connect</li><li>● Run engine and compare tachometer indication with the CONSULT-II value.</li></ul>	Almost the same speed as the CONSULT-II value.
ENG SPEED		

## On Board Diagnosis Logic

NFEC0294

Malfunction is detected when chipping of the signal plate (flywheel or drive plate) gear tooth (cog) is detected by the ECM.

## Possible Cause

NFEC0582

- Harness or connectors
- Crankshaft position sensor (POS)
- Signal plate (Drive plate/Flywheel)

# DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (POS) (COG)

DTC Confirmation Procedure

## DTC Confirmation Procedure

NFEC0295

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V.

2	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

### WITH CONSULT-II

NFEC0295S01

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 70 seconds at idle speed.
- 3) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-390.

### WITH GST

NFEC0295S02

Follow the procedure "WITH CONSULT-II" above.

# DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (POS) (COG)

Wiring Diagram



## Wiring Diagram

NFEC0296

### EC-POS-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC

◁ L ▷ : LHD MODELS  
 ▷ R ◁ : RHD MODELS  
 \*1 SB: ◁ L ▷  
 R/G: ▷ R ◁



MEC850C



# DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (POS) (COG)

Wiring Diagram (Cont'd)

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:


DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
85	W	CRANKSHAFT POSITION SENSOR (POS)	ENGINE RUNNING AT IDLE SPEED UNDER WARM-UP CONDITION	APPROX. 2.4V 
			ENGINE RUNNING AT 2,000 RPM	APPROX. 2.3V 

SEF856Y



## Diagnostic Procedure

NFEC0297

<b>1</b>	<b>RETIGHTEN GROUND SCERWS</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Loosen and retighten engine ground screws.</li> </ol>	
	
SEF255X	
▶	GO TO 2.

# DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (POS) (COG)

Diagnostic Procedure (Cont'd)

<b>2</b>	<b>CHECK CKPS (POS) POWER SUPPLY CIRCUIT</b>	
<p>1. Disconnect harness connectors F25, F171.</p> <div style="text-align: center;">  </div>		
SEF511WB		
<p>2. Check voltage between harness connector F25 terminal 4 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div>		
SEF323X		
<p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 4.
NG	▶	GO TO 3.


<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F25, F171</li> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between ECM and crankshaft position sensor (POS)</li> <li>● Harness for open or short between ECM relay and crankshaft position sensor (POS)</li> </ul>	
▶	Repair open circuit or short to ground or short to power in harness or connectors.


<b>4</b>	<b>CHECK CKPS (POS) GROUND CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Check harness continuity between harness connector F25 terminal 2 and engine ground. Refer to Wiring Diagram.  <span style="color: blue;">Continuity should exist.</span></p> <p>2. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 5.
NG	▶	Repair open circuit or short to power in harness or connectors.

## DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (POS) (COG)

Diagnostic Procedure (Cont'd)

<b>5</b>	<b>CHECK CKPS (POS) INPUT SIGNAL CIRCUIT</b>	
	1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 85 and harness connector F25 terminal 1. Refer to Wiring Diagram. <b>Continuity should exist.</b> 3. Also check harness for short to ground and short to power.	
	<b>OK or NG</b>	
OK	▶	GO TO 6.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.


<b>6</b>	<b>CHECK CKPS (POS) SUB-HARNESS CIRCUIT FOR OPEN AND SHORT</b>									
	1. Disconnect CKPS (POS) harness connector.									
										
	2. Check harness continuity between CKPS (POS) terminals and harness connector F171 terminals as follows.									
	<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>CKPS (POS) terminal</th> <th>Harness connector F171 terminal</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">4</td> </tr> </tbody> </table>		CKPS (POS) terminal	Harness connector F171 terminal	1	2	2	1	3	4
CKPS (POS) terminal	Harness connector F171 terminal									
1	2									
2	1									
3	4									
	SEF367Q									
	<b>Continuity should exist.</b>									
	3. Also check harness for short to ground and short to power.									
	<b>OK or NG</b>									
OK	▶	GO TO 7.								
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.								
	MTBL0352									


<b>7</b>	<b>CHECK CKPS (POS) INSTALLATION</b>	
	Check that CKPS (POS) and HO2S1 bank 2 harness clamp are installed correctly as shown below.	
		
	<b>OK or NG</b>	
OK	▶	GO TO 8.
NG	▶	Install CKPS (POS) correctly.
	SEM222FE	

# DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (POS) (COG)

Diagnostic Procedure (Cont'd)

<b>8</b>	<b>CHECK IMPROPER INSTALLATION</b>	
<ol style="list-style-type: none"> <li>1. Loosen and retighten the fixing bolt of the crankshaft position sensor (POS).</li> <li>2. Reconnect harness connectors disconnected.</li> <li>3. Perform "DTC Confirmation Procedure", EC-388 again.</li> </ol> <p style="text-align: center;"><b>Is a 1st trip DTC P1336 detected?</b></p>		
Yes	▶	GO TO 9.
No	▶	<b>INSPECTION END</b>

<b>9</b>	<b>CHECK CRANKSHAFT POSITION SENSOR (POS)</b>	
<ol style="list-style-type: none"> <li>1. Disconnect crankshaft position sensor (POS) harness connector.</li> <li>2. Loosen the fixing bolt of the sensor.</li> <li>3. Remove the sensor.</li> <li>4. Visually check the sensor for chipping.</li> </ol>		
		
SEF587P		
<b>OK or NG</b>		
OK	▶	GO TO 10.
NG	▶	Replace crankshaft position sensor (POS).

<b>10</b>	<b>CHECK CRANKSHAFT POSITION SENSOR (POS)-II</b>									
<ol style="list-style-type: none"> <li>1. Reconnect harness connectors disconnected.</li> <li>2. Turn ignition switch ON.</li> <li>3. Check voltage between ECM terminal 85 and ground by briefly touching the sensor core with a flat-bladed screwdriver.</li> </ol>										
<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;">  </div> <div style="flex: 1; margin-left: 20px;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>ECM terminal</th> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td rowspan="2">85</td> <td>Contacted</td> <td>Approximately 5V</td> </tr> <tr> <td>Pulled away</td> <td>Approximately 0V</td> </tr> </tbody> </table> <p style="text-align: left; margin-top: 10px;"><b>There should be a steady 5V as the flat-bladed screwdriver is drawn away slowly.</b></p> </div> </div>			ECM terminal	Condition	Voltage	85	Contacted	Approximately 5V	Pulled away	Approximately 0V
ECM terminal	Condition	Voltage								
85	Contacted	Approximately 5V								
	Pulled away	Approximately 0V								
SEF324X										
<b>OK or NG</b>										
OK	▶	GO TO 11.								
NG	▶	Replace crankshaft position sensor (POS).								

## DTC P1336 CRANKSHAFT POSITION SENSOR (CKPS) (POS) (COG)

Diagnostic Procedure (Cont'd)

<b>11</b>	<b>CHECK CKPS (POS) SHIELD CIRCUIT FOR OPEN AND SHORT</b>
1. Disconnect harness connectors F25, F171. 2. Check harness continuity between harness connector F25 terminal 3 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b> 3. Also check harness for short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 13.
NG	▶ GO TO 12.

<b>12</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"><li>● Harness connectors F25, F171</li><li>● Joint connector-18</li><li>● Harness for open or short between harness connector F25 and engine ground</li></ul>	
	▶ Repair open circuit or short to power in harness or connectors.

<b>13</b>	<b>CHECK GEAR TOOTH</b>
Visually check for chipping signal plate (flywheel or drive plate) gear tooth (cog).	
<b>OK or NG</b>	
OK	▶ GO TO 14.
NG	▶ Replace the signal plate (flywheel or drive plate).

<b>14</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
	▶ <b>INSPECTION END</b>

# DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

Component Description

## Component Description

The malfunction information related to A/T (Automatic Transmission) is transferred through the line (circuit) from TCM (Transmission control module) to ECM. Therefore, be sure to erase the malfunction information such as DTC not only in TCM (Transmission control module) but also ECM after the A/T related repair.

NFEC0849

## On Board Diagnosis Logic

Malfunction is detected when an incorrect signal from TCM (Transmission control module) is sent to ECM.

NFEC0850

## Possible Cause

- Harness or connectors  
[The communication line circuit between ECM and TCM (Transmission control module) is open or shorted.]
- Dead (Weak) battery
- TCM (Transmission control module)

NFEC0851

3	DATA MONITOR	
	MONITOR	NO DTC
	ENG SPEED	XXX rpm

SEF058Y

## DTC Confirmation Procedure

### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

### TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

### WITH CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 40 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-397.

NFEC0852S01

### WITH GST

Follow the procedure "WITH CONSULT-II" above.

NFEC0852S02




# DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

Wiring Diagram

## Wiring Diagram

=NFEC0853

### EC-ATDIAG-01



MEC009D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
60	BR/W	A/T DIAGNOSIS COMMUNICATION LINE	ENGINE RUNNING AT IDLE SPEED	VOLTAGE FLUCTUATES BETWEEN 0 to 2V.



SEF048YA

# DTC P1605 A/T DIAGNOSIS COMMUNICATION LINE

Diagnostic Procedure

## Diagnostic Procedure


NFEC0854

<b>1</b>	<b>CHECK A/T DIAGNOSIS COMMUNICATION LINE INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect ECM harness connector and TCM (Transmission Control Module) harness connector.</p>		
<p><b>View with glove box removed</b></p>  <p style="text-align: center;">ECM</p>		
SEF270X		
<p><b>View with center console removed</b></p>  <p style="text-align: right;">TCM</p>		
SEF271X		
<p>3. Check harness continuity between ECM terminal 60 and TCM terminal 15. Refer to Wiring Diagram.  <span style="color: blue;"><b>Continuity should exist.</b></span></p> <p>4. Also check harness for short to ground and short to power.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 2.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

<b>2</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

## DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

### Component Description



### Component Description

NFEC0855

When the gear position is "P" (A/T models only) or "N", park/neutral position (PNP) switch is "ON".

ECM detects the position because the continuity of the line (the "ON" signal) exists.

For A/T models, the park/neutral position (PNP) switch assembly also includes a transmission range switch to detect selector lever position.

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0856

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: "P" or "N"	ON
		Except above	OFF

### On Board Diagnosis Logic

NFEC0857

Malfunction is detected when the signal of the park/neutral position (PNP) switch is not changed in the process of engine starting and driving.

### Possible Cause

NFEC0858

- Harness or connectors  
[The park/neutral position (PNP) switch circuit is open or shorted.]
- Park/neutral position (PNP) switch

### DTC Confirmation Procedure

NFEC0859

#### CAUTION:

Always drive vehicle at a safe speed.

#### NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

# DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

DTC Confirmation Procedure (Cont'd)

2

DATA MONITOR	
MONITOR	NO DTC
P/N POSI SW	ON

SEF212Y

## WITH CONSULT-II

NFEC0859S01

- 1) Turn ignition switch "ON".
- 2) Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. Then check the "P/N POSI SW" signal under the following conditions.

Position (Selector lever)	Known-good signal
"N" and "P" position	ON
Except the above position	OFF

If NG, go to "Diagnostic Procedure", EC-401.

If OK, go to following step.

- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Start engine and warm it up to normal operating temperature.
- 5) Maintain the following conditions for at least 60 consecutive seconds.


ENG SPEED	1,400 - 4,000 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	2 - 10 msec
VHCL SPEED SE	More than 65 km/h (40 MPH)
Selector lever	Suitable position

- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-401.

5

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF
B/FUEL SCHDL	XXX msec

SEF213Y



## Overall Function Check

NFEC0860

Use this procedure to check the overall function of the park/neutral position (PNP) switch circuit. During this check, a 1st trip DTC might not be confirmed.

## WITH GST

NFEC0860S01

- 1) Turn ignition switch "ON".
- 2) Check voltage between ECM terminal 44 and body ground under the following conditions.

Condition (Gear position)	Voltage V (Known good data)
"P" and "N" position	Approx. 0
Except the above position	Battery voltage

- 3) If NG, go to "Diagnostic Procedure", EC-401.

# DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH



Wiring Diagram

## Wiring Diagram

NFEC0861

### EC-PNP/SW-01

- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- : WITH A/T
- : WITH M/T



MEC212D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
44	G/OR (A/T) G/W (M/T)	PARK/NEUTRAL POSITION (PNP) SWITCH	IGN ON WITH GEAR POSITION "N" OR "P"(A/T), GEAR POSITION NEUTRAL (M/T)	APPROX. 0V
			IGN ON WITHOUT THE ABOVE GEAR POSITION	BATTERY VOLTAGE

SEF635XC


# DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure

## Diagnostic Procedure FOR M/T MODELS

NFEC0862

NFEC0862S01

1 CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT	
1. Turn ignition switch "OFF". 2. Disconnect park/neutral position (PNP) switch harness connector.	
 <p>Park/neutral position (PNP) switch</p>	
3. Check harness continuity between PNP switch terminal 4 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b>	
4. Also check harness for short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 2.
NG	▶ Repair open circuit or short to power in harness or connectors.

AEC877A

2 CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT	
1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 44 and PNP switch terminal 3. Refer to Wiring Diagram. <b>Continuity should exist.</b>	
3. Also check harness for short to ground and short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 3.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

3 CHECK PARK/NEUTRAL POSITION (PNP) SWITCH	
Refer to MT-9, "Position Switch Check".	
<b>OK or NG</b>	
OK	▶ GO TO 4.
NG	▶ Replace park/neutral position (PNP) switch.


4 CHECK INTERMITTENT INCIDENT	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
	▶ <b>INSPECTION END</b>

## DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure (Cont'd)

### FOR A/T MODELS

=NFEC0862S02

<b>1</b>	<b>CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect park/neutral position (PNP) switch harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF279X</p> <p>3. Check harness continuity between PNP switch terminal 2 and engine ground. Refer to Wiring Diagram.  <span style="color: blue;">Continuity should exist.</span></p> <p>4. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 3.
NG	▶	GO TO 2.

<b>2</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F10, F151</li> <li>● Harness for open or short between park/neutral position (PNP) switch and engine ground</li> </ul>		
		▶ Repair open circuit or short to power in harness or connectors.

<b>3</b>	<b>CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Disconnect ECM harness connector.                  2. Check harness continuity between ECM terminal 44 and PNP switch terminal 1. Refer to Wiring Diagram.  <span style="color: blue;">Continuity should exist.</span></p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 5.
NG	▶	GO TO 4.

<b>4</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F10, F151</li> <li>● Harness for open or short between ECM and park/neutral position (PNP) switch</li> </ul>		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.

<b>5</b>	<b>CHECK PARK/NEUTRAL POSITION (PNP) SWITCH</b>	
<p>Refer to AT-125, "Diagnostic Procedure".</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 6.
NG	▶	Replace park/neutral position (PNP) switch.


## DTC P1706 PARK/NEUTRAL POSITION (PNP) SWITCH

*Diagnostic Procedure (Cont'd)*

<b>6</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# ABSOLUTE PRESSURE SENSOR


## Component Description



## Component Description

NFEC0644

The absolute pressure sensor detects ambient barometric pressure and sends the voltage signal to the ECM. As the pressure increases, the voltage rises.



# ABSOLUTE PRESSURE SENSOR





Wiring Diagram

## Wiring Diagram

NFEC0648

### EC-AP/SEN-01

- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- A : WITH A/T



MEC049D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**  
DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
80	W	ABSOLUTE PRESSURE SENSOR	IGN ON	APPROX. 4.4V
111	R	SENSORS' POWER SUPPLY	IGN ON	APPROX. 5V
58	B	SENSORS' GROUND	IGN ON	APPROX. 0V


SEF651XB


# ABSOLUTE PRESSURE SENSOR

Diagnostic Procedure

## Diagnostic Procedure


NFEC0647

<b>1</b>	<b>CHECK OVERALL FUNCTION</b>
<ol style="list-style-type: none"><li>1. Turn ignition switch "ON".</li><li>2. Check voltage between ECM terminal 80 and ground with CONSULT-II or tester.</li></ol>	
 <p>Voltage: 1.0 - 5.0V</p>	
SEF055Y	
OK or NG	
OK	▶ <b>INSPECTION END</b>
NG	▶ GO TO 2.



<b>2</b>	<b>RETIGHTEN GROUND SCREWS</b>
<ol style="list-style-type: none"><li>1. Turn ignition switch "OFF".</li><li>2. Loosen and retighten engine ground screws.</li></ol>	
	
SEF255X	
▶ GO TO 3.	

## ABSOLUTE PRESSURE SENSOR

Diagnostic Procedure (Cont'd)

3	CHECK ABSOLUTE PRESSURE SENSOR CONNECTOR FOR WATER
<p>1. Disconnect absolute pressure sensor harness connector.</p> <div style="text-align: center;">  </div>	
<p>2. Check sensor harness connector for water. <b>Water should not exist.</b></p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 4.
NG	▶ Repair or replace harness connector.

SEF257X

4	CHECK ABSOLUTE PRESSURE SENSOR POWER SUPPLY CIRCUIT
<p>1. Turn ignition switch "ON".</p> <p>2. Check voltage between absolute pressure sensor terminal 1 and ground with CONSULT-II or tester.</p>	
<div style="display: flex; justify-content: center; align-items: center; gap: 20px;">  </div> <div style="text-align: center; margin-top: 20px;">  <p style="margin-top: 10px;"><b>Voltage: Approximately 5V</b></p> </div>	
<b>OK or NG</b>	
OK	▶ GO TO 5.
NG	▶ Repair harness or connectors.

SEF299X

5	CHECK ABSOLUTE PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF".</p> <p>2. Check harness continuity between absolute pressure sensor terminal 3 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b></p> <p>3. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 7.
NG	▶ GO TO 6.

## ABSOLUTE PRESSURE SENSOR

Diagnostic Procedure (Cont'd)

<b>6</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness for open or short between ECM and absolute pressure sensor</li> <li>● Harness for open or short between TCM (Transmission Control Module) and absolute pressure sensor</li> </ul>	
▶	Repair open circuit or short to power in harness or connectors.

<b>7</b>	<b>CHECK ABSOLUTE PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>
1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 80 and absolute pressure sensor terminal 2. <b>Continuity should exist.</b> 3. Also check harness for short to ground and short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 8.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

<b>8</b>	<b>CHECK ABSOLUTE PRESSURE SENSOR</b>						
1. Remove absolute pressure sensor with its harness connector connected. 2. Remove hose from absolute pressure sensor. 3. Install a vacuum pump to absolute pressure sensor. 4. Turn ignition switch "ON" and check output voltage between ECM terminal 80 and engine ground under the following conditions.							
<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> </div> <div style="flex: 1; margin-left: 20px;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="padding: 5px;">Applied vacuum kPa (mbar, mmHg, inHg)</th> <th style="padding: 5px;">Voltage V</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">Not applied</td> <td style="padding: 5px;">3.2 - 4.8</td> </tr> <tr> <td style="padding: 5px;">-26.7 (-267, -200, -7.87)</td> <td style="padding: 5px;">1.0 to 1.4V lower than above value</td> </tr> </tbody> </table> </div> </div>		Applied vacuum kPa (mbar, mmHg, inHg)	Voltage V	Not applied	3.2 - 4.8	-26.7 (-267, -200, -7.87)	1.0 to 1.4V lower than above value
Applied vacuum kPa (mbar, mmHg, inHg)	Voltage V						
Not applied	3.2 - 4.8						
-26.7 (-267, -200, -7.87)	1.0 to 1.4V lower than above value						
SEF300XB							
<b>CAUTION:</b>							
<ul style="list-style-type: none"> <li>● Always calibrate the vacuum pump gauge when using it.</li> <li>● Do not apply below -93.3 kPa (-933 bar, -700 mmHg, -27.56 inHg) or over 101.3 kPa (1,013 bar, 760 mmHg, 29.92 inHg) of pressure.</li> </ul>							
<b>OK or NG</b>							
OK	▶ GO TO 9.						
NG	▶ Replace absolute pressure sensor.						

## ABSOLUTE PRESSURE SENSOR



*Diagnostic Procedure (Cont'd)*

9	CHECK ABSOLUTE PRESSURE SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect joint connector-18.</p> <p>3. Check the following.</p> <ul style="list-style-type: none"><li>● Continuity between joint connector terminal 2 and ground Refer to Wiring Diagram.</li><li>● Joint connector (Refer to EL-377, "HARNESS LAYOUT".) <b>Continuity should exist.</b></li></ul> <p>4. Also check harness for short to power.</p> <p>5. Then reconnect joint connector-18.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 10.
NG	▶ Repair open circuit or short to power in harness or connectors.

10	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# INTAKE AIR TEMPERATURE SENSOR

## Component Description



## Component Description

NFEC0064

The intake air temperature sensor is mounted to the air duct housing. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.

### <Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
20 (68)	3.5	2.1 - 2.9
80 (176)	1.23	0.27 - 0.38

\*: These data are reference values and are measured between ECM terminal 64 (Intake air temperature sensor) and ground.

### CAUTION:

**Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.**




# INTAKE AIR TEMPERATURE SENSOR

Wiring Diagram

## Wiring Diagram

NFEC0067

### EC-IATSEN-01




MEC064D



# INTAKE AIR TEMPERATURE SENSOR

Diagnostic Procedure

## Diagnostic Procedure

NFEC0068

<b>1</b>	<b>CHECK OVERALL FUNCTION</b>		
<p>1. Turn ignition switch "ON".                  2. Check voltage between ECM terminal 64 and ground with CONSULT-II or tester.</p>			
 <p style="text-align: right;"><b>Voltage: 0.05 - 4.8V</b></p>			
SEF004Y			
<b>OK or NG</b>			
OK	▶	<b>INSPECTION END</b>	
NG	▶	GO TO 2.	

<b>2</b>	<b>CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT</b>		
<p>1. Turn ignition switch "OFF".                  2. Disconnect intake air temperature sensor harness connector.</p>			
			
SEF258X			
<p>3. Turn ignition switch "ON".                  4. Check voltage between terminal 1 and ground.</p>			
 <p style="text-align: right;"><b>Voltage: Approximately 5V</b></p>			
SEF301X			
<b>OK or NG</b>			
OK	▶	GO TO 4.	
NG	▶	GO TO 3.	



# INTAKE AIR TEMPERATURE SENSOR

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors E8, F17</li> <li>● Harness for open or short between ECM and intake air temperature sensor</li> </ul>	
▶	Repair harness or connectors.

<b>4</b>	<b>CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT</b>
1. Turn ignition switch "OFF". 2. Check harness continuity between sensor terminal 2 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b>	
3. Also check harness for short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

<b>5</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors E8, F17</li> <li>● Harness for open or short between ECM and intake air temperature sensor</li> <li>● Harness for open or short between TCM (Transmission Control Module) and intake air temperature sensor</li> </ul>	
▶	Repair open circuit or short to power in harness or connectors.

<b>6</b>	<b>CHECK INTAKE AIR TEMPERATURE SENSOR</b>						
Check resistance between intake air temperature sensor terminals 1 and 2 as shown in the figure.							
	<p><b>&lt;Reference data&gt;</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Temperature °C (°F)</th> <th style="text-align: center;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">20 (68)</td> <td style="text-align: center;">2.1 - 2.9</td> </tr> <tr> <td style="text-align: center;">80 (176)</td> <td style="text-align: center;">0.27 - 0.38</td> </tr> </tbody> </table>	Temperature °C (°F)	Resistance kΩ	20 (68)	2.1 - 2.9	80 (176)	0.27 - 0.38
Temperature °C (°F)	Resistance kΩ						
20 (68)	2.1 - 2.9						
80 (176)	0.27 - 0.38						
							
SEF302X							
<b>OK or NG</b>							
OK	▶ GO TO 7.						
NG	▶ Replace intake air temperature sensor.						


## INTAKE AIR TEMPERATURE SENSOR

Diagnostic Procedure (Cont'd)

<b>7</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

## HEATED OXYGEN SENSOR 1 (FRONT)


Component Description



### Component Description

NFEC0108

The heated oxygen sensor 1 (front) is placed into the front tube. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 (front) has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 (front) signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



### CONSULT-II Reference Value in Data Monitor Mode

NFEC0109

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)			0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	<ul style="list-style-type: none"> <li>Engine: After warming up</li> </ul>	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

# HEATED OXYGEN SENSOR 1 (FRONT)

Wiring Diagram

## Wiring Diagram



NFEC0114

NFEC0114S01

**BANK 1**

**EC-FRO2RH-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

M19 - FUSE BLOCK-JUNCTION BOX (J/B)

MEC306D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
63	W	HEATED OXYGEN SENSOR 1 (FRONT) (BANK 1)	ENGINE RUNNING AT 2,000 RPM AFTER WARMING UP TO NORMAL OPERATING TEMPERATURE	0 - APPROX. 1.0V 

SEF854YC

# HEATED OXYGEN SENSOR 1 (FRONT)



Wiring Diagram (Cont'd)

**BANK 2**

NFEC0114S02

## EC-FRO2LH-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC307D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
62	W	HEATED OXYGEN SENSOR 1 (FRONT) (BANK 2)	ENGINE RUNNING AT 2,000 RPM AFTER WARMING UP TO NORMAL OPERATING TEMPERATURE	0 - APPROX. 1.0V 

SEF855YC

# HEATED OXYGEN SENSOR 1 (FRONT)


Diagnostic Procedure

## Diagnostic Procedure

NFEC0115


<b>1</b>	<b>INSPECTION START</b>	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

<b>2</b>	<b>CHECK OVERALL FUNCTION</b>											
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>Start engine and warm it up to normal operating temperature.</li> <li>Select "HO2S1 MNTR (B1)" and "HO2S1 MNTR (B2)" in "DATA MONITOR" mode with CONSULT-II.</li> <li>Keep the engine speed at 2,000 rpm under no load, and make sure that the monitors fluctuate between LEAN and RICH more than five times in 10 seconds.</li> </ol>												
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>HO2S1 MNTR (B1)</td> <td>LEAN</td> </tr> <tr> <td>HO2S1 MNTR (B2)</td> <td>RICH</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	ENG SPEED	XXX rpm	HO2S1 MNTR (B1)	LEAN	HO2S1 MNTR (B2)	RICH
DATA MONITOR												
MONITOR	NO DTC											
ENG SPEED	XXX rpm											
HO2S1 MNTR (B1)	LEAN											
HO2S1 MNTR (B2)	RICH											
<p><b>1 time: RICH → LEAN → RICH</b>  <b>2 times: RICH → LEAN → RICH → LEAN → RICH</b></p>												
SEF155Z												
OK or NG												
OK	▶	<b>INSPECTION END</b>										
NG	▶	GO TO 4.										




<b>3</b>	<b>CHECK OVERALL FUNCTION</b>	
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>Start engine and warm it up to normal operating temperature.</li> <li>Stop engine and wait at least 10 seconds.</li> <li>Set ECM in "Diagnostic test mode II [Heated oxygen sensor 1 monitor (front)]". Refer to "How to Switch Diagnostic Test Modes", EC-62.</li> <li>Keep the engine speed at 2,000 rpm under no load, and make sure that the MI comes ON more than five times in 10 seconds.</li> </ol>		
		
SAT652J		
<ol style="list-style-type: none"> <li>Switch the monitored sensor. Refer to "How to Switch Monitored Sensor from Bank 1 to Bank 2 or Vice Versa", EC-64.</li> <li>Perform step 4 again.</li> </ol>		
OK or NG		
OK	▶	<b>INSPECTION END</b>
NG	▶	GO TO 4.

## HEATED OXYGEN SENSOR 1 (FRONT)

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>RETIGHTEN GROUND SCREWS</b>
<ol style="list-style-type: none"><li>1. Turn ignition switch "OFF".</li><li>2. Loosen and retighten engine ground screws.</li></ol>	
 <p>The diagram shows a top-down view of the engine block. Two screws are labeled 'Engine ground'. A circular cap is labeled 'Oil filler cap'.</p>	
SEF255X	
▶ GO TO 5.	

<b>5</b>	<b>RETIGHTEN HEATED OXYGEN SENSOR 1 (FRONT)</b>
Loosen and retighten corresponding heated oxygen sensor 1 (front).	
<b>Tightening torque:</b> <b>40 - 60 N·m (4.1 - 6.1 kg·m, 30 - 44 ft·lb)</b>	
▶ GO TO 6.	

<b>6</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) HARNESS PROTECTOR COLOR</b>
<ol style="list-style-type: none"><li>1. Turn ignition switch "OFF".</li><li>2. Check heated oxygen sensor 1 (front) harness protector.</li></ol>	
 <p>The diagram shows a long, thin cylindrical component labeled 'HO2S1 (front)' with a connector at one end. Below it, the text reads 'HO2S1 (front) harness protector color'.</p>	
HO2S1 (front) (bank 1): Black HO2S1 (front) (bank 2): Blue	
SEF505YA	
3. Disconnect corresponding heated oxygen sensor 1 (front) harness connector.	
 <p>The diagram shows the engine compartment with a label 'Heated oxygen sensor 1 (front) (bank 2) harness connector'. A 'V6 3000 TWIN CAM 24VALVE' engine is shown. An arrow points to the 'Front'.</p>	 <p>The diagram shows the engine compartment with a label 'Heated oxygen sensor 1 (front) (bank 1) harness connector'.</p>
SEF902XA	
▶ GO TO 7.	

## HEATED OXYGEN SENSOR 1 (FRONT)

Diagnostic Procedure (Cont'd)


<b>7</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>												
<p>1. Disconnect ECM harness connector.                  2. Check harness continuity between ECM terminal and HO2S1 (front) terminal as follows.                  Refer to Wiring Diagram.</p>													
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">63</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td style="text-align: center;">62</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>			Terminals		Bank	ECM	Sensor	63	1	1	62	1	2
Terminals		Bank											
ECM	Sensor												
63	1	1											
62	1	2											
MTBL0511													
<p><b>Continuity should exist.</b></p> <p>3. Check harness continuity between ECM terminal or HO2S1 (front) terminal and ground as follows.                  Refer to Wiring Diagram.</p>													
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM or Sensor</th> <th>Ground</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">63 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">1</td> </tr> <tr> <td style="text-align: center;">62 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>			Terminals		Bank	ECM or Sensor	Ground	63 or 1	Ground	1	62 or 1	Ground	2
Terminals		Bank											
ECM or Sensor	Ground												
63 or 1	Ground	1											
62 or 1	Ground	2											
MTBL0512													
<p><b>Continuity should not exist.</b></p> <p>4. Also check harness for short to power.</p>													
<b>OK or NG</b>													
OK	▶	GO TO 8.											
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.											


<b>8</b>	<b>CHECK HEATED OXYGEN SENSOR 1 HEATER (FRONT)</b>							
<p>Check resistance between HO2S1 (front) terminals as follows.</p>								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th>Terminals</th> <th>Resistance</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">2 and 3</td> <td style="text-align: center;">2.3 - 4.3Ω at 25°C (77°F)</td> </tr> <tr> <td style="text-align: center;">1 and 2 1 and 3</td> <td style="text-align: center;">∞Ω (Continuity should not exist.)</td> </tr> </tbody> </table>			Terminals	Resistance	2 and 3	2.3 - 4.3Ω at 25°C (77°F)	1 and 2 1 and 3	∞Ω (Continuity should not exist.)
Terminals	Resistance							
2 and 3	2.3 - 4.3Ω at 25°C (77°F)							
1 and 2 1 and 3	∞Ω (Continuity should not exist.)							
SEF310X								
<p><b>CAUTION:</b>                  Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p>								
<b>OK or NG</b>								
OK (With CONSULT-II)	▶	GO TO 9.						
OK (Without CONSULT-II)	▶	GO TO 10.						
NG	▶	GO TO 11.						



## HEATED OXYGEN SENSOR 1 (FRONT)

Diagnostic Procedure (Cont'd)

<b>10</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT)</b>
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Stop engine and set ECM in diagnostic test mode-II [Heated oxygen sensor 1 monitor (front)].</li> <li>3. Set voltmeter probes between ECM terminal 63 (HO2S1 bank 1 signal) or 62 (HO2S1 bank 2 signal) and engine ground.</li> <li>4. Check the following with engine speed held at 2,000 rpm constant under no load.</li> </ol>	
<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;">  </div> <div style="flex: 2;"> <ul style="list-style-type: none"> <li>• MI comes on more than 5 times within 10 seconds in diagnostic test mode II (Heated oxygen sensor 1 monitor).</li> <li>• The maximum voltage is over 0.6V at least one time.</li> <li>• The minimum voltage is below 0.3V at least one time.</li> <li>• The voltage never exceeds 1.0V.</li> </ul> </div> </div>	
SEF039YA	
<p><b>CAUTION:</b>          Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p>	
<b>OK or NG</b>	
OK	▶ GO TO 12.
NG	▶ GO TO 11.

<b>11</b>	<b>REPLACE HEATED OXYGEN SENSOR 1 (FRONT)</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 1 (front) harness protector color.</li> </ol>	
	
<p>HO2S1 (front) (bank 1): Black          HO2S1 (front) (bank 2): Blue</p>	
SEF505YA	
<p><b>CAUTION:</b>          Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant. Refer to "Commercial Service Tools", EC-18.</p>	
▶	Replace malfunctioning heated oxygen sensor 1 (front).

## HEATED OXYGEN SENSOR 1 (FRONT)

Diagnostic Procedure (Cont'd)

12	CHECK HEATED OXYGEN SENSOR 1 (FRONT) SHIELD CIRCUIT FOR OPEN AND SHORT
<ol style="list-style-type: none"><li>1. Turn ignition switch "OFF".</li><li>2. Disconnect joint connector-17 or joint connector-18.</li><li>3. Check the following.<ul style="list-style-type: none"><li>● Continuity between joint connector terminal 1 or 2 and ground</li><li>● Joint connector (Refer to EL-377, "HARNES LAYOUT".) <b>Continuity should exist.</b></li></ul></li><li>4. Also check harness for short to power.</li><li>5. Then reconnect joint connector-17 or joint connector-18.</li></ol>	
<b>OK or NG</b>	
OK	▶ GO TO 13.
NG	▶ Repair open circuit or short to power in harness or connectors.

13	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
	▶ <b>INSPECTION END</b>

## HEATED OXYGEN SENSOR 1 HEATER (FRONT)

Description

### Description

#### SYSTEM DESCRIPTION

NFEC0123

NFEC0123S01

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 1 heater (front) control	Heated oxygen sensor 1 heater (front)
Crankshaft position sensor (REF)			

The ECM performs ON/OFF control of the heated oxygen sensor 1 heater (front) corresponding to the engine speed.

#### OPERATION

NFEC0123S02

Engine speed rpm	Heated oxygen sensor 1 heater (front)
Above 3,600	OFF
Below 3,600	ON

### CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

NFEC0124

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1)	● Engine speed: Below 3,600 rpm	ON
HO2S1 HTR (B2)	● Engine speed: Above 3,600 rpm	OFF

# HEATED OXYGEN SENSOR 1 HEATER (FRONT)

Wiring Diagram

## Wiring Diagram



NFEC0128

NFEC0128S01

**BANK 1**

**EC-FO2H-R-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.  
 (M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC308D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**  
 DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
3	OR/L	HEATED OXYGEN SENSOR 1 HEATER (FRONT) (BANK 1)	ENGINE RUNNING BELOW 3,600 RPM	0 - 1.0V
			ENGINE RUNNING ABOVE 3,600 RPM	BATTERY VOLTAGE

SEF655XE

# HEATED OXYGEN SENSOR 1 HEATER (FRONT)



Wiring Diagram (Cont'd)

## BANK 2

NFEC0128S02

### EC-FO2H-L-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC309D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
2	R/L	HEATED OXYGEN SENSOR 1 HEATER (FRONT) (BANK 2)	ENGINE RUNNING BELOW 3,600 RPM	0 - 1.0V
			ENGINE RUNNING ABOVE 3,600 RPM	BATTERY VOLTAGE


SEF656XE

# HEATED OXYGEN SENSOR 1 HEATER (FRONT)

Diagnostic Procedure





## Diagnostic Procedure

NFEC0129

<b>1</b>	<b>CHECK OVERALL FUNCTION</b>							
<ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Set the tester probe between ECM terminals 3 (HO2S1 heater bank 1 signal), 2 (HO2S1 heater bank 2 signal) and ground.</li> <li>3. Start engine and let it idle.</li> <li>4. Check the voltage under the following conditions.</li> </ol>								
								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">Conditions</th> <th style="padding: 5px;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">At idle</td> <td style="padding: 5px;">0 - 1V</td> </tr> <tr> <td style="padding: 5px;">Engine speed is above 3,600 rpm.</td> <td style="padding: 5px;">Battery voltage</td> </tr> </tbody> </table>			Conditions	Voltage	At idle	0 - 1V	Engine speed is above 3,600 rpm.	Battery voltage
Conditions	Voltage							
At idle	0 - 1V							
Engine speed is above 3,600 rpm.	Battery voltage							
SEF007Y								
<b>OK or NG</b>								
OK	▶	<b>INSPECTION END</b>						
NG	▶	GO TO 2.						

## HEATED OXYGEN SENSOR 1 HEATER (FRONT)

Diagnostic Procedure (Cont'd)



<b>2</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Check heated oxygen sensor 1 (front) harness protector color.</p> <div style="text-align: center;">  <p>HO2S1 (front)</p> <p>HO2S1 (front) harness protector color</p> </div> <p style="text-align: center;">HO2S1 (front) (bank 1): Black                      HO2S1 (front) (bank 2): Blue</p> <p style="text-align: right;">SEF505YA</p>		
<p>3. Disconnect corresponding heated oxygen sensor 1 (front) harness connector.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>Heated oxygen sensor 1 (front) (bank 2) harness connector</p> <p>Front</p> </div> <div style="text-align: center;">  <p>Heated oxygen sensor 1 (front) (bank 1) harness connector</p> </div> </div> <p style="text-align: right;">SEF902XA</p>		
<p>4. Turn ignition switch "ON".                  5. Check voltage between HO2S1 (front) terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="text-align: right;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p> </div> <p style="text-align: right;">SEF311X</p>		
OK	▶	GO TO 4.
NG	▶	GO TO 3.

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● Fuse block (J/B) connector M19</li> <li>● 15A fuse</li> <li>● Harness for open or short between heated oxygen sensor 1 (front) and fuse</li> </ul>		
▶		Repair harness or connectors.

## HEATED OXYGEN SENSOR 1 HEATER (FRONT)


Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK HEATED OXYGEN SENSOR 1 (FRONT) OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>												
<p>1. Turn ignition switch "OFF".                  2. Disconnect ECM harness connector.                  3. Check harness continuity between ECM terminal and HO2S1 (front) terminal as follows.                  Refer to Wiring Diagram.</p>													
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">3</td> <td style="text-align: center;">1</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>			Terminals		Bank	ECM	Sensor	3	3	1	2	3	2
Terminals		Bank											
ECM	Sensor												
3	3	1											
2	3	2											
MTBL0624													
<p><b>Continuity should exist.</b></p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>													
OK	▶	GO TO 5.											
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.											

<b>5</b>	<b>CHECK HEATED OXYGEN SENSOR 1 HEATER (FRONT)</b>	
<p>Check resistance between HO2S1 (front) terminals as follows.</p>		
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">    </div> <div style="text-align: center;">   </div> </div> <div style="display: flex; justify-content: space-around; margin-top: 20px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div>		
SEF310X		
<p><b>CAUTION:</b>                  Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 7.
NG	▶	GO TO 6.


## HEATED OXYGEN SENSOR 1 HEATER (FRONT)

Diagnostic Procedure (Cont'd)

<b>6</b>	<b>REPLACE HEATED OXYGEN SENSOR 1 (FRONT)</b>
1. Turn ignition switch "OFF". 2. Check heated oxygen sensor 1 (front) harness protector color.	
	
HO2S1 (front) (bank 1): Black HO2S1 (front) (bank 2): Blue	
SEF505YA	
<b>CAUTION:</b> Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant. Refer to "Commercial Service Tools", EC-18.	
▶	Replace malfunctioning heated oxygen sensor 1 (front).
<b>7</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

## HEATED OXYGEN SENSOR 2 (REAR)

Component Description



### Component Description

NFEC0146

The heated oxygen sensor 2 (rear), after three way catalyst (Manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 (front) are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2 (rear).

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 (rear) is not used for engine control operation.

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0147

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	● Engine: After warming up	Revving engine from idle up to 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)			LEAN ↔ RICH

# HEATED OXYGEN SENSOR 2 (REAR)

Wiring Diagram

## Wiring Diagram



=NFEC0152

NFEC0152S01

**BANK 1**

**EC-RRO2RH-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC310D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
72	W	HEATED OXYGEN SENSOR 2 (REAR) (BANK 1)	ENGINE RUNNING FROM IDLE UP TO 2,000 RPM UNDER WARM-UP CONDITION	0 - APPROX. 1.0V

SEF657XE

# HEATED OXYGEN SENSOR 2 (REAR)



Wiring Diagram (Cont'd)

## BANK 2

NFEC0152S02

### EC-RRO2LH-01

— : DETECTABLE LINE FOR DTC  
 — : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC311D

#### ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

#### CAUTION:

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
71	W	HEATED OXYGEN SENSOR 2 (REAR) (BANK 2)	ENGINE RUNNING FROM IDLE UP TO 2,000 RPM UNDER WARM-UP CONDITION	0 - APPROX. 1.0V


SEF658XE


# HEATED OXYGEN SENSOR 2 (REAR)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0153

<b>1</b>	<b>CHECK OVERALL FUNCTION-I</b>	<p>1. Start engine and drive the vehicle at over 70 km/h (43 MPH) for 2 consecutive minutes.</p> <p>2. Stop vehicle and keep the engine running.</p> <p>3. Set voltmeter probes between ECM terminals 72 (HO2S2 bank 1 signal), 71 (HO2S2 bank 2 signal) and ground.</p> <p>4. Check the voltage while revving up to 4,000 rpm under no load at least 10 times. (Depress and release the accelerator pedal as quickly as possible.)</p> <div style="display: flex; justify-content: space-around; align-items: center;">  <div style="text-align: center;"> <p><b>The voltage does not remain in the range of 0.2 - 0.4V.</b></p> </div> </div> <p style="text-align: right;">SEF008Y</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	<b>INSPECTION END</b>	
NG	▶	GO TO 2.	


<b>2</b>	<b>CHECK OVERALL FUNCTION-II</b>	<p>Keep engine at idle for 10 minutes, then check the voltage between ECM terminals 71, 72 and ground, or check the voltage when coasting at 80 km/h (50 MPH) in 3rd gear (M/T), "D" position with "OD" OFF (A/T).</p> <div style="display: flex; justify-content: space-around; align-items: center;">  <div style="text-align: center;"> <p><b>The voltage does not remain in the range of 0.2 - 0.4V.</b></p> </div> </div> <p style="text-align: right;">SEF008Y</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	<b>INSPECTION END</b>	
NG	▶	GO TO 3.	

## HEATED OXYGEN SENSOR 2 (REAR)

Diagnostic Procedure (Cont'd)

### 3 RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.





SEF255X



GO TO 4.

## HEATED OXYGEN SENSOR 2 (REAR)

Diagnostic Procedure (Cont'd)

4	CHECK HEATED OXYGEN SENSOR 2 (REAR) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT											
<p>1. Check heated oxygen sensor 2 (rear) harness protector color.</p> <div style="text-align: center;">  <p>HO2S2 (rear)</p> <p>HO2S2 (rear) harness protector color</p> </div> <p style="text-align: center;">HO2S2 (rear) (bank 1): White HO2S2 (rear) (bank 2): Red</p>												
	SEF154Z											
<p>2. Disconnect corresponding heated oxygen sensor 2 (rear) harness connector.</p> <div style="text-align: center;">  <p>Heated oxygen sensor 2 (rear) (bank 2) harness connector</p> <p>Heated oxygen sensor 2 (rear) (bank 1) harness connector</p> <p style="text-align: right;">Front</p> </div>												
	SEF467WB											
<p>3. Disconnect ECM harness connector.</p> <p>4. Check harness continuity between ECM terminal and HO2S2 (rear) terminal as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">Terminals</th> <th rowspan="2" style="text-align: center;">Bank</th> </tr> <tr> <th style="text-align: center;">ECM</th> <th style="text-align: center;">Sensor</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">72</td> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> <tr> <td style="text-align: center;">71</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>		Terminals		Bank	ECM	Sensor	72	1	1	71	1	2
Terminals		Bank										
ECM	Sensor											
72	1	1										
71	1	2										
	MTBL0504											
<p><b>Continuity should exist.</b></p> <p>5. Check harness continuity between ECM terminal or HO2S2 (rear) terminal and ground as follows. Refer to Wiring Diagram.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">Terminals</th> <th rowspan="2" style="text-align: center;">Bank</th> </tr> <tr> <th style="text-align: center;">ECM or Sensor</th> <th style="text-align: center;">Ground</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">72 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">1</td> </tr> <tr> <td style="text-align: center;">71 or 1</td> <td style="text-align: center;">Ground</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>		Terminals		Bank	ECM or Sensor	Ground	72 or 1	Ground	1	71 or 1	Ground	2
Terminals		Bank										
ECM or Sensor	Ground											
72 or 1	Ground	1										
71 or 1	Ground	2										
	MTBL0505											
<p>6. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>												
OK	▶ GO TO 5.											
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.											

## HEATED OXYGEN SENSOR 2 (REAR)


Diagnostic Procedure (Cont'd)

5	CHECK HEATED OXYGEN SENSOR 2 (REAR) GROUND CIRCUIT FOR OPEN AND SHORT	
1. Check harness continuity between HO2S2 (rear) terminal 4 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b>		
2. Also check harness for short to power.		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 6.
OK (Without CONSULT-II)	▶	GO TO 7.
NG	▶	Repair open circuit or short to power in harness or connectors


6	CHECK HEATED OXYGEN SENSOR 2 (REAR)	
Ⓟ <b>With CONSULT-II</b>		
1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.		
2. Stop vehicle with engine running.		
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.		
4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$ .		
(Reference data)		
SEF066Y		
"HO2S2 (B1)/(B2)" should be above 0.56V at least once when the "FUEL INJECTION" is +25%. "HO2S2 (B1)/(B2)" should be below 0.54V at least once when the "FUEL INJECTION" is -25%.		
<b>CAUTION:</b> Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.		
OK or NG		
OK	▶	GO TO 10.
NG	▶	GO TO 9.

## HEATED OXYGEN SENSOR 2 (REAR)

Diagnostic Procedure (Cont'd)

7	CHECK HEATED OXYGEN SENSOR 2 (REAR)-I
<p><b>⊗ Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.</li> <li>2. Stop vehicle with engine running.</li> <li>3. Set voltmeter probes between ECM terminal 72 (HO2S2 bank 1 signal) or 71 (HO2S2 bank 2 signal) and engine ground.</li> <li>4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times. (Depress and release accelerator pedal as soon as possible.)</li> </ol> <div style="display: flex; align-items: center; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  <div style="margin-left: 20px;"> <p><b>The voltage should be above 0.56V at least once during this procedure.</b></p> </div> </div> <div style="margin-left: 20px;"> <p>72: Bank 1 71: Bank 2</p> </div> </div> <p style="text-align: right; margin-top: 10px;">SEF313XB</p> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p>	
OK	▶ GO TO 10.
NG	▶ GO TO 8.

8	CHECK HEATED OXYGEN SENSOR 2 (REAR)-II
<p>Idle vehicle for 10 minutes, then check voltage between the same terminals as in Test No. 6; or check voltage when coasting from 80 km/h (50 MPH) in 3rd gear position (M/T), "D" position with "OD" OFF (A/T). <b>The voltage should go below 0.54V at least once during this procedure.</b></p> <p><b>CAUTION:</b> Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p>	
OK	▶ GO TO 10.
NG	▶ GO TO 9.

9	REPLACE HEATED OXYGEN SENSOR 2 (REAR)
<ol style="list-style-type: none"> <li>1. Stop vehicle and turn ignition switch "OFF".</li> <li>2. Check heated oxygen sensor 2 (rear) harness protector color.</li> </ol> <div style="text-align: center; margin-top: 20px;">  <p style="margin-top: 10px;">HO2S2 (rear) (bank 1): White HO2S2 (rear) (bank 2): Red</p> </div> <p style="text-align: right; margin-top: 10px;">SEF154Z</p> <p><b>CAUTION:</b> Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant. Refer to "Commercial Service Tools", EC-18.</p>	
▶	Replace malfunctioning heated oxygen sensor 2 (rear).

## HEATED OXYGEN SENSOR 2 (REAR)

Diagnostic Procedure (Cont'd)

<b>10</b>	<b>CHECK REAR HO2S SHIELD CIRCUIT FOR OPEN AND SHORT</b>
1. Turn ignition switch "OFF". 2. Disconnect joint connector-17. 3. Check the following. <ul style="list-style-type: none"><li>● Continuity between joint connector terminal 1 and ground</li><li>● Joint connector (Refer to EL-377, "HARNES LAYOUT".) <b>Continuity should exist.</b></li></ul>	
4. Also check harness for short to power. 5. Then reconnect joint connector-17.	
<b>OK or NG</b>	
OK	▶ GO TO 11.
NG	▶ Repair open circuit or short to power in harness or connectors.

<b>11</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
	▶ <b>INSPECTION END</b>

## HEATED OXYGEN SENSOR 2 HEATER (REAR)

Description

### Description

NFEC0162

#### SYSTEM DESCRIPTION

NFEC0162S01

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 2 heater (rear) control	Heated oxygen sensor 2 heater (rear)
Crankshaft position sensor (REF)			

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater (rear) corresponding to the engine speed.

#### OPERATION

NFEC0162S02

Engine speed rpm	Heated oxygen sensor 2 heater (rear)
Above 3,600	OFF
Below 3,600	ON

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0163

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none"> <li>● Ignition switch: ON (Engine stopped)</li> <li>● Engine is running above 3,600 rpm.</li> </ul>	OFF
	<ul style="list-style-type: none"> <li>● Engine is running below 3,600 rpm after driving for 2 minutes at a speed of 70 km/h (43 MPH) or more.</li> </ul>	ON

# HEATED OXYGEN SENSOR 2 HEATER (REAR)

Wiring Diagram

## Wiring Diagram



**BANK 1**

NFEC0167

NFEC0167S01

**EC-RO2H-R-01**

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.  
 (M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC312D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**  
 DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
5	P/B	HEATED OXYGEN SENSOR 2 HEATER (REAR) (BANK 1)	IGN ON	BATTERY VOLTAGE
			ENGINE RUNNING ABOVE 3,600 RPM	
			ENGINE RUNNING BELOW 3,600 RPM AFTER DRIVING FOR 2 MINUTES AT A SPEED OF 70 KM/H (43 MPH) OR MORE	0 - 1.0V

SEF659XE


# HEATED OXYGEN SENSOR 2 HEATER (REAR)

Wiring Diagram (Cont'd)



## BANK 2

NFEC0167S02

### EC-RO2H-L-01




: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)



MEC313D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
4	R/L	HEATED OXYGEN SENSOR 2 HEATER (REAR) (BANK 2)	IGN ON	BATTERY VOLTAGE
			ENGINE RUNNING ABOVE 3,600 RPM	
			ENGINE RUNNING BELOW 3,600 RPM AFTER DRIVING FOR 2 MINUTES AT A SPEED OF 70 KM/H (43 MPH) OR MORE	0 - 1.0V

SEF660XE

# HEATED OXYGEN SENSOR 2 HEATER (REAR)

Diagnostic Procedure




## Diagnostic Procedure

NFEC0168

<b>1</b>	<b>CHECK OVERALL FUNCTION</b>								
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and drive the vehicle at over 70 km/h (43 MPH) for 2 consecutive minutes.</li> <li>2. Stop vehicle and keep the engine running.</li> <li>3. Set the voltmeter probe between ECM terminals 5 (HO2S2 heater bank 1 signal), 4 (HO2S2 heater bank 2 signal) and ground.</li> <li>4. Check the voltage under the following conditions.</li> </ol>									
		<table border="1" style="border-collapse: collapse; width: 100%;"> <thead> <tr> <th style="text-align: center;">Conditions</th> <th style="text-align: center;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">At idle</td> <td style="text-align: center;">0 - 1V</td> </tr> <tr> <td style="text-align: center;">Engine speed is above 3,600 rpm.</td> <td style="text-align: center;">Battery voltage</td> </tr> </tbody> </table>		Conditions	Voltage	At idle	0 - 1V	Engine speed is above 3,600 rpm.	Battery voltage
Conditions	Voltage								
At idle	0 - 1V								
Engine speed is above 3,600 rpm.	Battery voltage								
		SEF010Y							
<b>OK or NG</b>									
OK	▶	<b>INSPECTION END</b>							
NG	▶	GO TO 2.							

## HEATED OXYGEN SENSOR 2 HEATER (REAR)

Diagnostic Procedure (Cont'd)

<b>2</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Check heated oxygen sensor 2 (rear) harness protector color.</p>		
 <p>HO2S2 (rear) harness protector color</p> <p>HO2S2 (rear) (bank 1): White                  HO2S2 (rear) (bank 2): Red</p>		
SEF154Z		
<p>3. Disconnect corresponding heated oxygen sensor 2 (rear) harness connector.</p>		
 <p>Heated oxygen sensor 2 (rear) (bank 2) harness connector      Heated oxygen sensor 2 (rear) (bank 1) harness connector</p> <p style="text-align: right;">Front</p>		
SEF467WB		
<p>4. Turn ignition switch "ON".                  5. Check voltage between HO2S2 (rear) terminal 3 and ground.</p>		
 <p style="text-align: right;"><b>Voltage: Battery voltage</b></p>		
SEF314X		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	GO TO 3.

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● Fuse block (J/B) connector M19</li> <li>● 15A fuse</li> <li>● Harness for open or short between heated oxygen sensor 2 (rear) and fuse</li> </ul>		
▶		Repair harness or connectors.

## HEATED OXYGEN SENSOR 2 HEATER (REAR)

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK HEATED OXYGEN SENSOR 2 (REAR) OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>												
<p>1. Turn ignition switch "OFF".                  2. Disconnect ECM harness connector.                  3. Check harness continuity between ECM terminal and HO2S2 (rear) terminal as follows.                  Refer to Wiring Diagram.</p>													
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Bank</th> </tr> <tr> <th>ECM</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">5</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">2</td> <td style="text-align: center;">2</td> </tr> </tbody> </table>			Terminals		Bank	ECM	Sensor	5	2	1	4	2	2
Terminals		Bank											
ECM	Sensor												
5	2	1											
4	2	2											
MTBL0506													
<p><b>Continuity should exist.</b></p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>													
OK	▶	GO TO 5.											
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.											

<b>5</b>	<b>CHECK HEATED OXYGEN SENSOR 2 HEATER (REAR)</b>	
<p>Check the resistance between HO2S2 (rear) terminals as follows.</p>		
SEF315X		
<p><b>CAUTION:</b>                  Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 7.
NG	▶	GO TO 6.

<b>6</b>	<b>REPLACE HEATED OXYGEN SENSOR 2 (REAR)</b>	
<p>Check heated oxygen sensor 2 (rear) harness protector color.</p>		
<p>HO2S2 (rear) (bank 1): White                  HO2S2 (rear) (bank 2): Red</p>		
SEF154Z		
<p><b>CAUTION:</b>                  Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner and approved anti-seize lubricant. Refer to "Commercial Service Tools", EC-18.</p>		
▶		Replace malfunctioning heated oxygen sensor 2 (rear).


## HEATED OXYGEN SENSOR 2 HEATER (REAR)

Diagnostic Procedure (Cont'd)

<b>7</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# FUEL TANK TEMPERATURE SENSOR


Component Description



## Component Description

NFEC0177

The fuel tank temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



## <Reference data>

Fuel temperature °C (°F)	Voltage* V	Resistance kΩ
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

\*: These data are reference values and are measured between ECM terminal 92 (Fuel tank temperature sensor) and ground.

### CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.






# FUEL TANK TEMPERATURE SENSOR

Diagnostic Procedure

## Diagnostic Procedure

NFEC0181

<b>1</b>	<b>CHECK OVERALL FUNCTION</b>		
<p>1. Turn ignition switch "ON".                  2. Check voltage between ECM terminal 92 and ground with CONSULT-II or tester.</p>			
			
SEF042Y			
OK or NG			
OK	▶	<b>INSPECTION END</b>	
NG	▶	GO TO 2.	

<b>2</b>	<b>CHECK FUEL TANK TEMPERATURE SENSOR POWER SUPPLY CIRCUIT</b>		
<p>1. Turn ignition switch "OFF".                  2. Disconnect fuel level sensor unit and fuel pump harness connector.</p>			
<p>View with rear seat removed</p>  <p>Fuel level sensor unit and fuel pump harness connector</p>			
SEF263X			
<p>3. Turn ignition switch "ON".                  4. Check voltage between fuel level sensor unit and fuel pump terminal 4 and ground with CONSULT-II or tester.</p>			
			
SEF586X			
OK or NG			
OK	▶	GO TO 4.	
NG	▶	GO TO 3.	

## FUEL TANK TEMPERATURE SENSOR

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors B3, M6 or B2, M2</li> <li>● Harness connectors M81, F49</li> <li>● Harness for open or short between ECM and fuel level sensor unit and fuel pump</li> </ul>	
▶	Repair harness or connector.


<b>4</b>	<b>CHECK FUEL TANK TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT</b>
1. Turn ignition switch "OFF". 2. Check harness continuity between fuel level sensor unit and fuel pump terminal 5 and body ground. Refer to Wiring Diagram. <b>Continuity should exist.</b> 3. Also check harness for short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to power in harness or connectors.

<b>5</b>	<b>CHECK FUEL TANK TEMPERATURE SENSOR</b>						
1. Remove fuel level sensor unit. 2. Check resistance between fuel level sensor unit and fuel pump terminals 4 and 5 by heating with hot water or heat gun as shown in the figure.							
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">Temperature °C (°F)</th> <th style="text-align: center;">Resistance kΩ</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">20 (68)</td> <td style="text-align: center;">2.3 - 2.7</td> </tr> <tr> <td style="text-align: center;">50 (122)</td> <td style="text-align: center;">0.79 - 0.90</td> </tr> </tbody> </table>		Temperature °C (°F)	Resistance kΩ	20 (68)	2.3 - 2.7	50 (122)	0.79 - 0.90
Temperature °C (°F)	Resistance kΩ						
20 (68)	2.3 - 2.7						
50 (122)	0.79 - 0.90						
SEF587X							
<b>OK or NG</b>							
OK	▶ GO TO 6.						
NG	▶ Replace fuel level sensor unit.						

<b>6</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

## CRANKSHAFT POSITION SENSOR (CKPS) (POS)

*Component Description*



### Component Description

NFEC0191

The crankshaft position sensor (POS) is located on the oil pan facing the gear teeth (cogs) of the signal plate (flywheel). It detects the crankshaft position signal (1° signal).

The sensor consists of a permanent magnet, core and coil.

When engine is running, the gap between the sensor and the gear teeth (cogs) will periodically change. Permeability near the sensor also changes.

Due to the permeability change, the magnetic flux near the core is changed. Therefore, the voltage signal generated in the coil is changed.

The ECM receives the voltage signal and detects the crankshaft position signal (1° signal).

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0492

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CKPS-RPM (POS)	<ul style="list-style-type: none"> <li>● Tachometer: Connect</li> <li>● Run engine and compare tachometer indication with the CONSULT-II value.</li> </ul>	Almost the same speed as the CONSULT-II value.

# CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Wiring Diagram

## Wiring Diagram

NFEC0195

### EC-CKPS-01


: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC

◁ L : LHD MODELS

▷ R : RHD MODELS

\*1 SB : ◁

R/G : ▷



101	102	1	2	3	4	5	6	7	8	9	10	58	59	60	61	62	63	64	65	66	67	109	110									
103	104	11	12	13	14	15	16	17	18	19	39	40	41	42	43	44	45	46	47	48	68	69	70	71	72	73	74	75	76	111	112	
105	106	20	21	22	23	24	25	26	27	28	29	49	50	51	52	53	54	55	56	57	77	78	79	80	81	82	83	84	85	86	113	114
107	108	30	31	32	33	34	35	36	37	38																					115	116



MEC906C



# CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Wiring Diagram (Cont'd)

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
85	W	CRANKSHAFT POSITION SENSOR (POS)	ENGINE RUNNING AT IDLE SPEED UNDER WARM-UP CONDITION	APPROX. 2.4V 
			ENGINE RUNNING AT 2,000 RPM	APPROX. 2.3V 

SEF856Y

## Diagnostic Procedure

NFEC0196




<b>1</b>	<b>INSPECTION START</b>	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.


<b>2</b>	<b>CHECK OVERALL FUNCTION</b>							
<p>Ⓟ <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Select "POS COUNT" in "DATA MONITOR" mode with CONSULT-II.</li> <li>3. Start engine and let it idle.</li> <li>4. Check the "POS COUNT" indication.</li> </ol>								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 50%;">MONITOR</th> <th style="width: 50%;">NO DTC</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">POS COUNT</td> <td style="text-align: center;">XXX</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	POS COUNT	XXX
DATA MONITOR								
MONITOR	NO DTC							
POS COUNT	XXX							
<p>"POS COUNT" indicates 179 - 181.</p>								
<p>OK or NG</p>								
OK	▶	<b>INSPECTION END</b>						
NG	▶	GO TO 4.						

SEF011Y

## CRANKSHAFT POSITION SENSOR (CKPS) (POS)



Diagnostic Procedure (Cont'd)

<b>3</b>	<b>CHECK OVERALL FUNCTION</b>
<p>⊗ <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and let it idle.</li> <li>2. Check voltage between ECM terminal 85 and ground.</li> </ol>	
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p>Voltage is approximately 2.4V.</p>  </div> </div>	
SEF012Y	
OK or NG	
OK	▶ <b>INSPECTION END</b>
NG	▶ <b>GO TO 4.</b>

<b>4</b>	<b>RETIGHTEN GROUND SCREWS</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Loosen and retighten engine ground screws.</li> </ol>	
	
SEF255X	
▶ <b>GO TO 5.</b>	

## CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Diagnostic Procedure (Cont'd)

<b>5</b>	<b>CHECK CKPS (POS) POWER SUPPLY CIRCUIT</b>	
1. Disconnect harness connectors F25, F171.		
		
SEF511WB		
2. Check voltage between harness connector F25 terminal 4 and ground with CONSULT-II or tester.		
		
SEF323X		
3. Also check harness for short to ground and short to power.		
<b>OK or NG</b>		
OK	▶	GO TO 7.
NG	▶	GO TO 6.


<b>6</b>	<b>DETECT MALFUNCTIONING PART</b>	
Check the following.		
<ul style="list-style-type: none"> <li>● Harness connectors F25, F171</li> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between ECM and crankshaft position sensor (POS)</li> <li>● Harness for open or short between ECM relay and crankshaft position sensor (POS)</li> </ul>		
▶		Repair open circuit or short to ground or short to power in harness or connectors.


<b>7</b>	<b>CHECK CKPS (POS) GROUND CIRCUIT FOR OPEN AND SHORT</b>	
1. Check harness continuity between harness connector F25 terminal 2 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b>		
2. Also check harness for short to power.		
<b>OK or NG</b>		
OK	▶	GO TO 8.
NG	▶	Repair open circuit or short to power in harness or connectors.

## CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Diagnostic Procedure (Cont'd)


<b>8</b>	<b>CHECK CKPS (POS) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
	<ol style="list-style-type: none"> <li>1. Disconnect ECM harness connector.</li> <li>2. Check harness continuity between ECM terminal 85 and harness connector F25 terminal 1. Refer to Wiring Diagram. <b>Continuity should exist.</b></li> <li>3. Also check harness for short to ground and short to power.</li> </ol> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶	GO TO 9.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.


<b>9</b>	<b>CHECK CKPS (POS) SUB-HARNESS CIRCUIT FOR OPEN AND SHORT</b>									
	<ol style="list-style-type: none"> <li>1. Disconnect CKPS (POS) harness connector.</li> </ol> <div style="text-align: center;">  <p style="margin-left: 100px;">Crankshaft position sensor (POS) harness connector</p> <p style="margin-left: 150px;">Oil pan</p> </div> <p style="text-align: right;">SEF367Q</p> <ol style="list-style-type: none"> <li>2. Check harness continuity between CKPS (POS) terminals and harness connector F171 terminals as follows.</li> </ol> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="padding: 2px;">CKPS (POS) terminal</th> <th style="padding: 2px;">Harness connector F171 terminal</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">1</td> <td style="padding: 2px;">2</td> </tr> <tr> <td style="padding: 2px;">2</td> <td style="padding: 2px;">1</td> </tr> <tr> <td style="padding: 2px;">3</td> <td style="padding: 2px;">4</td> </tr> </tbody> </table> <p style="text-align: right;">MTBL0352</p> <p><b>Continuity should exist.</b></p> <ol style="list-style-type: none"> <li>3. Also check harness for short to ground and short to power.</li> </ol> <p style="text-align: center;"><b>OK or NG</b></p>		CKPS (POS) terminal	Harness connector F171 terminal	1	2	2	1	3	4
CKPS (POS) terminal	Harness connector F171 terminal									
1	2									
2	1									
3	4									
OK	▶	GO TO 10.								
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.								

<b>10</b>	<b>CHECK CKPS (POS) INSTALLATION</b>	
	<p>Check that CKPS (POS) and HO2S1 bank 2 harness clamp are installed correctly as shown below.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Crankshaft position sensor (POS)</p> <p style="margin-left: 100px;">Heated oxygen sensor 1 (front) (bank 2) harness clamp</p> <p style="margin-left: 100px;"><b>8.4 - 10.8 N·m</b> <b>(0.86 - 1.10 kg-m,</b> <b>74.6 - 95.5 in-lb)</b></p> </div> <p style="text-align: right;">SEM222FE</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶	GO TO 11.
NG	▶	Install CKPS (POS) correctly.

## CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Diagnostic Procedure (Cont'd)

<b>11</b>	<b>CHECK CRANKSHAFT POSITION SENSOR (POS)-I</b>	
<ol style="list-style-type: none"> <li>1. Disconnect crankshaft position sensor (POS) harness connector.</li> <li>2. Loosen the fixing bolt of the sensor.</li> <li>3. Remove the sensor.</li> <li>4. Visually check the sensor for chipping.</li> </ol>		
		
SEF587P		
<b>OK or NG</b>		
OK	▶	GO TO 12.
NG	▶	Replace crankshaft position sensor (POS).

<b>12</b>	<b>CHECK CRANKSHAFT POSITION SENSOR (POS)-II</b>	
<ol style="list-style-type: none"> <li>1. Reconnect disconnected harness connectors.</li> <li>2. Turn ignition switch "ON".</li> <li>3. Check voltage between ECM terminal 85 and ground by briefly touching the sensor core with a flat-bladed screwdriver.</li> </ol>		
		
SEF324X		
<b>OK or NG</b>		
OK	▶	GO TO 13.
NG	▶	Replace crankshaft position sensor (POS).

ECM terminal	Condition	Voltage
85	Contacted	Approximately 5V
	Pulled away	Approximately 0V

**There should be a steady 5V as the flat-bladed screwdriver is drawn away slowly.**

<b>13</b>	<b>CHECK CKPS (POS) SHIELD CIRCUIT FOR OPEN AND SHORT</b>	
<ol style="list-style-type: none"> <li>1. Disconnect harness connectors F25, F171.</li> <li>2. Check harness continuity between harness connector F25 terminal 3 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b></li> <li>3. Also check harness for short to power.</li> </ol>		
<b>OK or NG</b>		
OK	▶	GO TO 15.
NG	▶	GO TO 14.

## CRANKSHAFT POSITION SENSOR (CKPS) (POS)

Diagnostic Procedure (Cont'd)

<b>14</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"><li>● Harness connectors F25, F171</li><li>● Joint connector-18</li><li>● Harness for open or short between harness connector F25 and engine ground</li></ul>	
	▶ Repair open circuit or short to power in harness or connectors.
<b>15</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
	▶ <b>INSPECTION END</b>

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Description


## Description SYSTEM DESCRIPTION

NFEC0221

NFEC0221S01

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed (POS signal)	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Throttle position switch	Closed throttle position		
Heated oxygen sensor 1 (front)	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Fuel tank temperature sensor	Fuel temperature in fuel tank		
Vehicle speed sensor	Vehicle speed		

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.



## COMPONENT DESCRIPTION

NFEC0221S02

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0222

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	● Engine: After warming up ● Air conditioner switch "OFF" ● Shift lever: "N" ● No-load Idle (Vehicle stopped)	0%
	2,000 rpm	—

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE




Wiring Diagram

## Wiring Diagram

NFEC0226

### EC-PRGVLV-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

M19 - FUSE BLOCK-JUNCTION BOX (J/B)

MEC070D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
1	PU/R	EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE	ENGINE RUNNING AT IDLE SPEED	BATTERY VOLTAGE (V) 
			ENGINE RUNNING AT 2,000 RPM (MORE THAN 100 SECONDS AFTER STARTING ENGINE)	BATTERY VOLTAGE (V) 

SEF858Y

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Diagnostic Procedure

## Diagnostic Procedure

NFEC0227


<b>1</b>	<b>INSPECTION START</b>	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.



<b>2</b>	<b>CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE CONTROL FUNCTION</b>																											
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Disconnect the EVAP purge hose connected to the EVAP canister purge volume control solenoid valve at the EVAP canister.</li> <li>3. Turn ignition switch "ON" and select "PURG VOL CONT/V" in "DATA MONITOR" mode with CONSULT-II.</li> <li>4. Start engine and let it idle.</li> <li>5. Change the valve opening percentage "Qu" and "Qd" and check for vacuum existence under the following conditions.</li> </ol>																												
<table border="1" style="display: inline-table; border-collapse: collapse; margin-right: 20px;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>PURG VOL CONT/V</th> <th>XXX %</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>ENG SPEED</th> <th>XXX rpm</th> </tr> </thead> <tbody> <tr> <td>A/F ALPHA-B1</td> <td>XX %</td> </tr> <tr> <td>A/F ALPHA-B2</td> <td>XX %</td> </tr> <tr> <td>HO2S1 MNTR (B1)</td> <td>LEAN</td> </tr> <tr> <td>HO2S1 (B2)</td> <td>LEAN</td> </tr> <tr> <td>THRTL POS SEN</td> <td>X. XX V</td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table> <table border="1" style="display: inline-table; border-collapse: collapse;"> <thead> <tr> <th>Conditions</th> <th>Vacuum</th> </tr> </thead> <tbody> <tr> <td>At idle</td> <td>Should not exist.</td> </tr> <tr> <td>Engine speed is about 2,000 rpm.</td> <td>Should exist.</td> </tr> </tbody> </table>			ACTIVE TEST		PURG VOL CONT/V	XXX %	MONITOR		ENG SPEED	XXX rpm	A/F ALPHA-B1	XX %	A/F ALPHA-B2	XX %	HO2S1 MNTR (B1)	LEAN	HO2S1 (B2)	LEAN	THRTL POS SEN	X. XX V			Conditions	Vacuum	At idle	Should not exist.	Engine speed is about 2,000 rpm.	Should exist.
ACTIVE TEST																												
PURG VOL CONT/V	XXX %																											
MONITOR																												
ENG SPEED	XXX rpm																											
A/F ALPHA-B1	XX %																											
A/F ALPHA-B2	XX %																											
HO2S1 MNTR (B1)	LEAN																											
HO2S1 (B2)	LEAN																											
THRTL POS SEN	X. XX V																											
Conditions	Vacuum																											
At idle	Should not exist.																											
Engine speed is about 2,000 rpm.	Should exist.																											
SEF156Z																												
<b>OK or NG</b>																												
OK	▶	GO TO 4.																										
NG	▶	GO TO 5.																										

<b>3</b>	<b>CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE CONTROL FUNCTION</b>							
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Disconnect the EVAP purge hose connected to the EVAP canister purge volume control solenoid valve at the EVAP canister.</li> <li>3. Start engine and let it idle for at least 80 seconds.</li> <li>4. Check for vacuum existence at the EVAP purge hose under the following conditions.</li> </ol>								
<table border="1" style="display: inline-table; border-collapse: collapse;"> <thead> <tr> <th>Conditions</th> <th>Vacuum</th> </tr> </thead> <tbody> <tr> <td>At idle</td> <td>Should not exist.</td> </tr> <tr> <td>Engine speed is about 2,000 rpm.</td> <td>Should exist.</td> </tr> </tbody> </table>			Conditions	Vacuum	At idle	Should not exist.	Engine speed is about 2,000 rpm.	Should exist.
Conditions	Vacuum							
At idle	Should not exist.							
Engine speed is about 2,000 rpm.	Should exist.							
SEF019Y								
<b>OK or NG</b>								
OK	▶	GO TO 4.						
NG	▶	GO TO 5.						

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK EVAP CANISTER</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Remove EVAP canister.</li> <li>3. Block port B of EVAP canister.</li> <li>4. Blow air through port A orally, and confirm that air flows freely through port C with check valve resistance.</li> <li>5. Block port A of EVAP canister.</li> <li>6. Blow air through port B orally, and confirm that air flows freely through port C.</li> </ol>	
	
SEF917W	
<b>OK or NG</b>	
OK	▶ <b>INSPECTION END</b>
NG	▶ Replace EVAP canister.

<b>5</b>	<b>CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Disconnect EVAP canister purge volume control solenoid valve harness connector.</li> </ol>	
	
SEF266X	
<ol style="list-style-type: none"> <li>3. Turn ignition switch "ON".</li> <li>4. Check voltage between EVAP canister purge volume control solenoid valve terminal 2 and ground with CONSULT-II or tester.</li> </ol>	
	
Voltage: Battery voltage	
SEF998X	
<b>OK or NG</b>	
OK	▶ GO TO 7.
NG	▶ GO TO 6.

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)



<b>6</b>	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● Fuse block (J/B) connector M19</li> <li>● 15A fuse</li> <li>● Harness for open or short between EVAP canister purge volume control solenoid valve and fuse</li> </ul>	
▶	Repair harness or connectors.

<b>7</b>	<b>CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between ECM terminal 1 and EVAP canister purge volume control solenoid valve terminal 1. Refer to Wiring Diagram. <b>Continuity should exist.</b></p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK (With CONSULT-II) ▶	GO TO 8.
OK (Without CONSULT-II) ▶	GO TO 9.
NG ▶	Repair open circuit or short to ground and short to power in harness or connectors.

<b>8</b>	<b>CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION</b>																				
<p>Ⓟ <b>With CONSULT-II</b></p> <p>1. Start engine.</p> <p>2. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.</p>																					
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>PURG VOL CONT/V</th> <th>XXX %</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>ENG SPEED</th> <th>XXX rpm</th> </tr> </thead> <tbody> <tr> <td>A/F ALPHA-B1</td> <td>XX %</td> </tr> <tr> <td>A/F ALPHA-B2</td> <td>XX %</td> </tr> <tr> <td>HO2S1 MNTR (B1)</td> <td>LEAN</td> </tr> <tr> <td>HO2S1 MNTR (B2)</td> <td>LEAN</td> </tr> <tr> <td>THRTL POS SEN</td> <td>X. XX V</td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>		ACTIVE TEST		PURG VOL CONT/V	XXX %	MONITOR		ENG SPEED	XXX rpm	A/F ALPHA-B1	XX %	A/F ALPHA-B2	XX %	HO2S1 MNTR (B1)	LEAN	HO2S1 MNTR (B2)	LEAN	THRTL POS SEN	X. XX V		
ACTIVE TEST																					
PURG VOL CONT/V	XXX %																				
MONITOR																					
ENG SPEED	XXX rpm																				
A/F ALPHA-B1	XX %																				
A/F ALPHA-B2	XX %																				
HO2S1 MNTR (B1)	LEAN																				
HO2S1 MNTR (B2)	LEAN																				
THRTL POS SEN	X. XX V																				
SEF677Y																					
<b>OK or NG</b>																					
OK ▶	GO TO 10.																				
NG ▶	GO TO 9.																				

# EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE


Diagnostic Procedure (Cont'd)

<b>9</b>	<b>CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE</b>	
<p><b>④ With CONSULT-II</b> Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.</p>		
		
SEF334X		
<p><b>⊗ Without CONSULT-II</b> Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.</p>		
		
SEF335X		
<b>OK or NG</b>		
OK	▶	GO TO 10.
NG	▶	Replace EVAP canister purge volume control solenoid valve.

<b>10</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

## VEHICLE SPEED SENSOR (VSS)

*Component Description*



### Component Description

The vehicle speed sensor is installed in the transaxle. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.

=NFEC0242


# VEHICLE SPEED SENSOR (VSS)

Wiring Diagram



## Wiring Diagram

=NFEC0247

### EC-VSSEN-01





- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ⬅ : LHD MODELS
- ➡ : RHD MODELS
- \*1 17D : ⬅
- 13D : ➡



REFER TO THE FOLLOWING.

- (M15) -SUPER
- MULTIPLE JUNCTION (SMJ)
- (M19) -FUSE BLOCK-JUNCTION BOX (J/B)



MEC052D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
86	P/L	VEHICLE SPEED SENSOR	VEHICLE DRIVING AT 10 KM/H (6 MPH) IN 1ST GEAR POSITION UNDER LIFTED UP CONDITION	APPROX. 2.0V 
			VEHICLE DRIVING AT 30 KM/H (19 MPH) IN 2ND GEAR POSITION UNDER LIFTED UP CONDITION	APPROX. 2.5V 

SEF859Y

# VEHICLE SPEED SENSOR (VSS)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0248

<b>1</b>	<b>INSPECTION START</b>	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

<b>2</b>	<b>CHECK OVERALL FUNCTION</b>															
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Lift up the vehicle.</li> <li>3. Start engine and let it idle.</li> <li>4. Select "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II.</li> <li>5. Check "VHCL SPEED SE" indication when rotating wheels with suitable gear position.</li> </ol>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> <tr> <td>PW/ST SIGNAL</td> <td>OFF</td> </tr> <tr> <td>VHCL SPEED SE</td> <td>XXX km/h</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	ENG SPEED	XXX rpm	COOLAN TEMP/S	XXX °C	B/FUEL SCHDL	XXX msec	PW/ST SIGNAL	OFF	VHCL SPEED SE	XXX km/h
DATA MONITOR																
MONITOR	NO DTC															
ENG SPEED	XXX rpm															
COOLAN TEMP/S	XXX °C															
B/FUEL SCHDL	XXX msec															
PW/ST SIGNAL	OFF															
VHCL SPEED SE	XXX km/h															
<p>“VHCL SPEED SE” indication should exceed 10 km/h (6 MPH).</p>																
SEF020Y																
OK or NG																
OK	▶	<b>INSPECTION END</b>														
NG	▶	GO TO 4.														

<b>3</b>	<b>CHECK OVERALL FUNCTION</b>					
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Lift up the vehicle.</li> <li>3. Start engine and let it idle.</li> <li>4. Read the voltage signal between ECM terminal 86 and ground with an oscilloscope.</li> <li>5. Verify that the oscilloscope screen shows a signal wave as shown below under the following conditions.</li> </ol>						
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> </div> <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Conditions</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="vertical-align: top;">                     Vehicle speed is 30 km/h (19 MPH) in 2nd gear position.                 </td> <td style="text-align: center;"> </td> </tr> </tbody> </table> </div> </div>			Conditions	Voltage	Vehicle speed is 30 km/h (19 MPH) in 2nd gear position.	
Conditions	Voltage					
Vehicle speed is 30 km/h (19 MPH) in 2nd gear position.						
SEF021Y						
OK or NG						
OK	▶	<b>INSPECTION END</b>				
NG	▶	GO TO 4.				

## VEHICLE SPEED SENSOR (VSS)

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK VEHICLE SPEED SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector and combination meter harness connector.</p> <p>3. Check harness continuity between ECM terminal 86 and combination meter terminal 32. Refer to Wiring Diagram. <b>Continuity should exist.</b></p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

<b>5</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● Harness for open or short between ECM and combination meter</li> </ul>		
	▶	Repair open circuit or short to ground or short to power in harness or connectors.

<b>6</b>	<b>CHECK SPEEDOMETER FUNCTION</b>	
<p>Make sure that speedometer functions properly.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 8.
NG	▶	GO TO 7.

<b>7</b>	<b>CHECK SPEEDOMETER CIRCUIT FOR OPEN AND SHORT</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M15, E81</li> <li>● Harness for open or short between combination meter and ABS actuator and electric unit</li> </ul> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	Check combination meter and ABS actuator and electric unit. Refer to EL or BR section.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

<b>8</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.</p>		
	▶	<b>INSPECTION END</b>

# IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Description

## Description SYSTEM DESCRIPTION

NFEC0249

NFEC0249S01

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed (POS signal)	Idle air control	IACV-AAC valve
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Park/neutral position (PNP) switch	Park/neutral position		
Air conditioner switch	Air conditioner operation		
Power steering oil pressure switch	Power steering load signal		
Battery	Battery voltage		
Vehicle speed sensor	Vehicle speed		
Ambient air temperature switch	Ambient air temperature		
Intake air temperature sensor	Intake air temperature		
Absolute pressure sensor	Ambient barometric pressure		


This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which by-passes the throttle valve via IACV-AAC valve. The IACV-AAC valve changes the opening of the air by-pass passage to control the amount of auxiliary air. This valve is actuated by a step motor built into the valve, which moves the valve in the axial direction in steps corresponding to the ECM output signals. One step of IACV-AAC valve movement causes the respective opening of the air by-pass passage. (i.e. when the step advances, the opening is enlarged.) The opening of the valve is varied to allow for optimum control of the engine idling speed. The crankshaft position sensor (POS) detects the actual engine speed and sends a signal to the ECM. The ECM then controls the step position of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner, power steering and cooling fan operation).

**NOTE:**

**If engine idle speed is out of the specified value, perform “Idle Air Volume Learning”, EC-41. For the target idle speed, refer to “Service Data and specifications (SDS)”, EC-559.**

# IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Description (Cont'd)



## COMPONENT DESCRIPTION

NFEC0249S02

### IACV-AAC Valve

NFEC0249S0201

The IACV-AAC valve is operated by a step motor for centralized control of auxiliary air supply. This motor has four winding phases and is actuated by the output signals of ECM which turns ON and OFF two windings each in sequence. Each time the IACV-AAC valve opens or closes to change the auxiliary air quantity, the ECM sends a pulse signal to the step motor. When no change in the auxiliary air quantity is needed, the ECM does not issue the pulse signal. A certain voltage signal is issued so that the valve remains at that particular opening.

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0250

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
IACV-AAC/V	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: "OFF"</li> <li>● Shift lever: "N"</li> <li>● No-load</li> </ul>	Idle	2 - 10 step
		2,000 rpm	—




# IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Wiring Diagram

## Wiring Diagram

=NFEC0254

### EC-AACVVLV-01



MEC071D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**  
DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
6	W/PU	IACV-AAC VALVE	ENGINE RUNNING AT IDLE SPEED	0.1 - 14V
7	Y/B			
8	Y			
17	GY/L			

SEF625XB

# IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Diagnostic Procedure

## Diagnostic Procedure

NFEC0255

<b>1</b>	<b>CHECK OVERALL FUNCTION</b>	<p>1. Turn ignition switch "OFF".</p> <p>2. Read the voltage signal between ECM terminals 6, 7, 8, 17 (IACV-AAC valve signal) and ground with an oscilloscope.</p> <p>3. Turn ignition switch "ON", wait at least 5 seconds and then "OFF".</p> <p>4. Verify that the oscilloscope screen shows the signal wave as shown below at least once every 10 seconds after turning ignition switch "OFF".</p>	
			SEF022Y
		<b>OK or NG</b>	
OK	▶	<b>INSPECTION END</b>	
NG	▶	GO TO 2.	


<b>2</b>	<b>CHECK IACV-AAC VALVE POWER SUPPLY CIRCUIT</b>	<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect IACV-AAC valve harness connector.</p>	
		<p>View with intake air duct removed</p>	SEC008C
		<p>3. Turn ignition switch "ON".</p> <p>4. Check voltage between IACV-AAC valve terminals 2, 5 and ground with CONSULT-II or tester.</p>	
			SEF343X
		<b>OK or NG</b>	
OK	▶	GO TO 4.	
NG	▶	GO TO 3.	

# IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between IACV-AAC valve and ECM relay</li> </ul>	
▶	Repair harness or connectors.

<b>4</b>	<b>CHECK IACV-AAC VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>										
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminals and IACV-AAC valve terminals as follows. Refer to Wiring Diagram.											
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">ECM terminal</th> <th style="padding: 5px;">IACV-AAC valve terminal</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; padding: 5px;">6</td> <td style="text-align: center; padding: 5px;">1</td> </tr> <tr> <td style="text-align: center; padding: 5px;">7</td> <td style="text-align: center; padding: 5px;">4</td> </tr> <tr> <td style="text-align: center; padding: 5px;">8</td> <td style="text-align: center; padding: 5px;">3</td> </tr> <tr> <td style="text-align: center; padding: 5px;">17</td> <td style="text-align: center; padding: 5px;">6</td> </tr> </tbody> </table>		ECM terminal	IACV-AAC valve terminal	6	1	7	4	8	3	17	6
ECM terminal	IACV-AAC valve terminal										
6	1										
7	4										
8	3										
17	6										
MTBL0354											
<p style="color: blue; margin: 0;"><b>Continuity should exist.</b></p> 4. Also check harness for short to ground and short to power.											
<b>OK or NG</b>											
OK	▶ GO TO 5.										
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.										

<b>5</b>	<b>CHECK AIR CONTROL VALVE (POWER STEERING) OPERATION-I</b>
1. Reconnect the ECM harness connector and IACV-AAC valve harness connector. 2. Disconnect the vacuum hose connected to the air control valve (Power steering) at the intake air duct. 3. Start engine and let it idle. 4. Check vacuum hose for vacuum existence.	
	
SEF971X	
<p style="color: blue; margin: 0;"><b>Vacuum slightly exists or does not exist.</b></p>	
<b>OK or NG</b>	
OK	▶ GO TO 6.
NG	▶ Replace air control valve (Power steering).

# IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE


Diagnostic Procedure (Cont'd)


<b>6</b>	<b>CHECK AIR CONTROL VALVE (POWER STEERING) OPERATION-II</b>	
<p>Check the vacuum hose for vacuum existence when steering wheel is turned.</p>		
<p><b>Vacuum should exist.</b></p>		
<p><b>OK or NG</b></p>		
OK	▶	GO TO 9.
NG	▶	GO TO 7.

<b>7</b>	<b>CHECK VACUUM PORT</b>	
<ol style="list-style-type: none"> <li>1. Stop engine.</li> <li>2. Disconnect the vacuum hose connected to the air control valve (Power steering) at the vacuum port.</li> <li>3. Blow air into vacuum port.</li> <li>4. Check that air flows freely.</li> </ol>		
<p><b>OK or NG</b></p>		
OK	▶	GO TO 8.
NG	▶	Repair or clean vacuum port.

# IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE


Diagnostic Procedure (Cont'd)

8	CHECK VACUUM HOSES AND TUBES
<p>1. Disconnect vacuum hoses between the air control valve (Power steering) and vacuum port, air control valve (Power steering) and air duct.</p> <p>2. Check hoses and tubes for cracks, clogging, improper connection or disconnection.</p>	
	
SEF109L	
<b>OK or NG</b>	
OK	▶ GO TO 9.
NG	▶ Repair hoses or tubes.

9	CHECK IACV-AAC VALVE-I
<p>1. Disconnect IACV-AAC valve harness connector.</p> <p>2. Check resistance between IACV-AAC valve terminal 2 and terminals 1, 3, terminal 5 and terminals 4, 6.</p>	
	
<p><b>Resistance:</b> Approximately 22Ω [at 20°C (68°F)]</p>	
SEF344X	
<b>OK or NG</b>	
OK	▶ GO TO 10.
NG	▶ Replace IACV-AAC valve assembly.

# IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Diagnostic Procedure (Cont'd)

<b>10</b>	<b>CHECK IACV-AAC VALVE-II</b>	
<p>1. Reconnect IACV-AAC valve harness connector and ECM harness connector.</p> <p>2. Turn ignition switch "ON" and "OFF", and ensure the IACV-AAC valve makes operating sound according to the ignition switch position.</p>		
<p>View with intake air duct removed</p>  <p>IACV-AAC valve</p>		
SEC009C		
<b>OK or NG</b>		
OK	▶	GO TO 12.
NG	▶	GO TO 11.


<b>11</b>	<b>REPLACE IACV-AAC VALVE</b>	
<p>1. Replace IACV-AAC valve assembly.</p> <p>2. Perform "Idle Air Volume Learning", EC-41.</p> <p><b>Which is the result CMPLT or INCMP?</b></p>		
<b>CMPLT or INCMP</b>		
CMPLT	▶	<b>INSPECTION END</b>
INCMP	▶	Follow the construction of "Idle Air Volume Learning".

<b>12</b>	<b>CHECK TARGET IDLE SPEED</b>	
<p>1. Turn ignition switch "OFF".</p> <p>2. Reconnect all harness connectors and vacuum hoses.</p> <p>3. Start engine and warm it up to normal operating temperature.</p> <p>4. Also warm up transmission to normal operating temperature.</p> <ul style="list-style-type: none"> <li>● For A/T models with CONSULT-II, drive vehicle until "FLUID TEMP SE" in "DATA MONITOR" mode of "A/T" system indicates less than 0.9V.</li> <li>● For A/T models without CONSULT-II and M/T models, drive vehicle for 10 minutes.</li> </ul> <p>5. Stop vehicle with engine running.</p> <p>6. Check target idle speed.</p> <p style="color: blue;"><b>M/T: 625±50 rpm (VQ30DE engine models)</b></p> <p style="color: blue;"><b>M/T: 675±50 rpm (VQ20DE engine models)</b></p> <p style="color: blue;"><b>A/T: 700±50 rpm (in "P" or "N" position)</b></p>		
<b>OK or NG</b>		
OK	▶	GO TO 13.
NG	▶	Perform "Idle Air Volume Learning", EC-41.

<b>13</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶ <b>INSPECTION END</b>		

## CLOSED THROTTLE POSITION SWITCH

Component Description



### Component Description

NFEC0256

A closed throttle position switch and wide open throttle position switch are built into the throttle position sensor unit. The wide open throttle position switch is used only for A/T control.

When the throttle valve is in the closed position, the closed throttle position switch sends a voltage signal to the ECM. The ECM only uses this signal to open or close the EVAP canister purge volume control solenoid valve when the throttle position sensor is malfunctioning.



# CLOSED THROTTLE POSITION SWITCH

Wiring Diagram

## Wiring Diagram

=NFEC0262

### EC-TP/SW1-01



MEC072D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
5	GY/L	THROTTLE POSITION SWITCH (CLOSED POSITION)	ENGINE RUNNING WITH ACCELERATOR PEDAL FULLY RELEASED UNDER WARM-UP CONDITION	BATTERY VOLTAGE
			IGN ON WITH ACCELERATOR PEDAL DEPRESSED	APPROX. 0V


SEF626XD



# CLOSED THROTTLE POSITION SWITCH

Diagnostic Procedure

## Diagnostic Procedure

NFEC0263

<b>1</b>	<b>CHECK OVERALL FUNCTION</b>								
<p>1. Start engine and warm it up to normal operating temperature.                  2. Check the voltage between ECM terminal 56 and ground under the following conditions.</p>									
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Conditions</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td>Accelerator pedal is fully released.</td> <td>Battery voltage</td> </tr> <tr> <td>Accelerator pedal is depressed.</td> <td>Approximately 0V</td> </tr> </tbody> </table>		Conditions	Voltage	Accelerator pedal is fully released.	Battery voltage	Accelerator pedal is depressed.	Approximately 0V
Conditions	Voltage								
Accelerator pedal is fully released.	Battery voltage								
Accelerator pedal is depressed.	Approximately 0V								
SEF023Y									
<b>OK or NG</b>									
OK	▶	<b>INSPECTION END</b>							
NG	▶	GO TO 2.							



<b>2</b>	<b>CHECK CLOSED THROTTLE POSITION SWITCH POWER SUPPLY CIRCUIT</b>		
<p>1. Turn ignition switch "OFF".                  2. Disconnect throttle position switch harness connector.</p>			
		SEC001C	
<p>3. Turn ignition switch "ON".                  4. Check voltage between throttle position switch terminal 5 and engine ground with CONSULT-II or tester.</p>			
		<b>Voltage: Battery voltage</b>	
SEF346X			
<b>OK or NG</b>			
OK	▶	GO TO 4.	
NG	▶	GO TO 3.	

## CLOSED THROTTLE POSITION SWITCH

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between throttle position switch and ECM relay</li> <li>● Harness for open or short between throttle position switch and ECM</li> </ul>	
▶	Repair harness or connectors.

<b>4</b>	<b>CHECK CLOSED THROTTLE POSITION SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Disconnect ECM harness connector.</li> <li>3. Check harness continuity between ECM terminal 56 and throttle position switch terminal 4. Refer to Wiring Diagram. <b>Continuity should exist.</b></li> <li>4. Also check harness for short to ground and short to power.</li> </ol> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

<b>5</b>	<b>CHECK THROTTLE POSITION SWITCH</b>						
<ol style="list-style-type: none"> <li>1. Reconnect ECM harness connector and throttle position switch harness connector.</li> <li>2. Start engine and warm it up to normal operating temperature.</li> <li>3. Turn ignition switch "OFF".</li> <li>4. Disconnect closed throttle position switch harness connector.</li> <li>5. Check continuity between closed throttle position switch terminals 4 and 5 under the following conditions. Resistance measurement must be made with throttle position switch installed in vehicle.</li> </ol>							
							
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">Throttle valve conditions</th> <th style="padding: 5px;">Continuity</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">Completely closed</td> <td style="padding: 5px;">Yes</td> </tr> <tr> <td style="padding: 5px;">Partially open or completely open</td> <td style="padding: 5px;">No</td> </tr> </tbody> </table>		Throttle valve conditions	Continuity	Completely closed	Yes	Partially open or completely open	No
Throttle valve conditions	Continuity						
Completely closed	Yes						
Partially open or completely open	No						
SEC010C							
<b>OK or NG</b>							
OK	▶ GO TO 7.						
NG	▶ GO TO 6.						

## CLOSED THROTTLE POSITION SWITCH

Diagnostic Procedure (Cont'd)

<b>6</b>	<b>ADJUST THROTTLE POSITION SWITCH</b>									
Check the following items. Refer to "Basic Inspection", EC-90.										
<table border="1" style="width: 100%; border-collapse: collapse;"><thead><tr><th style="width: 40%;">Items</th><th style="width: 60%;">Specifications</th></tr></thead><tbody><tr><td>Ignition timing</td><td>9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)</td></tr><tr><td>Closed throttle position switch idle position adjustment</td><td>Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF</td></tr><tr><td>Target idle speed</td><td>M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)</td></tr></tbody></table>			Items	Specifications	Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)	Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF	Target idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)
Items	Specifications									
Ignition timing	9° ± 5° BTDC (VQ20DE engine) 15° ± 5° BTDC (VQ30DE engine)									
Closed throttle position switch idle position adjustment	Feeler gauge thickness and switch condition 0.05 mm (0.0020 in): ON 0.15 mm (0.0059 in): OFF									
Target idle speed	M/T: 625 ± 50 rpm (VQ30DE engine) 675 ± 50 rpm (VQ20DE engine) A/T: 700 ± 50 rpm (in "P" or "N" position)									
MTBL0623										
<b>Is it possible to adjust closed throttle position switch?</b>										
<b>Yes or No</b>										
Yes	▶	GO TO 1.								
No	▶	Replace throttle position switch.								

<b>7</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

## A/T COMMUNICATION LINE

*System Description*

---

### **System Description**

NFEC0264

These circuit lines are used to control the smooth shifting up and down of A/T during the hard acceleration/ deceleration.

Voltage signals are exchanged between ECM and TCM (Transmission Control Module).




# A/T COMMUNICATION LINE

Wiring Diagram

## Wiring Diagram

=NFEC0269

### EC-ATCONT-01



MEC073D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**  
DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
36	Y	A/T COMMUNICATION LINE	ENGINE RUNNING AT IDLE SPEED	VOLTAGE FLUCTUATES BETWEEN 0 to 5V.
37	LG			
68	BR			
77	GY			
78	OR			


SEF043YA

# A/T COMMUNICATION LINE

Diagnostic Procedure

## Diagnostic Procedure

NFEC0270

<b>1</b>	<b>CHECK OVERALL FUNCTION</b>
<p>1. Start engine and warm it up to normal operating temperature. 2. Check the voltage between ECM terminals 36, 37, 68, 77, 78 and ground.</p> <div data-bbox="331 421 853 683"></div> <p data-bbox="901 537 1204 604">Voltage should fluctuate between 0 to 5V.</p> <p data-bbox="1380 689 1468 716">SEF024Y</p> <p data-bbox="742 728 853 761">OK or NG</p>	
OK	▶ <b>INSPECTION END</b>
NG	▶ GO TO 2.


## A/T COMMUNICATION LINE

Diagnostic Procedure (Cont'd)


### 2 CHECK A/T CONTROL INPUT SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector and TCM (Transmission Control Module) harness connector.

LHD models View with glove box removed




RHD models



SEF044Y

View with center console removed



SEF271X

3. Check harness continuity between the following terminals.

ECM	TCM
68	5
77	6
36	7
78	9
37	8

MTBL0405

Refer to Wiring Diagram.

**Continuity should exist.**

**OK or NG**

OK	▶	GO TO 3.
NG	▶	Repair harness or connectors.

### 3 CHECK A/T CONTROL INPUT SIGNAL CIRCUIT FOR SHORT

1. Check harness continuity between ECM terminals 36, 37, 68, 77, 78 and ground.  
Refer to Wiring Diagram.  
**Continuity should not exist.**
2. Also check harness for short to power.

**OK or NG**

OK	▶	GO TO 4.
NG	▶	Repair short to ground or short to power in harness or connectors.

### 4 CHECK INTERMITTENT INCIDENT

Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.

	▶	<b>INSPECTION END</b>
--	---	-----------------------

# SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Description

## Description SYSTEM DESCRIPTION

NFEC0523

NFEC0523S01

Sensor	Input Signal to ECM	ECM function	Actuator
Throttle position sensor	Throttle position	Swirl control valve control	Swirl control valve control solenoid valve ↓ Vacuum signal Swirl control valve actuator ↓ Swirl control valve
Ignition switch	Start signal		
Crankshaft position sensor (POS)	Engine speed (POS signal)		
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		

This system has a swirl control valve in the intake passage of each cylinder.

While idling and during low engine speed operation, the swirl control valve closes. Thus the velocity of the air in the intake passage increases, promoting the vaporization of the fuel and producing a swirl in the combustion chamber.


Because of this operation, this system tends to increase the burning speed of the gas mixture, improve fuel consumption, and increase the stability in running conditions.

Also, except when idling and during low engine speed operation, this system opens the swirl control valve. In this condition, this system tends to increase power by improving intake efficiency via reduction of intake flow resistance, intake flow.

The solenoid valve controls swirl control valve's shut/open condition. This solenoid valve is operated by the ECM.


Throttle position sensor (Idle position)	Engine speed	Swirl control valve control solenoid valve	Swirl control valve
ON	Below 3,200 rpm	ON	Closed
OFF	Less than 3,200 rpm	ON	Closed
	More than 3,600 rpm	OFF	Open

When engine coolant temperature is below 10°C (50°F) and above 55°C (131°F), swirl control valve is kept open regardless of above condition.



## SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

*Description (Cont'd)*



### COMPONENT DESCRIPTION

NFEC0523S02

#### Swirl Control Valve Control Solenoid Valve

NFEC0523S0201

The swirl control valve control solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the solenoid valve is bypassed to apply intake manifold vacuum to the swirl control valve actuator. This operation closes the swirl control valve. When the ECM sends an OFF signal, the vacuum signal is cut and the swirl control valve opens.

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0524

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
SWRL CONT S/V	<ul style="list-style-type: none"> <li>● Engine speed: Idle</li> </ul>	Engine coolant temperature is between 15°C (59°F) to 50°C (122°F).
		Engine coolant temperature is above 55°C (131°F).



# SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Wiring Diagram

## Wiring Diagram


NFEC0529

EC-SWL/C-01



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK-JUNCTION BOX (J/B)



MEC074D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
29	G	SWIRL CONTROL VALVE CONTROL SOLENOID VALVE	ENGINE RUNNING AT IDLE SPEED WITH ENGINE COOLANT TEMPERATURE BETWEEN 15°C (59°F) AND 50°C (122°F).	0 - 1V
			ENGINE RUNNING AT IDLE SPEED WITH ENGINE COOLANT TEMPERATURE ABOVE 55°C (131°F).	BATTERY VOLTAGE

SEF627XB


# SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure

## Diagnostic Procedure

NFEC0530

<b>1</b>	<b>INSPECTION START</b>
Do you have CONSULT-II?	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 3.

<b>2</b>	<b>CHECK OVERALL FUNCTION</b>
<p>④ <b>With CONSULT-II</b></p> <ol style="list-style-type: none"><li>1. Start engine and let it idle.</li><li>2. Select "SWIRL CONT SOL/V" in "ACTIVE TEST" mode with CONSULT-II.</li><li>3. Touch "ON" and "OFF" alternately on CONSULT-II screen.</li><li>4. Make sure the swirl control valve actuator rod moves according to "SWIRL CONT SOL/V".</li></ol>	
	
SEF621X	
<b>OK or NG</b>	
OK	▶ <b>INSPECTION END</b>
NG	▶ GO TO 4.


# SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)

## 3 CHECK OVERALL FUNCTION


⊗ Without CONSULT-II

1. Turn ignition switch "ON".
2. Confirm that the voltage between ECM terminal 70 (Engine coolant temperature sensor signal) and ground is more than 2.72V. If the voltage is out of range, cool the engine down.



SEF016Y

3. Start engine and let it idle.
4. Make sure the swirl control valve actuator rod moves when revving to over 3,200 rpm from idle.



Swirl control valve actuator


SEF621X



OK or NG

OK	▶	INSPECTION END
NG	▶	GO TO 5.

# SWIRL CONTROL VALVE CONTROL SOLENOID VALVE


Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK VACUUM SOURCE</b>	
<p><b>Ⓟ With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Disconnect the vacuum hose connected to the swirl control valve actuator at vacuum tank.</li> <li>3. Start engine and let it idle.</li> <li>4. Select "SWIRL CONT SOL/V" in "ACTIVE TEST" mode with CONSULT-II.</li> <li>5. Touch "ON" and "OFF" alternately on CONSULT-II screen.</li> <li>6. Check vacuum existence under the following conditions.</li> </ol>		
		
		
SEF026Y		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	GO TO 7.

<b>5</b>	<b>CHECK VACUUM SOURCE</b>	
<p><b>ⓧ Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Disconnect the swirl control valve control solenoid valve harness connector.</li> <li>3. Disconnect the vacuum hose connected to the swirl control valve actuator at vacuum tank.</li> <li>4. Start engine and let it idle.</li> <li>5. Apply 12V of direct current between swirl control valve control solenoid valve terminals 1 and 2.</li> <li>6. Check vacuum existence under the following conditions.</li> </ol>		
		
		
SEF027Y		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	GO TO 8.

## SWIRL CONTROL VALVE CONTROL SOLENOID VALVE



Diagnostic Procedure (Cont'd)

<b>6</b>	<b>CHECK VACUUM HOSES AND TUBES</b>	
<p>1. Turn ignition switch "OFF".                  2. Remove vacuum hoses between the swirl control valve actuator and the vacuum tank.                  3. Check hoses and tubes for cracks, clogging, improper connection or disconnection.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF109L</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	Repair or replace swirl control valve actuator.
NG	▶	Repair or replace vacuum hoses or tubes.

<b>7</b>	<b>CHECK SWIRL CONTROL VALVE CONTROL SOLENOID VALVE CIRCUIT</b>																					
<p>Ⓜ <b>With CONSULT-II</b>                  1. Turn ignition switch "ON".                  2. Select "SWIRL CONT SOL/V" in "ACTIVE TEST" mode with CONSULT-II.                  3. Touch "ON" and "OFF" alternately on CONSULT-II screen.</p> <div style="text-align: center;"> <table border="1" style="border-collapse: collapse; width: 150px;"> <tr><th colspan="2" style="text-align: center;">ACTIVE TEST</th></tr> <tr><td style="text-align: center;">SWIRL CONT SOL/V</td><td style="text-align: center;">OFF</td></tr> <tr><th colspan="2" style="text-align: center;">MONITOR</th></tr> <tr><td style="text-align: center;">ENG SPEED</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td style="text-align: center;">IACV-AAC/V</td><td style="text-align: center;">XXX step</td></tr> <tr><td> </td><td> </td></tr> </table> </div> <p style="text-align: right;">SEF069Y</p> <p>4. Make sure that clicking sound is heard from the swirl control valve control solenoid valve.</p> <p style="text-align: center;"><b>OK or NG</b></p>			ACTIVE TEST		SWIRL CONT SOL/V	OFF	MONITOR		ENG SPEED	XXX rpm	IACV-AAC/V	XXX step										
ACTIVE TEST																						
SWIRL CONT SOL/V	OFF																					
MONITOR																						
ENG SPEED	XXX rpm																					
IACV-AAC/V	XXX step																					
OK	▶	GO TO 11.																				
NG	▶	GO TO 8.																				

# SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)

<b>8</b>	<b>CHECK SWIRL CONTROL VALVE CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect swirl control valve control solenoid valve harness connector.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Intake manifold collector</p> <p style="margin-left: 100px;">Swirl control valve control solenoid valve</p> </div> <p style="text-align: right;">SEF272X</p> <p>3. Turn ignition switch "ON".                  4. Check voltage between swirl control valve control solenoid valve terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="margin-left: 150px;"><b>Voltage: Battery voltage</b></p> <p style="margin-left: 100px;"><b>OK or NG</b></p> </div> <p style="text-align: right;">SEF619X</p>		
OK	▶	GO TO 10.
NG	▶	GO TO 9.

<b>9</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● 15A fuse</li> <li>● Harness for open or short between swirl control valve control solenoid valve and fuse</li> </ul>		
▶		Repair harness or connectors.

<b>10</b>	<b>CHECK SWIRL CONTROL VALVE CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect ECM harness connector.                  3. Check harness continuity between ECM terminal 29 and swirl control valve control solenoid valve terminal 2. Refer to Wiring Diagram.  <b>Continuity should exist.</b>                  4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 11.
NG	▶	Repair open circuit, short to ground or short to power in harness connectors.


## SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)

### 11 CHECK SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

**Ⓟ With CONSULT-II**

1. Reconnect the disconnected harness connectors.
2. Start engine and let it idle.
3. Remove vacuum hose connected to swirl control valve actuator.
4. Select "SWIRL CONT SOL/V" in "ACTIVE TEST" mode with CONSULT-II.
5. Touch "ON" and "OFF" on CONSULT-II screen.
6. Check vacuum existence and operation delay time under the following conditions.




SWIRL CONT SOL/V	Vacuum
ON	should exist.
OFF	should not exist.

**Operation takes less than 1 second.**

SEF046Y

**ⓧ Without CONSULT-II**

1. Reconnect ECM harness connector.
2. Remove vacuum hose connected to swirl control valve actuator.
3. Start engine and let it idle.
4. Apply 12V of direct current between swirl control valve control solenoid valve terminals 1 and 2.
5. Check vacuum existence and operation delay time under the following conditions.



Condition	Vacuum
12V direct current supply	Should exist.
No supply	Should not exist.

**Operation takes less than 1 second.**

SEF047Y

**OK or NG**

OK	▶	GO TO 12.
NG	▶	Replace intake manifold collector assembly.

### 12 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.

	▶	<b>INSPECTION END</b>
--	---	-----------------------

# IGNITION SIGNAL

Component Description


## Component Description

NFEC0863

### IGNITION COIL & POWER TRANSISTOR

NFEC0863S01

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.



# IGNITION SIGNAL

Wiring Diagram

## Wiring Diagram

NFEC0864

### EC-IGNSYS-01

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC

REFER TO EL-POWER.

⬅ : LHD MODELS



➡ : RHD MODELS

\*1 SB: ⬅

R/G: ➡

\*2 R: ⬅

W/G: ➡



101	102	1	2	3	4	5	6	7	8	9	10					58	59	60	61	62	63	64	65	66	67	109	110								
103	104	11	12	13	14	15	16	17	18	19					39	40	41	42	43	44	45	46	47	48	68	69	70	71	72	73	74	75	76	111	112
105	106	20	21	22	23	24	25	26	27	28	29				49	50	51	52	53	54	55	56	57	77	78	79	80	81	82	83	84	85	86	113	114
107	108	30	31	32	33	34	35	36	37	38															87	88	89	90	91	92	93	94	95	115	116




MEC075D

# IGNITION SIGNAL

Wiring Diagram (Cont'd)

## EC-IGNSYS-02

: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC



101	102	1	2	3	4	5	6	7	8	9	10					58	59	60	61	62	63	64	65	66	67	109	110					
103	104	11	12	13	14	15	16	17	18	19	39	40	41	42	43	44	45	46	47	48	68	69	70	71	72	73	74	75	76	111	112	
105	106	20	21	22	23	24	25	26	27	28	29	49	50	51	52	53	54	55	56	57	77	78	79	80	81	82	83	84	85	86	113	114
107	108	30	31	32	33	34	35	36	37	38											87	88	89	90	91	92	93	94	95	115	116	



MEC076D



# IGNITION SIGNAL

Wiring Diagram (Cont'd)

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN THE ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
21	Y/R	IGNITION SIGNAL NO. 1	ENGINE RUNNING AT IDLE SPEED UNDER THE WARM UP CONDITION	0 - 0.2V ★ 
22	G/R	IGNITION SIGNAL NO. 2		
23	L/R	IGNITION SIGNAL NO. 3		
30	GY	IGNITION SIGNAL NO. 4		
31	PU/W	IGNITION SIGNAL NO. 5		
32	GY/R	IGNITION SIGNAL NO. 6		
			ENGINE RUNNING AT 2,500 RPM	0 - 0.2V ★ 

★ : AVERAGE VOLTAGE FOR PULSE SIGNAL (A CTUAL PULSE SIGNAL CAN BE CONFIRMED BY OSCILLOSCOPE.)

SEF860Y

## Diagnostic Procedure

NFEC0865


<b>1</b>	<b>INSPECTION START</b>
Turn ignition switch "OFF", and restart engine. <b>Is engine running?</b>	
<b>Yes or No</b>	
Yes (With CONSULT-II) ►	GO TO 2.
Yes (Without CONSULT-II) ►	GO TO 3.
No ►	GO TO 4.


<b>2</b>	<b>CHECK OVERALL FUNCTION</b>																				
<p>④ <b>With CONSULT-II</b></p> <p>1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.</p> <p>2. Make sure that all circuits do not produce a momentary engine speed drop.</p>																					
<table border="1" style="margin: auto;"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>POWER BALANCE</td><td></td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>MAS AIF SE-B1</td><td>XXX V</td></tr> <tr><td>IACV-AAC/V</td><td>XXX step</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table>		ACTIVE TEST		POWER BALANCE		MONITOR		ENG SPEED	XXX rpm	MAS AIF SE-B1	XXX V	IACV-AAC/V	XXX step								
ACTIVE TEST																					
POWER BALANCE																					
MONITOR																					
ENG SPEED	XXX rpm																				
MAS AIF SE-B1	XXX V																				
IACV-AAC/V	XXX step																				
<b>OK or NG</b>																					
OK ►	<b>INSPECTION END</b>																				
NG ►	GO TO 13.																				

SEF070Y

# IGNITION SIGNAL



Diagnostic Procedure (Cont'd)


<b>3</b>	<b>CHECK OVERALL FUNCTION</b>		
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> <li>1. Let engine idle.</li> <li>2. Read the voltage signal between ECM terminals 21, 22, 23, 30, 31, 32 and ground with an oscilloscope.</li> <li>3. Verify that the oscilloscope screen shows the signal wave as shown below.</li> </ol>			
			
SEF071Y			
<b>OK or NG</b>			
OK	▶	<b>INSPECTION END</b>	
NG	▶	GO TO 13.	

<b>4</b>	<b>CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I</b>		
<ol style="list-style-type: none"> <li>1. Turn ignition switch ON.</li> <li>2. Check voltage between ECM terminals 110, 112 and ground with CONSULT-II or tester.</li> </ol>			
			
SEF366X			
<b>OK or NG</b>			
OK	▶	GO TO 5.	
NG	▶	Go to TROUBLE DIAGNOSIS FOR POWER SUPPLY, EC-127.	

# IGNITION SIGNAL

Diagnostic Procedure (Cont'd)


5	CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II
<p>1. Turn ignition switch OFF. 2. Disconnect condenser harness connector.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Intake manifold collector</p> <p style="margin-left: 450px;">Condenser</p> </div> <p style="text-align: right;">SEF275X</p> <p>3. Turn ignition switch ON. 4. Check voltage between condenser terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="margin-left: 150px;">Voltage: Battery voltage</p> <p style="margin-left: 150px;">OK or NG</p> </div> <p style="text-align: right;">SEF367X</p>	
OK	▶ GO TO 11.
NG	▶ GO TO 6.

6	CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III
<p>1. Turn ignition switch OFF. 2. Disconnect ECM relay.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Battery</p> <p style="margin-left: 150px;">ECM relay</p> </div> <p style="text-align: right;">SEF589PB</p> <p>3. Check harness continuity between ECM relay terminal 7 and condenser terminal 1. Refer to Wiring Diagram. <b>Continuity should exist.</b></p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

## IGNITION SIGNAL


Diagnostic Procedure (Cont'd)

<b>7</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors F18, E15</li> <li>● Harness for open or short between ECM relay and condenser</li> </ul>	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

<b>8</b>	<b>CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV</b>
Check voltage between ECM relay terminal 6 and ground with CONSULT-II or tester.	
	
OK or NG	
OK	▶ GO TO 10.
NG	▶ GO TO 9.

SEF368X

<b>9</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● 15A fuse</li> <li>● Harness for open and short between ECM relay and fuse</li> </ul>	
▶	Repair or replace harness or connectors.


<b>10</b>	<b>CHECK ECM RELAY</b>						
1. Apply 12V direct current between ECM relay terminals 1 and 2. 2. Check continuity between ECM relay terminals 3 and 5, 6 and 7.							
							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Condition</th> <th style="width: 40%;">Continuity</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>OFF</td> <td style="text-align: center;">No</td> </tr> </tbody> </table>		Condition	Continuity	12V direct current supply between terminals 1 and 2	Yes	OFF	No
Condition	Continuity						
12V direct current supply between terminals 1 and 2	Yes						
OFF	No						
OK or NG							
OK	▶ GO TO 18.						
NG	▶ Replace ECM relay.						

SEF296X

# IGNITION SIGNAL




Diagnostic Procedure (Cont'd)

11		CHECK CONDENSER GROUND CIRCUIT FOR OPEN AND SHORT
1. Turn ignition switch OFF. 2. Check harness continuity between condenser terminal 2 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b> 3. Also check harness for short to power.		
<b>OK or NG</b>		
OK	▶	GO TO 12.
NG	▶	Repair open circuit or short to power in harness or connectors.

12		CHECK CONDENSER
Check resistance between condenser terminals 1 and 2.		
		
SEF369X		
<b>OK or NG</b>		
OK	▶	GO TO 13.
NG	▶	Replace condenser.

## IGNITION SIGNAL

Diagnostic Procedure (Cont'd)

<b>13</b>	<b>CHECK IGNITION COIL POWER SUPPLY CIRCUIT-V</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch OFF.</li> <li>2. Reconnect harness connectors disconnected.</li> <li>3. Disconnect ignition coil harness connector.</li> </ol>	
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>Oil filler cap</p> <p>Ignition coil (Bank 2) harness connector</p> </div> <div style="text-align: center;">  <p>Ignition coil (Bank 1) harness connector</p> <p>Intake manifold collector</p> </div> </div> <p style="text-align: right;">SEF274XA</p>	
<ol style="list-style-type: none"> <li>4. Turn ignition switch ON.</li> <li>5. Check voltage between ignition coil terminal 3 and ground with CONSULT-II or tester.</li> </ol>	
 <p style="text-align: center;">Voltage: Battery voltage</p>	
OK or NG	
OK	▶ GO TO 15.
NG	▶ GO TO 14.


<b>14</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the harness for open or short between ignition coil and harness connector F18.	
▶	Repair or replace harness or connectors.

<b>15</b>	<b>CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT</b>
<ol style="list-style-type: none"> <li>1. Turn ignition switch OFF.</li> <li>2. Check harness continuity between ignition coil terminal 2 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b></li> <li>3. Also check harness for short to power.</li> </ol>	
OK or NG	
OK	▶ GO TO 16.
NG	▶ Repair open circuit or short to power in harness or connectors.

# IGNITION SIGNAL

Diagnostic Procedure (Cont'd)

<b>16</b>	<b>CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminals 21, 22, 23, 30, 31, 32 and ignition coil terminal 1. Refer to Wiring Diagram.  <span style="color: blue;">Continuity should exist.</span></p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 17.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

<b>17</b>	<b>CHECK IGNITION COIL WITH POWER TRANSISTOR</b>									
<p>Check resistance between ignition coil terminals 2 and 3.</p> <div style="display: flex; align-items: center; justify-content: space-around;">  <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Terminals</th> <th style="text-align: center;">Resistance</th> <th style="text-align: center;">Result</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">2 and 3</td> <td style="text-align: center;">Not 0Ω</td> <td style="text-align: center;">OK</td> </tr> <tr> <td style="text-align: center;">0Ω</td> <td style="text-align: center;">NG</td> </tr> </tbody> </table> </div> <p style="text-align: right;">SEF371X</p> <p style="text-align: center;"><b>OK or NG</b></p>			Terminals	Resistance	Result	2 and 3	Not 0Ω	OK	0Ω	NG
Terminals	Resistance	Result								
2 and 3	Not 0Ω	OK								
	0Ω	NG								
OK	▶	GO TO 18.								
NG	▶	Replace ignition coil with power transistor.								

<b>18</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.</p>		
▶		<b>INSPECTION END</b>

## **A/T DIAGNOSIS COMMUNICATION LINE**

*Component Description*

---

### **Component Description**

The malfunction information related to A/T (Automatic Transmission) is transferred through the line (circuit) from TCM (Transmission control module) to ECM. NFEC0361




# A/T DIAGNOSIS COMMUNICATION LINE

Wiring Diagram

## Wiring Diagram

=NFEC0365

### EC-ATDG1-01



MEC078D

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
60	BR/W	A/T DIAGNOSIS COMMUNICATION LINE	ENGINE RUNNING AT IDLE SPEED	VOLTAGE FLUCTUATES BETWEEN 0 to 2V.


SEF048YA




# A/T DIAGNOSIS COMMUNICATION LINE

Diagnostic Procedure

## Diagnostic Procedure

NFEC0366

<b>1</b>	<b>CHECK OVERALL FUNCTION</b>	
<p>1. Start engine and warm it up to normal operating temperature.                  2. Check the voltage between ECM terminal 60 and ground.</p>		
 <p style="margin-left: 400px;"><b>Voltage should fluctuate between 0 - 2V.</b></p>		
SEF025Y		
<b>OK or NG</b>		
OK	▶	<b>INSPECTION END</b>
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK A/T DIAGNOSIS COMMUNICATION LINE INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect ECM harness connector and TCM (Transmission Control Module) harness connector.</p>		
<p><b>LHD models View with glove box removed</b></p>  <p style="margin-left: 400px;"><b>RHD models</b></p> 		
SEF044Y		
<p><b>View with center console removed</b></p> 		
SEF271X		
<p>3. Check harness continuity between ECM terminal 60 and TCM terminal 15. Refer to Wiring Diagram.  <span style="color: blue;"><b>Continuity should exist.</b></span></p> <p>4. Also check harness for short to ground and short to power.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.


## A/T DIAGNOSIS COMMUNICATION LINE

*Diagnostic Procedure (Cont'd)*

<b>3</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

## PARK/NEUTRAL POSITION (PNP) SWITCH

### Component Description



### Component Description

NFEC0367

When the gear position is "P" (A/T models only) or "N", park/neutral position (PNP) switch is "ON".

ECM detects the position because the continuity of the line (the "ON" signal) exists.

For A/T models, the park/neutral position (PNP) switch assembly also includes a transmission range switch to detect selector lever position.

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0368

Specification data are reference values.



MONITOR ITEM	CONDITION		SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: "P" or "N" (A/T models) Neutral (M/T models)	ON
		Except above	OFF

# PARK/NEUTRAL POSITION (PNP) SWITCH

Wiring Diagram

## Wiring Diagram

NFEC0373



MEC053D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
44	G/OR (A/T) G/W (M/T)	PARK/NEUTRAL POSITION (PNP) SWITCH	IGN ON WITH GEAR POSITION "N" OR "P"(A/T), GEAR POSITION NEUTRAL (M/T)	APPROX. 0V
			IGN ON WITHOUT THE ABOVE GEAR POSITION	BATTERY VOLTAGE

SEF635XC

# PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure


## Diagnostic Procedure FOR M/T MODELS

NFEC0374

NFEC0374S01


<b>1</b>	<b>INSPECTION START</b>	
Do you have CONSULT-II?		
<b>Yes or No</b>		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

<b>2</b>	<b>CHECK OVERALL FUNCTION</b>							
<p><b>Ⓜ With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>Turn ignition switch "ON".</li> <li>Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II.</li> <li>Check the "P/N POSI SW" signal under the following conditions.</li> </ol>								
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>P/N POSI SW</td> <td>ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	P/N POSI SW	ON
DATA MONITOR								
MONITOR	NO DTC							
P/N POSI SW	ON							
<table border="1" style="margin: auto;"> <thead> <tr> <th>Shift lever position</th> <th>P/N POSI SW</th> </tr> </thead> <tbody> <tr> <td>Neutral position</td> <td>ON</td> </tr> <tr> <td>Except the above position</td> <td>OFF</td> </tr> </tbody> </table>			Shift lever position	P/N POSI SW	Neutral position	ON	Except the above position	OFF
Shift lever position	P/N POSI SW							
Neutral position	ON							
Except the above position	OFF							
SEF049Y								
<b>OK or NG</b>								
OK	▶	<b>INSPECTION END</b>						
NG	▶	GO TO 4.						

<b>3</b>	<b>CHECK OVERALL FUNCTION</b>							
<p><b>⊗ Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>Turn ignition switch "ON".</li> <li>Check voltage between ECM terminal 44 and ground under the following conditions.</li> </ol>								
								
<table border="1" style="margin: auto;"> <thead> <tr> <th>Shift lever position</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Neutral position</td> <td>Apporox. 0V</td> </tr> <tr> <td>Except the above position</td> <td>Battery voltage</td> </tr> </tbody> </table>			Shift lever position	Voltage	Neutral position	Apporox. 0V	Except the above position	Battery voltage
Shift lever position	Voltage							
Neutral position	Apporox. 0V							
Except the above position	Battery voltage							
SEF050Y								
<b>OK or NG</b>								
OK	▶	<b>INSPECTION END</b>						
NG	▶	GO TO 4.						

## PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect park/neutral position (PNP) switch harness connector.</p>		
 <p style="text-align: center;">Park/neutral position (PNP) switch</p>		
AEC877A		
<p>3. Check harness continuity between PNP switch terminal 4 and engine ground. Refer to Wiring Diagram.  <span style="color: blue;">Continuity should exist.</span></p> <p>4. Also check harness for short to power.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 5.
NG	▶	Repair open circuit or short to power in harness or connectors.

<b>5</b>	<b>CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 44 and PNP switch terminal 3. Refer to Wiring Diagram.  <span style="color: blue;">Continuity should exist.</span></p> <p>3. Also check harness for short to ground and short to power.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

<b>6</b>	<b>CHECK PARK/NEUTRAL POSITION (PNP) SWITCH</b>	
Refer to MT-9, "Position Switch Check".		
<b>OK or NG</b>		
OK	▶	GO TO 7.
NG	▶	Replace park/neutral position (PNP) switch.

<b>7</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

# PARK/NEUTRAL POSITION (PNP) SWITCH


Diagnostic Procedure (Cont'd)

## FOR A/T MODELS

=NFEC0374S02


<b>1</b>	<b>INSPECTION START</b>	
Do you have CONSULT-II?		
<b>Yes or No</b>		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

<b>2</b>	<b>CHECK OVERALL FUNCTION</b>							
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II.</li> <li>3. Check the "P/N POSI SW" signal under the following conditions.</li> </ol>								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>P/N POSI SW</td> <td>ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	P/N POSI SW	ON
DATA MONITOR								
MONITOR	NO DTC							
P/N POSI SW	ON							
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th>Selector lever position</th> <th>P/N POSI SW</th> </tr> </thead> <tbody> <tr> <td>"N" and "P" position</td> <td>ON</td> </tr> <tr> <td>Except the above position</td> <td>OFF</td> </tr> </tbody> </table>			Selector lever position	P/N POSI SW	"N" and "P" position	ON	Except the above position	OFF
Selector lever position	P/N POSI SW							
"N" and "P" position	ON							
Except the above position	OFF							
SEF028Y								
<b>OK or NG</b>								
OK	▶	<b>INSPECTION END</b>						
NG	▶	GO TO 4.						

<b>3</b>	<b>CHECK OVERALL FUNCTION</b>							
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Check voltage between ECM terminal 44 and ground under the following conditions.</li> </ol>								
								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th>Selector lever position</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>"P" and "N" position</td> <td>Apporox. 0V</td> </tr> <tr> <td>Except the above position</td> <td>Battery voltage</td> </tr> </tbody> </table>			Selector lever position	Voltage	"P" and "N" position	Apporox. 0V	Except the above position	Battery voltage
Selector lever position	Voltage							
"P" and "N" position	Apporox. 0V							
Except the above position	Battery voltage							
SEF029Y								
<b>OK or NG</b>								
OK	▶	<b>INSPECTION END</b>						
NG	▶	GO TO 4.						

## PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect park/neutral position (PNP) switch harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF279X</p> <p>3. Check harness continuity between PNP switch terminal 2 and engine ground. Refer to Wiring Diagram.  <b>Continuity should exist.</b></p> <p>4. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

<b>5</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F10, F151</li> <li>● Harness for open or short between park/neutral position (PNP) switch and engine ground</li> </ul>		
		▶ Repair open circuit or short to power in harness or connectors.

<b>6</b>	<b>CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Disconnect ECM harness connector.                  2. Check harness continuity between ECM terminal 44 and PNP switch terminal 1. Refer to Wiring Diagram.  <b>Continuity should exist.</b></p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 8.
NG	▶	GO TO 7.

<b>7</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F10, F151</li> <li>● Harness for open or short between ECM and park/neutral position (PNP) switch</li> </ul>		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.

<b>8</b>	<b>CHECK PARK/NEUTRAL POSITION (PNP) SWITCH</b>	
<p>Refer to AT-125, "Diagnostic Procedure".</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 9.
NG	▶	Replace park/neutral position (PNP) switch.

## **PARK/NEUTRAL POSITION (PNP) SWITCH**

*Diagnostic Procedure (Cont'd)*

<b>9</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)


Description

## Description SYSTEM DESCRIPTION

NFEC0596

NFEC0596S01

Sensor	Input Signal to ECM	ECM function	Actuator
Mass air flow sensor	Amount of intake air	VIAS control	VIAS control solenoid valve
Throttle position sensor	Throttle position		
Closed throttle position	Throttle valve idle position		
Ignition switch	Start signal		
Crankshaft position sensor (POS)	Engine speed (POS signal)		
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Engine coolant temperature sensor	Engine coolant temperature		



SEF599X


When the engine is running at low or medium speed, the power valve is fully closed. Under this condition, the effective suction port length is equivalent to the total length of the intake manifold collector's suction port including the intake valve. This long suction port provides increased air intake which results in improved suction efficiency and higher torque generation.

The surge tank and one-way valve are provided. When engine is running at high speed, the ECM sends the signal to the VIAS control solenoid valve. This signal introduces the intake manifold vacuum into the power valve actuator and therefore opens the power valve to two suction passages together in the collector.

Under this condition, the effective port length is equivalent to the length of the suction port provided independently for each cylinder. This shortened port length results in enhanced engine output with reduced suction resistance under high speeds.

## VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)

Description (Cont'd)




### COMPONENT DESCRIPTION

#### Power Valve

NFEC0596S02

NFEC0596S0201

The power valve is installed in intake manifold collector and used to control the suction passage of the variable induction air control system. It is set in the fully closed or fully opened position by the power valve actuator operated by the vacuum stored in the surge tank. The vacuum in the surge tank is controlled by the VIAS control solenoid valve.



#### VIAS Control Solenoid Valve

NFEC0596S0202

The VIAS control solenoid valve cuts the intake manifold vacuum signal for power valve control. It responds to ON/OFF signals from the ECM. When the solenoid is off, the vacuum signal from the intake manifold is cut. When the ECM sends an ON signal the coil pulls the plunger downward and feeds the vacuum signal to the power valve actuator.

# VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)



Wiring Diagram

## Wiring Diagram

NFEC0597


### EC-VIAS/V-01

— : DETECTABLE LINE FOR DTC  
 — : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M19) - FUSE BLOCK - JUNCTION BOX (J/B)



MEC862C

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
16	Y/G	VIAS CONTROL SOLENOID VALVE	ENGINE RUNNING AT IDLE SPEED	BATTERY VOLTAGE
			ENGINE RUNNING ABOVE 5,000 RPM	0 - 1.0V



SEF636XB

# VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)

Diagnostic Procedure

## Diagnostic Procedure

NFEC0598




<b>1</b>	<b>CHECK OVERALL FUNCTION</b>																				
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Perform "VIAS SOL VALVE" in "ACTIVE TEST" mode with CONSULT-II.</li> <li>3. Turn VIAS control solenoid valve "ON" and "OFF", and make sure that power valve actuator rod moves.</li> </ol>																					
		<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>VIAS SOL VALVE</th> <th>OFF</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> </thead> <tbody> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>IACV-AAC/V</td> <td>XXX step</td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>	ACTIVE TEST		VIAS SOL VALVE	OFF	MONITOR		ENG SPEED	XXX rpm	IACV-AAC/V	XXX step									 <p style="text-align: right; margin-right: 50px;">Power valve actuator</p>
ACTIVE TEST																					
VIAS SOL VALVE	OFF																				
MONITOR																					
ENG SPEED	XXX rpm																				
IACV-AAC/V	XXX step																				
SEC236C																					
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Rev engine quickly up to above 5,000 rpm and make sure that power valve actuator rod moves.</li> </ol>																					
		 <p style="text-align: center;">Power valve actuator</p>																			
OK or NG																					
OK	▶	INSPECTION END																			
NG	▶	GO TO 2.																			

SEC236C

SEF052Y

# VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)

Diagnostic Procedure (Cont'd)

<b>2</b>	<b>CHECK VIAS CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT</b>	
<p>1. Stop engine. 2. Disconnect VIAS control solenoid valve harness connector.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF288X</p> <p>3. Turn ignition switch "ON". 4. Check voltage between terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <div style="text-align: center;">  <p style="margin-left: 100px;"><b>Voltage: Battery voltage</b></p> </div> <p style="text-align: right;">SEF603X</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 4.
NG	▶	GO TO 3.

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors M46, F44</li> <li>● 15A fuse</li> <li>● Harness continuity between fuse and VIAS control solenoid valve</li> </ul>		
▶		Repair harness or connectors.

<b>4</b>	<b>CHECK VIAS CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 16 and terminal 2. Refer to Wiring Diagram. <b>Continuity should exist.</b> 4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 5.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

## VARIABLE INDUCTION AIR CONTROL SYSTEM (VIAS)


Diagnostic Procedure (Cont'd)

<b>5</b>	<b>RETEST OVERALL FUNCTION</b>
1. Reconnect harness connectors disconnected. 2. Perform Test No. 1 again.	
<b>OK or NG</b>	
OK	▶ <b>INSPECTION END</b>
NG	▶ GO TO 6.

<b>6</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
<b>OK or NG</b>	
OK	▶ Replace VIAS control solenoid valve as intake manifold collector assembly.
NG	▶ Repair or replace harness or connectors.

# INJECTOR

Component Description



## Component Description

NFEC0383

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0384

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
INJ PULSE-B2 INJ PULSE-B1	<ul style="list-style-type: none"> <li>● Engine: After warming up</li> <li>● Air conditioner switch: "OFF"</li> <li>● Shift lever: "N"</li> <li>● No-load</li> </ul>	Idle	2.4 - 3.2 msec
		2,000 rpm	1.9 - 2.8 msec
B/FUEL SCHDL	ditto	Idle	2.0 - 3.2 msec
		2,000 rpm	1.4 - 2.6 msec


# INJECTOR

Wiring Diagram


## Wiring Diagram

NFEC0386

### EC-INJECT-01



REFER TO THE FOLLOWING.  
 (M19) - FUSE BLOCK-JUNCTION BOX (J/B)



MEC863C

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
101	R/B	INJECTOR NO. 1	ENGINE RUNNING AT IDLE SPEED UNDER WARM-UP CONDITION	BATTERY VOLTAGE  (V) 15 10 0  100 ms
102	L/W	INJECTOR NO. 5		
103	R/W	INJECTOR NO. 2		
104	PU/R	INJECTOR NO. 6		
105	R/Y	INJECTOR NO. 3		
107	R/L	INJECTOR NO. 4		

SEF862Y

# INJECTOR

Diagnostic Procedure

## Diagnostic Procedure

NFEC0387

<b>1</b>	<b>INSPECTION START</b>	
Turn ignition switch to "START". <b>Is any cylinder ignited?</b>		
<b>Yes or No</b>		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

<b>2</b>	<b>CHECK OVERALL FUNCTION</b>	
----------	-------------------------------	--

**With CONSULT-II**

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS AIF SE-B1	XXX V
IACV-AAC/V	XXX step

SEF070Y

3. Make sure that each circuit produces a momentary engine speed drop.

**Without CONSULT-II**

1. Start engine.
2. Listen to each injector operating sound.



MEC703B

**Clicking noise should be heard.**

**OK or NG**


OK	▶	<b>INSPECTION END</b>
NG	▶	GO TO 3.

# INJECTOR


Diagnostic Procedure (Cont'd)

## 3 CHECK INJECTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect injector harness connectors (bank 2) and harness connectors F43, F191 (bank 1).




SEF276X



SEF281XA

3. Turn ignition switch "ON".
4. Check voltage between injector terminal 1 and ground, harness connector F43 terminal 5 and ground with CONSULT-II or tester.



SEF897X

OK or NG

OK	▶	GO TO 5.
NG	▶	GO TO 4.

## 4 DETECT MALFUNCTIONING PART

- Check the following.
- Harness connectors M46, F44
  - Harness connectors F43, F191
  - Fuse block (J/B) connector M19
  - 10A fuse
  - Harness for open or short between injector and fuse
  - Harness for open or short between harness connector F43 and fuse

	▶	Repair harness or connectors.
--	---	-------------------------------


# INJECTOR

Diagnostic Procedure (Cont'd)

<b>5</b>	<b>CHECK INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between injector terminal 2 and ECM terminals 103, 104, 107, harness connector F191 terminals 6, 2, 1 and ECM terminals 101, 105, 102. Refer to Wiring Diagram.  <span style="color: blue;">Continuity should exist.</span></p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 7.
NG	▶	GO TO 6.

<b>6</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F43, F191</li> <li>● Harness for open or short between harness connector F191 and ECM</li> <li>● Harness for open or short between ECM and injector</li> </ul>		
▶		Repair open circuit or short to ground or short to power in harness or connectors.

<b>7</b>	<b>CHECK SUB-HARNESS CIRCUIT FOR OPEN AND SHORT (BANK 1)</b>							
<p>1. Remove intake manifold collector.</p> <p>2. Disconnect injector harness connectors (bank 1).</p> <p>3. Check harness continuity between the following terminals. Refer to Wiring Diagram.</p>								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="padding: 5px;">Harness connector F191</th> <th style="padding: 5px;">Injector F192, F193, F194</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; padding: 5px;">5</td> <td style="text-align: center; padding: 5px;">1</td> </tr> <tr> <td style="text-align: center; padding: 5px;">6, 2, 1</td> <td style="text-align: center; padding: 5px;">2</td> </tr> </tbody> </table>			Harness connector F191	Injector F192, F193, F194	5	1	6, 2, 1	2
Harness connector F191	Injector F192, F193, F194							
5	1							
6, 2, 1	2							
MTBL0359								
<span style="color: blue;">Continuity should exist.</span>								
<b>OK or NG</b>								
OK	▶	GO TO 8.						
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.						

<b>8</b>	<b>CHECK INJECTOR</b>	
<p>1. Disconnect injector harness connector.</p> <p>2. Check resistance between terminals as shown in the figure.</p>		
		
SEF964XA		
<b>OK or NG</b>		
OK	▶	GO TO 9.
NG	▶	Replace injector.

## INJECTOR

*Diagnostic Procedure (Cont'd)*

<b>9</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

## START SIGNAL

CONSULT-II Reference Value in Data Monitor Mode

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0388

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
START SIGNAL	• Ignition switch: ON → START → ON	OFF → ON → OFF



# START SIGNAL


Diagnostic Procedure

## Diagnostic Procedure

NFEC0391

<b>1</b>	<b>INSPECTION START</b>	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

<b>2</b>	<b>CHECK OVERALL FUNCTION</b>													
<p> <b>With CONSULT-II</b></p> <p>1. Turn ignition switch "ON".</p> <p>2. Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.</p>														
<table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>START SIGNAL</td> <td>OFF</td> </tr> <tr> <td>CLSD THL POS</td> <td>ON</td> </tr> <tr> <td>AIR COND SIG</td> <td>OFF</td> </tr> <tr> <td>P/N POSI SW</td> <td>ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	START SIGNAL	OFF	CLSD THL POS	ON	AIR COND SIG	OFF	P/N POSI SW	ON
DATA MONITOR														
MONITOR	NO DTC													
START SIGNAL	OFF													
CLSD THL POS	ON													
AIR COND SIG	OFF													
P/N POSI SW	ON													
<table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th>Condition</th> <th>"START SIGNAL"</th> </tr> </thead> <tbody> <tr> <td>Ignition switch "ON"</td> <td>OFF</td> </tr> <tr> <td>Ignition switch "START"</td> <td>ON</td> </tr> </tbody> </table>			Condition	"START SIGNAL"	Ignition switch "ON"	OFF	Ignition switch "START"	ON						
Condition	"START SIGNAL"													
Ignition switch "ON"	OFF													
Ignition switch "START"	ON													
SEF072Y														
OK or NG														
OK	▶	<b>INSPECTION END</b>												
NG	▶	GO TO 4.												

<b>3</b>	<b>CHECK OVERALL FUNCTION</b>							
<p> <b>Without CONSULT-II</b></p> <p>Check voltage between ECM terminal 42 and ground under the following conditions.</p>								
								
<table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Ignition switch "START"</td> <td>Battery voltage</td> </tr> <tr> <td>Other positions</td> <td>Approximately 0V</td> </tr> </tbody> </table>			Condition	Voltage	Ignition switch "START"	Battery voltage	Other positions	Approximately 0V
Condition	Voltage							
Ignition switch "START"	Battery voltage							
Other positions	Approximately 0V							
SEF362X								
OK or NG								
OK	▶	<b>INSPECTION END</b>						
NG	▶	GO TO 4.						

<b>4</b>	<b>CHECK STARTING SYSTEM</b>	
Turn ignition switch "OFF", then turn it to "START".		
<b>Does starter motor operate?</b>		
Yes or No		
Yes	▶	GO TO 5.
No	▶	Refer to SC-12, "STARTING SYSTEM".

## START SIGNAL

Diagnostic Procedure (Cont'd)

5		CHECK FUSE
1. Turn ignition switch "OFF". 2. Disconnect 10A fuse. 3. Check if 10A fuse is OK.		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Replace 10A fuse.

6		CHECK START SIGNAL INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
1. Disconnect ECM harness connector. 2. Disconnect ignition switch harness connector. 3. Check harness continuity between ECM terminal 42 and fuse block, ignition switch and fuse block. Refer to Wiring Diagram. <b>Continuity should exist.</b> 4. Also check harness for short to ground and short to power.		
OK or NG		
OK	▶	GO TO 8.
NG	▶	GO TO 7.

7		DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"><li>● Harness connectors M46, F44</li><li>● Fuse block (J/B) connectors M17, E83</li><li>● Harness for open or short between ignition switch and fuse</li><li>● Harness for open or short between ECM and fuse</li></ul>		
	▶	Repair open circuit or short to ground or short to power in harness or connectors.

8		CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
	▶	INSPECTION END

# FUEL PUMP

System Description


## System Description

NFEC0392

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed (POS signal)	Fuel pump control	Fuel pump relay
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Ignition switch	Start signal		

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a 120° signal from the crankshaft position sensor (REF), it knows that the engine is rotating, and causes the pump to operate. If the 120° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second.
Engine running and cranking	Operates.
When engine is stopped	Stops in 1.5 seconds.
Except as shown above	Stops.



## Component Description

NFEC0393

The fuel pump with a fuel damper is an in-tank type (the pump and damper are located in the fuel tank).

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0394

Specification data are reference values.



MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> <li>● Ignition switch is turned to ON. (Operates for 1 second.)</li> <li>● Engine running and cranking</li> </ul>	ON
	Except as shown above	OFF

# FUEL PUMP

Wiring Diagram

## Wiring Diagram

NFEC0396



MEC048D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**  
 DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
28	B/P	FUEL PUMP RELAY	FOR 1 SECOND AFTER IGN ON	0 - 1.5V
			ENGINE RUNNING	
			MORE THAN 1 SECOND AFTER IGN ON	BATTERY VOLTAGE (11 - 14V)


SEF639XB



# FUEL PUMP

Diagnostic Procedure

## Diagnostic Procedure

NFEC0397


<b>1</b>	<b>CHECK OVERALL FUNCTION</b>		
<ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Pinch fuel feed hose with two fingers.</li> </ol>			
			
SEC013C			
<p style="text-align: center;"><b>Fuel pressure pulsation should be felt on the fuel feed hose for 1 second after ignition switch is turned "ON".</b></p> <p style="text-align: center;"><b>OK or NG</b></p>			
OK	▶	<b>INSPECTION END</b>	
NG	▶	GO TO 2.	

<b>2</b>	<b>CHECK FUEL PUMP RELAY POWER SUPPLY CIRCUIT</b>		
<ol style="list-style-type: none"> <li>1. Turn ignition switch "OFF".</li> <li>2. Disconnect fuel pump relay.</li> </ol>			
			
SEF284X			
<ol style="list-style-type: none"> <li>3. Turn ignition switch "ON".</li> <li>4. Check voltage between terminals 1, 5 and ground with CONSULT-II or tester.</li> </ol>			
			
SEF310Y			
<b>OK or NG</b>			
OK	▶	GO TO 4.	
NG	▶	GO TO 3.	

## FUEL PUMP

Diagnostic Procedure (Cont'd)

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Fuse block (J/B) connector B5</li> <li>● 10A fuse</li> <li>● 15A fuse</li> <li>● Harness for open or short between fuse and fuel pump relay</li> </ul>	
▶ Repair harness or connectors.	

<b>4</b>	<b>CHECK FUEL PUMP POWER SUPPLY AND GROUND CIRCUIT FOR OPEN AND SHORT</b>
1. Turn ignition switch "OFF". 2. Disconnect fuel level sensor unit and fuel pump harness connector.	
 <p style="text-align: right;">SEF263X</p>	
3. Check harness continuity between fuel pump terminal 3 and body ground, fuel pump terminal 1 and fuel pump relay terminal 3. Refer to Wiring Diagram. <b>Continuity should exist.</b>	
4. Also check harness for short to ground and short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

<b>5</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness for open or short between fuel pump relay and fuel pump</li> <li>● Harness for open or short between fuel pump and body ground</li> </ul>	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

<b>6</b>	<b>CHECK FUEL PUMP RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>
1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 28 and fuel pump relay terminal 2. Refer to Wiring Diagram. <b>Continuity should exist.</b>	
3. Also check harness for short to ground and short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

<b>7</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors B3, M6 or B4, M3</li> <li>● Harness connectors M81, F49</li> <li>● Harness for open or short between ECM and fuel pump relay</li> </ul>	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

# FUEL PUMP

Diagnostic Procedure (Cont'd)

## 8 CHECK FUEL PUMP RELAY

### Ⓟ With CONSULT-II

1. Reconnect fuel pump relay, fuel level sensor unit and fuel pump harness connector and ECM harness connector.
2. Turn ignition switch "ON".
3. Turn fuel pump relay "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT-II and check operating sound.



ACTIVE TEST	
FUEL PUMP RELAY	ON
MONITOR	
ENG SPEED	XXX rpm

SEF073Y



### ⓧ Without CONSULT-II

Check continuity between terminals 3 and 5 under the following conditions.

LHD models



RHD models



Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

SEF367Z

OK or NG



OK                      ►      GO TO 9.

NG                      ►      Replace fuel pump relay.

## 9 CHECK FUEL PUMP

1. Disconnect fuel level sensor unit and fuel pump harness connector.
2. Check resistance between fuel level sensor unit and fuel pump terminals 1 and 3.

View with rear seat removed



Resistance: 0.2 - 5.0 Ω [at 25°C (77°F)]

SEF609X

OK or NG

OK                      ►      GO TO 10.

NG                      ►      Replace fuel pump.

## FUEL PUMP

Diagnostic Procedure (Cont'd)

<b>10</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# ELECTRONIC CONTROLLED ENGINE MOUNT

*System Description*

## System Description

NFEC0599

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed (POS signal)	Engine mount control	Electronic controlled engine mount
Crankshaft position sensor (REF)	Engine speed (REF signal)		
Vehicle speed sensor	Vehicle speed		

The ECM controls the engine mount operation corresponding to the engine speed and the vehicle speed. The control system has 2-step control [soft/hard].

Vehicle condition	Engine mount control
Idle (with vehicle stopped)	Soft
Driving	Hard

## CONSULT-II Reference Value in Data Monitor Mode

NFEC0600

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENGINE MOUNT	<ul style="list-style-type: none"> <li>● Engine: Running</li> </ul>	Idle
		2,000 rpm


# ELECTRONIC CONTROLLED ENGINE MOUNT

Wiring Diagram

## Wiring Diagram

NFEC0602

### EC-EMNT-01



101	102	1	2	3	4	5	6	7	8	9	10	58	59	60	61	62	63	64	65	66	67	109	110									
103	104	11	12	13	14	15	16	17	18	19	39	40	41	42	43	44	45	46	47	48	68	69	70	71	72	73	74	75	76	111	112	
105	106	20	21	22	23	24	25	26	27	28	29	49	50	51	52	53	54	55	56	57	77	78	79	80	81	82	83	84	85	86	113	114
107	108	30	31	32	33	34	35	36	37	38																					115	116



MEC866C

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:

DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
49	W	ELECTRONIC CONTROLLED ENGINE MOUNT-1	ENGINE RUNNING AT IDLE SPEED	0 - 1.0V
			ENGINE RUNNING AT 2,000 RPM	BATTERY VOLTAGE
50	W/R	ELECTRONIC CONTROLLED ENGINE MOUNT-2	ENGINE RUNNING AT IDLE SPEED	BATTERY VOLTAGE
			ENGINE RUNNING AT 2,000 RPM	0 - 1.0V

SEF640XB

# ELECTRONIC CONTROLLED ENGINE MOUNT

Diagnostic Procedure

## Diagnostic Procedure

NFEC0603

### 1 CHECK THE OVERALL FUNCTION


#### ④ With CONSULT-II

1. After warming up engine, run it at idle speed.
2. Shift selector lever to "D" range while depressing the brake pedal and pulling the parking brake control lever.
3. Perform "ENGINE MOUNTING" in "ACTIVE TEST" mode with CONSULT-II and check that the body vibration changes according to switching the condition (With vehicle stopped).


SEC237C

#### ⊗ Without CONSULT-II

1. After warming up engine, run it at idle speed.
2. Shift selector lever to "D" range while depressing the brake pedal and pulling the parking brake control lever.
3. Disconnect front or rear electronic controlled engine mount harness connector when engine speed is more than 1,000 rpm.



#### View with intake air duct



SEF285X


4. When returning engine speed to idle speed, check that the body vibration increases, compared with the condition of the above step 2 (With vehicle stopped).

OK or NG

OK	▶	INSPECTION END
NG	▶	GO TO 2.

## ELECTRONIC CONTROLLED ENGINE MOUNT

Diagnostic Procedure (Cont'd)

<b>2</b>	<b>CHECK ELECTRONIC CONTROLLED ENGINE MOUNT POWER SUPPLY CIRCUIT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect front or rear electronic controlled engine mount harness connector.                  3. Check voltage between electronic controlled engine mount terminal 3 and ground with CONSULT-II or tester.</p>		
 <p style="text-align: right;">Voltage: Battery voltage</p>		
SEF899X		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	GO TO 3.

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors E15, F18</li> <li>● 15A fuse</li> <li>● Harness for open or short between electronic controlled engine mount and battery</li> </ul>		
▶		Repair harness or connectors.


<b>4</b>	<b>CHECK ELECTRONIC CONTROLLED ENGINE MOUNT OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Disconnect ECM harness connector.                  2. Check harness continuity between ECM terminal 49 and electronic controlled engine mount terminal 1, ECM terminal 50 and electronic controlled engine mount terminal 2. Refer to Wiring Diagram.  <b>Continuity should exist.</b>                  3. Also check harness for short to ground and short to power.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 5.
NG	▶	Repair open circuit, short to ground or short to power in harness connectors.

<b>5</b>	<b>CHECK ELECTRONIC CONTROLLED ENGINE MOUNT</b>	
<p>Visually check front and rear electronic controlled engine mount.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	Replace front or rear engine mount assembly.

<b>6</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.</p>		
▶		<b>INSPECTION END</b>

## POWER STEERING OIL PRESSURE SWITCH

*Component Description*



### Component Description

NFEC0398

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.

### CONSULT-II Reference Value in Data Monitor Mode

NFEC0399

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PW/ST SIGNAL	<ul style="list-style-type: none"> <li>● Engine: After warming up, idle the engine</li> </ul>	Steering wheel in neutral position (forward direction) OFF
		The steering wheel is fully turned. ON


# POWER STEERING OIL PRESSURE SWITCH

Wiring Diagram

## Wiring Diagram

NFEC0401

### EC-PST/SW-01



101	1	2	3	4	5	6	7	8	9	10	58	59	60	61	62	63	64	65	66	67	109	110									
103	11	12	13	14	15	16	17	18	19	39	40	41	42	43	44	45	46	47	48	68	69	70	71	72	73	74	75	76	111	112	
105	20	21	22	23	24	25	26	27	28	29	49	50	51	52	53	54	55	56	57	77	78	79	80	81	82	83	84	85	86	113	114
107	30	31	32	33	34	35	36	37	38											87	88	89	90	91	92	93	94	95	115	116	



MEC931C

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**

**DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.**

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
47	G	POWER STEERING OIL PRESSURE SWITCH	ENGINE RUNNING WITH STEERING WHEEL BEING FULLY TURNED	0 - 1.0V
			ENGINE RUNNING WITH STEERING WHEEL NOT BEING TURNED	BATTERY VOLTAGE

SEF641XB

# POWER STEERING OIL PRESSURE SWITCH


Diagnostic Procedure

## Diagnostic Procedure

NFEC0402


<b>1</b>	<b>INSPECTION START</b>	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

<b>2</b>	<b>CHECK OVERALL FUNCTION</b>							
<p> <b>With CONSULT-II</b></p> <p>1. Start engine.</p> <p>2. Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.</p>								
<table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>PW/ST SIGNAL</td> <td>OFF</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	PW/ST SIGNAL	OFF
DATA MONITOR								
MONITOR	NO DTC							
PW/ST SIGNAL	OFF							
<table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th>Conditions</th> <th>PW/ST SIGNAL</th> </tr> </thead> <tbody> <tr> <td>Steering is in neutral position</td> <td>OFF</td> </tr> <tr> <td>Steering is turned</td> <td>ON</td> </tr> </tbody> </table>			Conditions	PW/ST SIGNAL	Steering is in neutral position	OFF	Steering is turned	ON
Conditions	PW/ST SIGNAL							
Steering is in neutral position	OFF							
Steering is turned	ON							
SEF311Y								
<b>OK or NG</b>								
OK	▶	<b>INSPECTION END</b>						
NG	▶	GO TO 4.						

<b>3</b>	<b>CHECK OVERALL FUNCTION</b>							
<p> <b>Without CONSULT-II</b></p> <p>1. Start engine.</p> <p>2. Check voltage between ECM terminal 47 and ground under the following conditions.</p>								
								
<table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th>Conditions</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Steering is neutral position.</td> <td>Approximately 5V</td> </tr> <tr> <td>Steering is turned to full position.</td> <td>Approximately 0V</td> </tr> </tbody> </table>			Conditions	Voltage	Steering is neutral position.	Approximately 5V	Steering is turned to full position.	Approximately 0V
Conditions	Voltage							
Steering is neutral position.	Approximately 5V							
Steering is turned to full position.	Approximately 0V							
SEF363X								
<b>OK or NG</b>								
OK	▶	<b>INSPECTION END</b>						
NG	▶	GO TO 4.						

## POWER STEERING OIL PRESSURE SWITCH

Diagnostic Procedure (Cont'd)

<b>4</b>	<b>CHECK POWER STEERING OIL PRESSURE SWITCH GROUND CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Turn ignition switch "OFF".                  2. Disconnect power steering oil pressure switch harness connector.</p>		
 <p style="text-align: right;">SEF286X</p>		
<p>3. Check harness continuity between power steering oil pressure switch terminal 1 and engine ground. Refer to Wiring Diagram.  <b>Continuity should exist.</b></p> <p>4. Also check harness for short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.


<b>5</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F17, E8 (RHD models)</li> <li>● Harness for open or short between power steering oil pressure switch and body ground</li> </ul>		
▶		Repair open circuit or short to power in harness or connectors.

<b>6</b>	<b>CHECK POWER STEERING OIL PRESSURE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>	
<p>1. Disconnect ECM harness connector.                  2. Check harness continuity between ECM terminal 47 and power steering oil pressure switch terminal 2. Refer to Wiring Diagram.  <b>Continuity should exist.</b></p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 8.
NG	▶	GO TO 7.

<b>7</b>	<b>DETECT MALFUNCTIONING PART</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors F17, E8 (RHD models)</li> <li>● Harness for open or short between power steering oil pressure switch and ECM</li> </ul>		
▶		Repair open circuit or short to ground or short to power in harness or connectors.

# POWER STEERING OIL PRESSURE SWITCH


*Diagnostic Procedure (Cont'd)*

<b>8</b>	<b>CHECK POWER STEERING OIL PRESSURE SWITCH</b>							
<p>1. Disconnect power steering oil pressure switch harness connector then start engine.                  2. Check continuity between power steering oil pressure switch terminals 1 and 2 under the following conditions.</p>								
								
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">Conditions</th> <th style="text-align: center;">Continuity</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Steering wheel is being fully turned.</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td style="text-align: center;">Steering wheel is not being turned.</td> <td style="text-align: center;">No</td> </tr> </tbody> </table>			Conditions	Continuity	Steering wheel is being fully turned.	Yes	Steering wheel is not being turned.	No
Conditions	Continuity							
Steering wheel is being fully turned.	Yes							
Steering wheel is not being turned.	No							
SEF364X								
<b>OK or NG</b>								
OK	▶	GO TO 9.						
NG	▶	Replace power steering oil pressure switch.						

<b>9</b>	<b>CHECK INTERMITTENT INCIDENT</b>	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.		
▶		<b>INSPECTION END</b>

# REFRIGERANT PRESSURE SENSOR



Description



## Description

The refrigerant pressure sensor is installed at the liquid tank of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.

NFEC0636








# REFRIGERANT PRESSURE SENSOR

Diagnostic Procedure

## Diagnostic Procedure

NFEC0638

<b>1</b>	<b>CHECK REFRIGERANT PRESSURE SENSOR OVERALL FUNCTION</b>	
<ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Turn A/C switch and blower switch "ON".</li> <li>3. Check voltage between ECM terminal 81 and ground with CONSULT-II or tester.</li> </ol>		
		
<b>Voltage: 1.0 - 4.0V</b>		
SEC014C		
<b>OK or NG</b>		
OK	▶	<b>INSPECTION END</b>
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT</b>	
<ol style="list-style-type: none"> <li>1. Turn A/C switch and blower switch "OFF".</li> <li>2. Stop engine.</li> <li>3. Disconnect refrigerant pressure sensor harness connector.</li> </ol>		
		
SEF287X		
<ol style="list-style-type: none"> <li>4. Turn ignition switch "ON".</li> <li>5. Check voltage between refrigerant pressure sensor terminal 1 and ground with CONSULT-II or tester.</li> </ol>		
		
<b>Voltage: Approximately 5V</b>		
SEF618X		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	GO TO 3.

## REFRIGERANT PRESSURE SENSOR

*Diagnostic Procedure (Cont'd)*

<b>3</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors E15, F18</li> <li>● Harness for open or short between ECM and refrigerant pressure sensor</li> </ul>	
▶	Repair harness or connectors.

<b>4</b>	<b>CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT</b>
1. Turn ignition switch "OFF". 2. Check harness continuity between refrigerant pressure sensor terminal 3 and engine ground. Refer to Wiring Diagram. <b>Continuity should exist.</b> 3. Also check harness for short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

<b>5</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors E8, F17</li> <li>● Harness for open or short between ECM and refrigerant pressure sensor</li> <li>● Harness for open or short between TCM (Transmission control module) and refrigerant pressure sensor</li> </ul>	
▶	Repair open circuit or short to power in harness or connectors.

<b>6</b>	<b>CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT</b>
1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 81 and refrigerant pressure sensor terminal 2. Refer to Wiring Diagram. <b>Continuity should exist.</b> 3. Also check harness for short to ground and short to power.	
<b>OK or NG</b>	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

<b>7</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"> <li>● Harness connectors E8, F17</li> <li>● Harness for open or short between ECM and refrigerant pressure sensor</li> </ul>	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

<b>8</b>	<b>CHECK REFRIGERANT PRESSURE SENSOR</b>
Refer to HA-82, "Refrigerant pressure sensor".	
<b>OK or NG</b>	
OK	▶ GO TO 9.
NG	▶ Replace refrigerant pressure sensor.

<b>9</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
▶	<b>INSPECTION END</b>

# ELECTRICAL LOAD SIGNAL

Wiring Diagram



## Wiring Diagram

NFEC0604

NFEC0604S01

### LHD MODELS

### EC-LOAD-01



REFER TO THE FOLLOWING.  
 (M15) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (B5) -FUSE BLOCK-  
 JUNCTION BOX (J/B)

MEC932C

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**  
**CAUTION:**  
 DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
52	W/G	ELECTRICAL LOAD SIGNAL	IGN ON WITH REAR WINDOW DEFOGGER SWITCH ON OR LIGHTING SWITCH ON AT 1ST POSITION	BATTERY VOLTAGE
			IGN ON UNDER EXCEPT ABOVE CONDITION	0V

SEF642XB



# ELECTRICAL LOAD SIGNAL

Wiring Diagram (Cont'd)

## RHD MODELS

NFE0604S02

### EC-LOAD-02



REFER TO THE FOLLOWING.  
 (M15) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (B5) -FUSE BLOCK-  
 JUNCTION BOX (J/B)

MEC010D

**ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.**

**CAUTION:**  
 DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
52	W/G	ELECTRICAL LOAD SIGNAL	IGN ON WITH REAR WINDOW DEFOGGER SWITCH ON OR LIGHTING SWITCH ON AT 1ST POSITION	BATTERY VOLTAGE
			IGN ON UNDER EXCEPT ABOVE CONDITION	0V


SEF642XB


# ELECTRICAL LOAD SIGNAL

Diagnostic Procedure

## Diagnostic Procedure

NFEC0605

<b>1</b>	<b>CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-I</b>							
<p>1. Turn ignition switch "ON".                  2. Check voltage between ECM terminal 52 and ground under the following conditions.</p>								
								
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Rear window defogger switch "ON"</td> <td>BATTERY VOLTAGE</td> </tr> <tr> <td>Rear window defogger switch "OFF"</td> <td>0V</td> </tr> </tbody> </table>			Condition	Voltage	Rear window defogger switch "ON"	BATTERY VOLTAGE	Rear window defogger switch "OFF"	0V
Condition	Voltage							
Rear window defogger switch "ON"	BATTERY VOLTAGE							
Rear window defogger switch "OFF"	0V							
SEF610X								
<b>OK or NG</b>								
OK	▶	GO TO 2.						
NG	▶	GO TO 3.						

<b>2</b>	<b>CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II</b>							
<p>Check voltage between ECM terminal 52 and ground under the following conditions.</p>								
								
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Lighting switch "ON" at 2nd position</td> <td>BATTERY VOLTAGE</td> </tr> <tr> <td>Lighting switch "OFF"</td> <td>0V</td> </tr> </tbody> </table>			Condition	Voltage	Lighting switch "ON" at 2nd position	BATTERY VOLTAGE	Lighting switch "OFF"	0V
Condition	Voltage							
Lighting switch "ON" at 2nd position	BATTERY VOLTAGE							
Lighting switch "OFF"	0V							
SEF611XA								
<b>OK or NG</b>								
OK	▶	<b>INSPECTION END</b>						
NG	▶	GO TO 7.						


<b>3</b>	<b>CHECK REAR WINDOW DEFOGGER FUNCTION</b>	
<p>1. Start engine.                  2. Turn "ON" the rear window defogger switch.                  3. Check the rear windshield. Is the rear windshield heated up?</p>		
<b>Yes or No</b>		
Yes	▶	GO TO 4.
No	▶	Refer to EL-174, "Rear Window Defogger".

# ELECTRICAL LOAD SIGNAL

Diagnostic Procedure (Cont'd)

## 4 CHECK REAR WINDOW DEFOGGER INPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Stop engine.
2. Disconnect ECM harness connector.
3. Disconnect rear window defogger relay.
4. Check harness continuity between ECM terminal 52 and rear window defogger relay terminal 5.



CONDITION	CONTINUITY
1	Should exist.
2	Should not exist.

SEF002Y

5. Also check harness for short to ground and short to power.

**OK or NG**

OK	▶	GO TO 6.
NG	▶	GO TO 5.

## 5 DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B1, M5
- Harness connectors M46, F44
- Diode M35
- Harness for open and short between ECM and rear window defogger relay

▶ Repair open circuit or short to ground or short to power in harness or connectors.

## 6 CHECK INTERMITTENT INCIDENT

Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.

▶ **INSPECTION END**

## 7 CHECK HEADLAMP FUNCTION

1. Start engine.
2. Turn the lighting switch "ON" at 2nd position with high beam.
3. Check that headlamps are illuminated.

**OK or NG**

OK (Models with conventional type headlamp)	▶	GO TO 8.
OK (Models with xenon type headlamp)	▶	GO TO 10.
NG	▶	Refer to EL-41, EL-47, "System Description".

# ELECTRICAL LOAD SIGNAL

Diagnostic Procedure (Cont'd)

<b>8</b>	<b>CHECK HEADLAMP INPUT SIGNAL CIRCUIT FOR OPEN OR SHORT</b>						
<p>1. Stop engine.                  2. Disconnect ECM harness connector.                  3. Disconnect daytime light control unit harness connector (Models with daytime light system), dimmer relay (Models without daytime light system).                  4. Check harness continuity between ECM terminal 52 and daytime light control unit terminal 4 or dimmer relay terminal 5 (LHD models), 7 (RHD models) under the following conditions.</p>							
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p><b>CONDITION 1</b></p> </div> <div style="text-align: center;"> <p><b>CONDITION 2</b></p> </div> </div>							
<table border="1" style="border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">CONDITION</th> <th>CONTINUITY</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td>Should exist.</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Should not exist.</td> </tr> </tbody> </table>		CONDITION	CONTINUITY	1	Should exist.	2	Should not exist.
CONDITION	CONTINUITY						
1	Should exist.						
2	Should not exist.						
<p>5. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>							
OK	▶	GO TO 12.					
NG	▶	GO TO 9.					

SEF368Z

<b>9</b>	<b>DETECT MALFUNCTIONING PART</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Harness connectors E81, M15</li> <li>● Harness connectors M46, F44</li> <li>● Diode E79</li> <li>● Harness for open and short between ECM and headlamp RH relay or dimmer relay</li> </ul>	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	

<b>10</b>	<b>CHECK HEADLAMP INPUT SIGNAL CIRCUIT FOR OPEN OR SHORT</b>						
<p>1. Stop engine.                  2. Disconnect ECM harness connector.                  3. Disconnect headlamp RH relay (LHD models), headlamp LH relay (RHD models).                  4. Check harness continuity between ECM terminal 52 and headlamp RH relay terminal or headlamp LH relay terminal 5 under the following conditions.</p>							
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p><b>CONDITION 1</b></p> </div> <div style="text-align: center;"> <p><b>CONDITION 2</b></p> </div> </div>							
<table border="1" style="border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">CONDITION</th> <th>CONTINUITY</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td>Should exist.</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Should not exist.</td> </tr> </tbody> </table>		CONDITION	CONTINUITY	1	Should exist.	2	Should not exist.
CONDITION	CONTINUITY						
1	Should exist.						
2	Should not exist.						
<p>5. Also check harness for short to ground and short to power.</p> <p style="text-align: center;"><b>OK or NG</b></p>							
OK	▶	GO TO 12.					
NG	▶	GO TO 11.					

SEF369Z

## ELECTRICAL LOAD SIGNAL

*Diagnostic Procedure (Cont'd)*

<b>11</b>	<b>DETECT MALFUNCTIONING PART</b>
Check the following. <ul style="list-style-type: none"><li>● Harness connectors E81, M15</li><li>● Harness connectors M46, F44</li><li>● Diode E79</li><li>● Harness for open and short between ECM and headlamp RH relay or headlamp LH relay</li></ul>	
	▶ Repair open circuit or short to ground or short to power in harness or connectors.
<b>12</b>	<b>CHECK INTERMITTENT INCIDENT</b>
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126.	
	▶ <b>INSPECTION END</b>


# MI & DATA LINK CONNECTORS

Wiring Diagram

## Wiring Diagram


NFEC0407

EC-MIL/DL-01



: DETECTABLE LINE FOR DTC  
 : NON-DETECTABLE LINE FOR DTC

REFER TO EL-POWER.



REFER TO THE FOLLOWING.  
 (M17), (M19) - FUSE BLOCK-JUNCTION BOX (J/B)

MEC214D

# SERVICE DATA AND SPECIFICATIONS (SDS)

Fuel Pressure Regulator

## Fuel Pressure Regulator

NFEC0408

Fuel pressure at idling kPa (bar, kg/cm <sup>2</sup> , psi)	
Vacuum hose is connected.	Approximately 235 (2.35, 2.4, 34)
Vacuum hose is disconnected.	Approximately 294 (2.94, 3.0, 43)

## Idle Speed and Ignition Timing

NFEC0409

Target idle speed*1	No-load*2 (in "P" or "N" position)	M/T: 625±50 rpm (VQ30DE) M/T: 675±50 rpm (VQ20DE) A/T: 700±50 rpm
Air conditioner: ON	In "P" or "N" position	825 rpm or more
Ignition timing*1	In "P" or "N" position	9°±5° BTDC (VQ20DE) 15°±5° BTDC (VQ30DE)
Throttle position sensor idle position		0.15 - 0.85V

\*1: Throttle position sensor harness connector connected

\*2: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

## Mass Air Flow Sensor

NFEC0411

Supply voltage	Battery voltage (11 - 14)V
Output voltage at idle	1.2 - 1.8*V
Mass air flow (Using CONSULT-II)	2.0 - 6.0 g-m/sec at idle* 7.0 - 20.0 g-m/sec at 2,500 rpm*

\*: Engine is warmed up to normal operating temperature and running under no-load.

## Engine Coolant Temperature Sensor

NFEC0412

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

## Heated Oxygen Sensor 1 Heater (front)

NFEC0414

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

## Fuel Pump

NFEC0415

Resistance [at 25°C (77°F)]	0.2 - 5.0Ω
-----------------------------	------------

## IACV-AAC Valve

NFEC0416

Resistance [at 20°C (77°F)]	Approximately 22Ω
-----------------------------	-------------------

## Injector

NFEC0417

Resistance [at 20°C (68°F)]	14 - 15Ω
-----------------------------	----------

## Resistor

NFEC0418

Resistance [at 25°C (77°F)]	Approximately 2.2 kΩ
-----------------------------	----------------------

## SERVICE DATA AND SPECIFICATIONS (SDS)

### Throttle Position Sensor

<b>Throttle Position Sensor</b>		NFEC0419
Throttle valve conditions	Voltage (at normal operating temperature, engine off, ignition switch ON, throttle opener disengaged)	
Completely closed (a)	0.15 - 0.85V	
Partially open	Between (a) and (b)	
Completely open (b)	3.5 - 4.7V	

### Calculated Load Value

<b>Calculated Load Value</b>		NFEC0420
	Calculated load value % (Using CONSULT-II)	
At idle	14.0 - 33.0	
At 2,500 rpm	12.0 - 25.0	

### Intake Air Temperature Sensor

<b>Intake Air Temperature Sensor</b>		NFEC0421
Temperature °C (°F)	Resistance kΩ	
20 (68)	2.1 - 2.9	
80 (176)	0.27 - 0.38	

### Heated Oxygen Sensor 2 Heater (rear)

<b>Heated Oxygen Sensor 2 Heater (rear)</b>		NFEC0422
Resistance [at 25°C (77°F)]	2.3 - 4.3Ω	

### Crankshaft Position Sensor (REF)

<b>Crankshaft Position Sensor (REF)</b>		NFEC0423
Resistance [at 20°C (68°F)]	470 - 570Ω	

### Fuel Tank Temperature Sensor

<b>Fuel Tank Temperature Sensor</b>		NFEC0424
Temperature °C (°F)	Resistance kΩ	
20 (68)	2.3 - 2.7	
50 (122)	0.79 - 0.90	

### Camshaft Position Sensor (PHASE)

<b>Camshaft Position Sensor (PHASE)</b>			NFEC0639
Resistance [at 20°C (68°F)]	HITACHI make	1,440 - 7,760Ω	
	MITSUBISHI make	2,090 - 2,550Ω	