

SECTION **IP**

INSTRUMENT PANEL

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CONTENTS

PRECAUTION	2	CLUSTER LID C	13
PRECAUTIONS	2	Exploded View	13
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	Removal and Installation	13
PREPARATION	3	CLUSTER LID D	14
PREPARATION	3	Exploded View	14
Special Service Tool	3	Removal and Installation	14
Commercial Service Tool	3	INSTRUMENT LOWER PANEL RH AND GLOVE BOX	15
SYMPTOM DIAGNOSIS	4	Exploded View	15
SQUEAK AND RATTLE TROUBLE DIAG- NOSES	4	Removal and Installation	15
Work Flow	4	INSTRUMENT LOWER PANEL LH	16
Generic Squeak and Rattle Troubleshooting	6	Exploded View	16
Diagnostic Worksheet	8	Removal and Installation	16
ON-VEHICLE REPAIR	10	A/T FINISHER	17
INSTRUMENT PANEL ASSEMBLY	10	Exploded View	17
Exploded View	10	Removal and Installation	17
Removal and Installation	11	CENTER CONSOLE	18
CLUSTER LID A	12	Exploded View	18
Exploded View	12	Removal and Installation	18
Removal and Installation	12	DISASSEMBLY AND ASSEMBLY	19
		INSTRUMENT LOWER PANEL RH AND GLOVE BOX	19
		Exploded View	19
		Disassembly and Assembly	19
		CENTER CONSOLE ASSEMBLY	21
		Exploded View	21
		Disassembly and Assembly	22

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000005713773

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION

< PREPARATION >



PREPARATION

PREPARATION

Special Service Tool



INFOID:000000005385585

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-39570) Chassis ear	 Locating the noise
— (J-43980) NISSAN Squeak and Rattle kit	 Repairing the cause of noise

Commercial Service Tool

INFOID:000000005385586

(Kent-Moore No.) Tool name	Description
(J-39565) Engine ear	 Locating the noise
Power Tool	 Loosening bolts and nuts

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000005385587



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [IP-8, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
- 2) Tap or push/pull around the area where the noise appears to be coming from.
- 3) Rev the engine.
- 4) Use a floor jack to recreate vehicle "twist".
- 5) At idle, apply engine load (electrical load, A/T shift selector in drive position with brakes applied).
- 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.

- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
- If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.

Refer to [IP-6, "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-43980) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

Always check with the Parts Department for the latest parts information.

The following materials are contained in the NISSAN Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100×135 mm (3.94×5.31 in)/76884-71L01: 60×85 mm (2.36×3.35 in)/76884-71L02: 15×25 mm (0.59×0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50×50 mm (1.97×1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50×50 mm (1.97×1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30×50 mm (1.18×1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

68370-4B000: 15×25 mm (0.59×0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll. The following materials not found in the kit can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used instead of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:000000005385588

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

- 2. Trunk lid striker out of adjustment
- 3. The trunk lid torsion bars knocking together
- 4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

A

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

- 1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
- 2. Sun visor shaft shaking in the holder
- 3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

B

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

- 1. Loose harness or harness connectors.
- 2. Front console map/reading lamp lens loose.
- 3. Loose screws at console attachment points.

C

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

D

Cause of seat noise include:

- 1. Headrest rods and holder
- 2. A squeak between the seat pad cushion and frame
- 3. The rear seatback lock and bracket

E

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

F

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

G

Causes of transmitted underhood noise include:

- 1. Any component mounted to the engine wall
- 2. Components that pass through the engine wall
- 3. Engine wall mounts and connectors
- 4. Loose radiator mounting pins
- 5. Hood bumpers out of adjustment
- 6. Hood striker out of adjustment

H

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

I

J

K

L

M

N

O

P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:0000000005385589





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

<input type="checkbox"/> Anytime	<input type="checkbox"/> After sitting out in the rain
<input type="checkbox"/> 1st time in the morning	<input type="checkbox"/> When it is raining or wet
<input type="checkbox"/> Only when it is cold outside	<input type="checkbox"/> Dry or dusty conditions
<input type="checkbox"/> Only when it is hot outside	<input type="checkbox"/> Other: _____

III. WHEN DRIVING:

<input type="checkbox"/> Through driveways	<input type="checkbox"/> Squeak (like tennis shoes on a clean floor)
<input type="checkbox"/> Over rough roads	<input type="checkbox"/> Creak (like walking on an old wooden floor)
<input type="checkbox"/> Over speed bumps	<input type="checkbox"/> Rattle (like shaking a baby rattle)
<input type="checkbox"/> Only about _____ mph	<input type="checkbox"/> Knock (like a knock at the door)
<input type="checkbox"/> On acceleration	<input type="checkbox"/> Tick (like a clock second hand)
<input type="checkbox"/> Coming to a stop	<input type="checkbox"/> Thump (heavy muffled knock noise)
<input type="checkbox"/> On turns: left, right or either (circle)	<input type="checkbox"/> Buzz (like a bumble bee)
<input type="checkbox"/> With passengers or cargo	
<input type="checkbox"/> Other: _____	
<input type="checkbox"/> After driving _____ miles or _____ minutes	

IV. WHAT TYPE OF NOISE

<input type="checkbox"/> Squeak (like tennis shoes on a clean floor)
<input type="checkbox"/> Creak (like walking on an old wooden floor)
<input type="checkbox"/> Rattle (like shaking a baby rattle)
<input type="checkbox"/> Knock (like a knock at the door)
<input type="checkbox"/> Tick (like a clock second hand)
<input type="checkbox"/> Thump (heavy muffled knock noise)
<input type="checkbox"/> Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

YES	NO	Initials of person performing
-----	----	-------------------------------

Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name: _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LAIA0071E

INSTRUMENT PANEL ASSEMBLY

< ON-VEHICLE REPAIR >


ON-VEHICLE REPAIR

INSTRUMENT PANEL ASSEMBLY

Exploded View

INFOID:000000005385590

SEC.680



AWJIA0474GB

INSTRUMENT PANEL ASSEMBLY

< ON-VEHICLE REPAIR >

1. Defroster grille	2. Speaker grille RH/LH	3. Instrument panel and pad assembly	A
4. Deck pocket mat RH/LH	5. Side ventilator assembly RH/LH	6. Combination meter cover	
7. Combination meter	8. Switch assembly	9. Cluster lid A	
10. Lower knee protector	11. Lower instrument panel LH	12. Steering column cover upper	B
13. Steering column cover lower	14. Cluster lid D	15. Cluster lid C	
16. Instrument lower cover RH	17. Glove box	18. Audio unit	
19. Audio bracket RH/LH	20. Center ventilator assembly RH/LH	21. Display assembly (if equipped)	C
22. Glove box lid striker	23. Fuse block cover	24. Lower instrument panel RH	
25. Glove box damper (if equipped)	26. Steering member		

INFOID:000000005385591

Removal and Installation

REMOVAL

CAUTION:

Before servicing the SRS, turn the ignition switch off, disconnect both battery terminals and wait at least three minutes.

1. Disconnect both the negative and positive battery terminals, then wait at least three minutes.
2. Remove the center console. Refer to [IP-18, "Removal and Installation"](#).
3. Remove instrument lower cover LH. Refer to [IP-16, "Removal and Installation"](#).
4. Remove the steering column. Refer to [ST-12, "Removal and Installation"](#).
5. Remove the combination meter. Refer to [MWI-101, "Removal and Installation"](#).
6. Remove audio unit. Refer to [AV-34, "Removal and Installation"](#).
7. Remove display unit (if equipped). Refer to [AV-307, "Removal and Installation"](#).
8. Remove lower knee protector.
9. Remove defroster grille and disconnect the optical sensor harness.
10. Remove side ventilator assembly LH.
11. Remove the LH assist grip and windshield garnish.
12. Remove side ventilator assembly RH.
13. Remove the RH assist grip and windshield garnish.
14. Remove the passenger air bag module. Refer to [SR-8, "Removal and Installation"](#).
15. Remove instrument panel and pad assembly.
16. Disconnect remaining instrument panel assembly electrical connectors.

INSTALLATION

Installation is in the reverse order of removal.


CLUSTER LID A

< ON-VEHICLE REPAIR >

CLUSTER LID A

Exploded View

INFOID:0000000005385592



1. Cluster lid A

2. Ignition switch escutcheon

Metal Clip

INFOID:0000000005385593

Removal and Installation

REMOVAL

1. Remove the lower instrument panel LH. Refer to [IP-16, "Removal and Installation"](#).
2. Tilt the steering wheel to the lowest position, then remove steering column cover upper.
3. Remove ignition switch escutcheon.
4. Pull cluster lid A rearward in vehicle to release the clips.
5. Disconnect the electrical connector(s), then remove cluster lid A.


INSTALLATION

Installation is in the reverse order of removal.

CLUSTER LID C

Exploded View

INFOID:0000000005385594



[] Metal clip

Removal and Installation

INFOID:0000000005385595

REMOVAL

1. Remove center console upper finisher and A/T finisher (if equipped). Refer to [IP-17, "Removal and Installation"](#).
2. Remove instrument lower panel RH and glove box. Refer to [IP-15, "Removal and Installation"](#).
3. Remove lower instrument panel LH. Refer to [IP-16, "Removal and Installation"](#).
4. Remove cluster lid D. Refer to [IP-14, "Removal and Installation"](#).
5. Disconnect the electrical connector(s), then remove cluster lid C.
6. Pull cluster lid C rearward in vehicle to release the clips.

INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

IP

K

L

M

N

O

P


CLUSTER LID D

< ON-VEHICLE REPAIR >

CLUSTER LID D

Exploded View

INFOID:0000000005385596



[] Metal clip

Removal and Installation

INFOID:0000000005385597

REMOVAL

1. Pull cluster lid D rearward in vehicle to release the clips.
2. Disconnect the electrical connector(s), then remove cluster lid D.

INSTALLATION

Installation is in the reverse order of removal.

INSTRUMENT LOWER PANEL RH AND GLOVE BOX

< ON-VEHICLE REPAIR >


INSTRUMENT LOWER PANEL RH AND GLOVE BOX

Removal and Installation

INFOID:000000005385598

REMOVAL

1. Release the clips, then remove instrument lower cover RH.
➡ Vehicle front
2. Remove lower instrument panel RH and glove box screws. Refer to [IP-19, "Exploded View"](#).
3. Disconnect the electrical connector, then remove the lower instrument panel RH and glove box.



INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

IP

K

L

M

N

O

P

INSTRUMENT LOWER PANEL LH

< ON-VEHICLE REPAIR >


INSTRUMENT LOWER PANEL LH

Removal and Installation

INFOID:000000005385599

REMOVAL

1. Remove lower instrument panel LH screws.
2. Pull lower instrument panel LH rearward in vehicle to release the clips.
3. Disconnect the electrical connector(s), then remove lower instrument panel LH.



INSTALLATION

Installation is in the reverse order of removal.


A/T FINISHER

Removal and Installation

INFOID:000000005385600

REMOVAL

1. Remove the shift lever handle (1).
2. Remove the storage compartment mask (3) and console upper finisher (4).
3. Pull up on A/T finisher (2) to release clips, then tilt aside.
4. Disconnect A/T finisher electrical connectors and remove from front center console assembly.



INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

IP

K

L

M

N

O

P

CENTER CONSOLE


< ON-VEHICLE REPAIR >

CENTER CONSOLE

Removal and Installation

INFOID:0000000005385601

REMOVAL



1. Remove A/T shift selector. Refer to [TM-184, "A/T Shift Selector Removal and Installation"](#).
2. Remove lower instrument panel RH and glove box. Refer to [IP-15, "Removal and Installation"](#).
3. Remove center console lower cover RH/LH.
4. Remove front center console screws.
5. Move front seats (including seat back) to forward most position, then remove rear center console screws.
6. Lift rear of center console upward then rearward to disengage heat duct.
7. Remove center console through rear door opening.

CAUTION:

When removing, two workers are required (one for each front and rear of center console). Cover seating and interior surfaces with a shop cloth to prevent damage.

INSTALLATION

Installation is in the reverse order of removal.

INSTRUMENT LOWER PANEL RH AND GLOVE BOX


< DISASSEMBLY AND ASSEMBLY >

DISASSEMBLY AND ASSEMBLY

INSTRUMENT LOWER PANEL RH AND GLOVE BOX

Exploded View

INFOID:000000005385602



1. Glove box damper (if equipped)	2. Glove box housing	3. Clips
4. Rubber stoppers	5. Glove box pins	6. Glove box
7. Glove box striker	8. Fuse block cover	9. Instrument lower panel RH and glove box assembly

Disassembly and Assembly

INFOID:000000005385603

DISASSEMBLY

1. Remove damper clip (if equipped) from glove box.
2. Remove glove box pins and glove box.
3. Remove glove box striker screws, using power tool and remove glove box striker.
4. Remove fuse block cover.
5. Remove glove box damper screws and remove glove box damper (if equipped).

ASSEMBLY

INSTRUMENT LOWER PANEL RH AND GLOVE BOX

< DISASSEMBLY AND ASSEMBLY >

Assembly is in the reverse order of disassembly.

CENTER CONSOLE ASSEMBLY


< DISASSEMBLY AND ASSEMBLY >

CENTER CONSOLE ASSEMBLY

Exploded View

INFOID:0000000005385604

SEC.969



ALJIA0103ZZ

1. Console lid assembly
2. A/T finisher
3. Console upper finisher
4. Storage compartment
5. Storage compartment mask
6. Console reinforcement assembly
7. Console front bracket
8. Lower side finisher LH
9. Center console lower cover LH

CENTER CONSOLE ASSEMBLY

< DISASSEMBLY AND ASSEMBLY >

10. Console cover LH	11. Rear console duct	12. Console power socket
13. Rear cup holder assembly	14. Rear finisher assembly	15. Console rear bracket
16. Heat duct	17. Rear upper finisher	18. Console bin mat
19. Console bin	20. Console cover RH	21. Center console lower cover RH
22. Lower side finisher RH	23. A/T transmission control	24. Mask
25. Cup holder insert		

Disassembly and Assembly

INFOID:000000005385605

DISASSEMBLY

1. Remove tray and mat from console bin.
2. Remove latch from console lid.
3. Remove console lid.
4. Remove console lid hinge.
5. Remove console bin.
6. Disconnect electrical harness from DVD player (if equipped).
7. Remove rear upper finisher.
8. Remove rear cup holder assembly.
9. Remove rear finisher assembly.
10. Disconnect rear finisher assembly electrical connectors.
11. Remove console power socket.
12. Remove upper side finishers LH/RH.
13. Remove screws on each side, disconnect clips and remove console covers LH/RH.
14. Remove mask and storage compartment.
15. Remove console front bracket.
16. Remove heat duct and console rear duct.
17. Remove console rear bracket.

ASSEMBLY

Assembly is in the reverse order of disassembly.