

SECTION

SE

SEAT

CONTENTS

COMPONENT DIAGNOSIS	2	PREPARATION	22
POWER SEAT	2	PREPARATION	22
Wiring Diagram — Driver Side Without Automatic		Special Service Tool	22
Drive Positioner —	2	Commercial Service Tool	22
Wiring Diagram — Passenger Side —	6	ON-VEHICLE REPAIR	23
HEATED SEAT	10	FRONT SEAT	23
Description	10	Exploded View	23
Wiring Diagram	11	Removal and Installation	30
SYMPTOM DIAGNOSIS	15	REAR SEAT	31
SQUEAK AND RATTLE TROUBLE DIAG- NOSES	15	Exploded View	31
Work Flow	15	Removal and Installation	33
Generic Squeak and Rattle Troubleshooting	17	DISASSEMBLY AND ASSEMBLY	34
Diagnostic Worksheet	19	FRONT SEAT	34
PRECAUTION	21	Exploded View	34
PRECAUTIONS	21	Disassembly and Assembly	41
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	21	REAR SEAT	46
Precaution for Work	21	Exploded View	46

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SEAT

< COMPONENT DIAGNOSIS >


COMPONENT DIAGNOSIS

POWER SEAT

Wiring Diagram — Driver Side Without Automatic Drive Positioner —

INFOID:000000005386302

POWER SEAT FOR DRIVER SIDE - WITHOUT AUTOMATIC DRIVE POSITIONER




ABJWA0095GB

POWER SEAT FOR DRIVER SIDE CONNECTORS - WITHOUT AUTOMATIC DRIVE POSITIONER


Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
10G	W/B	-



Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
5J	L/B	-



ABJIA0293GB

Connector No.	M82
Connector Name	CIRCUIT BREAKER-2
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/B	-
2	W/B	-

POWER SEAT

< COMPONENT DIAGNOSIS >

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10G	W/B	—

Connector No.	B45
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	—
2	B/W	—

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5J	L/B	—

Connector No.	B211
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	—
2	B	—

Connector No.	B212
Connector Name	SLIDING MOTOR LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	—
2	Y	—

Connector No.	B214
Connector Name	LIFTING MOTOR (FRONT) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	B/Y	—
2	R/Y	—

POWER SEAT

< COMPONENT DIAGNOSIS >

Terminal No.	Color of Wire	Signal Name
5	G	-
6	L	-
7	V	-
8	W/G	-
9	B/Y	-
10	R/Y	-

Connector No.	B216
Connector Name	POWER SEAT SWITCH LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	R	-
4	Y	-

Connector No.	B215
Connector Name	LIFTING MOTOR (REAR) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	W/G	-

Connector No.	B232
Connector Name	RECLINING MOTOR LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	G	-

ABJIA0094GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


POWER SEAT

< COMPONENT DIAGNOSIS >

Wiring Diagram — Passenger Side —

INFOID:000000005386303

POWER SEAT FOR PASSENGER SIDE




ABJWA0096GB

POWER SEAT FOR PASSENGER SIDE CONNECTORS


Terminal No.	Color of Wire	Signal Name
10G	W/B	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5M	W/L	-

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M82
Connector Name	CIRCUIT BREAKER-2
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	-
2	W/B	-

ABJIA0296GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SEAT


< COMPONENT DIAGNOSIS >

Connector No.	B154
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W/L	—
2	B	—

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5M	W/L	—

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	W/B	—

Terminal No.	Color of Wire	Signal Name
1	L	—
2	Y	—
3	G	—
4	W	—
5	B	—
6	R	—

Connector No.	B308
Connector Name	POWER SEAT SWITCH RH
Connector Color	WHITE



Connector No.	B303
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	—
2	B	—

ABJIA0119GB

POWER SEAT

< COMPONENT DIAGNOSIS >

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

Connector No.	B372
Connector Name	RECLINING MOTOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-

Connector No.	B309
Connector Name	SLIDING MOTOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	R	-

ABJIA0095GB

HEATED SEAT


< COMPONENT DIAGNOSIS >

HEATED SEAT

Description

INFOID:000000005386304

- When handling seat, be extremely careful not to scratch heating unit.
- Front passenger seat cushion and seatbacks equipped with air bags cannot be disassembled. They are replaced as assemblies only.
- Do not use any organic solvent, such as thinner, benzene, alcohol, etc. to clean trim.




HEATED SEAT

< COMPONENT DIAGNOSIS >

Wiring Diagram

INFOID:000000005386305

HEATED SEAT




SE

HEATED SEAT

< COMPONENT DIAGNOSIS >

HEATED SEAT CONNECTORS

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
76M	GR/B	–
77M	GR/L	–

Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5Q	G	–

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1J	GR	–
6J	L/B	–

Connector No.	M159
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G	–
2	GR	–
3	L/B	–
4	B	–

Connector No.	M160
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	–
2	GR/L	–
3	GR/B	–
4	B	–

Connector No.	B37
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	L/B	–
5	GR	–
6	B	–

HEATED SEAT

< COMPONENT DIAGNOSIS >


Connector No.	B118
Connector Name	FRONT SEAT HEATER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR/L	LO
2	B	E
3	GR/B	HI

Terminal No.	Color of Wire	Signal Name
1J	GR	-
6J	L/B	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B200
Connector Name	WIRE TO WIRE
Connector Color	WHITE




1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

Terminal No.	Color of Wire	Signal Name
4	O	-
5	GR	-
6	P	-

Terminal No.	Color of Wire	Signal Name
76M	GR/B	-
77M	GR/L	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABJIA0298GB

HEATED SEAT

< COMPONENT DIAGNOSIS >

Connector No.	B209
Connector Name	FRONT SEAT HEATER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	LO
2	O	E
3	P	HI

ABJIA0299GB

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000005386306



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [SE-19, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
 2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
- Refer to [SE-17. "Generic Squeak and Rattle Troubleshooting"](#) .

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-43980) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

Always check with the Parts Department for the latest parts information.

The following materials are contained in the NISSAN Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100×135 mm (3.94×5.31 in)/76884-71L01: 60×85 mm (2.36×3.35 in)/76884-71L02: 15×25 mm (0.59×0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50×50 mm (1.97×1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50×50 mm (1.97×1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30×50 mm (1.18×1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

68370-4B000: 15×25 mm (0.59×0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll. The following materials not found in the kit can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used instead of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:000000005386307

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lense loose.
3. Loose screws at console attachment points.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:000000005386308





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| ☐ Anytime | ☐ After sitting out in the rain |
| ☐ 1st time in the morning | ☐ When it is raining or wet |
| ☐ Only when it is cold outside | ☐ Dry or dusty conditions |
| ☐ Only when it is hot outside | ☐ Other: |

III. WHEN DRIVING:

- ☐ Through driveways
- ☐ Over rough roads
- ☐ Over speed bumps
- ☐ Only about ____ mph
- ☐ On acceleration
- ☐ Coming to a stop
- ☐ On turns: left, right or either (circle)
- ☐ With passengers or cargo
- ☐ Other: _____
- ☐ After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- ☐ Squeak (like tennis shoes on a clean floor)
- ☐ Creak (like walking on an old wooden floor)
- ☐ Rattle (like shaking a baby rattle)
- ☐ Knock (like a knock at the door)
- ☐ Tick (like a clock second hand)
- ☐ Thump (heavy muffled knock noise)
- ☐ Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	☐	☐	_____
- Noise verified on test drive	☐	☐	_____
- Noise source located and repaired	☐	☐	_____
- Follow up test drive performed to confirm repair	☐	☐	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LAIA0071E

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005712792

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Work

INFOID:000000005386310

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
 - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.
Then rub with a soft and dry cloth.
 - Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >



PREPARATION

PREPARATION

Special Service Tool


INFOID:000000005386311

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name		Description
— (J-39570) Chassis ear	 SIIA0993E	Locating the noise
— (J-43980) NISSAN Squeak and Rattle Kit	 SIIA0994E	Repairing the cause of noise

Commercial Service Tool

INFOID:000000005386312

(Kent-Moore No.) Tool name		Description
(J-39565) Engine ear	 SIIA0995E	Locating the noise

FRONT SEAT

< ON-VEHICLE REPAIR >


ON-VEHICLE REPAIR

FRONT SEAT

Exploded View

INFOID:000000005712798

Power Driver Seat



AWJIA0477GB

FRONT SEAT


< ON-VEHICLE REPAIR >

- | | | |
|-----------------------------------|--|--|
| 1. Headrest | 2. Headrest holder with multi position lock | 3. Headrest holder |
| 4. Armrest assembly (if equipped) | 5. Armrest cap (if equipped) | 6. Armrest bolt (if equipped) |
| 7. Seat cushion cover | 8. Seat cushion pad | 9. Seat cushion heating element (if equipped) |
| 10. Seat cushion frame | 11. Seatback assembly without armrest, (if equipped) | 12. Seat cushion inner finisher |
| 13. Lift motor | 14. Seat cushion front finisher | 15. Seat slide motor assembly |
| 16. Lift motor | 17. Driver power seat frame assembly | 18. Power seat controller |
| 19. Outer pedestal finisher | 20. Seat cushion outer finisher | 21. Bolt cover |
| 22. Reclining motor | 23. Driver seat wiring harness | 24. Wire harness cover |
| 25. Outer reclining cover | 26. Reclining rod | 27. Inner reclining cover |
| 28. LH inner leg cover | 29. Slide switch knob | 30. Recliner switch knob |
| 31. Power seat switch escutcheon | 32. Power seat switch | 33. Seatback assembly with armrest (if equipped) |
| 34. Seatback board | | |

FRONT SEAT

< ON-VEHICLE REPAIR >

Manual Driver Seat



AWJIA0457GB

- | | | |
|--|---|--|
| 1. Headrest | 2. Headrest holder with multi position lock | 3. Headrest holder |
| 4. Armrest assembly (if equipped) | 5. Armrest bolt (if equipped) | 6. Armrest cap (if equipped) |
| 7. Seatback assembly with armrest, with side airbag (if equipped) | 8. Seatback board without armrest, without airbag (if equipped) | 9. Seatback frame assembly without armrest, without airbag (if equipped) |
| 10. Seatback pad and cover without armrest, without airbag (if equipped) | 11. Seatback assembly without armrest, with side airbag (if equipped) | 12. Seat cushion inner finisher |

FRONT SEAT

< ON-VEHICLE REPAIR >


- | | | |
|--|--|--|
| 13. Reclining knob | 14. Release wire | 15. Front seat bracket |
| 16. Driver manual seat frame assembly | 17. Bolt cover | 18. Outer leg cover |
| 19. Seat cushion outer cover | 20. Inner reclining cover | 21. Reclining rod |
| 22. Outer reclining cover | 23. RH inner leg cover | 24. Seat cushion heating element (if equipped) |
| 25. Seat cushion frame | 26. Seat cushion pad and cover | 27. Seatback pad and cover with armrest, with airbag (if equipped) |
| 28. Seatback frame assembly with armrest, without airbag (if equipped) | 29. Seat lumbar assembly (if equipped) | 30. Lumbar adjusting knob |
| 31. Seatback board with armrest | | |

FRONT SEAT

< ON-VEHICLE REPAIR >

Center Seat

SEC. 870




WIA0947E

- | | | |
|-----------------------------------|--------------------------------|------------------------------|
| 1. Cupholder | 2. Armrest assembly | 3. Armrest pivot arm |
| 4. Armrest release bracket | 5. Armrest pivot release lever | 6. Upper armrest pivot cover |
| 7. Lower armrest pivot cover | 8. Seat cushion cover | 9. Seat cushion pad |
| 10. RH pedestal support | 11. LH pedestal support | 12. Seat belt tongue |
| 13. Center seat pan | 14. Inboard lower pivot cover | 15. Rear hinge cover |
| 16. Inboard armrest support cover | 17. Armrest support | 18. Armrest bolt cover |

FRONT SEAT

< ON-VEHICLE REPAIR >

Power Passenger Seat



AWJIA0478GB


- | | | |
|--|---|---|
| 1. Headrest | 2. Headrest holder with multi position lock | 3. Headrest holder |
| 4. Seat fold lever | 5. Seat fold handle and cable | 6. Seatback assembly with armrest, with side airbag (if equipped) |
| 7. Power seat switch | 8. Power seat switch escutcheon | 9. Recliner switch |
| 10. Seat slide switch | 11. Seat cushion assembly | 12. Outboard reclining arm outer cover |
| 13. Seatback assembly without arm rest | 14. Seat cushion outer finisher | 15. Bolt cover |

FRONT SEAT

< ON-VEHICLE REPAIR >

- | | | |
|---------------------------------------|--------------------------------|--|
| 16. Outer pedestal finisher | 17. Power seat frame assembly | 18. Seat cushion front finisher |
| 19. Seat cushion inner finisher | 20. Seat wiring harness | 21. Wire harness cover |
| 22. Inner recliner cover | 23. RH inner leg cover | 24. Seat latch cover |
| 25. Inner reclining cover | 26. Outer reclining cover | 27. Outboard reclining arm inner cover |
| 28. Inboard reclining arm inner cover | 29. Reclining rod | 30. Armrest assembly (if equipped) |
| 31. Armrest cap (if equipped) | 32. Armrest bolt (if equipped) | 33. Seatback board |

Manual Passenger Seat



AWJIA0479GB

FRONT SEAT

< ON-VEHICLE REPAIR >

- | | | |
|---|--|---|
| 1. Headrest | 2. Headrest holder with multi position lock | 3. Headrest holder |
| 4. Seat fold lever | 5. Seat fold handle and cable | 6. Seatback assembly with armrest, with side airbag (if equipped) |
| 7. Seatback board without armrest, without airbag (if equipped) | 8. Seatback frame assembly without armrest, without airbag (if equipped) | 9. Seatback pad and cover without armrest, without airbag (if equipped) |
| 10. Seatback assembly without armrest, with side airbag (if equipped) | 11. Seat recline lever | 12. Seat cushion outer finisher |
| 13. Bolt cover | 14. Outer pedestal finisher | 15. Power seat frame assembly |
| 16. Seat cushion inner finisher | 17. Seat rear cover | 18. Inner recliner cover |
| 19. RH inner leg cover | 20. Seat latch cover | 21. Armrest cover (if equipped) |
| 22. Inboard reclining arm inner cover | 23. Outboard reclining arm outer cover | 24. Outboard reclining arm outer cover |
| 25. Seat cushion assembly | 26. Armrest assembly (if equipped) | 27. Armrest cap (if equipped) |
| 28. Armrest bolt (if equipped) | 29. Seatback pad and cover with armrest, without airbag (if equipped) | 30. Seatback frame assembly with armrest, without airbag (if equipped) |
| 31. Seatback board with armrest, without airbag (if equipped) | | |

Removal and Installation

INFOID:000000005386314

REMOVAL

CAUTION:

- When removing or installing the seat trim, handle it carefully to keep dirt out and avoid damage.
- Before removing the front seat, turn the ignition switch off, disconnect both battery cables and wait at least 3 minutes.
- When checking the power seat circuit for continuity using a circuit tester, do not confuse its connector with the side air bag module connector. Such an error may cause the air bag to deploy.
- Do not drop, tilt, or bump the side air bag module while installing the seat. Always handle it with care.
- After front side air bag module inflates, front seatback assembly must be replaced.
- Front passenger seat is equipped with Occupant Classification System sensor and control module. Do not disassemble front passenger seat cushion assembly or remove trim as this will affect the Occupant Classification System calibration.
- Always replace passenger seat cushion as an assembly.

1. Slide the seat until the four seat to body bolts are visible and a tool can be inserted.

NOTE:

- If disassembling the seat after removal, set the front/rear cushion lifters to the top position.

2. Disconnect both battery cables and wait at least 3 minutes.
3. Disconnect the side air bag module harness connector (if equipped).
4. Remove the bolt and leg covers.
5. Remove the four seat to body bolts.
6. Disconnect the power seat harness connectors and remove the seat from the vehicle.

NOTE:

When removing and installing the seat, use shop cloths to protect the vehicle from damage.

INSTALLATION

Installation is in the reverse order of removal.

REAR SEAT

< ON-VEHICLE REPAIR >


REAR SEAT

Exploded View

INFOID:000000005386315

LH

SEC. 881



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

1. Seatback pad
4. Seatback latch release strap
7. Outboard pivot cover

2. Headrest
5. Seatback latch striker
8. Release lever handle

3. Seatback latch
6. Seatback frame
9. Seat cushion frame

WIA0949E


REAR SEAT

< ON-VEHICLE REPAIR >

- | | | |
|-----------------------------------|---------------------------|-------------------------------|
| 10. Seat cushion release assembly | 11. Outboard seat support | 12. Grocery bag hooks |
| 13. Inboard seat support | 14. Rear seat bracket | 15. Seat cushion pad |
| 16. Seat cushion trim | 17. Seatback trim | 18. Inboard outer pivot cover |
| 19. Inboard inner pivot cover | 20. Headrest guide | |

RH

SEC. 881



AWJIA0386GB

- | | | |
|---------------------------------|-----------------------------------|----------------------------------|
| 1. Seatback trim with armrest | 2. Seatback pad with armrest | 3. Seatback trim without armrest |
| 4. Seatback pad without armrest | 5. Seatback frame without armrest | 6. Seat cushion trim |

REAR SEAT

< ON-VEHICLE REPAIR >


- | | | |
|---------------------------------|------------------------------------|-----------------------------------|
| 7. Seat cushion pad | 8. Seatback striker assembly | 9. Outboard pivot cover |
| 10. Seat cushion release handle | 11. Outboard seatback pivot anchor | 12. Seat cushion release lever |
| 13. Seat cushion frame | 14. Grocery bag hooks | 15. Inboard seatback pivot anchor |
| 16. Rear seat bracket | 17. Outer inboard hinge cover | 18. Inner inboard hinge cover |
| 19. Seatback frame with armrest | 20. Arm rest pad and frame | 21. Arm rest trim |
| 22. Seatback latch assembly | 23. Locking headrest guide | 24. Headrest |
| 25. Seatback release strap | 26. Free headrest guide | |

Removal and Installation


INFOID:000000005386316

Removal

1. Lift the seat cushion into the stowed position.
2. Remove the seat belt and seat anchor bolts.



3. Remove the outboard pivot cover.
4. Remove the seatback hinge covers.
5. Remove the seat cushion release handle.
6. Release the seatback and remove the seat.



Installation

Installation is in the reverse order of removal.

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >


DISASSEMBLY AND ASSEMBLY

FRONT SEAT

Exploded View

INFOID:000000005714015

Power Driver Seat



AWJIA0477GB

FRONT SEAT


< DISASSEMBLY AND ASSEMBLY >

1. Headrest	2. Headrest holder with multi position lock	3. Headrest holder	A
4. Armrest assembly (if equipped)	5. Armrest cap (if equipped)	6. Armrest bolt (if equipped)	B
7. Seat cushion cover	8. Seat cushion pad	9. Seat cushion heating element (if equipped)	
10. Seat cushion frame	11. Seatback assembly without armrest, (if equipped)	12. Seat cushion inner finisher	C
13. Lift motor	14. Seat cushion front finisher	15. Seat slide motor assembly	
16. Lift motor	17. Driver power seat frame assembly	18. Power seat controller	D
19. Outer pedestal finisher	20. Seat cushion outer finisher	21. Bolt cover	
22. Reclining motor	23. Driver seat wiring harness	24. Wire harness cover	E
25. Outer reclining cover	26. Reclining rod	27. Inner reclining cover	
28. LH inner leg cover	29. Slide switch knob	30. Recliner switch knob	F
31. Power seat switch escutcheon	32. Power seat switch	33. Seatback assembly with armrest (if equipped)	
34. Seatback board			G
			H
			I
			SE
			K
			L
			M
			N
			O
			P

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

Manual Driver Seat



AWJIA0457GB

- | | | |
|--|---|--|
| 1. Headrest | 2. Headrest holder with multi position lock | 3. Headrest holder |
| 4. Armrest assembly (if equipped) | 5. Armrest bolt (if equipped) | 6. Armrest cap (if equipped) |
| 7. Seatback assembly with armrest, with side airbag (if equipped) | 8. Seatback board without armrest, without airbag (if equipped) | 9. Seatback frame assembly without armrest, without airbag (if equipped) |
| 10. Seatback pad and cover without armrest, without airbag (if equipped) | 11. Seatback assembly without armrest, with side airbag (if equipped) | 12. Seat cushion inner finisher |

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | |
|--|--|--|
| 13. Reclining knob | 14. Release wire | 15. Front seat bracket |
| 16. Driver manual seat frame assembly | 17. Bolt cover | 18. Outer leg cover |
| 19. Seat cushion outer cover | 20. Inner reclining cover | 21. Reclining rod |
| 22. Outer reclining cover | 23. RH inner leg cover | 24. Seat cushion heating element (if equipped) |
| 25. Seat cushion frame | 26. Seat cushion pad and cover | 27. Seatback pad and cover with armrest, with airbag (if equipped) |
| 28. Seatback frame assembly with armrest, without airbag (if equipped) | 29. Seat lumbar assembly (if equipped) | 30. Lumbar adjusting knob |
| 31. Seatback board with armrest | | |

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O


P

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

Center Seat

SEC. 870




WIA0947E

- | | | |
|-----------------------------------|--------------------------------|------------------------------|
| 1. Cupholder | 2. Armrest assembly | 3. Armrest pivot arm |
| 4. Armrest release bracket | 5. Armrest pivot release lever | 6. Upper armrest pivot cover |
| 7. Lower armrest pivot cover | 8. Seat cushion cover | 9. Seat cushion pad |
| 10. RH pedestal support | 11. LH pedestal support | 12. Seat belt tongue |
| 13. Center seat pan | 14. Inboard lower pivot cover | 15. Rear hinge cover |
| 16. Inboard armrest support cover | 17. Armrest support | 18. Armrest bolt cover |

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

Power Passenger Seat



AWJIA0478GB


- | | | |
|--|---|---|
| 1. Headrest | 2. Headrest holder with multi position lock | 3. Headrest holder |
| 4. Seat fold lever | 5. Seat fold handle and cable | 6. Seatback assembly with armrest, with side airbag (if equipped) |
| 7. Power seat switch | 8. Power seat switch escutcheon | 9. Recliner switch |
| 10. Seat slide switch | 11. Seat cushion assembly | 12. Outboard reclining arm outer cover |
| 13. Seatback assembly without arm rest | 14. Seat cushion outer finisher | 15. Bolt cover |

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | |
|---------------------------------------|--------------------------------|--|
| 16. Outer pedestal finisher | 17. Power seat frame assembly | 18. Seat cushion front finisher |
| 19. Seat cushion inner finisher | 20. Seat wiring harness | 21. Wire harness cover |
| 22. Inner recliner cover | 23. RH inner leg cover | 24. Seat latch cover |
| 25. Inner reclining cover | 26. Outer reclining cover | 27. Outboard reclining arm inner cover |
| 28. Inboard reclining arm inner cover | 29. Reclining rod | 30. Armrest assembly (if equipped) |
| 31. Armrest cap (if equipped) | 32. Armrest bolt (if equipped) | 33. Seatback board |

Manual Passenger Seat



AWJIA0479GB

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | |
|---|--|---|
| 1. Headrest | 2. Headrest holder with multi position lock | 3. Headrest holder |
| 4. Seat fold lever | 5. Seat fold handle and cable | 6. Seatback assembly with armrest, with side airbag (if equipped) |
| 7. Seatback board without armrest, without airbag (if equipped) | 8. Seatback frame assembly without armrest, without airbag (if equipped) | 9. Seatback pad and cover without armrest, without airbag (if equipped) |
| 10. Seatback assembly without armrest, with side airbag (if equipped) | 11. Seat recline lever | 12. Seat cushion outer finisher |
| 13. Bolt cover | 14. Outer pedestal finisher | 15. Power seat frame assembly |
| 16. Seat cushion inner finisher | 17. Seat rear cover | 18. Inner recliner cover |
| 19. RH inner leg cover | 20. Seat latch cover | 21. Armrest cover (if equipped) |
| 22. Inboard reclining arm inner cover | 23. Outboard reclining arm outer cover | 24. Outboard reclining arm outer cover |
| 25. Seat cushion assembly | 26. Armrest assembly (if equipped) | 27. Armrest cap (if equipped) |
| 28. Armrest bolt (if equipped) | 29. Seatback pad and cover with armrest, without airbag (if equipped) | 30. Seatback frame assembly with armrest, without airbag (if equipped) |
| 31. Seatback board with armrest, without airbag (if equipped) | | |

Disassembly and Assembly


INFOID:000000005712793

SEATBACK TRIM AND PAD

NOTE:

Only complete outboard seatback assemblies can be replaced on vehicles equipped with side air bags. Be sure to set the front/rear cushion lifter to the top position.


1. Remove the seatback board.
2. Remove the retainer.



3. Remove the headrest.
4. From inside of the seatback, squeeze the headrest holder tabs at the base of the stay pipe and pull the up to remove.

NOTE:


Before installing the headrest holder, check its orientation (front/rear and right/left).



FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

- Remove the snap ring and the lumbar support lever knob.



6. **CAUTION:**


On the passenger seat during installation, the wire harness clips must be installed in the holes they were originally in.

Do not add additional clips.

Disconnect the seatback heater harness. Remove the seatback trim and pad assembly. Remove the hog ring to separate the seatback trim from the pad and the heater unit.

Removal of seatback assembly

- Remove the seatback board.
- Remove the retainer.
- Remove the side air bag harness connector from the seat cushion.
- Remove the seatback bolts (two for each side) and seatback assembly.




Installation of seatback assembly

- Installation is in the reverse order of removal.

SEATBACK BOARD - SOFT SEATBACK

Removal


- The seatback board is attached to the seat frame with the following:
 - 2 top tabs (A)
 - 4 side tabs (B)
 - 2 bottom clips (C) (must be replaced)
- Move seat to forward position.




FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

3. Hold the seatback board as shown and pull the top of the seatback board away from the seat back frame.



4. Pull the middle part of the seatback board to disengage the side tabs (B) from the seatback frame.
5. Pull the lower part of the seatback board to disengage the bottom clips from the seatback frame.




Installation

Installation is in the reverse order of removal.


SEATBACK BOARD - HARD SEATBACK

Removal

1. The seatback board is attached to the seat frame with the following:
 - 2 top tabs (A)
 - 2 side tabs (B)
 - 2 bottom clips (C) (must be replaced)
2. Move seat to forward position.




3. Hold the seatback board as shown and pull the bottom of the seatback board away from the seat back frame.



FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

4. Pull the middle part of the seatback board to disengage the side tabs (B) from the seatback frame.
5. Lift the upper part of the seatback board to disengage the top tabs from the seatback frame.



Installation

Installation is in the reverse order of removal.

SEAT CUSHION TRIM AND PAD


CAUTION:

- Front passenger seat is equipped with Occupant Classification System sensor and control module. Do not disassemble front passenger seat cushion assembly or remove trim as this will affect the Occupant Classification System calibration.
- Always replace passenger seat cushion as an assembly.
- When removed, the passenger seat cushion must always be placed pan side UP to prevent damage.
- During installation, the wire harness clips must be installed in the holes they were originally in. Do not add additional clips.
- The Occupant Classification System control module can only be replaced as part of the seat cushion assembly.


NOTE:

If the vehicle has been involved in a collision the seat must be inspected for damage. Refer to [SR-18, "For Frontal Collision"](#).

1. Remove the power seat switch knobs and power seat switch escutcheon (or recline knobs on manual seat).



2. Remove the front seat cushion finisher (inner).




3. Remove the power seat switch screws (or lift knobs on manual seats).

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

4. Remove four bolts and the seat cushion assembly.




5. Remove the retainer on the seat cushion frame, then remove the harness connector for the seat heater.
6. On the drivers seat only, after removing the seat cushion trim and pad, remove the hog rings to separate the trim cover from the pad and seat cushion heater unit.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

INFOID:0000000005386319

LH

SEC. 881



WIIA0949E

- | | | |
|---------------------------------|---------------------------|-----------------------|
| 1. Seatback pad | 2. Headrest | 3. Seatback latch |
| 4. Seatback latch release strap | 5. Seatback latch striker | 6. Seatback frame |
| 7. Outboard pivot cover | 8. Release lever handle | 9. Seat cushion frame |


REAR SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | |
|-----------------------------------|---------------------------|-------------------------------|
| 10. Seat cushion release assembly | 11. Outboard seat support | 12. Grocery bag hooks |
| 13. Inboard seat support | 14. Rear seat bracket | 15. Seat cushion pad |
| 16. Seat cushion trim | 17. Seatback trim | 18. Inboard outer pivot cover |
| 19. Inner inboard pivot cover | 20. Headrest guide | |

RH

SEC. 881



- | | | |
|---------------------------------|-----------------------------------|----------------------------------|
| 1. Seatback trim with armrest | 2. Seatback pad with armrest | 3. Seatback trim without armrest |
| 4. Seatback pad without armrest | 5. Seatback frame without armrest | 6. Seat cushion trim |

AWJIA0386GB

REAR SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | |
|---------------------------------|------------------------------------|-----------------------------------|
| 7. Seat cushion pad | 8. Seatback striker assembly | 9. Outboard pivot cover |
| 10. Seat cushion release handle | 11. Outboard seatback pivot anchor | 12. Seat cushion release lever |
| 13. Seat cushion frame | 14. Grocery bag hooks | 15. Inboard seatback pivot anchor |
| 16. Rear seat bracket | 17. Outer inboard hinge cover | 18. Inner inboard hinge cover |
| 19. Seatback frame with armrest | 20. Arm rest pad and frame | 21. Arm rest trim |
| 22. Seatback latch assembly | 23. Locking headrest guide | 24. Headrest |
| 25. Seatback release strap | 26. Free headrest guide | |