

SECTION ADP

AUTOMATIC DRIVE POSITIONER

CONTENTS

BASIC INSPECTION	4	EXIT ASSIST FUNCTION : Component Parts Location	22
DIAGNOSIS AND REPAIR WORKFLOW	4	EXIT ASSIST FUNCTION : Component Description	22
Work Flow	4		
INSPECTION AND ADJUSTMENT	7	ENTRY ASSIST FUNCTION	23
Preliminary Check	7	ENTRY ASSIST FUNCTION : System Diagram	23
Special Repair Requirement	7	ENTRY ASSIST FUNCTION : System Description	23
PRE-INSPECTION FOR DIAGNOSTIC	8	ENTRY ASSIST FUNCTION : Component Parts Location	24
Basic Inspection	8	ENTRY ASSIST FUNCTION : Component Description	25
SYSTEM DESCRIPTION	10	DIAGNOSIS SYSTEM (DRIVER SEAT C/U)	26
AUTOMATIC DRIVE POSITIONER SYSTEM	10	Diagnosis Description	26
AUTOMATIC DRIVE POSITIONER SYSTEM	10	CONSULT-III Function	26
AUTOMATIC DRIVE POSITIONER SYSTEM : System Diagram	10	DTC/CIRCUIT DIAGNOSIS	29
AUTOMATIC DRIVE POSITIONER SYSTEM : System Description	11	U1000 CAN COMM CIRCUIT	29
AUTOMATIC DRIVE POSITIONER SYSTEM : Component Parts Location	11	Description	29
AUTOMATIC DRIVE POSITIONER SYSTEM : Component Description	12	DTC Logic	29
MANUAL FUNCTION	13	Special Repair Requirement	29
MANUAL FUNCTION : System Diagram	14	B2112 SLIDING MOTOR	30
MANUAL FUNCTION : System Description	14	Description	30
MANUAL FUNCTION : Component Parts Location	15	DTC Logic	30
MANUAL FUNCTION : Component Description	16	Diagnosis Procedure	30
MEMORY FUNCTION	17	B2113 RECLINING MOTOR	32
MEMORY FUNCTION : System Diagram	17	Description	32
MEMORY FUNCTION : System Description	17	DTC Logic	32
MEMORY FUNCTION : Component Parts Location	19	Diagnosis Procedure	32
MEMORY FUNCTION : Component Description....	19	B2114 SEAT LIFTER FR	34
EXIT ASSIST FUNCTION	20	Description	34
EXIT ASSIST FUNCTION : System Diagram	20	DTC Logic	34
EXIT ASSIST FUNCTION : System Description	21	Diagnosis Procedure	34
		B2115 SEAT LIFTER RR	36
		Description	36

DTC Logic	36	Component Function Check	59
Diagnosis Procedure	36	Diagnosis Procedure	59
B2117 ADJ PEDAL MOTOR	38	Component Inspection	60
Description	38		
DTC Logic	38		
Diagnosis Procedure	38		
B2120 ADJ PEDAL SENSOR	40		
Description	40		
DTC Logic	40		
Diagnosis Procedure	40		
B2126 DETENT SW	42		
Description	42		
DTC Logic	42		
Diagnosis Procedure (Floor Shift)	42		
Diagnosis Procedure (Column Shift)	43		
B2128 UART COMMUNICATION LINE	45		
Description	45		
DTC Logic	45		
Diagnosis Procedure	45		
POWER SUPPLY AND GROUND CIRCUIT	47		
BCM	47		
BCM : Diagnosis Procedure	47		
DRIVER SEAT CONTROL UNIT	47		
DRIVER SEAT CONTROL UNIT :			
Diagnosis Procedure	48		
DRIVER SEAT CONTROL UNIT : Special Repair Requirement	48		
AUTOMATIC DRIVE POSITIONER CONTROL UNIT	48		
AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure	49		
AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Special Repair Requirement	49		
SLIDING SWITCH	50		
Description	50		
Component Function Check	50		
Diagnosis Procedure	50		
Component Inspection	51		
RECLINING SWITCH	53		
Description	53		
Component Function Check	53		
Diagnosis Procedure	53		
Component Inspection	54		
LIFTING SWITCH (FRONT)	56		
Description	56		
Component Function Check	56		
Diagnosis Procedure	56		
Component Inspection	57		
LIFTING SWITCH (REAR)	59		
Description	59		
PEDAL ADJUSTING SWITCH	62		
Description	62		
Component Function Check	62		
Diagnosis Procedure	62		
Component Inspection	64		
SEAT MEMORY SWITCH	65		
Description	65		
Component Function Check	65		
Diagnosis Procedure	65		
Component Inspection	66		
DOOR MIRROR REMOTE CONTROL SWITCH	67		
CHANGEOVER SWITCH	67		
CHANGEOVER SWITCH : Description	67		
CHANGEOVER SWITCH : Component Function Check	67		
CHANGEOVER SWITCH : Diagnosis Procedure	67		
CHANGEOVER SWITCH : Component Inspection	69		
MIRROR SWITCH	69		
MIRROR SWITCH : Description	69		
MIRROR SWITCH : Component Function Check	69		
MIRROR SWITCH : Diagnosis Procedure	69		
MIRROR SWITCH : Component Inspection	71		
POWER SEAT SWITCH GROUND CIRCUIT ...	73		
Diagnosis Procedure	73		
PARK POSITION SWITCH	74		
Description	74		
Component Function Check	74		
Diagnosis Procedure (Floor Shift)	74		
Diagnosis Procedure (Column Shift)	75		
FRONT DOOR SWITCH (DRIVER SIDE)	77		
Description	77		
Component Function Check	77		
Diagnosis Procedure	77		
Component Inspection	78		
SLIDING SENSOR	79		
Description	79		
Component Function Check	79		
Diagnosis Procedure	79		
RECLINING SENSOR	81		
Description	81		
Component Function Check	81		
Diagnosis Procedure	81		
LIFTING SENSOR (FRONT)	83		
Description	83		
Component Function Check	83		
Diagnosis Procedure	83		

LIFTING SENSOR (REAR)	85	DRIVER SEAT CONTROL UNIT	108
Description	85	Reference Value	108
Component Function Check	85	Fail Safe	112
Diagnosis Procedure	85	DTC Index	113
PEDAL ADJUSTING SENSOR	87	AUTOMATIC DRIVE POSITIONER CON-	
Description	87	TROL UNIT	114
Component Function Check	87	Reference Value	114
Diagnosis Procedure	87	BCM (BODY CONTROL MODULE)	117
MIRROR SENSOR	89	Reference Value	117
DRIVER SIDE	89	Terminal Layout	120
DRIVER SIDE : Description	89	Physical Values	120
DRIVER SIDE : Component Function Check	89	Fail Safe	125
DRIVER SIDE : Diagnosis Procedure	89	DTC Inspection Priority Chart	125
PASSENGER SIDE	91	DTC Index	126
PASSENGER SIDE : Description	91	WIRING DIAGRAM	128
PASSENGER SIDE :		AUTOMATIC DRIVE POSITIONER	128
Component Function Check	91	Wiring Diagram	128
PASSENGER SIDE : Diagnosis Procedure	91	SYMPTOM DIAGNOSIS	143
SLIDING MOTOR	93	ADP SYSTEM SYMPTOMS	143
Description	93	Symptom Table	143
Component Function Check	93	NORMAL OPERATING CONDITION	145
Diagnosis Procedure	93	Description	145
RECLINING MOTOR	95	PRECAUTION	146
Description	95	PRECAUTIONS	146
Component Function Check	95	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	146
Diagnosis Procedure	95	Precaution for Work	146
LIFTING MOTOR (FRONT)	97	PREPARATION	147
Description	97	PREPARATION	147
Component Function Check	97	Special Service Tool	147
Diagnosis Procedure	97	Commercial Service Tool	147
LIFTING MOTOR (REAR)	99	UNIT REMOVAL AND INSTALLATION ...	148
Description	99	DRIVER SEAT CONTROL UNIT	148
Component Function Check	99	Removal and Installation	148
Diagnosis Procedure	99	AUTOMATIC DRIVE POSITIONER CON-	
PEDAL ADJUSTING MOTOR	101	TROL UNIT	149
Description	101	Removal and Installation	149
Component Function Check	101	SEAT MEMORY SWITCH	150
Diagnosis Procedure	101	Removal and Installation	150
DOOR MIRROR MOTOR	103	DOOR MIRROR REMOTE CONTROL	
Description	103	SWITCH	151
Component Function Check	103	Removal and Installation	151
Diagnosis Procedure	103	PEDAL ADJUSTING MOTOR	152
Component Inspection	105	Removal and Installation	152
SEAT MEMORY INDICATOR LAMP	106		
Description	106		
Component Function Check	106		
Diagnosis Procedure	106		
Component Inspection	107		
ECU DIAGNOSIS INFORMATION	108		

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006163432

WORK FLOW



DETAILED FLOW

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

1. GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2. CHECK DTC WITH AUTOMATIC DRIVE POSITIONER SYSTEM

Check "Self Diagnostic Result" with CONSULT-III.

Refer to [ADP-113, "DTC Index"](#).

Is any symptom described and any DTC is displayed?

Symptom is described, DTC is displayed.>>GO TO 3

Symptom is not described, DTC is displayed.>>GO TO 7

Symptom is described, DTC is not displayed.>>GO TO 4

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

>> GO TO 7

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

>> GO TO 5

5. CHECK NORMAL OPERATING CONDITION

Check normal operating condition. Refer to [ADP-145, "Description"](#).

Is the incident normal operation?

YES >> Inspection End.

NO >> GO TO 6

6. PERFORM BASIC INSPECTION

Isolate the malfunctioning point with the basic inspection. Refer to [ADP-7, "Preliminary Check"](#).

>> GO TO 8

7. PERFORM DTC CONFIRMATION PROCEDURE

Perform the confirmation procedure for the detected DTC.

Is the DTC displayed?

YES >> GO TO 9

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

8. PERFORM COMPONENT FUNCTION CHECK

Perform the component function check for the isolated malfunctioning point.

>> GO TO 9

9. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Isolate the malfunctioning point by performing the diagnosis procedure relevant to the symptom during the component diagnosis.

>> GO TO 10

10. REPAIR OR REPLACE

Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

>> GO TO 11

11. FINAL CHECK

Perform the DTC confirmation procedure (if DTC is detected) or component function check (if no DTC is detected) again, and then check that the malfunction can be repaired securely.

Are all malfunctions corrected?

YES >> Inspection End.

Symptom is detected.>> GO TO 4

DTC is detected.>> GO TO 7

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT

Preliminary Check

INFOID:0000000006163433

1. FOREIGN OBJECTS

Check the following:

- objects on or behind the seats that could cause binding
- objects under the seats that may be interfering with the seat's moving parts
- objects under pedals that may interfere with movement

Are there any foreign objects that could be causing interference?

YES >> Remove objects.
NO >> GO TO 2

2. WIRING CONNECTIONS

1. Disconnect harness connectors.
2. Check terminals for damage or loose connections.
3. Reconnect harness connectors.

Are any connectors damaged or loose?

YES >> Repair or replace damaged parts.
NO >> GO TO 3

3. POWER AND GROUND

Check power supply and ground circuits for control unit. Refer to [ADP-48, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Refer to [ADP-113, "DTC Index"](#).
NO >> Repair or replace as necessary.

Special Repair Requirement

INFOID:0000000006163434

Refer to Owner's Manual for Automatic Drive Positioner system operating instructions.

ADP

PRE-INSPECTION FOR DIAGNOSTIC

< BASIC INSPECTION >

PRE-INSPECTION FOR DIAGNOSTIC

Basic Inspection

INFOID:0000000006163435

1. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and ground circuit as shown below.

- Driver seat control unit: Refer to [ADP-48, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).
- Automatic drive positioner control unit: Refer to [ADP-49, "AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning part.

2. CHECK MANUAL FUNCTION

Check the manual function operations by operating the relevant switches as shown below.

- Seat (slide, reclining, lifting front, lifting rear)
- Pedal assembly (forward, backward)
- Door mirror

Do all manual functions operate normally?

YES >> GO TO 3

NO (Seat, pedal, door mirror)>> Go to SYMPTOM 1, refer to [ADP-143, "Symptom Table"](#). And, GO TO 4 if the result of SYMPTOM 1 is OK.

3. CHECK MEMORY FUNCTION 1

Register the seat positions (refer to Owner's Manual) and check that all parts of the seat, pedals, steering wheel and door mirrors move to their memory positions correctly.

Are the operations normal?

YES >> Check each malfunction according to the instruction of the SYMPTOM 4, refer to [ADP-143, "Symptom Table"](#).

No (memory indicator operates normally)>> Go to SYMPTOM 2, refer to [ADP-143, "Symptom Table"](#).

No (memory indicator does not operate normally either)>> GO TO 5

4. CHECK MEMORY FUNCTION 2

Register the seat positions (refer to Owner's Manual) and check that all parts of the seat, pedals and door mirrors move to their memory positions correctly.

Are the operations normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 7

5. CHECK SEAT MEMORY SWITCH/MEMORY INDICATOR

Check the seat memory switch/memory switch indicator of the SYMPTOM 5, refer to [ADP-143, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 6

NO >> Repair or replace the malfunctioning part.

6. CHECK OPERATION CONDITION

Check the memory operation conditions (refer to [ADP-11, "AUTOMATIC DRIVE POSITIONER SYSTEM : System Description"](#)).

Are all operation conditions fulfilled?

YES >> Go to SYMPTOM 6, refer to [ADP-143, "Symptom Table"](#).

NO >> Fulfill the operation conditions. Refer to [ADP-11, "AUTOMATIC DRIVE POSITIONER SYSTEM : System Description"](#).

7. CHECK MECHANISM

Check for the following.

- Mechanism deformation or pinched foreign materials.

PRE-INSPECTION FOR DIAGNOSTIC

< BASIC INSPECTION >

- Interference with other parts because of poor installation.

Is any malfunction present in the relevant parts?

YES >> Go to SYMPTOM 3, refer to [ADP-143, "Symptom Table"](#).
NO >> Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

AUTOMATIC DRIVE POSITIONER SYSTEM

AUTOMATIC DRIVE POSITIONER SYSTEM

AUTOMATIC DRIVE POSITIONER SYSTEM : System Diagram

INFOID:0000000006163436



ALJIA0496GB

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

AUTOMATIC DRIVE POSITIONER SYSTEM : System Description

INFOID:000000006163437


OUTLINE

The system automatically moves the driver seat, pedal assembly and door mirror position by the driver seat control unit and the automatic drive positioner control unit. The driver seat control unit corresponds with the automatic drive positioner control unit by UART communication.

Function		Description
Manual function		The driving position (seat, pedal assembly and door mirror position) can be adjusted by using the power seat switch, pedal adjusting switch or door mirror remote control switch.
Memory function		The seat, pedal assembly and outside mirror move to the stored driving position by pressing seat memory switch (1 or 2).
Entry/Exit assist function	Exit	On exit, the seat moves backward.
	Entry	On entry, the seat returns from exiting position to the previous driving position.

AUTOMATIC DRIVE POSITIONER SYSTEM : Component Parts Location

INFOID:000000006163438



1. A. Automatic drive positioner control unit M33, M34
B. Pedal adjusting motor assembly E109, E110
C. A/T shift selector (column shift) M68
2. A. Steering column
B. Key switch and key lock solenoid M27
C. BCM M18, M19, M20 (view with instrument panel removed)
3. A. Door mirror remote control switch D10
B. Seat memory switch D5

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

4. Pedal adjusting switch M96	5. A. Door mirror LH D4, RH D107 B. Front door switch LH B8	6. A. A/T selector lever (floor shift) B. A/T shift selector (park position switch) M203 (King Cab), M204 (Crew Cab)
7. A. Sliding motor LH B204 (driver seat view), reclining motor LH B205, lifting motor (front) B206, lifting motor (rear) B207 B. Driver seat control unit B202, B203 C. Power seat switch LH B208		

AUTOMATIC DRIVE POSITIONER SYSTEM : Component Description

INFOID:0000000006163439

CONTROL UNITS

Item	Function
Driver seat control unit	<ul style="list-style-type: none">Main unit of automatic drive positioner systemIt is connected to the CAN.It communicates with the automatic drive positioner control unit via UART communication.
Automatic drive positioner control unit	<ul style="list-style-type: none">It communicates with the driver seat control unit via UART communication.Perform various controls with the instructions of driver seat control unit.Perform the controls of the pedal adjusting, door mirror and the seat memory switch.
BCM	<ul style="list-style-type: none">Transmit the following status to the driver seat control unit via CAN communication.Front door LH: OPEN/CLOSEIgnition switch position: ACC/ONDoor lock: UNLOCK (remote keyless entry request switch operation)Key IDKey switch: Insert/Pull out ignition keyStarter: CRANKING/OTHER
Combination meter	Transmit the vehicle speed signal to the driver seat control unit via CAN communication.
AV control unit	The setting change of auto drive positioner system can be performed on the display.
A/T shift selector (park position switch)	Transmit the shift position signal (P range) to the driver seat control unit.

INPUT PARTS

Switches

Item	Function
Key switch and key lock solenoid	The key switch is installed to detect the key inserted/removed status.
Front door switch LH	Detect front door (driver side) open/close status.
A/T shift selector (park position switch)	Detect the P range position of A/T selector lever.
Set switch	The registration and system setting can be performed with its operation.
Seat memory switch 1/2	The registration and operation can be performed with its operation.
Power seat switch	<ul style="list-style-type: none">The following switch is installed.Reclining switchLifting switch (front)Lifting switch (rear)Sliding switch <p>The specific parts can be operated with the operation of each switch.</p>

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Item	Function
Pedal adjusting switch	<p>The following switch is installed.</p> <ul style="list-style-type: none"> • Pedal forward • Pedal backward <p>The specific parts can be operated with the operation of each switch.</p>
Door mirror remote control switch	<p>The following switch is installed.</p> <ul style="list-style-type: none"> • Mirror switch • Changeover switch <p>The specific parts can be operated with the operation of each switch.</p>

Sensors

Item	Function
Door mirror sensor (LH/RH)	Detect the up/down and left/right position of outside mirror face.
Pedal adjusting sensor	Detect the forward/backward position of pedal assembly.
Lifting sensor (front)	Detect the up/down position of seat lifting (front).
Lifting sensor (rear)	Detect the up/down position of seat lifting (rear).
Reclining sensor	Detect the tilt of seatback.
Sliding sensor	Detect the front/rear position of seat.

OUTPUT PARTS

Item	Function
Door mirror motor (LH/RH)	Move the outside mirror face upward/downward and left/right.
Pedal adjusting motor	Move the pedal assembly forward/backward.
Lifting motor (front)	Move the seat lifting (front) upward/downward.
Lifting motor (rear)	Move the seat lifting (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat forward/backward.
Seat memory indicator	Illuminates or flashes according to the registration/operation status.


MANUAL FUNCTION

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

MANUAL FUNCTION : System Diagram

INFOID:000000006163440



ALJIA0185GB

MANUAL FUNCTION : System Description

INFOID:000000006163441

OUTLINE

The driving position (seat, pedal assembly and door mirror position) can be adjusted manually with power seat switch, pedal adjusting switch and door mirror remote control switch.

OPERATION PROCEDURE

1. Turn ignition switch ON.
2. Operate power seat switch, pedal adjusting switch or door mirror remote control switch.
3. The driver seat, pedal assembly or door mirror operates according to the operation of each switch.

DETAIL FLOW

Seat

Order	Input	Output	Control unit condition
1	Power seat switch (sliding, lifting, reclining)	—	The power seat switch signal is inputted to the driver seat control unit when the power seat switch is operated.
2	—	Motors (sliding, lifting, reclining)	The driver seat control unit outputs signals to each motor according to the power seat switch input signal.

Adjustable pedals

Order	Input	Output	Control unit condition
1	Pedal adjusting switch	—	The pedal adjusting switch signal is input to the automatic drive positioner control unit when the pedal adjusting switch is operated.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Order	Input	Output	Control unit condition
2	—	Motor	The automatic drive positioner control unit actuates the motor according to the operation of the pedal adjusting switch signal from the driver seat control unit.
3	Sensors (forward, backward)	—	The automatic drive positioner control unit recognizes any operation limit of each actuator via each sensor and will not operate the actuator anymore at that time.

Door Mirror


Order	Input	Output	Control unit condition
1	Door mirror remote control switch	—	The door mirror remote control switch signal is inputted to the automatic drive positioner control unit when the door mirror remote control switch is operated.
2	—	Motors (Door mirror motor)	The automatic drive positioner control unit actuates each motor according to the operation of the door mirror remote control switch.

NOTE:

The door mirrors can be operated manually when ignition switch is in either ACC or ON position. The ignition switch signal (ACC/ON) is transmitted from BCM to the driver seat control unit via CAN communication and from the driver seat control unit to the automatic drive positioner control unit via UART communication.

MANUAL FUNCTION : Component Parts Location

INFOID:0000000006163442



ALJIA0514ZZ

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

1. A. Automatic drive positioner control unit M33, M34	2. A. Steering column B. Key switch and key lock solenoid M27 C. BCM M18, M19, M20 (view with instrument panel removed)	3. A. Door mirror remote control switch D10 B. Seat memory switch D5
B. Pedal adjusting motor assembly E109, E110		
C. A/T shift selector (column shift) M68		
4. Pedal adjusting switch M96	5. A. Door mirror LH D4, RH D107 B. Front door switch LH B8	6. A. A/T selector lever (floor shift) B. A/T shift selector (park position switch) M203 (King Cab), M204 (Crew Cab)
7. A. Sliding motor LH B204 (driver seat view), reclining motor LH B205, lifting motor (front) B206, lifting motor (rear) B207 B. Driver seat control unit B202, B203 C. Power seat switch LH B208		

MANUAL FUNCTION : Component Description

INFOID:0000000006163443

CONTROL UNITS

Item	Function
Driver seat control unit	<ul style="list-style-type: none">Operates the specific seat motor with the signal from the power seat switch.Transmits the ignition switch signal (ACC/ON) via UART communication to the automatic drive positioner control unit.Transmits the pedal adjusting switch signal via UART communication to the automatic drive positioner control unit.
Automatic drive positioner control unit	Operates the specific motor with the signal from driver seat control unit or door mirror remote control switch.
BCM	<ul style="list-style-type: none">Recognizes the following status and transmits it to the driver seat control unit via CAN communication.Ignition position: ACC/ON

INPUT PARTS

Switches

Item	Function
Power seat switch	<p>The following switch is installed.</p> <ul style="list-style-type: none">Reclining switchLifting switch (front)Lifting switch (rear)Sliding switch <p>The specific parts can be operated with the operation of each switch.</p>
Pedal adjusting switch	<p>The following switch is installed.</p> <ul style="list-style-type: none">Pedal forwardPedal backward <p>The specific parts can be operated with the operation of each switch.</p>
Door mirror remote control switch	<p>The following switch is installed.</p> <ul style="list-style-type: none">Mirror switchChangeover switch <p>The specific parts can be operated with the operation of each switch.</p>

Sensors

Item	Function
Pedal adjusting sensor	Detect the forward/backward position of pedal assembly.

OUTPUT PARTS

AUTOMATIC DRIVE POSITIONER SYSTEM


< SYSTEM DESCRIPTION >

Item	Function
Door mirror motor (LH/RH)	Move the outside mirror face upward/downward and left/right.
Pedal adjusting motor	Move the pedal assembly forward/backward.
Lifting motor (front)	Move the seat lifter (front) upward/downward.
Lifting motor (rear)	Move the seat lifter (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat forward/backward.

MEMORY FUNCTION

MEMORY FUNCTION : System Diagram

INFOID:000000006163444



MEMORY FUNCTION : System Description

INFOID:000000006163445

OUTLINE

The driver seat control unit can store the optimum driving positions (seat, pedal assembly and door mirror position) for 2 people. If the front seat position is changed, one-touch (pressing desired memory switch for more than 0.5 second) operation allows changing to the other driving position.

NOTE:

Further information for the memory storage procedure. Refer to Owner's Manual.

OPERATION PROCEDURE

1. Turn ignition switch ON.
2. Press desired memory switch for more than 0.5 second.
3. Front seat LH, pedal assembly and door mirror will move to the memorized position.

OPERATION CONDITION

Satisfy all of the following items. The memory function is not performed if these items are not satisfied.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Item	Request status
Ignition position	ON
Switch inputs <ul style="list-style-type: none"> • Power seat switch • Pedal adjusting switch • Door mirror control switch • Set switch • Seat memory switch 	OFF (Not operated)
A/T selector lever	P position

DETAIL FLOW


Order	Input	Output	Control unit condition
1	Memory switch	—	The memory switch signal is inputted to the automatic drive positioner control unit when memory switch 1 or 2 is operated. Memory switch signal is input to driver seat control unit via UART communication.
2	—	Motors (seat, pedal adjusting, door mirror)	Driver seat control unit operates each motor of seat when it recognizes the memory switch pressed for 0.5 second or more and requests each motor operation to automatic drive positioner control unit via UART communication. The automatic drive positioner control unit operates each motor.
		Memory switch Indicator	Driver seat control unit requests the flashing of memory indicator to automatic drive positioner control unit via UART communication while either of the motors is operating. The automatic drive positioner control unit illuminates the memory indicator.
3	Sensors (seat, pedal adjusting, door mirror)	—	Driver seat control unit judges the operating seat position with each seat sensor input. The positions of the adjustable pedals and outside mirror are monitored with each sensor signal that is input from auto drive positioner control unit via UART communication. Driver seat control unit stops the operation of each motor when each part reaches the recorded address.
4	—	Memory switch Indicator	Driver seat control unit requests the illumination of memory indicator to auto drive positioner control unit via UART communication after all motors stop. The auto driving positioner control unit illuminates the memory indicator for 5 seconds.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

MEMORY FUNCTION : Component Parts Location

INFOID:0000000006163446



1. A. Automatic drive positioner control unit M33, M34
B. Pedal adjusting motor assembly E109, E110
C. A/T shift selector (column shift) M68
2. A. Steering column
B. Key switch and key lock solenoid M27
C. BCM M18, M19, M20 (view with instrument panel removed)
3. A. Door mirror remote control switch D10
B. Seat memory switch D5
4. Pedal adjusting switch M96
5. A. Door mirror LH D4, RH D107
B. Front door switch LH B8
6. A. A/T selector lever (floor shift)
B. A/T shift selector (park position switch) M203 (King Cab), M204 (Crew Cab)
7. A. Sliding motor LH B204 (driver seat view), reclining motor LH B205, lifting motor (front) B206, lifting motor (rear) B207
B. Driver seat control unit B202, B203
C. Power seat switch LH B208

ADP

K

L

M

N

O

P

MEMORY FUNCTION : Component Description

INFOID:0000000006163447

CONTROL UNITS

Item	Function
Driver seat control unit	<ul style="list-style-type: none"> The address of each part is recorded. Operates each motor of seat to the registered position. Requests the operations of pedal assembly and door mirror to automatic drive positioner control unit.
Automatic drive positioner control unit	Operates the pedal adjusting motor and door mirror with the instructions from the driver seat control.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

INPUT PARTS

Switches

Item	Function
Memory switch 1/2	The registration and memory function can be performed with its operation.

Sensors

Item	Function
Door mirror sensor (LH/RH)	Detect the up/down and left/right position of outside mirror face.
Pedal adjusting sensor	Detect the forward/backward position of pedal assembly.
Lifting sensor (front)	Detect the up/down position of seat lifting (front).
Lifting sensor (rear)	Detect the up/down position of seat lifting (rear).
Reclining sensor	Detect the tilt of seatback.
Sliding sensor	Detect the front/rear position of seat.


OUTPUT PARTS

Item	Function
Door mirror motor (LH/RH)	Move the outside mirror face upward/downward and left/right.
Pedal adjusting motor	Move the pedal assembly forward/backward.
Lifting motor (front)	Move the seat lifter (front) upward/downward.
Lifting motor (rear)	Move the seat lifter (rear) upward/downward.
Reclining motor	Tilt and raise up the seatback.
Sliding motor	Slide the seat forward/backward.
Memory indicator	Illuminates or blinks according to the registration/operation status.

EXIT ASSIST FUNCTION

EXIT ASSIST FUNCTION : System Diagram

INFOID:000000006163448



AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

EXIT ASSIST FUNCTION : System Description

INFOID:000000006163449

OUTLINE

When exiting, if the conditions are satisfied, the seat is moved backward from normal sitting position. The seat slide amount at entry/exit operation can be changed.

NOTE:

- This function is set to OFF before delivery (initial setting).
- Further information for the system setting procedure. Refer to Owner's Manual.

OPERATION PROCEDURE

1. Open the driver door with ignition switch in OFF position.
2. Front seat LH will move to the exiting position.

OPERATION CONDITION

Satisfy all of the following items. The exit assist function is not performed if these items are not satisfied.

Item	Request status
Ignition switch	OFF
System setting [Entry/exit assist function]	ON
Initialization	Done
Switch inputs	
• Power seat switch	
• Pedal adjusting switch	
• Door mirror remote control switch	
• Set switch	
• Seat memory switch	OFF (Not operated)
A/T selector lever	P position

DETAIL FLOW


Order	Input	Output	Control unit condition
1	Front door switch LH	—	Driver seat control unit receives front door switch LH signal (open) from BCM via CAN communication.
2	—	Motor (seat sliding)	Driver seat control unit operates the seat sliding motor, which recognizes that the front door LH is opened with ignition switch OFF.

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

EXIT ASSIST FUNCTION : Component Parts Location

INFOID:000000006163450



1. A. Automatic drive positioner control unit M33, M34
B. Pedal adjusting motor assembly E109, E110
C. A/T shift selector (column shift) M68
2. A. Steering column
B. Key switch and key lock solenoid M27
C. BCM M18, M19, M20 (view with instrument panel removed)
3. A. Door mirror remote control switch D10
B. Seat memory switch D5
4. Pedal adjusting switch M96
5. A. Door mirror LH D4, RH D107
B. Front door switch LH B8
6. A. A/T selector lever (floor shift)
B. A/T shift selector (park position switch) M203 (King Cab), M204 (Crew Cab)
7. A. Sliding motor LH B204 (driver seat view), reclining motor LH B205, lifting motor (front) B206, lifting motor (rear) B207
B. Driver seat control unit B202, B203
C. Power seat switch LH B208

EXIT ASSIST FUNCTION : Component Description

INFOID:000000006163451

CONTROL UNITS

Item	Function
Driver seat control unit	Operates the seat sliding motor for a constant amount.
BCM	Recognizes the following status and transmits it to the driver seat control unit via CAN communication. <ul style="list-style-type: none"> • Front door LH: OPEN/CLOSE

INPUT PARTS

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Switches

Item	Function
Front door switch LH	Detect front door LH open/close status.

Sensors

Item	Function
Sliding sensor	Detect the front/rear position of seat.


OUTPUT PARTS

Item	Function
Sliding motor	Slide the seat forward/backward.

ENTRY ASSIST FUNCTION

ENTRY ASSIST FUNCTION : System Diagram

INFOID:0000000006163452



ENTRY ASSIST FUNCTION : System Description

INFOID:0000000006163453

OUTLINE

The seat is in the exiting position when either following condition (A or B) is satisfied, the seat returns from exiting position to the previous driving position.

NOTE:

- This function is set to OFF before delivery (initial setting).
- Further information for the system setting procedure. Refer to Owner's Manual.

OPERATION PROCEDURE

1. A: Turn the ignition switch ON.
B: Turn the ignition switch from OFF to ACC after closing the driver door.
2. Front seat LH will return from the exiting position to entry position.

OPERATION CONDITION

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

Satisfy all of the following items. The entry assist function is not performed if these items are not satisfied.


Item	Request status
Seat	The vehicle is not moved after performing the exit assist function.
Switch inputs <ul style="list-style-type: none"> • Power seat switch • Pedal adjusting switch • Door mirror control switch • Set switch • Memory switch 	OFF (Not operated)
A/T selector lever	P position

DETAIL FLOW

Order	Input	Output	Control unit condition
1	Door switch/Ignition switch	—	Driver seat control unit receives the signals of ignition switch signal and front door switch from BCM via CAN communication.
2	—	Motor (sliding)	Driver seat control unit operates the sliding motor when the operating conditions are satisfied.
	Sensor (sliding)	—	Sensor monitors the operating positions of seat and then stops the operation of motor when seat reaches the recorded address.

ENTRY ASSIST FUNCTION : Component Parts Location

INFOID:000000006163454



ALJIA0514ZZ

AUTOMATIC DRIVE POSITIONER SYSTEM

< SYSTEM DESCRIPTION >

1. A. Automatic drive positioner control unit M33, M34	2. A. Steering column B. Key switch and key lock solenoid M27 C. BCM M18, M19, M20 (view with instrument panel removed)	3. A. Door mirror remote control switch D10 B. Seat memory switch D5	A
B. Pedal adjusting motor assembly E109, E110			B
C. A/T shift selector (column shift) M68			
4. Pedal adjusting switch M96	5. A. Door mirror LH D4, RH D107 B. Front door switch LH B8	6. A. A/T selector lever (floor shift) B. A/T shift selector (park position switch) M203 (King Cab), M204 (Crew Cab)	C
7. A. Sliding motor LH B204 (driver seat view), reclining motor LH B205, lifting motor (front) B206, lifting motor (rear) B207 B. Driver seat control unit B202, B203 C. Power seat switch LH B208			D

INFOID:0000000006163455

ENTRY ASSIST FUNCTION : Component Description

CONTROL UNITS

Item	Function
Driver seat control unit	According to the ignition signal and front door switch LH signal from BCM, • Operates the seat sliding motor for a constant amount.
BCM	Recognizes the following status and transmits it to the driver seat control unit via CAN communication. • Front door LH: OPEN/CLOSE • Ignition switch position: ACC/ON

INPUT PARTS

Switches

Item	Function
Front door switch LH	Detect front door LH open/close status.

Sensors

Item	Function
Sliding sensor	Detect the front/rear position of seat.

OUTPUT PARTS

Item	Function
Sliding motor	Slide the seat forward/backward.

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

Diagnosis Description

INFOID:0000000006163456

The auto drive positioner system can be checked and diagnosed for component operation with CONSULT-III.

DIAGNOSTIC MODE

Diagnostic mode [AUTO DRIVE POS.]	Description
WORK SUPPORT	Changes the setting of each function.
SELF DIAGNOSTIC RESULT	Performs self-diagnosis for the auto drive positioner system and displays the results.
DATA MONITOR	Displays input signals transmitted from various switches and sensors to driver seat control unit in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	Drive each output device.
ECU IDENTIFICATION	Displays part numbers of driver seat control unit parts.

CONSULT-III Function

INFOID:0000000006163457

SELF-DIAGNOSIS RESULTS

Refer to [ADP-113, "DTC Index"](#).

DATA MONITOR

Monitor Item	Unit	Main Signals	Selection From Menu	Contents
SET SW	"ON/OFF"	×	×	ON/OFF status judged from the setting switch signal.
MEMORY SW1	"ON/OFF"	×	×	ON/OFF status judged from the seat memory switch 1 signal.
MEMORY SW2	"ON/OFF"	×	×	ON/OFF status judged from the seat memory switch 2 signal.
SLIDE SW-FR	"ON/OFF"	×	×	ON/OFF status judged from the sliding switch (forward) signal.
SLIDE SW-RR	"ON/OFF"	×	×	ON/OFF status judged from the sliding switch (backward) signal.
RECLN SW-FR	"ON/OFF"	×	×	ON/OFF status judged from the reclining switch (forward) signal.
RECLN SW-RR	"ON/OFF"	×	×	ON/OFF status judged from the reclining switch (backward) signal.
LIFT FR SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch front (up) signal.
LIFT FR SW-DN	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch front (down) signal.
LIFT RR SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch rear (up) signal.
LIFT RR SW-DN	"ON/OFF"	×	×	ON/OFF status judged from the lifting switch rear (down) signal.
MIR CON SW-UP	"ON/OFF"	×	×	ON/OFF status judged from the mirror switch (up) signal.
MIR CON SW-DN	"ON/OFF"	×	×	ON/OFF status judged from the mirror switch (down) signal.
MIR CON SW-RH	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (passenger side) signal.
MIR CON SW-LH	"ON/OFF"	×	×	ON/OFF status judged from the door mirror remote control switch (driver side) signal.

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

< SYSTEM DESCRIPTION >

Monitor Item	Unit	Main Signals	Selection From Menu	Contents
MIR CHNG SW-R	“ON/OFF”	×	×	ON/OFF status judged from the door mirror remote control switch (switching to right) signal.
MIR CHNG SW-L	“ON/OFF”	×	×	ON/OFF status judged from the door mirror remote control switch (switching to left) signal.
PEDAL SW-FR	“ON/OFF”	×	×	ON/OFF status judged from the pedal adjusting switch (forward) signal.
PEDAL SW-RR	“ON/OFF”	×	×	ON/OFF status judged from the pedal adjusting switch (backward) signal.
DETENT SW	“ON/OFF”	×	×	The selector lever position “OFF (P position) / ON (other than P position)” judged from the park position switch signal.
STARTER SW	“ON/OFF”	×	×	Ignition key switch ON (START, ON) /OFF (ACC, OFF) status judged from the ignition switch signal.
SLIDE PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
RECLN PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves backward, the value increases. If it moves forward, the value decreases.
LIFT FR PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases.
LIFT RR PULSE	—	—	×	Value (32768) when battery connections are standard. If it moves DOWN, the value increases. If it moves UP, the value decreases.
MIR/SEN RH U-D	“V”	—	×	Voltage input from door mirror sensor (passenger side) up/down is displayed.
MIR/SEN RH R-L	“V”	—	×	Voltage input from door mirror sensor (passenger side) left/right is displayed.
MIR/SEN LH U-D	“V”	—	×	Voltage input from door mirror sensor (driver side) up/down is displayed.
MIR/SEN LH R-L	“V”	—	×	Voltage input from door mirror sensor (driver side) left/right is displayed.
PEDAL SEN	“V”	—	×	Pedal position (voltage) judged from the pedal adjusting sensor signal is displayed.

ACTIVE TEST

CAUTION:

When driving vehicle, do not perform active test.

Test item	Description
SEAT SLIDE	Activates/deactivates the sliding motor.
SEAT RECLINING	Activates/deactivates the reclining motor.
SEAT LIFTER FR	Activates/deactivates the lifting motor (front).
SEAT LIFTER RR	Activates/deactivates the lifting motor (rear).
PEDAL MOTOR	Activates/deactivates the pedal adjusting motor.
MIRROR MOTOR RH	Activates/deactivates the mirror motor (passenger side).
MIRROR MOTOR LH	Activates/deactivates the mirror motor (driver side).
MEMORY SW INDCTR	Turns ON/OFF the memory indicator.

WORK SUPPORT

DIAGNOSIS SYSTEM (DRIVER SEAT C/U)

< SYSTEM DESCRIPTION >

Work item	Content	Item
SEAT SLIDE VOLUME SET	The amount of seat sliding for entry/exit assist can be selected from 3 items.	40 mm
		80 mm
		150 mm
EXIT SEAT SLIDE SETTING	Entry/exit assist (seat) can be selected: ON (operated) – OFF (not operated)	ON
		OFF

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000006163458

Refer to [BCS-27, "Description"](#).

DTC Logic

INFOID:000000006163459

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000	CAN COMM CIRCUIT	<ul style="list-style-type: none">Driver seat control unit cannot communicate to other control units.Driver seat control unit cannot communicate for more than the specified time.	<ul style="list-style-type: none">Harness or connectors (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. STEP 1

Turn ignition switch ON and wait at least 3 seconds.

>> GO TO 2

2. STEP 2

Check "Self diagnostic result" with CONSULT-III.

Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [BCS-27, "Diagnosis Procedure"](#).

NO >> Inspection End.

Special Repair Requirement

INFOID:000000006163460

Refer to Owner's Manual.

ADP

B2112 SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

B2112 SLIDING MOTOR

Description

INFOID:0000000006163461

- The seat sliding motor is installed to the power seat frame assembly.
- The seat sliding motor is installed with the driver seat control unit.
- Slides the seat frontward/rearward by changing the rotation direction of sliding motor.

DTC Logic

INFOID:0000000006163462

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2112	SEAT SLIDE	The driver seat control unit detects the output of sliding motor output terminal for 0.1 second or more even if the sliding switch is not input.	<ul style="list-style-type: none">• Driver seat control unit

DTC CONFIRMATION PROCEDURE

1. STEP 1

Turn ignition switch ON.

>> GO TO 2

2. STEP 2

Check "Self diagnostic result" with CONSULT-III.

Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [ADP-30, "Diagnosis Procedure"](#).

NO >> Inspection End.

NOTE:

First perform diagnosis for B2126 if B2126 is detected. Refer to [ADP-43, "Diagnosis Procedure \(Column Shift\)"](#).

Diagnosis Procedure

INFOID:0000000006163463

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT-III.
3. Erase the DTC.
4. Perform DTC confirmation procedure. Refer to [ADP-30, "DTC Logic"](#).

Is the DTC displayed again?

YES >> GO TO 2.

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

2. CHECK SLIDING MOTOR CIRCUIT (POWER SHORT)

1. Turn ignition switch OFF.
2. Disconnect sliding motor and driver seat control unit connector.
3. Check voltage between sliding motor harness connector and ground.

B2112 SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Voltage (V) (Approx.)
Sliding motor			
Connector	Terminals		
B204	1	Ground	0
	5		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair circuit for short to voltage.

3. CHECK DRIVER SEAT CONTROL UNIT OUTPUT SIGNAL

1. Connect driver seat control unit connector.
2. Check voltage between driver seat control unit harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Driver seat control unit			
Connector	Terminals		
B203	35	Ground	0
	42		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#)

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> Inspection End.

ADP

K

L

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

B2113 RECLINING MOTOR

Description

INFOID:0000000006163464

- The seat reclining motor is installed to the seatback assembly.
- The seat reclining motor is activated with the driver seat control unit.
- Tilts the seatback frontward/rearward by changing the rotation direction of reclining motor.

DTC Logic

INFOID:0000000006163465

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2113	SEAT RECLINING	The driver seat control unit detects the output of reclining motor output terminal for 0.1 second or more even if the reclining switch is not input.	• Driver seat control unit

DTC CONFIRMATION PROCEDURE

1. STEP 1

Turn ignition switch ON.

>> GO TO 2

2. STEP 2

Check "Self diagnostic result" with CONSULT-III.

Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [ADP-32, "Diagnosis Procedure"](#).
NO >> Inspection End.

NOTE:

First perform diagnosis for B2126 if B2126 is detected. Refer to [ADP-43, "Diagnosis Procedure \(Column Shift\)"](#).

Diagnosis Procedure

INFOID:0000000006163466

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT-III.
3. Erase the DTC.
4. Perform DTC confirmation procedure. Refer to [ADP-32, "DTC Logic"](#).

Is the DTC displayed again?

YES >> GO TO 2.
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

2. CHECK RECLINING MOTOR CIRCUIT (POWER SHORT)

1. Turn ignition switch OFF.
2. Disconnect reclining motor and driver seat control unit connector.
3. Check voltage between reclining motor harness connector and ground.

B2113 RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

(+) Reclining motor		(-)	Voltage (V) (Approx.)
Connector	Terminals		
B205	2	Ground	0
	3		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair circuit for short to voltage.

3. CHECK DRIVER SEAT CONTROL UNIT OUTPUT SIGNAL

1. Connect driver seat control unit connector.
2. Check voltage between driver seat control unit harness connector and ground.

(+) Driver seat control unit		(-)	Voltage (V) (Approx.)
Connector	Terminals		
B203	36	Ground	0
	44		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> Inspection End.

ADP

K

L

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

B2114 SEAT LIFTER FR

Description

INFOID:0000000006163467

- The lifting motor (front) is installed to the power seat frame assembly.
- The lifting motor (front) is activated with the driver seat control unit.
- Tilts the seat front up/down by changing the rotation direction of lifting motor (front).

DTC Logic

INFOID:0000000006163468

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2114	SEAT LIFTER FR	The driver seat control unit detects the output of lifting motor (front) output terminal for 0.1 second or more even if the lifting switch is not input.	• Driver seat control unit

DTC CONFIRMATION PROCEDURE

1. STEP 1

Turn ignition switch ON.

>> GO TO 2

2. STEP 2

Check "Self diagnostic result" with CONSULT-III.

Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [ADP-34, "Diagnosis Procedure"](#).
NO >> Inspection End.

NOTE:

First perform diagnosis for B2126 if B2126 is detected. Refer to [ADP-43, "Diagnosis Procedure \(Column Shift\)"](#).

Diagnosis Procedure

INFOID:0000000006163469

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT-III.
3. Erase the DTC.
4. Perform DTC confirmation procedure. Refer to [ADP-34, "DTC Logic"](#).

Is the DTC displayed again?

YES >> GO TO 2.
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

2. CHECK LIFTING MOTOR (FRONT) CIRCUIT (POWER SHORT)

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and tilt motor connector.
3. Check voltage between tilt motor harness connector and ground.

B2114 SEAT LIFTER FR

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Voltage (V) (Approx.)
Lifting motor (front)			
Connector	Terminals		
	1		
B206	5	Ground	0

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair circuit for short to voltage.

3. CHECK AUTOMATIC DRIVER POSITIONER CONTROL UNIT OUTPUT SIGNAL

1. Connect automatic drive positioner control unit connector.
2. Check voltage between automatic drive positioner control unit harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Automatic drive positioner control unit			
Connector	Terminals		
	37		
B203	45	Ground	0

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace automatic drive positioner control unit. Refer to [ADP-148, "Removal and Installation".](#)

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident".](#)

>> Inspection End.

ADP

< DTC/CIRCUIT DIAGNOSIS >

B2115 SEAT LIFTER RR

Description

INFOID:0000000006163470

- The lifting motor (rear) is installed to the power seat frame assembly.
- The lifting motor (rear) is activated with the driver seat control unit.
- Tilts the seat rear up/down by changing the rotation direction of lifting motor (rear).

DTC Logic

INFOID:0000000006163471

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2115	SEAT LIFTER RR	The driver seat control unit detects the output of lifting motor (rear) output terminal for 0.1 second or more even if the lifting switch is not input.	• Driver seat control unit

DTC CONFIRMATION PROCEDURE

1. STEP 1

Turn ignition switch ON.

>> GO TO 2

2. STEP 2

Check "Self diagnostic result" with CONSULT-III.

Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [ADP-36, "Diagnosis Procedure"](#).
NO >> Inspection End.

NOTE:

First perform diagnosis for B2126 if B2126 is detected. Refer to [ADP-43, "Diagnosis Procedure \(Column Shift\)"](#).

Diagnosis Procedure

INFOID:0000000006163472

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self diagnostic result" with CONSULT-III.
3. Erase the DTC.
4. Perform DTC confirmation procedure. Refer to [ADP-36, "DTC Logic"](#).

Is the DTC displayed again?

YES >> GO TO 2.
NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

2. CHECK LIFTING MOTOR (REAR) CIRCUIT (POWER SHORT)

1. Turn ignition switch OFF.
2. Disconnect reclining motor and driver seat control unit connector.
3. Check voltage between reclining motor harness connector and ground.

B2115 SEAT LIFTER RR

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Voltage (V) (Approx.)
Lifting motor (rear)			
Connector	Terminals		
	1		
B207	5	Ground	0

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair circuit for short to voltage.

3. CHECK DRIVER SEAT CONTROL UNIT OUTPUT SIGNAL

1. Connect driver seat control unit connector.
2. Check voltage between driver seat control unit harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Driver seat control unit			
Connector	Terminals		
	38		
B203	39	Ground	0

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> Inspection End.

ADP

K

L

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

B2117 ADJ PEDAL MOTOR

Description

INFOID:0000000006163473

- The pedal adjusting sensor is installed to pedal adjusting motor assembly.
- The resistance of pedal adjusting sensor is changed according to the forward/backward position of pedal assembly.
- The terminal voltage of automatic drive positioner control unit will be changed according to a change of pedal adjusting sensor resistance. Automatic drive positioner control unit calculates the pedal position from the voltage.

DTC Logic

INFOID:0000000006163474

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2117	ADJ PEDAL MOTOR	When any manual or automatic operations are not performed, if motor operation is detected for 0.1 second or more, status is judged "Output error".	<ul style="list-style-type: none">• Harness and connectors (pedal adjusting sensor circuit is opened/shorted, pedal adjusting sensor power supply circuit is opened/shorted.)• Pedal adjusting sensor

DTC CONFIRMATION PROCEDURE

1. STEP 1

Turn ignition switch ON.

>> GO TO 2

2. STEP 2

Check "Self diagnostic result" with CONSULT-III.

Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [ADP-38, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000006163475

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK PEDAL ADJUSTING MECHANISM

Check the following.

- Operation malfunction caused by pedal adjusting mechanism deformation or pinched harness or other foreign materials
- Operation malfunction and interference with other parts by poor installation

Is the inspection result normal?

YES >> GO TO 2
NO >> Repair or replace the malfunctioning part and check again.

2. CHECK FUNCTION

1. Turn ignition switch ON.
2. Check "PEDAL MOTOR" in "Active test" mode with CONSULT-III.

Test item	Description
PEDAL MOTOR	The pedal adjusting motor is activated by receiving the drive signal.

B2117 ADJ PEDAL MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Pedal adjusting motor assembly circuit is OK.
NO >> GO TO 3

3. CHECK PEDAL ADJUSTING MOTOR ASSEMBLY CIRCUIT HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and pedal adjusting motor assembly.
3. Check continuity between automatic drive positioner control unit connector M34 (A) terminals 37, 45 and pedal adjusting motor assembly connector E109 (B) terminals 1, 2.

37 - 1 : Continuity should exist.

45 - 2 : Continuity should exist.

4. Check continuity between automatic drive positioner control unit connector M34 (A) terminals 37, 45 and ground.

37 - Ground : Continuity should not exist.

45 - Ground : Continuity should not exist.

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

4. CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT OUTPUT SIGNAL

1. Connect the automatic drive positioner control unit and pedal adjusting motor assembly.
2. Check voltage between automatic drive positioner control unit connector and ground.

Connector	Terminals		Condition	Voltage (V) (Approx.)	
	(+)	(-)			
M34	37	Ground	Pedal adjusting switch ON (FORWARD operation)	Battery voltage	
			Other than above	0	
	45		Pedal adjusting switch ON (BACKWARD operation)	Battery voltage	
			Other than above	0	

Is the inspection result normal?



YES >> Replace pedal adjusting motor assembly. Refer to [ADP-152, "Removal and Installation"](#).
NO >> GO TO 5

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).
NO >> Repair or replace the malfunctioning part.



B2120 ADJ PEDAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

B2120 ADJ PEDAL SENSOR

Description

INFOID:0000000006163476

- The pedal adjusting sensor is installed in the pedal adjusting motor assembly.
- The resistance of pedal adjusting sensor is changed according to the forward/backward position of pedal adjusting motor assembly.
- The terminal voltage of automatic drive positioner control unit will be changed according to a change of pedal adjusting sensor resistance. Automatic drive positioner control unit calculates the pedal assembly position from the voltage.

DTC Logic

INFOID:0000000006163477

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2120	ADJ PEDAL SENSOR	The input voltage of pedal adjusting sensor is 0.5V or less or 4.5V or higher, for 0.5 seconds or more.	<ul style="list-style-type: none">• Harness and connectors (Pedal adjusting sensor circuit is opened/shorted, pedal adjusting sensor power supply circuit is opened/shorted.)• Pedal adjusting sensor

DTC CONFIRMATION PROCEDURE

1. STEP 1

Turn ignition switch ON.

>> GO TO 2

2. STEP 2

Check "Self diagnostic result" with CONSULT-III.

Is the DTC is detected?

YES >> Perform diagnosis procedure. Refer to [ADP-40, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000006163478

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK PEDAL ADJUSTING SENSOR SIGNAL

1. Turn ignition switch ON.
2. Select "PEDAL SEN" in "Data monitor" mode with CONSULT-III.
3. Check the pedal adjusting sensor signal under the following condition.

Monitor item	Condition		Value
PEDAL SEN	Pedal position	Forward	0.5V
		Backward	4.5V

Is the value normal?

YES >> Pedal adjusting circuit is OK.
NO >> GO TO 2

2. CHECK PEDAL ADJUSTING MOTOR ASSEMBLY CIRCUIT HARNESS CONTINUITY

B2120 ADJ PEDAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect automatic drive positioner control unit and pedal adjusting motor assembly.
2. Check continuity between automatic drive positioner connector M33 (A) terminal 8, M34 (C) terminals 33 and 41 and pedal adjusting motor assembly connector E110 (B) terminals 3, 4, 5.

8 - 4 : Continuity should exist.

33 - 3 : Continuity should exist.

41 - 5 : Continuity should exist.

3. Check continuity between automatic drive positioner control unit connector M33 (A) terminal 8, M34 (C) terminals 33 and 41 and ground.

8 - Ground : Continuity should not exist.


33 - Ground : Continuity should not exist.

41 - Ground : Continuity should not exist.

Is the inspection result normal?

YES >> Replace pedal adjusting motor assembly. Refer to [ADP-152, "Removal and Installation".](#)

NO >> Repair or replace harness.



< DTC/CIRCUIT DIAGNOSIS >

B2126 DETENT SW

Description

INFOID:0000000006163479

- The park position switch is installed on A/T shift selector. It is turned OFF when the A/T shift selector is in P position.
- The driver seat control unit judges that the A/T shift selector is in P position if continuity does not exist in this circuit.

DTC Logic

INFOID:0000000006163480

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2126	DETENT SW	A/T shift selector is in P position and the vehicle speed of 4 ± 2 MPH (7 ± 4 km/h) is detected.	<ul style="list-style-type: none">• Harness and connectors (Park position switch circuit is opened/shorted.)• A/T shift selector (park position switch)• Combination meter (CAN communication)

DTC CONFIRMATION PROCEDURE

1. STEP 1

Drive the vehicle at 4 ± 2 MPH (7 ± 4 km/h) or more.

>> GO TO 2

2. STEP 2

Check "Self diagnostic result" with CONSULT-III.

Is the DTC detected?

YES >> Perform diagnosis procedure. Refer to [ADP-42, "Diagnosis Procedure \(Floor Shift\)"](#) or [ADP-43, "Diagnosis Procedure \(Column Shift\)"](#).

NO >> Inspection End.

Diagnosis Procedure (Floor Shift)

INFOID:0000000006163481

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK DTC

Check "Self diagnostic result" for BCM with CONSULT-III.

Are other DTCs detected?

YES >> Check the DTC.

NO >> GO TO 2

2. CHECK PARK POSITION SWITCH SIGNAL

1. Turn ignition switch ON.
2. Select "DETENT SW" in "Data Monitor" mode with CONSULT-III.
3. Check park position switch signal under the following condition.

Monitor item	Condition		Status
DETENT SW	A/T shift selector	P position	OFF
		Other than above	ON

Is the status normal?

B2126 DETENT SW

< DTC/CIRCUIT DIAGNOSIS >

YES >> A/T shift selector (park position switch) circuit is OK.
NO >> GO TO 3

3. CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH) HARNESS

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector and driver seat control unit.
3. Check continuity between A/T shift selector connector M203 (King Cab) or M204 (Crew Cab) terminal 6 and driver seat control unit connector B202 terminal 21.

6 - 21 : Continuity should exist.

4. Check continuity between A/T shift selector connector M203 (King Cab) or M204 (Crew Cab) terminal 6 and ground.

6 - Ground : Continuity should not exist.

Is the inspection result normal?

YES >> GO TO 4
NO >> Repair or replace harness.

4. CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH)

Check continuity between A/T shift selector (park position switch) terminals as follows.

Terminals		Condition	Continuity
5	6	P position	No
		Other than P position	Yes

Is the inspection result normal?

YES >> GO TO 5
NO >> Replace A/T shift selector. Refer to [TM-185, "A/T Shift Selector Removal and Installation"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

ADP

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).
NO >> Repair or replace the malfunctioning part.

Diagnosis Procedure (Column Shift)

INFOID:0000000006163482

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK DTC

Check "Self diagnostic result" for BCM with CONSULT-III.

Are other DTCs detected?

YES >> Check the DTC.
NO >> GO TO 2

2. CHECK PARK POSITION SWITCH SIGNAL

1. Turn ignition switch ON.
2. Select "DETENT SW" in "Data Monitor" mode with CONSULT-III.
3. Check park position switch signal under the following condition.

Monitor item	Condition		Status
DETENT SW	A/T shift selector	P position	OFF
		Other than above	ON

Is the status normal?

B2126 DETENT SW

< DTC/CIRCUIT DIAGNOSIS >

YES >> A/T shift selector (park position switch) circuit is OK.
NO >> GO TO 3

3. CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH) HARNESS

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector and driver seat control unit.
3. Check continuity between A/T shift selector connector M68 terminal 8 and driver seat control unit connector B202 terminal 21.

8 - 21 : Continuity should exist.

4. Check continuity between A/T shift selector connector M68 terminal 8 and ground.

8 - Ground : Continuity should not exist.

5. Check continuity between A/T shift selector connector M68 terminal 1 and ground.

1 - Ground : Continuity should exist.

Is the inspection result normal?

YES >> GO TO 4
NO >> Repair or replace harness.

4. CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH)

Check continuity between A/T shift selector (park position switch) terminals as follows.

Terminals		Condition	Continuity
8	1	P position	No
		Other than P position	Yes

Is the inspection result normal?

YES >> GO TO 5
NO >> Replace A/T shift selector. Refer to [TM-185, "A/T Shift Selector Removal and Installation"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).
NO >> Repair or replace the malfunctioning part.

B2128 UART COMMUNICATION LINE

< DTC/CIRCUIT DIAGNOSIS >

B2128 UART COMMUNICATION LINE

Description

INFOID:0000000006163483

Driver seat control unit performs UART communication with the automatic drive positioner control unit using 2 communication lines, TX and RX line. Driver seat control unit receives the operation signals of pedal adjusting switch, door mirror remote control switch, set switch and memory switch and the position signals of adjustable pedal sensor and door mirror sensor from the automatic drive positioner control unit and transmits the operation request signal.

DTC Logic

INFOID:0000000006163484

DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2128	UART COMM	The communication between driver seat control unit and automatic drive positioner control unit is interrupted for a period of time.	<ul style="list-style-type: none"> UART communication line (UART communication line is open or shorted) Driver seat control unit Automatic drive positioner control unit

DTC CONFIRMATION PROCEDURE

1. STEP 1

Turn ignition switch ON.

>> GO TO 2

2. STEP 2

Operate pedal adjusting switch for more than 2 seconds.

>> GO TO 3

3. PROCEDURE 3

Check "Self diagnostic result" with CONSULT-III.

Is the DTC detected?

ADP

YES >> Perform diagnosis procedure. Refer to [ADP-45, "Diagnosis Procedure"](#).
 NO >> Inspection End.

Diagnosis Procedure


INFOID:0000000006163485

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK UART COMMUNICATION LINE CONTINUITY

- Turn ignition switch OFF.
- Disconnect driver seat control unit and automatic drive positioner control unit.
- Check continuity between driver seat control unit harness connector and automatic drive positioner control unit harness connector.

Driver seat control unit connector	Terminal	Automatic drive positioner control unit connector	Terminal	Continuity



B2128 UART COMMUNICATION LINE

< DTC/CIRCUIT DIAGNOSIS >

B202	1	M33	10	Yes
	17		26	

4. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal	Ground	Continuity
B202	1 17		No

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Repair or replace harness.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT BCM

BCM : Diagnosis Procedure

INFOID:000000006163486

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	22 (15A)
70		F (50A)
11	Ignition ACC or ON	4 (10A)
38	Ignition ON or START	59 (10A)

Is the fuse blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM harness connector and ground.

Connector	Terminals		Power source	Condition	Voltage (V) (Ap- prox.)
	(+)	(-)			
M18	11	Ground	ACC power supply	Ignition switch ACC or ON	Battery voltage
	38	Ground	Ignition power supply	Ignition switch ON or START	Battery voltage
M20	57	Ground	Battery power supply	Ignition switch OFF	Battery voltage
	70	Ground	Battery power supply	Ignition switch OFF	Battery voltage

Is the measurement value normal?

YES >> GO TO 3
NO >> Repair or replace harness.


3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.


BCM		Ground	Continuity
Connector	Terminal		
M20	67		Yes

Does continuity exist?

YES >> Inspection End.
NO >> Repair or replace harness.



ADP



DRIVER SEAT CONTROL UNIT

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DRIVER SEAT CONTROL UNIT : Diagnosis Procedure

INFOID:000000006163487

NOTE:


Do not disconnect the battery negative terminal and the driver seat control unit connector until DTC is confirmed with CONSULT-III.

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit.
3. Check voltage between driver seat control unit harness connector and ground.

Terminals		Power source	Condition	Voltage (V) (Approx.)
(+)	(-)			
Driver seat control unit connector	Terminal	Ground	START power supply	Ignition switch START
B202	6		Battery power supply	Ignition switch OFF
B203	33	Ground		Battery voltage
	40			



Is the inspection result normal?


YES >> GO TO 2
NO >> Check the following.

- Repair or replace harness.
- Circuit breaker.

2. CHECK GROUND CIRCUIT

Check continuity between the driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal	Ground	Continuity
B202	32		Yes
B203	48		



Is the inspection result normal?

YES >> Driver seat control unit power supply and ground circuit are OK.
NO >> Repair or replace harness.

DRIVER SEAT CONTROL UNIT : Special Repair Requirement

INFOID:000000006163488

1. PERFORM ADDITIONAL SERVICE

Perform additional service when removing battery negative terminal.

>> Refer to Owner's Manual.

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure

INFOID:000000006163489

NOTE:


Do not disconnect the battery negative terminal and the driver seat control unit connector until DTC is confirmed with CONSULT-III.

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the automatic drive positioner control unit.
3. Check voltage between automatic drive positioner control unit harness connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
Automatic drive positioner control unit connector	Terminal	
M34	34	Ground
	39	Battery voltage



Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace harness.

2. CHECK GROUND CIRCUIT


Check continuity between the automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M34	40		
	48		Yes

Is the inspection result normal?

YES >> Automatic drive positioner control unit power supply and ground circuit are OK.

NO >> Repair or replace harness.



AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Special Repair Requirement

INFOID:000000006163490

1. PERFORM ADDITIONAL SERVICE

Perform additional service when removing battery negative terminal.

>> Refer to Owner's Manual.

SLIDING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING SWITCH

Description

INFOID:0000000006163491

Sliding switch is equipped to the power seat switch LH on the seat cushion trim cover. The operation signal is input to the driver seat control unit when the sliding switch is operated.

Component Function Check

INFOID:0000000006163492

1. CHECK FUNCTION

1. Select "SLIDE SW-FR", "SLIDE SW-RR" in "Data monitor" mode with CONSULT-III.
2. Check sliding switch signal under the following conditions.

Monitor item	Condition	Status
SLIDE SW-FR	Sliding switch (forward)	Operate ON
		Release OFF
SLIDE SW-RR	Sliding switch (backward)	Operate ON
		Release OFF

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-50, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163493

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK SLIDING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminals		Condition	Voltage (V) (Approx.)	
	(+)	(-)			
B202	11	Ground	Operate (backward)	0	
			Release	Battery voltage	
	26		Operate (forward)	0	
			Release	Battery voltage	



Is the inspection result normal?

YES >> GO TO 5

NO >> GO TO 2

2. CHECK SLIDING SWITCH CIRCUIT

SLIDING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and power seat switch LH.
2. Check continuity between driver seat control unit harness connector and power seat switch LH harness connector.

Driver seat control unit connector	Terminal	Power seat switch LH connector	Terminal	Continuity
B202 (A)	11	B208 (B)	1	Yes
	26		5	

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal	Ground	Continuity
B202 (A)	11		No
	26		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK DRIVER SEAT CONTROL UNIT OUTPUT

1. Connect the driver seat control unit.
2. Turn ignition switch ON.
3. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminals		Voltage (V) (Approx.)
	(+)	(-)	
B202	11	Ground	Battery voltage
	26		

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace driver seat control unit. Refer to [SE-30, "Removal and Installation For Front Seat"](#).

4. CHECK SLIDING SWITCH

Refer to [ADP-51, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace power seat switch LH. Refer to [SE-44, "Disassembly and Assembly"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?


YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning part.

Component Inspection

INFOID:0000000006163494

1. CHECK SLIDING SWITCH




SLIDING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect power seat switch LH.
3. Check continuity between power seat switch LH terminals.

Terminal	Condition		Continuity
Power seat switch LH			
7	1	Sliding switch (backward)	Operate Yes Release No
	5	Sliding switch (forward)	Operate Yes Release No



Is the inspection result normal?

YES >> Inspection End.

NO >> Replace power seat switch LH. Refer to [SE-44, "Disassembly and Assembly"](#).

RECLINING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

RECLINING SWITCH

Description

INFOID:0000000006163495

Reclining switch is equipped to the power seat switch LH on the seat cushion trim cover. The operation signal is input to the driver seat control unit when the reclining switch is operated.

Component Function Check

INFOID:0000000006163496

1. CHECK FUNCTION

1. Select "RECLN SW-FR", "RECLN SW-RR" in "Data monitor" mode with CONSULT-III.
2. Check reclining switch signal under the following conditions.

Monitor item	Condition	Status
RECLN SW-FR	Reclining switch (forward)	Operate ON
		Release OFF
RECLN SW-RR	Reclining switch (backward)	Operate ON
		Release OFF

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-53, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163497

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK RECLINING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminals		Condition	Voltage (V) (Approx.)	
	(+)	(-)		Operate (backward)	0
B202	12	Ground	Reclining switch	Release	Battery voltage
	27			Operate (forward)	0
				Release	Battery voltage



Is the inspection result normal?

YES >> GO TO 5

NO >> GO TO 2

2. CHECK RECLINING SWITCH CIRCUIT

ADP

K

L

M

N

O

P

RECLINING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and power seat switch LH.
2. Check continuity between driver seat control unit harness connector and power seat switch LH harness connector.

Driver seat control unit connector	Terminal	Power seat switch LH connector	Terminal	Continuity
B202 (A)	12	B208 (B)	3	Yes
	27		4	

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal	Ground	Continuity
B202 (A)	12		No
	27		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK DRIVER SEAT CONTROL UNIT OUTPUT

1. Connect the driver seat control unit.
2. Turn ignition switch OFF.
3. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminals		Voltage (V) (Approx.)
	(+)	(-)	
B202	12	Ground	Battery voltage
	27		

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

4. CHECK RECLINING SWITCH

Refer to [ADP-54, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace power seat switch LH. Refer to [SE-44, "Disassembly and Assembly"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?


YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

Component Inspection

INFOID:0000000006163498

1. CHECK RECLINING SWITCH




RECLINING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect power seat switch LH.
3. Check continuity between power seat switch LH terminals.

Terminals		Condition		Continuity
Power seat switch LH		7	Reclining switch (backward)	Operate Yes Release No
7	3		Reclining switch (forward)	Operate Yes Release No
	4			



Is the inspection result normal?

YES >> Inspection End.

NO >> Replace power seat switch LH. Refer to [SE-44, "Disassembly and Assembly"](#).

A
B
C
D
E
F
G
H
I

ADP

K
L
M
N
O
P

LIFTING SWITCH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SWITCH (FRONT)

Description

INFOID:0000000006163499

Lifting switch (front) is equipped to the power seat switch LH on the seat cushion trim cover. The operation signal is input to the driver seat control unit when the lifting switch (front) is operated.

Component Function Check

INFOID:0000000006163500

1. CHECK FUNCTION

1. Select "LIFT FR SW-UP", "LIFT FR SW-DN" in "DATA MONITOR" mode with CONSULT-III.
2. Check lifting switch (front) signal under the following conditions.

Monitor item	Condition	Status	
LIFT FR SW-UP	Lifting switch front (up)	Operate	ON
		Release	OFF
LIFT FR SW-DN	Lifting switch front (down)	Operate	ON
		Release	OFF

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-56, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163501

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK LIFTING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminals		Condition	Voltage (V) (Approx.)	
	(+)	(-)		Operate (down)	0V
B202	13	Ground	Lifting switch (front)	Release	Battery voltage
	28			Operate (up)	0V
				Release	Battery voltage



Is the inspection result normal?

YES >> GO TO 5

NO >> GO TO 2

2. CHECK LIFTING SWITCH (FRONT) CIRCUIT

LIFTING SWITCH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and power seat switch LH.
2. Check continuity between driver seat control unit harness connector and power seat switch LH harness connector.

Driver seat control unit connector	Terminal	Power seat switch LH connector	Terminal	Continuity
B202 (A)	13	B208 (B)	9	Yes
	28		10	

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal	Ground	Continuity
B202 (A)	13		No
	28		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK DRIVER SEAT CONTROL UNIT OUTPUT

1. Connect the driver seat control unit.
2. Turn ignition switch OFF.
3. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminals		Voltage (V) (Approx.)
	(+)	(-)	
B202	13	Ground	Battery voltage
	28		

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

4. CHECK LIFTING SWITCH (FRONT)

Refer to [ADP-57, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace power seat switch LH. Refer to [SE-44, "Disassembly and Assembly"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?


YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

Component Inspection

INFOID:0000000006163502

1. CHECK LIFTING SWITCH (FRONT)




LIFTING SWITCH (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect power seat switch LH.
3. Check continuity between power seat switch LH terminals.

Terminal	Condition		Continuity
Power seat switch LH			
7	9	Lifting switch front (down)	Operate Yes Release No
	10	Lifting switch front (up)	Operate Yes Release No



Is the inspection result normal?

YES >> Inspection End.

NO >> Replace power seat switch LH. Refer to [SE-44, "Disassembly and Assembly"](#).

LIFTING SWITCH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SWITCH (REAR)

Description

INFOID:0000000006163503

Lifting switch (rear) is equipped to the power seat switch LH on the seat cushion trim cover. The operation signal is inputted to the driver seat control unit when the lifting switch (rear) is operated.

Component Function Check

INFOID:0000000006163504

1. CHECK FUNCTION

1. Select "LIFT RR SW-UP", "LIFT RR SW-DN" in "Data monitor" mode with CONSULT-III.
2. Check lifting switch (rear) signal under the following conditions.

Monitor item	Condition	Status
LIFT RR SW-UP	Lifting switch rear (up)	Operate
		Release
LIFT RR SW-DN	Lifting switch rear (down)	Operate
		Release

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-59, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163505

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK LIFTING SWITCH (REAR) SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminals		Condition	Voltage (V) (Approx.)
	(+)	(-)		
B202	14	Ground	Operate (down)	0
			Release	Battery voltage
	29		Operate (up)	0
			Release	Battery voltage



Is the inspection result normal?

YES >> GO TO 5

NO >> GO TO 2

2. CHECK LIFTING SWITCH (REAR) CIRCUIT

LIFTING SWITCH (REAR)

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and power seat switch LH.
2. Check continuity between driver seat control unit harness connector and power seat switch LH harness connector.

Driver seat control unit connector	Terminal	Power seat switch LH connector	Terminal	Continuity
B202 (A)	14	B208 (B)	2	Yes
	29		6	

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal	Ground	Continuity
B202 (A)	14		No
	29		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK DRIVER SEAT CONTROL UNIT OUTPUT

1. Connect the driver seat control unit.
2. Turn ignition switch OFF.
3. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminals		Voltage (V) (Approx.)
	(+)	(-)	
B202	14	Ground	Battery voltage
	29		

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

4. CHECK LIFTING SWITCH (REAR)

Refer to [ADP-60, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace power seat switch LH. Refer to [SE-44, "Disassembly and Assembly"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?


YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

Component Inspection

INFOID:0000000006163506

1. CHECK LIFTING SWITCH (REAR)



LIFTING SWITCH (REAR)

< DTC/CIRCUIT DIAGNOSIS >


1. Turn ignition switch OFF.
2. Disconnect power seat switch LH.
3. Check continuity between power seat switch LH terminals.

Terminal	Condition		Continuity
Power seat switch LH			
7	2	Lifting switch rear (down)	Operate Yes
		Release	No
	6	Lifting switch rear (up)	Operate Yes
		Release	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace power seat switch LH. Refer to [SE-44, "Disassembly and Assembly".](#)



PEDAL ADJUSTING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

PEDAL ADJUSTING SWITCH

Description

INFOID:0000000006163507

Pedal adjusting switch is on the instrument panel. The operation signal is input to the driver seat control unit when the pedal adjusting switch is operated. The pedal adjusting switch signal is sent to the automatic drive positioner control unit via UART communication.

Component Function Check

INFOID:0000000006163508

1. CHECK FUNCTION

1. Select "PEDAL SW-FR", "PEDAL SW-RR" in "Data monitor" mode with CONSULT-III.
2. Check pedal adjusting switch signal under the following conditions.

Monitor item	Condition	Status
PEDAL SW-FR	Pedal adjusting switch (forward)	Operate
		Release
PEDAL SW-RR	Pedal adjusting switch (backward)	Operate
		Release

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-62, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163509

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK PEDAL ADJUSTING SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminals		Condition	Voltage (V) (Approx.)	
	(+)	(-)		Operate (forward)	0
B202	15	Ground	Pedal adjusting switch	Release	Battery voltage
	30			Operate (backward)	0
				Release	Battery voltage



Is the inspection result normal?

YES >> GO TO 5

NO >> GO TO 2

2. CHECK PEDAL ADJUSTING SWITCH CIRCUIT


PEDAL ADJUSTING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and pedal adjusting switch.
2. Check continuity between driver seat control unit harness connector and pedal adjusting switch harness connector.

Driver seat control unit connector	Terminal	Pedal adjusting switch connector	Terminal	Continuity
B202	15	M96	2	Yes
	30		3	

3. Check continuity between driver seat control unit harness connector and ground.



Driver seat control unit connector	Terminal	Ground	Continuity
B202	15		No
	30		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK DRIVER SEAT CONTROL UNIT OUTPUT


1. Connect the driver seat control unit.
2. Turn ignition switch OFF.
3. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminals		Voltage (V) (Approx.)
	(+)	(-)	
B202	15	Ground	Battery voltage
	30		

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).



4. CHECK PEDAL ADJUSTING SWITCH

Refer to [ADP-64, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace pedal adjusting switch. Refer to [IP-11, "Exploded View"](#).

5. CHECK PEDAL ADJUSTING SWITCH GROUND CIRCUIT

Check continuity between pedal adjusting switch connector M96 terminal 1 and ground.


1 - Ground

: Continuity should exist.

Is the inspection result normal?

YES >> GO TO 6

NO >> Repair or replace harness.



6. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

PEDAL ADJUSTING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).
NO >> Repair or replace the malfunctioning part.


Component Inspection

INFOID:000000006163510

1. CHECK PEDAL ADJUSTING SWITCH

1. Turn ignition switch OFF.
2. Disconnect pedal adjusting switch.
3. Check continuity between pedal adjusting switch terminals.

Terminal		Condition	Continuity	
Pedal adjusting switch			Operate	Yes
1	2	Pedal adjusting switch (backward)	Operate	Yes
			Release	No
	3	Pedal adjusting switch (forward)	Operate	Yes
			Release	No



Is the inspection result normal?

YES >> Inspection End.
NO >> Replace pedal adjusting switch. Refer to [IP-11, "Exploded View"](#).

SEAT MEMORY SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SEAT MEMORY SWITCH

Description

INFOID:000000006163511

The seat memory switch is installed on the front door LH trim. The operation signal is input to the automatic drive positioner control unit when the memory switch is operated.

Component Function Check

INFOID:000000006163512

1. CHECK FUNCTION

1. Select "MEMORY SW 1", "MEMORY SW 2", "SET SW" in "Data monitor" mode with CONSULT-III.
2. Check seat memory switch signal under the following conditions.

Monitor item	Condition	Status
MEMORY SW1	Memory switch 1	Push
		Release
MEMORY SW2	Memory switch 2	Push
		Release
SET SW	Set switch	Push
		Release

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-65, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:000000006163513

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK MEMORY SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and seat memory switch.
3. Check continuity between automatic drive positioner control unit harness connector and seat memory switch harness connector.

Automatic drive positioner control unit connector	Terminal	Seat memory switch connector	Terminal	Continuity
M33	9	D5	1	Yes
	24		3	
	25		2	



4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M33	9		No
	24		
	25		

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace harness.

SEAT MEMORY SWITCH

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK MEMORY SWITCH GROUND CIRCUIT

Check continuity between seat memory switch harness connector and ground.

Seat memory switch connector	Terminal	Ground	Continuity
D5	4		Yes


Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.



Seat memory switch connector



PIIA4821E

3. CHECK SEAT MEMORY SWITCH

Refer to [ADP-66, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace seat memory switch. Refer to [ADP-150, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.


Component Inspection

INFOID:000000006163514

1. CHECK SEAT MEMORY SWITCH

1. Turn ignition switch OFF.
2. Disconnect seat memory switch.
3. Check continuity between seat memory switch terminals.

Terminal	Condition		Continuity	
Seat memory switch	1	Memory switch 1	Push	Yes
4	1	Memory switch 1	Release	No
			Push	Yes
	2	Memory switch 2	Release	No
			Push	Yes
	3	Set switch	Push	Yes
			Release	No



LIIA1020E

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace seat memory switch. Refer to [ADP-150, "Removal and Installation"](#).

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR REMOTE CONTROL SWITCH CHANGEOVER SWITCH

CHANGEOVER SWITCH : Description

INFOID:0000000006163515

Changover switch is integrated into door mirror remote control switch.

Changover switch has three positions (L, N and R).

It changes door mirror motor operation by transmitting control signal to automatic drive positioner control unit.

CHANGEOVER SWITCH : Component Function Check

INFOID:0000000006163516

1. CHECK CHANGEOVER SWITCH FUNCTION

Check the operation on "MIR CHNG SW-R" or "MIR CHNG SW-L" in "DATA MONITOR" mode with CONSULT-III.

Refer to [ADP-26, "CONSULT-III Function"](#).

Is the inspection result normal?

YES >> Changover switch function is OK.

NO >> Refer to [ADP-67, "CHANGEOVER SWITCH : Diagnosis Procedure"](#).

CHANGEOVER SWITCH : Diagnosis Procedure


INFOID:0000000006163517

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK CHANGEOVER SWITCH SIGNAL

1. Turn ignition switch to ACC.
2. Check voltage between automatic drive positioner control unit connector and ground.

Terminals		Change over switch condition	Voltage (V) (Approx.)	
(+)	(-)			
Automatic drive positioner control unit connector	Terminal	Ground	RIGHT	
			0	
	18		Other than above	
			5	
M33	2		LEFT	
			0	
	18		Other than above	
			5	



Is the inspection result normal?


YES >> GO TO 6

NO >> GO TO 2

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and door mirror remote control switch.
3. Check continuity between automatic drive positioner control unit connector and door mirror remote control switch connector.

Automatic drive positioner control unit connector	Terminal	Door mirror remote control switch connector	Terminal	Continuity
M33 (A)	2	D10 (B)	11	Yes
	18		10	



DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between automatic drive positioner control unit connector and ground.

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M33 (A)	2		
	18		No

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT


Check continuity between door mirror remote control switch connector and ground.

Door mirror remote control switch connector	Terminal	Ground	Continuity
D10	7		Yes

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.



4. CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT OUTPUT SIGNAL

1. Connect automatic drive positioner control unit.
2. Turn ignition switch to ACC.
3. Check voltage between automatic drive positioner control unit connector and ground.

Terminals		(-)	Voltage (V) (Approx.)
(+)	Terminal		
Automatic drive positioner control unit connector	2	Ground	5
	18		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

5. CHECK CHANGEOVER SWITCH

Check changeover switch.

Refer to [ADP-69, "CHANGEOVER SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace door mirror remote control switch. Refer to [ADP-151, "Removal and Installation"](#).

6. CHECK INTERMITTENT INCIDENT


Check intermittent incident.

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning parts.



DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

CHANGEOVER SWITCH : Component Inspection

INFOID:000000006163518

1. CHECK CHANGEOVER SWITCH

Check door mirror remote control switch.

Terminal		Change over switch condition	Continuity
Door mirror remote control switch			
10	7	LEFT	Yes
		Other than above	No
11	7	RIGHT	Yes
		Other than above	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace door mirror remote control switch. Refer to [ADP-151, "Removal and Installation".](#)

MIRROR SWITCH

MIRROR SWITCH : Description

INFOID:000000006163519

It operates angle of the door mirror face.

It transmits mirror face adjust operation to automatic drive positioner control unit.

MIRROR SWITCH : Component Function Check

INFOID:000000006163520

1. CHECK MIRROR SWITCH FUNCTION

Check the operation on "MIR CON SW-UP/DN" and "MIR CON SW-RH/LH" in "DATA MONITOR" mode with CONSULT-III.

Refer to [ADP-26, "CONSULT-III Function".](#)

Is the inspection result normal?

YES >> Mirror switch function is OK.

NO >> Refer to [ADP-69, "MIRROR SWITCH : Diagnosis Procedure".](#)


MIRROR SWITCH : Diagnosis Procedure

INFOID:000000006163521


Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram".](#)

1. CHECK MIRROR SWITCH FUNCTION

1. Turn ignition switch to ACC.
2. Check voltage between automatic drive positioner control unit connector and ground.



ADP



DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Terminals		(-)	Mirror switch Condition	Voltage (V) (Approx.)
(+)	Terminal			
Automatic drive positioner control unit connector	M33	Ground	UP	0
			Other than above	5
			LEFT	0
			Other than above	5
			DOWN	0
			Other than above	5
			RIGHT	0
			Other than above	5


Is the inspection result normal?

YES >> GO TO 6
NO >> GO TO 2

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and door mirror remote control switch.
3. Check continuity between automatic drive positioner control unit connector and door mirror remote control switch connector.

Automatic drive positioner control unit connector	Terminal	Door mirror remote control switch connector	Terminal	Continuity
M33 (A)	3	D10 (B)	15	Yes
	4		13	
	19		12	
	20		4	



4. Check continuity between automatic drive positioner control unit connector and ground.

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M33 (A)	3		No
	4		
	19		
	20		

Is the inspection result normal?

YES >> GO TO 3
NO >> Repair or replace harness.

3. CHECK DOOR MIRROR REMOTE CONTROL SWITCH GROUND CIRCUIT

DOOR MIRROR REMOTE CONTROL SWITCH


< DTC/CIRCUIT DIAGNOSIS >

Check continuity between door mirror remote control switch connector and ground.

Door mirror remote control switch connector	Terminal	Ground	Continuity
D10	7		Yes

Is the inspection result normal?

YES >> GO TO 4
NO >> Repair or replace harness.



4. CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT OUTPUT SIGNAL

1. Connect automatic drive positioner control unit.
2. Turn ignition switch to ACC.
3. Check voltage between automatic drive positioner control unit and ground.

Terminals		(-)	Voltage (V) (Approx.)
(+)	Terminal		
Automatic drive positioner control unit connector M33	3	Ground	5
	4		
	19		
	20		

Is the inspection result normal?

YES >> GO TO 5
NO >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

5. CHECK MIRROR SWITCH

Check mirror switch.

Refer to [ADP-71, "MIRROR SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Refer to [GI-39, "Intermittent Incident"](#).
NO >> Replace door mirror remote control switch. Refer to [ADP-151, "Removal and Installation"](#).

6. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).
NO >> Repair or replace the malfunctioning parts.

MIRROR SWITCH : Component Inspection

INFOID:000000006163522

1. CHECK MIRROR SWITCH

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O


P

DOOR MIRROR REMOTE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Check door mirror remote control switch.

Terminal	Mirror switch condition	Continuity
Door mirror remote control switch		
4	RIGHT	Yes
	Other than above	No
13	LEFT	Yes
	Other than above	No
15	UP	Yes
	Other than above	No
12	DOWN	Yes
	Other than above	No



Is the inspection result normal?

YES >> Inspection End.

NO >> Replace door mirror remote control switch. Refer to [ADP-151, "Removal and Installation"](#).

POWER SEAT SWITCH GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SEAT SWITCH GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000006163523

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK POWER SEAT SWITCH LH GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect power seat switch LH.
3. Check continuity between power seat switch LH connector and ground.

Power seat switch LH connector	Terminal	Ground	Continuity
B208	7		Yes

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Repair or replace harness.



PARK POSITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

PARK POSITION SWITCH

Description

INFOID:0000000006163524

The park position switch is installed on the A/T shift selector. It is turned OFF when the A/T selector lever is in P position. The driver seat control unit judges that the A/T shift selector is in P position if continuity does not exist in this circuit.

Component Function Check

INFOID:0000000006163525

1. CHECK FUNCTION

1. Select "DETENT SW" signal in "Data monitor" mode with CONSULT-III.
2. Check park position switch (key lock) signal under the following conditions.

Monitor item	Condition	Status
DETENT SW	A/T shift selector	P position
		Other than above

Is the indication normal?

YES >> Inspection End.
NO >> Perform diagnosis procedure. Refer to [ADP-75, "Diagnosis Procedure \(Column Shift\)"](#) or [ADP-74, "Diagnosis Procedure \(Floor Shift\)"](#).

Diagnosis Procedure (Floor Shift)

INFOID:0000000006163526

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK DTC WITH "BCM"

Check "Self Diagnostic Result" for BCM with CONSULT-III.

Is any DTC detected?

YES >> Check the DTC.
NO >> GO TO 2

2. CHECK A/T SHIFT SELECTOR [PARK POSITION SWITCH (KEY LOCK)] INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit.
3. Mechanical key must be inserted into the key switch and key lock solenoid.
4. Check voltage between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal		Condition	Voltage (V) (Approx.)	
	(+)	(-)		P position	0
B202	21	Ground	A/T shift selector	Other than above	Battery voltage

Is the inspection result normal?

YES >> GO TO 4
NO >> GO TO 3

3. CHECK A/T SHIFT SELECTOR [PARK POSITION SWITCH (KEY LOCK)] CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect driver seat control unit and A/T shift selector.
3. Check continuity between driver seat control unit harness connector and A/T shift selector harness connector.

PARK POSITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Connector	Terminal	Connector	Terminal	Continuity
B202	21	M203 (King Cab) M204 (Crew Cab)	6	Yes

4. Check continuity between driver seat control unit harness connector and ground.

Connector	Terminal	Ground	Continuity
B202	21		No

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

Diagnosis Procedure (Column Shift)

INFOID:0000000006163527

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK DTC WITH "BCM"

Check "Self Diagnostic Result" for BCM with CONSULT-III.

Is any DTC detected?

YES >> Check the DTC.

NO >> GO TO 2

2. CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH) INPUT SIGNAL

1. Turn ignition switch OFF.

2. Disconnect driver seat control unit.

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal		Condition		Continuity
B202	21	Ground	A/T shift selector	P position	No
				Other than above	Yes

Is the inspection result normal?

YES >> GO TO 5

NO >> GO TO 3

3. CHECK A/T SHIFT SELECTOR [PARK POSITION SWITCH (KEY LOCK)] CIRCUIT

1. Turn ignition switch OFF.

2. Disconnect A/T shift selector.

3. Check continuity between driver seat control unit harness connector and A/T shift selector harness connector.

Connector	Terminal	Connector	Terminal	Continuity
B202	21	M68	8	Yes

PARK POSITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between A/T shift selector harness connector and ground.

Connector	Terminal	Ground	Continuity
M68	1		Yes

5. Check continuity between A/T shift selector harness connector and ground.

Connector	Terminal	Ground	Continuity
M68	8		No

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

4. CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH)

Check continuity between A/T shift selector (park position switch) terminals as follows.

Terminals		Condition	Continuity
8	1	P position	No
		Other than P position	Yes

Is the inspection result normal?

YES >> GO TO 5

NO >> Replace A/T shift selector. Refer to [TM-185, "A/T Shift Selector Removal and Installation"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

FRONT DOOR SWITCH (DRIVER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

FRONT DOOR SWITCH (DRIVER SIDE)

Description

INFOID:0000000006163528

Detects front door LH open/close condition.

Component Function Check

INFOID:0000000006163529

1. CHECK FUNCTION

1. Select "DOOR SW-DR" in "Data monitor" mode with CONSULT-III.
2. Check the front door switch LH signal under the following conditions.

Monitor item	Condition		Status
DOOR SW-DR	Front door switch LH	Open	ON
		Close	OFF

Is the inspection result normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-77, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000006163530

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK FRONT DOOR SWITCH LH CIRCUIT

1. Disconnect BCM and front door switch LH.
2. Check continuity between BCM connector and front door switch LH connector.

BCM connector	Terminal	Front door switch LH connector	Terminal	Continuity
M19	47	B8	2	Yes

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
M19	47		No

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace harness.

2. CHECK FRONT DOOR SWITCH LH

Refer to [ADP-78, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3

NO >> Replace front door switch LH.


3. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-53, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.



FRONT DOOR SWITCH (DRIVER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

Component Inspection

INFOID:000000006163531


1. CHECK FRONT DOOR SWITCH LH

1. Turn ignition switch OFF.
2. Disconnect front door switch LH.
3. Check continuity between front door switch LH terminals.

Terminal	Condition		Continuity	
Front door switch LH			Pushed	No
2	Ground part of door switch	Front door switch LH	Released	Yes

Is the inspection result normal?

YES >> Inspection End.
NO >> Replace front door switch LH.



SLIDING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING SENSOR

Description

INFOID:0000000006163532

- The sliding sensor is installed to the power seat frame assembly.
- The pulse signal is input to the driver seat control unit when sliding is performed.
- The driver seat control unit counts the pulse and calculates the sliding amount of the seat.

Component Function Check

INFOID:0000000006163533

1. CHECK FUNCTION

1. Select "SLIDE PULSE" in "Data monitor" mode with CONSULT-III.
2. Check sliding sensor signal under the following conditions.

Monitor item	Condition	Value
SLIDE PULSE	Seat sliding	Operate (forward) Change (increase)
		Operate (backward) Change (decrease)
		Release No change

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-79, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163534

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK SLIDING SENSOR SIGNAL

1. Turn ignition switch OFF.
2. Read voltage signal between driver seat control unit harness connector and ground with oscilloscope.

Terminals		Condition	Voltage signal	
(+)	(-)			
Driver's seat control unit	Terminal	Seat sliding	Operate	Other than above
B202	24	Ground	6 4 2 0 50 ms	0 or 5



Is the inspection result normal?

YES >> GO TO 4

NO >> GO TO 2

2. CHECK SLIDING SENSOR CIRCUITS


SLIDING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and sliding motor LH.
2. Check continuity between driver seat control unit harness connector and sliding motor LH harness connector.

Driver seat control unit connector	Terminal	Sliding motor LH connector	Terminal	Continuity
B202 (A)	16	B204 (B)	3	Yes
	24		4	
	31		2	

3. Check continuity between driver seat control unit harness connector and ground.



Driver seat control unit connector	Terminal	Ground	Continuity
B202 (A)	16	Ground	No
	24		
	31		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK SEAT OPERATION

1. Connect driver seat control unit and sliding motor LH.
2. Check seat operation (except sliding operation) with memory function.

Is the inspection result normal?

YES >> Replace sliding motor LH. (Built in power seat frame assembly). Refer to [SE-44, "Disassembly and Assembly"](#).

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

< DTC/CIRCUIT DIAGNOSIS >

RECLINING SENSOR**Description**

INFOID:0000000006163535

- The reclining motor is installed to the seatback assembly.
- The pulse signal is inputted to the driver seat control unit when the reclining is operated.
- The driver seat control unit counts the pulse and calculates the reclining amount of the seat.

Component Function Check

INFOID:0000000006163536

1. CHECK FUNCTION

1. Select "RECLN PULSE" in "Data monitor" mode with CONSULT-III.
2. Check reclining sensor signal under the following conditions.

Monitor item	Condition	Value
RECLN PULSE	Seat reclining	Operate (forward) Change (increase)
		Operate (backward) Change (decrease)
		Release No change

Is the indication normal?


YES >> Inspection End.


NO >> Perform diagnosis procedure. Refer to [ADP-81, "Diagnosis Procedure"](#).**Diagnosis Procedure**

INFOID:0000000006163537

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).**1. CHECK RECLINING SENSOR SIGNAL**

1. Turn ignition switch OFF.
2. Read voltage signal between driver seat control unit harness connector and ground with oscilloscope.

Terminals		Condition	Voltage signal	
(+)	(-)			
Driver seat control unit	Terminal	Seat reclining	Operate	Other than above
B202	9	Ground	<p>(V)</p>  <p>50ms</p>	0 or 5

Is the inspection result normal?

YES >> GO TO 4

NO >> GO TO 2

2. CHECK RECLINING SENSOR CIRCUIT

RECLINING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and reclining motor LH.
2. Check continuity between driver seat control unit harness connector and reclining motor LH harness connector.

Driver seat control unit connector	Terminal	Reclining motor connector	Terminal	Continuity
B202 (A)	9	B205 (B)	1	Yes
	31		4	

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal	Ground	Continuity
B202 (A)	9		No
	31		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK SEAT OPERATION

1. Connect driver seat control unit and reclining motor LH connector.
2. Check seat operation (except reclining operation) with memory function.

Is the operation normal?

YES >> Replace reclining motor LH. (Built in power seat frame assembly). Refer to [SE-44, "Disassembly and Assembly".](#)

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation".](#)


4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident".](#)

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation".](#)

NO >> Repair or replace the malfunctioning part.



LIFTING SENSOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SENSOR (FRONT)

Description

INFOID:0000000006163538

- The lifting sensor (front) is installed to the power seat frame assembly.
- The pulse signal is input to the driver seat control unit when the lifting (front) is operated.
- The driver seat control unit counts the pulse and calculates the lifting (front) amount of the seat.

Component Function Check

INFOID:0000000006163539

1. CHECK FUNCTION

1. Select "LIFT FR PULSE" in "Data monitor" mode with CONSULT-III.
2. Check the lifting sensor (front) signal under the following conditions.

Monitor item	Condition	Value
LIFT FR PULSE	Seat lifting (front)	Operate (up)
		Change (increase)
		Operate (down)
		Change (decrease)
		Release
		No change

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-83, "Diagnosis Procedure"](#).


Diagnosis Procedure


INFOID:0000000006163540

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK LIFTING SENSOR (FRONT) SIGNAL

1. Turn ignition switch OFF.
2. Read the voltage signal between driver seat control unit harness connector and ground with an oscilloscope.

Terminals		Condition	Voltage signal	
(+)	(-)			
Driver seat control unit connector	Terminal	Seat lifting (front)	Operate	Other than above
B202	25	Ground		0 or 5



Is the inspection result normal?

YES >> GO TO 4

NO >> GO TO 2

2. CHECK LIFTING SENSOR (FRONT) CIRCUIT


LIFTING SENSOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and lifting motor (front).
2. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

Driver seat control unit connector	Terminal	Lifting motor (front) connector	Terminal	Continuity
B202 (A)	16	B206 (B)	3	Yes
	25		4	
	31		2	

3. Check continuity between driver seat control unit harness connector and ground.



Driver seat control unit connector	Terminal	Ground	Continuity
B202 (A)	16		No
	25		
	31		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK SEAT OPERATION

1. Connect driver seat control unit and lifting motor (front) connector.
2. Check seat operation [except lifting (front) operation] with memory function.

Is the operation normal?

YES >> Replace lifting motor (front). (Built in power seat frame assembly). Refer to [SE-44, "Disassembly and Assembly"](#).

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

LIFTING SENSOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING SENSOR (REAR)

Description

INFOID:0000000006163541

- The lifting sensor (rear) is installed to the power seat frame assembly.
- The pulse signal is input to the driver seat control unit when the lifting (rear) is operated.
- The driver seat control unit counts the pulse and calculates the lifting (rear) amount of the seat.

Component Function Check

INFOID:0000000006163542

1. CHECK FUNCTION

1. Select "LIFT RR PULSE" in "Data monitor" mode with CONSULT-III.
2. Check lifting sensor (rear) signal under the following conditions.

Monitor item	Condition	Value
LIFT RR PULSE	Seat lifting (rear)	Operate (up)
		Change (increase)
		Operate (down)
		Change (decrease)
		Release
		No change

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-85, "Diagnosis Procedure"](#).


Diagnosis Procedure


INFOID:0000000006163543

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK LIFTING SENSOR (REAR) SIGNAL

1. Turn ignition switch OFF.
2. Read voltage signal between driver seat control unit harness connector and ground with oscilloscope.

Terminals		Condition	Voltage signal	
(+)	(-)		Operate	Other than above
Driver seat control unit connector	B202	Seat lifting (rear)	Operate	 SIIA0693J
			Other than above	0 or 5



Is the inspection result normal?

YES >> GO TO 4

NO >> GO TO 2

2. CHECK LIFTING SENSOR (REAR) CIRCUIT

ADP

K

L

M

N

O

P

LIFTING SENSOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and lifting motor (rear).
2. Check the continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

Driver seat control unit connector	Terminal	Lifting motor (rear) connector	Terminal	Continuity
B202 (A)	10	B207 (B)	4	Yes
	16		3	
	31		2	

3. Check the continuity between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal	Ground	Continuity
B202 (A)	10		No
	16		
	31		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK SEAT OPERATION

1. Connect driver seat control unit and lifting motor (rear) connector.
2. Check the seat operation [except lifting (rear) operation] with memory function.

Is the operation normal?

YES >> Replace lifting motor (rear). (Built in power seat frame assembly). Refer to [SE-44, "Disassembly and Assembly".](#)

NO >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation".](#)


4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident".](#)

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation".](#)

NO >> Repair or replace the malfunctioning part.



PEDAL ADJUSTING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

PEDAL ADJUSTING SENSOR

Description

INFOID:0000000006163544

- The pedal adjusting sensor is installed to the pedal adjusting motor assembly.
- The resistance of pedal adjusting sensor is changed according to the forward/backward position of pedal assembly.
- The terminal voltage of automatic drive positioner control unit will be changed according to a change of pedal adjusting sensor resistance. Automatic drive positioner control unit calculates the pedal assembly position from the voltage.

Component Function Check

INFOID:0000000006163545

1. CHECK FUNCTION

1. Select "PEDAL SEN" in "Data monitor" mode with CONSULT-III.
2. Check the pedal sensor signal under the following condition.

Monitor item	Condition	Value
PEDAL SEN	Forward	0.5V
	Backward	4.5V

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-87, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163546

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK PEDAL ADJUSTING SENSOR SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between automatic drive positioner control unit harness connector and ground.

Terminal		Condition	Voltage (V) (Approx.)
(+)	(-)		
Automatic drive positioner control unit	Terminal	Pedal assembly position	Forward
			Backward



Is the inspection result normal?

YES >> GO TO 4

NO >> GO TO 2

2. CHECK PEDAL ADJUSTING SENSOR CIRCUIT

ADP

K

L

M

N

O

P

PEDAL ADJUSTING SENSOR

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect automatic drive positioner control unit and pedal adjusting motor assembly.
2. Check continuity between automatic drive positioner control unit harness connector and pedal adjusting motor assembly harness connector.

Automatic drive positioner control unit connector	Terminal	Pedal adjusting motor assembly connector	Terminal	Continuity
M33 (A)	8	E110 (B)	4	Yes
M34 (C)	33		3	
	41		5	

3. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M33 (A)	8		No
M34 (C)	33		
	41		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK DOOR MIRROR OPERATION

1. Connect automatic drive positioner control unit and pedal adjusting motor assembly.
2. Turn ignition switch ON.
3. Check door mirror operation with memory function.

Is the operation normal?

YES >> Replace pedal adjusting motor assembly. Refer to [ADP-152, "Removal and Installation"](#).

NO >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).


4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.



< DTC/CIRCUIT DIAGNOSIS >

MIRROR SENSOR

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000006163547

- The mirror sensor LH is installed to the door mirror LH.
- The resistance of 2 sensors (horizontal and vertical) is changed when the door mirror LH is operated.
- Automatic drive positioner control unit calculates the door mirror position according to the change of the voltage of 2 sensor input terminals.

DRIVER SIDE : Component Function Check

INFOID:000000006163548

1. CHECK FUNCTION

1. Select "MIR/SEN LH U-D", "MIR/SEN LH R-L" in "Data monitor" with CONSULT-III.
2. Check mirror sensor (driver side) signal under the following condition.

Monitor item	Condition	Value
MIR/SEN LH U-D	Close to peak	3.4V
	Close to valley	0.6V
	Close to right edge	3.4V
	Close to left edge	0.6V
MIR/SEN LH R-L		

Is the indication normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-89, "DRIVER SIDE : Diagnosis Procedure".](#)

DRIVER SIDE : Diagnosis Procedure

INFOID:000000006163549


Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram".](#)

ADP

1. CHECK DOOR MIRROR LH SENSOR SIGNAL

1. Turn ignition switch to ACC.
2. Check voltage between door mirror LH harness connector and ground.

Terminals		Condition	Voltage (V) (Approx.)
(+)	(-)		
Door mirror LH connector	D4	Door mirror LH	Close to peak
			3.4
			Close to valley
			0.6
Ground	7		Close to right edge
			3.4
Ground	8		Close to left edge
			0.6



Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 2.


2. CHECK DOOR MIRROR LH SENSOR CIRCUIT

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and door mirror LH connector.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror LH harness connector.

Automatic drive positioner control unit connector	Terminal	Door mirror LH connector	Terminal	Continuity
M33	6	D4	7	Yes
	22		8	



4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M33	6		No
	22		

Is the inspection result normal?


YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK DOOR MIRROR LH SENSOR CIRCUIT 2

1. Check continuity between automatic drive positioner control unit harness connector and door mirror LH harness connector.

Automatic drive positioner control unit connector	Terminal	Door mirror LH connector	Terminal	Continuity
M34	33	D4	5	Yes
	41		6	



2. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M34	33		No
	41		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK PEDAL ADJUSTING OPERATION

1. Connect driver seat control unit connector and door mirror LH connector.
2. Turn ignition switch ON.
3. Check pedal adjusting operation with memory function.

Is the operation normal?

YES >> Replace door mirror actuator LH. Refer to [MIR-18, "Mirror Actuator"](#).

NO >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:0000000006163550

- The mirror sensor RH is installed to the door mirror RH.
- The resistance of 2 sensors (horizontal and vertical) is changed when the door mirror RH is operated.
- Automatic drive positioner control unit calculates the door mirror position according to the change of the voltage of 2 sensor input terminals.

PASSENGER SIDE : Component Function Check

INFOID:0000000006163551

1. CHECK FUNCTION

1. Select "MIR/SEN RH U-D", "MIR/SEN RH R-L" in "Data monitor" with CONSULT-III.
2. Check the mirror sensor RH signal under the following conditions.

Monitor item	Condition	Value
MIR/SEN RH U-D	Close to peak	3.4V
	Close to valley	0.6V
	Close to right edge	3.4V
	Close to left edge	0.6V
MIR/SEN RH R-L		

Is the indication normal?

YES >> Inspection End.
NO >> Perform diagnosis procedure. Refer to [ADP-91, "PASSENGER SIDE : Diagnosis Procedure".](#)

PASSENGER SIDE : Diagnosis Procedure


INFOID:0000000006163552

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram".](#)

1. CHECK DOOR MIRROR RH SENSOR SIGNAL

1. Turn ignition switch to ACC.
2. Check voltage between door mirror RH harness connector and ground.

Terminals		Condition	Voltage (V) (Approx.)	
(+)	(-)			
Door mirror RH connector	D107	Door mirror RH	Close to peak	3.4
			Close to valley	0.6
			Close to right edge	3.4
			Close to left edge	0.6



Is the inspection result normal?

YES >> GO TO 5
NO >> GO TO 2


2. CHECK DOOR MIRROR RH SENSOR HARNESS CONTINUITY

MIRROR SENSOR

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and door mirror RH.
3. Check continuity between automatic drive positioner control unit harness connector and door mirror RH harness connector.

Automatic drive positioner control unit connector	Terminal	Door mirror RH connector	Terminal	Continuity
M33	5	D107	7	Yes
	21		8	



4. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M33	5		No
	21		

Is the inspection result normal?

YES >> GO TO 3


NO >> Repair or replace harness.

3.CHECK DOOR MIRROR RH SENSOR POWER SUPPLY CIRCUIT

1. Check continuity between automatic drive positioner control unit harness connector and door mirror RH harness connector.

Automatic drive positioner control unit connector	Terminal	Door mirror RH connector	Terminal	Continuity
M34	33	D107	5	Yes
	41		6	

2. Check continuity between automatic drive positioner control unit harness connector and ground.



Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M34	33		No
	41		

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace harness.

4.CHECK PEDAL ADJUSTING OPERATION

1. Connect driver seat control unit connector and door mirror RH connector.
2. Turn ignition switch ON.
3. Check pedal adjusting operation with memory function.

Is the operation normal?

YES >> Replace door mirror actuator. Refer to [MIR-18, "Mirror Actuator"](#).

NO >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING MOTOR

Description

INFOID:0000000006163553

- The sliding motor LH is installed to the power seat frame assembly.
- The sliding motor LH is installed with the driver seat control unit.
- The seat is slid forward/backward by changing the rotation direction of sliding motor LH.

Component Function Check

INFOID:0000000006163554

1. CHECK FUNCTION

1. Select "SEAT SLIDE" in "Active test" mode with CONSULT-III.
2. Check the sliding motor LH operation.

Test Item		Description	
SEAT SLIDE	OFF	Seat sliding	Stop
	FR		Forward
	RR		Backward

Is the operation of relevant parts normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-93, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163555

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK SLIDING MOTOR LH POWER SUPPLY

1. Turn the ignition switch OFF.
2. Perform "Active test" ("SEAT SLIDE") with CONSULT-III
3. Check voltage between driver seat control unit harness connector and ground.

Terminal		Test Item	Voltage (V) (Approx.)
(+)	(-)		
Driver seat control unit connector	Terminal	SEAT SLIDE	OFF 0
B203	35		FR (forward) Battery voltage
	Ground		RR (backward) 0
	42		OFF 0
			FR (forward) 0
			RR (backward) Battery voltage



Is the inspection result normal?

YES >> Replace sliding motor LH. (Built in power seat frame assembly). Refer to [SE-44, "Disassembly and Assembly"](#).

NO >> GO TO 2

2. CHECK SLIDING MOTOR LH CIRCUIT

SLIDING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and sliding motor LH.
2. Check continuity between driver seat control unit harness connector and sliding motor LH harness connector.

Driver seat control unit connector	Terminal	Sliding motor LH connector	Terminal	Continuity
B203 (A)	35	B204 (B)	5	Yes
	42		1	

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal	Ground	Continuity
B203 (A)	35		No
	42		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.


3. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.



RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

RECLINING MOTOR

Description

INFOID:0000000006163556

- The reclining motor LH is installed to the seatback assembly.
- The reclining motor LH is activated with the driver seat control unit.
- The seatback is reclined forward/backward by changing the rotation direction of reclining motor LH.

Component Function Check

INFOID:0000000006163557

1. CHECK FUNCTION

1. Select "SEAT RECLINING" in "Active test" mode with CONSULT-III.
2. Check the reclining motor LH operation.

Test Item		Description	
SEAT RECLINING	OFF	Seat reclining	Stop
	FR		Forward
	RR		Backward

Is the operation of relevant parts normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-95, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163558

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK RECLINING MOTOR LH POWER SUPPLY

1. Turn the ignition switch OFF.
2. Perform "Active test" ("SEAT RECLINING") with CONSULT-III
3. Check voltage between driver seat control unit harness connector and ground.

Terminal		Test Item	Voltage (V) (Approx.)		
(+)	(-)				
Driver seat control unit connector	Terminal				
B203	36	SEAT RECLINING	OFF	0	
			FR (forward)	Battery voltage	
			RR (backward)	0	
	44		OFF	0	
			FR (forward)	0	
			RR (backward)	Battery voltage	



Is the inspection result normal?

YES >> Replace reclining motor LH. (Built in seatback assembly). Refer to [SE-44, "Disassembly and Assembly"](#).

NO >> GO TO 2

2. CHECK RECLINING MOTOR LH CIRCUIT

RECLINING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit connector and reclining motor LH.
2. Check continuity between driver seat control unit harness connector and reclining motor harness connector.

Driver seat control unit connector	Terminal	Reclining motor LH connector	Terminal	Continuity
B203 (A)	36	B205 (B)	2	Yes
	44		3	

3. Check continuity between driver seat control unit harness connector and ground.

Driver seat control unit connector	Terminal	Ground	Continuity
B203 (A)	36		No
	44		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.


3. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.



LIFTING MOTOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING MOTOR (FRONT)

Description

INFOID:0000000006163559

- The lifting motor (front) is installed to the power seat frame assembly.
- The lifting motor (front) is activated with the driver seat control unit.
- The lifter (front) is moved upward/downward by changing the rotation direction of lifting motor (front).

Component Function Check

INFOID:0000000006163560

1. CHECK FUNCTION

1. Select "SEAT LIFTER FR" in "Active test" mode with CONSULT-III.
2. Check the lifting motor (front) operation.

Test Item		Description	
SEAT LIFTER FR	OFF	Seat lifting (front)	Stop
	UP		Upward
	DWN		Downward

Is the operation of relevant parts normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-97, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163561

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK LIFTING MOTOR (FRONT) POWER SUPPLY

1. Turn the ignition switch OFF.
2. Perform "Active test" ("SEAT LIFTER FR") with CONSULT-III.
3. Check voltage between driver seat control unit harness connector and ground.

Terminal		Test Item	Voltage (V) (Approx.)	
(+)	(-)		OFF	0
Driver seat control unit connector	B203	SEAT LIFTER FR	UP	0
			DWN (down)	Battery voltage
			OFF	0
			UP	Battery voltage
			DWN (down)	0



Is the inspection result normal?

YES >> Replace lifting motor (front). (Built in power seat frame assembly). Refer to [SE-44, "Disassembly and Assembly"](#).

NO >> GO TO 2

2. CHECK LIFTING MOTOR (FRONT) CIRCUIT


LIFTING MOTOR (FRONT)

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and lifting motor (front) connectors.
2. Check continuity between driver seat control unit harness connector and lifting motor (front) harness connector.

Driver seat control unit connector	Terminal	Lifting motor (front) connector	Terminal	Continuity
B203 (A)	37	B206 (B)	1	Yes
	45		5	

3. Check continuity between driver seat control unit harness connector and ground.



Driver seat control unit connector	Terminal	Ground	Continuity
B203 (A)	37		No
	45		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

LIFTING MOTOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

LIFTING MOTOR (REAR)

Description

INFOID:0000000006163562

- The lifting motor (rear) is installed to the power seat frame assembly.
- The lifting motor (rear) is activated with the driver seat control unit.
- The seat lifter (rear) is moved upward/downward by changing the rotation direction of lifting motor (rear).

Component Function Check

INFOID:0000000006163563

1. CHECK FUNCTION

1. Select "SEAT LIFTER RR" in "Active test" mode with CONSULT-III.
2. Check the lifting motor (rear) operation.

Test Item		Description	
SEAT LIFTER RR	OFF	Seat lifting (rear)	Stop
	UP		Upward
	DWN		Downward

Is the operation of relevant parts normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-99, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163564

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK LIFTING MOTOR (REAR) POWER SUPPLY

1. Turn the ignition switch OFF.
2. Perform "Active test" ("SEAT LIFTER RR") with CONSULT-III
3. Check voltage between driver seat control unit harness connector and ground.

Terminal		Test Item	Voltage (V) (Approx.)		
(+)	(-)		OFF	0	
Driver seat control unit connector	Terminal	SEAT LIFTER RR	UP	Battery voltage	
B203	38		DWN (down)	0	
	Ground		OFF	0	
			UP	0	
			DWN (down)	Battery voltage	



Is the inspection result normal?

YES >> Replace lifting motor (rear). (Built in power seat frame assembly). Refer to [SE-44, "Disassembly and Assembly"](#).

NO >> GO TO 2

2. CHECK LIFTING MOTOR (REAR) CIRCUIT


LIFTING MOTOR (REAR)

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect driver seat control unit and lifting motor (rear).
2. Check continuity between driver seat control unit harness connector and lifting motor (rear) harness connector.

Driver seat control unit connector	Terminal	Lifting motor (rear) connector	Terminal	Continuity
B203 (A)	38	B207 (B)	5	Yes
	39		1	

3. Check continuity between driver seat control unit harness connector and ground.



Driver seat control unit connector	Terminal	Ground	Continuity
B203 (A)	38	Ground	No
	39		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace driver seat control unit. Refer to [ADP-148, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

PEDAL ADJUSTING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

PEDAL ADJUSTING MOTOR

Description

INFOID:0000000006163565

- The pedal adjusting motor is installed to the pedal adjusting motor assembly.
- The pedal adjusting motor is activated with the automatic drive positioner control unit.
- The pedal assembly is adjusted forward/backward by changing the rotation direction of pedal adjusting motor.

Component Function Check

INFOID:0000000006163566

1. CHECK FUNCTION

1. Select "PEDAL MOTOR" in "Active test" mode with CONSULT-III.
2. Check the pedal adjusting motor operation.

Test item		Description	
PEDAL MOTOR	OFF	Pedal adjusting motor	Stop
	FR		Forward
	RR		Backward

Is the operation of relevant parts normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-101, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163567

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK PEDAL ADJUSTING MOTOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Perform "Active test" ("PEDAL MOTOR") with CONSULT-III.
3. Check voltage between automatic drive positioner control unit harness connector and ground.

Terminal		Test Item	Voltage (V) (Approx.)
(+)	(-)		
Automatic drive positioner control unit connector	Terminal	PEDAL MOTOR	OFF 0
			RR (backward) 0
	37		FR (forward) Battery voltage
M34			OFF 0
	45		RR (backward) Battery voltage
			FR (forward) 0



Is the inspection result normal?

YES >> Replace pedal adjusting motor assembly. Refer to [ADP-152, "Removal and Installation"](#).

NO >> GO TO 2


2. CHECK PEDAL ADJUSTING MOTOR CIRCUIT

PEDAL ADJUSTING MOTOR

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect automatic drive positioner control unit and pedal adjusting motor assembly.
2. Check continuity between automatic drive positioner control unit harness connector and pedal adjusting motor assembly harness connector.

Automatic drive positioner control unit connector	Terminal	Pedal adjusting motor assembly connector	Terminal	Continuity
M34 (A)	37	E109 (B)	1	Yes
	45		2	



3. Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M34 (A)	37		No
	45		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR MOTOR

Description

INFOID:0000000006163568

It makes mirror face operate from side to side and up and down with the electric power that automatic drive positioner control unit supplies.

Component Function Check

INFOID:0000000006163569

1. CHECK DOOR MIRROR MOTOR FUNCTION

Check the operation with "MIRROR MOTOR RH" and "MIRROR MOTOR LH" in "ACTIVE TEST" mode with CONSULT-III

Refer to [ADP-26, "CONSULT-III Function"](#).

Is the inspection result normal?

YES >> Door mirror motor function is OK.

NO >> Refer to [ADP-103, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163570

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK DOOR MIRROR MOTOR INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between door mirror connector and ground.

Terminals		Door mirror remote control switch condition	Voltage (V) (Approx.)	
(+)	(-)			
Door mirror connector	Terminal			
D4 (LH) D107 (RH)	1	Ground	UP Battery voltage	
			Other than above 0	
			LEFT Battery voltage	
	2		Other than above 0	
			DOWN / RIGHT Battery voltage	
			Other than above 0	



Is the inspection result normal?

YES >> Refer to [ADP-105, "Component Inspection"](#).


NO >> GO TO 2

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect automatic drive positioner control unit and door mirror.
3. Check continuity between automatic drive positioner control unit connector and door mirror connector.

Door mirror LH

Automatic drive positioner control unit connector	Terminal	Door mirror LH connector	Terminal	Continuity
M33	16	D4	3	Yes
	31		1	
	32		2	



DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Door mirror RH

Automatic drive positioner control unit connector	Terminal	Door mirror RH connector	Terminal	Continuity
M33	14	D107	1	Yes
	15		2	
	30		3	

4. Check continuity between automatic drive positioner control unit connector and ground.

Door mirror LH

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M33	16		No
	31		
	32		

Door mirror RH

Automatic drive positioner control unit connector	Terminal	Ground	Continuity
M33	14		No
	15		
	30		

Is the inspection result normal?

YES >> GO TO 3



NO >> Repair or replace harness.

3. CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT OUTPUT SIGNAL

1. Connect automatic drive positioner control unit.
2. Turn ignition switch ON.
3. Check voltage between automatic drive positioner control unit connector and ground.

Door mirror LH


Automatic drive positioner control unit connector	Terminals		Mirror switch condition	Voltage (V) (Approx.)	
	(+)	(-)			
M33	16	Ground	DOWN / RIGHT	Battery voltage	
			Other than above	0	
			UP	Battery voltage	
	31		Other than above	0	
			LEFT	Battery voltage	
			Other than above	0	



DOOR MIRROR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Door mirror RH			
Terminals		Mirror switch condition	Voltage (V) (Approx.)
(+)	(-)		
Automatic drive positioner control unit connector M33	Terminal 14	UP	Battery voltage
		Other than above	0
		LEFT	Battery voltage
	Terminal 15	Other than above	0
		DOWN / RIGHT	Battery voltage
		Other than above	0



Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

4. CHECK DOOR MIRROR MOTOR

Check door mirror motor.

Refer to [ADP-105, "Component Inspection"](#).

Is the inspection result normal?

YES >> Refer to [GI-39, "Intermittent Incident"](#).

NO >> Replace door mirror actuator. Refer to [MIR-18, "Mirror Actuator"](#).

Component Inspection

INFOID:0000000006163571

1. CHECK DOOR MIRROR MOTOR-I

Check that door mirror motor does not trap foreign objects and does not have any damage.

Refer to [MIR-15, "Door Mirror Assembly"](#).

Is the inspection result normal?


YES >> GO TO 2

NO >> Replace door mirror actuator. Refer to [MIR-18, "Mirror Actuator"](#).

2. CHECK DOOR MIRROR MOTOR-II

1. Turn ignition switch OFF.
2. Disconnect door mirror.
3. Apply 12V to each power supply terminal of door mirror motor.

Door mirror connector	Terminal		Operational direction
	(+)	(-)	
D4 (LH) D107 (RH)	3	2	RIGHT
	2	3	LEFT
	1	3	UP
	3	1	DOWN



Is the inspection result normal?

YES >> Inspection End.

NO >> Replace door mirror actuator. Refer to [MIR-18, "Mirror Actuator"](#).

SEAT MEMORY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

SEAT MEMORY INDICATOR LAMP

Description

INFOID:0000000006163572

- The seat memory switch is installed on the driver side door trim. The operation signal is inputted to the automatic drive positioner control unit when the memory switch is operated.
- The status of automatic drive positioner system can be checked according to the illuminating/flashing status.

Component Function Check

INFOID:0000000006163573

1. CHECK FUNCTION

- Select "MEMORY SW INDCTR" in "Active test" mode with CONSULT-III.
- Check the memory indicator operation.

Test item		Description	
MEMORY SW INDCTR	OFF	Memory switch indicator	OFF
	ON-1		Indicator 1: ON
	ON-2		Indicator 2: ON

Is the operation of relevant parts normal?

YES >> Inspection End.

NO >> Perform diagnosis procedure. Refer to [ADP-106, "Diagnosis Procedure"](#).

Diagnosis Procedure


INFOID:0000000006163574

Regarding Wiring Diagram information, refer to [ADP-128, "Wiring Diagram"](#).

1. CHECK SEAT MEMORY INDICATOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect automatic drive positioner control unit and seat memory switch.
- Check continuity between automatic drive positioner control unit harness connector and seat memory switch harness connector.

Automatic drive positioner control unit connector	Terminal	Seat memory switch connector	Terminal	Continuity
M33	12	D5	6	Yes
	13		7	



- Check continuity between automatic drive positioner control unit harness connector and ground.

Automatic drive positioner connector	Terminal	Ground	Continuity
M33	12		No
	13		

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair or replace harness.

2. CHECK MEMORY INDICATOR POWER SUPPLY

SEAT MEMORY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

Check voltage between seat memory switch harness connector and ground.


Seat memory switch connector	Terminals		Voltage (V) (Approx.)
	(+)	(-)	
D5	5	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3

NO >> Check the following.

- Fuse
- Harness for open or short between memory indicator and fuse.



3. CHECK MEMORY INDICATOR

Refer to [ADP-107, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4

NO >> Replace seat memory switch. Refer to [ADP-150, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace automatic drive positioner control unit. Refer to [ADP-149, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

Component Inspection

INFOID:0000000006163575

1. CHECK SEAT MEMORY INDICATOR

1. Disconnect seat memory switch.


2. Check continuity between seat memory switch terminals.

Terminal		Continuity
Seat memory switch		
(+)	(-)	
6	5	
7		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace seat memory switch. Refer to [ADP-150, "Removal and Installation"](#).



DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

DRIVER SEAT CONTROL UNIT

Reference Value

INFOID:000000006163576

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM


Monitor Item	Condition	Value/Status
SET SW	Set switch	Push
		Release
MEMORY SW1	Memory switch 1	Push
		Release
MEMORY SW2	Memory switch 2	Push
		Release
SLIDE SW-FR	Sliding switch (front)	Operate
		Release
SLIDE SW-RR	Sliding switch (rear)	Operate
		Release
RECLN SW-FR	Reclining switch (front)	Operate
		Release
RECLN SW-RR	Reclining switch (rear)	Operate
		Release
LIFT FR SW-UP	Lifting switch front (up)	Operate
		Release
LIFT FR SW-DN	Lifting switch front (down)	Operate
		Release
LIFT RR SW-UP	Lifting switch rear (up)	Operate
		Release
LIFT RR SW-DN	Lifting switch rear (down)	Operate
		Release
MIR CON SW-UP	Mirror switch	Up
		Other than above
MIR CON SW-DN	Mirror switch	Down
		Other than above
MIR CON SW-RH	Mirror switch	Right
		Other than above
MIR CON SW-LH	Mirror switch	Left
		Other than above
MIR CHNG SW-R	Changeover switch	Right
		Other than above
MIR CHNG SW-L	Changeover switch	Left
		Other than above
PEDAL SW-FR	Pedal adjusting switch	Forward
		Other than above
PEDAL SW-RR	Pedal adjusting switch	Backward
		Other than above

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
DETENT SW	AT selector lever	P position	OFF
		Other than above	ON
STARTER SW	Ignition position	Cranking	ON
		Other than above	OFF
SLIDE PULSE	Seat sliding	Forward	The numeral value decreases
		Backward	The numeral value increases
		Other than above	No change to numeral value
RECLN PULSE	Seat reclining	Forward	The numeral value decreases
		Backward	The numeral value increases
		Other than above	No change to numeral value
LIFT FR PULSE	Seat lifter (front)	Up	The numeral value decreases
		Down	The numeral value increases
		Other than above	No change to numeral value
LIFT RR PULSE	Seat lifter (rear)	Up	The numeral value decreases
		Down	The numeral value increases
		Other than above	No change to numeral value
MIR/SEN RH U-D	Door mirror (passenger side)	Close to peak	3.4
		Close to valley	0.6
MIR/SEN RH R-L	Door mirror (passenger side)	Close to left edge	3.4
		Close to right edge	0.6
MIR/SEN LH U-D	Door mirror (driver side)	Close to peak	3.4
		Close to valley	0.6
MIR/SEN LH R-L	Door mirror (driver side)	Close to left edge	0.6
		Close to right edge	3.4
PEDAL SEN	pedal position	Forward	0.5
		Backward	4.5




TERMINAL LAYOUT



PHYSICAL VALUES




DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No.		Wire color	Description		Condition	Voltage (V) (Approx)
+	-		Signal name	Input/Output		
1	Ground	W	UART LINE (RX)	Input	Ignition switch ON	 PIIA4813E
3	—	L/B	CAN-H	—	—	—
6	Ground	R	Ignition switch (START)	Input	Ignition switch	OFF 0 START Battery voltage
9	Ground	R/B	Reclining sensor signal	Input	Seat reclining	Operate  SIIA0692J
						Stop 0 or 5
10	Ground	B/R	Lifting sensor (rear) signal	Input	Seat lifting (rear)	Operate  SIIA0693J
						Stop 0 or 5
11	Ground	Y/R	Sliding switch backward signal	Input	Sliding switch	Operate (backward) 0 Release Battery voltage
						Release Battery voltage
12	Ground	L/W	Reclining switch backward signal	Input	Reclining switch	Operate (backward) 0 Release Battery voltage
						Release Battery voltage
13	Ground	V	Lifting switch (front) down signal	Input	Lifting switch (front)	Operate (down) 0 Release Battery voltage
						Release Battery voltage
14	Ground	P/L	Lifting switch (rear) down signal	Input	Lifting switch (rear)	Operate (down) 0 Release Battery voltage
						Release Battery voltage
15	Ground	SB	Pedal switch backward signal	Input	Pedal switch	Operate (backward) 0 Release Battery voltage
						Release Battery voltage
16	Ground	R/W	Sensor power supply	Output	—	5

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No.		Wire color	Description		Condition	Voltage (V) (Approx)
+	-		Signal name	Input/Output		
17	Ground	Y/R	UART LINE (TX)	Output	Ignition switch ON	 PIIA4814E
19	—	G	CAN-L	—	—	—
21	Ground	L	A/T shift selector (park position switch)	Input	A/T selector lever	P position
						Except P position
24	Ground	R/L	Sliding sensor signal	Input	Seat sliding	Operate
						 PIIA3277E
25	Ground	Y/G	Lifting sensor (front) signal	Input	Seat lifting (front)	Operate
						 SIIA0691J
26	Ground	L/R	Sliding switch forward signal	Input	Sliding switch	Operate (forward)
						Release
27	Ground	V/W	Reclining switch forward signal	Input	Reclining switch	Operate (forward)
						Release
28	Ground	BR/Y	Lifting switch (front) up signal	Input	Seat lifting switch (front)	Operate (up)
						Release
29	Ground	G/R	Lifting switch (rear) up signal	Input	Seat lifting switch (rear)	Operate (up)
						Release
30	Ground	L/Y	Pedal switch forward signal	Input	Pedal switch	Operate (forward)
						Release
31	Ground	GR/R	Sensor ground	—	—	0
32	Ground	G/W	Ground (signal)	—	—	0
33	Ground	W/B	Battery power source (C/B)	Input	—	Battery voltage

A

B

C

D

E

F

G

H

ADP

K

L

M

N

O

P

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No.		Wire color	Description		Condition		Voltage (V) (Approx)
+	-		Signal name	Input/ Output			
35	Ground	R/G	Sliding motor forward output signal	Output	Seat sliding	Operate (forward)	Battery voltage
						Release	0
36	Ground	L	Reclining motor forward output signal	Output	Seat reclining	Operate (forward)	Battery voltage
						Release	0
37	Ground	B	Lifting motor (front) down output signal	Output	Seat lifting (front)	Operate (down)	Battery voltage
						Stop	0
38	Ground	GR	Lifting motor (rear) up output signal	Output	Seat lifting (rear)	Operate (up)	Battery voltage
						Stop	0
39	Ground	R	Lifting motor (rear) down output signal	Output	Seat lifting (rear)	Operate (down)	Battery voltage
						Stop	0
40	Ground	G	Power source (Fuse)	Input	—		Battery voltage
42	Ground	R/Y	Sliding motor backward output signal	Output	Seat sliding	Operate (back-ward)	Battery voltage
						Stop	0
44	Ground	G/B	Reclining motor backward output signal	Output	Seat reclining	Operate (back-ward)	Battery voltage
						Stop	0
45	Ground	G/Y	Lifting motor (front) up output signal	Output	Seat lifting (front)	Operate (up)	Battery voltage
						Stop	0
48	Ground	B	Ground (power)	—	—		0

Fail Safe

INFOID:0000000006163578

The fail-safe mode may be activated if the following symptoms are observed.

FAIL-SAFE MODE

When any manual and automatic operations are not performed, if any motor operations of front seat LH or pedals are detected for T2 or more, status is judged "Output error".

OPERATED PORTION	T2
Seat sliding	Approx. 0.1 sec.
Seat reclining	Same as above
Seat lifting (Front)	Same as above
Seat lifting (Rear)	Same as above
Pedal adjust	Same as above

NOTE:

The front seat LH position and pedal adjustment functions (see the following table) operate simultaneously in the order of priority.

DRIVER SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Priority	Function	Priority	Function
1	Seat sliding, (door mirror LH/RH)*	4	Seat lifter-FR
2	Pedal	5	Seat lifter-RR
3	Seat reclining		

*: In conjunction with sliding the seat, the door mirrors are positioned.

CANCEL OF FAIL-SAFE MODE

The mode is cancelled when the A/T selector lever is shifted to P position from any other position.

DTC Index

INFOID:0000000006163579

CONSULT-III display	Timing ^{*1}		Item	Reference page
	Current mal- function	Previous mal- function		
CAN COMM CIRCUIT [U1000]	0	1-39	CAN communication	ADP-29
SEAT SLIDE [B2112]	0	1-39	Seat slide motor output	ADP-30
SEAT RECLINING [B2113]	0	1-39	Seat reclining motor output	ADP-32
SEAT LIFTER FRONT [B2114]	0	1-39	Seat lifting motor front output	ADP-34
SEAT LIFTER REAR [B2115]	0	1-39	Seat lifting motor rear output	ADP-36
ADJ PEDAL MOTOR [B2117]	0	1-39	Pedal adjusting motor output	ADP-38
ADJ PEDAL SENSOR [B2120]	0	1-39	Pedal adjusting sensor input	ADP-40
DETENT SW [B2126]	0	1-39	T. R. switch condition	ADP-42
UART COMM [B2128]	0	1-39	UART communication	ADP-45

*1:

- 0: Current malfunction is present
- 1-39: Displayed if any previous malfunction is present when current condition is normal. The numeral value increases by one at each IGN ON to OFF cycle from 1 to 39. The counter remains at 39 even if the number of cycles exceeds it. However, the counter is reset to 1 if any malfunction is detected again, the normal operation is resumed and the ignition switch is turned from OFF to ON.

AUTOMATIC DRIVE POSITIONER CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Reference Value


INFOID:0000000006163580

TERMINAL LAYOUT



PHYSICAL VALUES


Terminal No.	Wire color	Description		Condition	Voltage (V) (Approx.)
		Signal name	Input/Out-put		
2	Ground	LG	Changeover switch RH signal	Input	Changeover switch position
					RH 0
					Neutral or LH 5
3	Ground	Y/B	Mirror switch up signal	Input	Mirror switch
					Operated (up) 0
					Other than above 5
4	Ground	V/W	Mirror switch left signal	Input	Mirror switch
					Operated (left) 0
					Other than above 5
5	Ground	R/B	Door mirror sensor (RH) up/down signal	Input	Door mirror RH position
					Peak 3.4
					Valley 0.6
6	Ground	L/Y	Door mirror sensor (LH) up/down signal	Input	Door mirror LH position
					Peak 3.4
					Valley 0.6
8	Ground	BR/Y	Pedal sensor input signal	Input	Pedal sensor
					Forward 0.5
					Backward 4.5
9	Ground	LG/B	Memory switch 1 signal	Input	Memory switch 1
					Push 0
					Other than above 5
10	Ground	L	UART LINE (TX)	Output	Ignition switch ON
12	Ground	P	Memory inductor 1 signal	Output	Memory inductor 1
					Illuminate 0
					Other than above Battery voltage



PIIA4813E

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No.		Wire color	Description		Condition		Voltage (V) (Approx.)		
+	-		Signal name	Input/Out-put					
13	Ground	Y/G	Memory inductor 2 signal	Out-put	Memory inductor 2	Illuminate	0		
						Other than above	Battery voltage		
14	Ground	GR/R	Door mirror motor (RH) up output signal	Out-put	Door mirror RH	Operate (up)	1.5 - Battery voltage		
						Other than above	0		
15	Ground	V/R	Door mirror motor (RH) left output signal	Out-put	Door mirror RH	Operate (left)	1.5 - Battery voltage		
						Other than above	0		
16	Ground	O	Door mirror motor (LH) down output signal	Out-put	Door mirror (LH)	Operate (down)	1.5 - Battery voltage		
						Other than above	0		
			Door mirror motor (LH) right output signal			Operate (right)	1.5 - Battery voltage		
						Other than above	0		
18	Ground	BR/W	Changeover switch LH signal	Input	Changeover switch position	LH	0		
						Neutral or RH	5		
19	Ground	SB	Mirror switch down signal	Input	Mirror switch	Operate (down)	0		
						Other than above	5		
20	Ground	GR	Mirror switch right signal	Input	Mirror switch	Operate (right)	0		
						Other than above	5		
21	Ground	L/W	Door mirror sensor (RH) left/right signal	Input	Door mirror RH position	Left edge	3.4		
						Right edge	0.6		
22	Ground	G	Door mirror sensor (LH) left/right signal	Input	Door mirror LH position	Left edge	0.6		
						Right edge	3.4		
24	Ground	G/O	Set switch signal	Input	Set switch	Push	0		
						Other than above	5		
25	Ground	P/L	Memory switch 2 signal	Input	Memory switch 2	Push	0		
						Other than above	5		
26	Ground	W	UART LINE (RX)	Input	Ignition switch ON				

A
 B
 C
 D
 E
 F
 G
 H
 I
 ADP
 K
 L
 M
 N
 O
 P

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No.	Wire color	Description		Condition	Voltage (V) (Approx.)	
		Signal name	Input/Out-put			
30	Ground	Y	Door mirror motor (RH) down output signal	Output	Operate (down)	1.5 - Battery voltage
			Door mirror motor (RH) right output signal		Other than above	0
		R	Door mirror motor (LH) up output signal		Operate (right)	1.5 - Battery voltage
			Door mirror motor (LH) left output signal		Other than above	0
33	Ground	W/L	Sensor power supply	Input	—	5
34	Ground	Y/R	Battery power source	Input	—	Battery voltage
37	Ground	G	Pedal adjusting motor forward output signal	Output	Operate (forward)	Battery voltage
					Other than above	0
39	Ground	L/B	Battery power source	—	—	Battery voltage
40	Ground	B/W	Ground	—	—	0
41	Ground	W/G	Sensor ground	—	—	0
45	Ground	R	Pedal adjusting motor backward output signal	Output	Operate (back-ward)	Battery voltage
					Other than above	0
48	Ground	B	Ground	—	—	0

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:0000000006601979

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
ACC ON SW	Ignition switch OFF or ON	Off
	Ignition switch ACC	On
AIR COND SW	A/C switch OFF	Off
	A/C switch ON	On
AIR PRESS FL	Front left tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS FR	Front right tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS RL	Rear left tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS RR	Rear right tire air pressure value	kPa, kg/cm ² , psi
AUTO LIGHT SW	Lighting switch OFF	Off
	Lighting switch AUTO	On
BRAKE SW	Brake pedal released	Off
	Brake pedal applied	On
BUCKLE SW	Seat belt buckle unfastened	Off
	Seat belt buckle fastened	On
BUZZER	Buzzer in combination meter OFF	Off
	Buzzer in combination meter ON	On
CARGO LAMP SW	Cargo lamp switch OFF	Off
	Cargo lamp switch ON	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the LOCK side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the UNLOCK side	On
DOOR SW-AS	Front door RH closed	Off
	Front door RH opened	On
DOOR SW-DR	Front door LH closed	Off
	Front door LH opened	On
DOOR SW-RL	Rear door LH closed	Off
	Rear door LH opened	On
DOOR SW-RR	Rear door RH closed	Off
	Rear door RH opened	On
FAN ON SIG	Blower motor fan switch OFF	Off
	Blower motor fan switch ON	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER LOW	Front wiper switch OFF	Off
	Front wiper switch LO	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
FR WIPER HI	Front wiper switch OFF	Off
	Front wiper switch HI	On
FR WIPER INT	Front wiper switch OFF	Off
	Front wiper switch INT	On
FR WIPER STOP	Any position other than front wiper stop position	Off
	Front wiper stop position	On
HAZARD SW	When hazard switch is not pressed	Off
	When hazard switch is pressed	On
HEAD LAMP SW1	Headlamp switch OFF	Off
	Headlamp switch 1st	On
HEAD LAMP SW2	Headlamp switch OFF	Off
	Headlamp switch 1st	On
HI BEAM SW	High beam switch OFF	Off
	High beam switch HI	On
ID REGST FL1	ID registration of front left tire incomplete	YET
	ID registration of front left tire complete	DONE
ID REGST FR1	ID registration of front right tire incomplete	YET
	ID registration of front right tire complete	DONE
ID REGST RL1	ID registration of rear left tire incomplete	YET
	ID registration of rear left tire complete	DONE
ID REGST RR1	ID registration of rear right tire incomplete	YET
	ID registration of rear right tire complete	DONE
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
IGN SW CAN	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7
KEY CYL LK-SW	Door key cylinder LOCK position	Off
	Door key cylinder other than LOCK position	On
KEY CYL UN-SW	Door key cylinder UNLOCK position	Off
	Door key cylinder other than UNLOCK position	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
KEYLESS LOCK	LOCK button of key fob is not pressed	Off
	LOCK button of key fob is pressed	On
KEYLESS PANIC	PANIC button of key fob is not pressed	Off
	PANIC button of key fob is pressed	On
KEYLESS UNLOCK	UNLOCK button of key fob is not pressed	Off
	UNLOCK button of key fob is pressed	On
LIGHT SW 1ST	Lighting switch OFF	Off
	Lighting switch 1st	On
OIL PRESS SW	• Ignition switch OFF or ACC • Engine running	Off
	Ignition switch ON	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5V
	Dark outside of the vehicle	Close to 0V
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
TURN SIGNAL L	Turn signal switch OFF	Off
	Turn signal switch LH	On
TURN SIGNAL R	Turn signal switch OFF	Off
	Turn signal switch RH	On
VEHICLE SPEED	While driving	Equivalent to speedometer reading
WARNING LAMP	Low tire pressure warning lamp in combination meter OFF	Off
	Low tire pressure warning lamp in combination meter ON	On

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O


P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal Layout

INFOID:0000000006601980






LIIA2443E

Physical Values

INFOID:0000000006601981

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
2	SB	Combination switch input 5	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
3	G/Y	Combination switch input 4	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
4	Y	Combination switch input 3	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
5	G/B	Combination switch input 2	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
6	V	Combination switch input 1				
9	Y/B	Rear window defogger switch (Crew Cab)	Input	ON	Rear window defogger switch ON	0V
					Rear window defogger switch OFF	5V
11	O	Ignition switch (ACC or ON)	Input	ACC or ON	Ignition switch ACC or ON	Battery voltage
12	R/L	Front door switch RH (All)	Input	OFF	ON (open)	0V
		Rear door switch lower RH (King Cab)				
		Rear door switch upper RH (King Cab)			OFF (closed)	Battery voltage
13	GR	Rear door switch RH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
15	L/W	Tire pressure warning check connector	Input	OFF	—	5V
18	P	Remote keyless entry receiver and optical sensor (ground)	Output	OFF	—	0V

A
B
C
D
E
F
G
H
I
ADP
K
L
M
N
O
P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
19	V/W	Remote keyless entry receiver (power supply)	Output	OFF	Ignition switch OFF	 LIA1893E
20	G/W	Remote keyless entry receiver (signal)	Input	OFF	Stand-by (keyfob buttons released)	 LIA1894E
					When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed)	 LIA1895E
21	G	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage.
22	G	BUS	—	—	Ignition switch ON or power window timer operates	 PIIA2344E
23	G/O	Security indicator lamp	Output	OFF	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0V
25	BR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage.
27	W/R	Compressor ON signal	Input	ON	A/C switch OFF	5V
					A/C switch ON	0V
28	L/R	Front blower monitor	Input	ON	Front blower motor OFF	Battery voltage
					Front blower motor ON	0V
29	W/B	Hazard switch	Input	OFF	ON	0V
					OFF	5V
31	P/L	Cargo lamp switch	Input	OFF	Cargo lamp switch ON	0
					Cargo lamp switch OFF	Battery voltage

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
32	R/G	Combination switch output 5	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
33	R/Y	Combination switch output 4	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
34	L	Combination switch output 3	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
35	O/B	Combination switch output 2	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
36	R/W	Combination switch output 1				
37	B/R	Key switch and key lock solenoid	Input	OFF	Key inserted	Battery voltage
					Key inserted	0V
38	W/L	Ignition switch (ON)	Input	ON	—	Battery voltage
39	L	CAN-H	—	—	—	—
40	P	CAN-L	—	—	—	—
47	SB	Front door switch LH (All)	Input	OFF	ON (open)	0V
		Rear door switch lower LH (King Cab)				Battery voltage
		Rear door switch upper LH (King Cab)			OFF (closed)	
48	R/Y	Rear door switch LH (Crew Cab)	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
50	R/Y	Cargo bed lamp control	Output	OFF	Cargo lamp switch (ON)	0V
					Cargo lamp switch (OFF)	Battery voltage

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M
 N
 O
 P
 ADP

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
51	G/Y	Trailer turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
52	G/B	Trailer turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
56	R/G	Battery saver output	Output	OFF	15 minutes after ignition switch is turned OFF	0V
				ON	—	Battery voltage
57	Y/R	Battery power supply	Input	OFF	—	Battery voltage
58	W/R	Optical sensor	Input	ON	When optical sensor is illuminated	3.1V or more
					When optical sensor is not illuminated	0.6V or less
59	G	Front door lock assembly LH actuator (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage
60	G/B	Turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
61	G/Y	Turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
62	R/W	Step lamp LH and RH	Output	OFF	ON (any door open)	0V
					OFF (all doors closed)	Battery voltage
63	L	Interior room/map lamp	Output	OFF	Any door switch	0V
					ON (open) OFF (closed)	Battery voltage
65	V	All door lock actuators (lock)	Output	OFF	OFF (neutral)	0V
					ON (lock)	Battery voltage
66	G/Y	Front door lock actuator RH and rear door lock actuators LH/RH (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
67	B	Ground	Input	ON	—	0V
68	W/L	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
69	W/R	Power window power supply	Output	—	—	Battery voltage
70	W/B	Battery power supply	Input	OFF	—	Battery voltage

Fail Safe

INFOID:0000000006601983

Fail-safe index

BCM performs fail-safe control when any DTC listed below is detected.

Display contents of CONSULT	Fail-safe	Cancellation
U1000: CAN COMM CIRCUIT	Inhibit engine cranking	When the BCM re-establishes communication with the other modules.

DTC Inspection Priority Chart

INFOID:0000000006601984

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	• U1000: CAN COMM CIRCUIT
2	• B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC
3	<ul style="list-style-type: none"> • C1729: VHCL SPEED SIG ERR • C1735: IGNITION SIGNAL
4	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL

DTC Index

INFOID:0000000006601985

NOTE:

Details of time display

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—
U1000: CAN COMM CIRCUIT	—	—	BCS-27
B2190: NATS ANTENNA AMP	—	—	SEC-18
B2191: DIFFERENCE OF KEY	—	—	SEC-21
B2192: ID DISCORD BCM-ECM	—	—	SEC-22
B2193: CHAIN OF BCM-ECM	—	—	SEC-24
C1708: [NO DATA] FL	—	—	WT-14
C1709: [NO DATA] FR	—	—	WT-14
C1710: [NO DATA] RR	—	—	WT-14
C1711: [NO DATA] RL	—	—	WT-14
C1712: [CHECKSUM ERR] FL	—	—	WT-16
C1713: [CHECKSUM ERR] FR	—	—	WT-16
C1714: [CHECKSUM ERR] RR	—	—	WT-16
C1715: [CHECKSUM ERR] RL	—	—	WT-16

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Tire pressure monitor warning lamp ON	Reference page
C1716: [PRESSDATA ERR] FL	—	—	WT-18
C1717: [PRESSDATA ERR] FR	—	—	WT-18
C1718: [PRESSDATA ERR] RR	—	—	WT-18
C1719: [PRESSDATA ERR] RL	—	—	WT-18
C1720: [CODE ERR] FL	—	—	WT-16
C1721: [CODE ERR] FR	—	—	WT-16
C1722: [CODE ERR] RR	—	—	WT-16
C1723: [CODE ERR] RL	—	—	WT-16
C1724: [BATT VOLT LOW] FL	—	—	WT-16
C1725: [BATT VOLT LOW] FR	—	—	WT-16
C1726: [BATT VOLT LOW] RR	—	—	WT-16
C1727: [BATT VOLT LOW] RL	—	—	WT-16
C1729: VHCL SPEED SIG ERR	—	—	WT-19
C1735: IGNITION SIGNAL	—	—	WT-20

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

AUTOMATIC DRIVE POSITIONER


< WIRING DIAGRAM >

WIRING DIAGRAM

AUTOMATIC DRIVE POSITIONER


Wiring Diagram

INFOID:000000006464652




AUTOMATIC DRIVE POSITIONER

< WIRING DIAGRAM >



AUTOMATIC DRIVE POSITIONER


< WIRING DIAGRAM >



ABJWA0083GB

AUTOMATIC DRIVE POSITIONER

< WIRING DIAGRAM >




ABJWA0212GB

AUTOMATIC DRIVE POSITIONER


< WIRING DIAGRAM >

AUTOMATIC DRIVE POSITIONER CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1N	Y/R	—
14P	O	—

Terminal No.	Color of Wire	Signal Name
13P	P	—
14P	O	—

Terminal No.	Color of Wire	Signal Name
1	W/L	—
2	W/G	—
5	G	— (WITH AUTOMATIC DRIVE POSITIONER)
6	BR/Y	—
7	R	— (WITH AUTOMATIC DRIVE POSITIONER)

Terminal No.	Color of Wire	Signal Name
8	SB	—
9	Y/B	—
10	V/W	—
11	GR	—
12	BR	—
13	G	—
14	O	—
15	W/G	—
16	L/Y	—
17	W/L	—
18	R	—
19	LG	—
20	Y/R	—
21	BR/W	—

Connector No.	M9
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	P/L	—
2	G/O	—

Terminal No.	Color of Wire	Signal Name
3	Y/G	—
4	P	—
5	L/G/B	—

AUTOMATIC DRIVE POSITIONER

< WIRING DIAGRAM >


Connector No.	M20
Connector Name	BCM(BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W/B	BAT (F/L)

Terminal No.	Color of Wire	Signal Name
7G	W/L	-
10G	W/B	-
20G	G/R	-
43G	GR	- (COLUMN SHIFT)

Connector No.	M19
Connector Name	BCM(BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
47	SB	DOOR SW (DR)

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE


5G	4G	3G	2G	1G
9G	8G	7G	6G	
10G				
21G	20G	19G	18G	17G
30G	29G	28G	27G	26G
41G	40G	39G	38G	37G
50G	49G	48G	47G	46G
61G	60G	59G	58G	57G
70G	69G	68G	67G	66G
81G	80G	79G	78G	77G
7G	6G	5G	4G	3G
64G	63G	62G	61G	60G
56G	55G	54G	53G	52G
46G	45G	44G	43G	42G
36G	35G	34G	33G	32G
26G	25G	24G	23G	22G
16G	15G	14G	13G	12G
5G				

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	O	ACC SW
38	W/L	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M27
Connector Name	KEY SWITCH AND KEY LOCK SOLENOID
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	-
4	B/R	-

ABJIA0513GB

AUTOMATIC DRIVE POSITIONER

< WIRING DIAGRAM >

Connector No.	M33
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Color	WHITE

H.S.



Terminal No.	Color of Wire	Signal Name
1	-	-
2	LG	MIR SELECT SW RH
3	Y/B	MIR MANU SW UP
4	V/W	MIR MANU SW LH
5	R/B	VERTICAL SENS RH
6	L/Y	VERTICAL SENS LH
7	-	-

Terminal No.	Color of Wire	Signal Name
8	BR/Y	PEDAL POTENTION
9	L/G/B	MEMORY1 SW
10	L	TX
11	-	-
12	P	MEMORY1 IND
13	Y/G	MEMORY2 IND
14	G/R/R	RH MTR (UP-DN)
15	V/R	RH MTR (LT)
16	O	LH MTR (COM)
17	-	-
18	BR/W	MIR SELECT SW LH
19	SB	MIR MANU SW DN
20	GR	MIR MANU SW RH
21	L/W	HORIZONTAL SENS
22	G	HORIZONTAL SENS


Terminal No.	Color of Wire	Signal Name
23	-	-
24	G/O	SET SW
25	P/L	MEMORY2 SW
26	W	RX
27	-	-
28	-	-
29	-	-



Terminal No.	Color of Wire	Signal Name
30	Y	RH MTR (COM)
31	R	LH MTR (UP-DWN)
32	BR	LH MTR (LT)



Terminal No.	Color of Wire	Signal Name
37	G	FORWARD
38	-	-
39	L/B	BAT(PTC)
40	B/W	GND(SIG)
41	W/G	MEMORY(POT-RET)
42	-	-
43	-	-
44	-	-
45	R	PEDAL RR OUT
46	-	-
47	-	-
48	B	GND (POWER)



Terminal No.	Color of Wire	Signal Name
1Q	G/R	-



ABJIA0514GB

AUTOMATIC DRIVE POSITIONER


< WIRING DIAGRAM >

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5	6	7
8	9	10	11	12	13	14



Terminal No.	Color of Wire	Signal Name
5J	L/B	—
35J	O	—
36J	L/Y	—
37J	R	—
44J	W	—
45J	Y/R	—
46J	L/R	—
47J	L	—
51J	L	—
52J	P	—
60J	SB	—



Connector No.	M60
Connector Name	FUSE BLOCK (J/Block)
Connector Color	WHITE



Connector No.	M56
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5	6	7
8	9	10	11	12	13	14



Terminal No.	Color of Wire	Signal Name
10	L/R	—
11	B/R	—

Connector No.	M68
Connector Name	A/T SHIFT SELECTOR (COLUMN SHIFT)
Connector Color	WHITE

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16



Terminal No.	Color of Wire	Signal Name
1	B	—
3	G/W	—
8	L/R	DETENT SW

Connector No.	M74
Connector Name	WIRE TO WIRE
Connector Color	BROWN

9	8	7	6	5	4	3	2	1
20	19	18	17	16	15	14	13	11



Terminal No.	Color of Wire	Signal Name
8	Y	— (WITH AUTOMATIC DRIVE POSITIONER)
9	R/B	— (WITH AUTOMATIC DRIVE POSITIONER)
13	W/G	—
14	W/L	—
15	V/R	—
16	L/W	—
20	GR/R	—

ADP

K

M

Z

O

P

A

B

D

T

M

G

—

—

ABJIA0515GB


AUTOMATIC DRIVE POSITIONER

< WIRING DIAGRAM >

Connector No.	M96
Connector Name	PEDAL ADJUSTING SWITCH (WITH AUTOMATIC DRIVE POSITIONER)
Connector Color	BROWN



Connector No.	M82
Connector Name	CIRCUIT BREAKER-2
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
2	L/Y	-
3	R	-

Terminal No.	Color of Wire	Signal Name
1	L/B	-
2	W/B	-
3	-	-

Connector No.	M178
Connector Name	JOINT CONNECTOR-M10
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	G/W	-
2	GR	-




Terminal No.	Color of Wire	Signal Name
10	L/R	-
11	B/R	-

Terminal No.	Color of Wire	Signal Name
10	L	-
11	L	-
16	P	-
17	P	-



Terminal No.	Color of Wire	Signal Name
2	L	-
6	L	-
11	P	-
15	P	-




ABJIA0516GB


AUTOMATIC DRIVE POSITIONER

< WIRING DIAGRAM >

Connector No.	M203
Connector Name	A/T SHIFT SELECTOR (FLOOR SHIFT) (KING CAB)
Connector Color	WHITE



Connector No.	M204
Connector Name	A/T SHIFT SELECTOR (FLOOR SHIFT) (CREW CAB)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	B/R	DETENT KEY SW
6	L/R	DETENT KEY SW

Terminal No.	Color of Wire	Signal Name
5	B/R	DETENT KEY SW
6	L/R	DETENT KEY SW


Terminal No.	Color of Wire	Signal Name
1	W/L	-
2	W/G	-
5	G	- (WITH AUTOMATIC DRIVE POSITIONER)
6	BR/Y	-
7	R	- (WITH AUTOMATIC DRIVE POSITIONER)



Terminal No.	Color of Wire	Signal Name
3	W/L	-
4	BR/Y	-
5	W/G	-



Connector No.	E38
Connector Name	STOP LAMP SWITCH (COLUMN SHIFT)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	R	-



Terminal No.	Color of Wire	Signal Name
3	W/L	-
4	BR/Y	-
5	W/G	-



ADP

K

M

Z

O

P

A

B

C

D

F

G

—


L

P

AUTOMATIC DRIVE POSITIONER

< WIRING DIAGRAM >

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7G	L/W	-
10G	W/B	-
20G	G/R	-
43G	GR	-(COLUMN SHIFT)

Signal Name

1
2
3

Terminal No.	Color of Wire	Signal Name
1G	2G	3G
6G	7G	4G
		5G
		6G
		10G



Signal Name

1
2
3

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



11G	12G	14G	15G	16G	17G	18G	19G	20G	21G
22G	23G	24G	25G	26G	27G	28G	29G	30G	
31G	32G	33G	34G	35G	36G	37G	38G	39G	40G
41G	42G	43G	44G	45G	46G	47G	48G	49G	50G
51G	52G	53G	54G	55G	56G	57G	58G	59G	60G
61G	62G	63G	64G	65G	66G	67G	68G	69G	70G
71G	72G	73G	74G	75G					
76G	77G	78G	79G	80G					

Signal Name

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21

Terminal No.	Color of Wire	Signal Name
2	SB	-
3	B	-

Signal Name

1
2
3

Terminal No.	Color of Wire	Signal Name
9	Y/R	-
10	O	-
11	W	-
12	L	-
13	L/R	-
14	P	-
15	L	-
16	B/W	-


Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-
3	L/Y	-
8	L/B	-

ABJIA0518GB



AUTOMATIC DRIVE POSITIONER

< WIRING DIAGRAM >


Connector No.	B200
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GW	-
2	LY	-
3	SB	-
8	W/B	-
9	G	-
10	R	-
11	Y/R	-
12	W	-
13	L	-
14	G	-
15	L/B	-
16	B	-



Terminal No.	Color of Wire	Signal Name
10	B/R	PULSE (REAR LIFTER)
11	Y/R	SLIDE SW (BACKWARD)
12	L/W	RECLINE SW (BACKWARD)
13	V	FRONT LIFTER SW (DOWNWARD)
14	P/L	REAR LIFTER SW (DOWNWARD)
15	SB	PEDAL SW (BACKWARD)
16	R/W	PEDAL SUPPLY (ENCODER)
17	Y/R	TX (UART)
18	—	—
19	G	CAN-L
20	—	—




ABJIA0519GE

AUTOMATIC DRIVE POSITIONER

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
33	W/B	BAT(PTC)
34	—	—
35	R/G	SLIDE MOTOR (FORWARD)
36	L	RECLINER MOTOR (FORWARD)
37	B	FRONT LIFTER MOTOR (DOWNWARD)
38	GR	REAR LIFTER MOTOR (UPWARD)
39	R	REAR LIFTER MOTOR (DOWNWARD)



Connector No.	B203
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
40	G	BAT (FUSE)	40	G	BAT
41	—	—	41	—	—
42	R/Y	SLIDE MOTOR (BACKWARD)	42	R/Y	SLIDE MOTOR (BACKWARD)
43	—	—	43	—	—
44	G/B	RECLINER MOTOR (BACKWARD)	44	G/B	RECLINER MOTOR (BACKWARD)
45	G/Y	FRONT LIFTER MOTOR (UPWARD)	45	G/Y	FRONT LIFTER MOTOR (UPWARD)
46	—	—	46	—	—
47	—	—	47	—	—
48	B	GND (POWER)	48	B	GND (POWER)




Terminal No.	Color of Wire	Signal Name
1	1	—
2	2	—
3	3	—
4	4	—
5	5	—

Connector No.	B205
Connector Name	RECLINING MOTOR LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	1	—
2	2	—
3	3	—
4	4	—
5	5	—

Connector No.	B204
Connector Name	SLIDING MOTOR LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	R/Y	—
2	GR/R	—
3	R/W	—
4	R/L	—
5	R/G	—

AUTOMATIC DRIVE POSITIONER


< WIRING DIAGRAM >

Connector No.	B207
Connector Name	LIFTING MOTOR (REAR)
Connector Color	GRAY





Terminal No.	Color of Wire	Signal Name
1	B	—
2	GR/R	—
3	R/W	—
4	Y/G	—
5	G/Y	—
8	—	—
9	V	—
10	BR/Y	—

Connector No.	B208
Connector Name	POWER SEAT SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y/R	—
2	P/L	—
3	L/W	—
4	V/W	—
5	L/R	—
6	GR/R	—
7	B/W	—
8	—	—
9	V	—
10	BR/Y	—

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE

ADP

K

M

Z

O

P

A

B

C

D

M

G

I

—

P

—


Terminal No.	Color of Wire	Signal Name
9	Y/B	—
10	V/W	—
11	GR	— (WITH AUTOMATIC DRIVE POSITIONER)
12	BR	—
13	G	—
14	O	—
15	W/G	—
16	L/Y	—
17	W/L	—
18	R	—
19	LG	—
20	Y/R	—
21	BR/W	—

ABJIA0521GB


AUTOMATIC DRIVE POSITIONER

< WIRING DIAGRAM >

Connector No.	D10
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH (WITH AUTOMATIC DRIVE POSITIONER)
Connector Color	BROWN




Connector No.	D5
Connector Name	SEAT MEMORY SWITCH
Connector Color	WHITE



Connector No.	D4
Connector Name	DOOR MIRROR LH (WITH AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE




Connector No.	D107
Connector Name	DOOR MIRROR RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R	—
2	BR	—
3	O	—
4	W/L	—
5	W/G	—
6	L/Y	—
7	G	—
8	Y/G	—
9	LG/B	SET 1
10	P/L	SET 2
11	G/O	SET SW
12	B	GND
13	Y/R	—
14	P	IND1
15	Y/G	IND2

Terminal No.	Color of Wire	Signal Name
4	GR	—
7	B	—
10	BR/W	—
11	LG	—
12	SB	—
13	V/W	—
15	Y/B	—

Connector No.	D107
Connector Name	DOOR MIRROR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	Y	— (WITH AUTOMATIC DRIVE POSITIONER)
9	R/B	— (WITH AUTOMATIC DRIVE POSITIONER)
13	W/G	—
14	W/L	—
15	V/R	—
16	L/W	—
20	GR/R	— (WITH AUTOMATIC DRIVE POSITIONER)



< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS**ADP SYSTEM SYMPTOMS****Symptom Table**

INFOID:000000006163589

NOTE:

Always perform the “Basic Inspection” before performing diagnosis in the following table. Refer to [ADP-4, “Work Flow”](#).

SYMPTOM 1

Symptom	Diagnosis procedure	Reference page
Manual functions (for specific part) do not operate	Sliding operation	ADP-50
	Reclining operation	ADP-53
	Lifting operation (front)	ADP-56
	Lifting operation (rear)	ADP-59
	Pedal operation	1. Check pedal adjusting switch.
		ADP-62
	Door mirror operation	2. Check pedal adjusting sensor.
		ADP-87
	All parts of seat	1. Changeover switch.
		ADP-67
		2. Mirror switch
		ADP-69
		Check power seat switch ground circuit.
		ADP-73

SYMPTOM 2

Symptom	Diagnosis procedure	Reference page
Memory functions (for specific part) do not operate	Sliding operation	ADP-79
	Reclining operation	ADP-81
	Lifting operation (front)	ADP-83
	Lifting operation (rear)	ADP-85
	Pedal operation	ADP-87
	Door mirror operation	Driver side: ADP-89 Passenger side: ADP-91

SYMPTOM 3

Symptom	Diagnosis procedure	Reference page
Memory functions and manual functions (for specific part) do not operate	Sliding operation	ADP-93
	Reclining operation	ADP-95
	Lifting operation (front)	ADP-97
	Lifting operation (rear)	ADP-99
	Pedal operation	ADP-101
	Door mirror operation	ADP-103

SYMPTOM 4

ADP SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

Symptom	Diagnosis procedure	Reference page
Entry/Exit assist function does not operate.	1. Check system setting.	ADP-11
	2. Perform initialization.	ADP-7
	3. Check front door switch (driver side).	ADP-77

SYMPTOM 5

Symptom	Diagnosis procedure	Reference page
Memory indicators 1 and/or 2 do not illuminate.	1. Check seat memory switch.	ADP-65
	2. Check seat memory indicator.	ADP-106

SYMPTOM 6

Symptom	Diagnosis procedure	Reference page
Memory operation does not operate.	Check A/T shift selector (park position switch).	ADP-74

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:0000000006163590

The following symptoms are normal operations, and they do not indicate a malfunction.

Symptom	Cause	Action to take	Reference page
Entry/Exit assist function does not operate.	No initialization has been performed.	Perform initialization.	ADP-7
	NOTE: The entry/exit assist function is disabled before delivery (initial setting).	Change the settings.	ADP-23
Entry assist function does not operate.	Manual operation with power seat switch was performed after exit assist function execution.	Perform the memory function.	ADP-23
Memory function, entry/exit assist function does not operate.	The operation conditions are not fulfilled.	Fulfill the operation conditions.	Memory function: ADP-17
			Exit assist function: ADP-21
			Entry assist function: ADP-23

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000006163591

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Work

INFOID:0000000006163592

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
 - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.
Then rub with a soft and dry cloth.
 - Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >



PREPARATION

PREPARATION

Special Service Tool


INFOID:000000006163593

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-39570) Chassis ear	 SIIA0993E Locating the noise
— (J-43980) NISSAN Squeak and Rattle Kit	 SIIA0994E Repairing the cause of noise
— (J-46534) Trim Tool Set	 AWJIA0483ZZ Removing trim components

Commercial Service Tool

INFOID:000000006163594

(Kent-Moore No.) Tool name	Description
(J-39565) Engine ear	 SIIA0995E Locating the noise

DRIVER SEAT CONTROL UNIT

< UNIT REMOVAL AND INSTALLATION >

UNIT REMOVAL AND INSTALLATION

DRIVER SEAT CONTROL UNIT

Removal and Installation

INFOID:000000006163595

The driver seat control unit is part of the driver seat. Remove the driver seat, then the driver seat control unit. Refer to [SE-30, "Removal and Installation For Front Seat".](#)

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

< UNIT REMOVAL AND INSTALLATION >

AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Removal and Installation


INFOID:0000000006163596

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

REMOVAL

1. Remove the instrument lower panel LH. Refer to [IP-17, "Removal and Installation"](#).
2. Remove the lower knee protector.
3. Remove the screw from the automatic drive positioner control unit (1).
4. Remove automatic drive positioner control unit (1) from bracket and disconnect electrical connectors.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Clamp the harness in position.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

SEAT MEMORY SWITCH

< UNIT REMOVAL AND INSTALLATION >

SEAT MEMORY SWITCH

Removal and Installation

INFOID:0000000006163597


REMOVAL

CAUTION:


When removing and installing, use shop cloths to protect parts from damage.

1. Remove the seat memory switch from the front door finisher by using Tool.

Tool Number : — (J-46534)



2. Disconnect the electrical connector from the seat memory switch.
3. Release the clips (1) and remove the seat memory switch from the finish panel.



INSTALLATION

Install in the reverse order of removal.

DOOR MIRROR REMOTE CONTROL SWITCH

< UNIT REMOVAL AND INSTALLATION >


DOOR MIRROR REMOTE CONTROL SWITCH

Removal and Installation

INFOID:0000000006163598

REMOVAL

1. Remove the main power window, door lock/unlock and door mirror remote control switch finisher from the front door finisher LH. Refer to [INT-10, "Removal and Installation"](#).
2. Disconnect the electrical connector (1), release the retaining tabs (2) and remove the door mirror remote control switch from the finisher panel.



INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

ADP

K

L

M

N

O

P

PEDAL ADJUSTING MOTOR

< UNIT REMOVAL AND INSTALLATION >

PEDAL ADJUSTING MOTOR

Removal and Installation

INFOID:0000000006163599

The pedal adjusting motor is serviced as a part of the accelerator pedal. Refer to [ACC-3, "Removal and Installation"](#) for accelerator pedal and [BR-19, "Removal and Installation"](#) for brake pedal when removing pedal adjusting motors.