

SECTION MA

MAINTENANCE

CONTENTS

PRECAUTION	3	FOR NORTH AMERICA : Engine Coolant Mixture Ratio	22
PRECAUTIONS	3	FOR MEXICO	22
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	FOR MEXICO : Fluids and Lubricants	22
		FOR MEXICO : SAE Viscosity Number	23
		FOR MEXICO : Engine Coolant Mixture Ratio	24
PREPARATION	4	ENGINE MAINTENANCE	26
PREPARATION	4	Checking Drive Belts	26
Special Service Tool	4	Changing Engine Coolant	26
Commercial Service Tool	4	Checking Fuel Line	29
PERIODIC MAINTENANCE	5	Changing Fuel Filter	29
GENERAL MAINTENANCE	5	Changing Engine Air Cleaner Filter	29
FOR NORTH AMERICA	5	Changing Engine Oil	30
FOR NORTH AMERICA : General Maintenance	5	Changing Oil Filter	30
FOR MEXICO	7	Changing Spark Plugs	31
FOR MEXICO : General Maintenance	7	Checking EVAP Vapor Line	33
PERIODIC MAINTENANCE	9	CHASSIS AND BODY MAINTENANCE	34
FOR NORTH AMERICA	9	IN-CABIN MICROFILTER	34
FOR NORTH AMERICA : Introduction of Periodic Maintenance	9	IN-CABIN MICROFILTER : Removal and Installation	34
FOR NORTH AMERICA : Schedule 1	9	EXHAUST SYSTEM	35
FOR NORTH AMERICA : Schedule 2	12	EXHAUST SYSTEM : Checking Exhaust System	35
FOR MEXICO	13	A/T FLUID	35
FOR MEXICO : Introduction of Periodic Maintenance	13	A/T FLUID : Checking the A/T Fluid (ATF)	35
RECOMMENDED FLUIDS AND LUBRICANTS	21	A/T FLUID : Changing the A/T Fluid (ATF)	37
FOR NORTH AMERICA	21	TRANSFER FLUID	38
FOR NORTH AMERICA : Fluids and Lubricants	21	TRANSFER FLUID : Checking Transfer Fluid	38
FOR NORTH AMERICA : Engine Oil Recommendation	22	TRANSFER FLUID : Changing Transfer Fluid	38
		PROPELLER SHAFT	39
		PROPELLER SHAFT : Checking Propeller Shaft	39
		FRONT DIFFERENTIAL GEAR OIL	39
		FRONT DIFFERENTIAL GEAR OIL : Checking Differential Gear Oil	39

FRONT DIFFERENTIAL GEAR OIL : Changing Differential Gear Oil	39	STEERING GEAR AND LINKAGE	44
REAR DIFFERENTIAL GEAR OIL	40	STEERING GEAR AND LINKAGE : Checking Steering Gear and Linkage	44
REAR DIFFERENTIAL GEAR OIL : Checking Differential Gear Oil	40	POWER STEERING FLUID AND LINES	44
REAR DIFFERENTIAL GEAR OIL : Changing Differential Gear Oil	40	POWER STEERING FLUID AND LINES : Checking Power Steering Fluid and Line	44
WHEELS	41	AXLE AND SUSPENSION PARTS	45
WHEELS : Adjustment	41	AXLE AND SUSPENSION PARTS : Checking Axle and Suspension Parts	45
BRAKE FLUID LEVEL AND LEAKS	43	LOCKS AND HINGES	45
BRAKE FLUID LEVEL AND LEAKS : Checking Brake Fluid Level and Leaks	43	LOCKS AND HINGES : Lubricating Locks, Hinges and Hood Latches	46
BRAKE LINES AND CABLES	43	SEAT BELT, BUCKLES, RETRACTORS, AN- CHORS AND ADJUSTERS	46
BRAKE LINES AND CABLES : Checking Brake Line and Cables	43	SEAT BELT, BUCKLES, RETRACTORS, AN-CHORS AND ADJUSTERS : Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters	46
DISC BRAKE	43	... 46	
DISC BRAKE : Checking Disc Brake	43		

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000006158413

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION

< PREPARATION >




PREPARATION

PREPARATION

Special Service Tool



INFOID:000000006158414

The actual shapes of the Kent-Moore tools may differ from those of the special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV10115801 (J-38956) Oil filter cap wrench	 <p>NT375</p> <p>Removing and installing oil filter a: 64.3 mm (2.531 in)</p>
KV991J0010 (J-23688) Engine coolant refractometer	 <p>WBIA0539E</p> <p>Checking concentration of ethylene glycol in engine coolant</p>
KV991J0070 (J-45695) Coolant refill tool	 <p>LMA053</p> <p>Filling cooling system</p>

Commercial Service Tool

INFOID:000000006158415

(Kent-Moore No.) Tool name	Description
Power tool	 <p>PBIC0190E</p> <p>Loosening bolts and nuts</p>
Spark plug wrench	 <p>S-NT047</p> <p>Removing and installing spark plug</p>

GENERAL MAINTENANCE

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

GENERAL MAINTENANCE FOR NORTH AMERICA

FOR NORTH AMERICA : General Maintenance

INFOID:0000000006158416

General maintenance includes those items which should be checked during the normal day-to-day operation of the vehicle. They are essential if the vehicle is to continue operating properly. The owner can perform the checks and inspections themselves or they can have their NISSAN dealers do them.

OUTSIDE THE VEHICLE

The maintenance items listed here should be performed from time to time, unless otherwise specified.

Item	Reference page
Tires	MA-41. "WHEELS : Adjustment"
Wheel lug nuts	MA-41. "WHEELS : Adjustment"
Windshield	GW-2. "Work Flow"
Tire rotation	WT-46. "Adjustment"
Tire Pressure Monitoring System (TPMS) transmitter components	WT-48. "Transmitter (Pressure Sensor)"
Wheel alignment and balance	WT-45. "Inspection", WT-46. "Adjustment"
Windshield wiper blades	WW-54. "Wiper Motor and Linkage"
Doors and engine hood	MA-46. "LOCKS AND HINGES : Lubricating Locks, Hinges and Hood Latches"
Lamps	EXL-137. "Aiming Adjustment"

INSIDE THE VEHICLE

The maintenance items listed here should be checked on a regular basis, such as when performing periodic maintenance, cleaning the vehicle, etc.

Item	Reference page
Warning lamps and chimes	WCS-3. "Work Flow"
Windshield wiper and washer	WW-3. "Work Flow"
Windshield defroster	—
Steering wheel	ST-5. "NVH Troubleshooting Chart"

GENERAL MAINTENANCE

< PERIODIC MAINTENANCE >

Item		Reference page
Seats	Check seat position controls such as seat adjusters, seatback recliner, etc. to make sure they operate smoothly and that all latches lock securely in every position. Check that the head restraints move up and down smoothly and that the locks (if equipped) hold securely in all latched positions. Check that the latches lock securely for folding-down rear seat backs.	SE-15, "Work Flow"
Seat belts	Check that all parts of the seat belt system (e.g. buckles, anchors, adjusters and retractors) operate properly and smoothly and are installed securely. Check the belt webbing for cuts, fraying, wear or damage.	MA-46, "SEAT BELT, BUCKLES, RETRACTORS, ANCHORS AND ADJUSTERS : Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters"
Accelerator pedal	Check the pedal for smooth operation and make sure the pedal does not catch or require uneven effort. Keep the floor mats away from the pedal.	—
Brakes	Check that the brake does not pull the vehicle to one side when applied.	—
Brake pedal and booster	Check the pedal for smooth operation and make sure it has the proper distance under it when depressed fully. Check the brake booster function. Keep the floor mats away from the pedal.	MA-43, "DISC BRAKE : Checking Disc Brake", MA-43, "BRAKE LINES AND CABLES : Checking Brake Line and Cables"
Parking brake	Check that the parking brake control has the proper travel and make sure that the vehicle is held securely on a fairly steep hill when only the parking brake is applied.	MA-43, "BRAKE LINES AND CABLES : Checking Brake Line and Cables"
Automatic transmission "Park" mechanism	Check that the lock release button on the shift selector operates properly and smoothly. On a fairly steep hill check that the vehicle is held securely with the shift selector in the P (Park) position without applying the brakes.	—

UNDER THE HOOD AND VEHICLE

The maintenance items listed here should be checked periodically (e.g. each time you check the engine oil or refuel).

Item		Reference page
Windshield washer fluid	Check that there is adequate fluid in the tank.	—
Engine coolant level	Check the coolant level when the engine is cold.	MA-22, "FOR NORTH AMERICA : Engine Coolant Mixture Ratio"
Radiator and hoses	Check the front of the radiator and clean off any dirt, insects, leaves, etc., that may have accumulated. Make sure the hoses have no cracks, deformation, deterioration or loose connections.	—
Brake fluid level	Make sure that the brake fluid level is between the "MAX" and "MIN" lines on the reservoir.	MA-43, "BRAKE FLUID LEVEL AND LEAKS : Checking Brake Fluid Level and Leaks"
Battery	Check the fluid level in each cell. It should be between the "MAX" and "MIN" lines. Vehicles operated in high temperatures or under severe conditions require frequent checks of the battery fluid level.	—
Engine drive belt	Make sure that no belt is frayed, worn, cracked or oily.	MA-26, "Checking Drive Belts"
Engine oil level	Check the level on the dipstick after parking the vehicle on a level spot and turning off the engine.	MA-22, "FOR NORTH AMERICA : Engine Oil Recommendation"
Power steering fluid level and lines	Check the level on the reservoir with the engine off. Check the lines for improper attachment, leaks, cracks, etc.	MA-44, "POWER STEERING FLUID AND LINES : Checking Power Steering Fluid and Line"

GENERAL MAINTENANCE

< PERIODIC MAINTENANCE >

Item		Reference page
Automatic transmission fluid level	Check the level on the dipstick after putting the shift selector in "P"(Park) with the engine idling.	MA-35, "A/T FLUID : Checking the A/T Fluid (ATF)"
Exhaust system	Make sure there are no loose supports, cracks or holes. If the sound of the exhaust seems unusual or there is a smell of exhaust fumes, immediately locate the trouble and correct it.	MA-35, "EXHAUST SYSTEM : Checking Exhaust System"
Underbody	The underbody is frequently exposed to corrosive substances such as those used on icy roads or to control dust. It is very important to remove these substances, otherwise rust will form on the floor pan, frame, fuel lines and around the exhaust system. At the end of winter, the underbody should be thoroughly flushed with plain water, being careful to clean those areas where mud and dirt can easily accumulate.	—
Fluid leaks	Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioner after use is normal. If you should notice any leaks or gasoline fumes are evident, check for the cause and correct it immediately.	—

FOR MEXICO

FOR MEXICO : General Maintenance

INFOID:000000006730832

General maintenance includes those items which should be checked during the normal day-to-day operation of the vehicle. They are essential if the vehicle is to continue operating properly. The owner can perform the checks and inspections themselves or they can have their NISSAN dealers do them.

OUTSIDE THE VEHICLE

The maintenance items listed here should be performed from time to time, unless otherwise specified.

Item		Reference page
Tires	Check the pressure with a gauge often and always prior to a long distance trip. Adjust the pressure in all tires, including the spare, to the pressure specified. Check carefully for damage, cuts or excessive wear.	MA-41, "WHEELS : Adjustment"
Tire rotation	Tires should be rotated every 10,000 km (6,000 miles) for 2WD models and every 5,000 km (3,000 miles) for 4WD models.	MA-41, "WHEELS : Adjustment"
Tire Pressure Monitoring System (TPMS) transmitter components	Replace the TPMS transmitter grommet seal, valve core and cap when the tires are replaced due to wear or age.	WT-48, "Transmitter (Pressure Sensor)"
Windshield wiper blades	Check for cracks or wear if they do not wipe properly.	WW-53, "Front Wiper Arms"
Doors and engine hood	Check that all doors and the engine hood operate smoothly as well as the back tail gate. Also make sure that all latches lock securely. Lubricate if necessary. Make sure that the secondary latch keeps the engine hood from opening when the primary latch is released. When driving in areas using road salt or other corrosive materials, check lubrication frequently.	MA-46, "LOCKS AND HINGES : Lubricating Locks, Hinges and Hood Latches"

INSIDE THE VEHICLE

The maintenance items listed here should be checked on a regular basis, such as when performing periodic maintenance, cleaning the vehicle, etc.

Item		Reference page
Lamps	Make sure that the headlamps, stop lamps, tail lamps, turn signal lamps, and other lamps are all operating properly and installed securely. Also check head lamp aim. Clean the head lamps on a regular basis.	EXL-137, "Aiming Adjustment"
Warning lamps and chimes	Make sure that all warning lamps and chimes are operating properly.	WCS-5, "WARNING CHIME SYSTEM : Component Parts Location"

GENERAL MAINTENANCE

< PERIODIC MAINTENANCE >

Item		Reference page
Steering wheel	Check that it has the specified play. Be sure to check for changes in the steering condition, such as excessive play, hard steering or strange noises. Free play: Less than 35 mm (1.38 in.)	MA-44, "STEERING GEAR AND LINKAGE : Checking Steering Gear and Linkage"
Seat belts	Check that all parts of the seat belt system (e.g. buckles, anchors, adjusters and retractors) operate properly and smoothly and are installed securely. Check the belt webbing for cuts, fraying, wear or damage.	MA-46, "SEAT BELT, BUCKLES, RETRACTORS, ANCHORS AND ADJUSTERS : Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters"

UNDER THE HOOD AND VEHICLE

The maintenance items listed here should be checked periodically (e.g. each time you check the engine oil or refuel).

Item		Reference page
Windshield washer fluid	Check that there is adequate fluid in the tank.	—
Engine coolant level	Check the coolant level when the engine is cold.	MA-24, "FOR MEXICO : Engine Coolant Mixture Ratio"
Brake fluid level	Make sure that the brake fluid level is between the "MAX" and "MIN" lines on the reservoir.	MA-43, "BRAKE FLUID LEVEL AND LEAKS : Checking Brake Fluid Level and Leaks"
Battery	Check the fluid level in each cell. It should be between the "MAX" and "MIN" lines. Vehicles operated in high temperatures or under severe conditions require frequent checks of the battery fluid level.	—
Engine oil level	Check the level on the dipstick after parking the vehicle on a level spot and turning off the engine.	MA-22, "FOR MEXICO : Fluids and Lubricants"

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE FOR NORTH AMERICA

FOR NORTH AMERICA : Introduction of Periodic Maintenance

INFOID:000000006158417

Two different maintenance schedules are provided, and should be used, depending upon the conditions in which the vehicle is mainly operated. **After 60,000 miles (96,000 km) or 48 months, continue the periodic maintenance at the same mileage or time intervals, whichever comes first.**

Schedule 1	Follow Periodic Maintenance Schedule 1 if your driving habits frequently includes one or more of the following driving conditions: <ul style="list-style-type: none">Repeated short trips of less than 5 miles (8 km).Repeated short trips of less than 10 miles (16 km) with outside temperatures remaining below freezing.Operating in hot weather in stop-and-go "rush hour" traffic.Extensive idling and/or low speed driving for long distances, such as police, taxi or door-to-door delivery use.Driving in dusty conditions.Driving on rough, muddy, or salt spread roads.Towing a trailer or using a camper or car-top carrier.	Emission Control System Maintenance	MA-9
		Chassis and Body Maintenance	MA-9
Schedule 2	Follow Periodic Maintenance Schedule 2 if none of the driving conditions shown in Schedule 1 apply to the driving habits.	Emission Control System Maintenance	MA-12
		Chassis and Body Maintenance	MA-12

Maintenance for off-road driving (4WD only)

After driving the vehicle off-road through sand, mud, or water; more frequent maintenance may be required for the following items:

- ▲ Brake pads and rotors
- ▲ Brake lines and hoses
- ▲ Differential, transfer gear oil and automatic transmission fluid
- ▲ Steering linkage
- ▲ Drive shafts
- ▲ Engine air cleaner filter

FOR NORTH AMERICA : Schedule 1

INFOID:000000006158418

EMISSION CONTROL SYSTEM MAINTENANCE

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. []: At the mileage intervals only

MAINTENANCE OPERATION	Miles x 1,000 (km x 1,000) Months	3.75 (6) 3	7.50 (12) 6	11.25 (18) 9	15 (24) 12	18.75 (30) 15	22.5 (36) 18	26.25 (42) 21	30 (48) 24	Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.										
Drive belts	NOTE (1)									EM-13
Air cleaner filter	NOTE (2)								[R]	MA-29
EVAP vapor lines									I*	MA-33
Fuel lines									I*	FL-5
Fuel filter	NOTE (3)									MA-29
Engine coolant*	NOTE (4)									CO-10
Engine oil		R	R	R	R	R	R	R	R	LU-9
Engine oil filter		R	R	R	R	R	R	R	R	MA-30
Spark plugs (Iridium -tipped type)										MA-31
Intake and exhaust valve clearance*	NOTE (5)									EM-114

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

MAINTENANCE OPERATION		MAINTENANCE INTERVAL									Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	33.75 (54) 27	37.5 (60) 30	41.25 (66) 33	45 (72) 36	48.75 (78) 39	52.5 (84) 42	56.25 (90) 45	60 (96) 48		
Drive belts	NOTE (1)									I*	EM-13
Air cleaner filter	NOTE (2)									[R]	MA-29
EVAP vapor lines										I*	MA-33
Fuel lines										I*	FL-5
Fuel filter	NOTE (3)										MA-29
Engine coolant*	NOTE (4)										CO-11
Engine oil		R	R	R	R	R	R	R	R		LU-9
Engine oil filter		R	R	R	R	R	R	R	R		MA-30
Spark plugs (Iridium-tipped type)		Replace every 105,000 miles (168,000 km).									MA-31
Intake and exhaust valve clearance*	NOTE (5)										EM-114

(1) After 60,000 miles (96,000 km) or 48 months, inspect every 15,000 miles (24,000 km) or 12 months. Replace the drive belts if found damaged or if the auto belt tensioner reading reaches the maximum limit.

(2) If operating mainly in dusty conditions, more frequent maintenance may be required.

(3) Maintenance-free item. For service procedures, refer to the FL section.

(4) First replacement interval is 105,000 miles (168,000 km) or 84 months. After first replacement, replace every 75,000 miles (120,000 km) or 60 months. Use only Genuine NISSAN Long Life Antifreeze / Coolant (blue) or equivalent with the proper mixture ratio of 50% anti-freeze and 50% demineralized or distilled water. Mixing any other type of coolant or the use of non-distilled water will reduce the life expectancy of the factory-fill coolant.

(5) Periodic maintenance is not required. However, if valve noise increases, inspect valve clearance.

* Maintenance items and intervals with "*" are recommended by NISSAN for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

CHASSIS AND BODY MAINTENANCE

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary.

MAINTENANCE OPERATION		MAINTENANCE INTERVAL									Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	3.75 (6) 3	7.5 (12) 6	11.25 (18) 9	15 (24) 12	18.75 (30) 15	22.5 (36) 18	26.25 (42) 21	30 (48) 24		
Brake fluid										R	MA-43
Brake lines and cables					I					I	MA-43
Brake pads and rotors			I		I		I			I	MA-43
Automatic transmission fluid, transfer fluid and differential gear oil	NOTE (1)				I					I	TM-168, DLN-91 DLN-164, DLN-194, DLN-252
Steering gear and linkage, axle and suspension parts			I		I		I			I	MA-44, MA-45
Tire rotation	NOTE (2)										WT-46, "Adjustment"
Drive shaft boots and propeller shaft (4WD)			I		I		I			I	MA-39

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

MAINTENANCE OPERATION		MAINTENANCE INTERVAL									Reference Section - Page or - Content Title	
		Miles x 1,000 (km x 1,000) Months	3.75 (6) 3	7.5 (12) 6	11.25 (18) 9	15 (24) 12	18.75 (30) 15	22.5 (36) 18	26.25 (42) 21	30 (48) 24		
Perform at number of miles, kilometers or months, whichever comes first.												
Exhaust system			I		I		I		I		EX-4	
In-cabin microfilter					R					R		MA-34, "IN-CABIN MICROFILTER : Removal and Installation"
MAINTENANCE OPERATION		MAINTENANCE INTERVAL									Reference Section - Page or - Content Title	
		Miles x 1,000 (km x 1,000) Months	33.75 (54) 27	37.5 (60) 30	41.25 (66) 33	45 (72) 36	48.75 (78) 39	52.5 (84) 42	56.25 (90) 45	60 (96) 48		
Perform at number of miles, kilometers or months, whichever comes first.												
Brake fluid										R	MA-43	
Brake lines and cables					I					I	MA-43	
Brake pads and rotors			I		I		I		I	I	MA-43	
Automatic transmission fluid, transfer fluid and differential gear oil	NOTE (1)					I				I		MA-35, "A/T FLUID : Checking the A/T Fluid (ATF)", MA-39, "FRONT DIFFERENTIAL GEAR OIL : Checking Differential Gear Oil", MA-40, "REAR DIFFERENTIAL GEAR OIL : Checking Differential Gear Oil"
Steering gear and linkage, axle and suspension parts			I		I		I		I	I	MA-44, MA-45	
Tire rotation	NOTE (2)										WT-46	
Drive shaft boots and propeller shaft (4WD)			I		I		I		I	I	MA-39	
Exhaust system			I		I		I		I	I	EX-4	
In-cabin microfilter					R					R		MA-34, "IN-CABIN MICROFILTER : Removal and Installation"

(1) If towing a trailer, or using a camper or car-top carrier, or driving on rough or muddy roads, change (not just inspect) oil/fluid at every 30,000 miles (48,000 km) or 24 months. **Using automatic transmission fluid other than Genuine NISSAN Matic S ATF or Matic J**

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

ATF will cause deterioration in driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the NISSAN new vehicle limited warranty.

(2) Refer to "Tire rotation" under the "General maintenance" heading earlier in this section.

FOR NORTH AMERICA : Schedule 2

INFOID:000000006158419

EMISSION CONTROL SYSTEM MAINTENANCE

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. []: At the mileage intervals only

MAINTENANCE OPERATION		MAINTENANCE INTERVAL									Reference Section - Page or - Content Ti- tle
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	7.5 (12) 6	15 (24) 12	22.5 (36) 18	30 (48) 24	37.5 (60) 30	45 (72) 36	52.5 (84) 42	60 (96) 48		
Drive belts	NOTE (1)									I*	MA-26. "Checking Drive Belts"
Air cleaner filter					[R]					[R]	MA-29
EVAP vapor lines					I*					I*	MA-33
Fuel lines					I*					I*	MA-29
Fuel filter	NOTE (2)										MA-29
Engine coolant*	NOTE (3)										MA-26. "Changing En- gine Coolant"
Engine oil (Except FFV models)		R	R	R	R	R	R	R	R	R	MA-30
Engine oil (For FFV models)		Replace every 3,750 miles (6,000 km) or 3 months.									LU-9
Engine oil filter (Except FFV models)		R	R	R	R	R	R	R	R	R	MA-30
Engine oil filter (For FFV models)		Replace every 3,750 miles (6,000 km) or 3 months.									MA-30
Spark plugs (iridium-tipped type)		Replace every 105,000 miles (168,000 km).									MA-31
Intake and exhaust valve clearance*	NOTE (4)										EM-114. "Stan- dard and Limit"

(1) After 60,000 miles (96,000 km) or 48 months, inspect every 15,000 miles (24,000 km) or 12 months. Replace the drive belts if found damaged or if the auto belt tensioner reading reaches the maximum limit.

(2) Maintenance-free item. For service procedures, refer to FL section.

(3) First replacement interval is 105,000 miles (168,000 km) or 84 months. After first replacement, replace every 75,000 miles (120,000 km) or 60 months. Use only Genuine NISSAN Long Life Antifreeze / Coolant (blue) or equivalent with proper mixture ratio 50% antifreeze and 50% demineralized or distilled water. Mixing any other type of coolant or the use of non-distilled water will reduce the life expectancy of the factory-fill coolant.

(4) Periodic maintenance is not required. However, if valve noise increases, inspect valve clearance.

* Maintenance items and intervals with "*" are recommended by NISSAN for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

CHASSIS AND BODY MAINTENANCE

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary.

MAINTENANCE OPERATION		MAINTENANCE INTERVAL									Reference Section - Page or - Content Title
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months	7.5 (12) 6	15 (24) 12	22.5 (36) 18	30 (48) 24	37.5 (60) 30	45 (72) 36	52.5 (84) 42	60 (96) 48		
Brake fluid					R					R	MA-43
Brake lines and cables			I		I		I		I	I	MA-43
Brake pads and rotors			I		I		I		I	I	MA-43

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

MAINTENANCE OPERATION		MAINTENANCE INTERVAL									Reference Section - Page or - Content Title
	Miles x 1,000 (km x 1,000) Months	7.5 (12) 6	15 (24) 12	22.5 (36) 18	30 (48) 24	37.5 (60) 30	45 (72) 36	52.5 (84) 42	60 (96) 48		
Perform at number of miles, kilometers or months, whichever comes first.											
Automatic transmission fluid, transfer fluid and differential gear oil	NOTE (1)		I		I		I		I		MA-35, "A/T FLUID : Checking the A/T Fluid (ATF)" , MA-39, "FRONT DIFFERENTIAL GEAR OIL : Checking Differential Gear Oil" , MA-40, "REAR DIFFERENTIAL GEAR OIL : Checking Differential Gear Oil"
Steering gear and linkage, axle and suspension parts.				I					I		MA-44, MA-45
Tire rotation	NOTE (2)										WT-46
Drive shaft boots and propeller shaft (4WD)			I		I		I		I		MA-39
Exhaust system				I					I		EX-4
In-cabin microfilter			R		R		R		R		MA-34, "IN-CABIN MICROFILTER : Removal and Installation"

(1) Using automatic transmission fluid other than Genuine NISSAN Matic S ATF or Matic J ATF will cause deterioration in drivability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the NISSAN new vehicle limited warranty.

(2) Refer to "Tire rotation" under the "General maintenance" heading earlier in this section.

FOR MEXICO

FOR MEXICO : Introduction of Periodic Maintenance

INFOID:0000000006731015

The following tables show the normal maintenance schedule. Depending upon weather and atmospheric conditions, varying road surfaces, individual driving habits and vehicle usage, additional or more frequent maintenance may be required.

Periodic maintenance beyond the last period shown on the tables requires similar maintenance.

ENGINE AND EMISSION CONTROL MAINTENANCE

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

MA

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

Abbreviations: I = Inspect and correct or replace as necessary, R = Replace, E = Check and correct the engine coolant mixture ratio

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference page
km x 1,000 (Miles x 1,000) Months	10 (6) 6	20 (12) 12	30 (18) 18	40 (24) 24	50 (30) 30	60 (36) 36	70 (42) 42	80 (48) 48		
Engine compartment and under vehicle										
Intake & exhaust valve clearance	See NOTE (1)									EM-114, "Standard and Limit"
Drive belts	See NOTE (2)			I					I	MA-26, "Checking Drive Belts"
Engine oil (Use recommended oil.)★		R	R	R	R	R	R	R	R	MA-30, "Changing En- gine Oil"
Engine oil filter (Use Genuine NISSAN engine oil filter or equivalent.)★		R	R	R	R	R	R	R	R	MA-30, "Changing Oil Filter"
Engine coolant (Use Genuine NISSAN Engine Coolant or equivalent in its quality.)	See NOTE (3)			E					R	MA-26, "Changing En- gine Coolant"
Cooling system				I					I	MA-26, "Changing En- gine Coolant"
Fuel lines				I					I	MA-29, "Check- ing Fuel Line"
Air cleaner filter (Viscous paper type)				R					R	MA-29, "Change- ing En- gine Air Cleaner Filter"
Fuel filter	See NOTE (4)									—
Spark plugs (Iridium-tipped type)		Replace every 100,000 km (60,000 miles)								MA-31, "Change- ing Spark Plugs"
EVAP vapor lines				I					I	MA-33, "Check- ing EVAP Vapor Line"

(1) Periodic maintenance is not required. However, if valve noise increases, check valve clearance.

(2) Replace the drive belts if found damaged or if the auto belt tensioner reading reaches the maximum limit.

(3) Use Genuine NISSAN Engine Coolant or equivalent in its quality, in order to avoid possible aluminum corrosion within the engine cooling system caused by the use of non-genuine engine coolant. After first replacement, replace every 40,000 km (24,000 miles) or 24 months.

(4) Fuel filter is maintenance-free. For service procedures, refer to FL section.

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

NOTE:

- ★ Maintenance items with “★” should be performed more frequently according to “Maintenance Under Severe Driving Conditions”.

CHASSIS AND BODY MAINTENANCE

Abbreviations: I = Inspect and correct or replace as necessary, R = Replace, L=Lubricate

MAINTENANCE OPERATION	km x 1,000 (Miles x 1,000) Months	MAINTENANCE INTERVAL								Reference page
		10 (6) 6	20 (12) 12	30 (18) 18	40 (24) 24	50 (30) 30	60 (36) 36	70 (42) 42	80 (48) 48	
Underhood and under vehicle										
Brake and automatic transmission fluid (For level & leaks)★		I		I		I		I		MA-43. "BRAKE FLUID LEVEL AND LEAKS : Check- ing Brake Fluid Level and Leaks". MA-35. "A/T FLUID : Check- ing the A/T Flu- id (ATF)"
Brake fluid★					R				R	MA-44. "POW- ER STEER- ING FLUID AND LINES : Check- ing Pow- er Steering Fluid and Line"
Power steering fluid & lines (For level & leaks)		I	I	I	I	I	I	I	I	MA-44. "STEER- ING GEAR AND LINK- AGE : Check- ing Steering Gear and Link- age"

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Refer- ence page
km x 1,000 (Miles x 1,000) Months	10 (6) 6	20 (12) 12	30 (18) 18	40 (24) 24	50 (30) 30	60 (36) 36	70 (42) 42	80 (48) 48		
Perform either at number of kilometers (miles) or months, whichever comes first.										
Brake line & cable										MA-43, "BRAKE LINES AND CA- BLES : Check- ing Brake Line and Cables"
Exhaust system										MA-35, "EX- HAUST SYS- TEM : Check- ing Ex- haust System"
Transfer gear fluid (For level & leaks)										MA-38, "TRANS- FER FLUID : Check- ing Transfer Fluid"
Differential gear oil (For level & leaks)★										MA-40, "REAR DIFFER- ENTIAL GEAR OIL : Check- ing Dif- ferential Gear Oil", MA- 39, "FRONT DIFFER- ENTIAL GEAR OIL : Check- ing Dif- ferential Gear Oil"

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference page
km x 1,000 (Miles x 1,000) Months	10 (6) 6	20 (12) 12	30 (18) 18	40 (24) 24	50 (30) 30	60 (36) 36	70 (42) 42	80 (48) 48		
Perform either at number of kilometers (miles) or months, whichever comes first.										MA-44. "STEER- ING GEAR AND LINK- AGE : Check- ing Steering Gear and Link- age"
Steering gear & linkage, axle & suspension parts★				I					I	
Outside and inside										
Propeller shaft & drive shafts★			I	I		I		I		MA-39. "PRO- PELLER SHAFT : Check- ing Pro- peller Shaft", MA-45. "AXLE AND SUS- PEN- SION PARTS : Check- ing Axle and Sus- pension Parts"
Wheel alignment (If necessary, rotate & balance wheels)			I	I		I		I		MA-41. "WHEEL S : Ad- just- ment"
Brake pads, rotors, drums & linings★			I	I		I		I		MA-43. "DISC BRAKE : Check- ing Disc Brake"

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
MA

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference page	
Perform either at number of kilometers (Miles x 1,000) or months, whichever comes first.		km x 1,000 (Miles x 1,000) Months	10 (6) 6	20 (12) 12	30 (18) 18	40 (24) 24	50 (30) 30	60 (36) 36	70 (42) 42	80 (48) 48	
Foot brake & parking brake (For free play, stroke & operation)			I	I	I	I	I	I	I	I	MA-43, "BRAKE LINES AND CABLES : Checking Brake Line and Cables"
Air conditioner filter★				R		R		R		R	MA-34, "IN-CAB-IN MICROFILTER : Removal and Installation"

NOTE:

★ Maintenance items with "★" should be performed more frequently according to "Maintenance Under Severe Driving Conditions".

MAINTENANCE UNDER SEVERE DRIVING CONDITIONS

The maintenance intervals shown on the preceding pages are for normal operating conditions. If the vehicle is mainly operated under severe driving conditions as shown below, more frequent maintenance must be performed on the following items as shown in the table.

Severe driving conditions

- A — Driving in dusty conditions
- B — Repeatedly driving short distances
- C — Towing a trailer or caravan
- D — Extensive idling
- E — Driving in extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high
- F — Driving in high humidity or mountainous areas
- G — Driving in areas using salt or other corrosive materials
- H — Driving on rough and/or muddy roads or in the desert
- I — Driving with frequent use of braking or in mountainous areas

Maintenance operation: Inspect = Check and correct or replace as necessary.

Driving condition										Maintenance item	Maintenance operation	Maintenance interval	Reference page	
A											Air cleaner filter	Replace	More frequently	MA-34, "IN-CAB-IN MICROFILTER : Removal and Installation"
A B C D											Engine oil & engine oil filter	Replace	Every 5,000 km (3,000 miles) or 3 months	MA-30, "Changing Engine Oil", MA-30, "Changing Oil Filter"

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

Revision: August 2010

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

A	.	C	.	.	G	H	I	Brake pads, drums & linings	Inspect	Every 5,000 km (3,000 miles) or 3 months	MA-43_ "DISC BRAKE : Checking Disc Brake"
A	Air conditioner filter	Replace	More frequently	MA-34_ "IN-CAB IN MICRO FILTER : Removal and Installation"

Maintenance for off-road driving (4WD only)

Whenever you drive off-road through sand, mud or water, more frequent maintenance may be required of the following items.

- Brake pads and rotors
- Brake lines and hoses
- Differential gear oil, transfer fluid and automatic transmission fluid
- Steering linkage
- Propeller shafts and front drive shafts
- Air cleaner filter

RECOMMENDED FLUIDS AND LUBRICANTS

< PERIODIC MAINTENANCE >

RECOMMENDED FLUIDS AND LUBRICANTS FOR NORTH AMERICA

FOR NORTH AMERICA : Fluids and Lubricants

INFOID:000000006748436

Description		Capacity (Approximate)			Recommended Fluids/Lubricants
		Metric	US measure	Imp measure	
Windshield Washer Fluid	4.5 ℥	1 1/4 gal	1 gal		Genuine NISSAN Windshield Washer Concentrate & Antifreeze or equivalent
Fuel	105.8 ℥	28 gal	23 1/4 gal		Unleaded gasoline with an octane rating of at least 87 AKI (RON 91), or E-85 Ethanol fuel for Flexible Fuel Vehicles (FFV) *7
Engine oil Drain and refill	With oil filter change	6.5 ℥	6 7/8 qt	5 3/4 qt	<ul style="list-style-type: none"> • Engine oil with API Certification Mark*1 • Viscosity SAE 5W-30
	Without oil filter change	6.2 ℥	6 1/2 qt	5 1/2 qt	
Dry engine (engine overhaul)	7.6 ℥	8 qt	6 3/4 qt		
Cooling system	With reservoir at MAX level	12.2 ℥	12 7/8 qt	10 3/4 qt	Genuine NISSAN Long Life Anti-freeze coolant (blue) or equivalent
Automatic transmission fluid (ATF)	10.6 ℥	11 1/4 qt	9 3/8 qt		Genuine NISSAN Matic S ATF*2
Rear differential gear oil	2.01 ℥	4 1/4 pt	3 1/2 pt		Genuine NISSAN differential oil synthetic 75W-140 or API GL-5 synthetic gear oil, Viscosity SAE 75W-140 *6
Transfer fluid	2.0 ℥	2 1/8 qt	1 3/4 qt		Genuine NISSAN Matic D ATF (Continental U.S and Alaska) or Canada NISSAN Automatic Transmission Fluid or equivalent (if available)*9
Front differential gear oil	1.6 ℥	3 3/8 pt	2 7/8 pt		Genuine NISSAN Differential Oil Hypoid Super GL-5 80W-90 or API GL-5 Viscosity SAE 80W-90 *8
Power steering fluid (PSF)	1.0 ℥	1 1/8 qt	7/8 qt		Genuine NISSAN PSF or equivalent*3
Brake fluid	—	—	—		Genuine NISSAN Super Heavy Duty Brake Fluid*4 or equivalent, DOT 3 (US FMVSS No. 116)
Multi-purpose grease	—	—	—		NLGI No. 2 (lithium soap base)
Windshield washer fluid	4.5 ℥	4 3/4 qt	4 qt		Genuine NISSAN Windshield Washer Concentrate Cleaner & Anti-freeze or equivalent
Air conditioning system refrigerant	0.70 ± 0.05 kg	1.54 ± 0.11 lb	1.54 ± 0.11 lb		HFC-134a (R-134a)*5
Air conditioning system oil	200 mℓ	6.8 fl oz	7.0 fl oz		A/C System Oil Type S (DH-PS) *5

*1: For further details, refer to [MA-22, "FOR NORTH AMERICA : Engine Oil Recommendation"](#).

*2: If Genuine NISSAN Matic S ATF is not available, Genuine Matic J ATF may also be used. Using automatic transmission fluid other than Genuine NISSAN Matic S ATF or Matic J ATF will cause deterioration in driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the NISSAN new vehicle limited warranty.

*3: DEXRON™ VI type ATF may also be used.

*4: Available in mainland U.S.A. through a NISSAN dealer.

*5: For further details, see "Air conditioner specification label".

*6: See a NISSAN dealer for service for synthetic oil.

*7: For further details, refer to [GI-28, "Precaution for Fuel \(Unleaded Regular Gasoline Recommended\)"](#).

*8: For hot climates, Viscosity SAE 90 is suitable for ambient temperatures above 0°C (32°F).

*9: Using fluid other than Genuine NISSAN Matic D ATF will cause deterioration in driveability and transfer durability, and may damage the transfer, which is not covered by the NISSAN new vehicle limited warranty.


RECOMMENDED FLUIDS AND LUBRICANTS

< PERIODIC MAINTENANCE >

FOR NORTH AMERICA : Engine Oil Recommendation

INFOID:0000000006748437

NISSAN recommends the use of an energy conserving oil in order to improve fuel economy. Select only engine oils that meet the American Petroleum Institute (API) certification and International Lubricant Standardization and Approval Committee (ILSAC) certification and SAE viscosity standard (2). These oils have the API certification mark (1) on the front of the container. Oils which do not have the specified quality label should not be used as they could cause engine damage.



ALPIA0001ZZ

FOR NORTH AMERICA : Engine Coolant Mixture Ratio

INFOID:0000000006750395

MIXTURE RATIO

The engine cooling system is filled at the factory with a high-quality, year-round, anti-freeze coolant solution. The anti-freeze solution contains rust and corrosion inhibitors. Therefore, additional cooling system additives are not necessary.

		Anti-freeze coolant mixture ratio	
Protection for outside temperature down to:		Genuine NISSAN Engine Coolant or equivalent	Demineralized water or distilled water
°C	°F		
-35°	-30°	50%	50%

CAUTION:

- When adding or replacing coolant, be sure to use only genuine NISSAN Engine Coolant (blue) or equivalent in quality with the proper mixture ratio as specified.
- Mixing any other type of coolant or the use of non-distilled water will reduce the life expectancy of the factory-fill coolant.

FOR MEXICO

FOR MEXICO : Fluids and Lubricants

INFOID:0000000006748439

Description	Capacity (Approximate)			Recommended Fluids/Lubricants
	Metric	US measure	Imp measure	
Windshield Washer Fluid	4.5 ℥	1 1/4 gal	1 gal	Genuine NISSAN Windshield Washer Fluid or equivalent
Fuel	105.8 ℥	28 gal	23 1/4 gal	Unleaded gasoline with an octane rating of at least 87 AKI (RON 91)

RECOMMENDED FLUIDS AND LUBRICANTS

< PERIODIC MAINTENANCE >

Description		Capacity (Approximate)			Recommended Fluids/Lubricants
		Metric	US measure	Imp measure	
Engine oil Drain and refill	With oil filter change	6.5 ℥	6 7/8 qt	5 3/4 qt	<ul style="list-style-type: none"> • Genuine NISSAN engine oil *1 • API grade SL or SM *1 • ILSAC grade GF-2, GF-3 or GF-4 *1 • Viscosity SAE 10W-30 *1
	Without oil filter change	6.2 ℥	6 1/2 qt	5 1/2 qt	
Dry engine (engine overhaul)		7.6 ℥	8 qt	6 3/4 qt	
Cooling system	With reservoir at MAX level	12.2 ℥	12 7/8 qt	10 3/4 qt	Genuine NISSAN Engine Coolant or equivalent in its quality*2
Automatic transmission fluid (ATF)		10.6 ℥	11 1/4 qt	9 3/8 qt	Genuine NISSAN Matic S ATF*3
Rear differential gear oil		2.01 ℥	4 1/4 pt	3 1/2 pt	API GL-5 Synthetic gear oil, Viscosity SAE 75W-140 or equivalent *4
Transfer fluid		2.0 ℥	2 1/8 qt	1 3/4 qt	Genuine NISSAN Matic D ATF recommended *5
Front differential gear oil		1.6 ℥	3 3/8 pt	2 7/8 pt	Genuine NISSAN Differential Oil Hypoid Super GL-5 80W-90 or API GL-5 *1
Power steering fluid (PSF)		1.0 ℥	1 1/8 qt	7/8 qt	Genuine NISSAN PSF or equivalent *6
Brake fluid		—	—	—	Genuine NISSAN Brake Fluid, or equivalent DOT 3 (US FMVSS No. 116)
Multi-purpose grease		—	—	—	NLGI No. 2 (lithium soap base)
Windshield washer fluid		4.5 ℥	4 3/4 qt	4 qt	Windshield washer fluid
Air conditioning system refrigerant		0.70 ± 0.05 kg	1.54 ± 0.11 lb	1.54 ± 0.11 lb	HFC-134a (R-134a) *7
Air conditioning system oil		200 m ℥	6.8 fl oz	7.0 fl oz	A/C System Oil Type S (DH-PS) *7

*1: For further details, refer to [MA-23, "FOR MEXICO : SAE Viscosity Number"](#).

*2: Use Genuine NISSAN Engine Coolant or equivalent in its quality, in order to avoid possible aluminium corrosion within the engine cooling system caused by the use of non-genuine engine coolant. Note that any repairs for the incidents within the engine cooling system while using non-genuine engine coolant may not be covered by the warranty even if such incidents occurred during the warranty period.

*3: If Genuine NISSAN Matic S ATF is not available, Genuine NISSAN Matic J ATF may also be used. Using automatic transmission fluid other than Genuine NISSAN Matic S ATF or Matic J ATF will cause deterioration in driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the warranty

*4: See a NISSAN dealer for service for synthetic oil.

*5: Using fluid other than Genuine NISSAN Matic D ATF will cause deterioration in driveability and transfer durability, and may damage the transfer, which is not covered by the warranty.

*6: DEXRON™ VI type ATF may also be used.

*7: For further details, see "Air conditioner specification label".

FOR MEXICO : SAE Viscosity Number

INFOID:000000006748440


GASOLINE ENGINE OIL

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
MA

RECOMMENDED FLUIDS AND LUBRICANTS


< PERIODIC MAINTENANCE >

- 10W-30 is preferable.
5W-30 is also preferable and will improve fuel economy.
If 10W-30 or 5W-30 is not available, select the viscosity from the chart, that is suitable for the outside temperature range.



DIFFERENTIAL GEAR OIL

- 80W-90 for the front differential gear is preferable.



FOR MEXICO : Engine Coolant Mixture Ratio

INFOID:000000006751591

MIXTURE RATIO

The engine cooling system is filled at the factory with a high-quality, year-round, anti-freeze coolant solution. The anti-freeze solution contains rust and corrosion inhibitors. Therefore, additional cooling system additives are not necessary.

Protection for outside temperature down to:	Genuine NISSAN Engine Coolant or equivalent	Demineralized water or distilled water
°C	°F	

RECOMMENDED FLUIDS AND LUBRICANTS

< PERIODIC MAINTENANCE >

-15°	5°	30%	70%
-35°	-30°	50%	50%

CAUTION:

- When adding or replacing coolant, be sure to use only genuine NISSAN Engine Coolant or equivalent in quality with the proper mixture ratio as specified.
- Other types of coolant solutions may damage your cooling system.

When checking the engine coolant mixture ratio with the coolant hydrometer, use the chart below to correct the hydrometer reading (specific gravity) according to the coolant temperature as shown in the table.

Mixed Coolant Specific Gravity

Engine coolant mixture ratio	Coolant temperature °C (°F)			
	15° (59°)	25° (77°)	35° (95°)	45° (113°)
	Specific gravity			
30%	1.046 - 1.050	1.042 - 1.046	1.038 - 1.042	1.033 - 1.038
50%	1.076 - 1.080	1.070 - 1.076	1.065 - 1.071	1.059 - 1.065

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator. Wait until the engine and radiator cool down.


ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >

ENGINE MAINTENANCE

Checking Drive Belts

INFOID:0000000006751594



LBIA0391E

1. Drive belt	2. Power steering pump pulley	3. Generator pulley
4. Crankshaft pulley	5. A/C compressor	6. Idler pulley
7. Cooling fan pulley	8. Water pump pulley	9. Drive belt auto tensioner
A. Allowable working range		

WARNING:

Be sure to perform when the engine is stopped.

1. Remove air duct and resonator assembly when inspecting drive belt.
2. Make sure that indicator (single line notch) of each auto tensioner is within the allowable working range (between three line notches).
NOTE:
 - Check the drive belt auto tensioner indication when the engine is cold.
 - The indicator notch is located on the moving side of the drive belt auto tensioner.
3. Visually check entire belt for wear, damage or cracks.
4. If the indicator is out of allowable working range or belt is damaged, replace the belt. Refer to [MA-26](#).

DRIVE BELT TENSION

There is no manual drive belt tension adjustment. The drive belt tension is automatically adjusted by the drive belt auto tensioner.

Changing Engine Coolant

INFOID:0000000006751595

WARNING:

- To avoid being scalded, never change the coolant when the engine is hot.
- Wrap a thick cloth around the cap to carefully remove the cap. First, turn the cap a quarter of a turn to release any built-up pressure, then push down and turn the cap all the way to remove it.

DRAINING ENGINE COOLANT

1. Turn ignition switch ON and set temperature control lever all the way to HOT position or the highest temperature position. Wait 10 seconds and turn ignition switch OFF.
2. Remove the engine under cover or skid plate. Refer to [EXT-15, "Removal and Installation"](#).


ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >



3. Open the radiator drain plug at the bottom of the radiator, and remove the radiator filler cap. This is the only step required when partially draining the cooling system (radiator only).

CAUTION:

Do not to allow the coolant to contact the drive belts.



4. When draining all of the coolant in the system for engine removal or repair, it is necessary to drain the cylinder block. Remove the RH cylinder block drain plug to drain the right bank and the oil cooler hose to drain the left bank as shown.



5. Remove the reservoir tank to drain the engine coolant, then clean the reservoir tank before installing it.
6. Check the drained coolant for contaminants such as rust, corrosion or discoloration.
If the coolant is contaminated, flush the engine cooling system. Refer to [MA-26, "Changing Engine Coolant"](#).

REFILLING ENGINE COOLANT

1. Close the radiator drain plug. Install the reservoir tank, cylinder block drain plug, and the oil cooler hose, if removed for a total system drain or for engine removal or repair.
 - The radiator must be completely empty of coolant and water.
 - Apply sealant to the threads of the cylinder block drain plug. Use Genuine High Performance Thread Sealant or equivalent. Refer to [GI-15, "Recommended Chemical Products and Sealants"](#).

Radiator drain plug : Refer to [CO-16](#).

RH cylinder block drain plug : Refer to [MA-26](#).

2. Set the vehicle heater controls to the full HOT and heater ON position. Turn the vehicle ignition ON with the engine OFF as necessary to activate the heater mode.
3. Remove the vented reservoir cap and replace it with a non-vented reservoir cap before filling the cooling system.

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >

4. Install the Tool by installing the radiator cap adapter onto the radiator neck opening. Then attach the gauge body assembly with the refill tube and the venturi assembly to the radiator cap adapter.


Tool number : KV991J0070 (J-45695)

5. Insert the refill hose into the coolant mixture container that is placed at floor level. Make sure the ball valve is in the closed position.
 - Use specified coolant or equivalent.
Refer to [MA-21, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (United States and Canada), [MA-22, "FOR MEXICO : Fluids and Lubricants"](#) (Mexico).

Cooling system capacity (with reservoir) : Refer to [CO-25, "Standard and Limit"](#).

6. Install an air hose to the venturi assembly, the air pressure must be within specification.

Compressed air supply pressure : 549 - 824 kPa (5.6 - 8.4 kg/cm², 80 - 119 psi)




CAUTION:

The compressed air supply must be equipped with an air dryer.

7. The vacuum gauge will begin to rise and there will be an audible hissing noise. During this process open the ball valve on the refill hose slightly. Coolant will be visible rising in the refill hose. Once the refill hose is full of coolant, close the ball valve. This will purge any air trapped in the refill hose.
8. Continue to draw the vacuum until the gauge reaches 28 inches of vacuum. The gauge may not reach 28 inches in high altitude locations. Refer to the following table for expected vacuum reading.

Altitude above sea level	Vacuum gauge reading
0 - 100 m (328 ft)	: 28 inches of vacuum
300 m (984 ft)	: 27 inches of vacuum
500 m (1,641 ft)	: 26 inches of vacuum
1,000 m (3,281 ft)	: 24 - 25 inches of vacuum



9. When the vacuum gauge has reached the specified amount, disconnect the air hose and wait 20 seconds to see if the system loses any vacuum. If the vacuum level drops, perform any necessary repairs to the system and repeat steps 6 - 8 to bring the vacuum to the specified amount. Recheck for any leaks.
10. Place the coolant container (with the refill hose inserted) at the same level as the top of the radiator. Then open the ball valve on the refill hose so the coolant will be drawn up to fill the cooling system. The cooling system is full when the vacuum gauge reads zero.

CAUTION:

Do not allow the coolant container to get too low when filling, to avoid air from being drawn into the cooling system.

11. Remove the Tool from the radiator neck opening and install the radiator cap.
12. Remove the non-vented reservoir cap.
13. Fill the cooling system reservoir tank to the specified level. Run the engine to warm up the cooling system and top up the system as necessary before installing the vented reservoir cap.

FLUSHING COOLING SYSTEM

1. Drain the water from the engine cooling system. Refer to [MA-26, "Changing Engine Coolant"](#).

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >


2. Fill the radiator and the reservoir tank (to the "MAX" line), with water. Reinstall the radiator cap and leave the vented reservoir cap off.
3. Run the engine until it reaches normal operating temperature.
4. Press the engine accelerator two or three times under no-load.
5. Stop the engine and wait until it cools down.
6. Drain the water from the engine cooling system. Refer to [MA-26, "Changing Engine Coolant"](#).
7. Repeat steps 2 through 6 until clear water begins to drain from the radiator.

Checking Fuel Line

INFOID:000000006158424

Inspect fuel lines, fuel filler cap and fuel tank for improper attachment, leaks, cracks, damage, loose connections, chafing or deterioration.

If necessary, repair or replace damaged parts.



Changing Fuel Filter

INFOID:000000006158425


The fuel filter is part of the fuel level sensor unit, fuel filter and fuel pump assembly. Refer to [FL-11](#).

WARNING:

Before replacing the fuel filter, release the fuel pressure from the fuel system. Refer to [EC-473, "Fuel Pressure Check"](#).

Changing Engine Air Cleaner Filter

INFOID:000000006158426



1. Air cleaner case (lower)
2. Air cleaner filter
3. Air cleaner case (upper)
4. Air duct and resonator assembly

← Front

REMOVAL

NOTE:

- The viscous paper type filter does not need cleaning between replacement intervals.
- Replace the air filter as necessary for periodic maintenance. Refer to [MA-9, "FOR NORTH AMERICA : Introduction of Periodic Maintenance"](#). (United States and Canada), [MA-13, "FOR MEXICO : Introduction of Periodic Maintenance"](#) (Mexico).

MA

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >

1. Remove the air duct and resonator assembly.
2. Remove the air cleaner case (upper).
3. Remove the air cleaner filter from the air cleaner case (lower).

INSTALLATION

1. Install the new air cleaner filter in the air cleaner case (lower).
2. Install the air cleaner case (upper).


Changing Engine Oil

INFOID:0000000006158427

WARNING:

- Be careful not to burn yourself, as the engine oil is hot.
- Prolonged and repeated contact with used engine oil may cause skin cancer. Try to avoid direct skin contact with used engine oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.

1. Remove engine under cover or skid plate. Refer to [EXT-15, "Removal and Installation".](#)
2. Warm up engine, and check for oil leakage from engine components. Refer to [LU-8, "Inspection".](#)
3. Stop engine and wait for 10 minutes.
4. Loosen oil filler cap, then remove drain plug.
5. Drain engine oil.
6. Install drain plug with new washer.



CAUTION:
• Be sure to clean drain plug and install with new washer.

Oil pan drain plug : 34.3 N·m (3.5 kg·m, 25 ft-lb)

7. Refill with new engine oil. Refer to [MA-21, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (United States and Canada), [MA-22, "FOR MEXICO : Fluids and Lubricants"](#) (Mexico).

CAUTION:

- The refill capacity depends on the engine oil temperature and drain time. Use these specifications for reference only.
- Always use the oil level gauge to determine when the proper amount of engine oil is in the engine.

8. Warm up engine and check area around drain plug and oil filter for oil leakage.
9. Stop engine and wait for 10 minutes.
10. Check engine oil level. Refer to [LU-8, "Inspection".](#)

Changing Oil Filter

INFOID:0000000006158428

REMOVAL

1. Drain the engine oil. Refer to [LU-9, "Changing Engine Oil".](#)
2. Remove the oil filter using Tool.


Tool number : KV10115801 (J-38956)

WARNING:

- Be careful not to get burned when the engine and engine oil are hot.

CAUTION:

- The oil filter is provided with a relief valve. Use Genuine NISSAN oil filter or equivalent.
- Be careful not to get burned when the engine and engine oil are hot.
- When removing, prepare a shop cloth to absorb any engine oil leakage or spillage.
- Do not allow engine oil to adhere to the drive belts.




ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >

- Completely wipe off any engine oil that adheres to the engine and the vehicle.

INSTALLATION


1. Remove foreign materials adhering to the oil filter installation surface.
2. Apply engine oil to the oil seal circumference of the new oil filter.



3. Screw the oil filter manually until it touches the installation surface, then tighten it by 2/3 turn. Or tighten to specification.

Oil filter : 17.7 N·m (1.8 kg·m, 13 ft-lb)

4. Refill the engine with new engine oil. Refer to [LU-9, "Changing Engine Oil"](#).
5. Install the engine undercover.




6. Inspect the engine for oil leakage. Follow the "INSPECTION AFTER INSTALLATION" procedure.

INSPECTION AFTER INSTALLATION

1. Check the engine oil level. Refer to [LU-8, "Inspection"](#).
2. Start the engine and check for engine oil leakage.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level and add engine oil as required.

Changing Spark Plugs

INFOID:000000006158429



1. Ignition coil

2. Spark plug

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >

REMOVAL


1. Remove engine room cover using power tool. Refer to [EM-24, "Removal and Installation"](#).
2. Remove ignition coil. Refer to [EM-38, "Removal and Installation"](#).
3. Remove spark plug using suitable tool.

CAUTION:

Do not shock ignition coil.

CAUTION:

Do not drop or shock spark plug.



INSPECTION AFTER REMOVAL


- Do not use a wire brush for cleaning.
- If plug tip is covered with carbon, spark plug cleaner may be used.

Cleaner air pressure:


Less than 588 kPa (5.9 bar, 6 kg/cm², 85 psi)

Cleaning time:

Less than 20 seconds



- Checking and adjusting plug gap is not required between change intervals.



INSTALLATION

Installation is in the reverse order of removal.

Spark Plug Types

Make	NGK	
Model	Standard model	FFV model
Standard type*	DILFR5A-11	DILFR5A-11D
Gap (Nominal)	1.1 mm (0.043 in)	1.1 mm (0.043)

* : Always check with the Parts Department for the latest parts information.

CAUTION:

Do not drop or shock spark plug.

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >

Checking EVAP Vapor Line

INFOID:000000006158430

1. Visually inspect the EVAP vapor lines for improper attachment, cracks, damage, loose connections, chafing, or deterioration.
2. Inspect the vacuum relief valve of the fuel tank filler cap for clogging and sticking. Refer to [EC-475, "How to Detect Fuel Vapor Leakage"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

MA

CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >

CHASSIS AND BODY MAINTENANCE


IN-CABIN MICROFILTER

IN-CABIN MICROFILTER : Removal and Installation


INFOID:000000006751642

REPLACEMENT PROCEDURE

1. Remove the two lower glove box hinge pins to remove the glove box from the instrument panel and let it hang from the cord.




2. Remove the screw and remove the in-cabin microfilter cover.
3. Remove the in-cabin microfilters from the heater and cooling unit assembly housing.




4. Insert the first new in-cabin microfilter into the heater and cooling unit assembly housing and slide it over to the right. Insert the second new in-cabin microfilter into the heater and cooling unit assembly housing.

NOTE:

The in-cabin microfilters are marked with air flow arrows. The end of the microfilter with the arrow should face the rear of the vehicle. The arrows should point downward.




5. Install the in-cabin microfilter cover.



CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >

6. Install the lower glove box in the instrument panel and secure it with the two hinge pins.



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O


EXHAUST SYSTEM

EXHAUST SYSTEM : Checking Exhaust System

INFOID:000000006158432

Check exhaust pipes, muffler and mounting for improper attachment, leaks, cracks, damage or deterioration.

- If anything is found, repair or replace damaged parts.



I
J
K
L
M
N

A/T FLUID


A/T FLUID : Checking the A/T Fluid (ATF)

INFOID:000000006751644

CAUTION:

If using the vehicle for towing, the A/T fluid must be replaced as specified. Refer to [MA-9, "FOR NORTH AMERICA : Introduction of Periodic Maintenance"](#) (United States and Canada), [MA-13, "FOR MEXICO : Introduction of Periodic Maintenance"](#) (Mexico).

1. Before driving, the A/T fluid level can be checked at A/T fluid temperatures of 30° to 50° C (86° to 122° F) using the "COLD" range on the A/T fluid level gauge as follows:
 - a. Park the vehicle on a level surface and set the parking brake.
 - b. Start the engine and move the selector lever through each gear position. Shift the selector lever into the "P" position.
 - c. Check the A/T fluid level with the engine idling.
 - d. Remove the A/T fluid level gauge and wipe it clean with a lint-free paper.



O
MA

CAUTION:
When wiping the A/T fluid from the A/T fluid level gauge, always use a lint-free paper, not a cloth.

CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >

e. Re-insert the A/T fluid level gauge into the A/T fluid charging pipe until the cap contacts the top of the A/T fluid charging pipe as shown.

CAUTION:


To check A/T fluid level, insert the A/T fluid level gauge until the cap contacts the top of the A/T fluid charging pipe, with the gauge reversed from the normal inserted position.

f. Remove the A/T fluid level gauge and note the A/T fluid level. If the A/T fluid level is at low side of range, add A/T fluid to the transmission through the A/T fluid charging pipe.

CAUTION:

Do not overfill the transmission with A/T fluid.


g. Install the A/T fluid level gauge and the A/T fluid level gauge bolt.



SCIA2899E

A/T fluid level gauge bolt : Refer to [TM-206, "Removal and Installation \(2WD\)"](#) or [TM-208, "Removal and Installation \(4WD\)"](#)

2. Warm up the engine and transmission.
3. Check for any A/T fluid leaks.
4. Drive the vehicle to increase the A/T fluid temperature to 80° C (176° F).
5. Allow the A/T fluid temperature to fall to approximately 65°C (149°F). Use the CONSULT-III to monitor the A/T fluid temperature as follows:



SLIA0016E


NOTE:

The A/T fluid level will be significantly affected by the A/T fluid temperature as shown. Therefore monitor the A/T fluid temperature data using the CONSULT-III.

- a. Connect CONSULT-III to data link connector.
- b. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-III.
- c. Read out the value of "ATF TEMP 1".
6. Re-check the A/T fluid level at A/T fluid temperatures of approximately 65°C (149°F) using the "HOT" range on the A/T fluid level gauge as shown. The HOT range is between 50° - 80° C (122° - 176° F).

CAUTION:

- When wiping the A/T fluid from the A/T fluid level gauge, always use lint-free paper, not a cloth.



LLIA0071E

CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >


- To check the A/T fluid level, insert the A/T fluid level gauge until the cap contacts the top of the A/T fluid charging pipe, with the gauge reversed from the normal inserted position as shown.

7. Check the A/T fluid condition.

- If the A/T fluid is very dark or has some burned smell, there may be an internal problem with the transmission. Refer to [TM-172, "A/T Fluid Cooler Cleaning"](#). Flush the transmission cooling system after repairing the transmission.
- If the A/T fluid contains frictional material (clutches, bands, etc.), replace the radiator and flush the transmission cooler lines using cleaning solvent and compressed air after repairing the transmission.

8. Install the A/T fluid level gauge in the A/T fluid charging pipe.

9. Tighten the A/T fluid level gauge bolt to specification.



A/T fluid level gauge bolt : Refer to [TM-206, "Removal and Installation \(2WD\)"](#) or [TM-208, "Removal and Installation \(4WD\)"](#)

A/T FLUID : Changing the A/T Fluid (ATF)


INFOID:0000000006751645

CAUTION:

If using the vehicle for towing, the A/T fluid must be replaced as specified. Refer to [MA-9, "FOR NORTH AMERICA : Introduction of Periodic Maintenance"](#).

1. Drive the vehicle to warm up the A/T fluid to approximately 80° C (176° F).
2. Stop the engine.
3. Remove the A/T fluid level gauge.
4. Drain the A/T fluid from the drain plug hole, then install the drain plug with a new gasket. Refill the transmission with new A/T fluid. Always refill with the same volume as the drained A/T fluid. Use the A/T fluid level gauge to check the A/T fluid level as shown. Add A/T fluid as necessary.

Drain plug : Refer to [TM-212, "Component"](#).



- To flush out the old A/T fluid from the transmission oil coolers, pour new A/T fluid into the A/T fluid charging pipe with the engine idling and at the same time drain the old A/T fluid from the auxiliary transmission oil cooler hose return line.
- When the color of the A/T fluid coming out of the auxiliary transmission oil cooler hose return line is about the same as the color of the new A/T fluid, flushing out the old A/T fluid is complete. The amount of new A/T fluid used for flushing should be 30% to 50% increase of the specified capacity.

A/T fluid grade and capacity : Refer to [MA-21, "FOR NORTH AMERICA : Fluids and Lubricants" \(United States and Canada\)](#), [MA-22, "FOR MEXICO : Fluids and Lubricants" \(Mexico\)](#).

CAUTION:

- If Genuine NISSAN Matic S ATF is not available, Genuine NISSAN Matic J ATF may also be used.
- Using ATF fluid other than Genuine NISSAN Matic S ATF or Matic J ATF will cause deterioration in driveability and A/T durability, and may damage the A/T, which is not covered by the warranty.
- When filling the transmission with A/T fluid, do not spill the A/T fluid on any heat generating parts such as the exhaust parts.
- Do not reuse the drain plug gasket.

CHASSIS AND BODY MAINTENANCE


< PERIODIC MAINTENANCE >

5. Install the A/T fluid level gauge and tighten the A/T fluid level gauge bolt to specification.

A/T fluid level gauge bolt : Refer to [TM-206, "Removal and Installation \(2WD\)"](#) or [TM-208, "Removal and Installation \(4WD\)"](#)

6. Drive the vehicle to warm up the A/T fluid to approximately 80° C (176° F).

7. Check the fluid level and condition. If the A/T fluid is still dirty, repeat steps 2 through 6.



8. Install the A/T fluid level gauge in the A/T fluid charging pipe and install the A/T fluid level gauge bolt.

9. Tighten the A/T fluid level gauge bolt to specification.

A/T fluid level gauge bolt : Refer to [TM-206, "Removal and Installation \(2WD\)"](#) or [TM-208, "Removal and Installation \(4WD\)"](#)

TRANSFER FLUID

TRANSFER FLUID : Checking Transfer Fluid

INFOID:0000000006158436

CAUTION:

If using the vehicle for towing, the transfer fluid must be replaced as specified. Refer to [MA-9, "FOR NORTH AMERICA : Introduction of Periodic Maintenance"](#) (United States and Canada) or [MA-13, "FOR MEXICO : Introduction of Periodic Maintenance"](#) (Mexico).

FLUID LEAKAGE AND FLUID LEVEL

1. Make sure that fluid is not leaking from the transfer assembly or around it.
2. Check fluid level from the filler plug hole as shown.


CAUTION:

Do not start engine while checking fluid level.

3. Install the filler plug with a new gasket to the transfer. Tighten to the specified torque. Refer to [MA-38, "TRANSFER FLUID : Checking Transfer Fluid"](#).

CAUTION:

Do not reuse gasket.



TRANSFER FLUID : Changing Transfer Fluid

INFOID:0000000006158435

CAUTION:

If using the vehicle for towing, the transfer fluid must be replaced as specified. Refer to [MA-9, "FOR NORTH AMERICA : Introduction of Periodic Maintenance"](#) (United States and Canada) or [MA-13, "FOR MEXICO : Introduction of Periodic Maintenance"](#) (Mexico).

DRAINING

1. Stop engine.


CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >

2. Remove the drain plug and gasket and drain the fluid.
3. Install the drain plug with a new gasket to the transfer. Tighten to the specified torque. Refer to [TM-212, "Component"](#).

CAUTION:

Do not reuse gasket.



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
MA

FILLING

1. Remove the filler plug and gasket.
2. Fill the transfer with new fluid until the fluid level reaches the specified limit near the filler plug hole.

Fluid grade and capacity : Refer to [MA-21, "FOR NORTH AMERICA : Fluids and Lubricants" \(United States and Canada\)](#), [MA-22, "FOR MEXICO : Fluids and Lubricants" \(Mexico\)](#).


CAUTION:

Carefully fill fluid. (Fill up for approx. 3 minutes.)

3. Leave the vehicle for 3 minutes, and check fluid level again.
4. Install the filler plug with a new gasket to the transfer. Tighten to the specified torque. Refer to [TM-212, "Component"](#).

CAUTION:

Do not reuse gasket.



PROPELLER SHAFT

PROPELLER SHAFT : Checking Propeller Shaft

INFOID:0000000006158437

Check the front and rear propeller shafts for damage, dents, and cracks. Check the joints for looseness and any damage. Repair or replace as necessary.

FRONT DIFFERENTIAL GEAR OIL

FRONT DIFFERENTIAL GEAR OIL : Checking Differential Gear Oil

INFOID:0000000006751648


DIFFERENTIAL GEAR OIL LEAKAGE AND LEVEL

1. Make sure that differential gear oil is not leaking from the front final drive assembly or around it.
2. Check the differential gear oil level from the filler plug hole as shown.

CAUTION:

Do not start engine while checking differential gear oil level.

3. Install the filler plug with sealant applied on the threads to the front final drive assembly. Tighten to the specified torque. Refer to [DLN-171, "Disassembly and Assembly"](#).
 - Use High Performance Thread Sealant or equivalent. Refer to [GI-15, "Recommended Chemical Products and Sealants"](#).



FRONT DIFFERENTIAL GEAR OIL : Changing Differential Gear Oil

INFOID:0000000006751649

DRAINING

CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >


1. Stop the engine.
2. Remove the drain plug from the front final drive assembly to drain the differential gear oil.
3. Install the drain plug with sealant applied on the threads to the front final drive assembly. Tighten to the specified torque. Refer to [DLN-171, "Disassembly and Assembly"](#).
 - Use High Performance Thread Sealant or equivalent. Refer to [GI-15, "Recommended Chemical Products and Sealants"](#).

FILLING

1. Remove the filler plug from the front final drive assembly.
2. Fill the front final drive assembly with new differential gear oil until the level reaches the specified level near the filler plug hole.

Differential gear oil grade and capacity

: Refer to [MA-21, "FOR NORTH AMERICA : Fluids and Lubricants" \(United States and Canada\)](#), [MA-22, "FOR MEXICO : Fluids and Lubricants" \(Mexico\)](#).



3. Install the filler plug with sealant applied on the threads to the front final drive assembly. Tighten to the specified torque. Refer to [DLN-171, "Disassembly and Assembly"](#).
 - Use High Performance Thread Sealant or equivalent. Refer to [GI-15, "Recommended Chemical Products and Sealants"](#).


REAR DIFFERENTIAL GEAR OIL

REAR DIFFERENTIAL GEAR OIL : Checking Differential Gear Oil

INFOID:0000000006751646

DIFFERENTIAL GEAR OIL LEAKAGE AND LEVEL

1. Make sure that differential gear oil is not leaking from the rear final drive assembly or around it.
2. Check the differential gear oil level from the filler plug hole as shown.
CAUTION:
Do not start engine while checking differential gear oil level.
3. Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [DLN-199, "Disassembly and Assembly"](#).
 - Use High Performance Thread Sealant or equivalent. Refer to [GI-15, "Recommended Chemical Products and Sealants"](#).




REAR DIFFERENTIAL GEAR OIL : Changing Differential Gear Oil

INFOID:0000000006751647

DRAINING

1. Stop engine.
2. Remove the drain plug from the rear final drive assembly to drain the differential gear oil.
3. Install the drain plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [DLN-199, "Disassembly and Assembly"](#).
 - Use High Performance Thread Sealant or equivalent. Refer to [GI-15, "Recommended Chemical Products and Sealants"](#).



CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >


FILLING

1. Remove the filler plug from the rear final drive assembly.
2. Fill the rear final drive assembly with new differential gear oil until the level reaches the specified level near the filler plug hole.

Differential gear oil grade and capacity

: Refer to [MA-21, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (United States and Canada), [MA-22, "FOR MEXICO : Fluids and Lubricants"](#) (Mexico).

3. Install the filler plug with sealant applied on the threads to the rear final drive assembly. Tighten to the specified torque. Refer to [DLN-199, "Disassembly and Assembly"](#).
 - Use High Performance Thread Sealant or equivalent. Refer to [GI-15, "Recommended Chemical Products and Sealants"](#).



WHEELS

WHEELS : Adjustment

INFOID:0000000006751650

BALANCING WHEELS (ADHESIVE WEIGHT TYPE)

Preparation Before Adjustment

Remove inner and outer balance weights from the road wheel using releasing agent, remove double-faced adhesive tape from the road wheel.

CAUTION:

- Be careful not to scratch the road wheel during removal.
- After removing double-faced adhesive tape, wipe clean all traces of releasing agent from the road wheel.

Wheel Balance Adjustment

• If a balancer machine has an adhesive weight mode setting, select the adhesive weight mode setting and skip Step 2. below. If a balancer machine only has the clip-on (rim flange) weight mode setting, follow Step 2. to calculate the correct size adhesive weight.

1. Set road wheel on balancer machine using the center hole as a guide. Start the balancer machine.
2. For balancer machines that only have a clip-on (rim flange) weight mode setting, follow this step to calculate the correct size adhesive weight to use. When inner and outer imbalance values are shown on the balancer machine indicator, multiply outer imbalance value by 5/3 (1.67) to determine balance weight that should be used. Select the outer balance weight with a value closest to the calculated value above and install in to the designated outer position of, or at the designated angle in relation to the road wheel.

- a. Indicated imbalance value $\times 5/3$ = balance weight to be installed

Calculation example:


$23 \text{ g (0.81 oz)} \times 5/3 (1.67) = 38.33 \text{ g (1.35 oz)} \Rightarrow 40 \text{ g (1.41 oz)}$
balance weight (closer to calculated balance weight value)

NOTE:

Note that balance weight value must be closer to the calculated balance weight value.

Example:

$37.4 \Rightarrow 35 \text{ g (1.23 oz)}$
 $37.5 \Rightarrow 40 \text{ g (1.41 oz)}$



CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >


- Install balance weight in the position shown.

CAUTION:

- Do not install the inner balance weight before installing the outer balance weight.
- Before installing the balance weight, be sure to clean the mating surface of the road wheel.
- When installing balance weight (1) to road wheel, set it into the grooved area (A) on the inner wall of the road wheel as shown so that the balance weight center (B) is aligned with the balancer machine indication position (angle) (C).

CAUTION:

- Always use genuine NISSAN adhesive balance weights.
- Balance weights are non-reusable; always replace with new ones.
- Do not install more than three sheets of balance weight.



- If calculated balance weight value exceeds 50 g (1.76 oz), install two balance weight sheets in line with each other as shown.

CAUTION:

Do not install one balance weight sheet on top another.

- Start balancer machine again.


- Install balance weight on inner side of road wheel in the balancer machine indication position (angle).

CAUTION:

Do not install more than two balance weights.

- Start balancer machine. Make sure that inner and outer residual imbalance values are 5 g (0.17 oz) each or below.

- If either residual imbalance value exceeds 5 g (0.17 oz), repeat installation procedures.



Wheel balance	Dynamic (At flange)	Static (At flange)
Maximum allowable imbalance	Refer to WT-50, "Road Wheel" .	


TIRE ROTATION

- Follow the maintenance schedule for tire rotation service intervals. Refer to [MA-5, "FOR NORTH AMERICA : General Maintenance"](#) (United States and Canada) or [MA-7, "FOR MEXICO : General Maintenance"](#) (Mexico).

- When installing the wheel, tighten wheel nuts to the specified torque.

CAUTION:

- Do not include the spare tire when rotating the tires.
- When installing wheels, tighten them diagonally by dividing the work two to three times in order to prevent the wheels from developing any distortion.
- Be careful not to tighten wheel nut at torque exceeding the criteria for preventing strain of disc rotor.
- Use NISSAN genuine wheel nuts for aluminum wheels.



Wheel nut tightening torque : 133 N·m (14 kg-m, 98 ft-lb)

CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >

- Perform the ID registration, after tire rotation. Refer to [WT-6, "ID Registration Procedure".](#)


BRAKE FLUID LEVEL AND LEAKS

BRAKE FLUID LEVEL AND LEAKS : Checking Brake Fluid Level and Leaks

INFOID:000000006158443

LEVEL CHECK

- Make sure the fluid level in reservoir tank is between MAX and MIN lines as shown.
- Visually check around reservoir tank for fluid leaks.
- If fluid level is excessively low, check brake system for leaks.
- If brake warning lamp remains illuminated after parking brake pedal is released, check brake system for fluid leaks.



BRAKE LINES AND CABLES

BRAKE LINES AND CABLES : Checking Brake Line and Cables


INFOID:000000006158444

1. Check the brake lines and hoses for cracks, deterioration, and other damage. Replace any damaged parts.

CAUTION:

If brake fluid leaks are visible around the brake line joints, retighten the joint, or replace damaged parts as necessary.

2. Check for brake fluid leaks by fully depressing brake pedal while engine is running.




DISC BRAKE

DISC BRAKE : Checking Disc Brake

INFOID:000000006158445

ROTOR

Check the rotor condition for wear or damage. Refer to [BR-6, "DISC ROTOR : Inspection"](#) (front disc rotor) , [BR-7, "DISC ROTOR : Inspection"](#) (rear disc rotor) .




CALIPER

CHASSIS AND BODY MAINTENANCE


< PERIODIC MAINTENANCE >

Check the caliper for leaks, repair as necessary.



PAD

Check the pads for wear or damage. Refer to [BR-6, "BRAKE PAD : Inspection"](#) (front disc pad) , [BR-7, "BRAKE PAD : Inspection"](#) (rear disc pad) .




STEERING GEAR AND LINKAGE

STEERING GEAR AND LINKAGE : Checking Steering Gear and Linkage

INFOID:000000006158446

STEERING GEAR

- Check the steering gear housing for looseness, damage, and oil leakage as shown.
- Check the steering column connections for looseness.



STEERING LINKAGE

- Check the ball joint, dust cover and other component parts for looseness, wear, damage, and grease leakage.

POWER STEERING FLUID AND LINES

POWER STEERING FLUID AND LINES : Checking Power Steering Fluid and Line

INFOID:000000006158447

CHECKING FLUID LEVEL


CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >

- Check the power steering fluid level with the engine off.
- Check fluid level on reservoir. Use "HOT" range at fluid temperatures of 50° to 80°C (122° to 176°F). Use "COLD" range at fluid temperatures of 0° to 30°C (32° to 86°F).

CAUTION:


- **Do not overfill.**
- **Recommended fluid is Genuine NISSAN PSF or equivalent.**
Refer to [MA-21, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (United States and Canada), [MA-22, "FOR MEXICO : Fluids and Lubricants"](#) (Mexico).



LGIA0021E

CHECKING LINES

- Check lines for improper attachment, leaks, cracks, damage, loose connections, chafing, and deterioration.



SGIA0506E

AXLE AND SUSPENSION PARTS


AXLE AND SUSPENSION PARTS : Checking Axle and Suspension Parts

INFOID:0000000006158448

FRONT AND REAR AXLE AND SUSPENSION PARTS

Check front and rear axle and suspension parts for excessive play, cracks, wear or other damage.

- Shake each wheel to check for excessive play.
- Rotate each wheel to check for abnormal noise.



SMA525A

- Check the axle and suspension nuts and bolts for looseness.
- Check the strut and shock absorber for oil leakage or other damage.
- Check the suspension ball joints for grease leakage and ball joint dust cover for cracks or other damage.

PROPELLER SHAFT

Inspect the propeller shaft tube for dents or cracks. If damaged, replace the propeller shaft assembly.

LOCKS AND HINGES

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O






MA

CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >

LOCKS AND HINGES : Lubricating Locks, Hinges and Hood Latches

INFOID:0000000006158449



■ : Multi-purpose grease

WLIA0019E

NOTE:

Lubricate the locations shown with a suitable multi-purpose grease.

Refer to [MA-21, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (United States and Canada), [MA-22, "FOR MEXICO : Fluids and Lubricants"](#) (Mexico).

SEAT BELT, BUCKLES, RETRACTORS, ANCHORS AND ADJUSTERS

SEAT BELT, BUCKLES, RETRACTORS, ANCHORS AND ADJUSTERS : Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters

INFOID:0000000006158450

Check the seat belt buckles, webbing, retractors, anchors and adjusters. Replace any seat belt assembly as necessary. Refer to [SB-10, "Seat Belt Inspection"](#).

- Check the seat belt anchors for loose mounting bolts, damage, or excessive wear.

CHASSIS AND BODY MAINTENANCE

< PERIODIC MAINTENANCE >

- Check the seat belt webbing for any damage, cuts, fraying, or excessive wear.
- Check the retractor for smooth operation.
- Check the function of the buckles by inserting the seat belt tongue and checking for proper engagement of the buckle and press the button on the buckle to check for proper release of the seat belt tongue.

WARNING:

- **After any collision, inspect all seat belt assemblies, including retractors and other attached components, such as the guide rail set. NISSAN recommends replacing all seat belt assemblies in use during a collision, unless they are not damaged and are inspected to confirm they are operating properly after a minor collision.**

Also inspect all seat belt assemblies that are not in use during a collision, and replace any components if damaged or not operating properly. The seat belt pre-tensioner should be replaced even if the seat belts are not in use during a frontal collision where the driver and passenger air bags have been deployed.

- If any component of the seat belt assembly is suspected of being damaged or not operating properly, do not repair the component. Replace the components as an assembly.
- If the seat belt webbing is cut, frayed, or damaged then replace the seat belt assembly.
- Never lubricate the seat belt buckle or tongue.
- When replacing any seat belt assembly always use a Genuine NISSAN seat belt assembly.