

SECTION BCS

BODY CONTROL SYSTEM

| BCM | |
|--|----|
| PRECAUTION | 3 |
| PRECAUTIONS | 3 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 3 |
| PREPARATION | 4 |
| PREPARATION | 4 |
| Special Service Tool | 4 |
| SYSTEM DESCRIPTION | 5 |
| COMPONENT PARTS | 5 |
| BODY CONTROL SYSTEM | 5 |
| BODY CONTROL SYSTEM : Component Parts Location | 5 |
| POWER CONSUMPTION CONTROL SYSTEM | 6 |
| POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location | 6 |
| SYSTEM | 7 |
| BODY CONTROL SYSTEM | 7 |
| BODY CONTROL SYSTEM : System Description | 7 |
| BODY CONTROL SYSTEM : Fail Safe | 8 |
| COMBINATION AND LIGHTING SWITCH READING SYSTEM | 8 |
| COMBINATION AND LIGHTING SWITCH READING SYSTEM : System Description | 8 |
| SIGNAL BUFFER SYSTEM | 15 |
| SIGNAL BUFFER SYSTEM : System Description | 15 |
| POWER CONSUMPTION CONTROL SYSTEM | 16 |
| POWER CONSUMPTION CONTROL SYSTEM : System Description | 16 |
| SHIPPING MODE CONTROL SYSTEM | 17 |
| SHIPPING MODE CONTROL SYSTEM : System Description | 18 |
| DIAGNOSIS SYSTEM (BCM) | 19 |
| COMMON ITEM | 19 |
| COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) | 19 |
| DOOR LOCK | 20 |
| DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) | 20 |
| REAR DEFOGGER | 21 |
| REAR DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER) | 21 |
| BUZZER | 22 |
| BUZZER : CONSULT Function (BCM - BUZZER) | 22 |
| INT LAMP | 22 |
| INT LAMP : CONSULT Function (BCM - INT LAMP) | 22 |
| HEADLAMP | 23 |
| HEADLAMP : CONSULT Function (BCM - HEADLAMP) | 23 |
| WIPER | 24 |
| WIPER : CONSULT Function (BCM - WIPER) | 24 |
| FLASHER | 25 |
| FLASHER : CONSULT Function (BCM - FLASHER) | 25 |
| AIR CONDITIONER | 25 |
| AIR CONDITIONER : CONSULT Function (BCM - AIR CONDITIONER) | 25 |
| INTELLIGENT KEY | 25 |
| INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) | 26 |

A
B
C
D
E

F
G
H

I
J
K

BCS

L
M
N
O
P

| | | | |
|---|----|--|----|
| COMB SW | 28 | SHIPPING MODE CANCEL OPERATION | 65 |
| COMB SW : CONSULT Function (BCM - COMB SW) | 28 | Work Procedure | 65 |
| BCM | 29 | DTC/CIRCUIT DIAGNOSIS | 66 |
| BCM : CONSULT Function (BCM - BCM) | 29 | U0415 VEHICLE SPEED SIG | 66 |
| IMMU | 29 | DTC Description | 66 |
| IMMU : CONSULT Function (BCM - IMMU) | 29 | Diagnosis Procedure | 66 |
| BATTERY SAVER | 30 | U1000 CAN COMM CIRCUIT | 67 |
| BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER) | 30 | DTC Description | 67 |
| THEFT ALM | 30 | Diagnosis Procedure | 67 |
| THEFT ALM : CONSULT Function (BCM - THEFT ALM) | 30 | U1010 CONTROL UNIT (CAN) | 68 |
| RETAINED PWR | 31 | DTC Description | 68 |
| RETAINED PWR : CONSULT Function (BCM - RETAINED PWR) | 31 | Diagnosis Procedure | 68 |
| SIGNAL BUFFER | 31 | B2562 LOW VOLTAGE | 69 |
| SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER) | 31 | DTC Description | 69 |
| ECU DIAGNOSIS INFORMATION | 32 | Diagnosis Procedure | 69 |
| BCM | 32 | B259A ROOM LAMP FUSE | 70 |
| Reference Value | 32 | DTC Description | 70 |
| Fail Safe | 51 | Diagnosis Procedure | 70 |
| DTC Inspection Priority Chart | 51 | POWER SUPPLY AND GROUND CIRCUIT | 72 |
| DTC Index | 52 | Diagnosis Procedure | 72 |
| WIRING DIAGRAM | 54 | COMBINATION AND LIGHTING SWITCH INPUT CIRCUIT | 73 |
| BCM | 54 | Diagnosis Procedure | 73 |
| Wiring Diagram | 54 | COMBINATION AND LIGHTING SWITCH OUTPUT CIRCUIT | 75 |
| BASIC INSPECTION | 62 | Diagnosis Procedure | 75 |
| INSPECTION AND ADJUSTMENT | 62 | SYMPTOM DIAGNOSIS | 77 |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) | 62 | COMBINATION AND LIGHTING SWITCH SYSTEM SYMPTOMS | 77 |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Description | 62 | Symptom Table | 77 |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Work Procedure | 62 | NORMAL OPERATING CONDITION | 78 |
| CONFIGURATION (BCM) | 63 | Description | 78 |
| CONFIGURATION (BCM) : Description | 63 | REMOVAL AND INSTALLATION | 79 |
| CONFIGURATION (BCM) : Work Procedure | 63 | BCM (BODY CONTROL MODULE) | 79 |
| CONFIGURATION (BCM) : Configuration List | 64 | Removal and Installation | 79 |
| COMBINATION SWITCH | 80 | COMBINATION SWITCH | 80 |
| Removal and Installation | 80 | Removal and Installation | 80 |

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000014666394

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

< PREPARATION >

PREPARATION

PREPARATION

Special Service Tool

INFOID:000000014387207

The actual shape of the tools may differ from those illustrated here.

| Tool number (TechMate No.) | Description |
|----------------------------------|--|
| — (J-50190) Signal Tech II |  <ul style="list-style-type: none">• Activate and display TPMS transmitter IDs• Display tire pressure reported by the TPMS transmitter• Read TPMS DTCs• Register TPMS transmitter IDs• Test remote keyless entry keyfob relative to signal strength• Check Intelligent Key relative signal strength• Confirm vehicle Intelligent Key antenna signal strength• Compatible with future sensors• Equipped with a display |

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

COMPONENT PARTS

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : Component Parts Location

INFOID:0000000014387208



A. LH side of dash (view from drivers footwell
with steering column removed)

1. BCM

COMPONENT PARTS


< SYSTEM DESCRIPTION >

[BCM]

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location

INFOID:000000014387209



ALMIA0874ZZ

1. IPDM E/R
Refer to [PCS-5, "Component Parts Location".](#)
2. CAN gateway
Refer to [LAN-223, "Component Parts Location".](#)
3. BCM
Refer to [BCS-5, "BODY CONTROL SYSTEM : Component Parts Location".](#)
4. Combination meter
Refer to [MWI-8, "METER SYSTEM : Component Parts Location".](#)

< SYSTEM DESCRIPTION >

SYSTEM**BODY CONTROL SYSTEM****BODY CONTROL SYSTEM : System Description**

INFOID:000000014387210

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P**OUTLINE**

- BCM (body control module) controls various electrical components. It receives the information required from CAN communication and the signals received from each switch and sensor.
- BCM has a combination switch reading function for reading the status of combination switches (light, turn signal, wiper and washer) in addition to functions for controlling the operation of various electrical components. It also has a signal transmission function for other systems, and a power consumption control function that reduces the power consumption with the ignition switch OFF.
- BCM is equipped with a diagnosis function that operates with CONSULT and allows for various settings to be changed.

BCM CONTROL FUNCTION LIST

| System | Refer to |
|---|--|
| Combination switch reading system | BCS-8, "COMBINATION AND LIGHTING SWITCH READING SYSTEM : System Description" |
| Signal buffer system | BCS-15, "SIGNAL BUFFER SYSTEM : System Description" |
| Power consumption control system | BCS-16, "POWER CONSUMPTION CONTROL SYSTEM : System Description" |
| Shipping mode control system | BCS-18, "SHIPPING MODE CONTROL SYSTEM : System Description" |
| Auto light system | EXL-160, "AUTO LIGHT SYSTEM : System Description" (LED type headlamp) EXL-11, "AUTO LIGHT SYSTEM : System Description" (Halogen type headlamp) |
| Headlamp system | EXL-159, "HEADLAMP SYSTEM : System Description" (LED type headlamp) EXL-11, "HEADLAMP SYSTEM : System Description" (Halogen type headlamp) |
| Daytime running light system | EXL-161, "DAYTIME RUNNING LIGHT SYSTEM : System Description" (LED type headlamp) EXL-12, "DAYTIME RUNNING LIGHT SYSTEM : System Description" (Halogen type headlamp) |
| Front fog lamp system | EXL-164, "FRONT FOG LAMP SYSTEM : System Description" (LED type headlamp) EXL-15, "FRONT FOG LAMP SYSTEM : System Description" (Halogen type headlamp) |
| Turn signal and hazard warning lamp system | EXL-162, "TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description" (LED type headlamp) EXL-12, "TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description" (Halogen type headlamp) |
| Parking, license plate and tail lamp system | EXL-163, "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description" (LED type headlamp) EXL-13, "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description" (Halogen type headlamp) |
| Exterior lamp battery saver system | EXL-165, "EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description" (LED type headlamp) EXL-11, "HEADLAMP SYSTEM : System Description" (Halogen type headlamp) |
| Interior room lamp battery saver system | INL-7, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description" |
| Interior room lamp control system | |
| Front wiper and washer system | WW-9, "FRONT WIPER AND WASHER SYSTEM : System Description" |

BCS

SYSTEM

[BCM]

< SYSTEM DESCRIPTION >

| System | Refer to |
|--|--|
| Warning chime system | WCS-7, "WARNING CHIME SYSTEM : System Description" |
| Door lock system | DLK-17, "System Description" |
| Nissan vehicle immobilizer system (NVIS) | SEC-12, "NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description" |
| Vehicle security system | SEC-14, "VEHICLE SECURITY SYSTEM : System Description" |
| Panic alarm | |
| Rear window defogger system | DEF-7, "System Description" |
| Intelligent Key system/engine start system | Door lock function DLK-20, "DOOR LOCK FUNCTION : System Description" |
| | Warning function DLK-24, "WARNING FUNCTION : System Description" |
| | Key reminder function DLK-27, "KEY REMINDER FUNCTION : System Description" |
| | Engine start function SEC-9, "INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description" |
| Power window system | PWC-9, "System Description" |
| RAP (retained accessory power) system | BCS-31, "RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)" |

BODY CONTROL SYSTEM : Fail Safe

INFOID:0000000014387211

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|-------------------------|--|
| B2192: ID DISCORD BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2193: CHAIN OF BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2195: ANTI-SCANNING | Inhibit engine cranking | Ignition switch ON → OFF |
| B2560: START POW SUP CIRC | Inhibit engine cranking | 500 ms after the following CAN signal communication status has become consistent: • Starter control relay signal • Starter relay status signal |
| B2562: LOW VOLTAGE | Inhibit engine cranking | 100 ms after the power supply voltage increases to more than 8.8 V |
| B2608: STARTER RELAY | Inhibit engine cranking | 500 ms after the following signal communication status becomes consistent: • Starter motor relay control signal • Starter relay status signal (CAN) |
| B260A: IGN RELAY | Inhibit engine cranking | 500 ms after the following conditions are fulfilled: • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal) |
| B261E: FUEL MIS CONFIG | Inhibit engine cranking | BCM initialization |

COMBINATION AND LIGHTING SWITCH READING SYSTEM

COMBINATION AND LIGHTING SWITCH READING SYSTEM : System Description

INFOID:0000000014387212


SYSTEM DIAGRAM

SYSTEM


[BCM]

< SYSTEM DESCRIPTION >

Combination Switch Circuit (With Variable Intermittent Wipers)



Combination Switch Circuit (With Rain Sensing Wipers)



OUTLINE

SYSTEM


[BCM]

< SYSTEM DESCRIPTION >

- BCM reads the status of the combination and lighting switches (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5). It reads a maximum of 20 switch states.

COMBINATION AND LIGHTING SWITCH MATRIX (WITH VARIABLE INTERMITTENT WIPERS)

Combination Switch Circuit (With Variable Intermittent Wipers)



Combination and lighting switch INPUT-OUTPUT system list

| System | INPUT 1 | INPUT 2 | INPUT 3 | INPUT 4 | INPUT 5 |
|----------|--------------|--------------|--------------|------------|------------|
| OUTPUT 1 | — | FR WASHER | FR WIPER LOW | TURN LH | TURN RH |
| OUTPUT 2 | FR WIPER HI | — | FR WIPER INT | PASSING | HEADLAMP 1 |
| OUTPUT 3 | INT VOLUME 1 | — | — | HEADLAMP 2 | HI BEAM |
| OUTPUT 4 | — | INT VOLUME 3 | — | — | TAIL LAMP |
| OUTPUT 5 | INT VOLUME 2 | — | — | — | — |


COMBINATION AND LIGHTING SWITCH MATRIX (WITH RAIN SENSING WIPERS)

SYSTEM

[BCM]

< SYSTEM DESCRIPTION >

Combination Switch Circuit (With Rain Sensing Wipers)




Combination and lighting switch INPUT-OUTPUT system list

| System | INPUT 1 | INPUT 2 | INPUT 3 | INPUT 4 | INPUT 5 |
|----------|-------------|-----------|--------------|------------|------------|
| OUTPUT 1 | — | FR WASHER | FR WIPER LOW | TURN LH | TURN RH |
| OUTPUT 2 | FR WIPER HI | — | FR WIPER INT | PASSING | HEADLAMP 1 |
| OUTPUT 3 | AUTO 1 | — | — | HEADLAMP 2 | HI BEAM |
| OUTPUT 4 | — | AUTO 3 | AUTO LIGHT | — | TAIL LAMP |
| OUTPUT 5 | AUTO 2 | — | — | FR FOG | — |

COMBINATION AND LIGHTING SWITCH READING FUNCTION

Description

- BCM reads the status of the combination and lighting switches at 10 ms intervals normally.




< SYSTEM DESCRIPTION >

NOTE:

BCM reads the status of the combination and lighting switches at 60 ms intervals when BCM is controlled at low power consumption control mode.

- BCM operates as follows and judges the status of the combination and lighting switches.
- It operates the transistor on OUTPUT side in the following order: OUTPUT 1 → 2 → 3 → 4 → 5, and outputs voltage waveform.
- The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.
- It reads this change of the voltage as the status signal of the combination and lighting switches.


**Operation Example**

In the following operation example, the combination of the status signals of the combination and lighting switches is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".

Example 1: When a switch (TAIL LAMP) is turned ON

- The circuit between OUTPUT 4 and INPUT 5 is formed when the TAIL LAMP switch is turned ON.

Combination Switch Circuit (With Variable Intermittent Wipers)




SYSTEM

[BCM]

< SYSTEM DESCRIPTION >

Combination Switch Circuit (With Rain Sensing Wipers)



- BCM detects the combination and lighting switch status signal "5D" when the signal of OUTPUT 4 is input to INPUT 5.
- BCM judges that the TAIL LAMP switch is ON when the signal "5D" is detected.

Example 2: When some switches (TURN RH, TAIL LAMP) are turned ON

- The circuits between OUTPUT 1 and INPUT 5 and between OUTPUT 4 and INPUT 5 are formed when the TURN RH switch and TAIL LAMP switch are turned ON.

A
B
C
D
E
F
G
H
I
J
K
L

BCS


N
O
P

SYSTEM


[BCM]

< SYSTEM DESCRIPTION >

Combination Switch Circuit (With Variable Intermittent Wipers)



Combination Switch Circuit (With Rain Sensing Wipers)



SYSTEM

[BCM]

< SYSTEM DESCRIPTION >

- BCM detects the combination and lighting switch status signal "5AD" when the signals of OUTPUT 1 and OUTPUT 4 are input to INPUT 5.
- BCM judges that the TURN RH switch and TAIL LAMP switch are ON when the signal "5AD" is detected.

WIPER INTERMITTENT DIAL POSITION (WITH VARIABLE INTERMITTENT WIPERS)

BCM judges the wiper intermittent dial 1 - 5 by the status of INT VOLUME 1, 2 and 3 switches.

| Wiper intermittent dial position | Switch status | | |
|----------------------------------|---------------|--------------|--------------|
| | INT VOLUME 1 | INT VOLUME 2 | INT VOLUME 3 |
| 1 | OFF | ON | OFF |
| 2 | OFF | ON | ON |
| 3 | OFF | OFF | ON |
| 4 | OFF | OFF | OFF |
| 5 | ON | ON | OFF |

NOTE:

For details of wiper intermittent dial position, refer to [WW-9, "FRONT WIPER AND WASHER SYSTEM : System Description".](#)

WIPER AUTO DIAL POSITION (WITH RAIN SENSING WIPERS)

BCM judges the wiper auto dial 1 - 4 by the status of AUTO 1, 2 and 3 switches.

| Wiper auto dial position | Switch status | | |
|--------------------------|---------------|--------|--------|
| | AUTO 1 | AUTO 2 | AUTO 3 |
| 1 | OFF | ON | OFF |
| 2 | OFF | OFF | ON |
| 3 | OFF | OFF | OFF |
| 4 | ON | ON | OFF |

NOTE:


For details of wiper auto dial position, refer to [WW-9, "FRONT WIPER AND WASHER SYSTEM : System Description".](#)

SIGNAL BUFFER SYSTEM

SIGNAL BUFFER SYSTEM : System Description

INFOID:000000014387213

SYSTEM DIAGRAM



OUTLINE

BCM has the signal transmission function that outputs/transmits each input/received signal to each unit.

Signal transmission function list

SYSTEM

[BCM]

< SYSTEM DESCRIPTION >


| Signal name | Input | Output | Description |
|---|-----------------------------|---|---|
| <ul style="list-style-type: none"> • Ignition switch ON signal • Ignition switch signal | Engine switch (push switch) | IPDM E/R (CAN) | Inputs the push-button ignition switch (push switch) signal and transmits the ignition switch status judged with BCM via CAN communication. |
| Door switch signal | Any door switch | <ul style="list-style-type: none"> • Combination meter (CAN) • IPDM E/R (CAN) | Inputs the door switch signal and transmits it via CAN communication. |

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : System Description

INFOID:000000014387214

SYSTEM DIAGRAM



AWMIA1529GB

OUTLINE

- BCM incorporates a power saving control function that reduces the power consumption according to the vehicle status.
- BCM switches the status (control mode) by itself with the power saving control function. It performs the sleep request to each unit (IPDM E/R and combination meter) that operates with the ignition switch OFF.

Normal mode (wake-up)

- CAN communication is normally performed with other units
- Each control with BCM is operating properly

CAN communication sleep mode (CAN sleep)

- CAN transmission is stopped
- Control with BCM only is operating

Low power consumption mode (BCM sleep)

- Low power consumption control is active
- CAN transmission is stopped

LOW POWER CONSUMPTION CONTROL WITH BCM

BCM reduces the power consumption with the following operation in the low power consumption mode.

- The reading interval of each switch changes from a 10 ms interval to a 60 ms interval.

Sleep mode activation

- BCM receives the sleep-ready signal (ready) from IPDM E/R and combination meter via CAN communication.
- BCM transmits the sleep wake up signal (sleep) to each unit when all of the CAN sleep conditions are fulfilled.
- Each unit stops the transmission of CAN communication with the sleep wakeup signal. BCM is in CAN communication sleep mode.

SYSTEM

[BCM]

< SYSTEM DESCRIPTION >

- BCM is in the low power consumption mode and performs the low power consumption control when all of the BCM sleep conditions are fulfilled with CAN sleep condition.

Sleep condition

| CAN sleep condition | BCM sleep condition |
|--|--|
| <ul style="list-style-type: none"> Receiving the sleep-ready signal (ready) from all units Ignition switch: OFF Vehicle security system alarm: No operation Warning lamp: No operation Intelligent Key warning buzzer: No operation Brake switch: OFF Turn signal indicator lamp: No operation Exterior lamp: OFF Door lock status: No change CONSULT communication status: No communication Meter display signal: Non-transmission Door switch status: No change Rear window defogger: OFF | <ul style="list-style-type: none"> Interior room lamp battery saver: Time out RAP system: OFF Push-button ignition switch (push switch) illumination: OFF NATS: No operation Remote keyless entry receiver communication status: No communication |

Wake-up operation

- BCM changes from the low power consumption mode to the CAN communication sleep mode when any of the BCM wake-up conditions are fulfilled. Only the control with BCM is activated.
- BCM transmits the sleep wake up signal (wake up) to each unit when any of the CAN wake-up conditions are fulfilled. It changes from the low power consumption mode or the CAN communication sleep mode to the normal mode.
- Each unit starts the transmission of CAN communication with the sleep wake up signal. In addition, the combination meter transmits the wake up signal to BCM via CAN communication to report the CAN communication start.

| BCM wake-up condition | CAN wake-up condition |
|--|--|
| <ul style="list-style-type: none"> Door unlock sensor: OFF→ON, ON→OFF Front door lock assembly LH (key cylinder switch): Lock or unlock Door lock switch: OFF→ON Door unlock switch: OFF→ON Remote keyless entry receiver: Receiving valid keyfob | <ul style="list-style-type: none"> Receiving the sleep-ready signal (Not-ready) from any units Push-button ignition switch (push switch): OFF→ON Hazard switch: OFF→ON PASSING switch: OFF→ON, ON→OFF TAIL LAMP switch: OFF→ON Front door switch LH: OFF→ON, ON→OFF Front door switch RH: OFF → ON, ON → OFF Driver door request switch: OFF→ON Passenger door request switch: OFF→ON Stop lamp switch signal: ON Remote keyless entry receiver: Receiving valid keyfob |

SHIPPING MODE CONTROL SYSTEM

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

SYSTEM


[BCM]

< SYSTEM DESCRIPTION >

SHIPPING MODE CONTROL SYSTEM : System Description

INFOID:000000014387215

SYSTEM DIAGRAM



DESCRIPTION

- The BCM switches the status (shipping mode or normal mode) by itself according to the extended storage switch condition, and transmits the shipping mode status signal to the combination meter and each unit via CAN communication.
- When the shipping mode function is activated, the control units will not detect DTCs.
- BCM control functions are limited in shipping mode. Refer to [BCS-78, "Description"](#).
- When the BCM is in shipping mode, a message may be shown in the combination meter or display.
- For shipping mode cancel operation refer to [BCS-65, "Work Procedure"](#).

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000014387216

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

| Direct Diagnostic Mode | Description |
|------------------------|--|
| ECU Identification | The BCM part number is displayed. |
| Self Diagnostic Result | The BCM self diagnostic results are displayed. |
| Data Monitor | The BCM input/output data is displayed in real time. |
| Active Test | The BCM activates outputs to test components. |
| Work support | The settings for BCM functions can be changed. |
| Configuration | <ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM. |
| CAN Diag Support Mntr | The result of transmit/receive diagnosis of CAN communication is displayed. |

SYSTEM APPLICATION

BCM can perform the following functions:

| System | Sub System | Direct Diagnostic Mode | | | | | | |
|--------------------------------------|-----------------|------------------------|------------------------|--------------|-------------|--------------|---------------|-----------------------|
| | | ECU Identification | Self Diagnostic Result | Data Monitor | Active Test | Work support | Configuration | CAN Diag Support Mntr |
| Door lock | DOOR LOCK | | × | × | × | × | | |
| Rear window defogger | REAR DEFOGGER | | | × | × | × | | |
| Warning chime | BUZZER | | | × | × | | | |
| Interior room lamp timer | INT LAMP | | | × | × | × | | |
| Exterior lamp | HEADLAMP | | | × | × | × | | |
| Wiper and washer | WIPER | | | × | × | × | | |
| Turn signal and hazard warning lamps | FLASHER | | | × | × | × | | |
| Air conditioner | AIR CONDITIONER | | | × | | | | |
| Intelligent Key system | INTELLIGENT KEY | | × | × | × | × | | |
| Combination switch | COMB SW | | | × | | | | |
| BCM | BCM | × | × | | | × | × | × |
| Immobilizer | IMMU | | × | × | × | | | |
| Interior room lamp battery saver | BATTERY SAVER | | | × | × | | | |
| Vehicle security system | THEFT ALM | | | × | × | × | | |
| RAP system | RETAINED PWR | | | × | | | | |
| Signal buffer system | SIGNAL BUFFER | | | × | | | | |

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays it on CONSULT.

A
B
C
D
E
F
G
H
I
J
K
L
BCS
N
O
P

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

| CONSULT screen item | Indication/Unit | Description |
|---------------------|-----------------|--|
| Vehicle Speed | km/h | Vehicle speed at the moment a particular DTC is detected |
| Odo/Trip Meter | km | Total mileage (Odometer value) at the moment a particular DTC is detected |
| Vehicle Condition | SLEEP>LOCK | While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"**). |
| | SLEEP>OFF | While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".) |
| | LOCK>ACC | While turning power supply position from "LOCK" *to "ACC" |
| | ACC>ON | While turning power supply position from "ACC" to "IGN" |
| | RUN>ACC | While turning power supply position from "RUN" to "ACC" (Vehicle is stopped and selector lever is in P position.) |
| | CRANK>RUN | While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it) |
| | RUN>URGENT | While turning power supply position from "RUN" to "ACC" (Emergency stop operation) |
| | ACC>OFF | While turning power supply position from "ACC" to "OFF" |
| | OFF>LOCK | While turning power supply position from "OFF" to "LOCK"** |
| | OFF>ACC | While turning power supply position from "OFF" to "ACC" |
| | ON>CRANK | While turning power supply position from "IGN" to "CRANKING" |
| | OFF>SLEEP | While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode |
| | LOCK>SLEEP | While turning BCM status from normal mode (Power supply position is "LOCK"*.) to low power consumption mode |
| | LOCK | Power supply position is "LOCK" (Ignition switch OFF)* |
| | OFF | Power supply position is "OFF" (Ignition switch OFF) |
| | ACC | Power supply position is "ACC" (Ignition switch ACC) |
| | ON | Power supply position is "IGN" (Ignition switch ON with engine stopped) |
| | ENGINE RUN | Power supply position is "RUN" (Ignition switch ON with engine running) |
| | CRANKING | Power supply position is "CRANKING" (At engine cranking) |
| IGN Counter | 0 - 39 | <p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition is switched OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. |

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met:

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

DOOR LOCK

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)

INFOID:0000000014387217

SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|------------------------|--|
| REQ SW-DR [On/Off] | Indicates condition of door request switch LH. |
| REQ SW-AS [On/Off] | Indicates condition of door request switch RH. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| DOOR LOCK | This test is able to check door lock operation [ALL LOCK/ALL UNLK]. |

WORK SUPPORT

| Support Item | Setting | Description |
|-------------------------|---------|---|
| DOOR LOCK-UNLOCK SET | On* | Automatic door locks function ON. |
| | Off | Automatic door locks function OFF. |
| AUTO UNLOCK TYPE | MODE2 | Driver door only unlocks automatically. |
| | MODE1* | All doors unlock automatically. |
| AUTO LOCK FUNCTION | MODE3 | This mode is not used. |
| | MODE2 | Doors lock automatically when shifted out of P (park). |
| | MODE1* | Doors lock automatically when vehicle speed reaches 24 km/h (15 mph). |
| | Off | — |
| AUTO UNLOCK FUNCTION | MODE3 | This mode is not used. |
| | MODE2* | Doors unlock automatically when shifted into P (park). |
| | MODE1 | Doors unlock automatically when ignition is switched from ON to OFF. |
| | Off | — |
| SIGNATURE LIGHT SETTING | On* | Signature light setting ON. |
| | Off | Signature light setting OFF. |

* : Initial setting

REAR DEFOGGER

REAR DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:000000014387218

DATA MONITOR

| Monitor Item [Unit] | Description |
|----------------------|---|
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| REAR DEF SW [On/Off] | Indicates condition of rear window defogger switch. |

ACTIVE TEST

| Test Item | Description |
|---------------|---|
| REAR DEFOGGER | This test is able to check rear window defogger operation [Off/On]. |

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

WORK SUPPORT

| Support Item | Setting | Description |
|-----------------|---------|--|
| SET R-DEF TIMER | MODE3 | Rear defogger turns OFF after 1 minute. |
| | MODE2 | Rear defogger remains ON until turned OFF. |
| | MODE1* | Rear defogger turns OFF after 15 minutes. |

* : Initial setting

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:0000000014387219

DATA MONITOR

| Monitor Item [Unit] | Description |
|-----------------------|---|
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| UNLK SEN -DR [On/Off] | Indicates condition of door unlock sensor. |
| VEH SPEED 1 [km/h] | Indicates vehicle speed signal received from ABS on CAN communication line. |
| TAIL LAMP SW [On/Off] | Indicates condition of combination switch. |
| FR FOG SW [On/Off] | Indicates condition of front fog lamp switch. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |

ACTIVE TEST

| Test Item | Description |
|---------------------|--|
| SEAT BELT WARN TEST | This test is able to check seat belt warning chime operation [On/Off]. |
| LIGHT WARN ALM | This test is able to check light warning chime operation [On/Off]. |
| REVERSE WARNING | This test is able to check reverse warning chime operation [On/Off]. |

INT LAMP

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:0000000014387220

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| REQ SW -DR [On/Off] | Indicates condition of door request switch LH. |
| REQ SW -AS [On/Off] | Indicates condition of door request switch RH. |
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| UNLK SEN -DR [On/Off] | Indicates condition of door unlock sensor. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |
| RKE-LOCK [On/Off] | Indicates condition of lock signal from Intelligent Key. |
| RKE-UNLOCK [On/Off] | Indicates condition of unlock signal from Intelligent Key. |

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

ACTIVE TEST

| Test Item | Description |
|----------------|---|
| INT LAMP | This test is able to check interior room lamp operation [On/Off]. |
| STEP LAMP TEST | This test is able to check step lamp operation [On/Off]. |
| Cargo lamp | This test is able to check cargo lamp operation [On/Off]. |

WORK SUPPORT

NOTE:

The items listed below are the only applicable Work Support items for this vehicle. If other items are displayed on CONSULT, do not use or change the setting for these other items.

| Support Item | Setting | Description |
|---------------------------|---------|---|
| SET I/L D-UNLCK INTCON | On | Interior room lamp timer function ON. |
| | Off* | Interior room lamp timer function OFF. |
| SCENARIO LIGHTING SETTING | On | NOTE: Do not use this function since interior room lamp control is changed. |
| | Off* | |
| FOG LAMP OVERRIDE | On* | With fog override function. |
| | Off | Without fog override function. |

*: Initial setting

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEADLAMP)

INFOID:0000000014387221

DATA MONITOR

| Monitor Item [Unit] | Description |
|-------------------------------------|--|
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| ENGINE STATE [Stop/Stall/Crank/Run] | Indicates engine status received from ECM on CAN communication line. |
| VEH SPEED 1 [km/h] | Indicates vehicle speed signal received from ABS on CAN communication line. |
| TURN SIGNAL R [On/Off] | Indicates condition of combination switch. |
| TURN SIGNAL L [On/Off] | |
| TAIL LAMP SW [On/Off] | |
| HI BEAM SW [On/Off] | |
| HEAD LAMP SW 1 [On/Off] | |
| HEAD LAMP SW 2 [On/Off] | |
| PASSING SW [On/Off] | |
| AUTO LIGHT SW [On/Off] | |
| FR FOG SW [On/Off] | |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| OPTI SEN (DTCT) [V] | Indicates outside brightness voltage signal from optical sensor. |
| OPTI SEN (FILT) [V] | Indicates outside brightness voltage signal from optical sensor filtered by BCM. |

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

| Test Item | Description |
|-----------------------|---|
| FR FOG LAMP | This test is able to check front fog lamp operation [On/Off]. |
| DAYTIME RUNNING LIGHT | This test is able to check daytime running lamp operation [On/Off]. |
| ILL DIM SIGNAL | This test is able to check head lamp illumination dimming operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|------------------------|---------|--|
| TWILIGHT ON | MODE2* | Auto lamp function ON. |
| | MODE1 | Auto lamp function OFF. |
| WIPER LINK | MODE4 | This mode is not used. |
| | MODE3* | Wiper link function operates in INT, LOW and HI. |
| | MODE2 | Wiper link function operates in LOW and HI. |
| | MODE1 | Wiper link function OFF. |
| CUSTOM A/LIGHT SETTING | MODE4 | Less sensitive than normal setting (turns ON later). |
| | MODE3 | More sensitive than MODE2. |
| | MODE2 | More sensitive than normal setting (turns ON earlier). |
| | MODE1* | Normal setting. |
| ILL DELAY SET | MODE 8 | Auto lamp delay timer. |
| | MODE 7 | |
| | MODE 6 | |
| | MODE 4 | |
| | MODE 5 | |
| | MODE 3 | |
| | MODE 2 | |
| | MODE 1* | |

*: Initial setting

WIPER

WIPER : CONSULT Function (BCM - WIPER)

INFOID:0000000014387222

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| VEH SPEED 1 [km/h] | Indicates vehicle speed signal received from ABS on CAN communication line. |
| FR WIPER HI [On/Off] | Indicates condition of wiper operation of combination switch. |
| FR WIPER LOW [On/Off] | |
| FR WASHER SW [On/Off] | |
| FR WIPER INT [On/Off] | |
| FR WIPER STOP [On/Off] | Indicates front wiper auto stop signal received from IPDM E/R on CAN communication line. |
| INT VOLUME [1 – 5] | Indicates condition of intermittent wiper [1 - 5] or auto wiper [1 - 4] operation of combination switch. |
| RAIN SENSOR [On/Off] | Indicates condition of rain sensor. |

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

| Test Item | Description |
|-----------|---|
| FR WIPER | This test is able to check front wiper operation [Hi/Lo/INT/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|---------------------|---------|--|
| WIPER SPEED SETTING | On | Front wiper intermittent time linked with vehicle speed and wiper dial position. |
| | Off* | Front wiper intermittent time linked with wiper dial position. |
| RAIN SENSOR | On* | Rain sensor function ON. |
| | Off | Rain sensor function OFF. |

*: Initial setting

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000014387223

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| REQ SW -DR [On/Off] | Indicates condition of door request switch LH. |
| REQ SW -AS [On/Off] | Indicates condition of door request switch RH. |
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| TURN SIGNAL R [On/Off] | Indicates condition of turn signal function of combination switch. |
| TURN SIGNAL L [On/Off] | Indicates condition of turn signal function of combination switch. |
| HAZARD SW [On/Off] | Indicates condition of hazard switch. |
| RKE-LOCK [On/Off] | Indicates condition of lock signal from Intelligent Key. |
| RKE-UNLOCK [On/Off] | Indicates condition of unlock signal from Intelligent Key. |
| RKE-PANIC [On/Off] | Indicates condition of panic alarm signal from Intelligent Key. |

ACTIVE TEST

| Test Item | Description |
|-----------|--|
| FLASHER | This test is able to check turn signal lamp operation [Off/LH/RH]. |

WORK SUPPORT

| Support item | Setting | Description |
|------------------------|---------|-----------------------------|
| 3-TIME FLASHER SETTING | ON* | 3-Time flasher setting ON. |
| | OFF | 3-Time flasher setting OFF. |

* : Initial setting

AIR CONDITIONER

AIR CONDITIONER : CONSULT Function (BCM - AIR CONDITIONER)

INFOID:000000014387224

DATA MONITOR

| Monitor Item [Unit] | Description |
|----------------------|------------------------------------|
| FAN ON SIG [On/Off] | Indicates condition of fan switch. |
| AIR COND SW [On/Off] | Indicates condition of A/C switch. |

INTELLIGENT KEY

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000014387225

SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

DATA MONITOR

| Monitor Item [Unit] | Main | Description |
|---|------|--|
| REQ SW -DR [On/Off] | × | Indicates condition of door request switch LH. |
| REQ SW -AS [On/Off] | × | Indicates condition of door request switch RH. |
| PUSH SW [On/Off] | | Indicates condition of push-button ignition switch. |
| SHIFTLOCK SOLENOID PWR SUPPLY [On/Off] | × | Indicates condition of power supply to shiftlock solenoid. |
| BRAKE SW 1 [On/Off] | × | Indicates condition of brake switch. |
| BRAKE SW 2 [On/Off] | | Indicates condition of brake switch. |
| DETE/CANCL SW [On/Off] | × | Indicates condition of P (park) position. |
| SFT PN/N SW [On/Off] | × | Indicates condition of P (park) or N (neutral) position. |
| UNLK SEN -DR [On/Off] | × | Indicates condition of door unlock sensor. |
| PUSH SW -IPDM [On/Off] | | Indicates condition of push-button ignition switch received from IPDM E/R on CAN communication line. |
| IGN RLY1 -F/B [On/Off] | | Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line. |
| DETE SW -IPDM [On/Off] | | Indicates condition of park position switch received from TCM on CAN communication line. |
| SFT PN -IPDM [On/Off] | | Indicates condition of P (park) or N (neutral) position from TCM on CAN communication line. |
| SFT P -MET [On/Off] | | Indicates condition of P (park) position from TCM on CAN communication line. |
| SFT N -MET [On/Off] | | Indicates condition of N (neutral) position from IPDM E/R on CAN communication line. |
| ENGINE STATE [Stop/Start/Crank/Run] | × | Indicates condition of engine state from ECM on CAN communication line. |
| VEH SPEED 1 [mph/km/h] | × | Indicates condition of vehicle speed signal received from ABS on CAN communication line. |
| VEH SPEED 2 [mph/km/h] | × | Indicates condition of vehicle speed signal received from combination meter on CAN communication line. |
| DOOR STAT -DR [LOCK/READY/UNLK] | × | Indicates condition of driver side door status. |
| DOOR STAT -AS [LOCK/READY/UNLK] | × | Indicates condition of passenger side door status. |
| DOOR STAT -RR [LOCK/READY/UNLK] | × | Indicates condition of rear right side door status. |
| DOOR STAT -RL [LOCK/READY/UNLK] | × | Indicates condition of rear left side door status. |
| ID OK FLAG [Set/Reset] | | Indicates condition of Intelligent Key ID. |
| PRMT ENG STRT [Set/Reset] | | Indicates condition of engine start possibility. |
| PRMT RKE STRT [Set/Reset] | | Indicates condition of engine start possibility from Intelligent Key. |
| I-KEY OK FLAG [Key ON/Key OFF] | × | Indicates condition of Intelligent Key OK flag. |
| PRBT ENG STRT [Set/Reset] | | Indicates condition of engine start prohibit. |
| ID AUTHENTICATION CANCEL TIMER [under a stop] | | Indicates condition of Intelligent Key ID authentication. |
| ACC BATTERY SAVER [under a stop] | | Indicates condition of battery saver. |
| CRNK PRBT TMR [On/Off] | | Indicates condition of crank prohibit timer. |
| AUT CRNK TMR [On/Off] | | Indicates condition of automatic engine crank timer from Intelligent Key. |
| CRNK PRBT TME [sec] | | Indicates condition of crank prohibit timer. |
| AUT CRNK TMR [sec] | | Indicates condition of automatic engine crank timer from Intelligent Key. |

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Main | Description |
|-----------------------|------|--|
| CRANKING TME [sec] | | Indicates condition of engine cranking time from Intelligent Key. |
| ST RLY -REQ | | Indicates condition of starter relay. |
| IGN RLY 1 -REQ | | Indicates condition of ignition 1 relay. |
| IGN RLY 2 -REQ | | Indicates condition of ignition 2 relay. |
| DETE SW PWR [On/Off] | | Indicates condition of park position switch voltage. |
| ACC RLY -REQ [On/Off] | | Indicates condition of accessory relay control request. |
| RKE OPE COUN1 [0-19] | × | When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing. |
| RKE OPE COUN2 [0-19] | × | When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing. |
| RKE-LOCK [On/Off] | | Indicates condition of lock signal from Intelligent Key. |
| RKE-UNLOCK [On/Off] | | Indicates condition of unlock signal from Intelligent Key. |
| RKE-PANIC [On/Off] | | Indicates condition of panic signal from Intelligent Key. |
| RKE-MODE CHG [On/Off] | | Indicates condition of mode change signal from Intelligent Key. |

ACTIVE TEST

| Test Item | Description |
|----------------------------|--|
| INTELLIGENT KEY LINK (CAN) | This test is able to check Intelligent Key identification number [Off/ID No1/ID No2/ID No3/ID No4/ID No5]. |
| INT LAMP | This test is able to check interior room lamp operation [On/Off]. |
| FLASHER | This test is able to check hazard lamp operation [LH/RH/Off]. |
| HORN | This test is able to check horn operation [On]. |
| BATTERY SAVER | This test is able to check battery saver operation [On/Off]. |
| OUTSIDE BUZZER | This test is able to check Intelligent Key warning buzzer operation [On/Off]. |
| INSIDE BUZZER | This test is able to check combination meter warning chime operation [Take Out/Knob/Key/Off]. |
| INDICATOR | This test is able to check combination meter warning lamp operation [KEY ON/KEY IND/Off]. |
| IGN CONT2 | This test is able to check ignition relay-2 control operation [On/Off]. |
| ENGINE SW ILLUMI | This test is able to check push-button ignition switch START indicator operation [On/Off]. |
| PUSH SWITCH INDICATOR | This test is able to check push-button ignition switch indicator operation [On/Off]. |
| ACC CONT | This test is able to check accessory relay control operation [On/Off]. |
| IGN CONT1 | This test is able to check ignition relay-1 control operation [On/Off]. |
| ST CONT LOW | This test is able to check starter control relay operation [On/Off]. |
| IGNITION RELAY | This test is able to check ignition relay operation [On/Off]. |
| TRUNK/LUGGAGE LAMP TEST | This test is able to check cargo lamp illumination operation [On/Off]. |
| KEYFOB PW TEST | This test is able to check power window operation using the Intelligent Key [P/W up/down OFF/Send P/W down ON/Send P/W up ON]. |
| SHIFTLOCK SOLENOID TEST | This test is able to check shift lock solenoid operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|-----------------------|---------|-----------------------------------|
| IGN/ACC BATTERY SAVER | On* | Battery saver function ON. |
| | Off | Battery saver function OFF. |
| REMOTE ENGINE STARTER | On* | Remote engine start function ON. |
| | Off | Remote engine start function OFF. |

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

| Support Item | Setting | Description |
|--------------------------------|----------|---|
| ANSWERBACK I-KEY LOCK UNLOCK | BUZZER* | Buzzer reminder function by door lock/unlock request switch ON. |
| | HORN | Horn chirp reminder function by door lock request switch ON. |
| | Off | No reminder function by door lock/unlock request switch. |
| | INVALID | This mode is not used. |
| ANSWERBACK KEYLESS LOCK UNLOCK | On* | Buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key. |
| | Off | No buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key. |
| ANSWER BACK | On* | Horn chirp reminder when doors are locked with Intelligent Key. |
| | Off | No horn chirp reminder when doors are locked with Intelligent Key. |
| RETRACTABLE MIRROR SET | On | Retractable mirror set ON. |
| | Off* | Retractable mirror set OFF. |
| LOCK/UNLOCK BY I-KEY | On* | Door lock/unlock function from Intelligent Key ON. |
| | Off | Door lock/unlock function from Intelligent Key OFF. |
| ENGINE START BY I-KEY | On* | Engine start function from Intelligent Key ON. |
| | Off | Engine start function from Intelligent Key OFF. |
| CONFIRM KEY FOB ID | — | Intelligent Key ID code can be checked. |
| SHORT CRANKING OUTPUT | Start | Starter motor operation duration times. |
| | 70 msec | |
| | 100 msec | |
| | 200 msec | |
| END | — | — |
| INSIDE ANT DIAGNOSIS | — | This function allows inside key antenna self-diagnosis. |
| AUTO LOCK SET | MODE7 | 5 min |
| | MODE6 | 4 min |
| | MODE5 | 3 min |
| | MODE4 | 2 min |
| | MODE3* | 1 min |
| | MODE2 | 30 sec |
| | MODE1 | Off |

*: Initial Setting

COMB SW

COMB SW : CONSULT Function (BCM - COMB SW)

INFOID:0000000014387226

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| FR WIPER HI [On/Off] | Indicates condition of wiper operation of combination switch. |
| FR WIPER LOW [On/Off] | |
| FR WASHER SW [On/Off] | |
| FR WIPER INT [On/Off] | |
| INT VOLUME [1 - 5] | Indicates condition of intermittent wiper [1 - 5] or auto wiper [1 - 4] operation of combination switch. |
| TURN SIGNAL R [On/Off] | Indicates condition of right turn signal operation of combination switch. |
| TURN SIGNAL L [On/Off] | Indicates condition of left turn signal operation of combination switch. |
| TAIL LAMP SW [On/Off] | Indicates condition of tail lamp switch operation of combination switch. |

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|-------------------------|---|
| HI BEAM SW [On/Off] | Indicates condition of high beam switch operation of combination switch. |
| HEAD LAMP SW 1 [On/Off] | Indicates condition of head lamp switch 1 operation of combination switch. |
| HEAD LAMP SW 2 [On/Off] | Indicates condition of head lamp switch 2 operation of combination switch. |
| PASSING SW [On/Off] | Indicates condition of passing switch operation of combination switch. |
| AUTO LIGHT SW [On/Off] | Indicates condition of auto light switch operation of combination switch. |
| FR FOG SW [On/Off] | Indicates condition of front fog lamp switch operation of combination switch. |

BCM

BCM : CONSULT Function (BCM - BCM)

INFOID:000000014387227

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

ECU IDENTIFICATION

The BCM part number is displayed.

SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

WORK SUPPORT

| Support Item | Setting | Description |
|---------------------|---------|---|
| RESET SETTING VALUE | Reset | Returns BCM to initial value in factory shipment. |
| | Cancel | Cancels the reset function. |

CONFIGURATION

Refer to [BCS-63, "CONFIGURATION \(BCM\) : Description"](#).

CAN DIAG SUPPORT MNTR

Refer to [LAN-50, "CAN Diagnostic Support Monitor"](#).

IMMU

IMMU : CONSULT Function (BCM - IMMU)

INFOID:000000014387228

K

L

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------------|--|
| CONFIRM ID ALL [Yet/DONE] | Switches to DONE when an Intelligent Key is registered. |
| CONFIRM ID4 [Yet/DONE] | |
| CONFIRM ID3 [Yet/DONE] | |
| CONFIRM ID2 [Yet/DONE] | |
| CONFIRM ID1 [Yet/DONE] | |
| TP 4 [Yet/DONE] | DONE indicates the number of the Intelligent Key ID which has been registered. |
| TP 3 [Yet/DONE] | |
| TP 2 [Yet/DONE] | |
| TP 1 [Yet/DONE] | |
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| THEFT IND | This test is able to check security indicator operation [On/Off]. |

O

P

N

2017 Titan NAM

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:0000000014387229

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| REQ SW -DR [On/Off] | Indicates condition of door request switch LH. |
| REQ SW -AS [On/Off] | Indicates condition of door request switch RH. |
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| UNLK SEN -DR [On/Off] | Indicates condition of door unlock sensor. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |
| RKE-LOCK [On/Off] | Indicates condition of lock signal from Intelligent Key. |
| RKE-UNLOCK [On/Off] | Indicates condition of unlock signal from Intelligent Key. |

ACTIVE TEST

| Test item | Description |
|---------------|--|
| BATTERY SAVER | This test is able to check battery saver operation [On/Off]. |

THEFT ALM

THEFT ALM : CONSULT Function (BCM - THEFT ALM)

INFOID:0000000014387230

DATA MONITOR

| Monitor Item | Description |
|------------------------|--|
| REQ SW -DR [On/Off] | Indicates condition of door request switch LH. |
| REQ SW -AS [On/Off] | Indicates condition of door request switch RH. |
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| UNLK SEN -DR [On/Off] | Indicates condition of door unlock sensor. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |
| RKE-LOCK [On/Off] | Indicates condition of lock signal from Intelligent Key. |
| RKE-UNLOCK [On/Off] | Indicates condition of unlock signal from Intelligent Key. |

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

| Test Item | Description |
|-----------------------|--|
| FLASHER | This test is able to check turn signal lamp operation [LH/RH/Off]. |
| THEFT IND | This test is able to check security indicator lamp operation [On/Off]. |
| VEHICLE SECURITY HORN | This test is able to check vehicle security horn operation [On]. |
| HEADLAMP(HI) | This test is able to check vehicle security lamp operation [On]. |

WORK SUPPORT

| Support Item | Setting | Description |
|--------------------|---------|---------------------|
| SECURITY ALARM SET | On* | Security alarm ON. |
| | Off | Security alarm OFF. |

*: Initial setting

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000014387231

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------|--|
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |

SIGNAL BUFFER

SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER)

INFOID:000000014387232

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------|---|
| PUSH SW [On/Off] | Indicates condition of the push-button ignition switch. |

A

B

C

D

E

F

G

H

J

K

L

BCS

N

O

P

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM

Reference Value

INFOID:000000014387233

NOTE:

The Signal Tech II Tool [— (J-50190)] can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs
- Check Intelligent Key relative signal strength
- Confirm vehicle Intelligent Key antenna signal strength

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item | Condition | Value/Status |
|-------------------|--|--------------|
| ACC BATTERY SAVER | When battery saver is OFF | Under a stop |
| ACC RLY -REQ | When BCM is not requesting accessory relay activation. | Off |
| | When BCM is requesting accessory relay activation. | On |
| AIR COND SW | A/C switch OFF | Off |
| | A/C switch ON | On |
| AUTO CRNK TMR | When the remote engine start timer is OFF. | Off |
| | When the remote engine start timer is ON. | On |
| AUTO CRNK TMR | Remote engine start timer duration in seconds. | sec |
| AUTO LIGHT SW | Lighting switch OFF | Off |
| | Lighting switch AUTO | On |
| BRAKE SW 1 | When the brake pedal is released | On |
| | When the brake pedal is depressed | Off |
| BRAKE SW 2 | Brake pedal released | Off |
| | Brake pedal depressed | On |
| BUZZER | Buzzer in combination meter OFF | Off |
| | Buzzer in combination meter ON | On |
| CDL LOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the LOCK side | On |
| CDL UNLOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the UNLOCK side | On |
| CONFIRM ID ALL | The key ID does not match any key ID registered to BCM. | Yet |
| | The key ID matches any key ID registered to BCM. | DONE |
| CONFIRM ID4 | The key ID does not match the fourth key ID registered to BCM. | Yet |
| | The key ID matches the fourth key ID registered to BCM. | DONE |
| CONFIRM ID3 | The key ID does not match the third key ID registered to BCM. | Yet |
| | The key ID matches the third key ID registered to BCM. | DONE |
| CONFIRM ID2 | The key ID does not match the second key ID registered to BCM. | Yet |
| | The key ID matches the second key ID registered to BCM. | DONE |
| CONFIRM ID1 | The key ID does not match the first key ID registered to BCM. | Yet |
| | The key ID matches the first key ID registered to BCM. | DONE |
| CRANKING TME | Engine start timer duration. | sec |

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|---------------|--|--------------|-----|
| CRNK PRBT TME | Engine start prohibit timer duration. | sec | A |
| CRNK PRBT TMR | When the engine start prohibit timer is OFF. | Off | B |
| | When the engine start prohibit timer is ON. | On | |
| DETE SW -IPDM | When selector lever is in P position | Off | C |
| | When selector lever is in any position other than P | On | |
| DETE SW PWR | When BCM is not supplying power to park position switch. | Off | D |
| | When BCM is supplying power to park position switch. | On | |
| DETE/CANCL SW | When selector lever is in P position | Off | E |
| | When selector lever is in any position other than P | On | |
| DOOR STAT-AS | Passenger door LOCK status | LOCK | F |
| | Passenger door UNLOCK status | UNLK | |
| | Wait with selective UNLOCK operation (5 seconds) | READY | |
| DOOR STAT-DR | Driver door LOCK status | LOCK | G |
| | Driver door UNLOCK status | UNLK | |
| | Wait with selective UNLOCK operation (5 seconds) | READY | |
| DOOR STAT-RL | Rear left door LOCK status | LOCK | H |
| | Rear left door UNLOCK status | UNLK | |
| | Wait with selective UNLOCK operation (5 seconds) | READY | |
| DOOR STAT-RR | Rear right door LOCK status | LOCK | I |
| | Rear right door UNLOCK status | UNLK | |
| | Wait with selective UNLOCK operation (5 seconds) | READY | |
| DOOR SW-AS | Front door RH closed | Off | J |
| | Front door RH opened | On | |
| DOOR SW-DR | Front door LH closed | Off | K |
| | Front door LH opened | On | |
| DOOR SW-RL | Rear door LH closed | Off | L |
| | Rear door LH opened | On | |
| DOOR SW-RR | Rear door RH closed | Off | M |
| | Rear door RH opened | On | |
| ENGINE STATE | Engine stopped | Stop | BCS |
| | While the engine stalls | Stall | |
| | At engine cranking | Crank | |
| | Engine running | Run | |
| FAN ON SIG | Blower motor fan switch OFF | Off | N |
| | Blower motor fan switch ON | On | |
| FR FOG SW | Front fog lamp switch OFF | Off | O |
| | Front fog lamp switch ON | On | |
| FR WASHER SW | Front washer switch OFF | Off | P |
| | Front washer switch ON | On | |
| FR WIPER LOW | Front wiper switch OFF | Off | Q |
| | Front wiper switch LO | On | |
| FR WIPER HI | Front wiper switch OFF | Off | R |
| | Front wiper switch HI | On | |

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|--------------------------------|--|--------------|
| FR WIPER INT | Front wiper switch OFF | Off |
| | Front wiper switch INT or AUTO | On |
| FR WIPER STOP | Any position other than front wiper stop position | Off |
| | Front wiper stop position | On |
| HAZARD SW | When hazard switch is not pressed | Off |
| | When hazard switch is pressed | On |
| HEAD LAMP SW 1 | Headlamp switch OFF | Off |
| | Headlamp switch 1st | On |
| HEAD LAMP SW 2 | Headlamp switch OFF | Off |
| | Headlamp switch 1st | On |
| HI BEAM SW | High beam switch OFF | Off |
| | High beam switch HI | On |
| ID AUTHENTICATION CANCEL TIMER | When I-Key authentication is OFF. | Under a stop |
| ID OK FLAG | Ignition switch ACC or ON | Reset |
| | Ignition switch OFF | Set |
| IGN RLY1 F/B | Ignition switch OFF or ACC | Off |
| | Ignition switch ON | On |
| IGN RLY 1 -REQ | Ignition switch OFF or ACC | Off |
| | Ignition switch ON | On |
| IGN RLY 2 -REQ | Ignition switch OFF or ACC | Off |
| | Ignition switch ON | On |
| INT VOLUME | Wiper intermittent dial is in dial position 1 - 5 or AUTO dial is in position 1 - 4. | 1 - 5 |
| I-KEY OK FLAG | I-Key OFF | Key OFF |
| | I-Key ON | Key ON |
| KEY CYL LK-SW | Door key cylinder LOCK position | Off |
| | Door key cylinder other than LOCK position | On |
| KEY CYL UN-SW | Door key cylinder UNLOCK position | Off |
| | Door key cylinder other than UNLOCK position | On |
| OPTI SEN (DTCT) | Bright outside the vehicle | Close to 5V |
| | Dark outside the vehicle | Close to 0V |
| OPTI SEN (FILT) | Bright outside the vehicle | Close to 5V |
| | Dark outside the vehicle | Close to 0V |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| PRBT ENG STRT | When the engine start is prohibited | Reset |
| | When the engine start is permitted | Set |
| PRMT ENG STRT | When the engine start is prohibited | Reset |
| | When the engine start is permitted | Set |
| PRMT RKE STRT | When the engine start is prohibited | Reset |
| | When the engine start is permitted | Set |
| PUSH SW | Return ignition switch to LOCK position | Off |
| | Press ignition switch | On |

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|----------------------------------|---|--------------|
| PUSH SW-IPDM | When engine switch (push switch) is not pressed | Off |
| | When engine switch (push switch) is pressed | On |
| RAIN SENSOR | Rain sensor OFF | Off |
| | Rain sensor ON | On |
| REAR DEF SW | Rear window defogger switch OFF | Off |
| | Rear window defogger switch ON | On |
| REQ SW-AS | When passenger door request switch is not pressed | Off |
| | When passenger door request switch is pressed | On |
| REQ SW-DR | When driver door request switch is not pressed | Off |
| | When driver door request switch is pressed | On |
| REQ SW -RL | When rear door request switch LH is not pressed | Off |
| | When rear door request switch LH is pressed | On |
| REQ SW -RR | When rear door request switch RH is not pressed | Off |
| | When rear door request switch RH is pressed | On |
| RKE-LOCK | When LOCK button of Intelligent Key is not pressed | Off |
| | When LOCK button of Intelligent Key is pressed | On |
| RKE-MODE CHG | When LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously | Off |
| | When LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously | On |
| RKE OPE COUN1 | Operation frequency of Intelligent Key | 0-19 |
| RKE OPE COUN2 | Operation frequency of Intelligent Key | 0-19 |
| RKE-PANIC | When PANIC button of Intelligent Key is not pressed | Off |
| | When PANIC button of Intelligent Key is pressed | On |
| RKE-UNLOCK | When UNLOCK button of Intelligent Key is not pressed | Off |
| | When UNLOCK button of Intelligent Key is pressed | On |
| SFT N-MET | When selector lever is in any position other than N | Off |
| | When selector lever is in N position | On |
| SFT P-MET | When selector lever is in any position other than P | Off |
| | When selector lever is in P position | On |
| SFT PN -IPDM | When selector lever is in any position other than P or N | Off |
| | When selector lever is in P or N position | On |
| SFT PN/N SW | When selector lever is in any position other than P or N | Off |
| | When selector lever is in P or N position | On |
| SHIFTLOCK SOLE-NOID POWER SUPPLY | When BCM is not supplying power to shift lock. | Off |
| | When BCM is supplying power to shift lock. | On |
| ST RLY -REQ | Ignition switch OFF or ACC | Off |
| | Ignition switch ON | On |
| TAIL LAMP SW | Other than lighting switch 1ST and 2ND | Off |
| | Lighting switch 1ST or 2ND | On |
| TP 4 | The ID of fourth key is not registered to BCM | Yet |
| | The ID of fourth key is registered to BCM | DONE |
| TP 3 | The ID of third key is not registered to BCM | Yet |
| | The ID of third key is registered to BCM | DONE |

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

BCM


< ECU DIAGNOSIS INFORMATION >

[BCM]

| Monitor Item | Condition | Value/Status |
|---------------|--|--------------|
| TP 2 | The ID of second key is not registered to BCM | Yet |
| | The ID of second key is registered to BCM | DONE |
| TP 1 | The ID of first key is not registered to BCM | Yet |
| | The ID of first key is registered to BCM | DONE |
| TURN SIGNAL L | Turn signal switch OFF | Off |
| | Turn signal switch LH | On |
| TURN SIGNAL R | Turn signal switch OFF | Off |
| | Turn signal switch RH | On |
| UNLK SEN-DR | Driver door UNLOCK status | Off |
| | Driver door LOCK status | On |
| VEH SPEED 1 | While driving, equivalent to speedometer reading | mph, km/h |
| VEH SPEED 2 | While driving, equivalent to speedometer reading | mph, km/h |




< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT






PHYSICAL VALUES

A
B
C
D
E
F
G
H
I
J
K
L
BCS
N
O
P

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---------------------------------|------------------|---|---|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 1 (G) | Ground | Engine start switch | Input | Push-button igni-tion switch | Pressed | 0V |
| | | | | | Not pressed | Battery voltage |
| 3 (R) | Ground | Auto light power sup- ply 5V | Output | Push-button igni-tion switch | OFF | 0V |
| | | | | | ACC or ON | 5V |
| 4 (W/R) | Ground | Auto light signal | Input | Push-button igni-tion switch ON | When outside of the vehi- cle is bright | Close to 5V |
| | | | | | When outside of the vehi- cle is dark | Close to 0V |
| 10 (SB) | Ground | Combination switch input 5 | Input | Combination and lighting switches | OFF | 0 V |
| | | | | Combination switch | TURN RH |  PKIB4958J 1.0 V |
| | | | | | HI BEAM | |
| | | | | Lighting switch | HEADLAMP 1 | |
| 11 (G/Y) | Ground | Combination switch input 4 | Input | Combination, front fog lamps and lighting switches | OFF | 0 V |
| | | | | Front fog lamps switch | ON |  PKIB4958J 1.0 V |
| | | | | Combination switch | TURN LH | |
| | | | | | PASSING | |
| 12 (Y) | Ground | Combination switch input 3 | Input | Lighting switch | HEADLAMP 2 | |
| | | | | Combination and lighting switches | OFF | 0 V |
| | | | | Combination switch | FR WIPER LOW |  PKIB4958J 1.0 V |
| | | | | | FR WIPER INT (any intermittent position) | |
| | | | | Lighting switch | TAIL LAMP | |
| | | | | | AUTO LAMP | |

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--------------------------------|------------------|---------------------------------|---------------------------------------|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 13 (G/B) | Ground | Combination switch input 2 | Input | Combination switch | OFF | 0 V |
| | | | | | FR WASHER | |
| | | | | | Wiper intermittent dial 2 | |
| | | | | | Wiper AUTO dial 2 | |
| | | | | | Wiper intermittent dial 3 |  PKIB4958J 1.0 V |
| 14 (V) | Ground | Combination switch input 1 | Input | Combination switch | OFF | 0 V |
| | | | | | FR WIPER HI | |
| | | | | | Wiper intermittent dial 1 | |
| | | | | | Wiper AUTO dial 1 | |
| | | | | | Wiper intermittent dial 2 | |
| | | | | | Wiper AUTO dial 4 | |
| | | | | | Wiper intermittent dial 5 |  PKIB4958J 1.0 V |
| 17 (P) | Ground | Auto light reference ground | Input | Push-button ignition switch ON | | 0V |
| 18 (V) | Ground | Security indicator | Output | Security indicator | ON | 0V |
| | | | | | Blinking |  JPMIA0014GB 11.3V |
| | | | | | OFF | Battery voltage |
| 20 (R) | Ground | Shift P | Input | Selector lever | P position | 0V |
| | | | | | Any position other than P | Battery voltage |
| 21 (R/W) | Ground | Step lamp control | Output | Step lamp | ON | 0V |
| | | | | | OFF | Battery voltage |
| 23 (Y) | Ground | Air conditioner sw | Input | A/C switch | OFF | 9.0 - 12.0V |
| | | | | | ON | 0V |
| 25 (W) | Ground | Brake switch fuse | Input | — | | Battery voltage |
| 26 (L) | Ground | Shorting input | Input | Push-button ignition switch OFF | | Battery voltage |
| 27 (R/G) | Ground | Brake switch lamp | Input | Stop lamp switch | OFF (brake pedal is not depressed) | 0V |
| | | | | | ON (brake pedal is de- pressed) | Battery voltage |
| 29 (W) | Ground | Blower fan sw | Input | Blower motor switch | ON | Battery voltage |
| | | | | | OFF | 0V |

A

B

C

D

E

F

G

H

I

J

K

L



BCS

N



O

P

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|---|--|--|
| (+) | (-) | Signal name | Input/ Output | | | |
| 30 (P) | Ground | Driver door lock status | Input | Front door LH | LOCK status |  <small>JPMIA0011GB</small> 11.8V |
| | | | | | UNLOCK status | 0V |
| 32 (Y) | Ground | Rear window defogger ON signal | Input | Rear window defogger switch | OFF | 5V |
| | | | | | ON | 0V |
| 35 (R/G) | Ground | Trailer brake control unit brake switch | Input | Trailer brake control unit (pinch) switch | OFF (trailer brake control unit pinch switch is not depressed) | 0V |
| | | | | | ON (trailer brake control unit pinch switch is depressed) | Battery voltage |
| 36 (W/B) | Ground | Hazard switch | Input | Hazard switch | Pressed | 0 V |
| | | | | | Not pressed |  <small>JPMIA0012GB</small> 1.1V |
| 39 (B/R) | Ground | Shift N/P | Input | Selector lever | P or N position | Battery voltage |
| | | | | | Except P and N positions | 0V |
| 41 (Y/L) | Ground | Trailer light check relay output (vehicle stop lamps during trailer light check) | Output | Intelligent Key | Press and release LOCK button, within 2 seconds press and hold LOCK button for at least 2 seconds (keyfob), or Operate trailer light check from combination meter (Trailer Settings) | Battery voltage |
| | | | | | Except above | 0V |
| 42 (R/Y) | Ground | Cargo lamp output | Output | Cargo lamp switch | ON | 0V |
| | | | | | OFF | Battery voltage |
| 48 (R) | Ground | High side start switch LED | Output | Push-button ignition switch illumination | ON | 5.5V |
| | | | | | OFF | 0V |
| 52 (W) | Ground | Audio dongle | Input/ Output | Push-button ignition switch OFF | | 5V |

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|-------------------------------------|---|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 54 (W/L) | Ground | Power window lin/ communication | Input/ Output | Push-button igni- tion switch | ON |  <small>JPMIA0013GB</small> 10.2V |
| | | | | | OFF or ACC | |
| 55 (W/B) | Ground | Rain sensor K-line | Input/ Output | Push-button igni- tion switch | OFF | 0V |
| | | | | | ON |  <small>JPMIA0156GB</small> 8.0 – 9.0V |
| 59 (P) | Ground | CAN low | Input/ Output | — | | — |
| 60 (L) | Ground | CAN high | Input/ Output | — | | — |
| 61 (O) | Ground | Rear defogger relay output | Output | Rear window de- fogger | Active | Battery voltage |
| | | | | | Not activated | 0V |
| 62 (W) | Ground | Starter relay output | Output | Push-button igni- tion switch ON | When selector lever is in P or N position and the brake is depressed | Battery voltage |
| | | | | | When selector lever is in P or N position and the brake is not depressed | 0V |
| 64 (P) | Ground | Buzzer output | Output | Outside warning buzzer | Sounding | 0V |
| | | | | | Not sounding | Battery voltage |
| 66 (W) | Ground | Blower fan relay out- put | Output | Push-button igni- tion switch | OFF or ACC | 0V |
| | | | | | ON | Battery voltage |
| 67 (G) | Ground | Ignition electrical re- lay output 2 | Output | Push-button igni- tion switch | OFF or ACC | 0V |
| | | | | | ON | Battery voltage |
| 68 (L) | Ground | Dimmer signal output | Output | Push-button igni- tion switch ON | Either of the following con- ditions: • Lighting switch OFF • The area around the ve- hicle is bright (Shine a light on the optical sen- sor) | 0V |
| | | | | | The area around the ve- hicle is dark (Block the light from the optical sensor) | Battery voltage |
| 69 (R/B) | Ground | AT device output | Output | — | | Battery voltage |
| 70 (P) | Ground | IPDM E/R ignition output 1 | Output | Push-button igni- tion switch | OFF or ACC | Battery voltage |
| | | | | | ON | 0V |

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N







O

P

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--------------------------------|------------------|--|---------------------------|
| (+) | (-) | Signal name | Input/ Output | | |
| 71 (O) | Ground | Driver request switch | Input | Front door LH re- quest switch | ON (pressed) |
| | | | | | OFF (not pressed) |
| 72 (G) | Ground | Passenger request switch | Input | Front door RH re- quest switch | ON (pressed) |
| | | | | | OFF (not pressed) |
| 75 (L/W) | Ground | Combination switch output 5 | Output | Combination and front fog lamps switch | OFF |
| | | | | ON | |
| | | | | Combination switch | Wiper intermittent dial 1 |
| | | | | | Wiper AUTO dial 1 |
| | | | | | Wiper intermittent dial 2 |
| | | | | | Wiper AUTO dial 4 |
| | | | | | Wiper intermittent dial 5 |

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|-----------------------------|------------------|-----------------------------------|---|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 76 (P) | Ground | Combination switch output 4 | Output | Combination and lighting switches | OFF |  PKIB4960J 7.0 - 8.0 V |
| | | | | Lighting switch | TAIL LAMP |  PKIB4958J 1.2 V |
| | | | | | AUTO LAMP | |
| | | | | | Wiper intermittent dial 2 | |
| | | | | | Wiper AUTO dial 2 | |
| | | | | Combination switch | Wiper intermittent dial 3 | |
| 77 (L) | Ground | Combination switch output 3 | Output | Combination and lighting switches | OFF |  PKIB4960J 7.0 - 8.0 V |
| | | | | Lighting switch | HEADLAMP 2 |  PKIB4958J 1.2 V |
| | | | | | HI BEAM | |
| | | | | | Wiper AUTO dial 4 | |
| | | | | Combination switch | Wiper intermittent dial 5 | |
| | | | | | | |
| 78 (O/B) | Ground | Combination switch output 2 | Output | Combination and lighting switches | OFF |  PKIB4960J 7.0 - 8.0 V |
| | | | | Lighting switch | HEADLAMP 1 |  PKIB4958J 1.2 V |
| | | | | | PASSING | |
| | | | | | FR WIPER HI | |
| | | | | Combination switch | FR WIPER INT (any intermittent position) | |
| | | | | | | |

A

B

C

D

E

F

G

H

I

J

K

L






BCS

N






O

P

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-----------------------------|------------------|--------------------------------|---|
| (+) | (-) | Signal name | Input/ Output | | |
| 79 (R/W) | Ground | Combination switch output 1 | Output | Combination switch | OFF |
| | | | | |  PKIB4960J 7.0 - 8.0 V |
| | | | | | TURN RH |
| | | | | | TURN LH |
| | | | | | FR WIPER LOW |
| 82 (W) | Ground | Left rear door switch | Input | Rear door LH switch | FR WASHER |
| | | | | |  PKIB4958J 1.2 V |
| | | | | | OFF (when rear door LH closes) |
| 86 (G/B) | Ground | Left rear trailer flasher | Output | Push-button ignition switch ON | ON (when rear door LH opens) |
| | | | | |  JPMIA0011GB 11.8V |
| 87 (Y/B) | Ground | Right rear trailer flasher | Output | Push-button ignition switch ON | Turn signal switch OFF |
| | | | | | Battery voltage |
| | | | | |  PKIC6370E 6.0 - 7.0 V |
| | | | | | Turn signal switch LH |
| | | | | | Turn signal switch OFF |
| | | | | | Battery voltage |
| | | | | |  PKIC6370E 6.0 - 7.0 V |
| | | | | | Turn signal switch RH |

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---------------------------|------------------|-------------------------------------|------------------------------------|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 92 (O) | Ground | Right rear flasher | Output | Push-button igni- tion switch ON | Turn signal switch OFF | 0V |
| | | | | | Turn signal switch RH |  PKID0926E 6.5V |
| 93 (R) | Ground | Right rear door switch | Input | Rear door RH switch | OFF (when rear door RH closes) |  JPMIA0011GB 11.8V |
| | | | | | ON (when rear door RH opens) | 0V |
| 94 (G) | Ground | Passenger door switch | Input | Front door RH switch | OFF (when front door RH closes) |  JPMIA0011GB 11.8V |
| | | | | | ON (when front door RH opens) | 0V |
| 96 (BG) | Ground | Driver door switch | Input | Front door LH switch | OFF (front door LH CLOSE) |  JPMIA0011GB 11.8V |
| | | | | | ON (front door LH OPEN) | 0V |
| 97 (P/L) | Ground | Cargo lamp switch | Input | Cargo lamp switch | OFF |  JPMIA0011GB 11.8V |
| | | | | | ON | 0V |

A

B

C

D

E

F

G

H

I

J

K

L






BCS

N






O

P







< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|---|--|--|
| (+) | (-) | Signal name | Input/ Output | | | |
| 103 (G/B) | Ground | Left rear flasher | Output | Push-button igni- tion switch ON | Turn signal switch OFF | 0V |
| | | | | | Turn signal switch LH |  PKID0926E 6.5V |
| 105 (G/Y) | Ground | Right front flasher | Output | Push-button igni- tion switch ON | Turn signal switch OFF | 0V |
| | | | | | Turn signal switch RH |  PKID0926E 6.5V |
| 107 (W) | Ground | Low side start switch LED | Output | Push-button igni- tion switch | OFF | 0V |
| | | | | | NOTE: When the illumination brightening/dimming level is in the neutral position ON |  JSNIA0010GB |
| 108 (L/R) | Ground | Shift lock solenoid output | Input | Selector lever | P position | 0V |
| | | | | | Any position other than P | Battery voltage |
| 111 (P) | Ground | ACC LED | Output | Push-button igni- tion switch | OFF | Battery voltage |
| | | | | | ACC or ON | 0V |
| 113 (L) | Ground | ACC relay output | Output | Push-button igni- tion switch | OFF | 0V |
| | | | | | ACC or ON | Battery voltage |
| 114 (W) | Ground | Outside key antenna (passenger side) A | Output | When the front door RH request switch is oper- ated with push-but- ton ignition switch OFF | When Intelligent Key is in the antenna detection area |  JMKIA0062GB |
| | | | | | When Intelligent Key is not in the antenna detection area |  JMKIA0063GB |





< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | Description | | Condition | Value (Approx.) | A B C D E F G H I J K L BCS N O P | |
|------------------------------|-------------|---|-------------|--|---|--|
| | (+) | (-) | Signal name | Input/ Output | | |
| 115 (BG) | Ground | Outside key antenna (passenger side) B | Output | When the front door RH request switch is operated with push-button ignition switch OFF |  (V) 15 10 5 0 1 s <small>JMKIA0062GB</small> | A B C D E F G H I J K L BCS N O P |
| | | | | When Intelligent Key is not in the antenna detection area |  (V) 15 10 5 0 1 s <small>JMKIA0063GB</small> | |
| 116 (W) | Ground | Inside key antenna (console) A | Output | Push-button ignition switch OFF |  (V) 15 10 5 0 1 s <small>JMKIA0062GB</small> | A B C D E F G H I J K L BCS N O P |
| | | | | When Intelligent Key is not in the passenger compartment |  (V) 15 10 5 0 1 s <small>JMKIA0063GB</small> | |
| 117 (G/B) | Ground | Left front flasher | Output | Turn signal switch OFF | 0V | A B C D E F G H I J K L BCS N O P |
| | | | | Push-button ignition switch ON |  (V) 15 10 5 0 1 s <small>PKID0926E</small> 6.5V | |


< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--------------------------------------|------------------|--|--|
| (+) | (-) | Signal name | Input/ Output | | |
| 119 (R) | Ground | Remote keyless entry receiver signal | Input/ Output | Push-button ignition switch ON | Standby state  |
| | | | | | When receiving the signal from the transmitter  |
| 121 (G) | Ground | Outside key antenna (driver side) B | Output | When the front door LH request switch is operated with push-button ignition switch OFF | When Intelligent Key is in the antenna detection area  |
| | | | | | When Intelligent Key is not in the antenna detection area  |
| 122 (P) | Ground | Outside key antenna (driver side) A | Output | When the front door LH request switch is operated with push-button ignition switch OFF | When Intelligent Key is in the antenna detection area  |
| | | | | | When Intelligent Key is not in the antenna detection area  |

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | Description | | Condition | Value (Approx.) | A B C D E F G H I J K L BCS N O P | |
|------------------------------|-------------|---|------------------|---|--|--|
| | (+) | (-) | | | | |
| 123 (W) | Ground | Inside key antenna (instrument center) A | Output | Push-button ignition switch OFF When Intelligent Key is in the passenger compartment | (V) 15 10 5 0  JMKA0062GB | A B C D E F G H I J K L BCS N O P |
| | | | | | (V) 15 10 5 0  JMKA0063GB | A B C D E F G H I J K L BCS N O P |
| 124 (G) | Ground | Inside key antenna (instrument center) B | Output | Push-button ignition switch OFF When Intelligent Key is in the passenger compartment | (V) 15 10 5 0  JMKA0062GB | A B C D E F G H I J K L BCS N O P |
| | | | | | (V) 15 10 5 0  JMKA0063GB | A B C D E F G H I J K L BCS N O P |
| 126 (P) | Ground | NATS antenna amp. B | Input/ Output | During waiting | Intelligent Key backside is contacted to push-button ignition switch, turn ignition switch ON. | Just after pressing push-button ignition switch, pointer of analog volt meter should move. |
| 127 (BG) | Ground | NATS antenna amp. A | Input/ Output | During waiting | Intelligent Key backside is contacted to push-button ignition switch, turn ignition switch ON. | Just after pressing push-button ignition switch pointer of analog volt meter should move. |

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|-----------------------------------|------------------|--|--|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 128 (B) | Ground | Inside key antenna (console) B | Output | Push-button ignition switch OFF | When Intelligent Key is in the passenger compartment |  (V) 15 10 5 0 1 s <small>JMKIA0062GB</small> |
| | | | | | When Intelligent Key is not in the passenger compartment | |
| 129 (R/G) | Ground | Battery saver output | Output | After passing the interior room lamp battery saver operation time | | 0V |
| | | | | Any other time after passing the interior room lamp battery saver operation time | | Battery voltage |
| 130 (LG) | Ground | Passenger door unlock | Output | Front door RH | UNLOCK (actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (actuator is not activated) | 0V |
| 131 (W) | Ground | BCM battery fuse | Input | Push-button ignition switch OFF | | Battery voltage |
| 132 (Y) | Ground | Front RH and rear door lock | Output | Front RH and rear doors | LOCK (actuator is activated) | Battery voltage |
| | | | | | Other than LOCK (actuator is not activated) | 0V |
| 133 (BR) | Ground | Front RH and rear door unlock | Output | Front RH and rear doors | UNLOCK (actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (actuator is not activated) | 0V |
| 134 (B) | Ground | Ground 2 | — | Push-button ignition switch ON | | 0V |
| 135 (O) | Ground | Driver door lock | Output | All doors | LOCK (actuator is activated) | Battery voltage |
| | | | | | Other than LOCK (actuator is not activated) | 0V |
| 136 (L) | Ground | Room lamp control | Output | Interior room lamp | OFF | Battery voltage |
| | | | | | ON | 0V |
| 137 (V) | Ground | Driver door unlock | Output | Front door LH | UNLOCK (actuator is activated) | Battery voltage |
| | | | | | Other than UNLOCK (actuator is not activated) | 0V |
| 138 (V) | Ground | Rear door battery | Input | Push-button ignition switch OFF | | Battery voltage |
| 139 (W) | Ground | Fusible link battery power | Input | Push-button ignition switch OFF | | Battery voltage |

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | Description | | Condition | Value (Approx.) | |
|------------------------------|-------------|------------------------------------|-----------|---------------------------------|-----------------|
| | (+) | (-) | | | |
| 140 (LG) | Ground | Power window ignition power supply | Output | Push-button ignition switch ON | Battery voltage |
| 141 (V) | Ground | Power window battery power supply | Output | Push-button ignition switch OFF | Battery voltage |
| 142 (Y) | Ground | Front door battery | Input | Push-button ignition switch OFF | Battery voltage |
| 143 (B) | Ground | Ground 1 | — | Push-button ignition switch ON | 0V |

Fail Safe

INFOID:000000014387234

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|-------------------------|--|
| B2192: ID DISCORD BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2193: CHAIN OF BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2195: ANTI-SCANNING | Inhibit engine cranking | Ignition switch ON → OFF |
| B2560: START POW SUP CIRC | Inhibit engine cranking | 500 ms after the following CAN signal communication status has become consistent: • Starter control relay signal • Starter relay status signal |
| B2562: LOW VOLTAGE | Inhibit engine cranking | 100 ms after the power supply voltage increases to more than 8.8 V |
| B2608: STARTER RELAY | Inhibit engine cranking | 500 ms after the following signal communication status becomes consistent: • Starter motor relay control signal • Starter relay status signal (CAN) |
| B260A: IGN RELAY | Inhibit engine cranking | 500 ms after the following conditions are fulfilled: • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal) |
| B261E: FUEL MIS CONFIG | Inhibit engine cranking | BCM initialization |

DTC Inspection Priority Chart

INFOID:000000014387235

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | DTC |
|----------|--|
| 1 | • B2562: LOW VOLTAGE |
| 2 | • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT(CAN) |
| 3 | • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING • B2196: DONGLE NG • B2198: IMMOBI ANT NG |

A
B
C
D
EF
G
H
I
J
KN
O
P

BCS

< ECU DIAGNOSIS INFORMATION >

| Priority | DTC |
|----------|--|
| 4 | <ul style="list-style-type: none"> • B2555: STOP LAMP CIRCUIT • B2556: ENG START SW • B2557: VEHICLE SPEED • B2560: START POW SUP CIRC • B2601: SHIFT P SIGNAL • B2602: SHIFT P DIAG • B2603: SHIFT POSITION • B2604: SHIFT PN DIAG CAN • B2605: SHIFT PN DIAG IPDM • B2608: STARTER RELAY • B260A: IGN RELAY • B260F: ECM CAN COMM • B261A: ENGINE SW • B261B: CRANKING TIMEOUT • B261E: FUEL MIS CONFIG • B26F1: IGN RELAY OFF STUCK FAIL • B26F2: IGN RELAY ON STUCK FAIL • B26F3: INHIBIT RELAY ON STUCK FAIL • B26F4: INHIBIT RELAY OFF STUCK FAIL • B26F6: IGN USM CONT FAIL • B26F7: LF DRIVER COMMUNICATION FAIL • B26FC: KEYFOB MISS REGISTRATION • B26FD: SHIFT LOCK SOLENOID INSIDE F/B FAIL • B26FE: HOOD SW CAN DIAG FAIL • B26FF: INTELLIGENT TUNER COMMUNICATION FAIL • U0415: VDC CAN CIR2 |
| 5 | <ul style="list-style-type: none"> • B2621: INSIDE ANTENNA 1 • B2622: INSIDE ANTENNA 2 • B2626: OUTSIDE 1 ANTENNA • B2627: OUTSIDE 2 ANTENNA |
| 6 | B259A: ROOM LAMP FUSE BLOWN |

DTC Index

INFOID:0000000014387236

NOTE:

Details of time display

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition is switched OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

| CONSULT display | Fail-safe | Intelligent Key warning lamp ON | Reference page |
|---|-----------|---------------------------------|---|
| No DTC is detected. Further testing may be required. | — | — | — |
| U1000: CAN COMM CIRCUIT | — | — | BCS-67, "DTC Description" |
| U1010: CONTROL UNIT (CAN) | — | — | BCS-68, "DTC Description" |
| U0415: VDC CAN CIR2 | — | — | BCS-66, "DTC Description" |
| B2192: ID DISCORD BCM-ECM | × | — | SEC-78, "DTC Description" |
| B2193: CHAIN OF BCM-ECM | × | — | SEC-80, "DTC Description" |
| B2195: ANTI SCANNING | × | — | SEC-82, "DTC Description" |
| B2196: DONGLE NG | — | — | SEC-84, "DTC Description" |
| B2198: IMMOBI ANT NG | — | — | SEC-86, "DTC Description" |
| B2555: STOP LAMP CIRCUIT | — | — | SEC-88, "DTC Description" |
| B2556: ENG START SW | — | × | SEC-93, "DTC Description" |

< ECU DIAGNOSIS INFORMATION >

| CONSULT display | Fail-safe | Intelligent Key warning lamp ON | Reference page |
|---|-----------|---------------------------------|--|
| B2557: VEHICLE SPEED | — | × | SEC-96, "DTC Description" |
| B2560: START POW SUP CIRC | × | × | SEC-98, "DTC Description" |
| B2562: LOW VOLTAGE | × | — | BCS-69, "DTC Description" |
| B259A: ROOM LAMP FUSE BLOWN | — | — | BCS-70, "DTC Description" |
| B2601: SHIFT P SIGNAL | — | × | SEC-100, "DTC Description" |
| B2602: SHIFT P DIAG | — | × | SEC-103, "DTC Description" |
| B2603: SHIFT POSITION | — | × | SEC-106, "DTC Description" |
| B2604: SHIFT PN DIAG CAN | — | × | SEC-110, "DTC Description" |
| B2605: SHIFT PN DIAG IPDM | — | × | SEC-113, "DTC Description" |
| B2608: STARTER RELAY | × | × | SEC-116, "DTC Description" |
| B260A: IGN RELAY | × | × | PCS-79, "DTC Description" |
| B260F: ECM CAN COMM | × | × | SEC-118, "DTC Description" |
| B261A: ENGINE SW | — | × | PCS-81, "DTC Description" |
| B261B: CRANKING TIMEOUT | — | — | SEC-120, "DTC Description" |
| B261E: FUEL MIS CONFIG | × | × (Turn ON for 15 seconds) | SEC-121, "DTC Description" |
| B2621: INSIDE ANTENNA 1 | — | — | DLK-77, "DTC Description" |
| B2622: INSIDE ANTENNA 2 | — | — | DLK-80, "DTC Description" |
| B2626: OUTSIDE 1 ANTENNA | — | — | DLK-92, "DTC Description" |
| B2627: OUTSIDE 2 ANTENNA | — | — | DLK-95, "DTC Description" |
| B26F1: IGNITION RELAY OFF STUCK FAIL | — | — | PCS-84, "DTC Description" |
| B26F2: IGNITION RELAY ON STUCK FAIL | — | — | PCS-86, "DTC Description" |
| B26F3: INHIBIT RELAY ON STUCK FAIL | — | — | SEC-123, "DTC Description" |
| B26F4: INHIBIT RELAY OFF STUCK FAIL | — | — | SEC-124, "DTC Description" |
| B26F6: IGN USM CONT FAIL | — | — | PCS-88, "DTC Description" |
| B26F7: LF DRIVER COMMUNICATION FAIL | — | — | SEC-126, "DTC Description" |
| B26FC: KEYFOB MIS REGISTRATION | — | — | SEC-125, "DTC Description" |
| B26FD: SHIFT LOCK SOLENOID INSIDE F/B FAIL | — | — | DLK-83, "DTC Description" |
| B26FE: HOOD SWITCH CAN DIAG FAIL | — | — | DLK-85, "DTC Description" |
| B26FF: INTELLIGENT TUNER COMMUNICATION FAIL | — | — | DLK-88, "DTC Description" |

BCS


< WIRING DIAGRAM >

WIRING DIAGRAM


BCM

Wiring Diagram

INFOID:0000000014387237




< WIRING DIAGRAM >




AAMWA2347GB

< WIRING DIAGRAM >




AAMWA2348GB




AAMWA2349GB

< WIRING DIAGRAM >



AAMWA2350GB



AAMWA2351GB

BCS

BCM (BODY CONTROL MODULE) CONNECTORS

| Connector No. | Signal Name | Color of Wire | Wire No. |
|---------------|--------------------------|---------------|----------|
| C153 | TAILGATE LOCK RELAY | L | 1 |
| | | B | 2 |
| RH02FB | SUPERLOCK/DOOR UNLOCK AS | L | 3 |
| | | B | 4 |
| BLACK | GROUND | B | 5 |



| Terminal No. | Signal Name | Color of Wire | Wire No. |
|--------------|------------------------------|---------------|----------|
| 1 | TAILGATE RELAY OUTPUT | W | 1 |
| 2 | TAILGATE UNLOCK RELAY OUTPUT | GR | 2 |



| | | | | | | | | |
|---|---|--------------------------|----|-----|---------------------|----|-----|-------------------------|
| 1 | G | RELAY CONTROL | 10 | SB | COMBI SW IN 5 | 46 | - | - |
| 2 | B | GROUND | 11 | GR | COMBI SW IN 4 | 47 | - | - |
| 3 | L | RELAY OUTPUT | 12 | Y | COMBI SW IN 3 | 48 | R | HIGH SIDE START SW LED |
| 4 | L | SUPERLOCK/DOOR UNLOCK AS | 13 | GB | COMBI SW IN 2 | 49 | - | - |
| 5 | B | GROUND | 14 | V | COMBI SW IN 1 | 50 | - | - |
| | | | 15 | - | - | 51 | - | - |
| | | | 16 | - | - | 52 | W | AUDIO DONGLE |
| | | | 17 | P | GIN RE AL | 53 | - | - |
| | | | 18 | V | SECURITY INDICATOR | 54 | W/L | PWM/UART |
| | | | 19 | - | - | 55 | W/B | L&R SENSOR K-LINE |
| | | | 20 | R | SHIFT P | 56 | - | - |
| | | | 21 | R/W | STEP LAMP COUNT | 57 | - | - |
| | | | 22 | - | - | 58 | - | - |
| | | | 23 | Y | AIRCON SW | 59 | P | CAN-L |
| | | | 24 | - | - | 60 | L | CAN-H |
| | | | 25 | W | BRAKE SW FUSE | 61 | O | REAR DEFOGGER RELAY OUT |
| | | | 26 | L | SHORT IN PIN INPUT | 62 | W | STARTER RELAY OUT |
| | | | 27 | R/G | BRAKE SW LAMP | 63 | - | - |
| | | | 28 | - | - | 64 | P | BUZZER OUT |
| | | | 29 | W | BLOWER FAN SW | 65 | - | - |
| | | | 30 | P | DR DOOR LOCK STATUS | 66 | W | BLOWER FAN RELAY OUT |
| | | | 31 | - | - | 67 | G | IGN ELEC RELAY OUT 2 |
| | | | 32 | Y | REAR DEFOGGER SW | 68 | L | MR OUTPUT |
| | | | 33 | - | - | 69 | R/B | AT DEVICE OUT |
| | | | 34 | - | - | 70 | P | IGN USM OUT 1 |
| | | | 35 | R/G | REVERSE SW | 71 | O | DR REQUEST SW |
| | | | 36 | W/B | HAZARD SW | 72 | G | AS REQUEST SW |
| | | | 37 | - | - | 73 | - | - |
| | | | 38 | - | - | 74 | - | - |
| | | | 39 | B/R | SHIFT SW/NP | 75 | L/W | COMBI SW OUT 5 |
| | | | 40 | - | - | 76 | P | COMBI SW OUT 4 |

H.S.



| Connector No. | Signal Name | Color of Wire | Wire No. |
|---------------|---------------------------|---------------|----------|
| M18 | BCM (BODY CONTROL MODULE) | B/R | 39 |
| TH40FG-NH | BCM (BODY CONTROL MODULE) | P | 40 |
| GREEN | BCM (BODY CONTROL MODULE) | - | - |

| Connector No. | Signal Name | Color of Wire | Wire No. |
|---------------|-----------------------|---------------|----------|
| C162 | TAILGATE UNLOCK RELAY | L | 1 |
| | | B | 2 |
| 6098-4739 | RELAY CONTROL | G | 3 |
| | | GROUND | 4 |
| BLACK | DOOR LOCK AS/FR/RL | B | 5 |

H.S.

| Terminal No. | Signal Name | Color of Wire | Wire No. |
|--------------|--------------------|---------------|----------|
| 1 | RELAY CONTROL | L | 1 |
| 2 | GROUND | B | 2 |
| 3 | DOOR LOCK AS/FR/RL | G | 3 |
| 4 | GROUND | B | 4 |
| 5 | DOOR LOCK AS/FR/RL | B | 5 |

H.S.



| | | | | | | | | |
|---|---|--------------------------|----|-----|---------------------|----|-----|-------------------------|
| 1 | G | RELAY CONTROL | 10 | SB | COMBI SW IN 5 | 46 | - | - |
| 2 | B | GROUND | 11 | GR | COMBI SW IN 4 | 47 | - | - |
| 3 | L | RELAY OUTPUT | 12 | Y | COMBI SW IN 3 | 48 | R | HIGH SIDE START SW LED |
| 4 | L | SUPERLOCK/DOOR UNLOCK AS | 13 | GB | COMBI SW IN 2 | 49 | - | - |
| 5 | B | GROUND | 14 | V | COMBI SW IN 1 | 50 | - | - |
| | | | 15 | - | - | 51 | - | - |
| | | | 16 | - | - | 52 | W | AUDIO DONGLE |
| | | | 17 | P | GIN RE AL | 53 | - | - |
| | | | 18 | V | SECURITY INDICATOR | 54 | W/L | PWM/UART |
| | | | 19 | - | - | 55 | W/B | L&R SENSOR K-LINE |
| | | | 20 | R | SHIFT P | 56 | - | - |
| | | | 21 | R/W | STEP LAMP COUNT | 57 | - | - |
| | | | 22 | - | - | 58 | - | - |
| | | | 23 | Y | AIRCON SW | 59 | P | CAN-L |
| | | | 24 | - | - | 60 | L | CAN-H |
| | | | 25 | W | BRAKE SW FUSE | 61 | O | REAR DEFOGGER RELAY OUT |
| | | | 26 | L | SHORT IN PIN INPUT | 62 | W | STARTER RELAY OUT |
| | | | 27 | R/G | BRAKE SW LAMP | 63 | - | - |
| | | | 28 | - | - | 64 | P | BUZZER OUT |
| | | | 29 | W | BLOWER FAN SW | 65 | - | - |
| | | | 30 | P | DR DOOR LOCK STATUS | 66 | W | BLOWER FAN RELAY OUT |
| | | | 31 | - | - | 67 | G | IGN ELEC RELAY OUT 2 |
| | | | 32 | Y | REAR DEFOGGER SW | 68 | L | MR OUTPUT |
| | | | 33 | - | - | 69 | R/B | AT DEVICE OUT |
| | | | 34 | - | - | 70 | P | IGN USM OUT 1 |
| | | | 35 | R/G | REVERSE SW | 71 | O | DR REQUEST SW |
| | | | 36 | W/B | HAZARD SW | 72 | G | AS REQUEST SW |
| | | | 37 | - | - | 73 | - | - |
| | | | 38 | - | - | 74 | - | - |
| | | | 39 | B/R | SHIFT SW/NP | 75 | L/W | COMBI SW OUT 5 |
| | | | 40 | - | - | 76 | P | COMBI SW OUT 4 |



| Connector No. | Signal Name | Color of Wire | Wire No. |
|---------------|---------------------------|---------------|----------|
| M19 | BCM (BODY CONTROL MODULE) | P | 39 |
| TH40FB-NH | BCM (BODY CONTROL MODULE) | W/B | 40 |
| BLACK | BCM (BODY CONTROL MODULE) | - | - |

H.S.



| | | | | | | | | |
|---|---|--------------------------|----|-----|---------------------|----|-----|-------------------------|
| 1 | G | RELAY CONTROL | 10 | SB | COMBI SW IN 5 | 46 | - | - |
| 2 | B | GROUND | 11 | GR | COMBI SW IN 4 | 47 | - | - |
| 3 | G | RELAY OUTPUT | 12 | Y | COMBI SW IN 3 | 48 | R | HIGH SIDE START SW LED |
| 4 | G | SUPERLOCK/DOOR UNLOCK AS | 13 | GB | COMBI SW IN 2 | 49 | - | - |
| 5 | B | GROUND | 14 | V | COMBI SW IN 1 | 50 | - | - |
| | | | 15 | - | - | 51 | - | - |
| | | | 16 | - | - | 52 | W | AUDIO DONGLE |
| | | | 17 | P | GIN RE AL | 53 | - | - |
| | | | 18 | V | SECURITY INDICATOR | 54 | W/L | PWM/UART |
| | | | 19 | - | - | 55 | W/B | L&R SENSOR K-LINE |
| | | | 20 | R | SHIFT P | 56 | - | - |
| | | | 21 | R/W | STEP LAMP COUNT | 57 | - | - |
| | | | 22 | - | - | 58 | - | - |
| | | | 23 | Y | AIRCON SW | 59 | P | CAN-L |
| | | | 24 | - | - | 60 | L | CAN-H |
| | | | 25 | W | BRAKE SW FUSE | 61 | O | REAR DEFOGGER RELAY OUT |
| | | | 26 | L | SHORT IN PIN INPUT | 62 | W | STARTER RELAY OUT |
| | | | 27 | R/G | BRAKE SW LAMP | 63 | - | - |
| | | | 28 | - | - | 64 | P | BUZZER OUT |
| | | | 29 | W | BLOWER FAN SW | 65 | - | - |
| | | | 30 | P | DR DOOR LOCK STATUS | 66 | W | BLOWER FAN RELAY OUT |
| | | | 31 | - | - | 67 | G | IGN ELEC RELAY OUT 2 |
| | | | 32 | Y | REAR DEFOGGER SW | 68 | L | MR OUTPUT |
| | | | 33 | - | - | 69 | R/B | AT DEVICE OUT |
| | | | 34 | - | - | 70 | P | IGN USM OUT 1 |
| | | | 35 | R/G | REVERSE SW | 71 | O | DR REQUEST SW |
| | | | 36 | W/B | HAZARD SW | 72 | G | AS REQUEST SW |
| | | | 37 | - | - | 73 | - | - |
| | | | 38 | - | - | 74 | - | - |
| | | | 39 | B/R | SHIFT SW/NP | 75 | L/W | COMBI SW OUT 5 |
| | | | 40 | - | - | 76 | P | COMBI SW OUT 4 |

H.S.



| | | | | | | | | |
|---|---|--------------------------|----|-----|---------------------|----|-----|-------------------------|
| 1 | G | RELAY CONTROL | 10 | SB | COMBI SW IN 5 | 46 | - | - |
| 2 | B | GROUND | 11 | GR | COMBI SW IN 4 | 47 | - | - |
| 3 | G | RELAY OUTPUT | 12 | Y | COMBI SW IN 3 | 48 | R | HIGH SIDE START SW LED |
| 4 | G | SUPERLOCK/DOOR UNLOCK AS | 13 | GB | COMBI SW IN 2 | 49 | - | - |
| 5 | B | GROUND | 14 | V | COMBI SW IN 1 | 50 | - | - |
| | | | 15 | - | - | 51 | - | - |
| | | | 16 | - | - | 52 | W | AUDIO DONGLE |
| | | | 17 | P | GIN RE AL | 53 | - | - |
| | | | 18 | V | SECURITY INDICATOR | 54 | W/L | PWM/UART |
| | | | 19 | - | - | 55 | W/B | L&R SENSOR K-LINE |
| | | | 20 | R | SHIFT P | 56 | - | - |
| | | | 21 | R/W | STEP LAMP COUNT | 57 | - | - |
| | | | 22 | - | - | 58 | - | - |
| | | | 23 | Y | AIRCON SW | 59 | P | CAN-L |
| | | | 24 | - | - | 60 | L | CAN-H |
| | | | 25 | W | BRAKE SW FUSE | 61 | O | REAR DEFOGGER RELAY OUT |
| | | | 26 | L | SHORT IN PIN INPUT | 62 | W | STARTER RELAY OUT |
| | | | 27 | R/G | BRAKE SW LAMP | 63 | - | - |
| | | | 28 | - | - | 64 | P | BUZZER OUT |
| | | | 29 | W | BLOWER FAN SW | 65 | - | - |
| | | | 30 | P | DR DOOR LOCK STATUS | 66 | W | BLOWER FAN RELAY OUT |
| | | | 31 | - | - | 67 | G | IGN ELEC RELAY OUT 2 |
| | | | 32 | Y | REAR DEFOGGER SW | 68 | L | MR OUTPUT |
| | | | 33 | - | - | 69 | R/B | AT DEVICE OUT |
| | | | 34 | - | - | 70 | P | IGN USM OUT 1 |
| | | | 35 | R/G | REVERSE SW | 71 | O | DR REQUEST SW |
| | | | 36 | W/B | HAZARD SW | 72 | G | AS REQUEST SW |
| | | | 37 | - | - | 73 | - | - |
| | | | 38 | - | - | 74 | - | - |
| | | | 39 | B/R | SHIFT SW/NP | 75 | L/W | COMBI SW OUT 5 |
| | | | 40 | - | - | 76 | P | COMBI SW OUT 4 |

H.S.



<tbl

< BASIC INSPECTION >

BASIC INSPECTION

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM)

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Description

INFOID:000000014387238

BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement. Refer to [BCS-62, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\) : Work Procedure"](#).

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

AFTER REPLACEMENT

CAUTION:

- When replacing BCM, you must perform "After Replace ECU" with CONSULT.
- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- When replacing BCM, perform the system initialization (NATS).

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Work Procedure

INFOID:000000014387239

1. SAVING VEHICLE SPECIFICATION

① CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

>> GO TO 2.

2. REPLACE BCM

Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

>> GO TO 3.

3. WRITING VEHICLE SPECIFICATION

② CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, automatically an "Operation Log Selection" screen will be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [BCS-63, "CONFIGURATION \(BCM\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [BCS-63, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 4.

4. REGISTER INTELLIGENT KEYS

For initialization and registration of Intelligent Keys, refer to CONSULT Immobilizer mode and follow the on-screen instructions.

< BASIC INSPECTION >

>> Work End.

CONFIGURATION (BCM)

CONFIGURATION (BCM) : Description

INFOID:000000014387240

Vehicle specification needs to be written with CONSULT because it is not written after replacing BCM.
 Configuration has three functions as follows:

| Function | Description |
|--------------------------|--|
| "Before Replace ECU" | <ul style="list-style-type: none"> Reads the vehicle configuration of current BCM. Saves the read vehicle configuration. |
| "After Replace ECU" | Writes the vehicle configuration with manual selection. |
| "Select Saved Data List" | Writes the vehicle configuration with saved data. |

CAUTION:

- When replacing BCM, you must perform "Select Saved Data List" or "After Replace ECU" with CONSULT.
- Complete the procedure of "Select Saved Data List" or "After Replace ECU" in order.
- If you set incorrect "Select Saved Data List" or "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Select Saved Data List" or "After Replace ECU" except for new BCM.

CONFIGURATION (BCM) : Work Procedure

INFOID:000000014387241

1. WRITING MODE SELECTIONCONSULT

Select "Reprogramming, Configuration" of BCM.

When writing saved data>> GO TO 2.

When writing manually>> GO TO 3.

2. PERFORM "SAVED DATA LIST"CONSULT

Automatically "Operation Log Selection" window will display if "Before Replace ECU" was performed. Select applicable file from the "Save Data List" and press "Confirm".

>> Work End.

3. PERFORM "AFTER REPLACE ECU" OR "MANUAL CONFIGURATION"CONSULT

- Select "After Replace ECU" or "Manual Configuration".
- Identify the correct model and configuration list. Refer to [BCS-64, "CONFIGURATION \(BCM\) : Configuration List"](#).
- Confirm and/or change setting value for each item.

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

- Select "Next".

CAUTION:

Make sure to select "Next", confirm each setting value and press "OK" even if the indicated configuration of brand new BCM is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model cannot be memorized.

- When "Completed", select "End".

>> GO TO 4.

4. OPERATION CHECK

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

INSPECTION AND ADJUSTMENT

[BCM]

< BASIC INSPECTION >

Confirm that each function controlled by BCM operates normally.

>> Work End.

CONFIGURATION (BCM) : Configuration List

INFOID:000000014387242

CAUTION:

- Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.
- The “setting value” of this vehicle is as follows: Never select any other value than the setting value shown below. (If there is only 1 item in “setting value” that means that item is the only choice for this certain vehicle.)

| SETTING ITEM | | NOTE |
|--|---------------------------------------|---|
| Items | Setting value | |
| AUTO LIGHT | WITHOUT ⇌ MODE3 ⇌ MODE4 | <ul style="list-style-type: none">• WITHOUT: Without auto light system• MODE3: With auto light system and With daytime running lamps• MODE4: With auto light system and Without daytime running lamps |
| DRL | WITHOUT ⇌ MODE4 | <ul style="list-style-type: none">• WITHOUT: Without daytime running lamps• MODE4: With daytime running lamps |
| SIGNATURE LIGHT SETTING | WITH ⇌ WITHOUT | <ul style="list-style-type: none">• WITH: With LED headlamps• WITHOUT: With halogen headlamps |
| WELCOME LIGHT | WITH ⇌ WITHOUT | <ul style="list-style-type: none">• WITH: With welcome light function• WITHOUT: Without welcome light function |
| RAIN SENSOR CONFIG | WITH ⇌ WITHOUT | <ul style="list-style-type: none">• WITH: With rain sensing front wipers• WITHOUT: Without rain sensing front wipers |
| DONGLE | WITH ⇌ WITHOUT | <ul style="list-style-type: none">• WITH: With dongle (Canada)• WITHOUT: Without dongle (USA) |
| CAN ERR DETECT TELEMATICS | WITH ⇌ WITHOUT | <ul style="list-style-type: none">• WITH: With telematics system• WITHOUT: Without telematics system |
| CAN error detect transfer control unit | WITH ⇌ WITHOUT | <ul style="list-style-type: none">• WITH: 4WD models• WITHOUT: 2WD models |
| Key Fob Type | LCK/UNLCK/ALRM ⇌ ENST/LCK/UN-LCK/ALRM | <ul style="list-style-type: none">• LCK/UNLCK/ALRM: 3 button (w/o engine start)• ENST/LCK/UNLCK/ALRM: 4 button (w/engine start) |
| INTELLIGENT KEY TYPE | Half ⇌ Full | <ul style="list-style-type: none">• Half: Without door request switches• Full: With door request switches |
| ALT TYPE | GASOLINE ⇌ DIESEL | <ul style="list-style-type: none">• GASOLINE: With VK56VD• DIESEL: With Cummins 5.0L |
| TRAILER LIGHT CHECK | WITH ⇌ WITHOUT | <ul style="list-style-type: none">• WITH: With trailer light check• WITHOUT: Without trailer light check |

SHIPPING MODE CANCEL OPERATION

< BASIC INSPECTION >

[BCM]

SHIPPING MODE CANCEL OPERATION

Work Procedure

INFOID:0000000014387243

1. SHIPPING MODE CANCEL OPERATION

1. Turn ignition switch OFF.
2. Press in (turn on) the extended storage switch. Refer to [PG-179, "How To Check"](#).
3. Turn ignition switch ON.
4. Turn ignition switch OFF and wait at least 2 seconds.

NOTE:

Pressing in the extended storage switch moves the mode from Shipping to Normal.

>> GO TO 2.

2. SHIPPING MODE CANCEL CHECK

1. Turn ignition switch ON.
2. Check that extended storage warning message is not displayed in combination meter or display.

>> Work End.

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U0415 VEHICLE SPEED SIG

DTC Description

INFOID:000000014387244

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC Detection Condition | |
|---------|---|-------------------------|-----------------------------|
| U0415 | VDC CAN CIR2 (Vehicle speed) | Diagnosis condition | When ignition switch is ON. |
| | | Signal (terminal) | — |
| | | Threshold | — |
| | | Diagnosis delay time | 2 seconds or more |

POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- BCM

FAIL-SAFE

—

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

④ CONSULT

1. Erase the DTC.
2. Turn ignition switch OFF.
3. Perform "Self Diagnostic Result" mode of "BCM", after the ignition switch has been turned ON for 2 seconds or more.

Is any DTC detected?

YES >> Refer to [BCS-66, "Diagnosis Procedure"](#).NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014387245

1. SELF DIAGNOSTIC RESULT

④ CONSULT

1. Turn ignition switch ON.
2. Select "Self-Diagnostic Result" mode of "ABS".
3. Check DTC.

Is any DTC detected?

YES >> Repair or replace the malfunctioning part.

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

< DTC/CIRCUIT DIAGNOSIS >

U1000 CAN COMM CIRCUIT

DTC Description

INFOID:000000014387246

Description

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. CAN Communication Signal Chart. Refer to [LAN-74, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC Detection Condition | |
|---------|---|-------------------------|-----------------------------|
| U1000 | CAN COMM CIRCUIT (CAN communication circuit) | Diagnosis condition | When ignition switch is ON. |
| | | Signal (terminal) | — |
| | | Threshold | — |
| | | Diagnosis delay time | 2 seconds or more |

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

—

Diagnosis Procedure

INFOID:000000014387247

1. SELF DIAGNOSTIC RESULT

CONSULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" mode of "BCM".
3. Check DTC.

Is DTC "U1000" displayed?

YES >> Refer to [LAN-53, "Trouble Diagnosis Flow Chart"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

DTC Description

INFOID:000000014387248

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC Detection Condition | |
|---------|---|-------------------------|-----------------------------|
| U1010 | CONTROL UNIT(CAN) (Control unit) | Diagnosis condition | When ignition switch is ON. |
| | | Signal (terminal) | — |
| | | Threshold | — |
| | | Diagnosis delay time | 2 seconds or more |

POSSIBLE CAUSE

- BCM

FAIL-SAFE

—

Diagnosis Procedure

INFOID:000000014387249

1. REPLACE BCM

When DTC U1010 is detected, replace BCM.

>> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

< DTC/CIRCUIT DIAGNOSIS >

B2562 LOW VOLTAGE**DTC Description**

INFOID:000000014387250

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC Detection Condition | |
|---------|---|-------------------------|---|
| B2562 | LOW VOLTAGE (Low voltage) | Diagnosis condition | When ignition switch is ON. |
| | | Signal (terminal) | BCM power circuit (terminal 139 and 131 and ground) |
| | | Threshold | Less than 8.8V |
| | | Diagnosis delay time | 120 seconds or more |

POSSIBLE CAUSE

- Harness or connector (power supply circuit)
- BCM

FAIL-SAFE**DTC CONFIRMATION PROCEDURE****1.DTC CONFIRMATION PROCEDURE****①CONSULT**

1. Erase DTC.
2. Turn ignition switch OFF.
3. Perform the "Self Diagnostic Result" mode of "BCM", after the ignition switch is turned ON for 120 seconds or more.

Is any DTC detected?YES >> Refer to [BCS-69, "Diagnosis Procedure"](#).NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014387251

1.CHECK POWER SUPPLY CIRCUITCheck BCM power supply circuit. Refer to [BCS-72, "Diagnosis Procedure"](#).**Is the circuit normal?**YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair the malfunctioning part.

BCS

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

B259A ROOM LAMP FUSE**DTC Description**

INFOID:0000000014387252

DTC DETECTION LOGIC

| DTC No. | CONSULT screen terms (Trouble diagnosis content) | DTC Detection Condition | |
|---------|---|-------------------------|---|
| B259A | ROOM LAMP FUSE BLOWN (Room lamp fuse blown) | Diagnosis condition | When ignition switch is ON. |
| | | Signal (terminal) | BCM power circuit (terminal 131 and ground) |
| | | Threshold | Approx. 0V |
| | | Diagnosis delay time | 120 seconds or more |

POSSIBLE CAUSE

- Fuse
- Harness or connector (power supply circuit is open or shorted)
- Harness or connector (battery saver output circuit is shorted)
- BCM

FAIL-SAFE**DTC CONFIRMATION PROCEDURE****1. DTC CONFIRMATION PROCEDURE** **CONSULT**

1. Erase DTC.
2. Turn ignition switch OFF.
3. Perform the "Self Diagnostic Result" mode of "BCM", after the ignition switch has been turned ON for 120 seconds or more.

Is any DTC detected?YES >> Refer to [BCS-70, "Diagnosis Procedure"](#).NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000014387253

Regarding Wiring Diagram information, refer to [BCS-54, "Wiring Diagram"](#).**1. CHECK FUSE**

Check that the following fuse is not blown.

| Terminal No. | Signal name | Fuse No. |
|--------------|------------------|----------|
| 131 | BCM battery fuse | 1 (10A) |

Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK BAT BCM FUSE CIRCUIT

1. Disconnect BCM connector M81.
2. Check voltage between BCM connector M81 terminal 131 and ground.

B259A ROOM LAMP FUSE

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

| BCM | | Ground | Voltage (Approx.) |
|-----------|----------|--------|----------------------|
| Connector | Terminal | | |
| M81 | 131 | — | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK BATTERY SAVER OUTPUT CIRCUIT FOR SHORT TO GROUND

1. Turn ignition OFF.
2. Check continuity between BCM connector M81 terminal 129 and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M81 | 129 | — | No |

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BCM]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000014387254

Regarding Wiring Diagram information, refer to [BCS-54. "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

| Signal name | Fuse and fusible link No. | |
|----------------------------|---------------------------|---------|
| | Cummins 5.0L | VK56VD |
| Fusible link battery power | R (50A) | N (50A) |
| BCM battery fuse | 1 (10A) | 1 (10A) |

Is the fuse or fusible link blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.
2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

| BCM | | Ground | Voltage (Approx.) |
|-----------|----------|--------|-------------------|
| Connector | Terminal | | |
| M81 | 131 | (-) | Battery voltage |
| | 139 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M81 | 134 | — | Yes |
| | 143 | | |

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

COMBINATION AND LIGHTING SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BCM]

COMBINATION AND LIGHTING SWITCH INPUT CIRCUIT

Diagnosis Procedure

INFOID:000000014387255

Regarding Wiring Diagram information, refer to [BCS-54, "Wiring Diagram"](#).

1. CHECK INPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM, combination switch, lighting switch and front fog switch (if equipped) connectors.
3. Check continuity between BCM connector and combination switch connector.

| Combination switch signal | BCM | | Combination switch | | Continuity |
|---------------------------|-----------|----------|--------------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| Input 1 | M19 | 79 | M28 | 11 | Yes |
| Input 2 | | 78 | | 9 | |
| Input 3 | | 77 | | 7 | |
| Input 4 | | 76 | | 10 | |
| Input 5 | | 75 | | 13 | |

4. Check continuity between BCM connector and lighting switch connector.

| Lighting switch signal | BCM | | Lighting switch | | Continuity |
|------------------------|-----------|----------|-----------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| Input 2 | M19 | 78 | M59 | 2 | Yes |
| Input 3 | | 77 | | 3 | |
| Input 4 | | 76 | | 4 | |

5. Check continuity between BCM connector and front fog lamps switch connector (if equipped).

| Front fog switch signal | BCM | | Front fog switch | | Continuity |
|-------------------------|-----------|----------|------------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| Input 5 | M19 | 75 | M16 | 1 | Yes |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2. CHECK INPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM connector and ground.

BCS

| Switch signal | BCM | | Ground | Continuity |
|---------------|-----------|----------|--------|------------|
| | Connector | Terminal | | |
| Input 1 | M18 | 79 | Ground | No |
| Input 2 | | 78 | | |
| Input 3 | | 77 | | |
| Input 4 | | 76 | | |
| Input 5 | | 75 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

COMBINATION AND LIGHTING SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BCM]

3. CHECK BCM OUTPUT VOLTAGE

1. Connect BCM connector.
2. Check voltage between BCM connector and ground.

| Switch signal | Terminals | | | Voltage (Approx.) |
|---------------|-----------|----|-----|-------------------|
| | (+) | | (-) | |
| | BCM | | | |
| Connector | Terminal | | | Ground |
| Input 1 | M19 | 79 | | |
| Input 2 | | 78 | | |
| Input 3 | | 77 | | |
| Input 4 | | 76 | | |
| Input 5 | | 75 | | |

Is the inspection result normal?

YES >> Replace malfunctioning switch.

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

Refer to [BCS-32, "Reference Value"](#).

COMBINATION AND LIGHTING SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BCM]

COMBINATION AND LIGHTING SWITCH OUTPUT CIRCUIT

Diagnosis Procedure

INFOID:0000000014387256

Regarding Wiring Diagram information, refer to [BCS-54, "Wiring Diagram"](#).

1. CHECK OUTPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM, combination switch, lighting switch and front fog switch (if equipped) connectors.
3. Check continuity between BCM connector and combination switch connector.

| Combination switch signal | BCM | | Combination switch | | Continuity |
|---------------------------|-----------|----------|--------------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| Output 1 | M18 | 14 | M28 | 12 | Yes |
| Output 2 | | 13 | | 14 | |
| Output 3 | | 12 | | 5 | |
| Output 4 | | 11 | | 2 | |
| Output 5 | | 10 | | 8 | |

4. Check continuity between BCM connector and lighting switch connector.

| Lighting switch signal | BCM | | Lighting switch | | Continuity |
|------------------------|-----------|----------|-----------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| Output 3 | M18 | 12 | M59 | 7 | Yes |
| Output 4 | | 11 | | 6 | |
| Output 5 | | 10 | | 5 | |

5. Check continuity between BCM connector and front fog switch connector (if equipped).

| Front fog switch signal | BCM | | Front fog switch | | Continuity |
|-------------------------|-----------|----------|------------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| Output 4 | M18 | 11 | M16 | 2 | Yes |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2. CHECK OUTPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM connector and ground.

| Switch signal | BCM | | Ground | Continuity |
|---------------|-----------|----------|--------|------------|
| | Connector | Terminal | | |
| Output 1 | M18 | 14 | Ground | No |
| Output 2 | | 13 | | |
| Output 3 | | 12 | | |
| Output 4 | | 11 | | |
| Output 5 | | 10 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

COMBINATION AND LIGHTING SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BCM]

3. CHECK BCM INPUT SIGNAL

1. Connect BCM, combination switch, lighting switch and front fog switch (if equipped) connectors.
2. Turn ON any switch in the system that is malfunctioning.
3. Check voltage between BCM connector and ground.

| Switch signal | Terminals | | | Voltage (Approx.) | |
|---------------|-----------|----------|--------|---|--|
| | (+) (-) | | | | |
| | BCM | | | | |
| | Connector | Terminal | | | |
| Output 1 | M18 | 14 | Ground | Refer to BCS-32, "Reference Value". | |
| Output 2 | | 13 | | | |
| Output 3 | | 12 | | | |
| Output 4 | | 11 | | | |
| Output 5 | | 10 | | | |

Is the inspection result normal?

Yes >> Replace BCM. Refer to [BCS-79, "Removal and Installation".](#)

No >> Replace malfunctioning switch.

COMBINATION AND LIGHTING SWITCH SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[BCM]

SYMPTOM DIAGNOSIS

COMBINATION AND LIGHTING SWITCH SYSTEM SYMPTOMS

Symptom Table

INFOID:000000014387257

1. Perform "Data Monitor" of CONSULT to check for any malfunctioning item.
2. Check the malfunction combinations.

Malfunctioning item: x

| Data monitor item | | | | | | | | | | | | | Malfunction combination | |
|---|--------------|--------------|--------------|------------|---------------|---------------|--------------|------------|----------------|----------------|------------|---------------|-------------------------|---|
| FR WIPER HI | FR WIPER LOW | FR WASHER SW | FR WIPER INT | INT VOLUME | TURN SIGNAL R | TURN SIGNAL L | TAIL LAMP SW | HI BEAM SW | HEAD LAMP SW 1 | HEAD LAMP SW 2 | PASSING SW | AUTO LIGHT SW | FR FOG SW | |
| | x | x | | | x | x | | | | | | | | A |
| x | | | x | | | | | | x | | x | | | B |
| | | | x | | | | | x | | x | | | | C |
| | | | x | | | x | | | | | x | | | D |
| | | | x | | | | | | | | x | | | E |
| x | | | x | | | | | | | | | | | F |
| | | x | x | | | | | | | | | | | G |
| | x | x | | | | | | | | | x | | | H |
| | | | | x | | x | x | x | x | x | x | x | | I |
| | | | | x | | | | | | | | | | J |
| All Items | | | | | | | | | | | | | | K |
| If only one item is detected or the item is not applicable to the combinations A to K | | | | | | | | | | | | | | L |

3. Identify the malfunctioning part from the agreed combination and repair or replace the part.

| Malfunction combination | Malfunctioning part | Repair or replace |
|-------------------------|--------------------------------|---|
| A | Input 1 signal circuit | Inspect the output signal circuit applicable to the malfunctioning part. Refer to BCS-73, "Diagnosis Procedure" . |
| B | Input 2 signal circuit | |
| C | Input 3 signal circuit | |
| D | Input 4 signal circuit | |
| E | Input 5 signal circuit | |
| F | Output 1 signal circuit | Inspect the input signal circuit applicable to the malfunctioning part. Refer to BCS-75, "Diagnosis Procedure" . |
| G | Output 2 signal circuit | |
| H | Output 3 signal circuit | |
| I | Output 4 signal circuit | |
| J | Output 5 signal circuit | |
| K | BCM | Replace BCM. Refer to BCS-79, "Removal and Installation" . |
| L | Combination or lighting switch | Replace malfunctioning switch. |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
BCS

NORMAL OPERATING CONDITION

Description

INFOID:0000000014387258

SHIPPING MODE

- Shipping mode inhibits battery power consumption during transportation or storage of the vehicle. Vehicle is set to shipping mode before being shipped from the factory.
- When ignition switch is OFF, BCM operates shipping mode.
- BCM control function is limited in shipping mode. Remote keyless entry function does not operate in shipping mode.
- For shipping mode cancel operation, refer to [BCS-65. "Work Procedure"](#).

NOTE:

Do not cancel shipping mode during storage of the vehicle. Shipping mode should not be canceled until just prior to customer delivery.

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

BCM (BODY CONTROL MODULE)

Removal and Installation

INFOID:000000014387259

BCM

REMOVAL


CAUTION:

Before removing the BCM, retrieve current BCM configuration to use for reference when configuring brand-new BCM after installation. Refer to [BCS-7, "BODY CONTROL SYSTEM : System Description"](#).

NOTE:

The BCM is located on the LH side of the instrument panel.

1. Disconnect the battery or batteries. Refer to [PG-185, "Battery Disconnect"](#).
2. Remove the instrument lower panel LH. Refer to [IP-22, "Removal and Installation"](#).
3. Remove the screws (A) and release the BCM.
4. Disconnect the harness connectors.
5. Remove the BCM (1).



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- When replacing BCM, it must be configured. Refer to [BCS-63, "CONFIGURATION \(BCM\) : Description"](#).
- When replacing BCM, perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [BCS-63, "CONFIGURATION \(BCM\) : Description"](#).
- When replacing BCM, perform ID registration procedure of low tire pressure warning system. Refer to [BCS-63, "CONFIGURATION \(BCM\) : Description"](#).

BCS

< REMOVAL AND INSTALLATION >

COMBINATION SWITCH

Removal and Installation

INFOID:0000000014387260

REMOVAL

CAUTION:


- Before servicing, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.
- Do not use air tools or electric tools for servicing.

NOTE:

Shown with steering wheel removed for clarity only.

1. Disconnect the battery or batteries. Refer to [PG-185, "Battery Disconnect"](#).
2. Remove the instrument lower panel LH side. Refer to [IP-22, "Removal and Installation"](#).
3. Remove the upper steering column cover (1) and lower steering column cover.
4. Remove the tilt/telescopic switch electrical connector.
5. Loosen the combination switch bolts.
6. Disconnect the harness connector from the combination switch.
7. Remove the combination switch (2).

Combination switch bolts : 3.5 Nm (0.36 kg-m, 31 in-lb)



AWMIA1768ZZ

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After the work is completed, make sure no system malfunction is detected by air bag warning lamp.
- In case a malfunction is detected by the air bag warning system lamp, reset with the self-diagnosis function and delete the memory with CONSULT [GI-55, "Function and System Application"](#).
- If a malfunction is still detected after the above operation, perform self-diagnosis to repair malfunctions. Refer to [SRC-143, "Diagnosis Procedure"](#).