

DEF

SECTION DEF

DEFOGGER

CONTENTS

PRECAUTION	3	WITH AUTO A/C	15
PRECAUTIONS	3	WITH AUTO A/C : Wiring Diagram	15
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	WITH MANUAL A/C	24
Precaution for Work	3	WITH MANUAL A/C : Wiring Diagram	24
PREPARATION	4	BASIC INSPECTION	30
PREPARATION	4	DIAGNOSIS AND REPAIR WORKFLOW	30
Special Service Tool	4	Work Flow	30
SYSTEM DESCRIPTION	5	DTC/CIRCUIT DIAGNOSIS	33
COMPONENT PARTS	5	REAR WINDOW DEFOGGER SWITCH	33
Component Parts Location	5	WITH AUTO A/C	33
Rear Window Defogger	6	WITH AUTO A/C : Component Function Check	33
Door Mirror Defogger	6	WITH AUTO A/C : Diagnosis Procedure	33
SYSTEM	7	WITH MANUAL A/C	36
System Description	7	WITH MANUAL A/C : Component Function Check	36
DIAGNOSIS SYSTEM (BCM)	9	WITH MANUAL A/C : Diagnosis Procedure	36
COMMON ITEM	9	REAR WINDOW DEFOGGER RELAY	40
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	9	WITH AUTO A/C	40
REAR DEFOGGER	10	WITH AUTO A/C : Component Function Check	40
REAR DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)	10	WITH AUTO A/C : Diagnosis Procedure	40
DIAGNOSIS SYSTEM (IPDM E/R)	12	WITH AUTO A/C : Component Inspection	41
CONSULT Function (IPDM E/R)	12	WITH MANUAL A/C	41
ECU DIAGNOSIS INFORMATION	14	WITH MANUAL A/C : Component Function Check	41
BCM, IPDM E/R	14	WITH MANUAL A/C : Diagnosis Procedure	42
List of ECU Reference	14	WITH MANUAL A/C : Component Inspection	42
WIRING DIAGRAM	15	REAR WINDOW DEFOGGER	44
REAR WINDOW DEFOGGER SYSTEM	15	Component Function Check	44
		Diagnosis Procedure	44
		Component Inspection	45
		DOOR MIRROR DEFOGGER	46
		Component Function Check	46

Diagnosis Procedure	46	REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE	54
DOOR MIRROR DEFOGGER LH	47	Diagnosis Procedure	54
Component Function Check	47		
Diagnosis Procedure	47		
Component Inspection	47		
DOOR MIRROR DEFOGGER RH	49	DOOR MIRROR DEFOGGER DOES NOT OPERATE	55
Component Function Check	49	Diagnosis Procedure	55
Diagnosis Procedure	49		
Component Inspection	49		
SYMPTOM DIAGNOSIS	51	DOOR MIRROR DEFOGGER DOES NOT OPERATE BUT REAR WINDOW DEFOGGER OPERATES	56
REAR WINDOW DEFOGGER SYSTEM		Diagnosis Procedure	56
SYMPTOMS	51		
Symptom Table	51	REAR WINDOW DEFOGGER SWITCH DOES NOT LIGHT, BUT REAR WINDOW DEFOGGER OPERATES	57
REAR WINDOW DEFOGGER DOES NOT OPERATE	52	Diagnosis Procedure	57
Diagnosis Procedure	52		
REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGERS DO NOT OPERATE	53	REMOVAL AND INSTALLATION	58
Diagnosis Procedure	53	REAR WINDOW DEFOGGER	58
		Filament Check	58
		Filament Repair	58

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000014664640

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- **When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.**
- **When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.**

Precaution for Work

INFOID:0000000014389015

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000014389016

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.)	Description
— (J-46534) Trim Tool Set	Removing trim components



COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000014389017



ALLIA19242Z

No.	Component	Function
1.	Door mirror RH	Refer to DEF-6, "Door Mirror Defogger" .
2.	Fuse block (J/B) (Rear window defogger relay-2)	Operates the rear window defogger RH and the door mirror defoggers with the control signal from BCM.
3.	IPDM E/R (Rear window defogger relay-1)	Operates the rear window defogger LH with the control signal from BCM. Refer to PCS-5, "Component Parts Location" for detailed installation location.
4.	A/C auto amp. (with auto A/C)	<ul style="list-style-type: none">Transmits rear window defogger switch ON signal to the BCM.Transmits the indicator lamp ON signal when detecting the operation of rear window defogger. Refer to HAC-10, "Component Parts Location" for detailed installation location.
5.	BCM	<ul style="list-style-type: none">Operates the rear window defogger with the operation of rear window defogger switch.Performs the timer control for rear window defogger. Refer to BCS-5, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
6.	Door mirror LH	Refer to DEF-6, "Door Mirror Defogger" .
7.	A/C switch assembly (rear window defogger switch) (with auto A/C)	<ul style="list-style-type: none">Transmits rear window defogger switch ON signal.Turns the indicator lamp ON when detecting the operation of rear window defogger. Refer to HAC-10, "Component Parts Location" for detailed installation location.
	Front air control (rear window defogger switch) (with manual A/C)	<ul style="list-style-type: none">Transmits rear window defogger switch ON signal.Turns the indicator lamp ON when detecting the operation of rear window defogger. Refer to HAC-140, "Component Parts Location" for detailed installation location.

A
B
C
D
E
F
G
H
I
J
K

DEF

M

N

O

P

COMPONENT PARTS


< SYSTEM DESCRIPTION >

No.	Component	Function
8.	Rear window defogger LH	Refer to DEF-6, "Rear Window Defogger".
9.	Rear window defogger RH	Refer to DEF-6, "Rear Window Defogger".

Rear Window Defogger

INFOID:0000000014389018

Heats the heating wire with the power supply from the rear window defogger relay to prevent the rear window from fogging up.




JMLIA2595GB

Door Mirror Defogger

INFOID:0000000014389019

Heats the heating wire with the power supply from the rear window defogger relay to prevent the door mirror from fogging up.



JMLIA2596GB

SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM


System Description

INFOID:000000014389020

SYSTEM DIAGRAM



Manual A/C



OPERATION DESCRIPTION

Auto A/C

- When rear window defogger switch is turned ON while ignition switch is ON, the A/C switch assembly (rear window defogger switch) transmits rear window defogger switch signal to A/C auto amp.
- A/C auto amp. transmits rear window defogger switch signal to BCM.
- BCM transmits rear window defogger relay-1 control signal to IPDM E/R via CAN communication and the rear window defogger relay-2 control signal to the rear window defogger relay-2 for approximately 15 minutes.
- IPDM E/R turns rear window defogger relay-1 ON when rear window defogger relay-1 control signal is received.
- Rear window defogger LH (if equipped) is supplied with power and operates when rear window defogger relay-1 is turned ON.
- Rear window defogger RH (if equipped) and door mirror defoggers (if equipped) are supplied with power and operate when rear window defogger relay-2 is turned ON.

SYSTEM

< SYSTEM DESCRIPTION >

- When rear window defogger or door mirror defoggers are activated, indicator lamp on rear window defogger switch turns ON.

Manual A/C

- When door mirror defogger switch is turned ON while ignition switch is ON, the front air control (door mirror defogger switch) transmits rear window defogger switch signal to BCM.
- BCM transmits rear window defogger relay-2 control signal to rear window defogger relay-2.
- Door mirror defoggers are supplied with power and operate when rear window defogger relay-2 is turned ON.
- Mirror defogger ON is displayed when signal is received.

TIMER FUNCTION

- BCM turns rear window defogger relays ON for approximately 15 minutes when rear window defogger switch is turned ON while ignition switch is ON. It makes rear window defogger and door mirror defogger operate.
- Timer is canceled after pressing rear window defogger switch again during timer operation. The BCM turns rear window defogger relays OFF. The same reaction also occurs during timer operation, if the ignition switch is turned OFF.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000014687451

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none">The vehicle specification can be read and saved.The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions:

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays it on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed at the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) at the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK").
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF").
	LOCK>ACC	While turning power supply position from "LOCK" *to "ACC"
	ACC>ON	While turning power supply position from "ACC" to "IGN"
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopped and selector lever is in P position.)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF"
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC	While turning power supply position from "OFF" to "ACC"
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK"*.) to low power consumption mode
	LOCK	Power supply position is "LOCK" (Ignition switch OFF)*
	OFF	Power supply position is "OFF" (Ignition switch OFF)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition is switched OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met:

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

REAR DEFOGGER

REAR DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:0000000014687450

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
REAR DEF SW [On/Off]	Indicates condition of rear window defogger switch.

A

ACTIVE TEST

Test Item	Description
REAR DEFOGGER	This test is able to check rear window defogger operation [Off/On].

B

WORK SUPPORT

Support Item	Setting	Description
SET R-DEF TIMER	MODE3	Rear defogger turns OFF after 1 minute.
	MODE2	Rear defogger remains ON until turned OFF.
	MODE1*	Rear defogger turns OFF after 15 minutes.

C

D

E

* : Initial setting

F

G

H

I

J

K

DEF

M

N

O

P

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R)

CONSULT Function (IPDM E/R)

INFOID:000000014687452

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R:

Direct Diagnostic Mode	Description
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SELF DIAGNOSTIC RESULT

Refer to [PCS-23, "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line.
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
INTER/NP SW [On/Off]		Indicates condition of AT shift position.
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line.
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line.
ST/INHI RLY [Off/ ST /INHI]		Indicates condition of starter relay and starter control relay.
DETENT SW [On/Off]		Indicates condition of AT shift selector (park position switch).
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch.
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line
HOOD SW 2 [On/Off]		Indicates condition of hood switch 2.

ACTIVE TEST

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

Test item	Description
REAR DEFOGGER	This test is able to check rear defogger operation [On/Off].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].
HORN	This test is able to check horn operation [On].

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM, IPDM E/R

List of ECU Reference

INFOID:000000014389024

ECU	Reference
BCM	BCS-32, "Reference Value"
	BCS-51, "Fail_Safe"
	BCS-51, "DTC_Inspection_Priority_Chart"
	BCS-52, "DTC_Index"
IPDM E/R	PCS-14, "Reference Value"
	PCS-22, "Fail_Safe"
	PCS-23, "DTC_Index"

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

WIRING DIAGRAM

REAR WINDOW DEFOGGER SYSTEM WITH AUTO A/C

WITH AUTO A/C : Wiring Diagram


INFOID:0000000014389025

DEFOGGER - WITH AUTOMATIC A/C

- CAN COMMUNICATION LINE FOR DIAGNOSIS
- HM : WITH HEATED MIRRORS
- RV : WITH REAR WINDOW DEFOGGER
- V2 : WITH VK56VD AND WITH DRIVER ASSISTANCE
- V4 : CAN GATEWAY SYSTEM WITH Cummins 5.0L
- V6 : WITH Cummins 5.0L AND WITH NAVIGATION W
- V7 : WITH Cummins 5.0L AND WITH NAVIGATION W
- V8 : WITH VK56VD
- V9 : WITH Cummins 5.0L

IGNITION SWITCH
ON/OF START

BATTERY




REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFOGGER CONNECTORS - WITH AUTOMATIC A/C

Connector No.	B25	1	R	REAR WINDOW DEFOGGER
Connector Name	WIRE TO WIRE	2	B	GROUND
Connector Type	LO2MB-MC			
Connector Color	BLACK			
				

Connector No.	B149	1	R	REAR WINDOW DEFOGGER
Connector Name	WIRE TO WIRE	2	B	GROUND
Connector Type	TH80MDG7-CS16-TM4			
Connector Color	GRAY			
				



Terminal	Color of Wire	Signal Name	19A	LG	TO MAIN HARNESS
1	W	TO ENGINE ROOM HARNESS	20A	R	TO MAIN HARNESS
2	W	TO ENGINE ROOM HARNESS	21A	BG	TO MAIN HARNESS
			22A	LGR	TO MAIN HARNESS
			23A	YLG	TO MAIN HARNESS
			24A	BR/Y	TO MAIN HARNESS
			25A	-	TO MAIN HARNESS
			26A	GR	TO MAIN HARNESS
			27A	LG	TO MAIN HARNESS
			28A	LG/B	TO MAIN HARNESS
			29A	-	TO MAIN HARNESS
			30A	BR	TO MAIN HARNESS
			31A	W/R	TO MAIN HARNESS
			32A	G/R	TO MAIN HARNESS
			33A	-	TO MAIN HARNESS
			34A	SHIELD	TO MAIN HARNESS
			35A	P	TO MAIN HARNESS
			36A	B	TO MAIN HARNESS
			37A	-	TO MAIN HARNESS
			38A	R/B	TO MAIN HARNESS
			39A	G/O	TO MAIN HARNESS
			40A	V	TO MAIN HARNESS
			41A	SHIELD	TO MAIN HARNESS
			42A	SHIELD	TO MAIN HARNESS
			43A	R	TO MAIN HARNESS
			44A	G	TO MAIN HARNESS
			45A	-	TO MAIN HARNESS
			46A	-	TO MAIN HARNESS
			47A	Y	TO MAIN HARNESS
			48A	R/W	TO MAIN HARNESS
			49A	R/L	TO MAIN HARNESS
			50A	B	TO MAIN HARNESS
			51A	-	TO MAIN HARNESS
			52A	-	TO MAIN HARNESS
			53A	-	TO MAIN HARNESS
			54A	-	TO MAIN HARNESS
			55A	-	TO MAIN HARNESS
			56A	-	TO MAIN HARNESS
			57A	-	TO MAIN HARNESS
			58A	-	TO MAIN HARNESS
			59A	-	TO MAIN HARNESS
			60A	G/W	TO MAIN HARNESS
			61A	-	TO MAIN HARNESS
			62A	-	TO MAIN HARNESS
			63A	-	TO MAIN HARNESS
			64A	-	TO MAIN HARNESS
			65A	-	TO MAIN HARNESS
			66A	-	TO MAIN HARNESS
			67A	-	TO MAIN HARNESS
			68A	-	TO MAIN HARNESS
			69A	Y/R	TO MAIN HARNESS
			70A	R/G	TO MAIN HARNESS
			71A	-	TO MAIN HARNESS

Terminal No.	B78	1	R	REAR WINDOW DEFOGGER
Connector Name	REAR WINDOW DEFOGGER	2	B	GROUND
Connector Type	LH			
Connector Color	WHITE			
				

Terminal No.	SB	1	R	REAR WINDOW DEFOGGER
Connector Name	REAR WINDOW DEFOGGER	2	B	GROUND
Connector Type	MM2MW-LC			
Connector Color	WHITE			
				

Terminal No.	SBG	1	R	REAR WINDOW DEFOGGER
Connector Name	REAR WINDOW DEFOGGER	2	B	GROUND
Connector Type	MM2MW-LC			
Connector Color	WHITE			
				

AALIA5571GB

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFOGGER CONNECTORS - WITH AUTOMATIC A/C

Connector No.	D2	5	GR	POWERFOLD FOLD+ (WITH MEMORY MIRRORS)
Connector Name	WIRE TO WIRE	6	B/W	HEATED MIRROR +
Connector Type	NS16FW-CS	7	W	VCC
Connector Color	WHITE	8	R	VIDEO +
		9	G/B	FRONT TURN LH
		10	B	GND
		11	L/G/B	EC FEED
		12	Y/V	EC RETURN
		13	Y	MEMORY/GND
		14	SB	MEMORY FEED
		15	V	HOR SENSOR
		16	BG	VER SENSOR
		17	-	-
Terminal No.		Signal Name		Signal Name
1	B/W	TO MAIN HARNESS	B	HEATED MIRROR -
2	G/B	TO MAIN HARNESS	GND	SHIELD
3	L	TO MAIN HARNESS	B	VIDEO -
4	R	TO MAIN HARNESS	R/G	BAT SAVER OUT
5	W/R	TO MAIN HARNESS	L	ROOM LAMP CONT
6	W/L	TO MAIN HARNESS	W	LED LH
7	V	TO MAIN HARNESS	GND	EC FEED
8	B	TO MAIN HARNESS	B	EC RETURN
9	L/W	TO MAIN HARNESS	W	MEMORY GND
10	L/R	TO MAIN HARNESS	GND	VIDEO -
11	L/W	TO MAIN HARNESS	Y/V	FR TURN RH
12	L	TO MAIN HARNESS	Y	MEMORY FEED
13	Y	TO MAIN HARNESS	V	HOR SENSOR
14	SB	TO MAIN HARNESS	Y	VER SENSOR
15	V	TO MAIN HARNESS	BR	-
16	LG	TO MAIN HARNESS	16	-



Connector No.	D4	5	GR	SWITCH MIRROR LH
Connector Name	DOOR MIRROR LH	6	B/W	TO MAIN HARNESS
Connector Type	TH24MW-NH	7	B	TO MAIN HARNESS
Connector Color	WHITE	8	W/L	TO MAIN HARNESS
		9	V	TO MAIN HARNESS
		10	W/B	TO MAIN HARNESS
		11	G/Y	TO MAIN HARNESS
		12	W/B	TO MAIN HARNESS
		13	Y	TO MAIN HARNESS
		14	SB	TO MAIN HARNESS
		15	V	TO MAIN HARNESS
		16	LG	TO MAIN HARNESS



Connector No.	D101	5	GR	POWERFOLD FOLD+ (WITH MEMORY MIRRORS)
Connector Name	WIRE TO WIRE	6	B/W	HEATED MIRROR -
Connector Type	NS10FW-CS	7	W	VCC
Connector Color	WHITE	8	R	VIDEO -
		9	G/B	FR TURN RH
		10	B	GND
		11	L/G/B	EC FEED
		12	Y/V	EC RETURN
		13	Y	MEMORY GND
		14	SB	MEMORY FEED
		15	V	HOR SENSOR
		16	LG	VER SENSOR
		17	-	-
Terminal No.		Signal Name		Signal Name
1	B/W	TO MAIN HARNESS	B	HEATED MIRROR -
2	G/B	TO MAIN HARNESS	GND	SHIELD
3	L	TO MAIN HARNESS	B	VIDEO -
4	R	TO MAIN HARNESS	R/G	BAT SAVER OUT
5	W/R	TO MAIN HARNESS	L	ROOM AMP CONT
6	W/L	TO MAIN HARNESS	R	LED RH
7	V	TO MAIN HARNESS	GND	CAN-H
8	W/B	TO MAIN HARNESS	B	CAN-L
9	G/Y	TO MAIN HARNESS	BR	DTRI_RLY
10	LG	TO MAIN HARNESS	43	-
11	Y/V	TO MAIN HARNESS	44	W/B
12	Y	TO MAIN HARNESS	45	GR
13	SB	TO MAIN HARNESS	46	Y
14	V	TO MAIN HARNESS	47	Y
15	LG	TO MAIN HARNESS	48	RW
16	W/B	TO MAIN HARNESS	-	-



Connector No.	D107	5	GR	POWERFOLD FOLD+ (WITH MEMORY MIRRORS)
Connector Name	DOOR MIRROR RH	6	B/W	HEATED MIRROR +
Connector Type	TH24MW-NH	7	W	VCC
Connector Color	WHITE	8	R	VIDEO +
		9	G/B	FR TURN LH
		10	B	GND
		11	L/G/B	EC FEED
		12	Y/V	EC RETURN
		13	Y	MEMORY GND
		14	SB	MEMORY FEED
		15	V	HOR SENSOR
		16	LG	VER SENSOR
		17	-	-
Terminal No.		Signal Name		Signal Name
1	B/W	TO MAIN HARNESS	B	HEATED MIRROR +
2	G/B	TO MAIN HARNESS	GND	SHIELD
3	L	TO MAIN HARNESS	B	VIDEO +
4	R	TO MAIN HARNESS	R/G	BAT SAVER OUT
5	W/R	TO MAIN HARNESS	L	ROOM AMP CONT
6	W/L	TO MAIN HARNESS	R	LED RH
7	V	TO MAIN HARNESS	GND	CAN-H
8	W/B	TO MAIN HARNESS	B	CAN-L
9	G/Y	TO MAIN HARNESS	BR	DTRI_RLY
10	LG	TO MAIN HARNESS	43	-
11	Y/V	TO MAIN HARNESS	44	W/B
12	Y	TO MAIN HARNESS	45	GR
13	SB	TO MAIN HARNESS	46	Y
14	V	TO MAIN HARNESS	47	Y
15	LG	TO MAIN HARNESS	48	RW
16	W/B	TO MAIN HARNESS	-	-



Connector No.	E34	5	GR	POWERFOLD FOLD+ (WITH MEMORY MIRRORS)
Connector Name	WIRE TO WIRE	6	B/W	HEATED MIRROR -
Connector Type	L02FB-MC	7	W	VCC
Connector Color	BLACK	8	R	VIDEO -
		9	G/B	FR TURN LH
		10	B	GND
		11	L/G/B	EC FEED
		12	Y/V	EC RETURN
		13	Y	MEMORY/GND
		14	SB	MEMORY FEED
		15	V	HOR SENSOR
		16	LG	VER SENSOR
		17	-	-
Terminal No.		Signal Name		Signal Name
1	B/W	TO MAIN HARNESS	B	HEATED MIRROR -
2	G/B	TO MAIN HARNESS	GND	SHIELD
3	L	TO MAIN HARNESS	B	VIDEO -
4	R	TO MAIN HARNESS	R/G	BAT SAVER OUT
5	W/R	TO MAIN HARNESS	L	ROOM AMP CONT
6	W/L	TO MAIN HARNESS	R	LED RH
7	V	TO MAIN HARNESS	GND	CAN-H
8	W/B	TO MAIN HARNESS	B	CAN-L
9	G/Y	TO MAIN HARNESS	BR	DTRI_RLY
10	LG	TO MAIN HARNESS	43	-
11	Y/V	TO MAIN HARNESS	44	W/B
12	Y	TO MAIN HARNESS	45	GR
13	SB	TO MAIN HARNESS	46	Y
14	V	TO MAIN HARNESS	47	Y
15	LG	TO MAIN HARNESS	48	RW
16	W/B	TO MAIN HARNESS	-	-



Connector No.	E122	5	GR	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Name	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	6	W	TO BODY HARNESS
Connector Type	TH12FW-NH	7	WB	TO BODY HARNESS
Connector Color	WHITE	-	-	-
Connector No.	D101	5	GR	POWERFOLD FOLD+ (WITH MEMORY MIRRORS)
Connector Name	WIRE TO WIRE	6	B/W	HEATED MIRROR +
Connector Type	NS10FW-CS	7	W	VCC
Connector Color	WHITE	8	R	VIDEO -
		9	G/Y	FR TURN RH
		10	B	GND
		11	L/G/B	EC FEED
		12	Y/V	EC RETURN
		13	L	MEMORY GND
		14	V	MEMORY FEED
		15	Y	HOR SENSOR
		16	BR	VER SENSOR
		17	-	-
Terminal No.		Signal Name		Signal Name
1	B/W	TO MAIN HARNESS	B	HEATED MIRROR +
2	G/B	TO MAIN HARNESS	GND	SHIELD
3	L	TO MAIN HARNESS	B	VIDEO -
4	R	TO MAIN HARNESS	R/G	BAT SAVER OUT
5	W/R	TO MAIN HARNESS	L	ROOM AMP CONT
6	W/L	TO MAIN HARNESS	R	LED RH
7	V	TO MAIN HARNESS	GND	CAN-H
8	W/B	TO MAIN HARNESS	B	CAN-L
9	G/Y	TO MAIN HARNESS	BR	DTRI_RLY
10	LG	TO MAIN HARNESS	43	-
11	Y/V	TO MAIN HARNESS	44	W/B
12	Y	TO MAIN HARNESS	45	GR
13	SB	TO MAIN HARNESS	46	Y
14	V	TO MAIN HARNESS	47	Y
15	LG	TO MAIN HARNESS	48	RW
16	W/B	TO MAIN HARNESS	-	-



Connector No.	D107	5	GR	POWERFOLD FOLD+ (WITH MEMORY MIRRORS)
Connector Name	DOOR MIRROR RH	6	B/W	HEATED MIRROR +
Connector Type	TH24MW-NH	7	W	VCC
Connector Color	WHITE	8	R	VIDEO +
		9	G/B	FR TURN LH
		10	B	GND
		11	L/G/B	EC FEED
		12	Y/V	EC RETURN
		13	Y	MEMORY/GND
		14	SB	MEMORY FEED
		15	V	HOR SENSOR
		16	LG	VER SENSOR
		17	-	-
Terminal No.		Signal Name		Signal Name
1	B/W	TO MAIN HARNESS	B	HEATED MIRROR +
2	G/B	TO MAIN HARNESS	GND	SHIELD
3	L	TO MAIN HARNESS	B	VIDEO +
4	R	TO MAIN HARNESS	R/G	BAT SAVER OUT
5	W/R	TO MAIN HARNESS	L	ROOM AMP CONT
6	W/L	TO MAIN HARNESS	R	LED RH
7	V	TO MAIN HARNESS	GND	CAN-H
8	W/B	TO MAIN HARNESS	B	CAN-L
9	G/Y	TO MAIN HARNESS	BR	DTRI_RLY
10	LG	TO MAIN HARNESS	43	-
11	Y/V	TO MAIN HARNESS	44	W/B
12	Y	TO MAIN HARNESS	45	GR
13	SB	TO MAIN HARNESS	46	Y
14	V	TO MAIN HARNESS	47	Y
15	LG	TO MAIN HARNESS	48	RW
16	W/B	TO MAIN HARNESS	-	-



Connector No.	E122	5	GR	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Name	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM	6	W	TO BODY HARNESS
Connector Type	TH12FW-NH	7	WB	TO BODY HARNESS
Connector Color	WHITE	8	W	TO BODY HARNESS
		-	-	-
Connector No.	D101	5	GR	POWERFOLD FOLD+ (WITH MEMORY MIRRORS)
Connector Name	WIRE TO WIRE	6	B/W	HEATED MIRROR -
Connector Type	NS10FW-CS	7	W	VCC
Connector Color	WHITE	8	R	VIDEO -
		9	G/B	FR TURN RH
		10	B	GND
		11	L/G/B	EC FEED
		12	Y/V	EC RETURN
		13	Y	MEMORY GND
		14	SB	MEMORY FEED
		15	V	HOR SENSOR
		16	LG	VER SENSOR
		17	-	-
Terminal No.		Signal Name		Signal Name
1	B/W	TO MAIN HARNESS	B	HEATED MIRROR -
2	G/B	TO MAIN HARNESS	GND	SHIELD
3	L	TO MAIN HARNESS	B	VIDEO -
4	R	TO MAIN HARNESS	R/G	BAT SAVER OUT
5	W/R	TO MAIN HARNESS	L	ROOM AMP CONT
6	W/L	TO MAIN HARNESS	R	LED RH
7	V	TO MAIN HARNESS	GND	CAN-H
8	W/B	TO MAIN HARNESS	B	CAN-L
9	G/Y	TO MAIN HARNESS	BR	DTRI_RLY
10	LG	TO MAIN HARNESS	43	-
11	Y/V	TO MAIN HARNESS	44	W/B
12	Y	TO MAIN HARNESS	45	GR
13	SB	TO MAIN HARNESS	46	Y
14	V	TO MAIN HARNESS	47	Y
15	LG	TO MAIN HARNESS	48	RW
16	W/B	TO MAIN HARNESS	-	-



Connector No.	D107	5	GR	POWERFOLD FOLD+ (WITH MEMORY MIRRORS)


<tbl

REAR WINDOW DEFOGGER SYSTEM


< WIRING DIAGRAM >

DEFROGGER CONNECTORS - WITH AUTOMATIC A/C

Connector No.	E123	Connector No.	E130
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS08FBR-CS	Connector Type	TH10FB-NH
Connector Color	BROWN	Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
49	Y/B	A/C COMP - (WITH CUMMINS 5.0L)	63	-	-
49	GR/IR	A/C COMP - (WITH VK56VD)	64	R	DETENT SW
50	BR	TRAILER TOW	65	-	-
51	-	-	66	P	PUSH START SW
52	B	S-GND	67	-	-
53	-	-	68	L	IGN SIGNAL
54	-	-	69	-	-
55	-	-	70	-	-
56	-	-	71	SB	HOOD SW2
			72	W	E-CTRL - (WITH VK56VD)



Connector No.	E124	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M06FB-LC	Connector Type	M06FB-LC
Connector Color	BLACK	Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
57	W/B	RR DEF
58	BR	FUEL PUMP - (WITH CUMMINS 5.0L)
58	BR	FUEL PUMP - (WITH VK56VD)
59	-	-
60	-	-
61	-	-
62	B	P GND

AALIA5573GB

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFOGGER CONNECTORS - WITH AUTOMATIC A/C

Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name	Connector No.	Connector Name	Connector Type	Connector Color
ET152	WIRE TO WIRE	R/W	24G	Q/B	TO MAIN HARNESS	72G	L/W	TO MAIN HARNESS	
			25G	R/W	TO MAIN HARNESS	73G	SHIELD	TO MAIN HARNESS	
			26G	R	TO MAIN HARNESS	74G	W	TO MAIN HARNESS	
			27G	LG	TO MAIN HARNESS	75G	R	TO MAIN HARNESS	
			28G	Q/B	TO MAIN HARNESS	76G	R/G	TO MAIN HARNESS	
			29G	Q/B	TO MAIN HARNESS	77G	G	TO MAIN HARNESS	
			30G	BR/Y	TO MAIN HARNESS	78G	W	TO MAIN HARNESS	
			31G	P	TO MAIN HARNESS - (WITH CUMMINS 5.0L)	79G	-	TO MAIN HARNESS	
			31G	R	TO MAIN HARNESS - (WITH VGS610)	80G	R	TO MAIN HARNESS	
			32G	P	TO MAIN HARNESS	81G	L	TO MAIN HARNESS	
			33G	Y/L	TO MAIN HARNESS	82G	R	TO MAIN HARNESS	
			34G	GR	TO MAIN HARNESS	83G	L	TO MAIN HARNESS	
			35G	GR	TO MAIN HARNESS	85G	W/B	TO MAIN HARNESS	
			36G	SB	TO MAIN HARNESS	86G	BR	TO MAIN HARNESS	
			37G	R/W	TO MAIN HARNESS	87G	W/B	TO MAIN HARNESS	
			38G	BR	TO MAIN HARNESS	88G	P	TO MAIN HARNESS	
			39G	BR	TO MAIN HARNESS	89G	L	TO MAIN HARNESS	
			40G	-	TO MAIN HARNESS	90G	G	TO MAIN HARNESS	
			41G	R/G	TO MAIN HARNESS	91G	G	TO MAIN HARNESS	
			42G	O	TO MAIN HARNESS	92G	V/W	TO MAIN HARNESS	
			43G	B	TO MAIN HARNESS - (WITH CUMMINS 5.0L)	93G	BR	TO MAIN HARNESS	
			43G	G	TO MAIN HARNESS - (WITH VGS610)	94G	G	TO MAIN HARNESS	
			44G	R/Y	TO MAIN HARNESS	95G	G	TO MAIN HARNESS	
			45G	G	TO MAIN HARNESS	96G	W	TO MAIN HARNESS	
			46G	LG	TO MAIN HARNESS	97G	R	TO MAIN HARNESS	
			47G	R	TO MAIN HARNESS	98G	BR	TO MAIN HARNESS	
			48G	W	TO MAIN HARNESS	99G	GR/W	TO MAIN HARNESS	
			49G	-	TO MAIN HARNESS	100G	-	TO MAIN HARNESS	
			50G	BR	TO MAIN HARNESS	96G	W	TO MAIN HARNESS	
			51G	R	TO MAIN HARNESS	97G	R	TO MAIN HARNESS	
			52G	L	TO MAIN HARNESS	98G	W/B	TO MAIN HARNESS	
			53G	W	TO MAIN HARNESS	99G	BR	TO MAIN HARNESS	
			54G	W	TO MAIN HARNESS - (WITH CUMMINS 5.0L)	100G	GR/W	TO MAIN HARNESS	
			55G	Y	TO MAIN HARNESS	96G	W	TO MAIN HARNESS	
			56G	G	TO MAIN HARNESS	97G	R	TO MAIN HARNESS	
			66G	P	TO MAIN HARNESS - (WITH VGS610)	98G	W/B	TO MAIN HARNESS	
			66G	R/W	TO MAIN HARNESS - (WITH CUMMINS 5.0L)	99G	BR	TO MAIN HARNESS	
			76G	Y	TO MAIN HARNESS	100G	GR/W	TO MAIN HARNESS	
			86G	BR	TO MAIN HARNESS	96G	W	TO MAIN HARNESS	
			96G	R	TO MAIN HARNESS	97G	R	TO MAIN HARNESS	
			106G	W	TO MAIN HARNESS	98G	W/B	TO MAIN HARNESS	
			116G	R/G	TO MAIN HARNESS	99G	BR	TO MAIN HARNESS	
			126G	W/B	TO MAIN HARNESS	100G	GR/W	TO MAIN HARNESS	
			13G	BR	TO MAIN HARNESS	96G	W	TO MAIN HARNESS	
			14G	Y/B	TO MAIN HARNESS	97G	R	TO MAIN HARNESS	
			15G	GW	TO MAIN HARNESS	98G	W	TO MAIN HARNESS	
			16G	G	TO MAIN HARNESS	99G	R	TO MAIN HARNESS	
			17G	GY	TO MAIN HARNESS	100G	W/L	TO MAIN HARNESS	
			18G	GY	TO MAIN HARNESS	65G	W/R	TO MAIN HARNESS	
			19G	Y/N	TO MAIN HARNESS	66G	BR	TO MAIN HARNESS	
			20G	GY	TO MAIN HARNESS	67G	BR	TO MAIN HARNESS	
			21G	BY	TO MAIN HARNESS	68G	B	TO MAIN HARNESS	
			22G	GR	TO MAIN HARNESS	69G	Y	TO MAIN HARNESS	
			23G	Y/R	TO MAIN HARNESS	70G	L	TO MAIN HARNESS	
			71G	R/W	TO MAIN HARNESS	71G	W	TO MAIN HARNESS	

AALIA5574GB

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFOGGER CONNECTORS - WITH AUTOMATIC A/C

Connector No.	Wire	Signal Name						
1	2	3						
8	9	10	11	12	13	14	15	16
WIRE	WIRE	WIRE	WIRE	WIRE	WIRE	WIRE	WIRE	WIRE
NS16MW-CS								
WHITE								

H.S.

Terminal No.	Color of Wire	Signal Name
1	B/W	TO FRONT DOOR LH HARNESS
2	GR/B	TO FRONT DOOR LH HARNESS
3	L	TO FRONT DOOR LH HARNESS
4	R	TO FRONT DOOR LH HARNESS
5	W/R	TO FRONT DOOR LH HARNESS
6	W/L	TO FRONT DOOR LH HARNESS
7	V	TO FRONT DOOR LH HARNESS
8	B	TO FRONT DOOR LH HARNESS
9	L/W	TO FRONT DOOR LH HARNESS
10	L/R	TO FRONT DOOR LH HARNESS
11	L/W	TO FRONT DOOR LH HARNESS
12	L	TO FRONT DOOR LH HARNESS
13	Y	TO FRONT DOOR LH HARNESS
14	SB	TO FRONT DOOR LH HARNESS
15	V	TO FRONT DOOR LH HARNESS
16	L/G	TO FRONT DOOR LH HARNESS

Terminal No.	Color of Wire	Signal Name
7	-	-
8	-	-
9	-	-
10	SB	COMBI SW IN 5
11	G/Y	COMBI SW IN 4
12	Y	COMBI SW IN 3
13	GR/B	COMBI SW IN 2
14	V	COMBI SW IN 1
15	-	-
16	-	-
17	P	GND RF A/L
18	V	SECURITY INDICATOR
19	-	-
20	R	SHIFT P
21	R/W	STEP LAMP CONT
22	-	-
23	Y	AIRCON SW
24	-	-
25	W	BRAKE SW FUSE
26	L	SHORT IN PIN INPUT
27	R/G	BRAKE SW LAMP
28	-	-
29	W	BLOWER FAN SW
30	P	DR DOOR LOCK STATUS
31	-	-
32	Y	REAR DEFOGGER SW
33	-	-
34	-	-
35	R/G	REVERSE SW
36	W/B	HAZARD SW
37	-	-
38	-	-
39	B/R	SHIFT N/P
40	-	-

Terminal No.	Color of Wire	Signal Name
7	-	-
8	-	-
9	-	-
10	SB	COMBI SW IN 5
11	G/Y	COMBI SW IN 4
12	Y	COMBI SW IN 3
13	GR/B	COMBI SW IN 2
14	V	COMBI SW IN 1
15	-	-
16	-	-
17	P	GND RF A/L
18	V	SECURITY INDICATOR
19	-	-
20	R	SHIFT P
21	R/W	STEP LAMP CONT
22	-	-
23	Y	AIRCON SW
24	-	-
25	W	BRAKE SW FUSE
26	L	SHORT IN PIN INPUT
27	R/G	BRAKE SW LAMP
28	-	-
29	W	BLOWER FAN SW
30	P	DR DOOR LOCK STATUS
31	-	-
32	Y	REAR DEFOGGER SW
33	-	-
34	-	-
35	R/G	REVERSE SW
36	W/B	HAZARD SW
37	-	-
38	-	-
39	B/R	SHIFT N/P
40	-	-

Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW NO ESC
2	-	-
3	R	AL POWER SUPPLY 5V
4	W/R	A/T SIGNAL
5	-	-
6	-	-



Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW NO ESC
2	-	-
3	R	AL POWER SUPPLY 5V
4	W/R	A/T SIGNAL
5	-	-
6	-	-

AALIA5575GB

Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW NO ESC
2	-	-
3	R	AL POWER SUPPLY 5V
4	W/R	A/T SIGNAL
5	-	-
6	-	-

Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW NO ESC
2	-	-
3	R	AL POWER SUPPLY 5V
4	W/R	A/T SIGNAL
5	-	-
6	-	-

Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW NO ESC
2	-	-
3	R	AL POWER SUPPLY 5V
4	W/R	A/T SIGNAL
5	-	-
6	-	-

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFOGGER CONNECTORS - WITH AUTOMATIC A/C

Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name	
M31	WIRE TO WIRE	27G	LG	TO ENGINE ROOM HARNESS	80G	R	TO ENGINE ROOM HARNESS	81G	L	TO ENGINE ROOM HARNESS
		28G	G/B	TO ENGINE ROOM HARNESS	82G	R	TO ENGINE ROOM HARNESS	83G	L	TO ENGINE ROOM HARNESS
		29G	G/B	TO ENGINE ROOM HARNESS	84G	L	TO ENGINE ROOM HARNESS	85G	W	TO ENGINE ROOM HARNESS
		30G	BR/Y	TO ENGINE ROOM HARNESS	86G	BR	TO ENGINE ROOM HARNESS	87G	W	TO ENGINE ROOM HARNESS
		31G	R	TO ENGINE ROOM HARNESS	88G	G	TO ENGINE ROOM HARNESS	89G	P	TO ENGINE ROOM HARNESS
		32G	R	TO ENGINE ROOM HARNESS	90G	G	TO ENGINE ROOM HARNESS	91G	P	TO ENGINE ROOM HARNESS
		33G	Y/L	TO ENGINE ROOM HARNESS	92G	W/N	TO ENGINE ROOM HARNESS	93G	BR	TO ENGINE ROOM HARNESS
		34G	GR	TO ENGINE ROOM HARNESS	94G	B	TO ENGINE ROOM HARNESS	95G	G	TO ENGINE ROOM HARNESS
		35G	G/R	TO ENGINE ROOM HARNESS	96G	R	TO ENGINE ROOM HARNESS	97G	R	TO ENGINE ROOM HARNESS
		36G	SB	TO ENGINE ROOM HARNESS	98G	W/R	TO ENGINE ROOM HARNESS	99G	R	TO ENGINE ROOM HARNESS
		37G	R/W	TO ENGINE ROOM HARNESS	100G	R	TO ENGINE ROOM HARNESS	101G	GR/W	TO ENGINE ROOM HARNESS
		38G	BR	TO ENGINE ROOM HARNESS						
		39G	BR	TO ENGINE ROOM HARNESS						
		40G	-	TO ENGINE ROOM HARNESS						
		41G	R/G	TO ENGINE ROOM HARNESS						
		42G	O	TO ENGINE ROOM HARNESS						
		43G	G	TO ENGINE ROOM HARNESS						
		44G	R/Y	TO ENGINE ROOM HARNESS						
		45G	G	TO ENGINE ROOM HARNESS						
		46G	LG	TO ENGINE ROOM HARNESS						
		47G	R	TO ENGINE ROOM HARNESS						
		48G	W	TO ENGINE ROOM HARNESS						
		49G	-	TO ENGINE ROOM HARNESS						
		50G	BR	TO ENGINE ROOM HARNESS						
		51G	R	TO ENGINE ROOM HARNESS						
		52G	L	TO ENGINE ROOM HARNESS						
		53G	W	TO ENGINE ROOM HARNESS						
		54G	W	TO ENGINE ROOM HARNESS						
		55G	G	TO ENGINE ROOM HARNESS						
		56G	W	TO ENGINE ROOM HARNESS						
		57G	Y	TO ENGINE ROOM HARNESS						
		58G	B/G	TO ENGINE ROOM HARNESS						
		59G	B/G	TO ENGINE ROOM HARNESS						
		60G	B/G	TO ENGINE ROOM HARNESS						
		61G	O	TO ENGINE ROOM HARNESS						
		62G	W	TO ENGINE ROOM HARNESS						
		63G	O	TO ENGINE ROOM HARNESS						
		64G	W/L	TO ENGINE ROOM HARNESS						
		65G	W/R	TO ENGINE ROOM HARNESS						
		66G	B/G	TO ENGINE ROOM HARNESS						
		67G	B/G	TO ENGINE ROOM HARNESS						
		68G	O	TO ENGINE ROOM HARNESS						
		69G	W	TO ENGINE ROOM HARNESS						
		70G	Y	TO ENGINE ROOM HARNESS						
		71G	R/W	TO ENGINE ROOM HARNESS						
		72G	L/W	TO ENGINE ROOM HARNESS						
		73G	SHIELD	TO ENGINE ROOM HARNESS						
		74G	B	TO ENGINE ROOM HARNESS						
		75G	R	TO ENGINE ROOM HARNESS						
		76G	R/G	TO ENGINE ROOM HARNESS						
		77G	B/G	TO ENGINE ROOM HARNESS						
		78G	P	TO ENGINE ROOM HARNESS						
		79G	-	TO ENGINE ROOM HARNESS						

AALIA5576GB

DEF

ME

Z

O

P

A

B

C

D

E

F

G

H

I

J

K

L

M

DEF

ME

Z

O

P


A

B

C

D

1G	2G	3G	4G	5G	6G	7G	8G	9G	10G
1G	2G	3G	4G	5G	6G	7G	8G	9G	10G
1G	2G	3G	4G	5G	6G	7G	8G	9G	10G
1G	2G	3G	4G	5G	6G	7G	8G	9G	10G
1G	2G	3G	4G	5G	6G	7G	8G	9G	10G



REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFROGGER CONNECTORS - WITH AUTOMATIC A/C

Connector No.	M36	22A	G	TO BODY NO. 2 HARNESS	75A	SHIELD	TO BODY NO. 2 HARNESS	Connector No.	M75
Connector Name	WIRE TO WIRE	23A	Y	TO BODY NO. 2 HARNESS	76A	R	TO BODY NO. 2 HARNESS	Connector Name	WIRE TO WIRE
Connector Type	THB01FDGY-CS16-TM4	24A	L	TO BODY NO. 2 HARNESS	77A	L	TO BODY NO. 2 HARNESS	Connector Type	NST10MW-CS
Connector Color	GRAY	25A	-	TO BODY NO. 2 HARNESS	78A	SHIELD	TO BODY NO. 2 HARNESS	Connector Color	WHITE
H.S.		26A	GR	TO BODY NO. 2 HARNESS	79A	GR	TO BODY NO. 2 HARNESS		
		27A	LG	TO BODY NO. 2 HARNESS	80A	V	TO BODY NO. 2 HARNESS		
		28A	LG	TO BODY NO. 2 HARNESS	81A	R	TO BODY NO. 2 HARNESS		
		29A	GR	TO BODY NO. 2 HARNESS	82A	SHIELD	TO BODY NO. 2 HARNESS		
		30A	BR	TO BODY NO. 2 HARNESS	83A	R	TO BODY NO. 2 HARNESS		
		31A	WR	TO BODY NO. 2 HARNESS	84A	O	TO BODY NO. 2 HARNESS		
		32A	GR	TO BODY NO. 2 HARNESS	85A	SHIELD	TO BODY NO. 2 HARNESS		
		33A	-	TO BODY NO. 2 HARNESS	86A	W	TO BODY NO. 2 HARNESS		
		34A	SHIELD	TO BODY NO. 2 HARNESS	87A	B	TO BODY NO. 2 HARNESS		
		35A	P	TO BODY NO. 2 HARNESS	88A	W	TO BODY NO. 2 HARNESS		
		36A	B	TO BODY NO. 2 HARNESS	89A	SHIELD	TO BODY NO. 2 HARNESS		
		37A	-	TO BODY NO. 2 HARNESS	90A	G	TO BODY NO. 2 HARNESS		
		38A	RB	TO BODY NO. 2 HARNESS	91A	W/L	TO BODY NO. 2 HARNESS		
		39A	GO	TO BODY NO. 2 HARNESS	92A	BR	TO BODY NO. 2 HARNESS		
		40A	V	TO BODY NO. 2 HARNESS	93A	L/Y	TO BODY NO. 2 HARNESS		
		41A	SHIELD	TO BODY NO. 2 HARNESS	94A	R/L	TO BODY NO. 2 HARNESS		
		42A	SHIELD	TO BODY NO. 2 HARNESS	95A	BR	TO BODY NO. 2 HARNESS		
		43A	R	TO BODY NO. 2 HARNESS	96A	R	TO BODY NO. 2 HARNESS		
		44A	G	TO BODY NO. 2 HARNESS	97A	LG	TO BODY NO. 2 HARNESS		
		91A	92A	93A	94A	95A	96A	97A	98A
		98A	99A	99A	100A	100A	100A	100A	100A
		101A	102A	103A	104A	105A	106A	107A	108A
		108A	109A	109A	110A	110A	110A	110A	110A
		111A	112A	113A	114A	115A	116A	117A	118A
		118A	119A	119A	120A	120A	120A	120A	120A
		121A	122A	123A	124A	125A	126A	127A	128A
		128A	129A	129A	130A	130A	130A	130A	130A
		131A	132A	133A	134A	135A	136A	137A	138A
		138A	139A	139A	140A	141A	142A	143A	144A
		145A	146A	147A	148A	149A	150A	151A	152A
		152A	153A	154A	155A	156A	157A	158A	159A
		159A	160A	161A	162A	163A	164A	165A	166A
		166A	167A	168A	169A	170A	171A	172A	173A
		173A	174A	175A	176A	177A	178A	179A	180A
		180A	181A	182A	183A	184A	185A	186A	187A
		187A	188A	189A	190A	191A	192A	193A	194A
		194A	195A	196A	197A	198A	199A	200A	201A
		201A	202A	203A	204A	205A	206A	207A	208A
		208A	209A	210A	211A	212A	213A	214A	215A
		215A	216A	217A	218A	219A	220A	221A	222A
		222A	223A	224A	225A	226A	227A	228A	229A
		229A	230A	231A	232A	233A	234A	235A	236A
		236A	237A	238A	239A	240A	241A	242A	243A
		243A	244A	245A	246A	247A	248A	249A	250A
		250A	251A	252A	253A	254A	255A	256A	257A
		257A	258A	259A	260A	261A	262A	263A	264A
		264A	265A	266A	267A	268A	269A	270A	271A
		271A	272A	273A	274A	275A	276A	277A	278A
		278A	279A	280A	281A	282A	283A	284A	285A
		285A	286A	287A	288A	289A	290A	291A	292A
		292A	293A	294A	295A	296A	297A	298A	299A
		299A	300A	301A	302A	303A	304A	305A	306A
		306A	307A	308A	309A	310A	311A	312A	313A
		313A	314A	315A	316A	317A	318A	319A	320A
		320A	321A	322A	323A	324A	325A	326A	327A
		327A	328A	329A	330A	331A	332A	333A	334A
		334A	335A	336A	337A	338A	339A	340A	341A
		341A	342A	343A	344A	345A	346A	347A	348A
		348A	349A	350A	351A	352A	353A	354A	355A
		355A	356A	357A	358A	359A	360A	361A	362A
		362A	363A	364A	365A	366A	367A	368A	369A
		369A	370A	371A	372A	373A	374A	375A	376A
		376A	377A	378A	379A	380A	381A	382A	383A
		383A	384A	385A	386A	387A	388A	389A	390A
		390A	391A	392A	393A	394A	395A	396A	397A
		397A	398A	399A	400A	401A	402A	403A	404A
		404A	405A	406A	407A	408A	409A	410A	411A
		411A	412A	413A	414A	415A	416A	417A	418A
		418A	419A	420A	421A	422A	423A	424A	425A
		425A	426A	427A	428A	429A	430A	431A	432A
		432A	433A	434A	435A	436A	437A	438A	439A
		439A	440A	441A	442A	443A	444A	445A	446A
		446A	447A	448A	449A	450A	451A	452A	453A
		453A	454A	455A	456A	457A	458A	459A	460A
		460A	461A	462A	463A	464A	465A	466A	467A
		467A	468A	469A	470A	471A	472A	473A	474A
		474A	475A	476A	477A	478A	479A	480A	481A
		481A	482A	483A	484A	485A	486A	487A	488A
		488A	489A	490A	491A	492A	493A	494A	495A
		495A	496A	497A	498A	499A	500A	501A	502A
		502A	503A	504A	505A	506A	507A	508A	509A
		509A	510A	511A	512A	513A	514A	515A	516A
		516A	517A	518A	519A	520A	521A	522A	523A
		523A	524A	525A	526A	527A	528A	529A	530A
		530A	531A	532A	533A	534A	535A	536A	537A
		537A	538A	539A	540A	541A	542A	543A	544A
		544A	545A	546A	547A	548A	549A	550A	551A
		551A	552A	553A	554A	555A	556A	557A	558A
		558A	559A	560A	561A	562A	563A	564A	565A
		565A	566A	567A	568A	569A	570A	571A	572A
		572A	573A	574A	575A	576A	577A	578A	579A
		579A	580A	581A	582A	583A	584A	585A	586A
		586A	58						

Terminal No.	Color of Wire	Signal Name	47A	Y
1A	W	TO BODY NO. 2 HARNESS	48A	RY/W
2A	LG	TO BODY NO. 2 HARNESS	49A	R/LW
3A	V	TO BODY NO. 2 HARNESS	50A	B
4A	SB	TO BODY NO. 2 HARNESS	51A	-
5A	-	TO BODY NO. 2 HARNESS	52A	-
6A	BG	TO BODY NO. 2 HARNESS - (WITH CLIMATE CONTROLLED SEAT)	53A	-
6A	LG	TO BODY NO. 2 HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT)	54A	-
7A	W	TO BODY NO. 2 HARNESS	55A	-
8A	B	TO BODY NO. 2 HARNESS	60A	GW
9A	L/B	TO BODY NO. 2 HARNESS	61A	-
10A	W	TO BODY NO. 2 HARNESS	62A	-
11A	R	TO BODY NO. 2 HARNESS	63A	-
12A	BR	TO BODY NO. 2 HARNESS	64A	-
13A	G	TO BODY NO. 2 HARNESS	65A	-
14A	R/G	TO BODY NO. 2 HARNESS	66A	-
15A	O	TO BODY NO. 2 HARNESS	67A	-
16A	Q/L	TO BODY NO. 2 HARNESS	68A	-
17A	L	TO BODY NO. 2 HARNESS	69A	Y/R
18A	Y	TO BODY NO. 2 HARNESS	70A	R/G
19A	B/W	TO BODY NO. 2 HARNESS	71A	-
20A	R	TO BODY NO. 2 HARNESS	72A	W
21A	BG	TO BODY NO. 2 HARNESS	73A	G
			74A	W

AALIA5577GB

Revision: August 2016

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFOGGER CONNECTORS - WITH AUTOMATIC A/C

Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
M81	BCM (BODY CONTROL MODULE)	RG	1	Y	DOOR LOCK AS/FR/RL	5	-	-
		LG	2	W	DOOR UNLOCK AS/FR/RL	6	-	-
		W	3	BR	GND	7	W	AMB SEN5
		BR	4	BR	P/W POWER SUPPLY BAT	8	BR	STRG HEATER SW
		B	5	B	P/W POWER SUPPLY BAT	9	G	SUN SEN5
		O	6	B	BAT FRONT DOOR	10	-	-
		BR	7	BR	BAT REAR DOOR	11	-	-
		Y	8	W	BAT-POWER F/L	12	-	-
		Y	9	W	P/W POWER SUPPLY BAT	13	W	IGN2(ACC)
		BR	10	BR	BAT FRONT DOOR	14	Y	FAN GATE
		BR	11	BR	DOOR UNLOCK DBAS/FL	15	Y	RR DEF ON
		BR	12	W	BAT REAR DOOR	16	G	LIN SIG
		BR	13	W	BAT-POWER F/L	17	W	VACTR
		BR	14	W	P/W POWER SUPPLY BAT	18	-	-
		BR	15	W	BAT FRONT DOOR	19	G/R	PTC1 - (WITH CUMMINS 5.0L)
		BR	16	W	BAT REAR DOOR	20	P	STRG HEATER FLY
		BR	17	W	BAT-POWER F/L	21	P	CAN-L
		BR	18	W	P/W POWER SUPPLY BAT	22	B	P-QND
		BR	19	W	BAT FRONT DOOR	23	G	IGN
		BR	20	W	BAT REAR DOOR	24	V	RX (FR CONT)
		BR	21	W	BAT-POWER F/L	25	-	-
		BR	22	W	P/W POWER SUPPLY BAT	26	R	SENS GND
		BR	23	W	BAT FRONT DOOR	27	G	INCAR SENS
		BR	24	W	BAT REAR DOOR	28	P	INTAKE SENS
		BR	25	W	BAT-POWER F/L	29	-	-
		BR	26	W	P/W POWER SUPPLY BAT	30	-	-
		BR	27	W	BAT FRONT DOOR	31	-	-
		BR	28	W	BAT REAR DOOR	32	-	-
		BR	29	W	BAT-POWER F/L	33	Y	COMP ON

AALIA5578GB

REAR WINDOW DEFOGGER SYSTEM


< WIRING DIAGRAM >

WITH MANUAL A/C

WITH MANUAL A/C : Wiring Diagram

INFOID:0000000014389026

DEFROGGER - WITH MANUAL A/C



AALWA1740GB

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFOGGER CONNECTORS - WITH MANUAL A/C

Connector No.	D2	Color of Wire	GR	POWERFOLD FOLD+ (WITH MEMORY MIRRORS)
Connector Name	WIRE TO WIRE		B/W	HEATED MIRROR +
Connector Type	NS16FW-CS		W	VCC
Connector Color	WHITE		R	VIDEO +
			G/B	FRONT TURN LH
			B	GND
			L/G/B	EC FEED
			Y/W	EC RETURN
			Y	MEMORY/GND
			SB	MEMORY FEED
			V	HOR SENSOR
			BG	VER SENSOR
Terminal No.		Signal Name		
1	B/W	TO MAIN HARNESS	B	HEATED MIRROR -
2	G/B	TO MAIN HARNESS	GND	
3	L	TO MAIN HARNESS	B	SHIELD
4	R	TO MAIN HARNESS	21	BAU SAVER OUT
5	W/R	TO MAIN HARNESS	22	L
6	W/L	TO MAIN HARNESS	23	ROOM LAMP CONT
7	V	TO MAIN HARNESS	W	LED LH
8	B	TO MAIN HARNESS	GND	
9	L/W	TO MAIN HARNESS	B	
10	L/R	TO MAIN HARNESS		
11	L/W	TO MAIN HARNESS		
12	L	TO MAIN HARNESS		
13	Y	TO MAIN HARNESS		
14	SB	TO MAIN HARNESS		
15	V	TO MAIN HARNESS		
16	LG	TO MAIN HARNESS		




Connector No.	D107	Color of Wire	GR	POWERFOLD FOLD+ (WITH MEMORY MIRRORS)
Connector Name	DOOR MIRROR RH		B/R	SWITCH MTR UP
Connector Type	TH24MW-NH		2	SWITCH MTR LT
Connector Color	WHITE		3	MTR COMMON
			4	POWERFOLD UNFOLD+
			L/R	
			5	POWERFOLD FOLD+
			B/W	HEATED MIRROR +
			7	VCC
			8	VIDEO -
			9	FR TURN RH
			10	G/Y
			11	GND
			12	LG/B
			13	Y/N
			14	L
			15	Y
			16	BR
			17	-
			18	B
			19	W
			20	SHIELD
			21	R/G
			22	BAU SAVER OUT
			23	ROOM LAMP CONT
			24	R
				LED RH
				GND



Connector No.	D101	Color of Wire	GR	WIRE TO WIRE
Connector Name	NS10FW-CS		B	
Connector Type	WHITE		W	
Connector Color	WHITE		GND	
			10	4 3
			9	2 1
			8	10 9 8 7 6 5



Connector No.	D101	Color of Wire	GR	WIRE TO WIRE
Connector Name	NS10FW-CS		B	
Connector Type	WHITE		W	
Connector Color	WHITE		GND	
			10	4 3
			9	2 1
			8	10 9 8 7 6 5



Connector No.	D4	Color of Wire	GR	DOOR MIRROR LH
Connector Name	DOOR MIRROR LH		B/W	
Connector Type	TH24MW-NH		B	TO MAIN HARNESS
Connector Color	WHITE		W/L	TO MAIN HARNESS
			4	V
			5	W/B
			6	G/Y
			7	W/B
			8	U/B
			9	G/Y
			10	-



Connector No.	D4	Color of Wire	GR	DOOR MIRROR LH
Connector Name	DOOR MIRROR LH		B/W	
Connector Type	TH24MW-NH		B	TO MAIN HARNESS
Connector Color	WHITE		W/L	TO MAIN HARNESS
			4	V
			5	W/B
			6	G/Y
			7	W/B
			8	U/B
			9	G/Y
			10	-

AALIA5582GB

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFOGGER CONNECTORS - WITH MANUAL A/C

Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
FE152	WIRE TO WIRE	BR/W	24G	G/B	TO MAIN HARNESS	72G	L/W	TO MAIN HARNESS
			25G	R/W	TO MAIN HARNESS	73G	SHIELD	TO MAIN HARNESS
TH80MW-CS16-TM4			26G	R	TO MAIN HARNESS	74G	W	TO MAIN HARNESS
WHITE			27G	LG	TO MAIN HARNESS	75G	R	TO MAIN HARNESS
			28G	G/B	TO MAIN HARNESS	76G	R/G	TO MAIN HARNESS
			29G	G/B	TO MAIN HARNESS	77G	G	TO MAIN HARNESS
			30G	BR/Y	TO MAIN HARNESS	78G	W	TO MAIN HARNESS
			31G	P	TO MAIN HARNESS - (WITH CUMMINS 5.0L)	79G	-	TO MAIN HARNESS
				R	TO MAIN HARNESS - (WITH V650D)	80G	R	TO MAIN HARNESS
			32G	P	TO MAIN HARNESS	81G	L	TO MAIN HARNESS
			33G	YL	TO MAIN HARNESS	82G	R	TO MAIN HARNESS
			34G	GR	TO MAIN HARNESS	83G	L	TO MAIN HARNESS
			35G	GR	TO MAIN HARNESS	84G	L	TO MAIN HARNESS
			36G	SB	TO MAIN HARNESS	85G	WB	TO MAIN HARNESS
			37G	R/W	TO MAIN HARNESS	86G	BR	TO MAIN HARNESS
			38G	BR	TO MAIN HARNESS	87G	WB	TO MAIN HARNESS
			39G	BR	TO MAIN HARNESS	88G	P	TO MAIN HARNESS
			40G	-	TO MAIN HARNESS	89G	L	TO MAIN HARNESS
			41G	R/G	TO MAIN HARNESS	90G	G	TO MAIN HARNESS
			42G	O	TO MAIN HARNESS	91G	G	TO MAIN HARNESS
			43G	B	TO MAIN HARNESS - (WITH CUMMINS 5.0L)	92G	V/W	TO MAIN HARNESS
			43G	G	TO MAIN HARNESS - (WITH V650D)	93G	BR	TO MAIN HARNESS
			44G	R/Y	TO MAIN HARNESS	94G	G	TO MAIN HARNESS
			45G	G	TO MAIN HARNESS	95G	G	TO MAIN HARNESS
			46G	LG	TO MAIN HARNESS	96G	W	TO MAIN HARNESS
			47G	R	TO MAIN HARNESS	97G	BR	TO MAIN HARNESS
			48G	W	TO MAIN HARNESS	98G	GR/W	TO MAIN HARNESS
			49G	-	TO MAIN HARNESS	99G	Y	BATTERY
			50G	BR	TO MAIN HARNESS	100G	Y	BATTERY
			51G	R	TO MAIN HARNESS	101G	Y/G	BATTERY
			52G	L	TO MAIN HARNESS	102G	-	-
			53G	W	TO MAIN HARNESS	103G	-	-
			54G	W	TO MAIN HARNESS	104G	Y	BATTERY
			55G	BR	TO MAIN HARNESS	105G	Y/G	BATTERY
			56G	P	TO MAIN HARNESS - (WITH V650D)	106G	W	BLOWER FAN RELAY OUT
			66G	R/W	TO MAIN HARNESS - (WITH CUMMINS 5.0L)			
			7G	Y	TO MAIN HARNESS			
			86G	G	TO MAIN HARNESS			
			96G	R	TO MAIN HARNESS			
			106G	W	TO MAIN HARNESS			
			111G	RG	TO MAIN HARNESS			
			12G	WB	TO MAIN HARNESS			
			13G	BR	TO MAIN HARNESS			
			14G	Y/B	TO MAIN HARNESS			
			15G	GW	TO MAIN HARNESS			
			16G	G	TO MAIN HARNESS			
			17G	GY	TO MAIN HARNESS			
			18G	GR	TO MAIN HARNESS			
			19G	Y/V	TO MAIN HARNESS			
			20G	GY	TO MAIN HARNESS			
			21G	BY	TO MAIN HARNESS			
			22G	GR	TO MAIN HARNESS			
			23G	Y/R	TO MAIN HARNESS			
			71G	R/W	TO MAIN HARNESS			

AALIA5583GB

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFROGGER CONNECTORS - WITH MANUAL A/C

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS
Connector Color	WHITE

H.S.


Terminal No.	Color of Wire	Signal Name
1	B/W	TO FRONT DOOR LH HARNESS
2	G/B	TO FRONT DOOR LH HARNESS
3	L	TO FRONT DOOR LH HARNESS
4	R	TO FRONT DOOR LH HARNESS
5	W/R	TO FRONT DOOR LH HARNESS
6	W/L	TO FRONT DOOR LH HARNESS
7	V	TO FRONT DOOR LH HARNESS
8	B	TO FRONT DOOR LH HARNESS
9	L/W	TO FRONT DOOR LH HARNESS
10	L/R	TO FRONT DOOR LH HARNESS
11	L/W	TO FRONT DOOR LH HARNESS
12	L	TO FRONT DOOR LH HARNESS
13	Y	TO FRONT DOOR LH HARNESS
14	SB	TO FRONT DOOR LH HARNESS
15	V	TO FRONT DOOR LH HARNESS
16	L/G	TO FRONT DOOR LH HARNESS
17	P	GND RF A/U
18	V	SECURITY INDICATOR
19	-	-
20	R	SHIFT P
21	R/W	STEP LAMP CONT
22	-	-
23	Y	AIRCON SW
24	-	-
25	W	BRAKE SW FUSE
26	L	SHORT IN PIN INPUT
27	R/G	BRAKE SW LAMP
28	-	-
29	W	BLOWER FAN SW
30	P	DR DOOR LOCK STATUS
31	-	-
32	Y	REAR DEFOGGER SW
33	-	-
34	-	-
35	R/G	REVERSE SW
36	W/B	HAZARD SW
37	-	-
38	-	-
39	B/R	SHIFT N/P
40	-	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH

H.S.

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH
Connector Color	BLACK

H.S.



Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW NO ESCL
2	-	-
3	R	A/U POWER SUPPLY
4	W/R	A/U SIGNAL
5	-	-
6	-	-

AALIA5584GB

Terminal No.	Color of Wire	Signal Name
41	Y/L	TRAILER LIGHT CHECK RELAY OUT
42	R/Y	CARGO LAMP OUT
80	-	-

Terminal No.	Color of Wire	Signal Name
60	59	57
	58	56
	55	54
	52	51
	50	49
	47	46
	45	44
	42	41

DEF

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFOGGER CONNECTORS - WITH MANUAL A/C

Connector No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
M31	WIRE TO WIRE		27G	LG	TO ENGINE ROOM HARNESS
			28G	G/B	TO ENGINE ROOM HARNESS
			29G	G/B	TO ENGINE ROOM HARNESS
			30G	BRY	TO ENGINE ROOM HARNESS
			31G	R	TO ENGINE ROOM HARNESS
			32G	R	TO ENGINE ROOM HARNESS
			33G	Y/L	TO ENGINE ROOM HARNESS
			34G	GR	TO ENGINE ROOM HARNESS
			35G	G/R	TO ENGINE ROOM HARNESS
			36G	SB	TO ENGINE ROOM HARNESS
			37G	R/W	TO ENGINE ROOM HARNESS
			38G	BR	TO ENGINE ROOM HARNESS
			39G	BR	TO ENGINE ROOM HARNESS
			40G	-	TO ENGINE ROOM HARNESS
			41G	R/G	TO ENGINE ROOM HARNESS
			42G	O	TO ENGINE ROOM HARNESS
			43G	G	TO ENGINE ROOM HARNESS
			44G	R/Y	TO ENGINE ROOM HARNESS
			45G	G	TO ENGINE ROOM HARNESS
			46G	LG	TO ENGINE ROOM HARNESS
			47G	R	TO ENGINE ROOM HARNESS
			48G	W	TO ENGINE ROOM HARNESS
			49G	-	TO ENGINE ROOM HARNESS
			50G	BR	TO ENGINE ROOM HARNESS
			51G	R	TO ENGINE ROOM HARNESS
			52G	L	TO ENGINE ROOM HARNESS
			53G	W	TO ENGINE ROOM HARNESS
			54G	W	TO ENGINE ROOM HARNESS
			55G	G	TO ENGINE ROOM HARNESS
			56G	W	TO ENGINE ROOM HARNESS
			57G	Y	TO ENGINE ROOM HARNESS
			58G	BG	TO ENGINE ROOM HARNESS
			59G	BG	TO ENGINE ROOM HARNESS
			60G	BG	TO ENGINE ROOM HARNESS
			61G	O	TO ENGINE ROOM HARNESS
			62G	W	TO ENGINE ROOM HARNESS
			63G	O	TO ENGINE ROOM HARNESS
			64G	W/L	TO ENGINE ROOM HARNESS
			65G	W/R	TO ENGINE ROOM HARNESS
			66G	BG	TO ENGINE ROOM HARNESS
			67G	O	TO ENGINE ROOM HARNESS
			68G	B	TO ENGINE ROOM HARNESS
			69G	Y	TO ENGINE ROOM HARNESS
			70G	L	TO ENGINE ROOM HARNESS
			71G	R/W	TO ENGINE ROOM HARNESS
			72G	L/W	TO ENGINE ROOM HARNESS
			73G	SHIELD	TO ENGINE ROOM HARNESS
			74G	W	TO ENGINE ROOM HARNESS
			75G	R	TO ENGINE ROOM HARNESS
			76G	R/G	TO ENGINE ROOM HARNESS
			77G	BG	TO ENGINE ROOM HARNESS
			78G	P	TO ENGINE ROOM HARNESS
			79G	-	TO ENGINE ROOM HARNESS

AALIA5585GB

REAR WINDOW DEFOGGER SYSTEM

< WIRING DIAGRAM >

DEFROGGER CONNECTORS - WITH MANUAL A/C


Connector No.	M81	8	-	-
Connector Name	BCM (BODY CONTROL MODULE)	9	W	IGN(2ACC)
Connector Type	FFA09FW-FH46-SA	10	P	FAN GATE
Connector Color	WHITE	11	Y	RR DEF ON
		12	G	LIN SIG
		13	W	VACTR
		14	-	-
		15	-	-
		16	-	-
		17	P	CAN-L
		18	B	GND(POWER)
		19	G	IGN
		20	GR	ILL-
		21	R	SENS GND
		22	P	INTAKE SENS
		23	-	-
		24	-	-
		25	Y	COMP ON
		26	L/W	FAN FB
		27	B/W	RR DEF F/B
		28	-	-
		29	B	ACTR GND
		30	W	FAN ON
		31	-	-
		32	-	-

H.S.

Terminal No.	Color of Wire	Signal Name
29	RG	BATTERY SAVER OUT
30	LG	SUPER LOCK/DOOR UNLOCK AS
31	W	BAT BOM FUSE
32	Y	DOOR LOCK AS/FR/RL
33	BR	DOOR UNLOCK AS/FR/RL
34	B	GND2
35	O	DOOR LOCK DR/AS/FL
36	L	ROOM LAMP CONT
37	V	DOOR UNLOCK DB/AS/FL
38	V	BAT REAR DOOR
39	W	BAT-POWER F/L
40	LG	P/W POWER SUPPLY GND
41	V	P/W POWER SUPPLY BAT
42	Y	BAT FRONT DOOR
43	B	GND1

Connector No.	M132
Connector Name	FRONT AIR CONTROL
Connector Type	TH32FW-NH
Connector Color	WHITE

H.S.



Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
2	B	GND
3	SB	BAT
4	L	ILL+
5	-	-
6	-	-
7	-	-

AALIA5586GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000014389027

OVERALL SEQUENCE



DETAILED FLOW

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

1. GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is displayed.
 - Record DTC and freeze frame data. (Print them out with CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Is any symptom described and any DTC detected?

Symptom is described, DTC is displayed>>GO TO 3.

Symptom is described, DTC is not displayed>>GO TO 4.

Symptom is not described, DTC is displayed>>GO TO 5.

3. CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT to the vehicle in "Data Monitor" mode and check real-time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.

Connect CONSULT to the vehicle in "Data Monitor" mode and check real-time diagnosis results.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC, and then check that DTC is detected again.

At this time, always connect CONSULT to the vehicle, and check diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-51, "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC Confirmation Procedure is not included in Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC Confirmation Procedure.

Is DTC detected?

YES >> GO TO 7.

NO >> Refer to [GI-47, "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to [DEF-7, "System Description"](#) based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

>> GO TO 7.

7. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

NOTE:

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

The Diagnostic Procedure described is based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check voltage of related BCM terminals using CONSULT.

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.

2. Reconnect parts or connectors disconnected during Diagnostic Procedure after repair and replacement.

3. Check DTC. If DTC is displayed, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC was detected in step 2, perform DTC Confirmation Procedure or Component Function Check again, and then check that the malfunction has been repaired.

When symptom was described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Does the symptom reappear?

YES (DTC is detected)>>GO TO 7.

YES (Symptom remains)>>GO TO 6.

NO >> Inspection End.

REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

REAR WINDOW DEFOGGER SWITCH WITH AUTO A/C

WITH AUTO A/C : Component Function Check

INFOID:0000000014389028

1. CHECK REAR WINDOW DEFOGGER SWITCH FUNCTION

1. Push ignition switch to ON.
2. Press rear window defogger switch.
3. Check that the indicator lamp of the rear window defogger switch illuminates.
4. Press rear window defogger switch.
5. Check that the indicator lamp of the rear window defogger switch extinguishes.

Is the inspection result normal?

YES >> Rear window defogger switch function is OK.

NO >> Refer to [DEF-33, "WITH AUTO A/C : Diagnosis Procedure"](#).

WITH AUTO A/C : Diagnosis Procedure

INFOID:0000000014389029

Regarding Wiring Diagram information, refer to [DEF-15, "WITH AUTO A/C : Wiring Diagram"](#).

1. CHECK REAR WINDOW DEFOGGER RELAY OPERATION

1. Push the ignition switch to ON.
2. Check that an operation noise of rear window defogger relay [located in fuse block (J/B)] can be heard when pressing the rear window defogger switch ON and OFF.

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 5.

2. CHECK FUSE

Check if the following fuse in fuse block (J/B) is blown.

Component	Capacity	Fuse No.
Fuse block (J/B)	10A	22

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the blown fuse after repairing the affected circuit.

3. CHECK FOR VOLTAGE FROM THE REAR WINDOW DEFOGGER RELAY

1. Connect a voltmeter between fuse block (J/B) and ground.
2. While pressing the rear window defogger switch ON and OFF, check for voltage between fuse block (J/B) and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)						
Fuse block (J/B)	Connector	Terminal	M4	5P	Ground	Rear window defogger switch	ON	Battery voltage	OFF	0

Is the inspection result normal?

YES >> GO TO 4.

NO >> Perform rear window defogger relay diagnosis. Refer to [DEF-42, "WITH MANUAL A/C : Diagnosis Procedure"](#).

REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

4. CHECK REAR WINDOW DEFOGGER SWITCH INDICATOR CIRCUIT

1. Press rear window defogger switch.
2. Check for voltage between A/C auto amp. connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
A/C auto amp.				Connector	Terminal
M137	35	Ground	Rear window defogger switch	ON	Battery voltage
				OFF	0

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-122, "Removal and Installation"](#).

NO >> Repair or replace harness.

5. CHECK A/C AUTO AMP. (REAR WINDOW DEFOGGER SWITCH) FUNCTION

CONSULT

1. Select "REAR DEFOGGER" of "BCM".
2. Select "REAR DEF SW" in "Data Monitor" mode.
3. Check that the function operates normally according to the following conditions:

Monitor Item	Condition		status
REAR DEF SW	Rear window defogger switch	Pressed	On
		Released	Off

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 6.

6. CHECK REAR WINDOW DEFOGGER ON SIGNAL CIRCUIT

Check voltage between BCM connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
BCM				Connector	Terminal
M18	32	Ground	Rear window defogger switch	ON	0
				OFF	5

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> GO TO 7.

7. CHECK HARNESS CONTINUITY

1. Push ignition switch to OFF.
2. Disconnect BCM and front air control.
3. Check continuity between BCM connector and A/C auto amp.

BCM		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M18	32	M137	15	Yes

4. Check continuity between BCM harness connector and ground.

REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M18	32		No

Is the inspection result normal?

YES >> Replace A/C auto amp. Refer to [HAC-122, "Removal and Installation"](#).
 NO >> Repair or replace harness.

8. CHECK REAR WINDOW DEFOGGER RELAY GROUND CIRCUIT

CONSULT

1. Select "REAR DEFOGGER" of "BCM".
2. Select "REAR DEFOGGER" in "Active Test" mode.
3. Touch "On".
4. Check voltage between fuse block (J/B) connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Fuse block (J/B)				Connector	Terminal
M4	6P	Ground	Rear window defogger active test	ON	0
				OFF	Battery voltage

Is the inspection result normal?

YES >> GO TO 11.
 NO >> GO TO 9.

9. CHECK REAR WINDOW DEFOGGER RELAY CIRCUIT

Check voltage between fuse block (J/B) connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Fuse block (J/B)				Connector	Terminal
M4	6P	Ground	Rear window defogger switch	ON	0
				OFF	Battery voltage

Is the inspection result normal?

YES >> Replace rear window defogger relay.
 NO >> GO TO 10.

10. CHECK HARNESS CONTINUITY

1. Push ignition switch to OFF.
2. Disconnect BCM and fuse block (J/B).
3. Check continuity between BCM connector and fuse block (J/B) connector.

BCM		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M19	61	M4	6P	Yes

4. Check continuity between fuse block (J/B) connector and ground.

Fuse block (J/B)		Ground	Continuity
Connector	Terminal		
M4	6P		No

Is the inspection result normal?

REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

YES >> Perform rear window defogger relay component inspection. Refer to [DEF-42, "WITH MANUAL A/C : Component Inspection"](#). If OK, replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
NO >> Repair or replace harness.

11. CHECK REAR WINDOW DEFOGGER RELAY-2

Check rear window defogger relay-2.

Refer to [DEF-42, "WITH MANUAL A/C : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 12.
NO >> Replace rear window defogger relay-2.

12. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-47, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Check the following.

- Battery power supply circuit.
- Fuse block (J/B).

NO >> Repair or replace the malfunctioning parts.

WITH MANUAL A/C

WITH MANUAL A/C : Component Function Check

INFOID:0000000014389030

1. CHECK REAR WINDOW DEFOGGER SWITCH FUNCTION

1. Push ignition switch to ON.
2. Press rear window defogger switch.
3. Check that the indicator lamp of the rear window defogger switch illuminates.
4. Press rear window defogger switch.
5. Check that the indicator lamp of the rear window defogger switch extinguishes.

Is the inspection result normal?

YES >> Rear window defogger switch function is OK.
NO >> Refer to [DEF-36, "WITH MANUAL A/C : Diagnosis Procedure"](#).

WITH MANUAL A/C : Diagnosis Procedure

INFOID:0000000014389031

Regarding Wiring Diagram information, refer to [DEF-24, "WITH MANUAL A/C : Wiring Diagram"](#).

1. CHECK REAR WINDOW DEFOGGER RELAY OPERATION

1. Push the ignition switch to ON.
2. Check that an operation noise of rear window defogger relay [located in fuse block (J/B)] can be heard when pressing the rear window defogger switch ON and OFF.

Is the inspection result normal?

YES >> GO TO 2.
NO >> GO TO 5.

2. CHECK FUSE

Check if the following fuse in fuse block (J/B) is blown.

Component	Capacity	Fuse No.
Fuse block (J/B)	10A	22

Is the inspection result normal?

YES >> Replace the blown fuse after repairing the affected circuit.
NO >> GO TO 3.

REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK FOR VOLTAGE FROM THE REAR WINDOW DEFOGGER RELAY

1. Connect a voltmeter between fuse block (J/B) and ground.
2. While pressing the rear window defogger switch ON and OFF, check for voltage between fuse block (J/B) and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Fuse block (J/B)	Connector			ON	Battery voltage
M4	5P	Ground	Rear window defogger switch	OFF	0

Is the inspection result normal?

YES >> GO TO 4.

NO >> Perform rear window defogger relay diagnosis. Refer to [DEF-42, "WITH MANUAL A/C : Diagnosis Procedure".](#)

4. CHECK REAR WINDOW DEFOGGER SWITCH INDICATOR CIRCUIT

1. Press rear window defogger switch.
2. Check for voltage between front air control connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Front air control	Connector			ON	Battery voltage
M132	27	Ground	Rear window defogger switch	OFF	0

Is the inspection result normal?

YES >> Replace front air control. Refer to [HAC-230, "Removal and Installation".](#)

NO >> Repair or replace harness.

5. CHECK FRONT AIR CONTROL (REAR WINDOW DEFOGGER SWITCH) FUNCTION

CONSULT

1. Select "REAR DEFOGGER" of "BCM".
2. Select "REAR DEF SW" in "Data Monitor" mode.
3. Check that the function operates normally according to the following conditions:

Monitor Item	Condition		status
REAR DEF SW	Rear window defogger switch	Pressed	On
		Released	Off

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 6.

6. CHECK REAR WINDOW DEFOGGER ON SIGNAL CIRCUIT

Check voltage between BCM connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
BCM	Connector			ON	0
M18	32	Ground	Rear window defogger switch	OFF	5

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation".](#)

REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 7.

7. CHECK HARNESS CONTINUITY

1. Push ignition switch to OFF.
2. Disconnect BCM and front air control.
3. Check continuity between BCM connector and front air control connector.

BCM		Front air control		Continuity
Connector	Terminal	Connector	Terminal	
M18	32	M132	11	Yes

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M18	32		

Is the inspection result normal?

YES >> Replace front air control. Refer to [HAC-230, "Removal and Installation"](#).

NO >> Repair or replace harness.

8. CHECK REAR WINDOW DEFOGGER RELAY GROUND CIRCUIT

CONSULT

1. Select "REAR DEFOGGER" of "BCM".
2. Select "REAR DEFOGGER" in "Active Test" mode.
3. Touch "On".
4. Check voltage between fuse block (J/B) connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Fuse block (J/B)				ON	OFF
Connector	Terminal	Ground	Rear window defogger active test	0	Battery voltage

Is the inspection result normal?

YES >> GO TO 11.

NO >> GO TO 9.

9. CHECK REAR WINDOW DEFOGGER RELAY CIRCUIT

Check voltage between fuse block (J/B) connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
Fuse block (J/B)				ON	OFF
Connector	Terminal	Ground	Rear window defogger switch	0	Battery voltage

Is the inspection result normal?

YES >> Replace rear window defogger relay.

NO >> GO TO 10.

10. CHECK HARNESS CONTINUITY

1. Push ignition switch to OFF.
2. Disconnect BCM and fuse block (J/B).
3. Check continuity between BCM connector and fuse block (J/B) connector.

REAR WINDOW DEFOGGER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BCM		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M19	61	M4	6P	Yes

4. Check continuity between fuse block (J/B) connector and ground.

Fuse block (J/B)		Ground	Continuity
Connector	Terminal		
M4	6P		No

Is the inspection result normal?

YES >> Perform rear window defogger relay component inspection. Refer to [DEF-42, "WITH MANUAL A/C : Component Inspection"](#). If OK, replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness.

11. CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.

Refer to [DEF-42, "WITH MANUAL A/C : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 12.

NO >> Replace rear window defogger relay.

12. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-47, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Check the following.

- Battery power supply circuit.
- Fuse block (J/B).

NO >> Repair or replace the malfunctioning parts.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

REAR WINDOW DEFOGGER RELAY

< DTC/CIRCUIT DIAGNOSIS >

REAR WINDOW DEFOGGER RELAY WITH AUTO A/C

WITH AUTO A/C : Component Function Check

INFOID:000000014389032

REAR WINDOW DEFOGGER RELAY-1

1. CHECK REAR WINDOW DEFOGGER RELAY-1

With CONSULT

1. Select "REAR DEFOGGER" in "Active Test" mode of "IPDM E/R".
2. Touch "On".
3. Check that the rear window heating wire LH is getting warmer.

Is the inspection result normal?

YES >> Rear window defogger relay function is OK.

NO >> Refer to [DEF-40, "WITH AUTO A/C : Diagnosis Procedure"](#).

REAR WINDOW DEFOGGER RELAY-2

1. CHECK REAR WINDOW DEFOGGER RELAY-2

Check that an operation noise of rear window defogger relay [located in fuse block (J/B)] can be heard when turning the rear window defogger switch ON.

Is the inspection result normal?

YES >> Rear window defogger relay power supply circuit is OK.

NO >> Refer to [DEF-40, "WITH AUTO A/C : Diagnosis Procedure"](#).

WITH AUTO A/C : Diagnosis Procedure

INFOID:000000014389033

Regarding Wiring Diagram information, refer to [DEF-15, "WITH AUTO A/C : Wiring Diagram"](#).

REAR WINDOW DEFOGGER RELAY-1

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown.

Component	Capacity	Fuse No.
IPDM E/R	20A	53

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit.

2. CHECK IPDM E/R OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between IPDM E/R harness connector and ground.

(+) IPDM E/R		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal				
E124	57	Ground	Rear window defogger switch	ON	Battery voltage
				OFF	0

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

REAR WINDOW DEFOGGER RELAY-2

REAR WINDOW DEFOGGER RELAY

< DTC/CIRCUIT DIAGNOSIS >

1. CHECK REAR WINDOW DEFOGGER RELAY-2 GROUND CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between BCM connector and ground.

BCM		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal			ON	OFF
M19	61	Ground	Rear window defogger switch	0	

Is the inspection result normal?

YES >> Rear window defogger power supply circuit is OK.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and fuse block (J/B).
3. Check continuity between BCM connector and fuse block (J/B) connector.

BCM		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M19	61	M4	6P	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK REAR WINDOW DEFOGGER RELAY-2

Check rear window defogger relay-2.

Refer to [DEF-41, "WITH AUTO A/C : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#)

NO >> Replace rear window defogger relay-2.

WITH AUTO A/C : Component Inspection

INFOID:0000000014389034

DEF

1. CHECK REAR WINDOW DEFOGGER RELAY-2

Check rear window defogger relay-2.

Terminal	Condition		Continuity
Rear window defogger relay			
3	12V direct current supply between terminals 1 and 2.	Yes	
5	No current supply	No	

Is the inspection result normal?

YES >> Inspection End.


NO >> Replace rear window defogger relay-2.

WITH MANUAL A/C

WITH MANUAL A/C : Component Function Check

INFOID:0000000014389035

1. CHECK REAR WINDOW DEFOGGER RELAY-2 POWER SUPPLY CIRCUIT



REAR WINDOW DEFOGGER RELAY

< DTC/CIRCUIT DIAGNOSIS >

Check that an operation noise of rear window defogger relay-2 [located in fuse block (J/B)] can be heard when turning the rear window defogger switch ON.

Is the inspection result normal?

YES >> Rear window defogger relay-2 power supply circuit is OK.
NO >> Refer to [DEF-42, "WITH MANUAL A/C : Diagnosis Procedure"](#).

WITH MANUAL A/C : Diagnosis Procedure

INFOID:0000000014389036

Regarding Wiring Diagram information, refer to [DEF-24, "WITH MANUAL A/C : Wiring Diagram"](#).

1. CHECK REAR WINDOW DEFOGGER RELAY-2 GROUND CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between BCM connector and ground.

(+)		BCM	(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal				
M19	61	Ground	Rear window defogger switch	ON	0
				OFF	Battery voltage

Is the inspection result normal?

YES >> Rear window defogger power supply circuit is OK.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and fuse block (J/B).
3. Check continuity between BCM connector and fuse block (J/B) connector.

BCM		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M19	61	M4	6P	Yes

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace harness.

3. CHECK REAR WINDOW DEFOGGER RELAY-2

Check rear window defogger relay-2.

Refer to [DEF-42, "WITH MANUAL A/C : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#)
NO >> Replace rear window defogger relay-2.

WITH MANUAL A/C : Component Inspection

INFOID:0000000014389037

1. CHECK REAR WINDOW DEFOGGER RELAY-2

REAR WINDOW DEFOGGER RELAY

< DTC/CIRCUIT DIAGNOSIS >


Check rear window defogger relay-2.

Terminal		Condition	Continuity
	Rear window defogger relay		
3	5	12V direct current supply between terminals 1 and 2.	Yes
		No current supply	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace rear window defogger relay-2.



A
B
C
D
E
F
G
H
I
J
K

DEF

M
N
O
P

REAR WINDOW DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

REAR WINDOW DEFOGGER

Component Function Check

INFOID:0000000014389038

1. CHECK REAR WINDOW DEFOGGER

Check that the heating wire of rear window defogger is heated when turning the rear window defogger switch ON.

Is the inspection result normal?

YES >> Rear window defogger is OK.
NO >> Refer to [DEF-44, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000014389039

Regarding Wiring Diagram information, refer to [DEF-15, "WITH AUTO A/C : Wiring Diagram"](#).

1. CHECK FUSES

Check if any of the following fuses are blown.

Component	Capacity	Fuse No.
Fuse block (J/B)	15A	23
IPDM E/R	20A	53

Is the inspection result normal?

YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear window defogger connector and ground.

(+)	(-)	Condition	Voltage (V) (Approx.)	
Rear window defogger				
Connector	Terminal	Rear window defogger switch	ON	Battery voltage
B78 (LH)	1			
B115 (RH)	Ground	OFF	0	

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear window defogger connector.
3. Check continuity between rear window defogger connector and ground.

Rear window defogger	Terminal	Ground	Continuity
Connector			
B78 (LH)	2		Yes
B115 (RH)			

Is the inspection result normal?

YES >> GO TO 4.

REAR WINDOW DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

4. CHECK FILAMENT

Check filament.

Refer to [DEF-58, "Filament Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair filament. Refer to [DEF-58, "Filament Repair"](#).

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

DOOR MIRROR DEFOGGER

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR DEFOGGER

Component Function Check

INFOID:0000000014389041

1. CHECK DOOR MIRROR DEFOGGER

1. Select "REAR DEFOGGER" of "BCM"
2. Select "REAR DEFOGGER" in "Active Test" mode
3. Touch "ON".
4. Check that both side door mirror glasses are getting warmer.

Is the inspection result normal?

YES >> Door mirror defogger function is OK.
NO >> Refer to [DEF-46, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000014389042

Regarding Wiring Diagram information, refer to [DEF-15, "WITH AUTO A/C : Wiring Diagram"](#) (with auto A/C) or [DEF-24, "WITH MANUAL A/C : Wiring Diagram"](#) (with manual A/C).

1. CHECK DOOR MIRROR DEFOGGER FUSE

Check if the following fuse in fuse block (J/B) is blown.

Component	Capacity	Fuse No.
Fuse block (J/B)	10A	22

Is the inspection result normal?

YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit.

2. CHECK DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between fuse block (J/B) harness connector and ground.

(+)	(-)	Condition	Voltage (V) (Approx.)
Fuse block (J/B)			
Connector	Terminal	Rear window defogger switch	ON
M4	4P	Ground	Battery voltage
			0

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
NO >> Replace fuse block (J/B).

DOOR MIRROR DEFOGGER LH

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR DEFOGGER LH

Component Function Check

INFOID:0000000014389043

1. CHECK DOOR MIRROR DEFOGGER LH

Check that heating wire of door mirror defogger LH is heated when turning the rear window defogger switch ON.

Is the inspection result normal?

YES >> Door mirror defogger is OK.

NO >> Refer to [DEF-47, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000014389044

Regarding Wiring Diagram information, refer to [DEF-15, "WITH AUTO A/C : Wiring Diagram"](#) (with auto A/C) or [DEF-24, "WITH MANUAL A/C : Wiring Diagram"](#) (with manual A/C).

1. CHECK DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror LH.
3. Turn ignition switch ON.
4. Check voltage between door mirror LH connector and ground.

(+) Door mirror LH		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal			ON	OFF
D4	6	Ground	Rear window defogger switch	Battery voltage	0

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

2. CHECK DOOR MIRROR DEFOGGER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror LH connector and ground.

Door mirror LH		Ground	Continuity
Connector	Terminal		Yes
D4	18		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK DOOR MIRROR DEFOGGER LH

Check door mirror defogger LH.

Refer to [DEF-47, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace door mirror LH. Refer to [MIR-31, "Removal and Installation"](#).

Component Inspection

INFOID:0000000014389045

1. CHECK DOOR MIRROR DEFOGGER LH

DOOR MIRROR DEFOGGER LH

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect door mirror LH.
3. Check continuity between door mirror terminals.

Terminal		Continuity
6	18	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace door mirror LH. Refer to [MIR-31, "Removal and Installation"](#).

DOOR MIRROR DEFOGGER RH

< DTC/CIRCUIT DIAGNOSIS >

DOOR MIRROR DEFOGGER RH

Component Function Check

INFOID:0000000014389046

1. CHECK DOOR MIRROR DEFOGGER RH

Check that the heating wire of door mirror defogger RH is heated when turning the rear window defogger switch ON.

Is the inspection result normal?

YES >> Door mirror defogger RH is OK.
NO >> Refer to [DEF-49, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000014389047

Regarding Wiring Diagram information, refer to [DEF-15, "WITH AUTO A/C : Wiring Diagram"](#) (with auto A/C) or [DEF-24, "WITH MANUAL A/C : Wiring Diagram"](#) (with manual A/C).

1. CHECK DOOR MIRROR DEFOGGER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door mirror RH.
3. Turn ignition switch ON.
4. Check voltage between door mirror RH connector and ground.

(+) Door mirror RH		(-)	Condition	Voltage (V) (Approx.)	
Connector	Terminal			ON	OFF
D107	6	Ground	Rear window defogger switch	Battery voltage	0

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace harness.

2. CHECK DOOR MIRROR DEFOGGER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between door mirror RH connector and ground.

Door mirror RH		Ground	Continuity
Connector	Terminal		
D107	18		Yes

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace harness.

3. CHECK DOOR MIRROR DEFOGGER RH

Check door mirror defogger RH.

Refer to [DEF-49, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
NO >> Replace door mirror RH. Refer to [MIR-31, "Removal and Installation"](#).

Component Inspection

INFOID:0000000014389048

1. CHECK DOOR MIRROR DEFOGGER RH

DOOR MIRROR DEFOGGER RH

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect door mirror RH.
3. Check continuity between door mirror terminals.

Terminal		Continuity
6	18	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace door mirror RH. Refer to [MIR-31, "Removal and Installation"](#).

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

REAR WINDOW DEFOGGER SYSTEM SYMPTOMS

Symptom Table

INFOID:000000014389049

Symptom	Reference page
Rear window defogger does not operate (without heated mirrors).	DEF-52, "Diagnosis Procedure"
Rear window defogger and door mirror defoggers do not operate.	DEF-53, "Diagnosis Procedure"
Rear window defogger does not operate but both door mirror defoggers operate.	DEF-54, "Diagnosis Procedure"
Door mirror defogger does not operate (without rear window defogger).	DEF-55, "Diagnosis Procedure"
Door mirror defogger does not operate but rear window defogger operates.	DEF-56, "Diagnosis Procedure"
Rear window defogger switch does not light, but rear window defogger operates.	DEF-57, "Diagnosis Procedure"

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

REAR WINDOW DEFOGGER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER DOES NOT OPERATE

Diagnosis Procedure

INFOID:0000000014389050

1. CHECK REAR WINDOW DEFOGGER SWITCH

Check rear window defogger switch. Refer to [DEF-33, "WITH AUTO A/C : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.

Refer to [DEF-40, "WITH AUTO A/C : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK REAR WINDOW DEFOGGER

Check rear window defogger.

Refer to [DEF-44, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-47, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Check the following.

- Battery power supply circuit
- Fuse block (J/B)
- IPDM E/R

NO >> Repair or replace the malfunctioning parts.

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGERS DO NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGERS DO NOT OPERATE

Diagnosis Procedure

INFOID:000000014389051

1. CHECK REAR WINDOW DEFOGGER SWITCH

Check rear window defogger switch. Refer to [DEF-33, "WITH AUTO A/C : Component Function Check"](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR WINDOW DEFOGGER RELAY

Check rear window defogger relay.

Refer to [DEF-40, "WITH AUTO A/C : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK REAR WINDOW DEFOGGER

Check rear window defogger.

Refer to [DEF-44, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK INTERMITTENT INCIDENT

Check intermittent incident.

Refer to [GI-47, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Check the following.

- Battery power supply circuit
- Fuse block (J/B)
- IPDM E/R

NO >> Repair or replace the malfunctioning parts.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE

Diagnosis Procedure

INFOID:0000000014389052

1. CHECK REAR WINDOW DEFOGGER

Check rear window defogger. Refer to [DEF-44, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
NO >> Repair or replace the malfunctioning parts.

DOOR MIRROR DEFOGGER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DOOR MIRROR DEFOGGER DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000014389053

BOTH SIDES

1. CHECK DOOR MIRROR DEFOGGER

Check door mirror defogger.

Refer to [DEF-46, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

DRIVER SIDE

1. CHECK DOOR MIRROR DEFOGGER LH

Check door mirror defogger LH.

Refer to [DEF-47, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

PASSENGER SIDE

1. CHECK DOOR MIRROR DEFOGGER RH

Check door mirror defogger RH.

Refer to [DEF-49, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A

B

C

D

E

F

G

H

I

J

K

DEF

M

N

O

P

DOOR MIRROR DEFOGGER DOES NOT OPERATE BUT REAR WINDOW DEFOGGER OPERATES

< SYMPTOM DIAGNOSIS >

DOOR MIRROR DEFOGGER DOES NOT OPERATE BUT REAR WINDOW DEFOGGER OPERATES

Diagnosis Procedure

INFOID:0000000014389054

BOTH SIDES

1. CHECK DOOR MIRROR DEFOGGER

Check door mirror defogger.

Refer to [DEF-46, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

DRIVER SIDE

1. CHECK DOOR MIRROR DEFOGGER LH

Check door mirror defogger LH.

Refer to [DEF-47, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

PASSENGER SIDE

1. CHECK DOOR MIRROR DEFOGGER RH

Check door mirror defogger RH.

Refer to [DEF-49, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

REAR WINDOW DEFOGGER SWITCH DOES NOT LIGHT, BUT REAR WINDOW DEFOGGER OPERATES

< SYMPTOM DIAGNOSIS >

REAR WINDOW DEFOGGER SWITCH DOES NOT LIGHT, BUT REAR WINDOW DEFOGGER OPERATES

A

Diagnosis Procedure

INFOID:000000014389055

1. CHECK REAR WINDOW DEFOGGER SWITCH

B

Check that the rear window defogger switch is operating normally.

C

Is the inspection result normal?

D

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

E

NO >> Refer to [DEF-33, "WITH AUTO A/C : Diagnosis Procedure"](#) (with auto A/C) or [DEF-36, "WITH MANUAL A/C : Diagnosis Procedure"](#) (with manual A/C).

F

G

H

I

J

K

L

M

N

O

P

DEF

REAR WINDOW DEFOGGER

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

REAR WINDOW DEFOGGER

Filament Check


INFOID:000000014389056

1. When measuring voltage at the heat wire (1), wrap tin foil (3) around the top of the negative probe (2). Then press the foil against the wire with your finger (4).




AWLIA2730ZZ

2. Attach probe circuit tester (in Volt range) to middle portion of each filament.
 - 6 volts (normal filament).



AWLIA2731ZZ

3. If a filament is burned out (1), circuit tester registers zero (3) or battery voltage (2).
4. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



AWLIA2732ZZ

Filament Repair

INFOID:000000014389057

REPAIR EQUIPMENT

- Conductive silver composition (DuPont No. 4817 or equivalent)
- Ruler 30 cm (11.8 in) long

REAR WINDOW DEFOGGER

< REMOVAL AND INSTALLATION >

- Drawing pen
- Heat gun
- Alcohol
- Cloth


REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

NOTE:

Shake silver composition container before use.


3. Place ruler (1) on glass along broken line (2). Deposit conductive silver composition on break with drawing pen (3). Slightly overlap existing heat wire (4) on both sides [preferably 5 mm (0.20 in)] of the break.



4. After repair has been completed, check repaired wire (1) for continuity. This check should be conducted 10 minutes after silver composition is deposited.

CAUTION:

Do not touch repaired area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area (1) for approximately 20 minutes with a heat gun (2). A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet.

NOTE:

If a heat gun is not available, let the repaired area dry for 24 hours.

