

# EXT

## SECTION

# EXTERIOR

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXT

## CONTENTS

<b>PRECAUTION</b>	3	<b>SQUEAK AND RATTLE TROUBLE DIAG- NOSES</b>	18
<b>PRECAUTIONS</b>	3	Work Flow	18
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	3	Generic Squeak and Rattle Troubleshooting	19
Procedure without Cowl Top Cover	3	Diagnostic Worksheet	22
Precaution for Work	3		
<b>PREPARATION</b>	5	<b>REMOVAL AND INSTALLATION</b>	24
<b>PREPARATION</b>	5	<b>FRONT BUMPER</b>	24
Special Service Tool	5	Exploded View	24
Commercial Service Tool	5	Removal and Installation - Front Bumper	25
<b>CLIP LIST</b>	6	Removal and Installation - Bumper Fascia Upper	26
Descriptions for Clips	6	Adjustment	27
<b>SYSTEM DESCRIPTION</b>	10	<b>REAR BUMPER</b>	28
<b>COMPONENT PARTS</b>	10	Exploded View	28
<b>ACTIVE GRILLE SHUTTER SYSTEM</b>	10	Removal and Installation	29
ACTIVE GRILLE SHUTTER SYSTEM :		Adjustment	30
Component Parts Location	10		
ACTIVE GRILLE SHUTTER SYSTEM : Active			
grille shutter	11		
<b>SYSTEM</b>	12	<b>FRONT GRILLE</b>	32
<b>ACTIVE GRILLE SHUTTER SYSTEM</b>	12	Exploded View	32
ACTIVE GRILLE SHUTTER SYSTEM : System		Removal and Installation	32
Diagram	12		
ACTIVE GRILLE SHUTTER SYSTEM : System			
Description	12		
<b>WIRING DIAGRAM</b>	14	<b>ACTIVE GRILLE SHUTTER</b>	34
<b>ACTIVE GRILLE SHUTTER</b>	14	Exploded View	34
Wiring Diagram	14	Removal and Installation	34
<b>SYMPTOM DIAGNOSIS</b>	18		
		<b>COWL TOP</b>	35
		Exploded View	35
		Removal and Installation - Cowl Top Side Trim	
		Cover	35
		Removal and Installation - Cowl Top Cover	35
		Removal and Installation - Cowl Top Extension	36
		<b>UNDER COVER</b>	37
		<b>FRONT UNDER COVER</b>	37
		FRONT UNDER COVER : Exploded View	37
		FRONT UNDER COVER : Removal and Installa- tion	37
		<b>REAR UNDER COVER</b>	37
		REAR UNDER COVER : Exploded View	38

REAR UNDER COVER : Removal and Installation	38	SIDE STEP .....	47
		Exploded View .....	47
ENGINE UNDER COVER .....	38	Removal and Installation .....	47
ENGINE UNDER COVER : Exploded View .....	39	DOOR OUTSIDE MOLDING .....	48
ENGINE UNDER COVER : Removal and Installation .....	39	Exploded View .....	48
		Removal and Installation .....	48
FLOOR UNDER COVER .....	39	ROOF SIDE MOLDING .....	50
FLOOR UNDER COVER : Exploded View .....	40	Exploded View .....	50
FLOOR UNDER COVER : Removal and Installation .....	40	Removal and Installation .....	50
FENDER PROTECTOR .....	41	BED RAILS AND TRIM .....	51
Exploded View - Front Fender Protector .....	41	Exploded View - Without Storage Box .....	51
Removal and Installation - Front Fender Protector..	41	Removal and Installation - Without Storage Box ...	51
Exploded View - Rear Fender Protector .....	42	Exploded View - With Storage Box .....	52
Removal and Installation - Rear Fender Protector..	42	Removal and Installation - With Storage Box .....	52
OVER FENDER .....	43	TIE DOWN CLEAT .....	54
FRONT OVER FENDER .....	43	Exploded View .....	54
FRONT OVER FENDER : Exploded View .....	43	Removal and Installation .....	54
FRONT OVER FENDER : Removal and Installation .....	43	TAILGATE TRIM .....	55
REAR OVER FENDER .....	43	Exploded View .....	55
REAR OVER FENDER : Exploded View .....	44	Removal and Installation .....	55
REAR OVER FENDER : Removal and Installation..	44	TAILGATE FINISHER .....	56
MUDGUARD .....	45	Exploded View .....	56
Exploded View .....	45	Removal and Installation .....	56
Removal and Installation .....	45	REAR ROOF SPOILER .....	57
REAR WHEEL HOUSE WIND DEFLECTOR ...	46	Removal and Installation .....	57
Exploded View .....	46	SIDE PROTECTIVE STRIP .....	58
Removal and Installation .....	46	Exploded View .....	58
		Removal and Installation .....	58

&lt; PRECAUTION &gt;

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000014391489

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

##### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


##### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

#### Procedure without Cowl Top Cover

INFOID:0000000014391490

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc. to prevent damage to the windshield.



#### Precaution for Work

INFOID:0000000014391491

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
  - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
  - Then rub with a soft, dry cloth.
  - Oily dirt:

## PRECAUTIONS

### < PRECAUTION >

---

- Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
- Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
- Then rub with a soft, dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

## PREPARATION

< PREPARATION >



# PREPARATION

## PREPARATION

### Special Service Tool


INFOID:000000014391492

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-39570) Chassis Ear	 <p>Locating the noise</p>
— (J-46534) Trim Tool Set	 <p>Removing trim components</p>
— (J-50397) NISSAN Squeak and Rattle kit	 <p>Repairing the cause of noise</p>

### Commercial Service Tool

INFOID:000000014391493

(TechMate No.) Tool name	Description
(J-39565) Engine ear	 <p>Locating the noise</p>

# CLIP LIST





< PREPARATION >

## CLIP LIST

### Descriptions for Clips

INFOID:0000000014391494





Replace any clips which are damaged during removal or installation.

Symbol No.	Shapes	Removal & Installation
C101		<p><b>Removal:</b> Remove by bending up with flat-bladed screwdrivers or clip remover.</p> 
C103		 <p><b>Removal:</b> Remove with a clip remover.</p>
C203		<p><b>Removal:</b> Push center pin to catching position. (Do not remove center pin by hitting it.)</p>   <p><b>Installation:</b></p>
C205		<p><b>Removal:</b></p>  <p>Flat-bladed screwdriver Clip Finisher</p>
C206		<p><b>Removal:</b></p> 

SIIA0315E

# CLIP LIST

## < PREPARATION >




Symbol No.	Shapes	Removal & Installation
CE103		<b>Removal:</b> 
CF110		<b>Removal:</b> 
CF118		<b>Removal:</b> 
CR103		<b>Removal:</b> Holder portion of clip must be spread out to remove rod. 
CS101		<b>Removal:</b> 1. Screw out with a Phillips screwdriver. 2. Remove female portion with flat-bladed screwdriver. 

SIIA0316E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P  
EXT

# CLIP LIST





## < PREPARATION >

Symbol No.	Shapes	Removal & Installation	
CG101	  	<b>Removal:</b>  Rotate 45° to remove	<b>Installation:</b> 
CS102	 		
CS113	 	<b>Removal:</b> Disconnect upper connection of clip with a flat-bladed screwdriver, then remove clip while inserting a flat-bladed screwdriver between body panel and clip.	
C111	 		

SIIA0317E

# CLIP LIST

## < PREPARATION >

Symbol No.	Shapes	Removal & Installation
CG104		<p><b>Removal:</b> Remove by bending up with flat-bladed screwdrivers.</p> 
CE114		
CF118		<p><b>Removal:</b> Flat-bladed screwdrivers, Finisher</p> 

ALJIA0564GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

EXT

L  
M  
N  
O  
P

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### ACTIVE GRILLE SHUTTER SYSTEM

#### ACTIVE GRILLE SHUTTER SYSTEM : Component Parts Location

INFOID:0000000014681268



A. Behind front grille

No.	Component	Reference
1.	IPDM E/R	Refer to <a href="#">PCS-5, "Component Parts Location"</a> .
2.	ECM	Refer to <a href="#">EC-43, "ECM"</a> .
3.	Active grille shutter	Refer to <a href="#">EXT-11, "ACTIVE GRILLE SHUTTER SYSTEM : Active grille shutter"</a> .


## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

#### ACTIVE GRILLE SHUTTER SYSTEM : Active grille shutter

INFOID:000000014681269

Active grille shutter is located at front bumper lower opening, and according to the signal from ECM it operates actuator ② to perform open/close movement of flap ① to control the amount of air flow taken into engine compartment.



A

B

C

D

E

F

G

H

I

J

EXT

L

M

N

O

P

# SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM

### ACTIVE GRILLE SHUTTER SYSTEM

#### ACTIVE GRILLE SHUTTER SYSTEM : System Diagram

INFOID:0000000014681270




#### ACTIVE GRILLE SHUTTER SYSTEM : System Description

INFOID:0000000014681271

While driving, the active grille shutter system closes shutter to reduce air flow to engine compartment for the purpose of reducing aerodynamic drag, and as a result, improves the vehicle's fuel efficiency.

ECM controls active grille shutter system by detecting vehicle status through respective modules and sensors. Active grille shutter actuator is equipped with self-diagnosis function. When a malfunction is detected, a signal is transmitted to the ECM and the ECM records the active grille shutter malfunction.

#### BASIC MOVEMENTS



- S1: 30 km/h (19 MPH)
- S2: Approx. 30 - 140 km/h (19 - 88 MPH)
- \*1: Shutter initial position learning
- \*2: Judgment of high vehicle speed
- \*3: Judgment of low vehicle speed

#### DESCRIPTION OF MOVEMENTS

Active grille shutter is fully open when the vehicle stops or the ignition switch is turned OFF.

ECM operates the shutter to close position in order to perform shutter's initial position learning whenever the ignition switch is turned OFF → ON and the engine is started. At the end of initial position learning ECM operates shutter to open position.

While driving, after the initial position learning ends, ECM operates the active grille shutter to close position when the operational conditions of active grille shutter are met.

While driving at high speed, ECM operates the shutter to open position when the vehicle reaches the specified speed in order to prevent the shutter from shutting up due to wind resistance.

# SYSTEM

## < SYSTEM DESCRIPTION >

When the vehicle speed is reduced below the specified speed ECM operates active grille shutter to open position.

### NOTE:

- When any one of the conditions for opening the active grille shutter is satisfied, ECM performs active grille shutter initial position learning even when the vehicle speed is less than 30 km/h.
- ECM may perform active grille shutter initial position learning according to other diagnosis conditions.

## ACTIVE GRILLE SHUTTER OPERATIONAL CONDITIONS

ECM operates active grille shutter to close position when all of the following conditions are met.

Item	Status
Active grille shutter initial position learning	Complete
Vehicle speed	Approx. 30 - 140 km/h (19 - 88 MPH)
Engine coolant temperature	Approx. less than 102°C (216°F)
Engine oil temperature	Approx. less than 140°C (284°F)
A/T fluid temperature	Approx. less than 121°C (250°F)
Cooling fan	OFF
Refrigerant pressure	0.98 MPa (9.99 kg/cm <sup>2</sup> , 142.1 psi) or less
Malfunction of engine coolant temperature sensor system	Not detected
Malfunction of engine oil temperature sensor system	Not detected
Malfunction of vehicle speed sensor system	Not detected
Malfunction of CAN communication system	Not detected

ECM operates active grille shutter to open position when one of the following conditions is met.

Item	Status
Vehicle speed	<ul style="list-style-type: none"><li>• 22 km/h (14 MPH) or less</li><li>• 140 km/h (88 MPH) or more</li></ul>
Engine coolant temperature	Approx. 102°C (216°F) or more
Engine oil temperature	Approx. 140°C (284°F) or more
A/T fluid temperature	Approx. 121°C (250°F) or more
Cooling fan	ON
Refrigerant pressure	1.18 MPa (12.04 kg/cm <sup>2</sup> , 171.1 psi) or more
Malfunction of engine coolant temperature sensor system	Detected
Malfunction of engine oil temperature sensor system	Detected
Malfunction of vehicle speed sensor system	Detected
Malfunction of CAN communication system	Detected

# ACTIVE GRILLE SHUTTER

< WIRING DIAGRAM >

## WIRING DIAGRAM


### ACTIVE GRILLE SHUTTER

#### Wiring Diagram

INFOID:0000000014664639

#### ACTIVE GRILLE SHUTTER SYSTEM

■ : CAN COMMUNICATION LINE FOR DIAGNOSIS  
◇ : WITH VK56D AND WITH DRIVER ASSISTANCE SYSTEM



AAKWA1575GB

# ACTIVE GRILLE SHUTTER

< WIRING DIAGRAM >

## ACTIVE GRILLE SHUTTER SYSTEM CONNECTORS


Connector No.	E5	Connector No.	E8
Connector Name	WIRE TO WIRE	Connector Name	ACTIVE GRILLE SHUTTER
Connector Type	·TH24NW-NH	Connector Type	RH04FB
Connector Color	WHITE	Connector Color	BLACK

**H.S.**



137	R/W	ENG COMMUNICATION LINE
138	W	ENG COMMUNICATION LINE
139	R/G	STOP LAMP SWITCH
140	G/Y	Brake Pedal Position Switch
141	Y	EVAP CANISTER VENT CONTROL VALVE
142	L/W	SENSOR POWER SUPPLY
143	O	ACCELERATOR PEDAL POSITION SENSOR 2
144	P/L	SENSOR GROUND
145	W	POWER SUPPLY FOR ECM
146	W/G	SENSOR POWER SUPPLY
147	B	ECM GROUND
148	R	SENSOR GROUND
149	B	ECM GROUND
150	W/R	ACCELERATOR PEDAL POSITION SENSOR 1
151	R/Y	SENSOR GROUND
152	B	ECM GROUND

**H.S.**




Terminal No.	Color of Wire	Signal Name	Signal Name	Terminal No.	Color of Wire	Signal Name
1	L/R	TO ENGINE CONTROL HARNESS	W	149	B	ECM GROUND
2	BR	TO ENGINE CONTROL HARNESS	-	150	W/R	ACCELERATOR PEDAL POSITION SENSOR 1
3	V	TO ENGINE CONTROL HARNESS	L	151	R/Y	SENSOR GROUND
4	L/O	TO ENGINE CONTROL HARNESS	B	152	B	ECM GROUND
5	W	TO ENGINE CONTROL HARNESS	GRD			
6	BR	TO ENGINE CONTROL HARNESS				
7	Y/R	TO ENGINE CONTROL HARNESS				
8	BR	TO ENGINE CONTROL HARNESS				
9	W/L	TO ENGINE CONTROL HARNESS				
10	LY	TO ENGINE CONTROL HARNESS				
11	SB	TO ENGINE CONTROL HARNESS				
12	L	TO ENGINE CONTROL HARNESS				
13	W/R	TO ENGINE CONTROL HARNESS				
14	Y	TO ENGINE CONTROL HARNESS				
15	B	TO ENGINE CONTROL HARNESS				
16	B	TO ENGINE CONTROL HARNESS				
17	R	TO ENGINE CONTROL HARNESS				
18	B	TO ENGINE CONTROL HARNESS				
19	BR	TO ENGINE CONTROL HARNESS				
20	GR	TO ENGINE CONTROL HARNESS				
21	VR	TO ENGINE CONTROL HARNESS				
22	B	TO ENGINE CONTROL HARNESS				
23	B	TO ENGINE CONTROL HARNESS				
24	P	TO ENGINE CONTROL HARNESS				

**H.S.**



Connector No.	E16	Connector No.	E22
Connector Name	ECM (WITH VK6VD)	Connector Name	WIRE TO WIRE
Connector Type	MAA24FB-MEA8-RH	Connector Type	M08MB-LC

**H.S.**



Terminal No.	Color of Wire	Signal Name	Signal Name	Terminal No.	Color of Wire	Signal Name
121	OB	EVAP CONTROL SYSTEM PRESSURE SENSOR	-	1	V	TO ENGINE CONTROL HARNESS
122	-	-	-	2	L	TO ENGINE CONTROL HARNESS
123	P	CAN COMMUNICATION LINE (CAN-H)	-	3	W	TO ENGINE CONTROL HARNESS
124	L	CAN COMMUNICATION LINE (CAN-H)	-	4	L	TO ENGINE CONTROL HARNESS
125	SB	SENSOR POWER SUPPLY	-	5	L	TO ENGINE CONTROL HARNESS
126	-	-	-	6	L/Y	TO ENGINE CONTROL HARNESS
127	-	-	-	7	WL	TO ENGINE CONTROL HARNESS
128	V/W	FUEL TEMPERATURE SENSOR	-	8	R	TO ENGINE CONTROL HARNESS
130	R/W	FUEL PUMP CONTROL MODULE (FFCM) CHECK	-			
131	-	-	-			
132	-	-	-			
133	W	IGNITION SWITCH	-			
134	G/Y	ASCS STEERING SWITCH	-			
135	B/Y	SENSOR GROUND	-			
136	GR	FUEL PUMP CONTROL MODULE (FFCM)	-			

AAKIA4135GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
EXT

# ACTIVE GRILLE SHUTTER

< WIRING DIAGRAM >

## ACTIVE GRILLE SHUTTER SYSTEM CONNECTORS

Connector No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
EE119	BR	ECM VB - (WITH CUMMINS 5.0L)	25	BR	ECM VB - (WITH VK56VID)
	W		25	V	O2 SENS - (WITH VK56VID)
			26	R/L	PARKING RH
			27	R/L	TAIL 1
			28	R/L	FR WIPER HI
			29	Y	
			30	-	
			31	L	ECM RLY CONT
			32	L	ECM BAT - (WITH VK56VID)
			33	R/L	PARKING LH
			34	R/W	TAIL 2
			35	BR	FR WIPER LO
			36	-	
					
Connector No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
E123	W/B	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	49	Y/B	A/C COMP - (WITH CUMMINS 5.0L)
			49	GR/R	A/C COMP - (WITH VK56VID)
			50	BR	TRAILER TOW
			51	-	
			52	B	S-GND
			53	-	
			54	-	
			55	-	
			56	-	
			56	-	
					
Connector No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
E122	Y/B	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	49	Y/B	A/C COMP - (WITH VK56VID)
			49	GR/R	A/C COMP - (WITH VK56VID)
			50	BR	TRAILER TOW
			51	-	
			52	B	S-GND
			53	-	
			54	-	
			55	-	
			56	-	
			56	-	
					
Connector No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
E124	W/B	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	37	-	-
			38	-	-
			39	Y	WIPER AUTO STOP SW
			40	P	CAN-L
			41	L	CAN-H
			42	BR	DTBL RLY
			43	-	-
			44	W/B	START CONT
			45	GR	FUEL RLY CONT
			46	Y	HOOD SW
			47	R/W	ALT C - (WITH VK56VID)
			48	Y	HORN RLY CONT
					
Connector No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
E121	W/B	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	57	W/B	RR DEF
			58	BR	FUEL PUMP - (WITH CUMMINS 5.0L)
			58	Y	FUEL PUMP - (WITH VK56VID)
			59	-	-
			60	-	-
			61	-	-
			62	B	P GND
					


AAKIA4136GB

# ACTIVE GRILLE SHUTTER


< WIRING DIAGRAM >

## ACTIVE GRILLE SHUTTER SYSTEM CONNECTORS


Connector No.	F14	Connector No.	F34
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	·TH24FW-NH	Connector Type	M08FW-3Y-LC
Connector Color	WHITE	Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name	Signal Name		
1	L/R	TO ENGINE ROOM HARNESS	1	B	TO ENGINE ROOM HARNESS
2	BR	TO ENGINE ROOM HARNESS	2	B	TO ENGINE ROOM HARNESS
3	V	TO ENGINE ROOM HARNESS	3	B	TO ENGINE ROOM HARNESS
4	L/O	TO ENGINE ROOM HARNESS	4	W/R	TO ENGINE ROOM HARNESS
5	W	TO ENGINE ROOM HARNESS	5	P	TO ENGINE ROOM HARNESS
6	BR	TO ENGINE ROOM HARNESS	6	O	TO ENGINE ROOM HARNESS
7	Y/R	TO ENGINE ROOM HARNESS	7	SB	TO ENGINE ROOM HARNESS
8	BR	TO ENGINE ROOM HARNESS	8	R	TO ENGINE ROOM HARNESS
9	WL	TO ENGINE ROOM HARNESS	9	LY	TO ENGINE ROOM HARNESS
10	SB	TO ENGINE ROOM HARNESS	10	SB	TO ENGINE ROOM HARNESS
11	L	TO ENGINE ROOM HARNESS	11	BR	TO ENGINE ROOM HARNESS
12	W/R	TO ENGINE ROOM HARNESS	12	Y	TO ENGINE ROOM HARNESS
13			13	B	TO ENGINE ROOM HARNESS
14			14		
15			15		
16			16		
17			17		
18			18		
19			19		
20			20		
21			21		
22			22		
23			23		
24			24		



Terminal No.	Color of Wire	Signal Name	Signal Name		
1	L/R	TO ENGINE ROOM HARNESS	1	B	TO ENGINE ROOM HARNESS
2	BR	TO ENGINE ROOM HARNESS	2	B	TO ENGINE ROOM HARNESS
3	V	TO ENGINE ROOM HARNESS	3	B	TO ENGINE ROOM HARNESS
4	L/O	TO ENGINE ROOM HARNESS	4	W/R	TO ENGINE ROOM HARNESS
5	W	TO ENGINE ROOM HARNESS	5	P	TO ENGINE ROOM HARNESS
6	BR	TO ENGINE ROOM HARNESS	6	O	TO ENGINE ROOM HARNESS
7	Y/R	TO ENGINE ROOM HARNESS	7	SB	TO ENGINE ROOM HARNESS
8	BR	TO ENGINE ROOM HARNESS	8	R	TO ENGINE ROOM HARNESS
9	WL	TO ENGINE ROOM HARNESS	9	LY	TO ENGINE ROOM HARNESS
10	SB	TO ENGINE ROOM HARNESS	10	SB	TO ENGINE ROOM HARNESS
11	L	TO ENGINE ROOM HARNESS	11	BR	TO ENGINE ROOM HARNESS
12	W/R	TO ENGINE ROOM HARNESS	12	Y	TO ENGINE ROOM HARNESS
13			13	B	TO ENGINE ROOM HARNESS
14			14		
15			15		
16			16		
17			17		
18			18		
19			19		
20			20		
21			21		
22			22		
23			23		
24			24		



66	P	CAMSHAFT POSITION SENSOR (PHASES) (BANK 2)	111	O	THROTTLE CONTROL MOTOR POWER SUPPLY
67	-	-	112	L/G/B	INTAKE VALVE TIMING CONTROL SOLENOID VALVE (BANK 1)
68	P	EXHAUST VALVE TIMING CONTROL POSITION SENSOR (BANK 2)	113	L/G/R	INTAKE VALVE TIMING CONTROL SOLENOID VALVE (BANK 2)
69	L/W	A/F SENSOR 1 (BANK 2)	114	L/G/B	EXHAUST VALVE TIMING CONTROL SOLENOID VALVE (BANK 1)
70	Y/B	A/F SENSOR 1 (BANK 2)	71	-	-
72	-	-	115	L/G/R	EXHAUST VALVE TIMING CONTROL SOLENOID VALVE (BANK 2)
73	L/G/R	SENSOR POWER SUPPLY	116	L/W	A/F SENSOR 1 HEATER (BANK 1)
74	R	A/F SENSOR 1 (BANK 1)	117	SB	A/F SENSOR 1 HEATER (BANK 2)
75	-	-	118	LG	HEATED OXYGEN SENSOR 2 HEATER (BANK 1)
76	-	-	119	L/R	HEATED OXYGEN SENSOR 2 HEATER (BANK 2)
77	L/W	HEATED OXYGEN SENSOR 2 (BANK 2)	120	L	POWER SUPPLY FOR ECM (BACK-UP)
78	R/L	THROTTLE POSITION SENSOR 1	79	W	A/F SENSOR 1 (BANK 1)
80	B/W	THROTTLE POSITION SENSOR 2	81	-	-
82	-	-	83	V/G	SENSOR POWER SUPPLY
84	W/R	HEATED OXYGEN SENSOR 2 (BANK 1)	85	L	SENSOR GROUND
86	L/G	LIN (WITH ACTIVE GRILLE SHUTTER)	87	-	-
88	L/G	ECM RELAY (SELF SHUT-OFF)	89	-	-
90	BR/W	WVE ACTUATOR MOTOR RELAY (ABORT SIGNAL / VEHICLE CONTROL MODULE)	91	L/B	IGNITION SIGNAL NO. 2
92	BR/Y	IGNITION SIGNAL NO. 3	93	GR	FUEL PUMP RELAY
94	Y/R	IGNITION SIGNAL NO. 6	95	Y	IGNITION SIGNAL NO. 1
96	-	-	97	-	-
98	-	-	99	-	-
99	V/R	THROTTLE CONTROL MOTOR RELAY	100	-	-
101	O	IGNITION SIGNAL NO. 8	102	P/L	IGNITION SIGNAL NO. 5
103	-	-	104	L/G/R	IGNITION SIGNAL NO. 4
105	Q/Y	IGNITION SIGNAL NO. 7	106	V/W	EVAP CANISTER PURGE VALVE (L0)
107	W	MULTI-WAY CONTROL VALVE POSITION SENSOR	108	THROTTLE CONTROL MOTOR (OPEN)	THROTTLE CONTROL MOTOR (CLOSE)
109	R	PNP SIGNAL	110	-	-
111	-	-	112	-	-

Terminal No.	Color of Wire	Signal Name	Signal Name		
1	V	MULTI-WAY CONTROL VALVE POWER SUPPLY	10	-	-
57	R	MULTI-WAY CONTROL VALVE MOTOR (-)	101	O	IGNITION SIGNAL NO. 8
58	B	MULTI-WAY CONTROL VALVE MOTOR (+)	102	P/L	IGNITION SIGNAL NO. 5
59	B	HIGH PRESSURE FUEL PUMP (H0)	103	-	-
60	W	HIGH PRESSURE FUEL PUMP (L0)	104	L/G/R	IGNITION SIGNAL NO. 4
61	BR	MULTI-WAY CONTROL VALVE POSITION SENSOR	105	V/W	EVAP CANISTER PURGE VALVE (L0)
62	B/R	PNP SIGNAL	107	W	THROTTLE CONTROL MOTOR (OPEN)
63	L/G/B	SENSOR GROUND	108	R	THROTTLE CONTROL MOTOR (CLOSE)
64	SHIELD	SHIELD	109	-	-
65	W	ENGINE COOLANT TEMPERATURE SENSOR 2	110	-	-

# SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### SQUEAK AND RATTLE TROUBLE DIAGNOSES

#### Work Flow

INFOID:0000000014391495



SBT842

#### CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [EXT-22, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)  
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)  
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)  
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)  
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)  
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)  
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)  
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

#### DUPLICATE THE NOISE AND TEST DRIVE

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
- 2) Tap or push/pull around the area where the noise appears to be coming from.
- 3) Rev the engine.
- 4) Use a floor jack to recreate vehicle "twist".
- 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on CVT and A/T models).
- 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.

- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
- If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

## CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

## LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
  - removing the components in the area that you suspect the noise is coming from.  
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
  - tapping or pushing/pulling the component that you suspect is causing the noise.  
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
  - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
  - placing a piece of paper between components that you suspect are causing the noise.
  - looking for loose components and contact marks.

Refer to [EXT-19, "Generic Squeak and Rattle Troubleshooting"](#).

## REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
  - separate components by repositioning or loosening and retightening the component, if possible.
  - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-50397) is available through your authorized NISSAN Parts Department.

## CAUTION:

**Do not use excessive force as many components are constructed of plastic and may be damaged.**

## NOTE:

- Always check with the Parts Department for the latest parts information.
- The materials contained in the NISSAN Squeak and Rattle Kit (J-50397) are listed on the inside cover of the kit; and can each be ordered separately as needed.
- The following materials not found in the kit can also be used to repair squeaks and rattles.
- SILICONE GREASE: Use instead of UHMW tape that will be visible or does not fit. The silicone grease will only last a few months.
- SILICONE SPRAY: Use when grease cannot be applied.
- DUCT TAPE: Use to eliminate movement.

## CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

## Generic Squeak and Rattle Troubleshooting

INFOID:000000014391496

Refer to Table of Contents for specific component removal and installation information.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

### INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Cluster lid A and the instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar finisher
4. Instrument panel to windshield
5. Instrument panel pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

#### **CAUTION:**

**Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.**

### CENTER CONSOLE

Components to pay attention to include:

1. Shift selector assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

### DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-50397) to repair the noise.

### TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

### SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

### OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

1. Loose harness or harness connectors.
2. Front console map/reading lamp lens loose.
3. Loose screws at console attachment points.

## SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

## UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component installed to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator installation pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine rpm or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A

B

C

D

E

F

G

H

I

J

EXT

L

M

N

O

P

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## Diagnostic Worksheet

INFOID:0000000014391497





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

### SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

#### I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

---

---

### II. WHEN DOES IT OCCUR? (please check the boxes that apply)

<input type="checkbox"/> Anytime	<input type="checkbox"/> After sitting out in the rain
<input type="checkbox"/> 1st time in the morning	<input type="checkbox"/> When it is raining or wet
<input type="checkbox"/> Only when it is cold outside	<input type="checkbox"/> Dry or dusty conditions
<input type="checkbox"/> Only when it is hot outside	<input type="checkbox"/> Other: _____

### III. WHEN DRIVING:

<input type="checkbox"/> Through driveways	<input type="checkbox"/> Squeak (like tennis shoes on a clean floor)
<input type="checkbox"/> Over rough roads	<input type="checkbox"/> Creak (like walking on an old wooden floor)
<input type="checkbox"/> Over speed bumps	<input type="checkbox"/> Rattle (like shaking a baby rattle)
<input type="checkbox"/> Only about _____ mph	<input type="checkbox"/> Knock (like a knock at the door)
<input type="checkbox"/> On acceleration	<input type="checkbox"/> Tick (like a clock second hand)
<input type="checkbox"/> Coming to a stop	<input type="checkbox"/> Thump (heavy muffled knock noise)
<input type="checkbox"/> On turns: left, right or either (circle)	<input type="checkbox"/> Buzz (like a bumble bee)
<input type="checkbox"/> With passengers or cargo	
<input type="checkbox"/> Other: _____	
<input type="checkbox"/> After driving _____ miles or _____ minutes	

### IV. WHAT TYPE OF NOISE

<input type="checkbox"/> Squeak (like tennis shoes on a clean floor)
<input type="checkbox"/> Creak (like walking on an old wooden floor)
<input type="checkbox"/> Rattle (like shaking a baby rattle)
<input type="checkbox"/> Knock (like a knock at the door)
<input type="checkbox"/> Tick (like a clock second hand)
<input type="checkbox"/> Thump (heavy muffled knock noise)
<input type="checkbox"/> Buzz (like a bumble bee)

## TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

---

---

---

EXT

YES	NO	Initials of person performing
-----	----	-------------------------------

Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

L

M

N

VIN: \_\_\_\_\_ Customer Name: \_\_\_\_\_

W.O.# \_\_\_\_\_ Date: \_\_\_\_\_

O

This form must be attached to Work Order

LAIA0071E

P

# FRONT BUMPER

< REMOVAL AND INSTALLATION >


## REMOVAL AND INSTALLATION

### FRONT BUMPER

#### Exploded View

INFOID:000000014391498

#### Non-XD Models




1. Front bumper retainer
2. Bumper fascia upper
3. Bumper fascia upper side bracket (RH)
4. Front bumper side bracket (RH)
5. Headlamp bracket (RH)
6. Front sonar outer sensor (if equipped)
7. Front bumper finisher (RH)
8. Front bumper grill finisher (RH)
9. Front sonar inner sensor (if equipped)
10. Tow hook finisher (RH)
11. Tow hook finisher (RH)
12. Tow hook finisher (LH)
13. Front bumper grille finisher (LH)
14. Front air spoiler
15. Front bumper finisher (LH)
16. Headlamp bracket (LH)
17. Front bumper side bracket (LH)
18. Front bumper mounting bracket (LH)
19. Bumper fascia upper side bracket (LH)
20. Front bumper mounting bracket (RH)
- A. Clip

Front

## FRONT BUMPER

## < REMOVAL AND INSTALLATION >

## XD Models



1. Front bumper retainer	2. Bumper fascia upper	3. Bumper fascia upper side bracket (RH)
4. Front bumper side bracket (RH)	5. Front bumper	6. Front bumper finisher (RH)
7. Front sonar outer sensor	8. Front bumper grill finisher (RH)	9. Tow hook finisher (RH)
10. Front sonar inner sensor	11. License plate bracket	12. Tow hook finisher (LH)
13. Front bumper grill finisher (LH)	14. Front air spoiler	15. Front bumper finisher (LH)
16. Front bumper side bracket (LH)	17. Bumper fascia upper side bracket (LH)	18. Front bumper mounting bracket (LH)
19. Front bumper mounting bracket (RH)	A. Clip	Front

← Front


## Removal and Installation - Front Bumper

INFOID:0000000014391499

## REMOVAL

1. Remove front fender protector (LH/RH). Refer to [EXT-41. "Removal and Installation - Front Fender Protector"](#).
2. Remove front grill. Refer to [EXT-32. "Removal and Installation"](#).
3. Release clips using suitable tool, and remove front bumper grill finisher (1) from front bumper (2).


[ - ] : Metal clip




# FRONT BUMPER

## < REMOVAL AND INSTALLATION >


4. Disconnect harness connector (A) from front sonar inner sensor [1 (if equipped)].



5. Disconnect harness connector (A) from front sonar outer sensor [1 (if equipped)].



6. Disconnect harness connectors from fog lamp (if equipped).
7. Remove clip and bolt from tow hook finisher, then remove tow hook finisher.
8. Remove front bumper side bracket nuts (LH/RH).
9. Remove front bumper bolts [LH/RH (A)].



10. Remove front bumper.

**CAUTION:**

**When removing front bumper, two people are required.**

## INSTALLATION

Installation is in the reverse order of removal.

## Removal and Installation - Bumper Fascia Upper

INFOID:0000000014391500

## REMOVAL

1. Remove front grille. Refer to [EXT-32, "Removal and Installation"](#).
2. Remove active grille shutter (for Non-XD Models). Refer to [EXT-34, "Removal and Installation"](#).
3. Partially remove fender protector (LH/RH). Refer to [EXT-41, "Exploded View - Front Fender Protector"](#).
4. Remove bumper fascia upper screws.
5. Release clips and remove bumper fascia upper.

## INSTALLATION

Installation is in the reverse order of removal.


# FRONT BUMPER

## < REMOVAL AND INSTALLATION >

### Adjustment

INFOID:000000014391501

Check clearance and surface height between front bumper and each part by visual inspection and tactile feel. If clearance and surface height are out of specification, adjust them.



Unit: mm (in)

EXT

Section	Measurement	Standard	Parallelism
A-A	Clearance	$4.2 \pm 2.0$ ( $0.17 \pm 0.08$ )	1.5 (0.06)
	Surface Height	-	-
B-B	Clearance	$3.0 \pm 1.5$ ( $0.12 \pm 0.06$ )	1.2 (0.05)
	Surface Height	-	-
C-C	Clearance	$20.0 \pm 5.0$ ( $0.79 \pm 0.20$ )	5.0 (0.20)
	Surface Height	-	-
D-D	Clearance	$3.0 \pm 2.0$ ( $0.12 \pm 0.08$ )	-
	Surface Height	-	-
E-E	Clearance	$2.0 \pm 1.5$ ( $0.08 \pm 0.06$ )	1.5 (0.06)
	Surface Height	-	-
F-F	Clearance	-	-
	Surface Height	$0.0 \pm 1.7$ ( $0.00 \pm 0.7$ )	-
G-G	Clearance	$0.5, -1.0 - 0.5$ ( $0.02, -0.02$ )	-
	Surface Height	-	-
H-H	Clearance	$0.3, +1.0, -0.3$ ( $0.01, -0.04, -0.01$ )	-
	Surface Height	$0.8 \pm 1.0$ ( $0.03 \pm 0.04$ )	-

L

M

N

O

P

# REAR BUMPER


< REMOVAL AND INSTALLATION >

## REAR BUMPER

### Exploded View

INFOID:0000000014391502

#### WITH TRAILER HITCH




1. Bumper bracket (LH/RH)	2. Sonar sensor (if equipped)	3. Bumper finisher
4. License plate lamp	5. Bumper fascia (if equipped)	6. Bumper
Pawl	Metal clip	Front

# REAR BUMPER

## < REMOVAL AND INSTALLATION >

### WITHOUT TRAILER HITCH



1. Bumper assembly	2. Bumper bracket (LH/RH)	3. Sonar sensor (if equipped)
4. Bumper finisher	5. License plate lamp	6. Bumper fascia (if equipped)
7. Bumper	① Pawl	② Metal clip

Front

## Removal and Installation

INFOID:0000000014391503

### REMOVAL

1. Remove tailgate. Refer to [DLK-166, "TAILGATE ASSEMBLY : Removal and Installation"](#).
2. Remove license plate lamps. Refer to [EXL-142, "Removal and Installation"](#) (HALOGEN HEADLAMP) or [EXL-301, "Removal and Installation"](#) (LED HEADLAMP).
3. Remove trailer tow connector socket (if equipped).


## REAR BUMPER

### < REMOVAL AND INSTALLATION >

4. Disconnect license plate lamp connector (A) from chassis harness (LH) and separate vehicle.

**NOTE:**


Trailer hitch shown. Bumper reinforcement similar.



5. Disconnect side radar harness connector (A) and rear sonar harness connector (B) from chassis harness (RH) and separate from vehicle (if equipped).

**NOTE:**

Trailer hitch shown. Bumper reinforcement similar.



6. Release bumper finisher metal clips and pawls using suitable tool.
7. Separate adhesive tape from behind bumper finisher ends and remove bumper finisher from vehicle.

**CAUTION:**  
**Do not reuse adhesive tape.**

8. Remove bolts, and remove bumper from vehicle.

**CAUTION:**  
**When removing bumper, two people are required.**

9. Disconnect harness connector from side radar units (LH/RH) [if necessary (if equipped)]. Refer to [DAS-120, "Exploded View"](#).
10. Remove bumper fascia [if necessary (if equipped)].
11. Separate wire harness from bumper and remove wire harness (if necessary).
12. Remove side radar units and splash guards from bumper [if necessary (if equipped)]. Refer to [DAS-120, "Removal and Installation"](#).

### INSTALLATION

Installation is in the reverse order of removal.

**CAUTION:**

Perform camera image calibration (if equipped with around view monitor). Refer to [AV-332, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Description"](#).


### Adjustment

INFOID:0000000014391504

Check clearance and surface height between rear bumper and each part by visual inspection and tactile feel. If clearance and surface height are out of specification, adjust them.

## REAR BUMPER

### < REMOVAL AND INSTALLATION >



Unit: mm (in)

Section	Measurement	Standard	Parallelism
A-A	Clearance	$25.0 \pm 6.0$ (0.98 ± 0.24)	6.0 (0.24)
	Surface Height	-	-
B-B	Clearance	$20.0 \pm 5.4$ (0.79 ± 0.21)	5.4 (0.21)
	Surface Height	-	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

EXT


# FRONT GRILLE

< REMOVAL AND INSTALLATION >

## FRONT GRILLE

### Exploded View

INFOID:0000000014391505



1. Front grille

○ Pawl

△ Clip

#### NOTE:


XD Model shown, Non-XD Model similar.

### Removal and Installation

INFOID:0000000014391506

#### REMOVAL


1. Release the front grille (1) using a suitable tool with the following procedure:
  - a. Release clips (C)
  - b. Release clips (B)
  - c. Release pawls (A)



# FRONT GRILLE

## < REMOVAL AND INSTALLATION >

2. Disconnect harness connector (A) from front camera [1 (if equipped)], then remove the front grille.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J

## INSTALLATION

Installation is in the reverse order of removal.

1. Install front grille (1) using a suitable tool with the following procedure:
  - a. Install pawls (A)
  - b. Install clips (B)
  - c. Install clips (C)



I  
J

### CAUTION:

Perform the calibration and perform the writing to the around view monitor control unit when removing and replacing each camera, removing the camera mounting parts (front grille, door mirror, etc.) and replacing the around view monitor control unit (if equipped). Refer to [AV-332, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Description"](#).

EXT

L  
M  
N  
O  
P


# ACTIVE GRILLE SHUTTER

< REMOVAL AND INSTALLATION >

## ACTIVE GRILLE SHUTTER

### Exploded View

INFOID:0000000014698174



1. Active grille shutter

## Removal and Installation

INFOID:0000000014698175

### REMOVAL

1. Remove front grille. Refer to [EXT-32, "Removal and Installation"](#).
2. Disconnect the harness connector from the active grille shutter.
3. Remove active grille shutter bolts.
4. Remove active grille shutter.

### INSTALLATION

Installation is in the reverse order of removal.


# COWL TOP

< REMOVAL AND INSTALLATION >

## COWL TOP

### Exploded View

INFOID:0000000014391507



- 1. Cowl top cover seal
- 2. Cowl top side trim cover (RH)
- 3. Cowl top cover
- 4. Cowl top side seal (LH/RH)
- 5. Washer nozzle supply hose
- 6. Cowl top extension
- 7. Cowl top extension bracket
- 8. Cowl top side trim cover (LH)

 Pawl

J

EXT

### Removal and Installation - Cowl Top Side Trim Cover

INFOID:0000000014391508

#### REMOVAL

Using suitable tool, release clips and pawls and remove cowl top side trim cover (LH/RH).

#### CAUTION:

When performing the procedure after removing cowl top side trim cover, protect the lower end of windshield glass with urethane etc.

#### INSTALLATION

Installation is in the reverse order of removal.

### Removal and Installation - Cowl Top Cover

INFOID:0000000014391509

#### REMOVAL

1. Remove wiper arms (LH/RH). Refer to [WW-47, "WIPER ARM : Removal and Installation"](#).
2. Disconnect the washer nozzle supply hose.
3. Remove cowl top fender cover (LH/RH).
4. Release the cowl top clips and remove cowl top.

#### INSTALLATION

Installation is in the reverse order of removal.

#### CAUTION:

L

M

N

O

P

## COWL TOP

### < REMOVAL AND INSTALLATION >

Install so that there is no clearance between windshield glass and cowl top cover.

#### Removal and Installation - Cowl Top Extension

INFOID:0000000014391510

##### REMOVAL

1. Remove front wiper drive assembly. Refer to [WW-49, "WIPER DRIVE ASSEMBLY : Removal and Installation".](#)
2. Remove cowl top extension bracket bolts.
3. Remove cowl top extension bracket.
4. Remove cowl top extension.
5. Remove drain hose (if necessary).
6. Remove cowl top extension side seal (LH/RH) (if necessary).

##### INSTALLATION

Installation is in the reverse order of removal.

# UNDER COVER


< REMOVAL AND INSTALLATION >

## UNDER COVER

### FRONT UNDER COVER

#### FRONT UNDER COVER : Exploded View

INFOID:0000000014391511



1. Front under cover
2. Front side member
3. Front suspension cross member

Front

#### FRONT UNDER COVER : Removal and Installation

INFOID:0000000014391512

### REMOVAL

1. Remove front undercover bolts.
2. Remove front under cover.

### INSTALLATION

Installation is in the reverse order of removal.

### REAR UNDER COVER

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

EXT


L  
M  
N  
O  
P

# UNDER COVER

< REMOVAL AND INSTALLATION >

## REAR UNDER COVER : Exploded View

INFOID:0000000014391513



- 1. Rear fuel tank cross member
- 2. Rear under cover
- 3. Fuel tank
- 4. Front fuel tank cross member

⬅ Front

## REAR UNDER COVER : Removal and Installation

INFOID:0000000014391514

### REMOVAL

1. Remove rear under cover bolts.
2. Remove rear under cover.

### INSTALLATION

Installation is in the reverse order of removal.


### ENGINE UNDER COVER

# UNDER COVER

< REMOVAL AND INSTALLATION >

## ENGINE UNDER COVER : Exploded View

INFOID:000000014391515



1. Front suspension cross member (front)
2. Engine under cover
3. Front suspension cross member (rear)

INFOID:000000014391516

## ENGINE UNDER COVER : Removal and Installation

EXT

### REMOVAL

1. Remove engine under cover screws.
2. Remove engine under cover.

### INSTALLATION

Installation is in the reverse order of removal.

### FLOOR UNDER COVER

L

M

N

O


P

# UNDER COVER

< REMOVAL AND INSTALLATION >

FLOOR UNDER COVER : Exploded View

INFOID:0000000014391517



1. Transfer case

2. Floor under cover

Front

FLOOR UNDER COVER : Removal and Installation

INFOID:0000000014391518

## REMOVAL

1. Remove floor under cover bolts.
2. Remove floor under cover.

## INSTALLATION

Installation is in the reverse order of removal.


# FENDER PROTECTOR

< REMOVAL AND INSTALLATION >

## FENDER PROTECTOR

### Exploded View - Front Fender Protector

INFOID:0000000014391519



1. Front fender protector

2. Fender clip

Front

### Removal and Installation - Front Fender Protector

INFOID:0000000014391520

#### FRONT FENDER PROTECTOR

##### REMOVAL

1. Remove the mudguard. Refer to [EXT-45, "Removal and Installation"](#).
2. Remove the front fender protector screws.
3. Release the front fender protector clips using suitable tool.
4. Remove the front fender protector.

##### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

EXT


L  
M  
N  
O  
P

# FENDER PROTECTOR

< REMOVAL AND INSTALLATION >

## Exploded View - Rear Fender Protector

INFOID:0000000014391521



1. Rear fender protector

◀ Front

## Removal and Installation - Rear Fender Protector

INFOID:0000000014391522

### REMOVAL

1. Remove the mud guard. Refer to [EXT-45, "Removal and Installation"](#).
2. Remove the rear wheel house wind deflector (if equipped). Refer to [EXT-46, "Removal and Installation"](#).
3. Partially remove the rear over fender (if equipped). Refer to [EXT-44, "REAR OVER FENDER : Exploded View"](#).
4. Remove the rear fender protector screws.
5. Remove the rear fender protector.

### INSTALLATION

Installation is in the reverse order of removal.

# OVER FENDER


< REMOVAL AND INSTALLATION >

## OVER FENDER

### FRONT OVER FENDER

#### FRONT OVER FENDER : Exploded View

INFOID:0000000014391523



1. Front over fender

△ Clip

#### FRONT OVER FENDER : Removal and Installation

INFOID:0000000014391524

EXT

##### REMOVAL

1. Remove front mudguard. Refer to [EXT-45, "Removal and Installation"](#).
2. Remove front over fender screws.
3. Release clips and remove front over fender.

##### INSTALLATION

Installation is in the reverse order of removal.

##### CAUTION:

- Visually check the clips for deformation and damage during installation. Replace with new ones if necessary.
- When installing front over fender, check that clips are securely placed in body panel holes.


### REAR OVER FENDER

# OVER FENDER

< REMOVAL AND INSTALLATION >

REAR OVER FENDER : Exploded View

INFOID:0000000014391525



1. Rear over fender

△ Clip

## REAR OVER FENDER : Removal and Installation

INFOID:0000000014391526

### REMOVAL

1. Remove rear wheel house wind deflector. Refer to [EXT-46, "Removal and Installation"](#)
2. Remove rear over fender screws.
3. Release clips and remove rear over fender.

### INSTALLATION

Installation is in the reverse order of removal.

#### CAUTION:

- Visually check the clips for deformation and damage during installation. Replace with new ones if necessary.
- When installing over fender, check that clips are securely placed in body panel holes.


# MUDGUARD

< REMOVAL AND INSTALLATION >

## MUDGUARD

### Exploded View

INFOID:0000000014391527



1. Mudguard

**NOTE:**

Front shown; rear similar.

### Removal and Installation

INFOID:0000000014391528

#### REMOVAL

1. Remove mudguard screws.
2. Remove mudguard.

#### INSTALLATION

Installation is in the reverse order of removal.


# REAR WHEEL HOUSE WIND DEFLECTOR

< REMOVAL AND INSTALLATION >

## REAR WHEEL HOUSE WIND DEFLECTOR

### Exploded View

INFOID:0000000014391529



1. Rear wheel house wind deflector  Front

### Removal and Installation

INFOID:0000000014391530

#### REMOVAL

1. Remove rear wheel house wind deflector screws.
2. Remove rear wheel house wind deflector.

#### INSTALLATION

Installation is in the reverse order of removal.


## SIDE STEP

< REMOVAL AND INSTALLATION >

### SIDE STEP

#### Exploded View

INFOID:0000000014391531



1. Side step bracket
2. Side step

#### Removal and Installation

INFOID:0000000014391532

##### REMOVAL

1. Disconnect the harness connector from the side step.
2. Remove side step bolts, and then remove side step from side step bracket.
3. Remove side step bracket nut and bolt, then remove side step bracket.

##### INSTALLATION

Installation is in the reverse order of removal.


# DOOR OUTSIDE MOLDING

< REMOVAL AND INSTALLATION >

## DOOR OUTSIDE MOLDING

### Exploded View

INFOID:0000000014391533



1. Rear door
2. Front door
3. Door molding front
4. Door molding rear

### Removal and Installation

INFOID:0000000014391534

#### FRONT DOOR OUTSIDE MOLDING

##### REMOVAL

1. Fully open door window.
2. Remove door mirror. Refer to [MIR-31, "Removal and Installation"](#)
3. Remove screw cover and remove screw.
4. Twist and pull up to upper side, and remove front door outside molding.

##### INSTALLATION

Installation is in the reverse order of removal.

#### REAR DOOR OUTSIDE MOLDING

##### REMOVAL

1. Fully open door window.
2. Remove screw cover and remove screw.
3. Twist and pull up to upper side, and remove rear door outside molding.

##### INSTALLATION

## DOOR OUTSIDE MOLDING

### < REMOVAL AND INSTALLATION >

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

EXT

L

M

N

O

P


# ROOF SIDE MOLDING

< REMOVAL AND INSTALLATION >

## ROOF SIDE MOLDING

### Exploded View

INFOID:0000000014391535



1. Roof side molding (LH)

2. Roof side molding (RH)

A. Double-sided tape

### Removal and Installation

INFOID:0000000014391536

#### REMOVAL

Using a suitable tool, release pawls and remove roof side molding.

**CAUTION:**

Apply protective tape to painted surfaces to prevent damage.

#### INSTALLATION

**NOTE:**

- The roof side molding (LH/RH) are affixed with double-faced adhesive tape.
- To re-use existing molding, clean all double-faced adhesive tape from molding and apply new double-faced adhesive tape to the molding.

1. Remove tape and clean surface with isopropyl alcohol or equivalent to degrease surface.
2. Align clips and install roof side molding, put pressure on double sided tape to secure fit.

**CAUTION:**

- Use double-faced adhesive tape.
- Do not wash vehicle within 24 hours of installation, to secure contact.


# BED RAILS AND TRIM

< REMOVAL AND INSTALLATION >

## BED RAILS AND TRIM

### Exploded View - Without Storage Box

INFOID:0000000014391537



1. Center tie down rail	2. Bedside finisher	3. Bedside tie down rail (LH)
4. Floor rail cover	5. Floor rail (LH)	6. Tie down cleat

#### NOTE:

LH shown, RH similar.

### Removal and Installation - Without Storage Box

INFOID:0000000014391538

#### REMOVAL

1. Remove center tie down rail bolts, then remove center tie down rail.
2. Remove bedside tie down rail bolts, then remove bedside tie down rail (LH/RH).
3. Release clips and remove bedside finisher.
4. Slide floor rail cover forward and remove.
5. Remove floor rail bolts, then remove floor rail.
6. Remove tie down cleat (if necessary).

#### INSTALLATION


## BED RAILS AND TRIM

### < REMOVAL AND INSTALLATION >

Installation is in the reverse order of removal.

### Exploded View - With Storage Box

INFOID:0000000014391539



1. Bed liner floor trim
2. Bed liner front trim
3. Bedside storage box (RH)
4. Bedside finisher (RH)

#### NOTE:

RH shown, LH similar.

### Removal and Installation - With Storage Box

INFOID:0000000014391540

#### REMOVAL

1. Release clips and remove bedside finisher.
2. Remove storage box bolts.
3. Remove storage box.  
**CAUTION:**  
**When removing storage box, two people are required.**
4. Remove bed liner front trim clips, then remove bed liner front trim.

## BED RAILS AND TRIM

### < REMOVAL AND INSTALLATION >

5. Remove bolts from bed liner floor trim.

**CAUTION:**

**When removing bolts from bed trim, two people are required.**

6. Remove bed liner floor trim.

### INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

EXT

L

M

N

O

P


# TIE DOWN CLEAT

< REMOVAL AND INSTALLATION >

## TIE DOWN CLEAT

### Exploded View

INFOID:0000000014710143



1. Center tie down rail	2. Bedside finisher	3. Bedside tie down rail (LH)
4. Floor rail cover	5. Floor rail (LH)	6. Tie down cleat

### Removal and Installation

INFOID:0000000014710144

#### REMOVAL

1. Loosen tie down cleat nut.
2. Remove tie down cleat.

#### INSTALLATION

Installation is in the reverse order of removal.


# TAILGATE TRIM

< REMOVAL AND INSTALLATION >

## TAILGATE TRIM

### Exploded View

INFOID:0000000014391541



- 1. Tailgate protector
- 2. Tailgate cover plate
- 3. Tailgate trim
- 4. Tailgate assembly
- 5. Tailgate finisher

Clip

INFOID:0000000014391542

### Removal and Installation

EXT

#### REMOVAL

1. Release clips using suitable tool and remove tailgate trim.

#### INSTALLATION

Installation is in the reverse order of removal.

L

M

N

O

P


# TAILGATE FINISHER

< REMOVAL AND INSTALLATION >

## TAILGATE FINISHER

### Exploded View

INFOID:0000000014391543



AWKIA3908ZZ

1. Tailgate protector	2. Tailgate cover plate	3. Tailgate trim
4. Tailgate assembly	5. Tailgate finisher	△ Clip

### Removal and Installation

INFOID:0000000014391544

#### REMOVAL

1. Remove tailgate protector.
2. Remove tailgate cover plate.
3. Release clips using suitable tool and remove tailgate trim.
4. Remove tailgate finisher nuts.
5. Release tailgate finisher clips using suitable tool and remove tailgate finisher.

#### INSTALLATION

Installation is in the reverse order of removal.

# REAR ROOF SPOILER

< REMOVAL AND INSTALLATION >

## REAR ROOF SPOILER

### Removal and Installation


INFOID:0000000014391545

#### REMOVAL

1. Remove headliner. Refer to [INT-32, "Removal and Installation"](#).
2. Remove rear roof spoiler nuts (A).
3. Release clips and remove rear roof spoiler (1).

**NOTE:**

LH shown, RH similar.



#### INSTALLATION

Installation is in the reverse order of removal.

EXT


# SIDE PROTECTIVE STRIP

< REMOVAL AND INSTALLATION >

## SIDE PROTECTIVE STRIP

### Exploded View

INFOID:0000000014727258



1. Side protective strip

#### NOTE:

LH shown, RH similar.

### Removal and Installation

INFOID:0000000014727259

#### REMOVAL

1. Slide side protective seal upward and remove..

#### INSTALLATION

Installation is in the reverse order of removal.