

SECTION

PB

PARKING BRAKE SYSTEM

CONTENTS

PRECAUTION	2	Exploded View	7	PB
PRECAUTIONS	2	Removal and Installation	8	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	PARKING BRAKE FRONT CABLE	10	
PREPARATION	3	Removal and Installation	10	G
PREPARATION	3	PARKING BRAKE REAR CABLE	11	
Commercial Service Tool	3	Removal and Installation	11	H
BASIC INSPECTION	4	PARKING BRAKE SWITCH	12	
PARKING BRAKE SHOE	4	Removal and Installation	12	I
Inspection	4	PARKING BRAKE SHOE	13	
PERIODIC MAINTENANCE	5	Exploded View	13	
PARKING BRAKE SYSTEM	5	Removal and Installation	13	J
Inspection	5	Break-In Procedure	14	
Adjustment	5	SERVICE DATA AND SPECIFICATIONS (SDS)	15	K
REMOVAL AND INSTALLATION	7	SERVICE DATA AND SPECIFICATIONS (SDS)	15	
PARKING BRAKE CONTROL	7	Parking Drum Brake	15	L
		Parking Drum Brake (Non-XD Models)	15	
		Parking Brake Control	15	M

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000014392568

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

PREPARATION



< PREPARATION >

PREPARATION

PREPARATION

Commercial Service Tool

INFOID:0000000014392569

Tool name	Description
Brake drum clearance gauge 	Measuring rear rotor drum inner diameter
Power tool 	Loosening nuts, screws and bolts

PARKING BRAKE SHOE

< BASIC INSPECTION >

BASIC INSPECTION

PARKING BRAKE SHOE

Inspection


INFOID:000000014392570

LINING THICKNESS INSPECTION

- Check thickness of lining.

Standard thickness (new) (A) : Refer to [PB-15, "Parking Drum Brake"](#).

Wear limit thickness (A) : Refer to [PB-15, "Parking Drum Brake"](#).




DRUM INNER DIAMETER INSPECTION

- Check inner diameter of drum in rear disc brake rotor using a suitable tool.

Standard inner diameter (new) : Refer to [PB-15, "Parking Drum Brake"](#).

Wear limit of inner diameter : Refer to [PB-15, "Parking Drum Brake"](#).



OTHER INSPECTIONS

- Check the following:
 - Lining for excessive wear, damage, and peeling.
 - Shoe sliding surface for excessive wear and damage.
 - Anti-rattle pin for excessive wear and corrosion.
 - Return spring for sagging.
- Make sure that adjuster moves smoothly.
- Visually check the inside of drum for excessive wear, cracks, and damage.
- Replace with new parts as necessary.

PARKING BRAKE SYSTEM

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

PARKING BRAKE SYSTEM

Inspection

INFOID:0000000014392571

PEDAL STROKE

1. Operate parking brake pedal with a force of 196 N (20.0 kg-f, 44.1 lb-f). Check that pedal stroke is within specified number of notches. (Check it by listening to the clicks of the ratchet.)

Number of notches : Refer to [PB-15, "Parking Brake Control"](#).

2. When brake warning lamp turns ON, check that pedal stroke is within specified number of notches. (Check it by listening to the clicks of the ratchet.)

Number of notches : Refer to [PB-15, "Parking Brake Control"](#).

Inspect Components


- Check each component for installation condition such as looseness.
- Check parking brake pedal assembly for bends, damage and cracks. Replace if necessary.
- Check cables for wear, damage and cracks. Replace if necessary.
- Check parking brake switch, and replace it if necessary. Refer to [PB-12, "Removal and Installation"](#).

Adjustment

INFOID:0000000014392572


ADJUSTMENT

1. Remove instrument lower panel LH. Refer to [IP-22, "Removal and Installation"](#).
2. Release parking brake pedal (1) by turning adjusting nut (A) with a deep socket wrench and loosening front cable (2).



3. Remove wheels and tires using a power tool. Refer to [WT-69, "Removal and Installation"](#).
4. Secure disc brake rotor using wheel nuts.
5. Remove adjusting hole plug from back plate. Turn adjuster in direction shown using a suitable tool until disc brake rotor is locked.

(A) :RH
(B) :LH
⇐ Front




PARKING BRAKE SYSTEM

< PERIODIC MAINTENANCE >

6. Turn adjuster back 14 - 15 notches from locked position in direction as shown using a suitable tool.

(A) :RH
(B) :LH
↶ Front



7. Rotate disc brake rotor to make sure there is no drag. Install adjusting hole plug.
8. Adjust cable with following procedure:
- Operate parking brake pedal with a force of 490 N (50.0 kg-f, 110.2 lb-f) for more than 30 minutes.
 - Adjust parking brake pedal stroke by turning adjusting nut with deep socket wrench. Refer to [PB-15, "Parking Brake Control"](#).
- CAUTION:**
Do not reuse the adjusting nut if it is removed.
- c. Operate parking brake pedal with a force of 196 N (20.0 kg-f, 44.1 lb-f) 10 times or more. Check that pedal stroke is within specified number of notches. (Check it by listening to the number of clicks of the ratchet.)

Number of notches : Refer to [PB-15, "Parking Brake Control"](#).

- d. Rotate disc brake rotor with parking brake pedal released and check that there is no drag.
- CAUTION:**
If any drag is found, verify the parking brake components are installed and adjusted correctly.
9. Install wheels and tires using a power tool. Refer to [WT-69, "Removal and Installation"](#).
10. Install instrument lower panel LH. Refer to [IP-22, "Removal and Installation"](#).

PARKING BRAKE CONTROL

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

PARKING BRAKE CONTROL

Exploded View

INFOID:0000000014392573

XD Models




- | | | |
|------------------------------|--------------------------|----------------------------|
| 1. Parking brake front cable | 2. Parking brake control | 3. Parking brake pedal pad |
| 4. Parking brake switch | 5. Rear cable (LH) | 6. Washers |
| 7. Rear cable (RH) | 8. Spring | A. Adjusting nut |
| ⇐ Front | ⇐ Front | |

PARKING BRAKE CONTROL

< REMOVAL AND INSTALLATION >

Non-XD Models



- | | | |
|------------------------------|--------------------------|----------------------------|
| 1. Parking brake front cable | 2. Parking brake control | 3. Parking brake pedal pad |
| 4. Parking brake switch | 5. Rear cable (LH) | 6. Washers |
| 7. Rear cable (RH) | 8. Spring | A. Adjusting nut |
| ⇐ Front | ⇐ Front | |

Removal and Installation

INFOID:0000000014392574


REMOVAL

1. Remove instrument lower panel LH. Refer to [IP-22, "Removal and Installation"](#).
2. Disconnect harness connector from parking brake switch.

PARKING BRAKE CONTROL

< REMOVAL AND INSTALLATION >


3. Remove screw (A) and remove sonar control unit (1).



4. Remove harness retainer screw from steering member.
5. Remove adjusting nut (A).

CAUTION:

Do not reuse adjusting nut.



6. Remove parking brake control nuts and remove parking brake control.
7. Separate parking brake front cable from parking brake control.
8. Remove parking brake switch.

INSTALLATION

Installation is in the reverse order of removal.

- Adjust parking brake. Refer to [PB-5, "Adjustment"](#).

CAUTION:

The cables should be free from twists, damage, cracks, and corrosion.

PARKING BRAKE FRONT CABLE

< REMOVAL AND INSTALLATION >

PARKING BRAKE FRONT CABLE

Removal and Installation


INFOID:000000014392575

REMOVAL

1. Remove parking brake control. Refer to [PB-8, "Removal and Installation"](#).
NOTE:
It is not necessary to remove parking brake switch.
2. Remove center console. Refer to [IP-24, "Removal and Installation"](#).
3. Place front floor trim (RH) aside. Refer to [INT-30, "Removal and Installation"](#).
4. Remove bolts from parking brake front cable. Refer to [PB-7, "Exploded View"](#).
5. Remove Around View Monitor control unit. Refer to [AV-360, "Removal and Installation"](#).
6. Remove spring (3) from equalizer (1).
7. Pull equalizer (1) on parking brake front cable (2) and separate parking brake rear cable [LH/RH (4)] from parking brake front cable.

CAUTION:

To prevent damage to parts, do not bend parking brake cables.



8. Remove parking brake front cable.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Do not reuse the adjusting nut.

- After installation, adjust parking brake pedal. Refer to [PB-5, "Adjustment"](#).

PARKING BRAKE REAR CABLE

< REMOVAL AND INSTALLATION >

PARKING BRAKE REAR CABLE

Removal and Installation

INFOID:0000000014392576

REMOVAL

1. Loosen adjusting nut.


NOTE:

It is not necessary to remove parking brake front cable.

2. Remove spring (3) from equalizer (1).
3. Pull equalizer (1) on parking brake front cable (2) and separate parking brake rear cable [LH/RH (4)] from parking brake front cable.

CAUTION:

To prevent damage to parts, do not bend parking brake cables.



4. Separate parking brake rear cable from toggle lever. Refer to [PB-13, "Exploded View"](#).
5. Remove nuts and bolts from rear parking brake cable.
6. Remove parking brake rear cable.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Do not reuse the adjusting nut if the nut is removed.

- After installation, adjust the parking brake shoes. Refer to [PB-14, "Break-In Procedure"](#).

PARKING BRAKE SWITCH

< REMOVAL AND INSTALLATION >

PARKING BRAKE SWITCH

Removal and Installation

INFOID:0000000014392577

REMOVAL

1. Remove parking brake control nuts and remove parking brake control. Refer to [PB-7. "Exploded View"](#).
2. Disconnect harness connector from parking brake switch.
3. Remove parking brake switch.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- **Replace parking brake switch if it has been dropped or sustained an impact.**
- **Do not reuse adjusting nut.**


PARKING BRAKE SHOE

< REMOVAL AND INSTALLATION >

PARKING BRAKE SHOE

Exploded View

INFOID:0000000014392578



- | | | |
|------------------------|---------------------|------------------------|
| 1. Retainers | 2. Retainer springs | 3. Anti-rattle pins |
| 4. Upper return spring | 5. Adjuster | 6. Parking brake shoes |
| 7. Lower return spring | 8. Toggle lever | 9. Bushing |

 Apply PBC (Poly Butyl Cuprysil) grease or silicone-based grease.

Removal and Installation

INFOID:0000000014392579

REMOVAL

WARNING:

- Clean brakes with a vacuum dust collector to minimize the hazard of airborne particles or other materials.
- Clean dust on disc brake rotor and back plate using a vacuum dust collector. Do not blow with compressed air.

1. Remove rear wheels and tires using a power tool. Refer to [WT-69, "Removal and Installation"](#).
2. Remove disc brake rotor. Refer to [BR-50, "DISC BRAKE ROTOR : Removal and Installation"](#).

CAUTION:


- Parking brake must be in the completely released position.
 - Put matching marks on both disc brake rotor and wheel hub when removing disc brake rotor.
3. If disc brake rotor cannot be removed, remove as follows:
 - a. Secure disc brake rotor with wheel nuts and remove adjuster hole plug.

PARKING BRAKE SHOE

< REMOVAL AND INSTALLATION >

- b. Using a suitable tool, rotate adjuster in direction shown to retract and loosen brake shoe.

- (A) :RH
(B) :LH
⇐ Front



4. Remove anti-rattle pins, retainers, anti-rattle springs, return spring and adjuster spring.

CAUTION:

Do not drop the removed parts.

5. Remove parking brake shoes, adjuster, and toggle lever.

CAUTION:


- The parking brake shoes for the front side are made of different materials from those for the rear side. Do not misidentify them when removing.
- Do not drop the removed parts.

INSTALLATION

Installation is in the reverse order of removal.

- Assemble adjuster so that threaded part is expanded when rotating it in direction shown.

- (A) :RH
(B) :LH
⇐ Front



- Apply PBC (Poly Butyl Cuprysil) grease or silicone-based grease to back plate and brake shoe.

CAUTION:

The parking brake shoes for the front side are made of different materials from those for the rear side. Do not misidentify them when replacing.

- Shorten adjuster by rotating it.
- When assembling the adjuster, apply PBC (Poly Butyl Cuprysil) grease or silicone-based grease to threads and pivot.
- Check parking brake shoe lining and drum inner surface for grease. Wipe off any grease on the surfaces.
- Inspect the parking brake shoes. Refer to [PB-4, "Inspection"](#).

Break-In Procedure

INFOID:0000000014392580

1. Perform parking brake break-in (drag on) operation by driving vehicle under the following conditions:
 - Drive forward.
 - Vehicle speed: Approx. 40 km/h $\pm$ 5 (25 MPH) set (constant and forward)
 - Parking brake operating force: Approx. 250 $\pm$ 20 N (25.5 $\pm$ 2.04 kg-f, 56.2 $\pm$ 4.5 lb-f)
 - Time: Approx. 15 + 5, - 0 seconds

CAUTION:

To prevent lining from getting too hot, allow a cool off period of approximately 5 minutes after every break-in operation.

2. After break-in procedure, check parking brake pedal stroke.

CAUTION:

If it is out of specification, adjust again. Refer to [PB-5, "Adjustment"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Parking Drum Brake

INFOID:0000000014392581

Unit: mm (in)

XD Models	Brake lining	Standard thickness (new)	3.3 (0.130)
		Wear limit thickness	1.0 (0.039)
	Drum (in disc)	Standard inner diameter (new)	227.075 ± 0.075 (8.94 ± 0.003)
		Wear limit of inner diameter	227.7 (8.96)

Unit: mm (in)

Non-XD Models	Brake lining	Standard thickness (new)	3.3 (0.130)
		Wear limit thickness	1.0 (0.039)
	Drum (in disc)	Standard inner diameter (new)	227 ± 0.15 (8.9 ± 0.01)
		Wear limit of inner diameter	228 (8.98)

Parking Drum Brake (Non-XD Models)

INFOID:0000000014727090

Unit: mm (in)

Brake lining	Standard thickness (new)	3.3 (0.130)
	Wear limit thickness	1.0 (0.039)
Drum (in disc)	Standard inner diameter (new)	227.075 ± 0.075 (8.94 ± 0.003)
	Wear limit of inner diameter	227.7 (8.96)

Parking Brake Control

INFOID:0000000014392582

Control type	Foot pedal
Number of notches [under force of 196 N (20.0 kg-f, 44.1 lb-f)]	5 – 7 notches
Number of notches when warning lamp switch comes ON	1 notch
Pedal stroke at 196 N (measured at foot pad along the line of pedal travel)	110 - 121 mm (4.33 - 4.76 in)