

PCS

SECTION

POWER CONTROL SYSTEM

CONTENTS

IPDM E/R	WIRING DIAGRAM	25
PRECAUTION	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	25
PRECAUTIONS	CUMMINS 5.0L	25
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	CUMMINS 5.0L : Wiring Diagram	25
Precaution for Work	VK56VD	29
	VK56VD : Wiring Diagram	30
PREPARATION	DTC/CIRCUIT DIAGNOSIS	35
PREPARATION	U1000 CAN COMM CIRCUIT	35
Special Service Tools	DTC Description	35
	Diagnosis Procedure	36
SYSTEM DESCRIPTION	U1010 CONTROL UNIT (CAN)	37
COMPONENT PARTS	DTC Description	37
Component Parts Location	Diagnosis Procedure	37
SYSTEM	B2098 IGNITION RELAY ON STUCK	38
RELAY CONTROL SYSTEM	DTC Description	38
RELAY CONTROL SYSTEM : System Description	Diagnosis Procedure	38
	B2099 IGNITION RELAY OFF STUCK	40
	DTC Description	40
	Diagnosis Procedure	40
POWER CONSUMPTION CONTROL SYSTEM	POWER SUPPLY AND GROUND CIRCUIT	42
POWER CONSUMPTION CONTROL SYSTEM : System Description	Diagnosis Procedure	42
DIAGNOSIS SYSTEM (IPDM E/R)	UNIT REMOVAL AND INSTALLATION	43
Diagnosis Description	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	43
CONSULT Function (IPDM E/R)	Removal and Installation of IPDM E/R	43
ECU DIAGNOSIS INFORMATION	POWER DISTRIBUTION SYSTEM	
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	PRECAUTION	44
Reference Value		
Fail Safe		
DTC Index		

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	44	Diagnosis Procedure	77
Precaution for Work	44		
PREPARATION	45	U1010 CONTROL UNIT (CAN)	78
PREPARATION	45	DTC Description	78
Special Service Tool	45	Diagnosis Procedure	78
SYSTEM DESCRIPTION	46	B260A IGNITION RELAY	79
COMPONENT PARTS	46	DTC Description	79
Component Parts Location	46	Diagnosis Procedure	79
Push-button Ignition Switch	48		
SYSTEM	49	B261A PUSH-BUTTON IGNITION SWITCH	81
POWER DISTRIBUTION SYSTEM	49	DTC Description	81
POWER DISTRIBUTION SYSTEM : System Description	49	Diagnosis Procedure	81
Fail Safe	50		
DIAGNOSIS SYSTEM (BCM)	51	B26F1 IGNITION RELAY	84
COMMON ITEM	51	DTC Description	84
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	51	Diagnosis Procedure	84
INTELLIGENT KEY	52	B26F2 IGNITION RELAY	86
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)	52	DTC Description	86
		Diagnosis Procedure	86
ECU DIAGNOSIS INFORMATION	56		
BCM, IPDM E/R	56	PUSH-BUTTON IGNITION SWITCH	90
List of ECU Reference	56	Component Function Check	90
		Diagnosis Procedure	90
		Component Inspection	91
WIRING DIAGRAM	57	POWER SUPPLY AND GROUND CIRCUIT	93
POWER DISTRIBUTION SYSTEM	57	BCM	93
CUMMINS 5.0L	57	BCM : Diagnosis Procedure	93
CUMMINS 5.0L : Wiring Diagram	57		
VK56VD	64	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	93
VK56VD : Wiring Diagram	65	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure	93
BASIC INSPECTION	73		
DIAGNOSIS AND REPAIR WORK FLOW	73	SYMPTOM DIAGNOSIS	95
Work Flow	73	PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE	95
PROCEDURE FOR TEMPORARILY DISABLING THE IGNITION BATTERY SAVER SYSTEM	76	Description	95
Description	76	Diagnosis Procedure	95
Work Procedure	76		
DTC/CIRCUIT DIAGNOSIS	77	PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR DOES NOT ILLUMINATE ...	96
U1000 CAN COMM CIRCUIT	77	Diagnosis Procedure	96
DTC Description	77		

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000014388533

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

Precaution for Work

INFOID:0000000014388534

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

< PREPARATION >


PREPARATION

PREPARATION

Special Service Tools

INFOID:000000014388535

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.)	Tool name	Description
— (J-46534) Trim Tool Set	 AWJIA0483ZZ	Removing trim components


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000014388536



A Engine room right side rear (Cummins 5.0L)

1. IPDM E/R


B Engine room right side rear (VK56VD)

2. IPDM E/R

< SYSTEM DESCRIPTION >

SYSTEM**RELAY CONTROL SYSTEM****RELAY CONTROL SYSTEM : System Description**

INFOID:0000000014388537

SYSTEM DIAGRAM**DESCRIPTION**

IPDM E/R controls relays based on input signals from various sensors and from request signals received via CAN communication.

CAUTION:

IPDM E/R integrated relays cannot be removed.

SYSTEM

[IPDM E/R]

< SYSTEM DESCRIPTION >

Relay	Signal Type	Transmitting Unit	Control Part	Reference page
Front fog lamp relay ¹	Front fog lamp request signal	BCM (CAN)	Front fog lamps	EXL-15 EXL-164
Headlamp high relay	High beam request signal	BCM (CAN)	Headlamp high	EXL-11 EXL-159
Headlamp low relay ²	Low beam request signal	BCM (CAN)	Headlamp low	EXL-11
Tail lamp relay	Position light request signal	BCM (CAN)	<ul style="list-style-type: none"> Parking lamps Side marker lamps License plate lamps Tail lamps Trailer tow relay 1 Illumination system 	EXL-13 EXL-162
• Front wiper relay • Front wiper high relay	Front wiper request signal	BCM (CAN)	Front wiper motor	WW-9
A/C relay	A/C request signal	<ul style="list-style-type: none"> BCM (CAN) ECM (CAN) 	A/C compressor	HAC-17 HAC-147
Rear window defogger relay-1	Rear window defogger request signal	BCM (CAN)	Rear window defogger LH	DEF-7
Ignition relay-1	Ignition switch ON signal	Ignition switch	Ignition relay	PCS-38
Starter relay	Ignition switch START signal	<ul style="list-style-type: none"> TCM BCM 	Starter motor	STR-7
Starter control relay				

¹: If equipped

²: Halogen headlamp only

RELAY CONTROL SYSTEM : Fail Safe

INFOID:0000000014388538

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM

Control part	Fail-safe in operation
Headlamp	<ul style="list-style-type: none"> Turns ON the headlamp low relay when the ignition switch is turned ON Turns OFF the headlamp low relay when the ignition switch is turned OFF Headlamp high relay OFF
• Parking lamps • License plate lamps • Tail lamps	<ul style="list-style-type: none"> Turns ON the tail lamp relay when the ignition switch is turned ON Turns OFF the tail lamp relay when the ignition switch is turned OFF
Front wiper	<ul style="list-style-type: none"> The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.
Rear window defogger (if equipped)	Rear window defogger relay OFF
A/C compressor	A/C relay OFF
Front fog lamps (if equipped)	Front fog lamp relay OFF

IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

SYSTEM

[IPDM E/R]

< SYSTEM DESCRIPTION >

Ignition switch	Ignition relay	Tail lamp relay
ON	ON	—
OFF	OFF	—

NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

Ignition switch	Front wiper switch	Auto stop signal
ON	OFF	Front wiper stop position signal cannot be input 10 seconds.
	ON	The signal does not change for 10 seconds.

NOTE:

This operation status can be confirmed on the IPDM E/R “DATA MONITOR” that displays “Block” for the item “WIP PROT” while the wiper is stopped.

STARTER MOTOR PROTECTION FUNCTION


IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : System Description

INFOID:000000014388539

SYSTEM DIAGRAM



DESCRIPTION

Outline

- IPDM E/R incorporates a power consumption control function that reduces the power consumption according to the vehicle status.
- IPDM E/R changes its status (control mode) with the sleep wake up signal received from BCM via CAN communication.

Normal mode (wake-up)

- CAN communication is normally performed with other control units.
- Individual unit control by IPDM E/R is normally performed.

Low power consumption mode (sleep)

- Low power consumption control is active.
- CAN transmission is stopped.

< SYSTEM DESCRIPTION >

Sleep Mode Activation

- IPDM E/R judges that the sleep-ready conditions are fulfilled when the ignition switch is OFF and none of the conditions below are present. Then it transmits a sleep-ready signal (ready) to BCM via CAN communication.
 - Front wiper fail-safe operation
 - Outputting signals to actuators
 - Switches or relays operating
 - Auto active test is starting
 - Emergency OFF
 - Output requests are being received from control units via CAN communication.
- IPDM E/R stops CAN communication and enters the low power consumption mode when it receives a sleep wake up signal (sleep) from BCM and the sleep-ready conditions are fulfilled.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R)**Diagnosis Description**

INFOID:000000014388540

AUTO ACTIVE TEST**Description**

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation:

- Rear window defogger
- Front wipers (HI, LO)
- Front fog lamps (if equipped)
- Tail, license and parking lamps
- Daytime running lamps (if equipped)
- Headlamps (HI, LO)
- A/C compressor (magnetic clutch)

Operation Procedure

1. Close the hood and front door RH, and lift the wiper arms from the windshield (to prevent windshield damage due to wiper operation).
- NOTE:**
When auto active test is performed with hood opened, sprinkle water on windshield before hand.
2. Turn ignition switch OFF.
3. Turn the ignition switch ON and, within 20 seconds, press the front door switch LH 10 times. Then turn the ignition switch OFF.
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.

CAUTION:


- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-98, "Component Function Check"](#).
- Do not start the engine.

Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 6 steps are repeated 3 times.

Operation sequence	Inspection Location	Operation
1	Rear window defogger	10 seconds
2	Front wipers	HI for 5 seconds → LO for 5 seconds
3	Front fog lamps (if equipped), tail, license and parking lamps and daytime running lamps (if equipped)	10 seconds
4	Headlamps	LO for 10 seconds → HI on-off for 5 seconds
5	A/C compressor (magnetic clutch)	ON ⇔ OFF 5 times

Concept of auto active test



*: If equipped

- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger (if equipped) operate?	YES	BCM signal input circuit
		NO	CAN communication signal between BCM and IPDM E/R
Any of the following components do not operate: • Front wipers (HI, LO) • Front fog lamps (if equipped) • Tail lamps • License plate lamps • Parking lamps • Daytime running lamps (if equipped) • Headlamps (HI, LO)	Perform auto active test. Does the applicable system operate?	YES	BCM signal input system
		NO	<ul style="list-style-type: none"> Lamp or front wiper motor malfunction Lamp or front wiper motor ground circuit Harness or connector between IPDM E/R and applicable system IPDM E/R (integrated relay malfunction)
A/C compressor does not operate	Perform auto active test. Does the A/C compressor operate?	YES	<ul style="list-style-type: none"> BCM signal input circuit CAN communication signal between BCM and ECM CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> Magnetic clutch malfunction Harness or connector between IPDM E/R and magnetic clutch IPDM E/R (integrated relay malfunction)

CONSULT Function (IPDM E/R)

INFOID:0000000014388541

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R:

DIAGNOSIS SYSTEM (IPDM E/R)

[IPDM E/R]

< SYSTEM DESCRIPTION >

Direct Diagnostic Mode	Description
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SELF DIAGNOSTIC RESULT

Refer to [PCS-23, "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line.
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
INTER/NP SW [On/Off]		Indicates condition of AT shift position.
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line.
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line.
ST/INHI RLY [Off/ ST /INHI]		Indicates condition of starter relay and starter control relay.
DETENT SW [On/Off]		Indicates condition of AT shift selector (park position switch).
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch.
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line
HOOD SW 2 [On/Off]		Indicates condition of hood switch 2.

ACTIVE TEST

Test item	Description
REAR DEFOGGER	This test is able to check rear defogger operation [On/Off].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].

DIAGNOSIS SYSTEM (IPDM E/R)

[IPDM E/R]

< SYSTEM DESCRIPTION >

Test item	Description
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].
HORN	This test is able to check horn operation [On].

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

ECU DIAGNOSIS INFORMATION

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000014388542

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status	
A/C COMP REQ	A/C switch OFF	Off	
	A/C switch ON	On	
TAIL&CLR REQ	Lighting switch OFF	Off	
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)	On	
HL LO REQ	Lighting switch OFF	Off	
	Lighting switch 2ND HI or AUTO (Light is illuminated)	On	
HL HI REQ	Lighting switch OFF	Off	
	Lighting switch HI	On	
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF	Off
		• Front fog lamp switch ON • Daytime light activated (Canada only)	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC	Off	
	Ignition switch ON	On	
IGN RLY	Ignition switch OFF or ACC	Off	
	Ignition switch ON	On	
PUSH SW	Release the push-button ignition switch	Off	
	Press the push-button ignition switch	On	
INTER/NP SW	Ignition switch ON	AT selector lever in any position other than P or N	Off
		AT selector lever in P or N position	On
ST RLY CONT	Ignition switch ON	Off	
	At engine cranking	On	
IHBT RLY -REQ	Ignition switch ON	Off	
	At engine cranking	On	

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Monitor Item	Condition		Value/Status
ST/INHI RLY	Ignition switch ON		Off
	At engine cranking		ST →INHI
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF		UNKWN
DETENT SW	Ignition switch ON	AT selector lever in any position other than P	Off
		AT selector lever in P position	On
DTRL REQ	Not operated		Off
	Daytime Running Lights ON		On
HOOD SW	Hood closed		Off
	Hood open		On
THFT HRN REQ	Not operated		Off
	<ul style="list-style-type: none"> Panic alarm is activated Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM 		On
HORN CHIRP	Not operated		Off
	Door locking with keyfob (horn chirp mode)		On
HOOD SW 2	Hood closed		Off
	Hood open		On

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O


P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

[IPDM E/R]

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



PHYSICAL VALUES – WITH CUMMINS 5.0L

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
1 (B/Y)	Ground	Fusible link IPDM E/R	Input	Ignition switch OFF
2 (R)	Ground	Fusible link main	Input	Ignition switch OFF
4 (B/R)	Ground	Transmission range switch signal	Input	AT selector lever in any position other than P or N position
				0 V
5 (L/W)	Ground	Headlamp HI RH	Output	AT selector lever in P or N position
				Battery voltage
5 (L/W)	Ground	Headlamp HI RH	Output	• Lighting switch HI • Lighting switch PASS
				Battery voltage
				Lighting switch OFF
				0 V

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K L PCS N O P	
	Signal name	Input/ Output				
6 (G)	Ground	Headlamp HI LH	Output	Ignition switch ON	• Lighting switch HI • Lighting switch PASS	Battery voltage
					Lighting switch OFF	0 V
7 (L)	Ground	Headlamp LO LH	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
8 (R/Y)	Ground	Headlamp LO RH	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 2ND	Battery voltage
9 (G/W)	Ground	Front fog lamp LH	Output	Ignition switch ON	Fog lamp switch OFF	0 V
					Fog lamp switch ON	Battery voltage
11 (P)	Ground	Actuator power relay output	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)		0 V
				• Ignition switch ON • Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		Battery voltage
12 (W/R)	Ground	Front fog lamp RH	Output	Ignition switch ON	Fog lamp switch OFF	0 V
					Fog lamp switch ON	Battery voltage
13 (Y/R)	Ground	Transmission control module	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
14 (G)	Ground	Reverse lamps	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
15 (GR)	Ground	ABS actuator and electric unit (control unit)	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
16 (G)	Ground	Actuator power relay control	Output	Ignition switch ON → OFF		0 - 1.0 V ↓ Battery voltage ↓ 0 V
				Ignition switch ON		0 - 1.0 V
17 (L/W)	Ground	ECM ignition switch	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
19 (W/R)	Ground	Starter motor	Output	At engine cranking		5 V
20 (L)	Ground	Fusible link ignition switch	Input	Ignition switch OFF		Battery voltage
25 (BR)	Ground	ECM battery	Output	Ignition switch OFF		Battery voltage
27 (R/L)	Ground	Parking lamp RH	Output	Ignition switch ON	Lighting switch 1ST	Battery voltage
					Lighting switch OFF	0 V
28 (R/L)	Ground	Tail and license plate lamps	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
29 (Y)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch HI	Battery voltage

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
31 (L)	Ground	ECM relay control	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)
				• Ignition switch ON • Ignition switch OFF (More than a few seconds after turning ignition switch OFF)
33 (R/L)	Ground	Parking lamp LH	Output	Ignition switch ON Lighting switch 1ST
				Lighting switch OFF 0 V
34 (R/W)	Ground	Illumination	Output	Ignition switch ON Lighting switch OFF
				Lighting switch 1ST Battery voltage
35 (BR)	Ground	Front wiper LO	Output	Ignition switch ON Front wiper switch OFF
				Front wiper switch LO Battery voltage
39 (L/Y)	Ground	Wiper autostop	Input	Ignition switch ON Front wiper stop position
				Any position other than front wiper stop position 0 V
40 (P)	—	CAN-low	Input/ Output	—
41 (L)	—	CAN-high	Input/ Output	—
42 (BR)	Ground	Daytime running lamps relay	Output	Ignition switch ON Daytime running light system active
				Ignition switch ON Daytime running light system inactive 0 V
44 (W/B)	Ground	Starter control	Input	Ignition switch ON AT selector lever in any position other than P or N
				AT selector lever P or N Battery voltage
45 (GR)	Ground	Fuel pump relay control	Output	• Approximately 1 second after turning the ignition switch ON • Engine running
				Approximately 1 second or more after turning the ignition switch ON 0 - 1.0 V Battery voltage
46 (Y)	Ground	Hood switch	Input	Ignition switch ON Hood closed
				Hood open Battery voltage
48 (R/W)	Ground	Horn relay	Input	The horn is deactivated
				The horn is activated Battery voltage 0 V
49 (Y/B)	Ground	A/C compressor	Output	Engine running A/C compressor OFF
				A/C compressor ON (A/C compressor is operating) Battery voltage
50 (BR)	Ground	Trailer tow relay	Output	Ignition switch OFF Battery voltage
52 (B)	Ground	Ground (signal)	—	Ignition switch ON 0 V
57 (W/B)	Ground	Rear window defogger relay	Output	Ignition switch ON Rear defogger switch ON
				Rear defogger switch OFF 0V

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K L PCS N O P
	Signal name	Input/ Output			
58 (BR)	Ground	Lift pump	Output	Approximately 1 second or more after turning the ignition switch ON	0 V
				<ul style="list-style-type: none"> Approximately 1 second after turning the ignition switch ON Engine running 	Battery voltage
62 (B)	Ground	Ground (Power)	—	Ignition switch ON	0 V
64 (R)	Ground	Park position switch	Input	Press the AT selector button (AT selector lever P)	Battery voltage
				<ul style="list-style-type: none"> AT selector lever in any position other than P Release the AT selector button (AT selector lever P) 	0 V
66 (P)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch	0 V
				Release the push-button ignition switch	Battery voltage
68 (L)	Ground	Ignition signal*	Input	Ignition switch OFF or ACC	Battery voltage
				Ignition switch ON	0 V
71 (SB)	Ground	Hood switch 2	Input	Ignition switch ON	0 V
				Hood closed	Battery voltage
				Hood open	

*: Ignition battery saver logic turns OFF the IPDM E/R and BCM if the ignition is ON for 30 minutes with the engine OFF.

PHYSICAL VALUES – WITH VK56VD

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K L PCS N O P
	Signal name	Input/ Output			
1 (B/Y)	Ground	Fusible link IPDM E/R	Input	Ignition switch OFF	Battery voltage
2 (R)	Ground	Fusible link main	Input	Ignition switch OFF	Battery voltage
4 (B/R)	Ground	Transmission range switch signal	Input	Ignition switch ON	0 V
				AT selector lever in P or N position	Battery voltage
5 (L/W)	Ground	Headlamp HI RH	Output	Ignition switch ON	<ul style="list-style-type: none"> Lighting switch HI Lighting switch PASS
				Lighting switch OFF	0 V
6 (G)	Ground	Headlamp HI LH	Output	Ignition switch ON	<ul style="list-style-type: none"> Lighting switch HI Lighting switch PASS
				Lighting switch OFF	0 V
7 (L)	Ground	Headlamp LO LH	Output	Ignition switch ON	<ul style="list-style-type: none"> Lighting switch OFF Lighting switch 2ND
				Lighting switch 2ND	Battery voltage
8 (R/Y)	Ground	Headlamp LO RH	Output	Ignition switch ON	<ul style="list-style-type: none"> Lighting switch OFF Lighting switch 2ND
				Lighting switch 2ND	Battery voltage
9 (G/W)	Ground	Front fog lamp LH	Output	Ignition switch ON	<ul style="list-style-type: none"> Fog lamp switch OFF Fog lamp switch ON
				Fog lamp switch ON	Battery voltage

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >




[IPDM E/R]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
+	-			
11 (O)	Ground	Electronic throttle control	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)
				• Ignition switch ON • Ignition switch OFF (More than a few seconds after turning ignition switch OFF)
12 (W/R)	Ground	Front fog lamp RH	Output	Ignition switch ON Fog lamp switch OFF Fog lamp switch ON
13 (Y/R)	Ground	Transmission control module	Output	Ignition switch OFF
				Ignition switch ON
14 (G)	Ground	Reverse lamps	Output	Ignition switch OFF
				Ignition switch ON
15 (GR)	Ground	ABS actuator and electric unit (control unit)	Output	Ignition switch OFF
				Ignition switch ON
16 (V/R)	Ground	Throttle control motor relay control	Output	Ignition switch ON → OFF
				Ignition switch ON 0 - 1.0 V ↓ Battery voltage ↓ 0 V
17 (W)	Ground	ECM ignition switch	Output	Ignition switch OFF
				Ignition switch ON
19 (W/R)	Ground	Starter motor	Output	At engine cranking
20 (L)	Ground	Fusible link ignition switch	Input	Ignition switch OFF
25 (W)	Ground	ECM battery	Output	Ignition switch OFF
26 (V)	Ground	O2 sensor	Output	Ignition switch OFF
27 (R/L)	Ground	Parking lamp RH	Output	Ignition switch ON Lighting switch 1ST
				Lighting switch OFF 0 V
28 (R/L)	Ground	Tail and license plate lamps	Output	Ignition switch ON Lighting switch OFF
				Lighting switch 1ST Battery voltage
29 (Y)	Ground	Front wiper HI	Output	Ignition switch ON Front wiper switch OFF
				Front wiper switch HI Battery voltage
31 (L)	Ground	ECM relay control	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)
				• Ignition switch ON • Ignition switch OFF (More than a few seconds after turning ignition switch OFF) 0 - 1.5 V
32 (L)	Ground	ECM power supply	Output	Ignition switch OFF
33 (R/L)	Ground	Parking lamp LH	Output	Ignition switch ON Lighting switch 1ST
				Lighting switch OFF 0 V

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >


[IPDM E/R]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	A B C D E F G H I J K L M N O P	
	Signal name	Input/ Output				
34 (R/W)	Ground	Illumination	Output	Ignition switch ON	Lighting switch OFF 0 V	
				Ignition switch ON	Lighting switch 1ST Battery voltage	
35 (BR)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF 0 V	
				Ignition switch ON	Front wiper switch LO Battery voltage	
39 (L/Y)	Ground	Wiper autostop	Input	Ignition switch ON	Front wiper stop position 0 V	
				Ignition switch ON	Any position other than front wiper stop position Battery voltage	
40 (P)	—	CAN-low	Input/ Output	—	—	
41 (L)	—	CAN-high	Input/ Output	—	—	
42 (BR)	Ground	Daytime running lamps relay	Output	Ignition switch ON	Daytime running light system active Battery voltage	
				Ignition switch ON	Daytime running light system inactive 0 V	
44 (W/B)	Ground	Starter control	Input	Ignition switch ON	AT selector lever in any position other than P or N 0 V	
				Ignition switch ON	AT selector lever P or N Battery voltage	
45 (GR)	Ground	Fuel pump relay control	Output	• Approximately 1 second after turning the ignition switch ON • Engine running	0 - 1.0 V	
				Approximately 1 second or more after turning the ignition switch ON	Battery voltage	
46 (Y)	Ground	Hood switch	Input	Ignition switch ON	Hood closed 0 V	
				Ignition switch ON	Hood open Battery voltage	
47 (Y)	Ground	Power generation command signal	Output	Ignition switch ON	 6.3 V	PCS N O P
				40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE"	 3.8 V	
				40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE"	 1.4 V	

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
48 (R/W)	Ground	Horn relay	Input	The horn is deactivated
				0 V
49 (GR/R)	Ground	A/C compressor	Output	A/C compressor OFF
				A/C compressor ON (A/C compressor is operating)
50 (BR)	Ground	Trailer tow relay	Output	Battery voltage
52 (B)	Ground	Ground (signal)	—	0 V
57 (W/B)	Ground	Rear window defogger relay	Output	Ignition switch ON
				Rear defogger switch ON
58 (B/Y)	Ground	Lift pump	Output	Approximately 1 second or more after turning the ignition switch ON
				• Approximately 1 second after turning the ignition switch ON • Engine running
62 (B)	Ground	Ground (Power)	—	Battery voltage
64 (R)	Ground	Park position switch	Input	Press the AT selector button (AT selector lever P)
				• AT selector lever in any position other than P • Release the AT selector button (AT selector lever P)
66 (P)	Ground	Push-button ignition switch	Input	0 V
				Battery voltage
68 (L)	Ground	Ignition signal*	Input	Ignition switch OFF or ACC
				0 V
71 (SB)	Ground	Hood switch 2	Input	Ignition switch ON
				Hood closed
72 (W)	Ground	Cooling fan control	Output	Hood open
				Battery voltage
				OFF
				ACC
				ON
			Engine running	
				 2. 5 V

*: Ignition battery saver logic turns OFF the IPDM E/R and BCM if the ignition is ON for 30 minutes with the engine OFF.

Fail Safe

INFOID:000000014388543

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

If No CAN Communication Is Available With BCM

Control part	Fail-safe in operation
Headlamp	<ul style="list-style-type: none"> Turns ON the headlamp low relay when the ignition switch is turned ON Turns OFF the headlamp low relay when the ignition switch is turned OFF Headlamp high relay OFF
• Parking lamps • License plate lamps • Tail lamps	<ul style="list-style-type: none"> Turns ON the tail lamp relay when the ignition switch is turned ON Turns OFF the tail lamp relay when the ignition switch is turned OFF
Front wiper	<ul style="list-style-type: none"> The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.
Rear window defogger (if equipped)	Rear window defogger relay OFF
A/C compressor	A/C relay OFF
Front fog lamps (if equipped)	Front fog lamp relay OFF

IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Ignition switch	Ignition relay	Tail lamp relay
ON	ON	—
OFF	OFF	—

NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

Ignition switch	Front wiper switch	Auto stop signal
ON	OFF	Front wiper stop position signal cannot be input 10 seconds.
	ON	The signal does not change for 10 seconds.

NOTE:

This operation status can be confirmed on the IPDM E/R “DATA MONITOR” that displays “Block” for the item “WIP PROT” while the wiper is stopped.

STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

DTC Index

INFOID:000000014388544

CONSULT display	Fail-safe	TIME ^{NOTE}	Refer to
No DTC is detected. Further testing may be required.	—	—	—
U1000: CAN COMM CIRCUIT	×	CRNT	1 – 39
U1010: CONTROL UNIT (CAN)	×	CRNT	1 – 39
B2098: IGN RELAY ON	×	CRNT	1 – 39

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

CONSULT display	Fail-safe	TIME ^{NOTE}		Refer to
B2099: IGN RELAY OFF	—	CRNT	1 – 39	PCS-40
B210B: PNP RELAY ON	—	CRNT	1 – 39	SEC-127
B210C: PNP RELAY OFF	—	CRNT	1 – 39	SEC-128
B210D: STARTER RELAY ON	—	CRNT	1 – 39	SEC-129
B210E: STARTER RELAY OFF	—	CRNT	1 – 39	SEC-131
B210F: INTRLCK PNP SW ON	—	CRNT	1 – 39	SEC-133
B2110: INTRLCK PNP SW OFF	—	CRNT	1 – 39	SEC-136

NOTE:

The details of TIME display are as follows.

- CRNT: The malfunctions that are detected now
- 1 - 39: The number is indicated when it is normal at present and a malfunction was detected in the past. It increases like $0 \rightarrow 1 \rightarrow 2 \dots 38 \rightarrow 39$ after returning to the normal condition whenever IGN OFF \rightarrow ON. It is fixed to 39 until the self-diagnosis results are erased if it is over 39. It returns to 0 when a malfunction is detected again in the process.

WIRING DIAGRAM


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

CUMMINS 5.0L

CUMMINS 5.0L : Wiring Diagram

INFOID:0000000014388545

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) - WITH Cummins 5.0L




AAMWA2150GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

[IPDM E/R]




AAMWA2151GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

[IPDM E/R]

< WIRING DIAGRAM >



AAMWA2152GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

[IPDM E/R]

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) CONNECTORS - WITH Cummins 5.0L

Connector No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
EE27	4	R	1	BATT		16	W/R	ETC RLY CONT - (WITH VKS6V0)
Connector Name						17	L/W	IGN COIL - (WITH CUMMINS 5.0L)
FUSIBLE LINK BOX LH (BATTERY)						17	W	IGN COIL - (WITH VKS6V0)
Connector No.						18	-	-
Connector Name								
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)								
Connector Type	L02FBR-MC							
Connector Color	BROWN							
								
EE18	4	R	1	BATT		16	W/R	ETC RLY CONT - (WITH VKS6V0)
Connector Name						17	L/W	IGN COIL - (WITH CUMMINS 5.0L)
FUSIBLE LINK BOX LH (BATTERY)						17	W	IGN COIL - (WITH VKS6V0)
Connector No.						18	-	-
Connector Name								
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)								
Connector Type	L02FBR-MC							
Connector Color	BLACK							
								
EE19	4	R	1	BATT		1	B/Y	F/1,MAIN
Connector Name						2	R	F/1,MAIN
FUSIBLE LINK BOX RH (BATTERY)								
Connector Type	L02FBR-MC							
Connector Color	BROWN							
								
EE21	9	7	6	□	5	4	3	
Connector Name								
FUSIBLE LINK BOX RH (BATTERY)								
Connector Type	L02FBR-MC							
Connector Color	BROWN							
								
EE22	9	8	7	6	□	5	4	3
Connector Name								
FUSIBLE LINK BOX RH (BATTERY)								
Connector Type	L02FBR-MC							
Connector Color	GRAY							
								
EE2	9	8	7	6	□	5	4	3
Connector Name								
FUSIBLE LINK BOX RH (BATTERY)								
Connector Type	L02FBR-MC							
Connector Color	GRAY							
								
EE26	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE27	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE28	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE29	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE30	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE31	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE32	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE33	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE34	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE35	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE36	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE37	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE38	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE39	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE40	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE41	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE42	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE43	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE44	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE45	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE46	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE47	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE48	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE49	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE50	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE51	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE52	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector Type	NS12FBR-CS							
Connector Color	BROWN							
								
EE53	29	28	27	26	25			
Connector Name								
FR FOG/L RH								
Connector								



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

[IPDM E/R]

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) CONNECTORS - WITH Cummins 5.0L

Connector No.	E123	Connector No.	E130
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS08FBR-CS	Connector Type	TH10FB-NH
Connector Color	BROWN	Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name	Signal Name
49	Y/B	A/C COMP - (WITH CUMMINS 5.0L)	-
49	GR/R	A/C COMP - (WITH VK56VD)	-
50	BR	TRAILER TOW	R
51	-	-	DETENT SW
52	B	S-ND	-
53	-	-	PUSH START SW
54	-	-	-
55	-	-	IGN SIGNAL
56	-	-	-
63	-	-	-
64	-	-	-
65	-	-	-
66	P	-	-
67	-	-	-
68	L	-	-
69	-	-	-
70	-	-	-
71	SB	-	-
72	W	HOOD SW2	E-CTRL - (WITH VK56VD)



Terminal No.	Color of Wire	Signal Name	Signal Name
57	W/B	RR DEF	-
58	B/Y	FUEL PUMP - (WITH VK56VD)	-
58	BR	FUEL PUMP - (WITH CUMMINS 5.0L)	-
59	-	-	-
60	-	-	-
61	-	-	-
62	B	P GND	-



Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M06FB-LC
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name	Signal Name
57	W/B	RR DEF	-
58	B/Y	FUEL PUMP - (WITH VK56VD)	-
58	BR	FUEL PUMP - (WITH CUMMINS 5.0L)	-
59	-	-	-
60	-	-	-
61	-	-	-
62	B	P GND	-

AAMIA5010GB

VK56VD

A

B

C

D

E

F

G

H

I

K

L

PCS

Z

O

P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


< WIRING DIAGRAM >

[IPDM E/R]

VK56VD : Wiring Diagram

INFOID:000000014388546

IPDME/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) - WITH VK56VD




AAMWA2333GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

[IPDM E/R]

- CAN COMMUNICATION LINE FOR DIAGNOSIS
- HO : WITH HOOD SWITCH
- HV : WITH HALOGEN HEADLAMPS AND DAYTIME RUNNING LIGHT SYSTEM
- IL : WITH ACTIVE GRILLE SHUTTER
- OG : WITH INVERTER SYSTEM
- V2 : WITH VK56VD AND WITH DRIVER ASSISTANCE SYSTEM
- V3 : WITH VK56VD AND WITHOUT DRIVER ASSISTANCE SYSTEM




AAMWA2334GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

[IPDM E/R]

< WIRING DIAGRAM >

IPDM E/R
(INTELLIGENT
POWER
DISTRIBUTION
MODULE
ENGINE
ROOM)
(E119,
E120,
E121,
E122,
E123,
E124,
E125)



AAMWA2335GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

[IPDM E/R]

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) CONNECTORS - WITH VK56VD

Connector No.	E118	17	W	Ign coil - (WITH VK56VD)	35	BR	FR WIPER LO	52	B	S-GND
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	18	-	-	36	-	-	53	-	-
Connector Type	L02FB-MC							54	-	-
Connector Color	BLACK							55	-	-
								56	-	-
Connector No.	E120									
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)									
Connector Type	M06FW-LC									
Connector Color	WHITE									
Terminal No.	Color of Wire	Signal Name								
1	BR	F/L USM								
2	R	F/L MAIN								
Connector No.	E119	19	WR	STARTER MOTOR	37	-	-			
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	20	L	F/L IGN SW	38	-	-			
Connector Type	NS16FW-CS	21	-	-	39	LY	WIPER AUTO STOP SW	57	WB	RR DEF
Connector Color	WHITE	22	-	-	40	P	CAN-L	58	BR	FUEL PUMP - (WITH CUMMINS 5.0L)
		23	-	-	41	L	CAN-H	59	BY	FUEL PUMP - (WITH VK56VD)
Terminal No.	Color of Wire	Signal Name								
24	-	-			42	BR	DTBL R/L Y	60	-	-
					43	-	-	61	-	-
Connector No.	E121	44	WB	START CONT	62	-	-	62	B	P GND
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	45	GR	FUEL R/L CONT						
Connector Type	NS12FB-R-CS	46	Y	HOOD SW						
Connector Color	BROWN	47	Y	ALT C - (WITH VK56VD)						
		48	R/W	HORN R/L CONT						
Connector No.	E123									
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)									
Connector Type	NS08FB-R-CS									
Connector Color	BROWN									
Terminal No.	Color of Wire	Signal Name								
3	-	-			29	28	27	26	25	
4	BR	NP SW			36	35	34	33	32	31 30
5	L/W	H/LAMP HI RH								
6	G	H/LAMP HI LH								
7	L	H/LAMP LO LH								
8	RY	H/LAMP LO RH								
9	GR/W	FR FG/LH								
10	-	-								
11	P	ETC VB - (WITH CUMMINS 5.0L)								
11	O	ETC VB - (WITH VK56VD)								
12	WR	FR FG/LH								
13	YR	ANT ECUG IGN								
14	G	REVERSE LAMP GN								
15	GR	ABS ECUG								
16	G	ETC RLY CONT - (WITH CUMMINS 5.0L)								
16	V/R	ETC RLY CONT - (WITH VK56VD)								
17	L/W	IGN COIL - (WITH CUMMINS 5.0L)								
Terminal No.	Color of Wire	Signal Name								
25	BR	ECM VB - (WITH CUMMINS 5.0L)								
25	W	ECM VB - (WITH VK56VD)								
26	V	O2 SENS - (WITH VK56VD)								
27	R/L	PARKING RH								
28	R/L	TAIL 1								
29	Y	FR WIPER HI								
30	-	-								
31	L	ECM RLY CONT								
32	L	ECM BAT - (WITH VK56VD)								
33	R/L	PARKING LH								
34	R/W	TAIL 2								


AAMIA5011GB

A Z Y X C G T I M P S R D E F B C O N N E C T O R S

PCS

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) CONNECTORS - WITH VK56VD

Connector No.	E130	Connector No.	E148
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Name	FUSIBLE LINK BOX (BATTERY) (WITH VK56VD)
Connector Type	TH105FB-NH	Connector Type	L02FG1-MC
Connector Color	BLACK	Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
63	-	-	3	W	BATTERY
64	R	DETENT SW	4	R	BATTERY
65	-	-			
66	P	PUSH START SW			
67	-	-			
68	L	IGN SIGNAL			
69	-	-			
70	-	-			
71	SB	HOOD SW2			
72	W	E-CPLG - (WITH VK56VD)			



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
66	-	-	1	B/L	BATTERY
67	-	-	2	B/Y	BATTERY
68	-	-			
69	-	-			
70	-	-			
71	SB	HOOD SW2			
72	W	E-CPLG - (WITH VK56VD)			



Connector No.	Connector Name	Connector Type	Connector Color
	FUSIBLE LINK BOX (BATTERY) (WITH VK56VD)	L02FBR-MC	



Terminal No.	Color of Wire	Signal Name
1	B/L	BATTERY
2	B/Y	BATTERY

AAMIA5012GB

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

DTC Description

INFOID:000000014388547

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-74, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
U1000	CAN COMM CIRCUIT (CAN communication circuit)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	2 seconds or more

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

Control part	Fail-safe operation
A/C compressor	A/C relay OFF

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> Turns ON the headlamp low relay when the ignition switch is turned ON. Turns OFF the headlamp low relay when the ignition switch is turned OFF. Headlamp high relay OFF
<ul style="list-style-type: none"> Parking lamp License plate lamp Illumination Tail lamp Side marker lamp 	<ul style="list-style-type: none"> Turns ON the tail lamp relay when the ignition switch is turned ON. Turns OFF the tail lamp relay when the ignition switch is turned OFF.
Front wiper motor	<ul style="list-style-type: none"> The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating. Returns wiper automatically to stop position when ignition switch is turned ON if fail-safe control is activated while front wiper motor is operated and the wiper is in any position other than the stop position. The status is held at service position if the fail-safe control is activated while the service position function is operating.
Front fog lamp	Front fog lamp relay OFF
Horn	Horn relay OFF
Ignition relay-1	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF

< DTC/CIRCUIT DIAGNOSIS >

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ CONSULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" mode of "IPDM E/R".
3. Check DTC.

Is DTC "U1000" displayed?

YES >> Refer to [PCS-36, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014388548

1. PERFORM SELF DIAGNOSIS

④ CONSULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" mode of "IPDM E/R".
3. Check DTC.

Is DTC "U1000" displayed?

YES >> Refer to [LAN-53, "Trouble Diagnosis Flow Chart"](#).

NO >> Refer to [GI-47, "Intermittent Incident"](#).

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)**DTC Description**

INFOID:000000014388549

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
U1010	CONTROL UNIT(CAN) (Control unit)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	2 seconds or more

POSSIBLE CAUSE

- IPDM E/R

FAIL-SAFE

—

DTC CONFIRMATION PROCEDURE**1. PERFORM DTC CONFIRMATION PROCEDURE****④ CONSULT**

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" mode of "IPDM E/R".
3. Check DTC.

Is DTC "U1000" displayed?YES >> Refer to [PCS-37, "Diagnosis Procedure"](#).NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014388550

1. REPLACE IPDM E/RReplace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

>> Inspection End.

PCS

N

O

P

B2098 IGNITION RELAY ON STUCK

DTC Description

INFOID:0000000014388551

- IPDM E/R operates the ignition relay when it receives an ignition switch ON signal from BCM via CAN communication.
- Turn the ignition relay OFF by pressing the push-button ignition switch once when the vehicle speed is 4 km/h (2.5 MPH) or less.
- Turn the ignition relay OFF with the following operation when the vehicle speed is more than 4 km/h (2.5 MPH) or when an abnormal condition occurs in CAN communication from the combination meter (Emergency OFF)
 - Press and hold the push-button ignition switch for 2 seconds or more.
 - Press the push-button ignition switch 3 times within 1.5 seconds.

NOTE:

The ignition relay does not turn ON for 3 seconds after emergency OFF even if the push-button ignition switch is pressed.

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2098	IGN RELAY ON (Ignition relay ON circuit)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	1 second or more

Possible Cause

- IPDM E/R.
- Harness or connectors (ignition relay circuit short).

FAIL-SAFE

Turns ON the tail lamp relay for 10 minutes.

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

 CONSULT

- Turn ignition switch ON.
- Turn ignition switch OFF and wait 1 second or more.
- Check DTC in "Self Diagnostic Result" mode of "IPDM E/R".

Is DTC detected?

YES >> Refer to [PCS-38, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000014388552

Regarding Wiring Diagram information, refer to [PCS-25, "CUMMINS 5.0L : Wiring Diagram"](#).

1. SELF DIAGNOSTIC RESULT

 CONSULT

- Check "Self Diagnostic Result" mode of "IPDM E/R".

What is the display history of DTC "B2098"?

"CRNT">> GO TO 2.

"PAST" >> GO TO 5.

2. CHECK IGNITION RELAY CONTROL CIRCUIT VOLTAGE 1

B2098 IGNITION RELAY ON STUCK

[IPDM E/R]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch ON.
2. Check voltage between IPDM E/R harness connector E130 and ground.

Connector	Terminal	(-)	Voltage (Approx.)
E130	68	Ground	0 V

Is the inspection result normal?

YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK IGNITION RELAY CONTROL CIRCUIT VOLTAGE 2

1. Disconnect IPDM E/R connector.
2. Turn ignition switch ON.
3. Check voltage between IPDM E/R harness connector E130 and ground.

Connector	Terminal	(-)	Voltage (Approx.)
E130	68	Ground	0 V

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).
NO >> Repair or replace harness or connectors.

4. CHECK IGNITION RELAY CONTROL CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E130 and ground.

Connector	Terminal	Ground	Continuity
E130	68		No

Is the inspection result normal?

YES >> Perform the diagnosis procedure for DTC B26F2. Refer to [PCS-86, "DTC Description"](#).
NO >> Repair or replace harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

PCS

< DTC/CIRCUIT DIAGNOSIS >

B2099 IGNITION RELAY OFF STUCK

DTC Description

INFOID:0000000014388553

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2099	IGN RELAY OFF (Ignition relay OFF circuit)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	1 second or more

NOTE:

When IPDM E/R power supply voltage is low (Approx. 7 - 8 V for about 1 second), the "DTC: B2099" may be detected.

POSSIBLE CAUSE

- IPDM E/R
- Fuse
- Battery

FAIL-SAFE

—

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" mode of "IPDM E/R".
3. Check DTC.

Is DTC detected?

YES >> Refer to [PCS-40, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000014388554

Regarding Wiring Diagram information, refer to [PCS-25, "CUMMINS 5.0L : Wiring Diagram"](#).

1. CHECK FUSE

Check that all of the fuses installed on the downstream of the contact point side circuit of the ignition relay in IPDM E/R are not blown.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after replacing the affected circuit if a fuse is blown.

2. CHECK IGNITION RELAY CONTROL CIRCUIT VOLTAGE

1. Turn ignition switch ON
2. Check voltage between IPDM E/R harness connector E130 and ground.

B2099 IGNITION RELAY OFF STUCK

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

(+)		(-)	Voltage (Approx.)
IPDM E/R			
Connector	Terminal		
E130	68	Ground	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

A

3. CHECK BATTERY VOLTAGE

Check battery voltage.

Which is the measurement result?

More than 12.4 V>>GO TO 4.

Less than 12.4 V>>Perform battery inspection. Refer to [PG-175, "How to Handle Battery"](#).

C

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

D

>> Inspection End.

E

F

G

H

I

J

K

L

PCS

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000014388555

Regarding Wiring Diagram information, refer to [PCS-25, "CUMMINS 5.0L : Wiring Diagram"](#).**1. CHECK FUSIBLE LINKS**

Check that the following fusible links are not blown.

Terminal	Signal name	Fusible link No.	
		Cummins 5.0L	VK56VD
1	Battery power supply	A (250A), D (100A)	A (250A), B (80A)
2		C (100A)	E (60A)
20		F (250A), J (100A), P (40A)	A (250A), C (100A), U (40A)

Is the fusible link blown?

YES >> Replace the blown fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connectors E118 and E120.
2. Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E118	1	(-)	Battery voltage
	2		
E120	20		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R connectors E123 and E124.
2. Check continuity between IPDM E/R connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E123	52	—	Yes
	62		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

UNIT REMOVAL AND INSTALLATION

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Removal and Installation of IPDM E/R

INFOID:0000000014388556

REMOVAL


CAUTION:

Do not remove the relays from the IPDM E/R. Except for the fuses, the IPDM E/R must be replaced as an assembly.


NOTE:

Cummins 5.0L Models shown. VK56VD Models similar.

1. Disconnect the battery or batteries negative terminal(s). Refer to [PG-185, "Battery Disconnect"](#).
2. Release the clips (A) and remove IPDM E/R upper cover (1).



3. Release the clips (A) and pull IPDM E/R (1) from case.



4. Disconnect the harness connectors and remove IPDM E/R from vehicle.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
PCS
N
O
P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000014388557

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

Precaution for Work

INFOID:0000000014388558

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000014388559

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.)	Description
— (J-46534) Trim Tool Set	Removing trim components



A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O


P

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000014388560



A. Front of center stack

B. Instrument lower panel RH

AWMIA1843ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

No.	Component	Function
1.	IPDM E/R	<ul style="list-style-type: none"> IPDM E/R detects push-button ignition switch (push switch) status, and transmits push-button ignition switch status signal (CAN) to BCM. IPDM E/R receives ignition relay (IPDM E/R) control signal and ignition switch ON signal (CAN) from BCM, and controls ignition relay (built in IPDM E/R) <p>Refer to PCS-5, "Component Parts Location" for detailed installation location.</p>
2.	Fuse and relay box (VK56VD) <ul style="list-style-type: none"> Stop lamp relay (without LED rear combination lamps) TCM (transmission control module) relay 	<ul style="list-style-type: none"> Stop lamp relay detects that brake pedal is depressed, and transmits the signal to BCM. TCM relay provides ignition power to the A/T assembly.
3.	Fuse and relay box (Cummins 5.0L) <ul style="list-style-type: none"> Stop lamp relay (without LED rear combination lamps) 	<ul style="list-style-type: none"> Stop lamp relay detects that brake pedal is depressed, and transmits the signal to BCM.
4.	A/T assembly (VK56VD)	The A/T assembly transmits shift P (park) and N (neutral) signals to the BCM. Refer to TM-267, "A/T CONTROL SYSTEM : Transmission Range Switch" .
5.	Transmission range switch (Cummins 5.0L)	The transmission range switch transmits shift P (park) and N (neutral) signals to the BCM. Refer to TM-17, "A/T CONTROL SYSTEM : Transmission Range Switch" .
6.	BCM	<ul style="list-style-type: none"> BCM controls power distribution system. BCM judges ignition switch position by push-button ignition switch (push switch) and vehicle condition. BCM checks the ignition switch position internally. <p>Refer to BCS-5, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.</p>
7.	Stop lamp switch (with LED rear combination lamps)	Stop lamp switch detects that brake pedal is depressed, and transmits the signal to BCM. Refer to BRC-12, "Stop Lamp Switch" .
8.	AT shift selector (park position switch)	AT shift selector detects shift lever status, transmits park position switch signal to BCM.
9.	Push-button ignition switch	Refer to PCS-48, "Push-button Ignition Switch" .
10.	Accessory relay-2	<ul style="list-style-type: none"> Accessory relay-2 is controlled by BCM. Accessory relay-2 supplies accessory power supply or ignition ON signal to each ECU when ignition is turned ON. BCM compares status of accessory relay-2 control signal, and ignition position judged by BCM.
11.	Fuse block (J/B)	The fuse block (J/B) houses the fuses and relays of the power distribution system.
12.	Ignition relay-2 (in fuse block)	<ul style="list-style-type: none"> Ignition relay-2 is controlled by BCM. Ignition relay-2 supplies ignition ON power supply or ignition ON signal to each ECU and system when ignition is turned ON. BCM compares status of ignition relay-2 control signal and ignition position judged by BCM. BCM monitors ignition relay-2 operating status by ignition relay-2 feedback signal.
13.	Front blower motor relay (in fuse block)	<ul style="list-style-type: none"> Front blower motor relay is controlled by BCM. Front blower motor supplies ignition ON power supply or ignition ON signal to air conditioning system when ignition is turned ON. BCM compares status of front blower motor relay control signal and ignition position judged by BCM.
14.	Accessory relay-1 (in fuse block)	<ul style="list-style-type: none"> Accessory relay-1 is controlled by BCM. Accessory relay-1 supplies accessory power supply or ignition ON signal to each ECU when ignition is turned ON. BCM compares status of accessory relay-1 control signal, and ignition position judged by BCM.

COMPONENT PARTS


< SYSTEM DESCRIPTION >

Push-button Ignition Switch

[POWER DISTRIBUTION SYSTEM]

INFOID:000000014388561


Push-button ignition switch is pressed, and transmits the status signal to BCM and IPDM E/R.



JMMIA13742Z

SYSTEM**POWER DISTRIBUTION SYSTEM****POWER DISTRIBUTION SYSTEM : System Description**

INFOID:000000014388562

SYSTEM DIAGRAM**DESCRIPTION****Power Distribution System**

- The power distribution system is the system that BCM controls with the operation of the push-button ignition switch and performs the power distribution to each power circuit. This system is used instead of the mechanical power supply changing mechanism with the operation of the conventional key cylinder.
- The push-button ignition switch can be operated when Intelligent Key is in the following condition:
 - Intelligent Key is in the detection area of the inside key antenna.
 - Intelligent Key backside is contacted to push-button ignition switch.
- The push-button ignition switch operation is input to BCM as a signal. BCM changes the power supply position according to the status and operates the following relays to supply power to each power circuit:
 - Ignition relay-1
 - Ignition relay-2
 - Accessory relay-1
 - Accessory relay-2
 - Front blower motor relay

NOTE:

The engine switch operation changes due to the conditions of brake pedal, selector lever and vehicle speed.

- The power supply position can be confirmed with the lighting of the indicators in the push-button ignition switch.

Ignition Battery Saver System

When all the following conditions are met for a period of time, the battery saver system will cut off the power supply (ignition switch ON/ACC → OFF) to prevent battery discharge.

- Ignition switch is in the ACC or ON position
- Turn signal lamp is not in operation
- Selector lever is in the P (park) position

RESET CONDITION OF IGNITION BATTERY SAVER SYSTEM

If any of the following conditions are met, the battery saver system is released.

- Ignition switch is not in the ACC or ON position
- Turn signal lamp is in operation
- Selector lever is not in the P (park) position

NOTE:

The ignition battery saver system can be temporarily disabled, without using CONSULT, to prevent it from functioning when performing trouble diagnosis. Refer to [PCS-76, "Work Procedure"](#).

Power Supply Position Change Table by Push-Button Ignition Switch Operation

SYSTEM

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

The power supply position changing operation can be performed with the following operations.

NOTE:

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below.
- When starting the engine, the BCM monitors under the engine start conditions:
 - Brake pedal operating condition
 - Selector lever position
 - Vehicle speed

VEHICLE SPEED: LESS THAN 4 KM/H (2.5 MPH)

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever position	Brake pedal operation condition	
OFF → ACC	—	Not depressed	1
OFF → ACC → ON	—	Not depressed	2
OFF → ACC → ON → OFF	—	Not depressed	3
OFF → START ACC → START ON → START	P or N position	Depressed	1
Engine is running → OFF	—	—	1

VEHICLE SPEED: 4 KM/H (2.5 MPH) OR MORE

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever position	Brake pedal operation condition	
Engine is running → ACC	—	—	Emergency stop operation
Engine stall return operation while driving	N position	Not depressed	1

Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

Fail Safe

INFOID:0000000014388563

Display contents of CONSULT	Fail-safe	Cancellation
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI-SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: START POW SUP CIRC	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent: <ul style="list-style-type: none"> Starter control relay signal Starter relay status signal
B2562: LOW VOLTAGE	Inhibit engine cranking	100 ms after the power supply voltage increases to more than 8.8 V
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent: <ul style="list-style-type: none"> Starter motor relay control signal Starter relay status signal (CAN)
B260A: IGN RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled: <ul style="list-style-type: none"> IGN relay (IPDM E/R) control signal: OFF (Battery voltage) Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B261E: FUEL MIS CONFIG	Inhibit engine cranking	BCM initialization

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000014692784

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions:

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays it on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed at the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) at the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK").
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF").
	LOCK>ACC	While turning power supply position from "LOCK" *to "ACC"
	ACC>ON	While turning power supply position from "ACC" to "IGN"
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopped and selector lever is in P position.)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF"
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC	While turning power supply position from "OFF" to "ACC"
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK"*.) to low power consumption mode
	LOCK	Power supply position is "LOCK" (Ignition switch OFF)*
	OFF	Power supply position is "OFF" (Ignition switch OFF)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> The number is 0 when a malfunction is detected now. The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition is switched OFF → ON. The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met:

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:0000000014692785

SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Monitor Item [Unit]	Main	Description
REQ SW -DR [On/Off]	×	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	×	Indicates condition of door request switch RH.
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
SHIFTLOCK SOLENOID PWR SUPPLY [On/Off]	×	Indicates condition of power supply to shiftlock solenoid.
BRAKE SW 1 [On/Off]	×	Indicates condition of brake switch.
BRAKE SW 2 [On/Off]		Indicates condition of brake switch.
DETE/CANCL SW [On/Off]	×	Indicates condition of P (park) position.
SFT PN/N SW [On/Off]	×	Indicates condition of P (park) or N (neutral) position.
UNLK SEN -DR [On/Off]	×	Indicates condition of door unlock sensor.
PUSH SW -IPDM [On/Off]		Indicates condition of push-button ignition switch received from IPDM E/R on CAN communication line.
IGN RLY1 -F/B [On/Off]		Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line.
DETE SW -IPDM [On/Off]		Indicates condition of park position switch received from TCM on CAN communication line.
SFT PN -IPDM [On/Off]		Indicates condition of P (park) or N (neutral) position from TCM on CAN communication line.
SFT P -MET [On/Off]		Indicates condition of P (park) position from TCM on CAN communication line.
SFT N -MET [On/Off]		Indicates condition of N (neutral) position from IPDM E/R on CAN communication line.
ENGINE STATE [Stop/Start/Crank/Run]	×	Indicates condition of engine state from ECM on CAN communication line.
VEH SPEED 1 [mph/km/h]	×	Indicates condition of vehicle speed signal received from ABS on CAN communication line.
VEH SPEED 2 [mph/km/h]	×	Indicates condition of vehicle speed signal received from combination meter on CAN communication line.
DOOR STAT -DR [LOCK/READY/UNLK]	×	Indicates condition of driver side door status.
DOOR STAT -AS [LOCK/READY/UNLK]	×	Indicates condition of passenger side door status.
DOOR STAT -RR [LOCK/READY/UNLK]	×	Indicates condition of rear right side door status.
DOOR STAT -RL [LOCK/READY/UNLK]	×	Indicates condition of rear left side door status.
ID OK FLAG [Set/Reset]		Indicates condition of Intelligent Key ID.
PRMT ENG STRT [Set/Reset]		Indicates condition of engine start possibility.
PRMT RKE STRT [Set/Reset]		Indicates condition of engine start possibility from Intelligent Key.
I-KEY OK FLAG [Key ON/Key OFF]	×	Indicates condition of Intelligent Key OK flag.
PRBT ENG STRT [Set/Reset]		Indicates condition of engine start prohibit.
ID AUTHENTICATION CANCEL TIMER [under a stop]		Indicates condition of Intelligent Key ID authentication.
ACC BATTERY SAVER [under a stop]		Indicates condition of battery saver.
CRNK PRBT TMR [On/Off]		Indicates condition of crank prohibit timer.
AUT CRNK TMR [On/Off]		Indicates condition of automatic engine crank timer from Intelligent Key.
CRNK PRBT TME [sec]		Indicates condition of crank prohibit timer.
AUT CRNK TMR [sec]		Indicates condition of automatic engine crank timer from Intelligent Key.
CRANKING TME [sec]		Indicates condition of engine cranking time from Intelligent Key.
ST RLY -REQ		Indicates condition of starter relay.
IGN RLY 1 -REQ		Indicates condition of ignition 1 relay.
IGN RLY 2 -REQ		Indicates condition of ignition 2 relay.
DETE SW PWR [On/Off]		Indicates condition of park position switch voltage.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Monitor Item [Unit]	Main	Description
ACC RLY -REQ [On/Off]		Indicates condition of accessory relay control request.
RKE OPE COUN1 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE OPE COUN2 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE-LOCK [On/Off]		Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]		Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]		Indicates condition of panic signal from Intelligent Key.
RKE-MODE CHG [On/Off]		Indicates condition of mode change signal from Intelligent Key.

ACTIVE TEST

Test Item	Description
INTELLIGENT KEY LINK (CAN)	This test is able to check Intelligent Key identification number [Off/ID No1/ID No2/ID No3/ID No4/ID No5].
INT LAMP	This test is able to check interior room lamp operation [On/Off].
FLASHER	This test is able to check hazard lamp operation [LH/RH/Off].
HORN	This test is able to check horn operation [On].
BATTERY SAVER	This test is able to check battery saver operation [On/Off].
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation [On/Off].
INSIDE BUZZER	This test is able to check combination meter warning chime operation [Take Out/Knob/Key/Off].
INDICATOR	This test is able to check combination meter warning lamp operation [KEY ON/KEY IND/Off].
IGN CONT2	This test is able to check ignition relay-2 control operation [On/Off].
ENGINE SW ILLUMI	This test is able to check push-button ignition switch START indicator operation [On/Off].
PUSH SWITCH INDICATOR	This test is able to check push-button ignition switch indicator operation [On/Off].
ACC CONT	This test is able to check accessory relay control operation [On/Off].
IGN CONT1	This test is able to check ignition relay-1 control operation [On/Off].
ST CONT LOW	This test is able to check starter control relay operation [On/Off].
IGNITION RELAY	This test is able to check ignition relay operation [On/Off].
TRUNK/LUGGAGE LAMP TEST	This test is able to check cargo lamp illumination operation [On/Off].
KEYFOB PW TEST	This test is able to check power window operation using the Intelligent Key [P/W up/down OFF/Send P/W down ON/Send P/W up ON].
SHIFTLOCK SOLENOID TEST	This test is able to check shift lock solenoid operation [On/Off].

WORK SUPPORT

Support Item	Setting	Description
IGN/ACC BATTERY SAVER	On*	Battery saver function ON.
	Off	Battery saver function OFF.
REMOTE ENGINE STARTER	On*	Remote engine start function ON.
	Off	Remote engine start function OFF.
ANSWERBACK I-KEY LOCK UNLOCK	BUZZER*	Buzzer reminder function by door lock/unlock request switch ON.
	HORN	Horn chirp reminder function by door lock request switch ON.
	Off	No reminder function by door lock/unlock request switch.
	INVALID	This mode is not used.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Support Item	Setting		Description
ANSWERBACK KEYLESS LOCK UN-LOCK	On*		Buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.
	Off		No buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.
ANSWER BACK	On*		Horn chirp reminder when doors are locked with Intelligent Key.
	Off		No horn chirp reminder when doors are locked with Intelligent Key.
RETRACTABLE MIRROR SET	On		Retractable mirror set ON.
	Off*		Retractable mirror set OFF.
LOCK/UNLOCK BY I-KEY	On*		Door lock/unlock function from Intelligent Key ON.
	Off		Door lock/unlock function from Intelligent Key OFF.
ENGINE START BY I-KEY	On*		Engine start function from Intelligent Key ON.
	Off		Engine start function from Intelligent Key OFF.
CONFIRM KEY FOB ID	—		Intelligent Key ID code can be checked.
SHORT CRANKING OUTPUT	Start	70 msec	Starter motor operation duration times.
		100 msec	
		200 msec	
	End	—	
INSIDE ANT DIAGNOSIS	—		This function allows inside key antenna self-diagnosis.
AUTO LOCK SET	MODE7	5 min	Auto door lock time can be set in this mode.
	MODE6	4 min	
	MODE5	3 min	
	MODE4	2 min	
	MODE3*	1 min	
	MODE2	30 sec	
	MODE1	Off	

*: Initial Setting

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

ECU DIAGNOSIS INFORMATION

BCM, IPDM E/R

List of ECU Reference

INFOID:000000014388566

ECU	Reference
BCM	BCS-32, "Reference Value"
	BCS-51, "Fail_Safe"
	BCS-51, "DTC_Inspection_Priority_Chart"
	BCS-52, "DTC_Index"
IPDM E/R	PCS-14, "Reference Value"
	PCS-22, "Fail_Safe"
	PCS-23, "DTC_Index"

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >


[POWER DISTRIBUTION SYSTEM]

WIRING DIAGRAM

POWER DISTRIBUTION SYSTEM CUMMINS 5.0L

CUMMINS 5.0L : Wiring Diagram


INFOID:0000000014388567



POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]



AAMWA2162GB

POWER DISTRIBUTION SYSTEM


< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

POWER DISTRIBUTION SYSTEM CONNECTORS - WITH Cummins 5.0L

Connector No.	Connector Name	Connector No.	Connector Name	Wire to Wire	21F	L/R	TO ENGINE CONTROL NO. 2 HARNESS	
ET12	STOP LAMP RELAY	E52	WIRE TO WIRE		22F	L/W	TO ENGINE CONTROL NO. 2 HARNESS	
Connector Name	MS02FL-M2-LC	Connector Type	RK26FGY-RS20-X6		23F	R/L	TO ENGINE CONTROL NO. 2 HARNESS	
Connector Color	BLUE	Connector Color	GRAY		24F	W/L	TO ENGINE CONTROL NO. 2 HARNESS	
					25F	W/R	TO ENGINE CONTROL NO. 2 HARNESS	
					26F	B/R	TO ENGINE CONTROL NO. 2 HARNESS	
					27F	Y	TO ENGINE CONTROL NO. 2 HARNESS	
					28F	W/R	TO ENGINE CONTROL NO. 2 HARNESS	
					29F	L/O	TO ENGINE CONTROL NO. 2 HARNESS	
					30F	B	TO ENGINE CONTROL NO. 2 HARNESS	
					31F	B	TO ENGINE CONTROL NO. 2 HARNESS	
Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	
1	B	GROUND	1F	Y	TO ENGINE CONTROL NO. 2 HARNESS	1	BY	F/L USM
2	W	RELAY CONTROL	2F	B	TO ENGINE CONTROL NO. 2 HARNESS	2	R	F/L MAIN
3	RG	STOP LAMPS	3F	BR	TO ENGINE CONTROL NO. 2 HARNESS			
5	RY	BATTERY	4F	W/R	TO ENGINE CONTROL NO. 2 HARNESS			
			5F	B/R	TO ENGINE CONTROL NO. 2 HARNESS			
			6F	O	TO ENGINE CONTROL NO. 2 HARNESS			
			7F	GR/Y	TO ENGINE CONTROL NO. 2 HARNESS			
			8F	V	TO ENGINE CONTROL NO. 2 HARNESS			
			9F	BR	TO ENGINE CONTROL NO. 2 HARNESS			
1	RY	BATTERY	10F	Y/B	TO ENGINE CONTROL NO. 2 HARNESS	41F	W	TO ENGINE CONTROL NO. 2 HARNESS
2	W	RELAY CONT. (WITHOUT LED REAR COMBINATION LAMPS)	11F	L	TO ENGINE CONTROL NO. 2 HARNESS	42F	Y	TO ENGINE CONTROL NO. 2 HARNESS
2	RG	STOP LAMPS (WITH LED REAR COMBINATION LAMPS)	12F	R	TO ENGINE CONTROL NO. 2 HARNESS	43F	B/P	TO ENGINE CONTROL NO. 2 HARNESS
3	GR	IGNITION	13F	Y	TO ENGINE CONTROL NO. 2 HARNESS	44F	Y/B	TO ENGINE CONTROL NO. 2 HARNESS
4	RB	STOP 2	14F	V	TO ENGINE CONTROL NO. 2 HARNESS	45F	L/Y	TO ENGINE CONTROL NO. 2 HARNESS
			15F	SB	TO ENGINE CONTROL NO. 2 HARNESS	46F	O	TO ENGINE CONTROL NO. 2 HARNESS
			16F	P	TO ENGINE CONTROL NO. 2 HARNESS	47F	W/R	TO ENGINE CONTROL NO. 2 HARNESS
			17F	Y/R	TO ENGINE CONTROL NO. 2 HARNESS	48F	L	TO ENGINE CONTROL NO. 2 HARNESS
			18F	R	TO ENGINE CONTROL NO. 2 HARNESS	49F	BR	TO ENGINE CONTROL NO. 2 HARNESS
			19F	V	TO ENGINE CONTROL NO. 2 HARNESS	50F	SHIELD	TO ENGINE CONTROL NO. 2 HARNESS
			20F	BR	TO ENGINE CONTROL NO. 2 HARNESS	51F	L	TO ENGINE CONTROL NO. 2 HARNESS

AAMIA5013GB





POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

POWER DISTRIBUTION SYSTEM CONNECTORS - WITH Cummins 5.0L



Connector No.	Signal Name	Color of Wire	Wire to Wire	Terminal	Color of Wire	Signal Name
E152		24G	G/B	TO MAIN HARNESS	72G	L/W
		25G	R/W		73G	SHIELD
		26G	R	TO MAIN HARNESS	74G	W
		27G	LG	TO MAIN HARNESS	75G	R
		28G	G/B	TO MAIN HARNESS	76G	R/G
		29G	G/B	TO MAIN HARNESS	77G	G
		30G	BR/Y	TO MAIN HARNESS	78G	W
		31G	P	TO MAIN HARNESS - (WITH CUMMINS 5.0L)	79G	-
		31G	R	TO MAIN HARNESS - (WITH VGS610)	80G	R
		32G	P	TO MAIN HARNESS	81G	L
		33G	Y/L	TO MAIN HARNESS	82G	R
		34G	GR	TO MAIN HARNESS	83G	L
		35G	G/R	TO MAIN HARNESS	84G	L
		36G	SB	TO MAIN HARNESS	85G	WB
		37G	R/W	TO MAIN HARNESS	86G	BR
		38G	BR	TO MAIN HARNESS	87G	WB
		39G	BR	TO MAIN HARNESS	88G	P
		40G	-	TO MAIN HARNESS	89G	L
		41G	R/G	TO MAIN HARNESS	90G	G
		42G	O	TO MAIN HARNESS	91G	G
		43G	B	TO MAIN HARNESS - (WITH CUMMINS 5.0L)	92G	V/W
		43G	G	TO MAIN HARNESS - (WITH VGS610)	93G	BR
		44G	R/Y	TO MAIN HARNESS	94G	G
		45G	G	TO MAIN HARNESS	95G	G
		46G	LG	TO MAIN HARNESS	96G	W
		47G	R	TO MAIN HARNESS	97G	R
		48G	W	TO MAIN HARNESS	98G	WB
		49G	-	TO MAIN HARNESS	99G	BR
		50G	BR	TO MAIN HARNESS	100G	GR/W
		51G	R	TO MAIN HARNESS		
		52G	L	TO MAIN HARNESS		
		53G	W	TO MAIN HARNESS		
		54G	W	TO MAIN HARNESS - (WITH CUMMINS 5.0L)		
		55G	G	TO MAIN HARNESS		
		56G	BR	TO MAIN HARNESS		
		57G	R	TO MAIN HARNESS		
		58G	W	TO MAIN HARNESS		
		59G	R/W	TO MAIN HARNESS - (WITH VGS610)		
		60G	BG	TO MAIN HARNESS		
		61G	B	TO MAIN HARNESS		
		62G	W	TO MAIN HARNESS		
		63G	R	TO MAIN HARNESS		
		64G	W/L	TO MAIN HARNESS		
		65G	W/R	TO MAIN HARNESS		
		66G	BG	TO MAIN HARNESS		
		67G	BG	TO MAIN HARNESS		
		68G	B	TO MAIN HARNESS		
		69G	Y	TO MAIN HARNESS		
		70G	L	TO MAIN HARNESS		
		71G	R/W	TO MAIN HARNESS		
		72G	Y/R	TO MAIN HARNESS		
		73G	Y/R	TO ENGINE ROOM HARNESS	4F	W/R
		74G	W	TO ENGINE ROOM HARNESS	5F	BR
		75G	R	TO ENGINE ROOM HARNESS	6F	O/L
		76G	R/G	TO ENGINE ROOM HARNESS	7F	GR
		77G	G	TO ENGINE ROOM HARNESS	8F	P
		78G	W	TO ENGINE ROOM HARNESS	9F	BRW
		79G	-	TO ENGINE ROOM HARNESS	10F	GY
		80G	R	TO ENGINE ROOM HARNESS	11F	L/W
		81G	L	TO MAIN HARNESS	12F	R/W
		82G	R	TO MAIN HARNESS	13F	G/Y
		83G	L	TO MAIN HARNESS	14F	V/W
		84G	L	TO MAIN HARNESS	15F	LG
		85G	WB	TO MAIN HARNESS	16F	RY
		86G	BR	TO MAIN HARNESS	17F	BR/Y
		87G	WB	TO MAIN HARNESS	18F	R
		88G	P	TO MAIN HARNESS	19F	V
		89G	L	TO MAIN HARNESS	20F	BR
		90G	G	TO MAIN HARNESS	21F	L/R
		91G	G	TO MAIN HARNESS	22F	I/V/G
		92G	V/W	TO MAIN HARNESS	23F	SB
		93G	BR	TO MAIN HARNESS	24F	W/L
		94G	G	TO MAIN HARNESS	25F	W/B
		95G	G	TO MAIN HARNESS	26F	B/Y
		96G	W	TO MAIN HARNESS	27F	Y
		97G	R	TO MAIN HARNESS	28F	W/R
		98G	WB	TO MAIN HARNESS	29F	L/O
		99G	BR	TO MAIN HARNESS	30F	B
		100G	GR/W	TO MAIN HARNESS	31F	B
				TO MAIN HARNESS	32F	V
				TO MAIN HARNESS	33F	BG
				TO MAIN HARNESS	34F	L/R
				TO MAIN HARNESS	35F	R/W
				TO MAIN HARNESS	36F	L/O
				TO MAIN HARNESS	37F	L/O
				TO MAIN HARNESS	38F	Y/W
				TO MAIN HARNESS	39F	RY
				TO MAIN HARNESS	40F	G/B
				TO MAIN HARNESS	41F	W
				TO MAIN HARNESS	42F	Y
				TO MAIN HARNESS	43F	B/P
				TO MAIN HARNESS	44F	Y/B
				TO MAIN HARNESS	45F	L/Y
				TO MAIN HARNESS	46F	O
				TO MAIN HARNESS	47F	W/L
				TO MAIN HARNESS	48F	L
				TO MAIN HARNESS	49F	BR
				TO ENGINE ROOM HARNESS	50F	SHIELD
				TO ENGINE ROOM HARNESS	51F	L
				TO ENGINE ROOM HARNESS	52F	BR

AAMIA5015GB


POWER DISTRIBUTION SYSTEM

[POWER DISTRIBUTION SYSTEM]

< WIRING DIAGRAM >


POWER DISTRIBUTION SYSTEM CONNECTORS - WITH Cummins 5.0L

Connector No.	F212
Connector Name	TRANSMISSION RANGE SWITCH
Connector Type	HS10FB
Connector Color	BLACK




H.S.

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS
Connector Color	WHITE
Connector Diagram	



Terminal No.	Color of Wire	Signal Name
1	L/W	RANGE SIGNAL C
2	P	RANGE SIGNAL B
3	R/Y	IGNITION
4	GR	RANGE SIGNAL PA
5	Y/R	RANGE SIGNAL PA
6	OL	BATTERY
7	R	REVERSE RELAY CONT
8	BR/R	NPSW
9	BR/Y	IGNITION RELAY
10	-	-



H.S.

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH
Connector Color	GREEN



Color	BLACK
-------	-------

Terminal No.	Color of Wire	Signal Name
41	Y/L	TRAILER LIGHT CHECK RELAY OUT
42	R/OW	CARGO LOAD CUT

Terminal No.	Color of Wire	Signal Name
1N	-	-
2N	W	BATTERY
3N	W	BLOWER FAN RELAY OUT
4N	V	BATTERY
5N	Y	BATTERY
6N	W	BATTERY
7N	L	ACG RELAY OUT
8N	W	IGNITION

AAMIA5016GE

7	-	-	-
8	-	-	-
9	-	-	-
10	SB	COMBI SW IN 5	COMBI SW IN 4
11	G/Y	COMBI SW IN 3	COMBI SW IN 2
12	Y	COMBI SW IN 1	-
13	G/B	-	-
14	V	-	-
15	-	-	-
16	P	GND REF A/L	SECURITY INDICATOR
17	V	-	-
18	-	R	SHIFT P
19	-	R/W	STEP LAMP CONT
20	-	-	-
21	-	-	AIRCON SW
22	-	-	BRAKE SW/FUSE
23	Y	-	SHORT IN PIN INPUT
24	-	-	BRAKE SW/LAMP
25	W	-	-
26	L	-	-
27	R/G	-	-
28	-	-	BLOWER FAN SW
29	W	P	DR DOORLOCK STATUS
30	-	-	-
31	-	-	REAR DEFROGGER SW
32	Y	-	-
33	-	-	-
34	-	-	-
35	R/G	W/B	REVERSE SW
36	W/B	-	HAZARD SW
37	-	-	-
38	-	-	-
39	B/R	-	SHIFT N/P
40	-	-	-

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH
Connector Color	BLACK

COLLECTOR CO.	
65	-
66	W
67	G
68	L
69	R/B
70	P
71	O
72	G
73	-
74	-
75	L/W
76	P
77	L
78	O/B
79	R/W
80	-

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH
Connector Color	BLACK

Revision: August 2016

POWER DISTRIBUTION SYSTEM CONNECTORS - WITH Cummins 5.0L

Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name	Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name
M31	WIRE TO WIRE	27G	LG	TO ENGINE ROOM HARNESS	80G	R	TO ENGINE ROOM HARNESS	81G	L	TO ENGINE ROOM HARNESS	
		28G	G/B	TO ENGINE ROOM HARNESS	82G	R	TO ENGINE ROOM HARNESS	83G	L	TO ENGINE ROOM HARNESS	
		29G	G/B	TO ENGINE ROOM HARNESS	84G	L	TO ENGINE ROOM HARNESS	85G	W	TO ENGINE ROOM HARNESS	
		30G	B/R	TO ENGINE ROOM HARNESS	86G	B/R	TO ENGINE ROOM HARNESS	87G	W	TO ENGINE ROOM HARNESS	
		31G	R	TO ENGINE ROOM HARNESS	88G	P	TO ENGINE ROOM HARNESS	89G	P	TO ENGINE ROOM HARNESS	
		32G	R	TO ENGINE ROOM HARNESS	90G	P	TO ENGINE ROOM HARNESS	91G	P	TO ENGINE ROOM HARNESS	
		33G	Y/L	TO ENGINE ROOM HARNESS	92G	V/W	TO ENGINE ROOM HARNESS	93G	BR	TO ENGINE ROOM HARNESS	
		34G	GR	TO ENGINE ROOM HARNESS	94G	B	TO ENGINE ROOM HARNESS	95G	G	TO ENGINE ROOM HARNESS	
		35G	G/R	TO ENGINE ROOM HARNESS	96G	R	TO ENGINE ROOM HARNESS	97G	R	TO ENGINE ROOM HARNESS	
		36G	SB	TO ENGINE ROOM HARNESS	98G	W/R	TO ENGINE ROOM HARNESS	99G	R	TO ENGINE ROOM HARNESS	
		37G	R/W	TO ENGINE ROOM HARNESS	100G	GR/W	TO ENGINE ROOM HARNESS	101G	BR	SHIFT UP	
		38G	BR	TO ENGINE ROOM HARNESS				102G	V/W	SHIFT DOWN	
		39G	BR	TO ENGINE ROOM HARNESS							
		40G	-	TO ENGINE ROOM HARNESS							
		41G	R/G	TO ENGINE ROOM HARNESS							
		42G	O	TO ENGINE ROOM HARNESS							
		43G	G	TO ENGINE ROOM HARNESS							
		44G	R/Y	TO ENGINE ROOM HARNESS							
		45G	G	TO ENGINE ROOM HARNESS							
		46G	LG	TO ENGINE ROOM HARNESS							
		47G	R	TO ENGINE ROOM HARNESS							
		48G	W	TO ENGINE ROOM HARNESS							
		49G	-	TO ENGINE ROOM HARNESS							
		50G	BR	TO ENGINE ROOM HARNESS							
		51G	R	TO ENGINE ROOM HARNESS							
		52G	L	TO ENGINE ROOM HARNESS							
		53G	W	TO ENGINE ROOM HARNESS							
		54G	W	TO ENGINE ROOM HARNESS							
		55G	G	TO ENGINE ROOM HARNESS							
		56G	W	TO ENGINE ROOM HARNESS							
		57G	Y	TO ENGINE ROOM HARNESS							
		58G	B/G	TO ENGINE ROOM HARNESS							
		59G	B/G	TO ENGINE ROOM HARNESS							
		60G	B/G	TO ENGINE ROOM HARNESS							
		61G	O	TO ENGINE ROOM HARNESS							
		62G	W	TO ENGINE ROOM HARNESS							
		63G	O	TO ENGINE ROOM HARNESS							
		64G	W/L	TO ENGINE ROOM HARNESS							
		65G	W/R	TO ENGINE ROOM HARNESS							
		66G	B/G	TO ENGINE ROOM HARNESS							
		67G	O	TO ENGINE ROOM HARNESS							
		68G	B	TO ENGINE ROOM HARNESS							
		69G	Y	TO ENGINE ROOM HARNESS							
		70G	L	TO ENGINE ROOM HARNESS							
		71G	R/W	TO ENGINE ROOM HARNESS							
		72G	L/W	TO ENGINE ROOM HARNESS							
		73G	SHIELD	TO ENGINE ROOM HARNESS							
		74G	W	TO ENGINE ROOM HARNESS							
		75G	R	TO ENGINE ROOM HARNESS							
		76G	R/G	TO ENGINE ROOM HARNESS							
		77G	B/G	TO ENGINE ROOM HARNESS							
		78G	P	TO ENGINE ROOM HARNESS							
		79G	-	TO ENGINE ROOM HARNESS							


AAMIA5017GB

< WIRING DIAGRAM >


POWER DISTRIBUTION SYSTEM

[POWER DISTRIBUTION SYSTEM]


Connector No.	M68
Connector Name	A/T SHIFT SELECTOR
Connector Type	TK08FW
Connector Color	WHITE



Connector No.	M69
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-C/S
Connector Color	WHITE




Connector No.	M70
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M71
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-C/S
Connector Color	WHITE


Connector No.	M72
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M73
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M74
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M75
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M76
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M77
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M78
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M79
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M80
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M81
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE



Connector No.	M82
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M83
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M84
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE




Connector No.	M85
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE



Connector No.	M86
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE



Connector No.	M87
Connector Name	IGNITION
Connector Type	TH08FW-NH
Connector Color	WHITE



Connector No.	M88
<tbl_info cols

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

POWER DISTRIBUTION SYSTEM CONNECTORS - WITH Cummins 5.0L

Connector No.	M70	Color of Wire	Signal Name
Connector Name	FUSE BLOCK (J/B)		
Connector Type	NS16FBR-CS		
Connector Color	BROWN		
			

Terminal No.	1R	Color of Wire	Signal Name
	2R	GR	TAIL LAMP 2
	3R	Y/R	IGNITION
	4R	-	BATTERY
	5R	W	BATTERY
	6R	GR/W	ACCESSORY
	7R	-	-
	8R	-	-
	9R	-	-
	10R	W	BATTERY
	11R	-	-
	12R	BG	BATTERY
	13R	B	ACCESSORY
	14R	GR	BATTERY
	15R	Y	BATTERY
	16R	GR	ACCESSORY

7R	6R	5R	4R	3R	2R	1R
16R	15R	14R	13R	12R	11R	10R

7R	6R	5R	4R	3R	2R	1R
16R	15R	14R	13R	12R	11R	10R

Connector No.	M80	Color of Wire	Signal Name
Connector Name	BCM (BODY CONTROL MODULE)		
Connector Type	TH24FB-NH		
Connector Color	BLACK		
			

116	115	114	13	125	124	123	122	121	120	119	118	117
-----	-----	-----	----	-----	-----	-----	-----	-----	-----	-----	-----	-----

111	P	ACC LED
112	-	-
113	L	ACC RELAY OUT
114	W	AS DOOR ANT A
115	BG	AS DOOR ANT B
116	W	ROOM ANT 2 A
117	GR/B	FL FLASHER
118	-	-
119	R	RF NIN/MOCO
120	-	-
121	G	DR DOOR ANT B
122	P	DR DOOR ANT A
123	W	ROOM ANT 1 A
124	G	ROOM ANT 1 B
125	-	-
126	P	IMMO/START BUTTON ANT B
127	BG	IMMO/START BUTTON ANT A
128	B	ROOM ANT 2 B

Terminal No.	1R	Color of Wire	Signal Name
	2R	GR	TAIL LAMP 2
	3R	Y/R	IGNITION
	4R	-	BATTERY
	5R	W	BATTERY
	6R	GR/W	ACCESSORY
	7R	-	-
	8R	-	-
	9R	-	-
	10R	W	BATTERY
	11R	-	-
	12R	BG	BATTERY
	13R	B	ACCESSORY
	14R	GR	BATTERY
	15R	Y	BATTERY
	16R	GR	ACCESSORY

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115	116	117
-----	-----	-----	-----	-----	-----	-----

111	112	113	114	115</

POWER DISTRIBUTION SYSTEM


[POWER DISTRIBUTION SYSTEM]

< WIRING DIAGRAM >

VK56VD : Wiring Diagram

INFOID:000000014388568


POWER DISTRIBUTION SYSTEM - WITH VK56VD



POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]



AAMWA2154GB


POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

POWER DISTRIBUTION SYSTEM CONNECTORS - WITH VK56VD

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Type	·TH24NW-NH
Connector Color	WHITE



Connector No.	E12
Connector Name	STOP LAMP RELAY
Connector Type	MS02FL-M2-LC
Connector Color	BLUE



Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Signal Name
1	L/R	TO ENGINE CONTROL HARNESS	GROUND
2	BR	TO ENGINE CONTROL HARNESS	RELAY CONTROL
3	V	TO ENGINE CONTROL HARNESS	STOP LAMPS
4	L/O	TO ENGINE CONTROL HARNESS	BATTERY
5	W	TO ENGINE CONTROL HARNESS	
6	BR	TO ENGINE CONTROL HARNESS	
7	Y/R	TO ENGINE CONTROL HARNESS	
8	BR	TO ENGINE CONTROL HARNESS	
9	WL	TO ENGINE CONTROL HARNESS	
10	LY	TO ENGINE CONTROL HARNESS	
11	SB	TO ENGINE CONTROL HARNESS	
12	L	TO ENGINE CONTROL HARNESS	
13	WR	TO ENGINE CONTROL HARNESS	
14	Y	TO ENGINE CONTROL HARNESS	
15	B	TO ENGINE CONTROL HARNESS	
16	B	TO ENGINE CONTROL HARNESS	
17	R	TO ENGINE CONTROL HARNESS	
18	B	TO ENGINE CONTROL HARNESS	
19	BR	TO ENGINE CONTROL HARNESS	
20	GR	TO ENGINE CONTROL HARNESS	
21	VR	TO ENGINE CONTROL HARNESS	
22	B	TO ENGINE CONTROL HARNESS	
23	B	TO ENGINE CONTROL HARNESS	
24	P	TO ENGINE CONTROL HARNESS	



Terminal No.	Color of Wire	Signal Name	Signal Name
1	R/Y	BATTERY	
2	W	RELAY CONT. (WITHOUT LED REAR COMBINATION LAMPS)	
3	R/G	STOP LAMPS- (WITH LED REAR COMBINATION LAMPS)	



Terminal No.	Color of Wire	Signal Name	Signal Name
1	Y/R	IGNITION	STOP 2
2	BR		



Terminal No.	Color of Wire	Signal Name	Signal Name
1	GR	IGNITION	STOP 2
2	R/B		



Terminal No.	Color of Wire	Signal Name	Signal Name
1	B	GROUND	
2	BR	IGNITION RELAY CONT.	
3	Y/R	VIGN	



Terminal No.	Color of Wire	Signal Name	Signal Name
1	R	ACC	
2	BR	ACC	



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
PCS

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

POWER DISTRIBUTION SYSTEM CONNECTORS - WITH VK56VD

Connector No.	E118	17	W	IGN COIL-(WITH VKE69D)
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	18	-	-
Connector Type	L02FB-MC			
Connector Color	BLACK			
Connector No.	E120			
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)			
Connector Type	M06FW-LC			
Connector Color	WHITE			

Terminal No.	Color of Wire	Signal Name
1	B/Y	F/L USM
2	R	F/L MAIN

Connector No.	Connector Name	IPDM E/R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)	NS16FW-CS	WHITE	CONNECTOR COLOR	W/R	19	20	L	STARTER MOTOR	F41NSW
E119							21	-	-		-
							22	-	-		-
							23	-	-		-
							24	-	-		-

Connector No.	E122
Connector Name	IPD M/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH12FW-NH
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
3	-	-
4	B/R	NF SW
5	L/W	H/LAMP HI RH
6	G	H/LAMP HI LH
7	L	H/LAMP LO LH
8	R/Y	H/LAMP LO RH
9	Q/W	FR FG/G/LH
10	-	-
11	P	ETC VB - (WITH CUMMINS 5.0L)
11	O	ETC VB - (WITH VV565/D)
12	W/R	FR FG/G/LH
12	Y/R	AT/EU/IGN
14	G	REVERSE LAMP (GN)
15	GR	ABS/ECU/VIN
16	G	ETC RLY CONT - (WITH CUMMINS 5.0L)
16	V/R	ETC RLY CONT - (WITH VV565/D)
17	L/W	IGN COIL - (WITH CUMMINS 5.0L)

AAMIA5020G1

POWER DISTRIBUTION SYSTEM


[POWER DISTRIBUTION SYSTEM]

< WIRING DIAGRAM >

POWER DISTRIBUTION SYSTEM CONNECTORS - WITH VK56VD

Connector No.	Signal Name
E152	WIRE TO WIRE
TH80MW-CS16-TM4	WHITE
24G	G/B
26G	R/W
26G	R
27G	LG
28G	G/B
29G	G/B
30G	BR/Y
31G	P
31G	R
32G	P
33G	Y/L
34G	GR
35G	G/R
36G	SB
37G	R/W
38G	BR
39G	BR
40G	-
41G	R/G
42G	O
43G	B
43G	G
44G	R/Y
45G	G
46G	LG
47G	R
48G	W
49G	TO MAIN HARNESS - (WITH CUMMINS 5.0L)
50G	TO MAIN HARNESS - (WITH VK56VD)
51G	TO MAIN HARNESS
52G	TO MAIN HARNESS
53G	TO MAIN HARNESS
54G	TO MAIN HARNESS
55G	TO MAIN HARNESS
56G	TO MAIN HARNESS
57G	TO MAIN HARNESS
58G	TO MAIN HARNESS
59G	TO MAIN HARNESS
60G	TO MAIN HARNESS
61G	TO MAIN HARNESS
62G	TO MAIN HARNESS
63G	TO MAIN HARNESS
64G	TO MAIN HARNESS
65G	W/R
66G	BR
67G	BR
68G	B
69G	Y
70G	L
71G	TO MAIN HARNESS
72G	L/W
73G	SHIELD
74G	W
75G	R
76G	R/G
77G	G
78G	W
79G	-
80G	R
81G	L
82G	R
83G	L
84G	L
85G	W/B
86G	B/R
87G	W/B
88G	P
89G	L
90G	G
91G	G
92G	V/W
93G	BR
94G	G
95G	G
96G	W
97G	R
98G	W/B
99G	BR
100G	GR/W

H.S.



Connector No.	Signal Name	Wire To Wire
4	3	2
1	L	TO ENGINE ROOM HARNESS
2	W	TO ENGINE ROOM HARNESS
3	P	TO ENGINE ROOM HARNESS
4	SB	TO ENGINE ROOM HARNESS

Terminal No.	Color of Wire	Signal Name
1	L	TO ENGINE ROOM HARNESS
2	W	TO ENGINE ROOM HARNESS
3	P	TO ENGINE ROOM HARNESS
4	SB	TO ENGINE ROOM HARNESS

H.S.

Connector No.	Signal Name
14	WIRE TO WIRE
TH24FW-NH	WHITE
24	11
23	10
22	9
21	8
20	7
19	6
18	5
17	4
16	3
15	2
14	1

H.S.

Terminal No.	Color of Wire	Signal Name
10	L/Y	TO ENGINE ROOM HARNESS
11	SB	TO ENGINE ROOM HARNESS
12	L	TO ENGINE ROOM HARNESS
13	W/R	TO ENGINE ROOM HARNESS
14	Y	TO ENGINE ROOM HARNESS
15	B	TO ENGINE ROOM HARNESS
16	B	TO ENGINE ROOM HARNESS
17	R	TO ENGINE ROOM HARNESS
18	B	TO ENGINE ROOM HARNESS
19	GR	TO ENGINE ROOM HARNESS
20	GR	TO ENGINE ROOM HARNESS
21	V/R	TO ENGINE ROOM HARNESS
22	SHIELD	TO ENGINE ROOM HARNESS
23	P	TO ENGINE ROOM HARNESS

H.S.

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

POWER DISTRIBUTION SYSTEM CONNECTORS - WITH VK56VD

Connector No.	F46
Connector Name	A/T ASSEMBLY (WITH VK56VD)
Connector Type	RK10FG
Connector Color	GREEN
	



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS
Connector Color	WHITE



Terminal No.	7	Color of Wire	-	Signal Name	-	Terminal No.	43	Color of Wire	-	Signal Name	-
	8		-		-		44		-		-
	9		-		-		45		-		-
	10		SB	COMBI SW IN 5			46		-		-
	11		GY	COMBI SW IN 4			47		-		-
	12		Y	COMBI SW IN 3			48		R	HIGH SIDE START SW LED	
	13		GB	COMBI SW IN 2			49		-		-
	14		V	COMBI SW IN 1			50		-		-
	15		-	-			51		-		-
	16		-	-			52		W	AUDIO DONGLE	
	17		P	GND RF A/L			53		-		-
	18		V	SECURITY INDICATOR			54		WL	PW/UART	
	19		-	-			55		WB	L&R SENSOR K-LINE	
	20		R	SHIFT P			56		-		-
	21		R/W	STEP LAMP 2ONT			57		-		-
	22		-	-			58		-		-
	23		Y	AIRCON SW			59		P	CAN-L	
	24		-	-			60		L	CAN-H	
	25		W	Brake SW FUSE			61		O	REAR DEFOGGER RELAY OUT	
	26		L	SHORT IN PIN INPUT			62		W	STARTER RELAY OUT	
	27		R/G	Brake SW LAMP			63		-		-
	28		-	-			64		P	EUZZER OUT	
	29		W	BLOWER FAN SW			65		-		-
	30		P	DR DOOR LOCK STATUS			66		W	BLOWER FAN RELAY OUT	
	31		-	-			67		G	IGN ELEC RELAY OUT 2	
	32		Y	REAR DEFOGGER SW			68		L	MR OUTPUT	
	33		-	-			69		R/B	AT DEVICE OUT	
	34		-	-			70		P	IGN INISM OUT 1	
	35		R/G	REVERSE SW			71		O	DR REQUEST SW	
	36		WB	HAZARD SW			72		G	AS REQUEST SW	
	37		-	-			73		-		-
	38		-	-			74		-		-
	39		B/R	SHIFT N/P			75		L/W	COMBI SW OUT 5	
	40		-	-			76		P	COMBI SW OUT 4	
							77		L	COMBI SW OUT 3	
							78		O/B	COMBI SW OUT 2	
							79		R/W	COMBI SW OUT 1	
							80		-		-

H.S.



Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	1	Color of Wire	G	Signal Name	ENG START SW NO ESCL
	2		-		-
	3		R	A/L POWER SUPPLY 5V	A/L SIGNAL
	4		W/R		TRAILER LIGHT CHECK RELAY OUT
	5		-		CARGO LAMP OUT
	6		-		

H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



H.S.



POWER DISTRIBUTION SYSTEM

[POWER DISTRIBUTION SYSTEM]

< WIRING DIAGRAM >

POWER DISTRIBUTION SYSTEM CONNECTORS - WITH VK56VD

Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name	Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name
M31	WIRE TO WIRE	27G	LG	TO ENGINE ROOM HARNESS	80G	R	TO ENGINE ROOM HARNESS	61G	L	TO ENGINE ROOM HARNESS	Connector No. M46
		28G	G/B	TO ENGINE ROOM HARNESS	82G	R	TO ENGINE ROOM HARNESS	83G	L	TO ENGINE ROOM HARNESS	Connector Name PUSH-BUTTON IGNITION SWITCH
		29G	G/B	TO ENGINE ROOM HARNESS	84G	L	TO ENGINE ROOM HARNESS	85G	W	TO ENGINE ROOM HARNESS	Connector Type TH08FW-NH
		30G	B/Y	TO ENGINE ROOM HARNESS	86G	B/R	TO ENGINE ROOM HARNESS	87G	W	TO ENGINE ROOM HARNESS	Connector Color WHITE
		31G	R	TO ENGINE ROOM HARNESS	88G	B/R	TO ENGINE ROOM HARNESS	89G	G	TO ENGINE ROOM HARNESS	
		32G	R	TO ENGINE ROOM HARNESS	90G	G	TO ENGINE ROOM HARNESS	91G	P	TO ENGINE ROOM HARNESS	
		33G	Y/L	TO ENGINE ROOM HARNESS	92G	V/W	TO ENGINE ROOM HARNESS	93G	BR	TO ENGINE ROOM HARNESS	
		34G	GR	TO ENGINE ROOM HARNESS	94G	B	TO ENGINE ROOM HARNESS	95G	G	TO ENGINE ROOM HARNESS	
		35G	G/R	TO ENGINE ROOM HARNESS	96G	R	TO ENGINE ROOM HARNESS	97G	R	TO ENGINE ROOM HARNESS	
		36G	SB	TO ENGINE ROOM HARNESS	98G	W/R	TO ENGINE ROOM HARNESS	99G	R	TO ENGINE ROOM HARNESS	
		37G	R/W	TO ENGINE ROOM HARNESS	100G	G	TO ENGINE ROOM HARNESS				
		38G	BR	TO ENGINE ROOM HARNESS							
		39G	BR	TO ENGINE ROOM HARNESS							
		40G	-	TO ENGINE ROOM HARNESS							
		41G	R/G	TO ENGINE ROOM HARNESS							
		42G	O	TO ENGINE ROOM HARNESS							
		43G	G	TO ENGINE ROOM HARNESS							
		44G	R/Y	TO ENGINE ROOM HARNESS							
		45G	G	TO ENGINE ROOM HARNESS							
		46G	LG	TO ENGINE ROOM HARNESS							
		47G	R	TO ENGINE ROOM HARNESS							
		48G	W	TO ENGINE ROOM HARNESS							
		49G	-	TO ENGINE ROOM HARNESS							
		50G	BR	TO ENGINE ROOM HARNESS							
		51G	R	TO ENGINE ROOM HARNESS							
		52G	L	TO ENGINE ROOM HARNESS							
		53G	W	TO ENGINE ROOM HARNESS							
		54G	W	TO ENGINE ROOM HARNESS							
		55G	W	TO ENGINE ROOM HARNESS							
		56G	W	TO ENGINE ROOM HARNESS							
		57G	Y	TO ENGINE ROOM HARNESS							
		58G	B/G	TO ENGINE ROOM HARNESS							
		59G	B/G	TO ENGINE ROOM HARNESS							
		60G	B/G	TO ENGINE ROOM HARNESS							
		61G	O	TO ENGINE ROOM HARNESS							
		62G	W	TO ENGINE ROOM HARNESS							
		63G	O	TO ENGINE ROOM HARNESS	10G	-	-				
		64G	W/L	TO ENGINE ROOM HARNESS	20G	O/L	IGNITION				
		65G	W/R	TO ENGINE ROOM HARNESS	30G	-	-				
		66G	B/G	TO ENGINE ROOM HARNESS	40G	-	-				
		67G	O	TO ENGINE ROOM HARNESS	50G	-	-				
		68G	B	TO ENGINE ROOM HARNESS	60G	R/W	BATTERY				
		69G	Y	TO ENGINE ROOM HARNESS	70G	R/W	IGNITION				
		70G	L	TO ENGINE ROOM HARNESS	80G	-	-				
		71G	R/W	TO ENGINE ROOM HARNESS							
		72G	L/W	TO ENGINE ROOM HARNESS							
		73G	SHIELD	TO ENGINE ROOM HARNESS							
		74G	W	TO ENGINE ROOM HARNESS							
		75G	R	TO ENGINE ROOM HARNESS							
		76G	R/G	TO ENGINE ROOM HARNESS							
		77G	B/G	TO ENGINE ROOM HARNESS							
		78G	P	TO ENGINE ROOM HARNESS							
		79G	-	TO ENGINE ROOM HARNESS							

AAMIA5023GB

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

POWER DISTRIBUTION SYSTEM CONNECTORS - WITH VK56VD

Connector No.	M69	14R	G/Y	BATTERY
Connector Name	FUSE BLOCK (J/B)	15R	Y	BATTERY
Connector Type	NS10FW-CS	16R	G/R	ACCESSORY
Connector Color	WHITE			
		4M 3M	□	2M 1M
		10M 9M	8M 7M	6M 5M



Terminal No.	Color of Wire	Signal Name
1M	GR	IGNITION
2M	-	-
3M	-	-
4M	-	-
5M	R/Y	BATTERY
6M	R/W	TAIL LAMP 2
7M	-	-
8M	-	-
9M	-	-
10M	W/R	IGNITION

7R 6R 5R 4R	□	3R 2R 1R
16R 15R 14R 13R	12R 11R	10R 9R 8R



Terminal No.	Color of Wire	Signal Name
105	G/Y	FR FLASHER
106	-	-
107	W	LOW SIDE START SW LED
108	L/R	SHIFT LOCK SOLENOID OUT
109	-	-
110	-	-
111	P	ACC LED
112	-	-
113	L	ACC RELAY OUT
114	W	AS DOOR ANT A
115	BG	AS DOOR ANT B
116	W	ROOM ANT 2 A
117	G/B	FL FLASHER
118	-	-
119	R	RF NMOCO
120	-	-
121	G	DR DOOR ANT B
122	P	DR DOOR ANT A
123	W	ROOM ANT 1 A
124	G	ROOM ANT 1 B
125	-	-
126	P	IMMO START BUTTON ANT B
127	BG	IMMO START BUTTON ANT A
128	B	ROOM ANT 2 B

7R	6R	5R	4R	□	3R	2R	1R
16R	15R	14R	13R	12R	11R	10R	9R



Terminal No.	Color of Wire	Signal Name	Signal Name
129	R/G	BATTERY SAVER OUT	
130	LG	SUPER LOCK/DOOR UNLOCK AS	
131	W	BAT BOM FUSE	
132	Y	DOOR LOCK AS/FRL	
133	BR	DOOR UNLOCK AS/FRL	
134	B	GND2	
135	O	DOOR LOCK DIS/FRL	
136	L	ROOM LAMP CONT	
137	V	DOOR UNLOCK DIS/FRL	
138	V	BAT REAR DOOR	
139	W	BAT POWER F/L	
140	LG	P/W POWER SUPPLY G/N	
141	V	P/W POWER SUPPLY BAT	
142	Y	BAT FRONT DOOR	
143	B	GND1	



Terminal No.	Color of Wire	Signal Name
1	B	GROUND
2	L	RELAY CONTROL
3	R	RELAY OUTPUT
5	W	BATTERY

AAMIA5024GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000014388569

OVERALL SEQUENCE



DETAILED FLOW

A
B
C
D
E
F
G
H
I
J
K
L
PCS
N
O
P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]

1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the component or system that is malfunctioning.

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT).
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

NOTE:

Freeze frame data is useful if the DTC is not detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-51, "DTC Inspection Priority Chart"](#), and determine trouble diagnosis order.

Is DTC detected?

YES >> GO TO 7.

NO >> Refer to [GI-47, "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Refer to [GI-47, "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Inspection End.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

PROCEDURE FOR TEMPORARILY DISABLING THE IGNITION BATTERY SAVER SYSTEM

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]

PROCEDURE FOR TEMPORARILY DISABLING THE IGNITION BATTERY SAVER SYSTEM

Description

INFOID:0000000014388570

The ignition battery saver system can be temporarily disabled, without using CONSULT, to prevent it from functioning when performing trouble diagnosis. Refer to [PCS-76, "Work Procedure"](#).

Work Procedure

INFOID:0000000014388571

1. Enter the vehicle carrying a registered Intelligent Key.
2. Place the ignition switch in the OFF position.
3. Without depressing the brake pedal, press and hold the push-button ignition switch continuously for ten seconds.
4. Check that the buzzer in the combination meter sounds for 2 seconds.
5. Operation is completed.

NOTE:

When the ignition switch is placed in any position other than ON, the ignition battery saver system is activated again.

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

DTC Description

INFOID:000000014692786

Description

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. CAN Communication Signal Chart. Refer to [LAN-74, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
U1000	CAN COMM CIRCUIT (CAN communication circuit)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	2 seconds or more

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

—

Diagnosis Procedure

INFOID:000000014692787

1. SELF DIAGNOSTIC RESULT

CONSULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" mode of "BCM".
3. Check DTC.

Is DTC "U1000" displayed?

YES >> Refer to [LAN-53, "Trouble Diagnosis Flow Chart"](#).
 NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).
 NO-2 >> Confirmation after repair: Inspection End.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

U1010 CONTROL UNIT (CAN)**DTC Description**

INFOID:000000014692788

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
U1010	CONTROL UNIT(CAN) (Control unit)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	2 seconds or more

POSSIBLE CAUSE

- BCM

FAIL-SAFE

—

Diagnosis Procedure

INFOID:000000014692789

1. REPLACE BCM

When DTC U1010 is detected, replace BCM.

>> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

< DTC/CIRCUIT DIAGNOSIS >

B260A IGNITION RELAY**DTC Description**

INFOID:000000014388576

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B260A	IGN RELAY	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	2 seconds or more

POSSIBLE CAUSE

- Harness or connectors
- BCM
- IPDM E/R

FAIL SAFE

—

DTC CONFIRMATION PROCEDURE**1. PERFORM DTC CONFIRMATION PROCEDURE****① CONSULT**

1. Turn ignition switch ON under the following conditions and wait for at least 2 seconds:
 - AT selector lever is in the P (park) or N (neutral) position.
 - Release the brake pedal.
2. Perform "Self Diagnostic Result" mode of "BCM".

Is DTC B260A detected?

YES >> Refer to [PCS-79, "Diagnosis Procedure"](#).
 NO >> Inspection End.

Diagnosis Procedure

INFOID:000000014388577

Regarding Wiring Diagram information, refer to [PCS-57, "CUMMINS 5.0L : Wiring Diagram"](#).**1. SELF DIAGNOSTIC RESULT****① CONSULT**

Perform "Self Diagnostic Result" mode of "IPDM E/R".

Are any DTCs detected?

YES >> Refer to [PCS-23, "DTC Index"](#).
 NO >> GO TO 2.

2. CHECK IGNITION RELAY-1 POWER SUPPLY (IPDM E/R)

Check voltage between IPDM E/R connector E130 terminal 68 and ground.

IPDM E/R		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E130	68	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).
 NO >> GO TO 3.

B260A IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

3. CHECK IGNITION RELAY-1 POWER SUPPLY (BCM)

Check voltage between BCM connector M19 terminal 70 and ground.

BCM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M19	70	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

YES >> Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

B261A PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

B261A PUSH-BUTTON IGNITION SWITCH

DTC Description

INFOID:0000000014388578

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B261A	ENGINE SW (Push-button ignition switch)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	1 second or more

POSSIBLE CAUSE

- Harness or connectors
[Push-button ignition switch circuit is open or shorted]
- BCM
- IPDM E/R

FAIL-SAFE

—

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

CONSULT

1. Press the push-button ignition switch under the following conditions, and wait for at least 1 second.
 - AT selector lever is in the P (park) or N (neutral) position.
 - Release the brake pedal.
2. Perform "Self Diagnostic Result" mode of "BCM".

Is DTC B261A detected?

YES >> Refer to [PCS-81, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000014388579

Regarding Wiring Diagram information, refer to [PCS-57, "CUMMINS 5.0L : Wiring Diagram"](#).

1. CHECK PUSH-BUTTON IGNITION SWITCH OUTPUT SIGNAL (PUSH-BUTTON IGNITION SWITCH)

1. Disconnect push-button ignition switch connector.
2. Check voltage between push-button ignition switch connector M46 terminal 8 and ground.

Push-button ignition switch		Ground	Voltage (Approx.)
Connector	Terminal		
M46	8	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK IGNITION SWITCH OUTPUT SIGNAL (IPDM E/R)

Check voltage between IPDM E/R connector E130 terminal 66 and ground.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

B261A PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E130	66	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

3. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (IPDM E/R)

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector E130 and BCM connector M18.
3. Check continuity between IPDM E/R connector E130 terminal 66 and push-button ignition switch connector M46 terminal 8.

IPDM E/R		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
E130	66	M46	8	Yes

4. Check continuity between IPDM E/R connector E130 terminal 66 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E130	66	—	No

Is the inspection result normal?

YES >> Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace harness or connectors.

4. CHECK IGNITION SWITCH OUTPUT SIGNAL (BCM)

Check voltage between BCM connector M18 terminal 1 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M18	1	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

5. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (BCM)

1. Turn ignition switch OFF.
2. Disconnect BCM connector M18 and IPDM E/R connector E130.
3. Check continuity between BCM connector M18 terminal 1 and push-button ignition switch connector M46 terminal 8.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M18	1	M46	8	Yes

4. Check continuity between BCM connector M18 terminal 1 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M18	1	—	No

Is the inspection result normal?

B261A PUSH-BUTTON IGNITION SWITCH

[POWER DISTRIBUTION SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

YES >> Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

B26F1 IGNITION RELAY**DTC Description**

INFOID:0000000014388580

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B26F1	IGN RELAY OFF STUCK FAIL (Ignition relay off)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	–
		Threshold	–
		Diagnosis delay time	2 seconds or more

POSSIBLE CAUSE

- Harness or connectors
(Ignition relay circuit is open)
- BCM
- IPDM E/R

FAIL-SAFE

Inhibit engine cranking.

DTC CONFIRMATION PROCEDURE**1. PERFORM DTC CONFIRMATION PROCEDURE****④ CONSULT**

1. Turn ignition switch ON under the following conditions, and wait for 2 seconds or more:
 - AT selector lever is in the P (park) or N (neutral) position.
 - Do not depress brake pedal.
2. Perform “Self Diagnostic Result” mode of “BCM”.

Is DTC B26F1 detected?

YES >> Go to [PCS-84, "Diagnosis Procedure"](#).
 NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000014388581

Regarding Wiring Diagram information, refer to [PCS-57, "CUMMINS 5.0L : Wiring Diagram"](#).**1. SELF DIAGNOSTIC RESULT****④ CONSULT**

1. Perform “Self Diagnostic Result” mode of “IPDM E/R”.
2. Erase DTCs.
3. Turn ignition switch OFF.
4. Turn ignition switch ON.
5. Perform “Self Diagnostic Result” mode of “IPDM E/R”.

Are any DTCs detected?

YES >> Refer to [PCS-23, "DTC Index"](#).
 NO >> GO TO 2.

2. CHECK IGNITION RELAY-1 CONTROL SIGNAL (IPDM E/R)

Check voltage between BCM connector M19 terminal 70 and ground.

BCM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			

B26F1 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

M19	70	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

3. CHECK IGNITION RELAY-1 CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector E130 and BCM connector M19.
3. Check continuity between IPDM E/R connector E130 terminal 68 and BCM connector M19 terminal 70.

IPDM E/R		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E130	68	M19	70	Yes

4. Check continuity between IPDM E/R connector E130 terminal 68 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E130	68	—	No

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

B26F2 IGNITION RELAY**DTC Description**

INFOID:0000000014388582

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B26F2	IGN RELAY ON STUCK FAIL (Ignition relay on)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	–
		Threshold	–
		Diagnosis delay time	2 seconds or more

POSSIBLE CAUSE

- Harness or connectors
(Ignition relay circuit is shorted)
- BCM
- IPDM E/R

FAIL-SAFE

Inhibit engine cranking

DTC CONFIRMATION PROCEDURE**1. PERFORM DTC CONFIRMATION PROCEDURE****④ CONSULT**

1. Turn ignition switch ON under the following conditions, and wait for 2 seconds or more:
 - AT selector lever is in the P (park) or N (neutral) position.
 - Do not depress brake pedal.
2. Perform “Self Diagnostic Result” mode of “BCM”.

Is DTC B26F2 detected?

YES >> Go to [PCS-86, "Diagnosis Procedure"](#).
 NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000014388583

Regarding Wiring Diagram information, refer to [PCS-57, "CUMMINS 5.0L : Wiring Diagram"](#).**1. SELF DIAGNOSTIC RESULT****④ CONSULT**

1. Perform “Self Diagnostic Result” mode of “IPDM E/R”.
2. Erase DTCs.
3. Turn ignition switch OFF.
4. Turn ignition switch ON.
5. Perform “Self Diagnostic Result” mode of “IPDM E/R”.

Are any DTCs detected?

YES >> Refer to [PCS-23, "DTC Index"](#).
 NO >> GO TO 2.

2. CHECK IGNITION RELAY-1 CONTROL SIGNAL (IPDM E/R)

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector E130.
3. Check voltage between IPDM E/R connector E130 terminal 68 and ground.

B26F2 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

IPDM E/R		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E130	68	—	Ignition: OFF	0V

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> GO TO 3.

3. CHECK IGNITION RELAY-1 CONTROL SIGNAL CIRCUIT

1. Disconnect BCM connector M19.
2. Check voltage between IPDM E/R connector E130 terminal 68 and ground.

IPDM E/R		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E130	68	—	Ignition: OFF	0V

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

B26F6 BCM

DTC Description

INFOID:000000014388584

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B26F6	IGN USM CONT FAIL (Body control module)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	–
		Threshold	–
		Diagnosis delay time	0.5 seconds or more

POSSIBLE CAUSE

- BCM

FAIL-SAFE

DTC CONFIRMATION PROCEDURE

1. CHECK DTC PRIORITY

If DTC B26F6 is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for the DTC U1000 or U1010.

Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000: Refer to [PCS-77, "DTC Description"](#). U1010: Refer to [PCS-78, "DTC Description"](#).

NO >> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON under the following conditions, and wait for 0.5 seconds or more:

- AT selector lever is in the P (park) or N (neutral) position.
- Do not depress brake pedal.

2. Perform "Self Diagnostic Result" mode of "BCM".

Is DTC B26F6 detected?

YES >> Go to [PCS-88, "Diagnosis Procedure"](#).

NO >> Inspection End.

Diagnosis Procedure

INFOID:000000014388585

Regarding Wiring Diagram information, refer to [PCS-57, "CUMMINS 5.0L : Wiring Diagram"](#).

1. SELF DIAGNOSTIC RESULT

CONSULT

Perform "Self Diagnostic Result" mode of "IPDM E/R".

Are any DTCs detected?

YES >> Refer to [PCS-23, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK IGNITION RELAY-1 POWER SUPPLY (IPDM E/R)

Check voltage between IPDM E/R connector E130 terminal 68 and ground.

IPDM E/R		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E130	68	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> GO TO 3.

3. CHECK IGNITION RELAY-1 POWER SUPPLY (BCM)

Check voltage between BCM connector M19 terminal 70 and ground.

BCM		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M19	70	—	Ignition: OFF	0V
			Ignition: ON	Battery voltage

Is the inspection result normal?

YES >> Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

PUSH-BUTTON IGNITION SWITCH

Component Function Check

INFOID:0000000014388586

1. CHECK FUNCTION

CONSULT

1. Select "PUSH SW" in "Data Monitor" mode of BCM.
2. Check the push-button ignition switch signal under the following conditions.

Test item	Condition	Status
PUSH SW	Push-button ignition switch is pressed	On
	Push-button ignition switch is not pressed	Off

Is the indication normal?

YES >> Inspection End.
NO >> Go to [PCS-90, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000014388587

Regarding Wiring Diagram information, refer to [PCS-57, "CUMMINS 5.0L : Wiring Diagram"](#).

1. CHECK PUSH-BUTTON IGNITION SWITCH OUTPUT SIGNAL (PUSH-BUTTON IGNITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector M46 and IPDM E/R connector E130.
3. Check voltage between push-button ignition switch connector M46 terminal 8 and ground.

Push-button ignition switch		Ground	Voltage (Approx.)
Connector	Terminal		
M46	8	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (BCM)

1. Disconnect BCM connector M18.
2. Check continuity between BCM connector M18 terminal 1 and push-button ignition switch connector M46 terminal 8.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M18	1	M46	8	Yes

3. Check continuity between BCM connector M18 terminal 1 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M18	1	—	No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
NO >> Repair or replace harness or connectors.

3. CHECK IGNITION SWITCH OUTPUT SIGNAL (IPDM E/R)

Check voltage between IPDM E/R connector E130 terminal 66 and ground.

PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E130	66	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (IPDM E/R)

1. Disconnect BCM connector M18.
2. Check continuity between IPDM E/R connector E130 terminal 66 and push-button ignition switch connector M46 terminal 8.

IPDM E/R		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
E130	66	M46	8	Yes

3. Check continuity between IPDM E/R connector E130 terminal 66 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E130	66	—	No

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace harness or connectors.

5. CHECK PUSH-BUTTON IGNITION SWITCH GROUND CIRCUIT

Check continuity between push-button ignition switch connector M46 terminal 4 and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M46	4	—	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness or connectors.

6. CHECK PUSH-BUTTON IGNITION SWITCH

Refer to [PCS-91, "Component Inspection"](#).

Is the inspection result normal?

YES >> Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace push-button ignition switch. Refer to [PCS-98, "Removal and Installation"](#).

Component Inspection

INFOID:000000014388588

1. CHECK PUSH-BUTTON IGNITION SWITCH

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check continuity between push-button ignition switch terminals.

Push-button ignition switch terminals	Condition	Continuity
4 – 8	Pressed	Yes
	Not pressed	No

Is the inspection result normal?

PUSH-BUTTON IGNITION SWITCH

[POWER DISTRIBUTION SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

YES >> Inspection End.

NO >> Replace push-button ignition switch. Refer to [PCS-98, "Removal and Installation".](#)

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000014692790

Regarding Wiring Diagram information, refer to [BCS-54, "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.	
	Cummins 5.0L	VK56VD
Fusible link battery power	R (50A)	N (50A)
BCM battery fuse	1 (10A)	1 (10A)

Is the fuse or fusible link blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.
2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M81	131	(-)	Battery voltage
	139		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	134	—	Yes
	143		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000014692791

Regarding Wiring Diagram information, refer to [PCS-25, "CUMMINS 5.0L : Wiring Diagram"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

1. CHECK FUSIBLE LINKS

Check that the following fusible links are not blown.

Terminal	Signal name	Fusible link No.	
		Cummins 5.0L	VK56VD
1	Battery power supply	A (250A), D (100A)	A (250A), B (80A)
2		C (100A)	E (60A)
20		F (250A), J (100A), P (40A)	A (250A), C (100A), U (40A)

Is the fusible link blown?

YES >> Replace the blown fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connectors E118 and E120.
2. Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E118	1	(-)	Battery voltage
	2		
E120	20		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R connectors E123 and E124.
2. Check continuity between IPDM E/R connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E123	52	—	Yes
	62		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

SYMPTOM DIAGNOSIS

PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE

Description

INFOID:000000014388591

Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.

NOTE:

The engine start function, door lock function, power distribution system, and NATS-IVIS in the Intelligent Key system are closely related to each other regarding control. The vehicle security function can operate only when the door lock and power distribution system are operating normally.

Conditions of Vehicle (Operating Conditions)

- "ENGINE START BY I-KEY" in "WORK SUPPORT" is ON when setting on CONSULT.
- One or more of Intelligent Keys with registered Intelligent Key ID is in the vehicle.

Diagnosis Procedure

INFOID:000000014388592

1. PERFORM WORK SUPPORT

CONSULT

Perform "INSIDE ANT DIAGNOSIS" in "Work support" mode of "INTELLIGENT KEY".

Refer to [PCS-52, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)".](#)

>> GO TO 2.

2. SELF DIAGNOSTIC RESULT

CONSULT

Perform "Self Diagnostic Result" mode of "BCM".

Are any DTCs detected?

YES >> Refer to [BCS-52, "DTC Index".](#)

NO >> GO TO 3.

3. CHECK PUSH-BUTTON IGNITION SWITCH

Check push-button ignition switch.

Refer to [PCS-90, "Component Function Check".](#)

Is the operation normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning parts.

4. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident".](#)

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR DOES NOT ILLUMINATE

Diagnosis Procedure

INFOID:0000000014388593

1. CHECK PUSH-BUTTON IGNITION SWITCH OPERATION

Check push-button ignition switch.

Refer to [PCS-90, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR POWER CIRCUIT

1. Disconnect push-button ignition switch connector.

2. Check voltage between push-button ignition switch connector M46 terminal 3 and ground.

Push-button ignition switch		Ground	Voltage (Approx.)
Connector	Terminal		
M46	3	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR CONTROL CIRCUIT

1. Turn ignition switch OFF.

2. Disconnect BCM connector M80.

3. Check continuity between BCM connector M80 terminal 111 and push-button ignition switch connector M46 terminal 7.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M80	111	M46	7	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness or connectors.

4. REPLACE BCM

Replace BCM. Refer to [BCS-79, "Removal and Installation"](#)

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

REMOVAL AND INSTALLATION

BCM (BODY CONTROL MODULE)

Removal and Installation

INFOID:000000014388594

For removal and installation of the BCM (Body Control Module), refer to [BCS-79, "Removal and Installation".](#)

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

PUSH-BUTTON IGNITION SWITCH

< REMOVAL AND INSTALLATION >


[POWER DISTRIBUTION SYSTEM]

PUSH-BUTTON IGNITION SWITCH

Exploded View

INFOID:0000000014388595

SEC.253



ALKIA2470ZZ

1. NATS antenna amp.


2. Push-button ignition switch

Removal and Installation

INFOID:0000000014388596


REMOVAL

1. Remove the center console. Refer to [IP-24, "Removal and Installation"](#).
2. Remove the cluster lid C side finisher.
3. Disconnect the push-button ignition switch electrical connector.
4. Release the pawl on each side of the push-button ignition switch (1) and remove from the cluster lid C side finisher.



ALKIA4174ZZ

5. Release the pawl on each side and remove the push-button ignition switch (1) from the NATS antenna amp (2).



ALKIA4175ZZ

INSTALLATION

Installation is in the reverse order of removal.