

SECTION PWC

POWER WINDOW CONTROL SYSTEM

CONTENTS

PRECAUTION	4	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH	16
PRECAUTIONS	4	Reference Value	16
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH	18
Precaution for Work	4	Reference Value	18
PREPARATION	5	WIRING DIAGRAM	20
PREPARATION	5	POWER WINDOW SYSTEM	20
Special Service Tool	5	Wiring Diagram	20
SYSTEM DESCRIPTION	6	BASIC INSPECTION	32
COMPONENT PARTS	6	DIAGNOSIS AND REPAIR WORKFLOW	32
Component Parts Location	6	Work Flow	32
Main Power Window and Door Lock/Unlock Switch	7	INSPECTION AND ADJUSTMENT	34
Power Window and Door Lock/Unlock Switch RH	7	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL	34
Rear Power Window Switch	7	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description	34
Power Window Motor	7	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement	34
Rear Power Slide Glass Switch	8	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	34
Rear Power Slide Glass Motor	8	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description	34
SYSTEM	9	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement	34
System Description	9	DTC/CIRCUIT DIAGNOSIS	36
Fail-safe	10	POWER SUPPLY AND GROUND CIRCUIT	36
DIAGNOSIS SYSTEM (BCM)	12	BCM	36
COMMON ITEM	12	BCM : Diagnosis Procedure	36
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	12	POWER WINDOW MAIN SWITCH	36
RETAINED PWR	13		
RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)	13		
ECU DIAGNOSIS INFORMATION	15		
BCM (BODY CONTROL MODULE)	15		
List of ECU Reference	15		

A
B
C
D
E

F
G
H
I
J

PWC

L
M
N

O

P

POWER WINDOW MAIN SWITCH : Diagnosis Procedure	36	FRONT POWER WINDOW SWITCH	55
FRONT POWER WINDOW SWITCH (PASSENGER SIDE)	37	FRONT POWER WINDOW SWITCH : Description	55
FRONT POWER WINDOW SWITCH (PASSENGER SIDE) : Diagnosis Procedure	38	FRONT POWER WINDOW SWITCH : Component Function Check	55
REAR POWER WINDOW SWITCH	38	FRONT POWER WINDOW SWITCH : Diagnosis Procedure	56
REAR POWER WINDOW SWITCH : Diagnosis Procedure	39	REAR POWER SLIDE GLASS CIRCUIT CHECK	58
POWER WINDOW MOTOR	40	Rear Power Slide Glass Circuit Inspection	58
DRIVER SIDE	40	REAR POWER SLIDE GLASS OPEN RELAY CHECK	59
DRIVER SIDE : Component Function Check	40	Rear Power Slide Glass Open Relay Check	59
DRIVER SIDE : Diagnosis Procedure	40	REAR POWER SLIDE GLASS CLOSE RELAY CHECK	61
PASSENGER SIDE	41	Rear Power Slide Glass Close Relay Check	61
PASSENGER SIDE : Component Function Check	41	SYMPTOM DIAGNOSIS	63
PASSENGER SIDE : Diagnosis Procedure	41	NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH	63
REAR LH	42	Diagnosis Procedure	63
REAR LH : Component Function Check	42	DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE	64
REAR LH : Diagnosis Procedure	42	Diagnosis Procedure	64
REAR RH	43	FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE	65
REAR RH : Component Function Check	43	Diagnosis Procedure	65
REAR RH : Diagnosis Procedure	43	REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE	66
ENCODER	45	Diagnosis Procedure	66
DRIVER SIDE	45	REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE	67
DRIVER SIDE : Component Function Check	45	Diagnosis Procedure	67
DRIVER SIDE : Diagnosis Procedure	45	ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)	68
PASSENGER SIDE	47	Diagnosis Procedure	68
PASSENGER SIDE : Component Function Check	47	ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)	69
PASSENGER SIDE : Diagnosis Procedure	47	Diagnosis Procedure	69
DOOR SWITCH	50	AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)	70
Component Function Check	50	Diagnosis Procedure	70
Diagnosis Procedure	50	AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)	71
Component Inspection	51	Diagnosis Procedure	71
DOOR KEY CYLINDER SWITCH	52		
Component Function Check	52		
Diagnosis Procedure	52		
Component Inspection	53		
POWER WINDOW SERIAL LINK	54		
POWER WINDOW MAIN SWITCH	54		
POWER WINDOW MAIN SWITCH : Description	54		
POWER WINDOW MAIN SWITCH : Component Function Check	54		
POWER WINDOW MAIN SWITCH : Diagnosis Procedure	54		

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY	REAR POWER SLIDE GLASS DOES NOT OPERATE	76
.....72	Diagnosis Procedure	76
Diagnosis Procedure		72
DOES NOT OPERATE BY KEY CYLINDER SWITCH	REMOVAL AND INSTALLATION	77
.....73		
Diagnosis Procedure		73
KEYLESS POWER WINDOW DOWN DOES NOT OPERATE	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH	77
.....74	Removal and Installation	77
Diagnosis Procedure		74
POWER WINDOW LOCK SWITCH DOES NOT FUNCTION	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH	79
.....75	Removal and Installation	79
Diagnosis Procedure		75
REAR POWER WINDOW SWITCH		80
	Removal and Installation	80
REAR POWER SLIDE GLASS SWITCH		81
	Removal and Installation	81

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000014391417

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

Precaution for Work

INFOID:0000000014391418

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

PREPARATION

PREPARATION

Special Service Tool

INFOID:000000014391419

A

B

C

D

E

F

G

H

I

J

PWC

L


M

N

O

P

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.)	Tool name	Description
— (J-46534) Trim Tool Set	 AWJIA0483ZZ	Removing trim components

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000014391420



ANKIA3808ZZ

No.	Part	Function
1.	Rear power slide glass motor	Refer to PWC-8, "Rear Power Slide Glass Motor".
2.	Rear power window switch RH	Refer to PWC-7, "Rear Power Window Switch".
3.	Rear power window motor RH	Refer to PWC-7, "Power Window Motor".
4.	Front door switch RH	<ul style="list-style-type: none">Detects door open/close condition and transmits to BCM.Refer to DLK-15, "Front Door Switch".
5.	Power window and door lock/unlock switch RH	Refer to PWC-7, "Power Window and Door Lock/Unlock Switch RH".
6.	Front power window motor RH	Refer to PWC-7, "Power Window Motor".
7.	Rear power slide glass switch	Refer to PWC-8, "Rear Power Slide Glass Switch".
8.	BCM	<ul style="list-style-type: none">Supplies power to the window switches.Controls retained power.Refer to BCS-5, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
9.	Front power window motor LH	Refer to PWC-7, "Power Window Motor".
10.	Main power window and door lock/unlock switch	Refer to PWC-7, "Main Power Window and Door Lock/Unlock Switch".
11.	Front door lock assembly LH (key cylinder switch)	Transmits operation condition of door key cylinder switch to main power window and door lock/unlock switch.
12.	Front door switch LH	<ul style="list-style-type: none">Detects door open/close condition and transmits to BCM.Refer to DLK-15, "Front Door Switch".
13.	Rear power window motor LH	Refer to PWC-7, "Power Window Motor".
14.	Rear power window switch LH	Refer to PWC-7, "Rear Power Window Switch".


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Main Power Window and Door Lock/Unlock Switch

INFOID:0000000014391421


- Main power window and door lock/unlock switch controls all power windows.
- Main power window and door lock/unlock switch integrates UP/DOWN switch, power window lock switch, and door lock/unlock switch.
- Main power window and door lock/unlock switch controls power window lock function and AUTO UP/DOWN function.
- Receives encoder pulse signal and then controls anti-pinch system.



Power Window and Door Lock/Unlock Switch RH

INFOID:0000000014391422


- Power window and door lock/unlock switch RH transmits AUTO UP/DOWN signal to front power window motor RH.
- Receives AUTO UP/DOWN signal from BCM and then transmits to front power window motor RH.
- Receives encoder pulse signal and then controls anti-pinch system.



Rear Power Window Switch

INFOID:0000000014391423


- Each power window switch transmits UP/DOWN signal to each motor.
- Each power window switch transmits UP/DOWN signal from main power window and door lock/unlock switch to each motor.



Power Window Motor

INFOID:0000000014391424

- Integrates the encoder for front power windows.
- Starts operation according to signals from each power window switch.
- Transmits each power window motor rotation as a pulse signal to each power window switch.




COMPONENT PARTS

< SYSTEM DESCRIPTION >

Rear Power Slide Glass Switch

INFOID:0000000014391425


- Rear power slide glass switch is located in the overhead console.
- Rear power slide glass transmits OPEN/CLOSE signal to the rear power slide glass motor.



Rear Power Slide Glass Motor

INFOID:0000000014391426

- Starts operation according to signal from rear power sliding glass switch.
- Transmits rear power sliding glass motor rotation as a pulse signal to rear power sliding glass switch.



SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM

System Description

INFOID:0000000014391427

SYSTEM DIAGRAM



POWER WINDOW OPERATION

- Power window system is activated by the power window switches when the ignition switch is in the ON position or during the retained power operation after ignition switch turns OFF.
- Main power window and door lock/unlock switch can open/close door glass.
- Front and rear power window switches can open/close the corresponding door glass.
- Power window lock switch can lock all power windows other than driver front.
- Front power windows open when pressing Intelligent Key unlock button for 3 seconds.
- If door glass receives resistance that is more than the specified value and the power window is in the AUTO-UP operation, power window will move in the reverse direction (anti-pinch function).

REAR POWER SLIDE GLASS OPERATION (IF EQUIPPED)

- Rear power slide glass system is operable during the retained power operation timer after turning ignition switch ON and OFF.
- Rear power slide glass switch can open/close the rear power slide glass.

SYSTEM

< SYSTEM DESCRIPTION >

POWER WINDOW AUTO-OPERATION

- AUTO-UP/DOWN operation can be performed when each power window motor turns to AUTO.
- Encoder continues detecting the movement of power window motor and outputs the encoder pulse signal to power window switch while power window motor is operating.
- Power window switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully open/closed position.
- Power window motor is operable in case encoder is malfunctioning.
- AUTO function does not operate if encoder is malfunctioning.

POWER WINDOW SERIAL LINK

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signals mentioned below are transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH.

- Keyless power window down signal.

- Door switch signal.

The signals mentioned below are transmitted from power window main switch to front power window switch (passenger side).

- Front passenger side door window operation signal.

- Retained power operation signal.

RETAINED POWER OPERATION

- Retained power operation is an additional power supply function that enables the power window system to operate for 45 seconds even after the ignition switch is turned OFF.

Retained Power Function Cancel Conditions:

- Front door CLOSED (door switch OFF) → OPEN (door switch ON).
- When ignition switch is ON again
- When timer time passes (45 seconds)

POWER WINDOW LOCK FUNCTION

Ground circuit inside main power window and door lock/unlock switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the main power window and door lock/unlock switch.

ANTI-PINCH OPERATION

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150 mm (5.9 in) or 2 seconds when detected.
- Encoder continues detecting the movement of power window motor and transmits to the power window switch as the encoder pulse signal while power window motor is operating.
- Resistance is applied to the power window motor rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window switch lowers the door glass for 150 mm (5.9 in) or 2 seconds after it detects encoder pulse signal frequency change.

Operation Condition

When front door glass AUTO-UP operation is performed, anti-pinch function does not operate just before the door glass closes and is fully closed.

NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

Fail-safe

INFOID:0000000014391428

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when an error beyond the regulation value is detected between the fully closed position and the actual position of the glass.

SYSTEM

< SYSTEM DESCRIPTION >

Malfunction	Malfunction condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing for more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control:

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000014697570

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none">The vehicle specification can be read and saved.The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions:

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays it on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed at the moment a particular DTC is detected	A
Odo/Trip Meter	km	Total mileage (Odometer value) at the moment a particular DTC is detected	B
Vehicle Condition	SLEEP>LOCK	Power position status at the moment a particular DTC is detected*	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK").
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF").
	LOCK>ACC		While turning power supply position from "LOCK" to "ACC".
	ACC>ON		While turning power supply position from "ACC" to "IGN".
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopped and selector lever is in P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF".
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK".
	OFF>ACC		While turning power supply position from "OFF" to "ACC".
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING".
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF") to low power consumption mode.
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK") to low power consumption mode.
	LOCK		Power supply position is "LOCK" (Ignition switch OFF)*
	OFF		Power supply position is "OFF" (Ignition switch OFF)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING		Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> The number is 0 when a malfunction is detected now. The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition is switched OFF → ON. The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. 	PWC

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met:

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:0000000014697571

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:000000014391431

ECU	Reference
BCM	BCS-32, "Reference Value"
	BCS-51, "Fail Safe"
	BCS-51, "DTC Inspection Priority Chart"
	BCS-52, "DTC Index"

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH


< ECU DIAGNOSIS INFORMATION >

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Reference Value



INFOID:0000000014391432

TERMINAL LAYOUT




AWKIA2145ZZ

PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/ Output		
1 (B)	Ground	Ground	Output	—	0 V
3 (W/R)	Ground	Door lock actuator signal	Output	—	—
4 (R)	12 (B)	Encoder pulse signal 2	Input	When power window motor operates	 (V) 6 4 2 0 10 ms JMKIA0070GB
5 (BG)	12 (B)	Encoder pulse signal 1	Input	When power window motor operates	 (V) 6 4 2 0 10 ms JMKIA0070GB
6 (SB)	Ground	Rear power window motor RH DOWN signal.	Output	When rear power window switch RH is operated DOWN	Battery voltage
7 (V)	Ground	Rear power window motor RH UP signal.	Output	When rear power window switch RH is operated UP	Battery voltage
8 (L)	Ground	Rear power window motor LH DOWN signal.	Output	When rear power window switch LH is operated DOWN	Battery voltage
9 (Y)	Ground	Rear power window motor LH UP signal.	Output	When rear power window switch LH is operated UP	Battery voltage
10 (LG)	Ground	Ignition switch power supply	Input	Ignition switch ON	Battery voltage
				Other than above	0 V

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/ Output		
11 (W/L)	Ground	Power window serial link	Input/ Output	IGN SW ON or power window operating	 JPMIA0013GB
12 (B)	Ground	Encoder ground	—	—	0 V
14 (P)	Ground	Encoder power supply	Output	When ignition is ON or power window timer operates	Battery voltage
15 (B/W)	Ground	Door lock actuator signal	Output	—	Battery voltage
17 (W)	19 (R)	Main power window and door lock/unlock switch UP signal	Output	When main power window and door lock/unlock switch is operated UP	Battery voltage
18 (V)	Ground	Battery power supply	Input	—	Battery voltage
19 (R)	17 (W)	Main power window and door lock/unlock switch DOWN signal	Output	When main power window and door lock/unlock switch is operated DOWN	Battery voltage

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PWC

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH


< ECU DIAGNOSIS INFORMATION >

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH




Reference Value

INFOID:0000000014391433

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/ Output		
3 (W/L)	Ground	Power window serial link	Input/ Output	IGN SW ON or power window operating	 JPMIA0013GB
4 (G/B)	Ground	Encoder ground	—	—	—
5 (W)	Ground	Encoder power supply	Output	When ignition switch is ON or power window timer operates	Battery voltage
7 (B)	Ground	Ground	—	—	—
8 (V)	Ground	Battery power supply	Input	—	Battery voltage
9 (R/L)	4 (G/B)	Encoder pulse signal 1	Input	When power window motor operates	 JMKIA0070GB
10 (L/W)	4 (G/B)	Encoder pulse signal 2	Input	When power window motor operates	 JMKIA0070GB

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/ Output		
11 (G)	12 (L)	Assistant window switch UP signal	Output	When power window and door lock/unlock switch RH is oper- ated UP	Battery voltage
12 (L)	11 (G)	Assistant window switch DOWN signal	Output	When power window and door lock/unlock switch RH is oper- ated DOWN	Battery voltage

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

POWER WINDOW SYSTEM


< WIRING DIAGRAM >

WIRING DIAGRAM

POWER WINDOW SYSTEM


Wiring Diagram

INFOID:0000000014391434



POWER WINDOW SYSTEM

< WIRING DIAGRAM >



AAKWA1580GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM CONNECTORS

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Type	TK10FW-N8
Connector Color	WHITE



Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4
Connector Color	WHITE



28J	L	TO MAIN HARNESS
29J	G/O	TO MAIN HARNESS
30	SB	TO MAIN HARNESS
31J	LG	TO MAIN HARNESS
32J	R	TO MAIN HARNESS
33J	L	TO MAIN HARNESS
34J	Y	TO MAIN HARNESS
35J	P	TO MAIN HARNESS
36J	Q/R	TO MAIN HARNESS
37J	L/G	TO MAIN HARNESS
38J	SB	TO MAIN HARNESS
39J	Y/L	TO MAIN HARNESS
40J	BR	TO MAIN HARNESS
41J	L	TO MAIN HARNESS
42J	L	TO MAIN HARNESS
43J	SB	TO MAIN HARNESS
44J	BR	TO MAIN HARNESS
45J	BG	TO MAIN HARNESS
46J	P/Y	TO MAIN HARNESS
47J	Y/G/R	TO MAIN HARNESS
48J	V	TO MAIN HARNESS
49J	B/R/Y	TO MAIN HARNESS
50J	G/W	TO MAIN HARNESS
51J	-	TO MAIN HARNESS
52J	SHIELD	TO MAIN HARNESS
53J	R	TO MAIN HARNESS
54J	L	TO MAIN HARNESS
55J	R	TO MAIN HARNESS
56J	W	TO MAIN HARNESS
57J	L/G	TO MAIN HARNESS
58J	O	TO MAIN HARNESS
59J	-	TO MAIN HARNESS
60J	SHIELD	TO MAIN HARNESS
61J	G	TO MAIN HARNESS
62J	-	TO MAIN HARNESS
63J	R/W	TO MAIN HARNESS
64J	L/W	TO MAIN HARNESS
65J	SHIELD	TO MAIN HARNESS
66J	B	TO MAIN HARNESS
67J	SHIELD	TO MAIN HARNESS
68J	Q/L	TO MAIN HARNESS
69J	SHIELD	TO MAIN HARNESS
70J	BR	TO MAIN HARNESS
71J	L/W	TO MAIN HARNESS
72J	-	TO MAIN HARNESS
73J	-	TO MAIN HARNESS
74J	SHIELD	TO MAIN HARNESS
75J	L/G/B	TO MAIN HARNESS
76J	R	TO MAIN HARNESS
77J	SHIELD	TO MAIN HARNESS
78J	G/R/B	TO MAIN HARNESS
79J	B	TO MAIN HARNESS

1	2	3	4
---	---	---	---

Terminal	Color of Wire No.	Signal Name
1	P	TO MAIN HARNESS
2J	R/Y	TO MAIN HARNESS
3J	L	TO MAIN HARNESS
4J	U/B	TO MAIN HARNESS
5J	G/W	TO MAIN HARNESS
6J	L/G/Y	TO MAIN HARNESS
7J	B/R/G	TO MAIN HARNESS
8J	S/B/R	TO MAIN HARNESS
9J	BR	TO MAIN HARNESS
10J	-	TO MAIN HARNESS
11J	O/B	TO MAIN HARNESS
12J	L	TO MAIN HARNESS
13J	S/B/O	TO MAIN HARNESS
14J	Y	TO MAIN HARNESS
15J	-	TO MAIN HARNESS
16J	R	TO MAIN HARNESS
17J	G	TO MAIN HARNESS
18J	SB	TO MAIN HARNESS
19J	O	TO MAIN HARNESS
20J	O/B	TO MAIN HARNESS
21J	Y/R	TO MAIN HARNESS
22J	P	TO MAIN HARNESS
23J	W	TO MAIN HARNESS
24J	W/R	TO MAIN HARNESS
25J	V	TO MAIN HARNESS
26J	L	TO MAIN HARNESS
27J	R	TO MAIN HARNESS

AAKIA4142GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM CONNECTORS


Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NS8
Connector Color	WHITE



Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Type	TH80-MDGY-CS16-TM4
Connector Color	GRAY
	
	H.S.



Connector No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
B149	SBG	TO MAIN HARNESS. (WITHOUT CLIMATE CONTROLLED SEATS)	1A	SBG	TO MAIN HARNESS. (WITHOUT CLIMATE CONTROLLED SEATS)
Connector Name	WIRE TO WIRE	TO MAIN HARNESS. (WITH CLIMATE CONTROLLED SEATS)	1A	SB	TO MAIN HARNESS. (WITH CLIMATE CONTROLLED SEATS)
Connector Type	TH80MDGY-CS16-TM4	TO MAIN HARNESS	2A	L	TO MAIN HARNESS
Connector Color	GRAY	TO MAIN HARNESS	3A	V	TO MAIN HARNESS
		TO MAIN HARNESS	4A	Y/W	TO MAIN HARNESS
		TO MAIN HARNESS	5A	B	TO MAIN HARNESS
		TO MAIN HARNESS	6A	L/B	TO MAIN HARNESS
		TO MAIN HARNESS	7A	W	TO MAIN HARNESS
		TO MAIN HARNESS	8A	LG	TO MAIN HARNESS
		TO MAIN HARNESS	9A	GR	TO MAIN HARNESS
		TO MAIN HARNESS	10A	BR	TO MAIN HARNESS
		TO MAIN HARNESS	11A	LG	TO MAIN HARNESS
		TO MAIN HARNESS	12A	BR/G	TO MAIN HARNESS
		TO MAIN HARNESS	13A	Y/W	TO MAIN HARNESS
		TO MAIN HARNESS	14A	R/G	TO MAIN HARNESS
		TO MAIN HARNESS	15A	Y/L	TO MAIN HARNESS
		TO MAIN HARNESS	16A	OR/L	TO MAIN HARNESS
		TO MAIN HARNESS	17A	L	TO MAIN HARNESS
		TO MAIN HARNESS	18A	Y	TO MAIN HARNESS
		TO MAIN HARNESS	19A	LG	TO MAIN HARNESS
		TO MAIN HARNESS	20A	R	TO MAIN HARNESS
		TO MAIN HARNESS	21A	BG	TO MAIN HARNESS
		TO MAIN HARNESS	22A	LC/R	TO MAIN HARNESS
		TO MAIN HARNESS	23A	Y/G	TO MAIN HARNESS
		TO MAIN HARNESS	24A	BR/Y	TO MAIN HARNESS
		TO MAIN HARNESS	25A	-	TO MAIN HARNESS
		TO MAIN HARNESS	26A	GR	TO MAIN HARNESS
		TO MAIN HARNESS	27A	LG	TO MAIN HARNESS
		TO MAIN HARNESS	28A	LG/B	TO MAIN HARNESS
		TO MAIN HARNESS	29A	-	TO MAIN HARNESS
		TO MAIN HARNESS	30A	BR	TO MAIN HARNESS
		TO MAIN HARNESS	31A	WR	TO MAIN HARNESS
		TO MAIN HARNESS	32A	GR	TO MAIN HARNESS
		TO MAIN HARNESS	33A	-	TO MAIN HARNESS
		SHIELD	34A	SHIELD	TO MAIN HARNESS
		TO MAIN HARNESS	35A	P	TO MAIN HARNESS
		TO MAIN HARNESS	36A	B	TO MAIN HARNESS
		TO MAIN HARNESS	37A	-	TO MAIN HARNESS
		TO MAIN HARNESS	38A	RB	TO MAIN HARNESS
		TO MAIN HARNESS	39A	GO	TO MAIN HARNESS
		TO MAIN HARNESS	40A	V	TO MAIN HARNESS
		SHIELD	41A	SHIELD	TO MAIN HARNESS
		TO MAIN HARNESS	42A	SHIELD	TO MAIN HARNESS
		TO MAIN HARNESS	43A	R	TO MAIN HARNESS
		TO MAIN HARNESS	44A	G	TO MAIN HARNESS
		TO MAIN HARNESS	45A	-	TO MAIN HARNESS
		TO MAIN HARNESS	46A	-	TO MAIN HARNESS
		TO MAIN HARNESS	47A	Y	TO MAIN HARNESS
		TO MAIN HARNESS	48A	BR/W	TO MAIN HARNESS
		TO MAIN HARNESS	49A	RL	TO MAIN HARNESS
		TO MAIN HARNESS	50A	B	TO MAIN HARNESS
		TO MAIN HARNESS	51A	-	TO MAIN HARNESS
		TO MAIN HARNESS	52A	-	TO MAIN HARNESS
		TO MAIN HARNESS	53A	-	TO MAIN HARNESS
		TO MAIN HARNESS	54A	-	TO MAIN HARNESS
		TO MAIN HARNESS	55A	-	TO MAIN HARNESS
		TO MAIN HARNESS	56A	-	TO MAIN HARNESS
		TO MAIN HARNESS	57A	-	TO MAIN HARNESS
		TO MAIN HARNESS	58A	-	TO MAIN HARNESS
		TO MAIN HARNESS	59A	-	TO MAIN HARNESS
		TO MAIN HARNESS	60A	GR/W	TO MAIN HARNESS
		TO MAIN HARNESS	61A	-	TO MAIN HARNESS
		TO MAIN HARNESS	62A	-	TO MAIN HARNESS
		TO MAIN HARNESS	63A	-	TO MAIN HARNESS
		TO MAIN HARNESS	64A	-	TO MAIN HARNESS
		TO MAIN HARNESS	65A	-	TO MAIN HARNESS
		TO MAIN HARNESS	66A	-	TO MAIN HARNESS
		TO MAIN HARNESS	67A	-	TO MAIN HARNESS
		TO MAIN HARNESS	68A	-	TO MAIN HARNESS
		TO MAIN HARNESS	69A	Y/R	TO MAIN HARNESS
		TO MAIN HARNESS	70A	RG	TO MAIN HARNESS
		TO MAIN HARNESS	71A	-	TO MAIN HARNESS
		TO MAIN HARNESS	72A	Y/B	TO MAIN HARNESS
		TO MAIN HARNESS	73A	G	TO MAIN HARNESS
		TO MAIN HARNESS	74A	BR	TO MAIN HARNESS
		TO MAIN HARNESS	75A	SHIELD	TO MAIN HARNESS



AAKTA4143GI

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM CONNECTORS

Connector No.	D2	Color of Wire	Signal Name
Connector Name	WIRE TO WIRE		
Connector Type	NS16FW-CS		
Connector Color	WHITE		
			
			

Terminal No.	Color of Wire	Signal Name
6	SB	RR DN
7	V	RR UP
8	L	RL DN
9	Y	RL UP
10	LG	IGN
11	W/L	COM
12	B	ENCODER GND
13	-	-
14	P	ENCODER+
15	B/W	D LOCK ACTR DR
16	-	-

Terminal No.	Color of Wire	Signal Name
1	B/W	TO MAIN HARNESS
2	GR/B	TO MAIN HARNESS
3	L	TO MAIN HARNESS
4	R	TO MAIN HARNESS
5	W/R	TO MAIN HARNESS
6	W/L	TO MAIN HARNESS
7	V	TO MAIN HARNESS
8	B	TO MAIN HARNESS
9	L/W	TO MAIN HARNESS
10	L/R	TO MAIN HARNESS
11	L/W	TO MAIN HARNESS
12	L	TO MAIN HARNESS
13	Y	TO MAIN HARNESS
14	SB	TO MAIN HARNESS
15	V	TO MAIN HARNESS
16	LG	TO MAIN HARNESS

Connector No.	D8	Color of Wire	Signal Name
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH		
Connector Type	NS03FW-CS		
Connector Color	WHITE		
			
			

Terminal No.	Color of Wire	Signal Name
17	W	DR UP
18	V	BAT
19	R	DR DN

Connector No.	D9	Color of Wire	Signal Name
Connector Name	FRONT POWER WINDOW MOTOR LH		
Connector Type	RS06FG		
Connector Color	GREEN		
			
			

Terminal No.	Color of Wire	Signal Name
1	B/W	TO MAIN HARNESS
2	B	TO MAIN HARNESS
3	W/L	TO MAIN HARNESS
4	V	TO MAIN HARNESS
5	W/B	TO MAIN HARNESS
6	G/Y	TO MAIN HARNESS
7	W/B	TO MAIN HARNESS
8	U/B	TO MAIN HARNESS
9	G/Y	TO MAIN HARNESS
10	-	TO MAIN HARNESS

Terminal No.	Color of Wire	Signal Name
1	B	GNB
2	-	-
3	W/R	D LOCK ACTR DR
4	R	ENCODER SIG2
5	BG	ENCODER SIG1

AAKIA4144GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM CONNECTORS

Connector No.	Connector Name	Connector Type	Connector Color	Pinout Diagram	Pinout Table	Connector No.	Connector Name	Connector Type	Connector Color	Pinout Diagram	Pinout Table
D201	WIRE TO WIRE				1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	12	O/L	TO BODY NO. 2 HARNESS			8 V UP
TK10MW-NS8						13	Y	TO BODY NO. 2 HARNESS			
WHITE						14	BR	TO BODY NO. 2 HARNESS			
						15	B	TO BODY NO. 2 HARNESS			
						16	BR	TO BODY NO. 2 HARNESS			
						17	Y	TO BODY NO. 2 HARNESS			
						18	V	TO BODY NO. 2 HARNESS			
D204	REAR POWER WINDOW MOTOR LH	RS06FG	GREEN		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	1	L	UP	D304	REAR POWER WINDOW MOTOR RH	RS06FG
						2	—	—			
						3	LG	DOWN			
						4	—	—			
						5	—	—			
						6	—	—			
D301	WIRE TO WIRE	TK10MW-NS8	WHITE		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	1	L	UP	D309	REAR POWER WINDOW SWITCH RH	NS08FW-CS
						2	—	—			
						3	LG	DOWN			
						4	—	—			
						5	—	—			
						6	—	—			
D203	REAR POWER WINDOW SWITCH LH	NS08FW-CS	WHITE		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	1	—	—			
						2	—	—			
						3	—	—			
						4	—	—			
						5	—	—			
						6	—	—			
						7	—	—			
						8	O/L	TO BODY NO. 2 HARNESS			
						9	—	—			
						10	—	—			
						11	R/L	TO BODY NO. 2 HARNESS			

AAKIA4145GB

POWER WINDOW SYSTEM


< WIRING DIAGRAM >

POWER WINDOW SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1P	R	IGNITION
2P	Y	IGNITION
3P	G	IGNITION RELAY OUT
4P	B/W	RH DEF FLY
5P	B/W	RR DEF FLY
6P	O	RR DEF RELAY OUT
7P	G	IGNITION
8P	W	IGNITION
9P	L	BATTERY
10P	-	-
11P	-	-
12P	-	-
13P	R	BATTERY
14P	Y	BATTERY
15P	Y/G	BATTERY
16P	W	BLOWER FAN RELAY OUT




8	B	TO FRONT DOOR LH HARNESS
9	L/W	TO FRONT DOOR LH HARNESS
10	U/R	TO FRONT DOOR LH HARNESS
11	L/W	TO FRONT DOOR LH HARNESS
12	L	TO FRONT DOOR LH HARNESS
13	Y	TO FRONT DOOR LH HARNESS
14	SB	TO FRONT DOOR LH HARNESS
15	V	TO FRONT DOOR LH HARNESS
16	L/G	TO FRONT DOOR LH HARNESS

7P	6P	5P	4P	3P	2P	1P
16P	15P	14P	13P	12P	11P	9P

Connector No.	Connector Name
M18	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH
Connector Color	GREEN
Connector No.	Connector Name



Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW NO ESCL
2	-	-
3	R	A/L POWER SUPPLY 5V
4	W/R	AL SIGNAL
5	-	-
6	-	-
7	-	-
8	-	-
9	-	-
10	SB	COMBI SW/IN 5
11	G/Y	COMBI SW/IN 4
12	Y	COMBI SW/IN 3
13	G/B	COMBI SW/IN 2
14	V	COMBI SW/IN 1
15	-	-
16	-	-
17	P	GND RF A/L
18	V	SECURITY INDICATOR
19	-	-
20	R	SHIFT P
21	R/W	STEP AMP CONT
22	-	-
23	-	AIRCON SW
24	-	-
25	W	BRAKE SW FUSE
26	L	SHORT IN PIN INPUT
27	R/G	BRAKE SW LAMP
28	-	-



60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
80	79	78	77	76	75	74	73	72	71	69	68	67	66	65	64	63	62	61	60
80	79	78	77	76	75	74	73	72	71	69	68	67	66	65	64	63	62	61	60
80	79	78	77	76	75	74	73	72	71	69	68	67	66	65	64	63	62	61	60




Terminal No.	Color of Wire	Signal Name
41	Y/L	TRAILER LIGHT CHECK RELAY OUT
42	R/Y	CARGO LAMP OUT
43	-	-
44	-	-
45	-	-
46	-	-
47	-	-
48	R	HIGH SIDE START SW LED
49	-	-
50	-	-
51	-	-
52	W	AUDIO DONGLE
53	-	-
54	W/L	PW UART
55	W/B	L&F SENSOR K-LINE
56	-	-
57	-	-
58	-	-
59	P	CAN-L
60	L	CAN-H
61	O	REAR DEFOGGER RELAY OUT
62	W	STARTER RELAY OUT
63	-	-
64	P	BUZZER OUT

AAKIA4147GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM CONNECTORS



AAKIA4148GB

POWER WINDOW SYSTEM


< WIRING DIAGRAM >

POWER WINDOW SYSTEM CONNECTORS

Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name
M36	WIRE TO WIRE	Y	23A	Y	TO BODY NO. 2 HARNESS
		L	24A	L	TO BODY NO. 2 HARNESS
		-	25A	-	TO BODY NO. 2 HARNESS
		GR	26A	GR	TO BODY NO. 2 HARNESS
		LG	27A	LG	TO BODY NO. 2 HARNESS
		LG	28A	LG	TO BODY NO. 2 HARNESS
		GR	29A	GR	TO BODY NO. 2 HARNESS
		BR	30A	BR	TO BODY NO. 2 HARNESS
		W/R	31A	W/R	TO BODY NO. 2 HARNESS
		G/R	32A	G/R	TO BODY NO. 2 HARNESS
		-	33A	-	TO BODY NO. 2 HARNESS
		SHIELD	34A	SHIELD	TO BODY NO. 2 HARNESS
		P	35A	P	TO BODY NO. 2 HARNESS
		B	36A	B	TO BODY NO. 2 HARNESS
		-	37A	-	TO BODY NO. 2 HARNESS
		R/B	38A	R/B	TO BODY NO. 2 HARNESS
		G/O	39A	G/O	TO BODY NO. 2 HARNESS
		V	40A	V	TO BODY NO. 2 HARNESS
		SHIELD	41A	SHIELD	TO BODY NO. 2 HARNESS
		R/W	42A	R/W	TO BODY NO. 2 HARNESS
		R	43A	R	TO BODY NO. 2 HARNESS
		G	44A	G	TO BODY NO. 2 HARNESS
		-	45A	-	TO BODY NO. 2 HARNESS
		Y	47A	Y	TO BODY NO. 2 HARNESS
		R/W	48A	R/W	TO BODY NO. 2 HARNESS
		R/L	49A	R/L	TO BODY NO. 2 HARNESS
		B	50A	B	TO BODY NO. 2 HARNESS
		-	51A	-	TO BODY NO. 2 HARNESS
		SHIELD	52A	-	TO BODY NO. 2 HARNESS
		-	53A	-	TO BODY NO. 2 HARNESS
		SHIELD	54A	-	TO BODY NO. 2 HARNESS
		-	55A	-	TO BODY NO. 2 HARNESS
		SHIELD	56A	-	TO BODY NO. 2 HARNESS
		-	57A	-	TO BODY NO. 2 HARNESS
		SHIELD	58A	-	TO BODY NO. 2 HARNESS
		-	59A	-	TO BODY NO. 2 HARNESS
		SHIELD	60A	G/W	TO BODY NO. 2 HARNESS
		-	61A	-	TO BODY NO. 2 HARNESS
		SHIELD	62A	-	TO BODY NO. 2 HARNESS
		-	63A	-	TO BODY NO. 2 HARNESS
		SHIELD	64A	-	TO BODY NO. 2 HARNESS
		-	65A	-	TO BODY NO. 2 HARNESS
		SHIELD	66A	-	TO BODY NO. 2 HARNESS
		-	67A	-	TO BODY NO. 2 HARNESS
		SHIELD	68A	-	TO BODY NO. 2 HARNESS
		-	69A	Y/R	TO BODY NO. 2 HARNESS
		SHIELD	70A	R/G	TO BODY NO. 2 HARNESS
		-	71A	-	TO BODY NO. 2 HARNESS
		SHIELD	72A	W	TO BODY NO. 2 HARNESS
		-	73A	G	TO BODY NO. 2 HARNESS
		SHIELD	74A	W	TO BODY NO. 2 HARNESS
		-	75A	SHIELD	TO BODY NO. 2 HARNESS

AAKIA4149GB


PWC



POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM CONNECTORS



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1J	G	TO BODY HARNESS	6J	G	TO BODY HARNESS
2J	R/Y	TO BODY HARNESS	5J	R	TO BODY HARNESS
3J	L	TO BODY HARNESS	56J	W	TO BODY HARNESS
4J	L/B	TO BODY HARNESS	57J	R	TO BODY HARNESS
5J	B	TO BODY HARNESS	58J	B	TO BODY HARNESS
6J	BR	TO BODY HARNESS	59J	-	TO BODY HARNESS
7J	BG	TO BODY HARNESS	60J	SHIELD	TO BODY HARNESS
8J	SB	TO BODY HARNESS	61J	G	TO BODY HARNESS
9J	BR	TO BODY HARNESS	62J	-	TO BODY HARNESS
10J	R	TO BODY HARNESS	63J	R/W	TO BODY HARNESS
11J	OB	TO BODY HARNESS	64J	L/W	TO BODY HARNESS
12J	L	TO BODY HARNESS	65J	SHIELD	TO BODY HARNESS
13J	W	TO BODY HARNESS	66J	B	TO BODY HARNESS
14J	Y	TO BODY HARNESS	67J	SHIELD	TO BODY HARNESS
15J	-	TO BODY HARNESS	68J	W	TO BODY HARNESS
16J	R	TO BODY HARNESS	69J	SHIELD	TO BODY HARNESS
17J	G	TO BODY HARNESS	70J	B/R	TO BODY HARNESS
18J	SB	TO BODY HARNESS	71J	L/W	TO BODY HARNESS
19J	O	TO BODY HARNESS	72J	-	TO BODY HARNESS
20J	OB	TO BODY HARNESS	73J	-	TO BODY HARNESS
21J	Y	TO BODY HARNESS	74J	SHIELD	TO BODY HARNESS
22J	P	TO BODY HARNESS	75J	R	TO BODY HARNESS
23J	W	TO BODY HARNESS	76J	O	TO BODY HARNESS
24J	WR	TO BODY HARNESS	77J	SHIELD	TO BODY HARNESS
25J	P	TO BODY HARNESS	78J	W	TO BODY HARNESS
26J	L	TO BODY HARNESS	79J	B	TO BODY HARNESS
27J	R	TO BODY HARNESS	80J	W	TO BODY HARNESS

AAKIA4150GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM CONNECTORS

Connector No.	M154
Connector Name	REAR POWER SLIDE GLASS CLOSE-RELAY
Connector Type	MS03FB-M2-LC
Connector Color	BLACK
	

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	TH32MW-NH
Connector Color	WHITE
	

Connector No.	R19
Connector Name	REAR POWER SLIDE GLASS SWITCH
Connector Type	TH06FW-IV
Connector Color	WHITE
	

Terminal No.	Color of Wire	Signal Name
1	LG	P/W POWER SUPPLY GN
2	G	RELAY CONTROL
3	L/Y	RELAY OUTPUT
4	B	GROUND
5	L/W	BATTERY

Terminal No.	Color of Wire	Signal Name
1	LG	P/W POWER SUPPLY GN
2	G	RELAY CONTROL
3	L/Y	RELAY OUTPUT
4	B	GROUND
5	L/W	BATTERY

Terminal No.	Color of Wire	Signal Name
1	SHIELD	TO MAIN HARNESS
2	R	TO MAIN HARNESS
3	W	TO MAIN HARNESS
4	Y/R	TO MAIN HARNESS
5	G/W	TO MAIN HARNESS
6	G/R	TO MAIN HARNESS
7	B	TO MAIN HARNESS
8	L	TO MAIN HARNESS
9	R/G	TO MAIN HARNESS
10	G	TO MAIN HARNESS
11	L/W	TO MAIN HARNESS
12	L	TO MAIN HARNESS
13	GR	TO MAIN HARNESS
14	R	TO MAIN HARNESS
15	W/B	TO MAIN HARNESS
16	U/B	TO MAIN HARNESS
17	-	TO MAIN HARNESS
18	P	TO MAIN HARNESS
19	W/L	TO MAIN HARNESS
20	W/B	TO MAIN HARNESS
21	-	TO MAIN HARNESS
22	-	TO MAIN HARNESS
23	-	TO MAIN HARNESS
24	-	TO MAIN HARNESS
25	-	TO MAIN HARNESS
26	-	TO MAIN HARNESS
27	-	TO MAIN HARNESS
28	Y/R	TO MAIN HARNESS
29	G/R	TO MAIN HARNESS
30	G/W	TO MAIN HARNESS
31	L/G/B	TO MAIN HARNESS
32	Y/W	TO MAIN HARNESS

Terminal No.	Color of Wire	Signal Name
1	LG	P/W POWER SUPPLY GN
2	L/W	RELAY CONTROL
3	B/V	RELAY OUTPUT
4	B	GROUND
5	L/B/R	BATTERY

AAKIA4151GB

A

B

C

D

E

F

G

H

I

PWC

L

M

N

O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000014391435

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW CUSTOMER

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

>> GO TO 2.

2. REPRODUCE THE MALFUNCTION

Reproduce the malfunction that the customer describes on the vehicle.

Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3. SYMPTOM DIAGNOSIS

Use Symptom Diagnosis from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4. COMPONENT DIAGNOSIS

Perform the diagnosis with Component Diagnosis of the applicable system.

>> GO TO 5.

5. REPAIR OR REPLACE THE MALFUNCTIONING PART

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6. PERFORM FINAL OPERATIONAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> Inspection End.

NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000014391436

If any of the following work has been done Initial setting is necessary:

- Power supply to the main power window and door lock/unlock switch or power window motor is cut off by the removal of battery terminal or the battery fuse is blown.
- Disconnection and connection of main power window and door lock/unlock switch harness connector.
- Removal and installation of motor from regulator assembly.
- Operation of regulator assembly as an independent unit.
- Removal and installation of glass.
- Removal and installation of door glass run.

The following specified operations can not be performed under the non-initialized condition:

- Auto-up operation
- Anti-pinch function

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000014391437

INITIALIZATION PROCEDURE

1. Disconnect battery minus terminal or main power and window door lock/unlock switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 2 seconds or more.
5. Initializing procedure is completely.
6. Inspect anti-pinch function.

CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
2. Place a piece of wood near fully closed position.
3. Close door glass completely with AUTO-UP.

- Check that glass lowers for approximately 150 mm (5.9 in) without pinching piece of wood and stops.
- Check that glass does not rise when operating the main power and door lock/unlock switch while lowering.

CAUTION:

- Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
- Check that AUTO-UP operates before inspection when system initialization is performed.
- Do not check with hands and other body parts because they may be pinched. Do not get pinched.
- It may switch to fail-safe mode if open/close operation is performed continuously without full close. Perform initial setting in that situation. Refer to [PWC-10, "Fail-safe"](#)
- Finish initial setting. Otherwise, next operation cannot be done.

1. Auto-up operation
2. Anti-pinch function

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000014391438

Refer to [PWC-34, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"](#).

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Re-

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

quirement

INFOID:000000014391439

Refer to [PWC-34, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#) for initialization procedure and check anti-pinch function.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT BCM

BCM : Diagnosis Procedure

INFOID:0000000014697572

Regarding Wiring Diagram information, refer to [BCS-54, "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.	
	Cummins 5.0L	VK56VD
Fusible link battery power	R (50A)	N (50A)
BCM battery fuse	1 (10A)	1 (10A)

Is the fuse or fusible link blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.
2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M81	131	(-)	Battery voltage
	139		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	134	—	Yes
	143		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:0000000014391441

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

1. CHECK POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch connectors.
3. Turn ignition switch ON.
4. Check voltage between main power window and door lock/unlock switch harness connectors and ground.

(+) Main power window and door lock/unlock switch		(-)	Voltage (Approx.)
Connector	Terminal		
D7	10	Ground	Battery voltage
D8	18		

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M81.
3. Check continuity between BCM harness connector M81 and main power window and door lock/unlock switch harness connector.

BCM		Main power window and door lock/unlock switch		Continuity
Connector	Terminal	Connector	Terminal	
M17	140	D7	10	Yes
	141	D8	18	

4. Check continuity between BCM harness connector M81 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	140		Yes
	141		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between main power window and door lock/unlock switch harness connector D7 and ground.

Main power window and door lock/unlock switch		Ground	Continuity
Connector	Terminal		
D7	1		Yes

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT POWER WINDOW SWITCH (PASSENGER SIDE) : Diagnosis Procedure

INFOID:000000014391442

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).

1. CHECK POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector D129.
3. Turn ignition switch ON.
4. Check voltage between power window and door lock/unlock switch RH harness connector D129 and ground.

(+) Power window and door lock/unlock switch RH		(-)	Voltage (Approx.)
Connector	Terminal		
D129	8	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M81.
3. Check continuity between BCM harness connector M81 and power window and door lock/unlock switch RH harness connector D129.

BCM		Power window and door lock/unlock switch RH		Continuity
Connector	Terminal	Connector	Terminal	
M81	141	D129	8	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between power window and door lock/unlock switch RH harness connector D129 and ground.

Power window and door lock/unlock switch RH		Ground	Continuity
Connector	Terminal		
D129	7		Yes

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

REAR POWER WINDOW SWITCH

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000014391443

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).

1. CHECK POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH connector D203 and rear power window switch RH connector D309.
3. Turn ignition switch ON.
4. Check voltage between rear power window switch harness connector D203, D309, and ground.

(+) Connector		(-) Terminal	Voltage (Approx.)
Rear power window switch			
Connector	Terminal		
LH	D203	4	Ground
RH	D309		Battery voltage

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector M17 and rear power window switch harness connector D203 and D309.

BCM		Rear power window switch			Continuity
Connector	Terminal	Connector		Terminal	
M17	140	LH	D203	4	Yes
		RH	D309		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between rear power window switch harness connector D203, D309, and ground.

Rear power window switch		Ground	Continuity
Connector	Terminal		
LH	D203		
RH	D309	2	Yes

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

POWER WINDOW MOTOR DRIVER SIDE

DRIVER SIDE : Component Function Check

INFOID:000000014391444

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check front power window motor LH operation with main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Refer to [PWC-40, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000014391445

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).

1. CHECK FRONT POWER WINDOW MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH connector D9.
3. Turn ignition switch ON.
4. Check voltage between front power window motor LH harness connector D9 and ground.

(+)		(-)	Condition	Voltage (Approx.)		
Front power window motor LH	Connector	Terminal				
D9	1	Ground	Main power window and door lock/unlock switch	UP		
				Battery voltage		
	3			DOWN		
				0		
				UP		
				0		
				Battery voltage		

Is the inspection result normal?

YES >> Replace front power window motor LH. Refer to [GW-19, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch connector D8.
3. Check continuity between main power window and door lock/unlock switch harness connector D8 and front power window motor LH harness connector D9.

Main power window and door lock/unlock switch		Front power window motor LH		Continuity
Connector	Terminal	Connector	Terminal	
D8	17	D9	1	Yes
	19		3	

4. Check continuity between main power window and door lock/unlock switch harness connector D8 and ground.

Main power window and door lock/unlock switch		Ground	Continuity
Connector	Terminal		
D8	17		
	19		

Is the inspection result normal?

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-77, "Removal and Installation".](#)

NO >> Repair or replace harness.

PASSENGER SIDE

PASSENGER SIDE : Component Function Check

INFOID:000000014391446

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check front power window motor RH operation with main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

Is the inspection result normal?

YES >> Front power window motor RH is OK.

NO >> Refer to [PWC-41, "PASSENGER SIDE : Diagnosis Procedure".](#)

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000014391447

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram".](#)

1. CHECK FRONT POWER WINDOW MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor RH connector D105.
3. Turn ignition switch ON.
4. Check voltage between front power window motor RH harness connector D105 and ground.

(+) Front power window motor RH		(-)	Condition	Voltage (Approx.)	
Connector	Terminal			UP	Battery voltage
D105	1	Ground	Power window and door lock/unlock switch RH	DOWN	0
	3			UP	0
				DOWN	Battery voltage

Is the inspection result normal?

YES >> Replace front power window motor RH. Refer to [GW-19, "Removal and Installation".](#)

NO >> GO TO 2.

2. CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/switch RH connector D129.
3. Check continuity between power window and door lock/unlock switch RH harness connector D129 and front power window motor RH harness connector D105.

Power window and door lock/unlock switch RH		Front power window motor RH		Continuity
Connector	Terminal	Connector	Terminal	
D129	11	D105	1	Yes
	12		3	

4. Check continuity between power window and door lock/unlock switch RH harness connector D105 and ground.

Power window and door lock/unlock switch RH		Ground	Continuity
Connector	Terminal		
D129	11		No
	12		

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-79, "Removal and Installation"](#).

NO >> Repair or replace harness.

REAR LH

REAR LH : Component Function Check

INFOID:0000000014391448

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check rear power window motor LH operation with main power window and door lock/unlock switch or rear power window switch LH.

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Refer to [PWC-42, "REAR LH : Diagnosis Procedure"](#).

REAR LH : Diagnosis Procedure

INFOID:0000000014391449

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).

1. CHECK REAR POWER WINDOW MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH connector D204.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH harness connector D204 and ground.

(+) Rear power window motor LH		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
D204	3	Ground	Rear power window switch LH	UP
				Battery voltage
				DOWN
	1			0

Is the inspection result normal?

YES >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH connector D203.
3. Check continuity between rear power window switch LH harness connector D203 and rear power window motor LH harness connector D204.

Rear power window switch LH		Rear power window motor LH		Continuity
Connector	Terminal	Connector	Terminal	
D203	5	D204	1	Yes
	6		3	

4. Check continuity between rear power window switch LH harness connector D203 and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Rear power window switch LH		Ground	Continuity
Connector	Terminal		
D203	5		No
	6		

Is the inspection result normal?

YES >> Replace rear power window switch LH. Refer to [PWC-80, "Removal and Installation"](#).
 NO >> Repair or replace harness.

REAR RH

REAR RH : Component Function Check

INFOID:0000000014391450

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check rear power window motor RH operation with main power window and door lock/unlock switch or rear power window switch RH.

Is the inspection result normal?

YES >> Rear power window motor RH is OK.
 NO >> Refer to [PWC-43, "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:0000000014391451

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).

1. CHECK REAR POWER WINDOW MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH connector D304.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH harness connector D304 and ground.

(+)		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
D304	1	Ground	Rear power window switch RH	UP
	3			Battery voltage
				DOWN
				0
				UP
				Battery voltage
				DOWN
				0

Is the inspection result normal?

YES >> Replace rear power window motor RH. Refer to [GW-25, "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH connector D309.
3. Check continuity between rear power window switch RH harness connector D309 and rear power window motor RH harness connector D304.

Rear power window switch RH		Rear power window motor RH		Continuity
Connector	Terminal	Connector	Terminal	
D309	5	D304	1	Yes
	6		3	

4. Check continuity between rear power window switch RH harness connector D309 and ground.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Rear power window switch RH		Ground	Continuity
Connector	Terminal		
D309	5		No
	6		

Is the inspection result normal?

YES >> Replace rear power window switch RH. Refer to [PWC-80, "Removal and Installation"](#).
NO >> Repair or replace harness.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

ENCODER DRIVER SIDE

DRIVER SIDE : Component Function Check

INFOID:000000014391452

1. CHECK ENCODER

Check that driver side door glass performs AUTO open/close operation normally by main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Encoder is OK.

NO >> Refer to [PWC-45, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure


INFOID:000000014391453

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).

1. CHECK ENCODER SIGNAL

1. Turn ignition switch ON.
2. Check signal between main power window and door lock/unlock switch harness connector D7 and ground with oscilloscope.

Signal name	(+)		(-)	Signal (Reference value)
	Main power window and door lock/unlock switch			
	Connector	Terminal		
Encoder signal 1	D7	5	Ground	Refer to following signals
Encoder signal 2		4		



Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-77, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK ENCODER SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch connector D7 and front power window motor LH connector D9.
3. Check continuity between main power window and door lock/unlock switch harness connector D7 and front power window motor LH harness connector D9.

Main power window and door lock/unlock switch		Front power window motor LH		Continuity
Connector	Terminal	Connector	Terminal	
D7	4	D9	5	Yes
	5		6	

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between main power window and door lock/unlock switch harness connector D7 and ground.

Main power window and door lock/unlock switch		Ground	Continuity
Connector	Terminal		
D7	4		
	5		No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK ENCODER POWER SUPPLY

1. Connect main power window and door lock/unlock switch connector D9.
2. Turn ignition switch ON.
3. Check voltage between front power window motor LH harness connector D9 and ground.

(+)		(-)	Voltage (Approx.)		
Front power window motor LH					
Connector	Terminal				
D9	2	Ground	Battery voltage		

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK ENCODER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch connector D7.
3. Check continuity between main power window and door lock/unlock switch harness connector D7 and front power window motor LH harness connector D9.

Main power window and door lock/unlock switch		Front power window motor LH		Continuity
Connector	Terminal	Connector	Terminal	
D7	14	D9	2	

4. Check continuity between main power window and door lock/unlock switch harness connector D7 and ground.

Main power window and door lock/unlock switch		Ground	Continuity
Connector	Terminal		
D7	14		No

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-77, "Removal and Installation"](#).

NO >> Repair or replace harness.

5. CHECK GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Check continuity between front power window motor LH harness connector D9 and ground.

Front power window motor LH		Ground	Continuity
Connector	Terminal		
D9	4		Yes

Is the inspection result normal?

YES >> Replace front power window motor LH. Refer to [GW-19, "Removal and Installation"](#).

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 6.

6. CHECK GROUND CIRCUIT 2

1. Disconnect main power window and door lock/unlock switch connector D7.
2. Check continuity between main power window and door lock/unlock switch harness connector D7 and front power window motor LH harness connector D9.

Main power window and door lock/unlock switch		Front power window motor LH		Continuity
Connector	Terminal	Connector	Terminal	
D7	12	D9	4	Yes

3. Check continuity between main power window and door lock/unlock switch harness connector D7 and ground.

Main power window and door lock/unlock switch		Ground	Continuity
Connector	Terminal		
D7	12		No

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-77, "Removal and Installation"](#).

NO >> Repair or replace harness.

PASSENGER SIDE

PASSENGER SIDE : Component Function Check

INFOID:000000014391454

1. CHECK ENCODER

Check that passenger side door glass performs AUTO open/close operation normally by main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

Is the inspection result normal?

YES >> Encoder is OK.

NO >> Refer to [PWC-47, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000014391455

PWC

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).


1. CHECK ENCODER SIGNAL

1. Turn ignition switch ON.
2. Check signal between power window and door lock/unlock switch RH harness connector D129 and ground with oscilloscope.

Signal name	(+)		(-)	Signal (Reference value)		
	Power window and door lock/unlock switch RH					
	Connector	Terminal				
Encoder signal 1	D129	9	Ground	Refer to following signals		
Encoder signal 2		10				

ENCODER

< DTC/CIRCUIT DIAGNOSIS >



JMKIA5210GB

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-79, "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK ENCODER SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector D129 and front power window motor RH connector D105.
3. Check continuity between power window and door lock/unlock switch RH harness connector D129 and front power window motor RH harness connector D105.

Power window and door lock/unlock switch RH		Front power window motor RH		Continuity
Connector	Terminal	Connector	Terminal	
D129	9	D105	6	Yes
	10		5	

4. Check continuity between power window and door lock/unlock switch RH harness connector D129 and ground.

Power window and door lock/unlock switch RH		Ground	Continuity
Connector	Terminal		
D129	9		Yes
	10		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK ENCODER POWER SUPPLY

1. Connect power window and door lock/unlock switch RH connector D129.
2. Turn ignition switch ON.
3. Check voltage between power window and door lock/unlock switch RH harness connector D129 and ground.

(+)		(-)	Voltage (Approx.)
Power window and door lock/unlock switch RH			
Connector	Terminal		
D129	2	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4. CHECK ENCODER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH connector D129.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between power window and door lock/unlock switch RH harness connector D129 and power window and door lock/unlock motor RH harness connector D105.

Power window and door lock/unlock switch RH		Front power window motor RH		Continuity
Connector	Terminal	Connector	Terminal	
D129	5	D105	2	Yes

4. Check continuity between power window and door lock/unlock switch RH harness connector D129 and ground.

Power window and door lock/unlock switch RH		Ground	Continuity
Connector	Terminal		
D129	5		

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-79, "Removal and Installation"](#).

NO >> Repair or replace harness.

5.CHECK GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Check continuity between front power window motor RH harness connector D105 and ground.

Front power window motor RH		Ground	Continuity
Connector	Terminal		
D105	4		

Is the inspection result normal?

YES >> Replace front power window motor RH. Refer to [GW-19, "Removal and Installation"](#).

NO >> GO TO 6.

6.CHECK GROUND CIRCUIT 2

1. Disconnect power window and door lock/unlock switch RH connector D129.
2. Check continuity between power window and door lock/unlock switch RH harness connector D129 and front power window motor RH harness connector D105.

Power window and door lock/unlock switch RH		Front power window motor RH		Continuity
Connector	Terminal	Connector	Terminal	
D129	4	D105	4	Yes

3. Check continuity between power window and door lock/unlock switch RH harness connector D129 and ground.

Power window and door lock/unlock switch RH		Ground	Continuity
Connector	Terminal		
D129	4		

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-79, "Removal and Installation"](#).

NO >> Repair or replace harness.

PWC

L

M

N

O

P

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR SWITCH

Component Function Check

INFOID:0000000014697573

1. CHECK FUNCTION

CONSULT

1. Select "DOOR LOCK" of "BCM".
2. Select "DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL" or "DOOR SW-RR" in "Data Monitor" mode.
3. Check that the function operates normally according to the following conditions:

Monitor Item	Condition		Status
DOOR SW-DR	Front door LH	Open	On
		Closed	Off
DOOR SW-AS	Front door RH	Open	On
		Closed	Off
DOOR SW-RL	Rear door LH	Open	On
		Closed	Off
DOOR SW-RR	Rear door RH	Open	On
		Closed	Off

Is the inspection result normal?

YES >> Door switch is OK.
NO >> Refer to [PWC-50, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:0000000014697574

Regarding Wiring Diagram information, refer to [DLK-39, "Wiring Diagram"](#).

1. CHECK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check signal between malfunctioning door switch harness connector and ground using oscilloscope.

(+) Door switch		(-)	Signal (Reference value)
Connector	Terminal		
Front LH	B8	3	 PKIB4960J 7.0 - 8.0 V
Front RH	B108		
Rear LH	B18		
Rear RH	B116		

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between door switch harness connector and BCM harness connector.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Door switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
Front LH	B8	3	M20	96
Front RH	B108			94
Rear LH	B18			82
Rear RH	B116			93

3. Check continuity between door switch harness connector and ground.

Door switch		Ground	Continuity
Connector	Terminal		
Front LH	B8		No
Front RH	B108		
Rear LH	B18		
Rear RH	B116		Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR SWITCH

Refer to [DLK-99, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace malfunctioning door switch. Refer to [DLK-191, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000014697575

PWC

1.CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check continuity between door switch terminals.

Door switch		Condition		Continuity	
Terminal		Door switch	Door switch		
3	Ground contact is part of the switch.		Pressed	No	
			Released	Yes	

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace malfunctioning door switch. Refer to [DLK-191, "Removal and Installation"](#).

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR KEY CYLINDER SWITCH

Component Function Check

INFOID:0000000014697576

1. CHECK FUNCTION

CONSULT

1. Select "DOOR LOCK" of "BCM".
2. Select "KEY CYL LK-SW" or "KEY CYL UN-SW" in "Data Monitor" mode.
3. Check that the function operates normally according to the following conditions:

Monitor Item	Condition	Status
KEY CYL LK-SW	Lock	ON
	Neutral / Unlock	OFF
KEY CYL UN-SW	Unlock	ON
	Neutral / Lock	OFF

Is the inspection result normal?

YES >> Door key cylinder switch is OK.
NO >> Refer to [PWC-52, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000014697577

Regarding Wiring Diagram information, refer to [DLK-56, "Wiring Diagram"](#).

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly LH connector.
3. Check voltage between front door lock assembly LH harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		
D14	5	Ground	5 V
	6		

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SWITCH SIGNAL CIRCUIT

1. Disconnect main power window and door lock/unlock switch connector.
2. Check continuity between main power window and door lock/unlock switch harness connector and front door lock assembly LH harness connector.

Main power window and door lock/unlock switch		Front door lock assembly LH		Continuity
Connector	Terminal	Connector	Terminal	
D7	3	D14	6	Yes
	15		5	

3. Check continuity between power window main switch harness connector and ground.

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Main power window and door lock/unlock switch		Ground	Continuity
Connector	Terminal		
D7	3		
	15		No

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-77, "Removal and Installation".](#)

NO >> Repair or replace harness.

3. CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly LH harness connector and ground.

Front door lock assembly LH		Ground	Continuity
Connector	Terminal		
D14	4		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK DOOR KEY CYLINDER SWITCH

Refer to [DLK-111, "Component Inspection".](#)

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly LH. Refer to [DLK-172, "DOOR LOCK : Removal and Installation".](#)

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident".](#)

>> Inspection End.

Component Inspection

INFOID:000000014697578

PWC

1. CHECK DOOR KEY CYLINDER SWITCH

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly LH connector.
3. Check continuity between front door lock assembly LH terminals.

Front door lock assembly LH		Driver side door key cylinder	Condition		Continuity	
Terminal			Unlock		Yes	
5			Neutral / Lock		No	
	4		Lock		Yes	
6			Neutral / Unlock		No	

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace front door lock assembly LH. Refer to [DLK-172, "DOOR LOCK : Removal and Installation".](#)

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

POWER WINDOW SERIAL LINK

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000014391462

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signals mentioned below are transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH:

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH:

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Power window lock switch signal
- Retained power operation signal

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000014391463

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

Check "CDL LOCK SW" or "CDL UNLOCK SW" in "Data Monitor" mode of "BCM (DOOR LOCK)" with CONSULT. Refer to [BCS-20, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Monitor item	Condition	
CDL LOCK SW	LOCK	: ON
	UNLOCK	: OFF
CDL UNLOCK SW	LOCK	: OFF
	UNLOCK	: ON

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-54, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000014391464

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).


Power Window Serial Link Check

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

1. Remove key and close front door LH and RH.
2. Check signal between BCM harness connector M20 and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 seconds just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

Terminal		(-)	Signal (Reference value)
(+)	Terminal		
BCM			
M20	54	Ground	 PIIA1297E

Is the inspection result normal?

YES >> Power window serial link is OK.
NO >> GO TO 2.

2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and main power window and door lock/unlock switch.
3. Check continuity between BCM harness connector M20 and main power window and door lock/unlock switch harness connector D7.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M20	54	D7	11	Yes

4. Check continuity between BCM connector M20 and ground.

BCM connector	Terminal	Ground	Continuity
M20	54		No

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-77, "Removal and Installation"](#).
NO >> Repair or replace harness or connectors.

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:0000000014391465

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signals mentioned below are transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH:

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH:

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Retained power operation signal
- Power window lock switch signal

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:0000000014391466

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH OUTPUT SIGNAL

Check "CDL LOCK SW" or "CDL UNLOCK SW" in "Data Monitor" mode of "" with CONSULT. Refer to [BCS-20, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

Monitor item	Condition	
CDL LOCK SW	LOCK	: ON
	UNLOCK	: OFF
CDL UNLOCK SW	LOCK	: OFF
	UNLOCK	: ON

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-56, "FRONT POWER WINDOW SWITCH : Diagnosis Procedure".](#)

FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:0000000014391467


Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram".](#)

Power Window Serial Link Check

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

1. Remove key and close the front door LH and RH.
2. Check signal between BCM harness connector M20 and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 seconds just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".

Terminal		Signal (Reference value)
(+)	(-)	
BCM connector	Terminal	
M20	54	Ground



PTTA1297E

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> GO TO 2.

2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check continuity between BCM harness connector M20 and power window and door lock/unlock switch RH harness connector M129.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M20	54	D129	3	Yes

4. Check continuity between BCM connector M20 and ground.

BCM connector	Terminal	Ground	Continuity
M20	54		No

Is the inspection result normal?

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-77, "Removal and Installation".](#)

NO >> Repair or replace the harness or connectors.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

REAR POWER SLIDE GLASS CIRCUIT CHECK

< DTC/CIRCUIT DIAGNOSIS >

REAR POWER SLIDE GLASS CIRCUIT CHECK

Rear Power Slide Glass Circuit Inspection

INFOID:0000000014391468

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).

1. CHECK REAR POWER SLIDE GLASS SWITCH OPERATION

1. Turn ignition switch OFF.
2. Disconnect rear power slide glass switch connector R19.
3. Check continuity between rear power slide glass switch terminals 1, 3 and 5.

Terminals		Condition	Continuity
3	5	Rear power drop glass switch is pressed OPEN	Yes
	1	Rear power drop glass switch is pressed CLOSE	Yes

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace rear power slide glass switch. Refer to [PWC-81, "Removal and Installation"](#).

2. CHECK REAR POWER SLIDE GLASS SWITCH GROUND CIRCUIT HARNESS CONTINUITY

Check continuity between rear power slide glass switch connector R19 and ground.

Connector	Terminal	Ground	Continuity
R19	3		Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK REAR POWER SLIDE GLASS SIGNAL

1. Connect rear power slide glass switch.
2. Disconnect rear power slide glass motor connector B150.
3. Turn ignition switch ON.
4. Check voltage between rear power slide glass motor connector B150 and ground.

Connector	(+)	(-)	Condition	Voltage (Approx.)	
B150	1	Ground	Close	Battery voltage	
			Open	0	
	2		Close	0	
			Open	Battery voltage	

Is the inspection result normal?

YES >> Replace rear power slide glass motor. Refer to [GW-27, "Removal and Installation"](#).

NO >> Repair or replace harness.

REAR POWER SLIDE GLASS OPEN RELAY CHECK

< DTC/CIRCUIT DIAGNOSIS >

REAR POWER SLIDE GLASS OPEN RELAY CHECK

Rear Power Slide Glass Open Relay Check

INFOID:000000014391469

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).

1. CHECK REAR POWER SLIDE GLASS OPEN RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power slide glass open relay connector M155.
3. Turn ignition switch ON.
4. Check voltage between rear power slide glass open relay connector M155 and ground.

Connector	(+)	(-)	Voltage (Approx.)
M155	1	Ground	Battery voltage
	5		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

2. CHECK REAR POWER SLIDE GLASS OPEN RELAY

Check continuity between rear power slide glass open relay terminals.

Terminals		Condition	Continuity
3	4	12V direct current supply between terminals 1 and 2	No
		No current supply	Yes
	5	12V direct current supply between terminals 1 and 2	Yes
		No current supply	No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace rear power slide glass open relay.

3. CHECK REAR POWER SLIDE GLASS OPEN RELAY GROUND CIRCUIT

Check continuity between rear power slide glass open relay connector M155 and ground.

Connector	Terminal	Ground	Continuity
M155	4		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK REAR POWER SLIDE GLASS OPEN RELAY CIRCUIT

1. Disconnect rear power slide glass switch.
2. Check continuity between rear power slide glass open relay connector M155 and rear power slide glass switch connector R19.

Rear power slide glass open relay		Rear power slide switch		Continuity
Connector	Terminal	Connector	Terminal	
M155	2	R19	5	Yes

Is the inspection result normal?

REAR POWER SLIDE GLASS OPEN RELAY CHECK

< DTC/CIRCUIT DIAGNOSIS >

YES >> Replace rear power slide glass switch. Refer to [PWC-81, "Removal and Installation"](#).
NO >> Repair or replace harness.

REAR POWER SLIDE GLASS CLOSE RELAY CHECK

< DTC/CIRCUIT DIAGNOSIS >

REAR POWER SLIDE GLASS CLOSE RELAY CHECK

Rear Power Slide Glass Close Relay Check

INFOID:0000000014391470

Regarding Wiring Diagram information, refer to [PWC-20, "Wiring Diagram"](#).

1. CHECK REAR POWER SLIDE GLASS CLOSE RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power slide glass close relay connector M154.
3. Turn ignition switch ON.
4. Check voltage between rear power slide glass close relay connector M154 and ground.

Connector	(+)	(-)	Voltage (Approx.)
M154	1	Ground	Battery voltage
	5		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

2. CHECK REAR POWER SLIDE GLASS CLOSE RELAY

Check continuity between rear power slide glass close relay terminals.

Terminals		Condition	Continuity
3	4	12V direct current supply between terminals 1 and 2	No
		No current supply	Yes
	5	12V direct current supply between terminals 1 and 2	Yes
		No current supply	No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace rear power drop glass close relay.

3. CHECK REAR POWER SLIDE GLASS CLOSE RELAY GROUND CIRCUIT

Check continuity between rear power slide glass close relay connector M154 and ground.

Connector	Terminal	Ground	Continuity
M154	4		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK REAR POWER SLIDE GLASS CLOSE RELAY CIRCUIT

1. Disconnect rear power slide glass switch.
2. Check continuity between rear power slide glass close relay connector M154 and rear power slide glass switch connector R19.

Rear power slide glass open relay		Rear power slide switch		Continuity
Connector	Terminal	Connector	Terminal	
M154	2	R19	1	Yes

Is the inspection result normal?

REAR POWER SLIDE GLASS CLOSE RELAY CHECK

< DTC/CIRCUIT DIAGNOSIS >

YES >> Replace rear power slide glass switch. Refer to [PWC-81, "Removal and Installation"](#).
NO >> Repair or replace harness.

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

Diagnosis Procedure

INFOID:000000014391471

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.

Refer to [BCS-72, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window switch main power supply and ground circuit.

Refer to [PWC-36, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH SERIAL CIRCUIT

Check main power window and door lock/unlock switch serial circuit.

Refer to [PWC-54, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.

Refer to [PWC-36, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:0000000014391472

1. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-40, "DRIVER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident".](#)

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000014391473

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Refer to [PWC-38, "FRONT POWER WINDOW SWITCH \(PASSENGER SIDE\) : Diagnosis Procedure".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH SERIAL LINK CIRCUIT

Check power window and door lock/unlock switch RH serial link circuit.

Refer to [PWC-54, "POWER WINDOW MAIN SWITCH : Component Function Check".](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH circuit.

Refer to [PWC-40, "DRIVER SIDE : Component Function Check".](#)

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident".](#)

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:0000000014391474

1. CHECK REAR POWER WINDOW SWITCH LH

Check rear power window switch LH.

Refer to [PWC-39, "REAR POWER WINDOW SWITCH : Diagnosis Procedure".](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-42, "REAR LH : Component Function Check".](#)

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident".](#)

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:0000000014391475

1. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH.

Refer to [PWC-39, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-43, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000014391476

1. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-45, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

Diagnosis Procedure

INFOID:000000014391477

1. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-45, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMAL-LY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:0000000014391478

1. PERFORM INITIALIZATION PROCEDURE

Refer to [PWC-34, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description"](#).

Does automatic function operate normally?

YES >> Inspection End.

NO >> GO TO 2.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-45, "DRIVER SIDE : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)

Diagnosis Procedure

INFOID:000000014391479

1. PERFORM INITIALIZATION PROCEDURE

Refer to [PWC-34, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description"](#).

Does automatic function operate normally?

YES >> Inspection End.

NO >> GO TO 2.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-45, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

Diagnosis Procedure

INFOID:0000000014391480

1. CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [DLK-98, "Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

DOES NOT OPERATE BY KEY CYLINDER SWITCH

< SYMPTOM DIAGNOSIS >

DOES NOT OPERATE BY KEY CYLINDER SWITCH

Diagnosis Procedure

INFOID:0000000014391481

1. CHECK FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH)

Check front door lock assembly LH (key cylinder switch).

Refer to [DLK-102, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

Diagnosis Procedure

INFOID:0000000014391482

1. CHECK KEYFOB FUNCTION

Check keyfob function.

Refer to [BCS-26, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#) with remote keyless entry system.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:0000000014391483

1. REPLACE MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Replace main power window and door lock/unlock switch.

Refer to [PWC-77, "Removal and Installation"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

REAR POWER SLIDE GLASS DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR POWER SLIDE GLASS DOES NOT OPERATE

Diagnosis Procedure

INFOID:0000000014391484

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.

Refer to [BCS-72, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER SLIDE GLASS SWITCH

Check rear power slide glass switch.

Refer to [PWC-58, "Rear Power Slide Glass Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK REAR POWER SLIDE GLASS MOTOR CIRCUIT

Check rear power slide glass motor circuit.

Refer to [PWC-58, "Rear Power Slide Glass Circuit Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK REAR POWER SLIDE GLASS RELAYS

Check rear power slide glass relays.

Refer to [PWC-59, "Rear Power Slide Glass Open Relay Check"](#) and [PWC-61, "Rear Power Slide Glass Close Relay Check"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH


Removal and Installation

INFOID:000000014391485


REMOVAL

1. Remove the main power window and door lock/unlock switch finisher and main power window and door lock/unlock switch (1) from the door finisher using suitable tool.

 : Clip




2. Disconnect the harness connector (1) from the main power window and door lock/unlock switch.




3. Release the main power window and door lock/unlock switch finisher pawls from the main power window and door lock/unlock switch (1) using suitable tool.

 : Pawl



4. Remove the main power window and door lock/unlock switch (1).



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< REMOVAL AND INSTALLATION >

Whenever the main power window and door lock/unlock switch is disconnected from the harness connector, it is necessary to perform the initialization procedure. Refer to [PWC-34, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description"](#).

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

< REMOVAL AND INSTALLATION >

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH


Removal and Installation

INFOID:0000000014391486

REMOVAL


1. Using a suitable tool release the clips and remove power window and door lock/unlock switch RH and the power window and door lock/unlock switch RH finisher (1).

 : Clip



2. Disconnect the harness connector from the power window and door lock/unlock switch RH.
3. Using a suitable tool, release the pawls and remove the power window and door lock/unlock switch RH (1).

 : Pawl



INSTALLATION

Installation is in the reverse order of removal.

PWC

L

M

N

O

P

REAR POWER WINDOW SWITCH

< REMOVAL AND INSTALLATION >

REAR POWER WINDOW SWITCH

Removal and Installation

INFOID:0000000014391487


REMOVAL

1. Remove the rear power window switch finisher and rear power window switch (1) using suitable tool.

NOTE:

RH shown, LH similar.

 : Clip




ALKIA4347ZZ

2. Disconnect the harness connector from the rear power window switch.

3. Using a suitable tool, release the pawls and remove the rear power window switch (1) from the rear power window switch finisher (2).

 : Pawl



ALKIA3475ZZ

INSTALLATION

Installation is in the reverse order of removal.

REAR POWER SLIDE GLASS SWITCH

< REMOVAL AND INSTALLATION >

REAR POWER SLIDE GLASS SWITCH


Removal and Installation

INFOID:000000014391488

REMOVAL

1. Remove the overhead console. Refer to [INT-32, "Removal and Installation"](#).
2. Disconnect the harness connector from the rear power slide glass switch.
3. Remove rear power slide glass switch (1) from the overhead console using suitable tool.

○ : Pawl



INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P