

# SECTION **SEC**

## SECURITY CONTROL SYSTEM

### CONTENTS

<b>PRECAUTION</b>	4	INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)	19
<b>PRECAUTIONS</b>	4	<b>THEFT ALM</b>	22
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	THEFT ALM : CONSULT Function (BCM - THEFT ALM)	22
Precaution for Work	4	<b>IMMU</b>	23
<b>PREPARATION</b>	5	IMMU : CONSULT Function (BCM - IMMU)	23
<b>PREPARATION</b>	5	<b>DIAGNOSIS SYSTEM (IPDM E/R)</b>	24
Special Service Tool	5	CONSULT Function (IPDM E/R)	24
<b>SYSTEM DESCRIPTION</b>	6	<b>ECU DIAGNOSIS INFORMATION</b>	26
<b>COMPONENT PARTS</b>	6	<b>ECM, IPDM E/R, BCM</b>	26
Component Parts Location	6	List of ECU Reference	26
NATS Antenna Amp.	7	<b>WIRING DIAGRAM</b>	27
Hood Switch	8	<b>INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION</b>	27
<b>SYSTEM</b>	9	Wiring Diagram	27
<b>INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION</b>	9	<b>NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS</b>	41
INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description	9	Wiring Diagram	41
<b>NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS</b>	11	<b>VEHICLE SECURITY SYSTEM</b>	50
NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description	12	Wiring Diagram	50
<b>VEHICLE SECURITY SYSTEM</b>	14	<b>BASIC INSPECTION</b>	64
VEHICLE SECURITY SYSTEM : System Description	14	<b>DIAGNOSIS AND REPAIR WORK FLOW</b>	64
<b>DIAGNOSIS SYSTEM (BCM)</b>	18	Work Flow	64
<b>COMMON ITEM</b>	18	<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT</b>	67
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	18	<b>ECM</b>	67
<b>INTELLIGENT KEY</b>	19	ECM : Description	67
		ECM : Work Procedure	67
		<b>BCM</b>	67

A  
B  
C  
D  
E

F  
G  
H  
I  
J

SEC

L  
M  
N  
O  
P

BCM : Description .....	67	<b>B2557 VEHICLE SPEED .....</b>	96
BCM : Work Procedure .....	67	DTC Description .....	96
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>69</b>	Diagnosis Procedure .....	96
<b>U1000 CAN COMM CIRCUIT .....</b>	<b>69</b>	<b>B2560 STARTER CONTROL RELAY .....</b>	<b>98</b>
DTC Description .....	69	DTC Description .....	98
Diagnosis Procedure .....	69	Diagnosis Procedure .....	98
<b>U1010 CONTROL UNIT (CAN) .....</b>	<b>70</b>	<b>B2601 SHIFT POSITION .....</b>	<b>100</b>
DTC Description .....	70	DTC Description .....	100
Diagnosis Procedure .....	70	Diagnosis Procedure .....	100
Component Inspection .....	102		
<b>P1610 LOCK MODE .....</b>	<b>71</b>	<b>B2602 SHIFT POSITION .....</b>	<b>103</b>
DTC Description .....	71	DTC Description .....	103
Diagnosis Procedure .....	71	Diagnosis Procedure .....	103
Component Inspection .....	105		
<b>P1611 ID DISCORD, IMMU-ECM .....</b>	<b>73</b>	<b>B2603 SHIFT POSITION .....</b>	<b>106</b>
DTC Description .....	73	DTC Description .....	106
Diagnosis Procedure .....	73	Diagnosis Procedure .....	106
Component Inspection .....	109		
<b>P1612 CHAIN OF ECM-IMMU .....</b>	<b>75</b>	<b>B2604 SHIFT POSITION .....</b>	<b>110</b>
DTC Description .....	75	DTC Description .....	110
Diagnosis Procedure .....	75	Diagnosis Procedure .....	110
<b>P1615 DIFFRENCE OF KEY .....</b>	<b>77</b>	<b>B2605 SHIFT POSITION .....</b>	<b>113</b>
DTC Description .....	77	DTC Description .....	113
Diagnosis Procedure .....	77	Diagnosis Procedure .....	113
<b>B2192 ID DISCORD, IMMU-ECM .....</b>	<b>78</b>	<b>B2608 STARTER RELAY .....</b>	<b>116</b>
DTC Description .....	78	DTC Description .....	116
Diagnosis Procedure .....	78	Diagnosis Procedure .....	116
<b>B2193 CHAIN OF ECM-IMMU .....</b>	<b>80</b>	<b>B260F ENGINE STATUS .....</b>	<b>118</b>
DTC Description .....	80	DTC Description .....	118
Diagnosis Procedure .....	80	Diagnosis Procedure .....	118
<b>B2195 ANTI-SCANNING .....</b>	<b>82</b>	<b>B261B REMOTE ENGINE START .....</b>	<b>120</b>
DTC Description .....	82	DTC Description .....	120
Diagnosis Procedure .....	82	Diagnosis Procedure .....	120
<b>B2196 DONGLE UNIT .....</b>	<b>84</b>	<b>B261E VEHICLE TYPE .....</b>	<b>121</b>
DTC Description .....	84	DTC Description .....	121
Diagnosis Procedure .....	84	Diagnosis Procedure .....	121
<b>B2198 NATS ANTENNA AMP. .....</b>	<b>86</b>	<b>B26F3 STARTER CONTROL RELAY .....</b>	<b>123</b>
DTC Description .....	86	DTC Description .....	123
Diagnosis Procedure .....	86	Diagnosis Procedure .....	123
<b>B2555 STOP LAMP .....</b>	<b>88</b>	<b>B26F4 STARTER CONTROL RELAY .....</b>	<b>124</b>
DTC Description .....	88	DTC Description .....	124
Diagnosis Procedure (Without LED combination lamps) .....	88	Diagnosis Procedure .....	124
Diagnosis Procedure (With LED combination lamps) .....	90		
Component Inspection (Stop Lamp Switch) .....	91		
Component Inspection (Stop Lamp Relay) .....	92		
<b>B2556 PUSH-BUTTON IGNITION SWITCH .....</b>	<b>93</b>	<b>B26FC KEY REGISTRATION .....</b>	<b>125</b>
DTC Description .....	93	DTC Description .....	125
Diagnosis Procedure .....	93	Diagnosis Procedure .....	125
Component Inspection .....	94		
<b>B26F7 BCM .....</b>	<b>126</b>		
DTC Description .....	126		
Diagnosis Procedure .....	126		

<b>B210B STARTER CONTROL RELAY .....</b>	127	<b>SYMPTOM DIAGNOSIS .....</b>	144
DTC Description .....	127		
Diagnosis Procedure .....	127		
<b>B210C STARTER CONTROL RELAY .....</b>	128	<b>INTELLIGENT KEY SYSTEM SYMPTOMS ...</b>	144
DTC Description .....	128	Diagnosis Procedure .....	144
Diagnosis Procedure .....	128		
<b>B210D STARTER RELAY .....</b>	129	<b>ENGINE CAN NOT START .....</b>	145
DTC Description .....	129	Description .....	145
Diagnosis Procedure .....	129	Diagnosis Procedure .....	145
<b>B210E STARTER RELAY .....</b>	131	<b>ENGINE DOES NOT START WHEN INTELLI-</b>	
DTC Description .....	131	<b>GENT KEY IS INSIDE OF VEHICLE .....</b>	146
Diagnosis Procedure .....	131	Description .....	146
<b>B210F TRANSMISSION RANGE SWITCH ....</b>	133	Diagnosis Procedure .....	146
DTC Description .....	133		
Diagnosis Procedure .....	133	<b>ENGINE DOES NOT START WHEN INTELLI-</b>	
<b>B2110 TRANSMISSION RANGE SWITCH ....</b>	136	<b>GENT KEY IS INSIDE OF VEHICLE (ONE</b>	
DTC Description .....	136	<b>KEY) .....</b>	148
Diagnosis Procedure .....	136	Description .....	148
<b>POWER SUPPLY AND GROUND CIRCUIT ...</b>	139	Diagnosis Procedure .....	148
<b>BCM .....</b>	139	<b>DOOR DOES NOT LOCK/UNLOCK AND EN-</b>	
BCM : Diagnosis Procedure .....	139	<b>GINE DOES NOT START (REQ SW/PUSH</b>	
<b>IPDM E/R (INTELLIGENT POWER DISTRIBU-</b>		<b>SW) (ONE KEY) .....</b>	149
<b>TION MODULE ENGINE ROOM) .....</b>	139	Description .....	149
IPDM E/R (INTELLIGENT POWER DISTRIBU-		Diagnosis Procedure .....	149
TION MODULE ENGINE ROOM) : Diagnosis Pro-			
cedure .....	139	<b>REMOVAL AND INSTALLATION .....</b>	151
<b>SECURITY INDICATOR LAMP .....</b>	141	<b>NATS ANTENNA AMP. .....</b>	151
Component Function Check .....	141	Removal and Installation .....	151
Diagnosis Procedure .....	141		
<b>HORN FUNCTION .....</b>	143	<b>REMOTE KEYLESS ENTRY RECEIVER .....</b>	152
Component Function Check .....	143	Removal and Installation .....	152
Diagnosis Procedure .....	143		
		<b>PUSH BUTTON IGNITION SWITCH .....</b>	153
		Removal and Installation .....	153
		<b>BCM (BODY CONTROL MODULE) .....</b>	154
		Removal and Installation .....	154

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000014391277

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

### Precaution for Work

INFOID:0000000014391278

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

## PREPARATION

< PREPARATION >


# PREPARATION

## PREPARATION

### Special Service Tool

INFOID:000000014391279

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.)	Tool name	Description
— (J-46534) Trim Tool Set	 AWJIA0483ZZ	Removing trim components

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# COMPONENT PARTS


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000014391280



A. View of center console.

No.	Component	Function
1.	Rear door switch RH	Door switch detects door open/close condition and then transmits ON/OFF signal to BCM.
2.	Inside key antenna (console)	<ul style="list-style-type: none"><li>Inside key antenna (console) detects whether Intelligent Key is inside the vehicle or not, and then transmits the signal to the BCM.</li><li>Refer to <a href="#">DLK-14, "Inside Key Antenna (Console)"</a>.</li></ul>
3.	Front door switch RH	Door switch detects door open/close condition and then transmits ON/OFF signal to BCM.
4.	Inside key antenna (instrument panel)	<ul style="list-style-type: none"><li>Inside key antenna (instrument panel) detects whether Intelligent Key is inside the vehicle or not, and then transmits the signal to the BCM.</li><li>Refer to <a href="#">DLK-14, "Inside Key Antenna (Instrument Center)"</a>.</li></ul>
5.	Remote keyless entry receiver	<ul style="list-style-type: none"><li>Remote keyless entry receiver receives button operation signal and key ID signal of Intelligent Key and then transmits them to BCM.</li><li>Refer to <a href="#">DLK-13, "Remote Keyless Entry Receiver"</a>.</li></ul>
6.	IPDM E/R	<ul style="list-style-type: none"><li>IPDM E/R detects push-button ignition switch (push switch) status, and transmits push-button ignition switch status signal (CAN) to BCM.</li><li>Refer to <a href="#">PCS-5, "Component Parts Location"</a>.</li></ul>
7.	Hood switch	<ul style="list-style-type: none"><li>Hood switch transmits hood open/closed signal to the IPDM E/R.</li><li>Refer to <a href="#">SEC-6, "Component Parts Location"</a>.</li></ul>

# COMPONENT PARTS


## < SYSTEM DESCRIPTION >

No.	Component	Function
8.	Horns	IPDM E/R energizes the horns when the security system is activated.
9.	BCM	<ul style="list-style-type: none"> <li>BCM controls INTELLIGENT KEY SYSTEM (ENGINE START FUNCTION), NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] and VEHICLE SECURITY SYSTEM.</li> <li>BCM performs the ID verification between BCM and Intelligent Key when the Intelligent Key is carried into the detection area of inside key antenna, and push-button ignition switch is pressed. If the ID verification result is OK, ignition switch operation is available.</li> </ul> <p>Then, when the ignition switch is turned ON, BCM performs ID verification between BCM and ECM. If the ID verification result is OK, ECM can start engine.</p> <p>• Refer to <a href="#">BCS-5. "BODY CONTROL SYSTEM : Component Parts Location"</a> for detailed installation location.</p>
10.	Combination meter	<ul style="list-style-type: none"> <li>Combination meter transmits the vehicle speed signal to BCM via CAN communication.</li> <li>BCM also receives the vehicle speed signal from ABS actuator and electric unit (control unit) via CAN communication. BCM compares both signals to detect the vehicle speed.</li> <li>Security indicator lamp is located on combination meter.</li> <li>Security indicator lamp blinks when ignition switch is in any position other than ON to warn that NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] is on board.</li> <li>Refer to <a href="#">MWI-8. "METER SYSTEM : Component Parts Location"</a> (type A meter) <a href="#">MWI-116. "METER SYSTEM : Component Parts Location"</a> (type B meter)</li> </ul>
11.	Transmission range switch	<ul style="list-style-type: none"> <li>The transmission range switch detects the selector lever position.</li> <li>Refer to <a href="#">TM-17. "A/T CONTROL SYSTEM : Transmission Range Switch"</a>.</li> </ul>
12.	A/T shift selector (Park position switch)	A/T shift selector detects shift lever status, transmits detention switch signal to BCM.
13.	Front door switch LH	Front door switch LH transmits door open/closed signal to the BCM.
14.	Rear door switch LH	Rear door switch LH transmits door open/closed signal to the BCM.
15.	Push-button ignition switch	Push-button ignition switch has push switch inside which detects that push-button ignition switch is pressed and then transmits ON/OFF signal to BCM. BCM changes the ignition switch position with the operation of push-button ignition switch. BCM maintains the ignition switch position status while push-button ignition switch is not operated.
16.	NATS antenna amp.	<a href="#">SEC-7. "NATS Antenna Amp."</a>

## NATS Antenna Amp.

INFOID:000000014391281

The ID verification is performed between BCM and transponder integrated into Intelligent Key via NATS antenna amp. when Intelligent Key backside is contacted to power switch, in case that Intelligent Key battery is discharged. If the ID verification result is OK, the operation of power switch is available.



JMKIA93502Z


## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

#### Hood Switch

INFOID:0000000014391282

Hood switch ① detects that hood is open and then transmits ON/OFF signal to IPDM E/R. IPDM E/R transmits hood switch signal to BCM via CAN communication. Hood switch is integrated into hood lock assembly LH.



# SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM

### INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

#### INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description

INFOID:000000014391283

#### SYSTEM DIAGRAM



ALKIA4331GB

#### SYSTEM DESCRIPTION

- The engine start function of Intelligent Key system makes it possible to start and stop the engine without using the key, based on the electronic ID verification. The electronic ID verification is performed between BCM and Intelligent Key when the push-button ignition switch is pressed, while the Intelligent Key is within the detection area of inside key antenna.

#### NOTE:

The driver should carry the Intelligent Key at all times.

- Intelligent Key has 2 IDs [Intelligent Key ID and IVIS (NATS) ID]. It can perform the door lock/unlock operation and the push-button ignition switch operation when the registered Intelligent Key is carried.
- When Intelligent Key battery is discharged, engine can be started by operating push-button ignition switch after contacting Intelligent Key backside to push-button ignition switch. At that time, the IVIS (NATS) ID verification is performed.
- If the ID is successfully verified, when push-button ignition switch is pressed, the engine can be started.
- Up to 4 Intelligent Keys can be registered (Including the standard Intelligent Key) upon request from the customer.
- For initialization and registration of Intelligent Key, refer to CONSULT Immobilizer mode and follow the on-screen instructions.

# SYSTEM

## < SYSTEM DESCRIPTION >

### NOTE:

Refer to [SEC-9, "INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description"](#) for any functions other than engine start function of Intelligent Key system.

### PRECAUTIONS FOR INTELLIGENT KEY SYSTEM

**The transponder [the chip for IVIS (NATS) ID verification] is integrated into the Intelligent Key. In that case, the IVIS (NATS) ID verification can be performed when Intelligent Key backside is contacted to push-button ignition switch. If verification result is OK, engine can be started.**

### OPERATION WHEN INTELLIGENT KEY IS CARRIED

1. When the push-button ignition switch is pressed, the BCM activates the inside key antenna and transmits the request signal to the Intelligent Key.
2. The Intelligent Key receives the request signal and transmits the Intelligent Key ID signal to the BCM.
3. BCM receives the Intelligent Key ID signal via remote keyless entry receiver and verifies it with the registered ID.
4. BCM turns ACC relay ON and transmits the ignition power supply ON signal to IPDM E/R.
5. IPDM E/R turns the ignition relay ON and starts the ignition power supply.
6. BCM detects the selector lever position and brake pedal operating condition.
7. BCM transmits the starter request signal to IPDM E/R and turns the starter relay in IPDM E/R ON, if BCM judges that the engine start condition\* is satisfied.
8. IPDM E/R turns the starter control relay ON when receiving the starter request signal.
9. Power supply is supplied through the starter relay and the starter control relay to operate the starter motor.

### CAUTION:

**If a malfunction is detected in the Intelligent Key system, the “KEY” warning lamp in the combination meter illuminates. At that time, the engine cannot be started.**

10. When BCM receives feedback signal from ECM indicating that the engine is started, the BCM transmits a stop signal to IPDM E/R and stops cranking by turning OFF the starter motor relay. (If engine start is unsuccessful, cranking stops automatically within 5 seconds.)

### CAUTION:

**When the Intelligent Key is carried outside of the vehicle (inside key antenna detection area) while the power supply is in the ACC or ON position, even if the engine start condition\* is satisfied, the engine cannot be started.**

\*: For the engine start condition, refer to the table below “POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION”.

### OPERATION RANGE

Engine can be started when Intelligent Key is inside the vehicle. However, sometimes engine may not start when Intelligent Key is on instrument panel or in glove box.

### ENGINE START OPERATION WHEN INTELLIGENT KEY IS CONTACTED TO PUSH-BUTTON IGNITION SWITCH

When Intelligent Key battery is discharged, the IVIS (NATS) ID verification between transponder in Intelligent Key and BCM is performed when Intelligent Key backside is contacted to push-button ignition switch. If the verification result is OK, engine can be started.

### POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

The power supply position changing operation can be performed with the following operations.

### NOTE:

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below.
- When starting the engine, the BCM monitors under the engine start conditions:
  - Brake pedal operating condition
  - Selector lever position
  - Vehicle speed

Vehicle speed: less than 4 km/h (2.5 MPH)

# SYSTEM

## < SYSTEM DESCRIPTION >

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
LOCK → ACC	—	Not depressed	1
LOCK → ACC → ON	—	Not depressed	2
LOCK → ACC → ON → OFF	—	Not depressed	3
LOCK → START ACC → START ON → START	P or N position	Depressed	1
Engine is running → OFF	—	—	1

Vehicle speed: 4 km/h (2.5 MPH) or more

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
Engine is running → ACC	—	—	Emergency stop operation
Engine stall return operation while driving	N position	Not depressed	1

Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P


# SYSTEM

## < SYSTEM DESCRIPTION >

### NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description

INFOID:000000014391284

#### SYSTEM DIAGRAM



#### SYSTEM DESCRIPTION

- The NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] prevents the engine from being started by an Intelligent Key whose ID is not registered to the vehicle (BCM). It has higher protection against auto theft involving the duplication of mechanical keys.
- The ignition key integrated in the Intelligent Key cannot start the engine. When the Intelligent Key battery is discharged, the NVIS (NATS) ID verification is performed between the transponder integrated with Intelligent Key and BCM via NATS antenna amp., when the Intelligent Key backside is contacted to push-button ignition switch. If the verification results are OK, the engine start operation can be performed by the push-button ignition switch operation.
- Locate the security indicator lamp and apply the anti-theft system equipment sticker that warns that the NVIS (NATS) is on-board the model.
- Security indicator lamp always blinks when the power supply position is any position other than ON.
- Up to 4 Intelligent Keys can be registered (including the standard ignition key) upon request from the owner.
- Specified registration is required when replacing ECM, BCM or Intelligent Key.
- For initialization and registration of Intelligent Key, refer to CONSULT Immobilizer mode and follow the on-screen instructions.
- Possible symptom of NVIS (NATS) malfunction is "Engine cannot start". The engine can not be started because of other than NVIS (NATS) malfunction, so start the trouble diagnosis according to [SEC-64, "Work Flow"](#).
- If ECM other than genuine part is installed, the engine cannot be started. For ECM replacement procedure, refer to [EC-1993, "Removal and Installation"](#).

# SYSTEM

## < SYSTEM DESCRIPTION >

### PRECAUTIONS FOR KEY REGISTRATION

- The ID registration is a procedure that erases the current NVIS (NATS) ID once, and then reregisters a new ID. Therefore, before starting the registration operation, collect all registered Intelligent Keys from the customer.
- When registering the Intelligent Key, perform only one procedure to simultaneously register both ID [NVIS (NATS) ID and Intelligent Key ID].

A  
B  
C  
D

### SECURITY INDICATOR LAMP

- Warns that the vehicle is equipped with NVIS (NATS).
- Security indicator lamp always blinks when the power supply position is any position other than ON.

C  
D

#### NOTE:

Because security indicator lamp is highly efficient, the battery is barely affected.

D  
E  
F  
G

### ENGINE START OPERATION WHEN INTELLIGENT KEY IS CONTACTED TO PUSH-BUTTON IGNITION SWITCH

1. When the brake pedal is depressed while the selector lever is in the P (Park) position, the BCM activates the NATS antenna amp. that is located behind the push-button ignition switch.
2. When Intelligent Key (transponder built-in) backside is contacted to push-button ignition switch, BCM starts NVIS (NATS) ID verification between BCM and Intelligent Key (transponder built-in) via NATS antenna amp.
3. When the NVIS (NATS) ID verification result is OK, buzzer in combination meter sounds and BCM transmits the result to ECM.
4. BCM turns ACC relay ON and transmits ignition power supply ON signal to IPDM E/R.
5. IPDM E/R turns the ignition relay ON and starts the ignition power supply.
6. BCM detects that the selector lever position is P (Park) or N (Neutral).
7. BCM transmits starter request signal to IPDM E/R and turns the starter relay in IPDM E/R ON if BCM judges that the engine start condition\* is satisfied.
8. IPDM E/R turns the starter control relay ON when receiving the starter request signal.
9. Power supply is supplied through the starter relay and the starter control relay to operate the starter motor.
10. When BCM receives feedback signal from ECM indicating that the engine is started, BCM transmits a stop signal to IPDM E/R and stops cranking by turning off the starter motor relay. (If engine start is unsuccessful, cranking stops automatically within 5 seconds.)

H  
I  
J

\*: For the engine start condition, refer to the table "POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION" below.

SEC

### POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

L

The power supply position changing operation can be performed with the following operations.

M

#### NOTE:

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below.
- When starting the engine, the BCM monitors under the engine start conditions:
  - Brake pedal operating condition
  - Selector lever position
  - Vehicle speed

N

Vehicle speed: less than 4 km/h (2.5 MPH)

O  
P

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
LOCK → ACC	—	Not depressed	1
LOCK → ACC → ON	—	Not depressed	2
LOCK → ACC → ON → OFF	—	Not depressed	3

# SYSTEM

## < SYSTEM DESCRIPTION >

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
LOCK → START ACC → START ON → START	P (Park) or N (Neutral) position	Depressed	1
Engine is running → OFF	—	—	1

Vehicle speed: 4 km/h (2.5 MPH) or more

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
Engine is running → ACC	—	—	Emergency stop operation
Engine stall return operation while driving	N (Neutral) position	Not depressed	1

Emergency stop operation


- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

## VEHICLE SECURITY SYSTEM

### VEHICLE SECURITY SYSTEM : System Description

INFOID:0000000014391285

#### SYSTEM DIAGRAM



#### SYSTEM DESCRIPTION

- The vehicle security system has two alarm functions (theft warning alarm and panic alarm) and reduces the possibility of a theft or mischief by activating horns and headlamps intermittently.

# SYSTEM

## < SYSTEM DESCRIPTION >


- The panic alarm does not start when the theft warning alarm is activating and the panic alarm stops when the theft warning alarm is activated.
- The priority of the functions are as per the following.

Priority	Function
1	Theft warning alarm
2	Panic alarm

## THEFT WARNING ALARM

- The theft warning alarm function activates horns and headlamps intermittently when BCM detects that any door or hood is opened by unauthorized means while the system is in the ARMED state.
- Security indicator lamp on combination meter always blinks when power supply position is any position other than ON. Security indicator lamp blinking warns that the vehicle is equipped with a vehicle security system.

## Operation Flow



JMKIA5416GB

No.	System state	Switching condition		
		A	B	
1	DISARMED to PRE-ARMED	When all conditions of A and one condition of B is satisfied.	<ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Closed</li> <li>Hood: Closed</li> </ul>	<ul style="list-style-type: none"> <li>All doors are locked by:           <ul style="list-style-type: none"> <li>Door key cylinder LOCK switch</li> <li>LOCK button of Intelligent Key</li> <li>Door request switch</li> </ul> </li> </ul>
2	PRE-ARMED to ARMED	When all of the following conditions are satisfied for 30 seconds.	<ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Locked</li> <li>Hood: Closed</li> </ul>	
3	ARMED to ALARM	When one condition of A and one condition of B are satisfied.	<ul style="list-style-type: none"> <li>A</li> <li>Intelligent Key: Not used</li> </ul>	<ul style="list-style-type: none"> <li>Any door: Open</li> <li>Hood: Open</li> </ul>
4	DISARMED to PRE-RESET	When all conditions of A and one condition of B is satisfied.	<ul style="list-style-type: none"> <li>A</li> <li> <ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Closed</li> <li>Hood: Open</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>All doors are locked by:           <ul style="list-style-type: none"> <li>Door key cylinder LOCK switch</li> <li>LOCK button of Intelligent Key</li> <li>Door request switch</li> </ul> </li> </ul>
5	PRE-ARMED to PRE-RESET	When one of the following conditions is satisfied.	<ul style="list-style-type: none"> <li>Hood: Open</li> </ul>	
6	ARMED to PRE-RESET	No conditions.		
7	ALARM to PRE-RESET			

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# SYSTEM

## < SYSTEM DESCRIPTION >

No.	System state	Switching condition
8	PRE-RESET to DISARMED	When one of the following conditions is satisfied. <ul style="list-style-type: none"> <li>• Power supply position: ACC/ON/CRANKING/RUN</li> <li>• Door key cylinder UNLOCK switch: ON</li> <li>• UNLOCK button of Intelligent Key: ON</li> <li>• Door request switch: ON</li> <li>• UNLOCK switch of door lock and unlock switch: ON</li> <li>• Any door: Open</li> </ul>
9	PRE-RESET to PRE-ARMED	When all of the following conditions are satisfied. <ul style="list-style-type: none"> <li>• Power supply position: OFF/LOCK</li> <li>• All doors: Closed</li> <li>• Hood: Closed</li> </ul>
10	PRE-ARMED to DISARMED	When one of the following conditions is satisfied. <ul style="list-style-type: none"> <li>• Power supply position: ACC/ON/CRANKING/RUN</li> <li>• Door key cylinder UNLOCK switch: ON</li> <li>• UNLOCK button of Intelligent Key: ON</li> <li>• Door request switch: ON</li> <li>• Any door: Open</li> </ul>
11	ARMED to DISARMED	When one of the following conditions is satisfied. <ul style="list-style-type: none"> <li>• Power supply position: ACC/ON/CRANKING/RUN</li> <li>• Door key cylinder UNLOCK switch: ON</li> <li>• UNLOCK button of Intelligent Key: ON</li> <li>• Door request switch: ON</li> </ul>
12	ALARM to DISARMED	
13	RE-ALARM	When one of the following conditions is satisfied after the ALARM operation is finished. <ul style="list-style-type: none"> <li>• Any door: Open</li> <li>• Hood: Open</li> </ul>

### NOTE:

- BCM ignores the door key cylinder UNLOCK switch signal input for 1 second after the door key cylinder LOCK switch signal input.
- To lock/unlock all doors by operating remote control button of Intelligent Key or door request switch, Intelligent Key must be within the detection area of outside key antenna. For details, refer to [SEC-9, "INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description".](#)

### DISARMED Phase

The vehicle security system is not set in the DISARMED phase. The vehicle security system stays in this phase while any door is open because it is assumed that the owner is inside or nearby the vehicle. Security indicator lamp blinks every 2.4 seconds.

When the vehicle security system is reset, each phase switches to the DISARMED phase directly.

### PRE-ARMED Phase

The PRE-ARMED phase is the transient state between the DISARMED phase and the ARMED phase. This phase is maintained for 30 seconds so that the owner can reset the setting due to a mis-operation. This phase switches to the ARMED phase when vehicle conditions are not changed for 30 seconds. Security indicator lamp illuminates while being in this phase.

To reset the PRE-ARMED phase, refer to the switching condition of No. 10 in the table above.

### ARMED Phase

The vehicle security system is set and BCM monitors all necessary inputs. If any door or hood is opened without using Intelligent Key, vehicle security system switches to the ALARM phase. Security indicator lamp blinks every 2.4 seconds.

To reset the ARMED phase, refer to the switching condition of No. 11 in the table above.

### ALARM Phase

BCM transmits "Theft Warning Horn Request" signal and "High Beam Request" signal intermittently to IPDM E/R via CAN communication. In this phase, horns and headlamps are activated intermittently for approximately 50 seconds to warn that the vehicle is accessed by unauthorized means. ON/OFF timing of horns and headlamps are synchronized. After 50 seconds, the vehicle security system returns to the ARMED phase. At this time, if BCM still detects unauthorized access to the vehicle, the system is switched to the ALARM phase again. This RE-ALARM operation is carried out a maximum of 2 times.

To cancel the ALARM operation, refer to the switching condition of No. 12 in the table above.

### NOTE:

If a battery terminal is disconnected during the ALARM phase, theft warning alarm stops. But when the battery terminal is reconnected, theft warning alarm is activated again.

### PRE-RESET Phase

# SYSTEM

## < SYSTEM DESCRIPTION >

The PRE-RESET phase is the transient state between each phase and DISARMED phase. If only the condition of hood is not satisfied, the system switches to the PRE-RESET phase. Then, when any condition is changed, the system switches to the DISARMED phase or PRE-ARMED phase.

### PANIC ALARM

- The panic alarm function activates horns and headlamps intermittently when the owner presses the PANIC ALARM button of Intelligent Key outside the vehicle while the power supply position is OFF or LOCK.
- When BCM receives panic alarm signal from Intelligent Key, BCM transmits “Theft Warning Horn Request” signal and “High Beam Request” signal intermittently to IPDM E/R via CAN communication. To prevent the activation due to mis-operation of Intelligent Key by owner, the panic alarm function is activated when BCM receives the signal for 0.4 - 0.6 seconds.
- Panic alarm operation is maintained for 25 seconds.
- Panic alarm operation is cancelled when BCM receives one of the following signals:
  - LOCK button of Intelligent Key: ON
  - UNLOCK button of Intelligent Key: ON
  - PANIC ALARM button of Intelligent Key: Long pressed
  - Any door request switch: ON

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000014664552

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"><li>The vehicle specification can be read and saved.</li><li>The vehicle specification can be written when replacing BCM.</li></ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions:

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				

### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays it on CONSULT.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed at the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) at the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK").
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF").
	LOCK>ACC	While turning power supply position from "LOCK" to "ACC".
	ACC>ON	While turning power supply position from "ACC" to "IGN".
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopped and selector lever is in P position.)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF".
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK".
	OFF>ACC	While turning power supply position from "OFF" to "ACC".
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING".
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF") to low power consumption mode.
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK") to low power consumption mode.
	LOCK	Power supply position is "LOCK" (Ignition switch OFF)*
	OFF	Power supply position is "OFF" (Ignition switch OFF)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> <li>The number is 0 when a malfunction is detected now.</li> <li>The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition is switched OFF → ON.</li> <li>The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>

### NOTE:

\*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met:

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

## INTELLIGENT KEY

### INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:0000000014664553

## SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

## DATA MONITOR

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Main	Description
REQ SW -DR [On/Off]	×	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	×	Indicates condition of door request switch RH.
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
SHIFTLOCK SOLENOID PWR SUPPLY [On/Off]	×	Indicates condition of power supply to shiftlock solenoid.
BRAKE SW 1 [On/Off]	×	Indicates condition of brake switch.
BRAKE SW 2 [On/Off]		Indicates condition of brake switch.
DETE/CANCL SW [On/Off]	×	Indicates condition of P (park) position.
SFT PN/N SW [On/Off]	×	Indicates condition of P (park) or N (neutral) position.
UNLK SEN -DR [On/Off]	×	Indicates condition of door unlock sensor.
PUSH SW -IPDM [On/Off]		Indicates condition of push-button ignition switch received from IPDM E/R on CAN communication line.
IGN RLY1 -F/B [On/Off]		Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line.
DETE SW -IPDM [On/Off]		Indicates condition of park position switch received from TCM on CAN communication line.
SFT PN -IPDM [On/Off]		Indicates condition of P (park) or N (neutral) position from TCM on CAN communication line.
SFT P -MET [On/Off]		Indicates condition of P (park) position from TCM on CAN communication line.
SFT N -MET [On/Off]		Indicates condition of N (neutral) position from IPDM E/R on CAN communication line.
ENGINE STATE [Stop/Start/Crank/Run]	×	Indicates condition of engine state from ECM on CAN communication line.
VEH SPEED 1 [mph/km/h]	×	Indicates condition of vehicle speed signal received from ABS on CAN communication line.
VEH SPEED 2 [mph/km/h]	×	Indicates condition of vehicle speed signal received from combination meter on CAN communication line.
DOOR STAT -DR [LOCK/READY/UNLK]	×	Indicates condition of driver side door status.
DOOR STAT -AS [LOCK/READY/UNLK]	×	Indicates condition of passenger side door status.
DOOR STAT -RR [LOCK/READY/UNLK]	×	Indicates condition of rear right side door status.
DOOR STAT -RL [LOCK/READY/UNLK]	×	Indicates condition of rear left side door status.
ID OK FLAG [Set/Reset]		Indicates condition of Intelligent Key ID.
PRMT ENG STRT [Set/Reset]		Indicates condition of engine start possibility.
PRMT RKE STRT [Set/Reset]		Indicates condition of engine start possibility from Intelligent Key.
I-KEY OK FLAG [Key ON/Key OFF]	×	Indicates condition of Intelligent Key OK flag.
PRBT ENG STRT [Set/Reset]		Indicates condition of engine start prohibit.
ID AUTHENTICATION CANCEL TIMER [under a stop]		Indicates condition of Intelligent Key ID authentication.
ACC BATTERY SAVER [under a stop]		Indicates condition of battery saver.
CRNK PRBT TMR [On/Off]		Indicates condition of crank prohibit timer.
AUT CRNK TMR [On/Off]		Indicates condition of automatic engine crank timer from Intelligent Key.
CRNK PRBT TME [sec]		Indicates condition of crank prohibit timer.
AUT CRNK TMR [sec]		Indicates condition of automatic engine crank timer from Intelligent Key.
CRANKING TME [sec]		Indicates condition of engine cranking time from Intelligent Key.
ST RLY -REQ		Indicates condition of starter relay.
IGN RLY 1 -REQ		Indicates condition of ignition 1 relay.
IGN RLY 2 -REQ		Indicates condition of ignition 2 relay.
DETE SW PWR [On/Off]		Indicates condition of park position switch voltage.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Main	Description
ACC RLY -REQ [On/Off]		Indicates condition of accessory relay control request.
RKE OPE COUN1 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE OPE COUN2 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE-LOCK [On/Off]		Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]		Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]		Indicates condition of panic signal from Intelligent Key.
RKE-MODE CHG [On/Off]		Indicates condition of mode change signal from Intelligent Key.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
SEC  
L  
M  
N  
O  
P

## ACTIVE TEST

Test Item	Description
INTELLIGENT KEY LINK (CAN)	This test is able to check Intelligent Key identification number [Off/ID No1/ID No2/ID No3/ID No4/ID No5].
INT LAMP	This test is able to check interior room lamp operation [On/Off].
FLASHER	This test is able to check hazard lamp operation [LH/RH/Off].
HORN	This test is able to check horn operation [On].
BATTERY SAVER	This test is able to check battery saver operation [On/Off].
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation [On/Off].
INSIDE BUZZER	This test is able to check combination meter warning chime operation [Take Out/Knob/Key/Off].
INDICATOR	This test is able to check combination meter warning lamp operation [KEY ON/KEY IND/Off].
IGN CONT2	This test is able to check ignition relay-2 control operation [On/Off].
ENGINE SW ILLUMI	This test is able to check push-button ignition switch START indicator operation [On/Off].
PUSH SWITCH INDICATOR	This test is able to check push-button ignition switch indicator operation [On/Off].
ACC CONT	This test is able to check accessory relay control operation [On/Off].
IGN CONT1	This test is able to check ignition relay-1 control operation [On/Off].
ST CONT LOW	This test is able to check starter control relay operation [On/Off].
IGNITION RELAY	This test is able to check ignition relay operation [On/Off].
TRUNK/LUGGAGE LAMP TEST	This test is able to check cargo lamp illumination operation [On/Off].
KEYFOB PW TEST	This test is able to check power window operation using the Intelligent Key [P/W up/down OFF/Send P/W down ON/Send P/W up ON].
SHIFTLOCK SOLENOID TEST	This test is able to check shift lock solenoid operation [On/Off].

## WORK SUPPORT

Support Item	Setting	Description
IGN/ACC BATTERY SAVER	On*	Battery saver function ON.
	Off	Battery saver function OFF.
REMOTE ENGINE STARTER	On*	Remote engine start function ON.
	Off	Remote engine start function OFF.
ANSWERBACK I-KEY LOCK UNLOCK	BUZZER*	Buzzer reminder function by door lock/unlock request switch ON.
	HORN	Horn chirp reminder function by door lock request switch ON.
	Off	No reminder function by door lock/unlock request switch.
	INVALID	This mode is not used.

N  
O  
P

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Support Item	Setting		Description
ANSWERBACK KEYLESS LOCK UN-LOCK	On*		Buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.
	Off		No buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.
ANSWER BACK	On*		Horn chirp reminder when doors are locked with Intelligent Key.
	Off		No horn chirp reminder when doors are locked with Intelligent Key.
RETRACTABLE MIRROR SET	On		Retractable mirror set ON.
	Off*		Retractable mirror set OFF.
LOCK/UNLOCK BY I-KEY	On*		Door lock/unlock function from Intelligent Key ON.
	Off		Door lock/unlock function from Intelligent Key OFF.
ENGINE START BY I-KEY	On*		Engine start function from Intelligent Key ON.
	Off		Engine start function from Intelligent Key OFF.
CONFIRM KEY FOB ID	—		Intelligent Key ID code can be checked.
SHORT CRANKING OUTPUT	Start	70 msec	Starter motor operation duration times.
		100 msec	
		200 msec	
End		—	
INSIDE ANT DIAGNOSIS	—		This function allows inside key antenna self-diagnosis.
AUTO LOCK SET	MODE7	5 min	Auto door lock time can be set in this mode.
	MODE6	4 min	
	MODE5	3 min	
	MODE4	2 min	
	MODE3*	1 min	
	MODE2	30 sec	
	MODE1	Off	

\*: Initial Setting

## THEFT ALM

### THEFT ALM : CONSULT Function (BCM - THEFT ALM)

INFOID:0000000014664554

## DATA MONITOR

Monitor Item	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Monitor Item	Description
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.

A

## ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [LH/RH/Off].
THEFT IND	This test is able to check security indicator lamp operation [On/Off].
VEHICLE SECURITY HORN	This test is able to check vehicle security horn operation [On].
HEADLAMP(HI)	This test is able to check vehicle security lamp operation [On].

B

C

D

E

## WORK SUPPORT

Support Item	Setting	Description
SECURITY ALARM SET	On*	Security alarm ON.
	Off	Security alarm OFF.

F

G

\*: Initial setting

## IMMU

### IMMU : CONSULT Function (BCM - IMMU)

INFOID:000000014664555

H

#### SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

I

#### DATA MONITOR

Monitor Item [Unit]	Description
CONFIRM ID ALL [Yet/DONE]	Switches to DONE when an Intelligent Key is registered.
CONFIRM ID4 [Yet/DONE]	
CONFIRM ID3 [Yet/DONE]	
CONFIRM ID2 [Yet/DONE]	
CONFIRM ID1 [Yet/DONE]	
TP 4 [Yet/DONE]	DONE indicates the number of the Intelligent Key ID which has been registered.
TP 3 [Yet/DONE]	
TP 2 [Yet/DONE]	
TP 1 [Yet/DONE]	
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.

J

SEC

L

M

N

## ACTIVE TEST

Test Item	Description
THEFT IND	This test is able to check security indicator operation [On/Off].

O

P

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R)

### CONSULT Function (IPDM E/R)

INFOID:000000014664556

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R:

Direct Diagnostic Mode	Description
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

#### SELF DIAGNOSTIC RESULT

Refer to [PCS-23, "DTC Index"](#).

#### DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line.
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
INTER/NP SW [On/Off]		Indicates condition of AT shift position.
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line.
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line.
ST/INHI RLY [Off/ ST /INHI]		Indicates condition of starter relay and starter control relay.
DETENT SW [On/Off]		Indicates condition of AT shift selector (park position switch).
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch.
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line
HOOD SW 2 [On/Off]		Indicates condition of hood switch 2.

#### ACTIVE TEST

## DIAGNOSIS SYSTEM (IPDM E/R)

### < SYSTEM DESCRIPTION >

Test item	Description
REAR DEFOGGER	This test is able to check rear defogger operation [On/Off].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].
HORN	This test is able to check horn operation [On].

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

&lt; ECU DIAGNOSIS INFORMATION &gt;

# ECU DIAGNOSIS INFORMATION

**ECM, IPDM E/R, BCM**

## List of ECU Reference

INFOID:000000014391291

ECU	Reference
ECM	<a href="#">EC-816, "Reference Value"</a>
	<a href="#">EC-828, "Fail safe"</a>
	<a href="#">EC-837, "DTC Index"</a>
	<a href="#">EC-837, "DTC Index"</a>
IPDM E/R	<a href="#">PCS-14, "Reference Value"</a>
	<a href="#">PCS-22, "Fail_Safe"</a>
	<a href="#">PCS-23, "DTC Index"</a>
BCM	<a href="#">BCS-32, "Reference Value"</a>
	<a href="#">BCS-51, "Fail_Safe"</a>
	<a href="#">BCS-51, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-52, "DTC Index"</a>

## **INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION**

## < WIRING DIAGRAM >

## WIRING DIAGRAM

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

## Wiring Diagram


INFOID:000000014391292

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

BATTERY

**IGNITION SWITCH**


- CAN COMMUNICATION LINE FOR DIAGNOSIS
- V2 / WITH VK56/D AND WITH DRIVERS ASSISTANCE SYSTEM
- V3 / WITH VK56/D AND WITHOUT DRIVERS ASSISTANCE SYSTEM
- V4 / WITH CAN GATEWAY SYSTEM AND Cummins 5.0L
- V5 / WITH Cummins 5.0L AND WITHOUT NAVIGATION SYSTEM



AAKWA1564GB

# INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION


## < WIRING DIAGRAM >



AAKWA1565GB

## **INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION**

## < WIRING DIAGRAM >




AAKWA1566GB

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION


## < WIRING DIAGRAM >

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS


Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Type	TH04FW-NH
Connector Color	WHITE




Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4
Connector Color	WHITE




80J	W	TO MAIN HARNESS
81J	SHIELD	TO MAIN HARNESS
82J	L/R	TO MAIN HARNESS
83J	-	TO MAIN HARNESS
84J	-	TO MAIN HARNESS
85J	Y/B	TO MAIN HARNESS
86J	G	TO MAIN HARNESS
87J	B/R	TO MAIN HARNESS
88J	SHIELD	TO MAIN HARNESS
89J	GR/BR	TO MAIN HARNESS
90J	L	TO MAIN HARNESS
91J	L/B	TO MAIN HARNESS
92J	SB	TO MAIN HARNESS
93J	B	TO MAIN HARNESS
94J	L	TO MAIN HARNESS
95J	LG	TO MAIN HARNESS
96J	R	TO MAIN HARNESS
97J	B/Y	TO MAIN HARNESS
98J	L/B	TO MAIN HARNESS
99J	WL	TO MAIN HARNESS
100J	SB	TO MAIN HARNESS
Connector No.	B108	
Connector Name	FRONT DOOR SWITCH RH	
Connector Type	TH04FW-NH	
Connector Color	WHITE	
 		




28J	L	TO MAIN HARNESS
29J	G/O	TO MAIN HARNESS
30J	SB	TO MAIN HARNESS
31J	LG	TO MAIN HARNESS
32J	R	TO MAIN HARNESS
33J	L	TO MAIN HARNESS
34J	Y	TO MAIN HARNESS
35J	P	TO MAIN HARNESS
36J	GR	TO MAIN HARNESS
37J	LGB	TO MAIN HARNESS
38J	SB	TO MAIN HARNESS
39J	YL	TO MAIN HARNESS
40J	BR	TO MAIN HARNESS
41J	L	TO MAIN HARNESS
42J	L	TO MAIN HARNESS
43J	SB	TO MAIN HARNESS
44J	BR	TO MAIN HARNESS
45J	BG	TO MAIN HARNESS
46J	P/Y	TO MAIN HARNESS
47J	Y/GR	TO MAIN HARNESS
48J	V	TO MAIN HARNESS
49J	BR/Y	TO MAIN HARNESS
50J	G/W	TO MAIN HARNESS
51J	-	TO MAIN HARNESS
52J	SHIELD	TO MAIN HARNESS
53J	R	TO MAIN HARNESS
54J	L	TO MAIN HARNESS
55J	R	TO MAIN HARNESS
56J	W	TO MAIN HARNESS
57J	L/G	TO MAIN HARNESS
58J	O	TO MAIN HARNESS
59J	-	TO MAIN HARNESS
60J	SHIELD	TO MAIN HARNESS
61J	G	TO MAIN HARNESS
62J	-	TO MAIN HARNESS
63J	R/W	TO MAIN HARNESS
64J	LW	TO MAIN HARNESS
65J	SHIELD	TO MAIN HARNESS
66J	B	TO MAIN HARNESS
67J	SHIELD	TO MAIN HARNESS
68J	OIL	TO MAIN HARNESS
69J	SHIELD	TO MAIN HARNESS
70J	BR	TO MAIN HARNESS
71J	LW	TO MAIN HARNESS
72J	-	TO MAIN HARNESS
73J	-	TO MAIN HARNESS
74J	SHIELD	TO MAIN HARNESS
75J	LGB	TO MAIN HARNESS
76J	R	TO MAIN HARNESS
77J	SHIELD	TO MAIN HARNESS
78J	GRB	TO MAIN HARNESS
79J	B	TO MAIN HARNESS



Connector No.	B108	Connector Name	FRONT DOOR SWITCH RH
Connector Type	TH04FW-NH	Connector Color	WHITE
			
			 



Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	—	—
2	—	—
3	SB	RL DOOR SW
4	—	—

3	LGR	AS DOOR SW
4	-	-






## **INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION**

## < WIRING DIAGRAM >

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

 <b>B116</b>	<b>REAR DOOR SWITCH RH</b>	6A	LG/Y	TO MAIN HARNESS -(WITHOUT CLIMATE CONTROLLED SEATS)	-	TO MAIN HARNESS
 <b>TH04FW-NH</b>		6A	LG	TO MAIN HARNESS -(WITH CLIMATE CONTROLLED SEATS)	-	TO MAIN HARNESS
 <b>WHITE</b>		7A	W	TO MAIN HARNESS	60A	G/N
 <b>TH04FW-NH</b>		8A	B	TO MAIN HARNESS	61A	-
 <b>WHITE</b>		9A	LB	TO MAIN HARNESS	62A	-
 <b>TH04FW-NH</b>		10A	W	TO MAIN HARNESS	63A	-
 <b>WHITE</b>		11A	LG	TO MAIN HARNESS	64A	-
 <b>TH04FW-NH</b>		12A	BP/O	TO MAIN HARNESS	65A	-
 <b>WHITE</b>		13A	YW	TO MAIN HARNESS	66A	-



AAKIA4083GE

## **INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION**

## < WIRING DIAGRAM >

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

Connector No.	E119	IPDME/R (INTELLIGENT POWER DISTRIBUTION MODULE, ENGINE ROOM)	NS16FW-CS	WHITE
Connector Name				
Connector Type				
Connector Color				

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
3	-	-	42	41	39
4	B/R	NP SW	43	49	38
5	L/W	H/LAMP HI RH	44	45	37
6	G	H/LAMP HI LH	48	47	44
7	L	H/LAMP LO LH			
8	R/Y	H/LAMP LO RH			
9	G/W	FR FOG/L LH	37	-	-
10	-	-	38	-	-
11	P	ETC VB - (WITH CUMMINS 5.0L)	39	L/Y	WIPER AUTO STOP SW
11	O	ETC VB - (WITH VK56VD)	40	P	CAN-L
12	W/R	FR FOG/L RH	41	L	CAN-H
13	Y/R	A/T ECU IGN	42	BR	DTR/L RLY
14	G	REVERSE LAMP GRN	43	-	-
15	GR	A/B ECU IGN	44	W/B	START/CONT
16	G	ETC RLY CONT - (WITH CUMMINS 5.0L)	45	GR	FUEL RLY CONT
16	V/R	ETC RLY CONT - (WITH VK56VD)	46	Y	HOOD SW
17	L/W	IGN COIL - (WITH CUMMINS 5.0L)	47	Y	ALT C - (WITH VK56VD)
17	W	IGN COIL - (WITH VK56D)	48	R/W	HORN RLY CONT
18	-	-			

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M06FW1-LC
Connector Color	WHITE
Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS06FBFR-CS
Connector Color	BROWN

Terminal No.	Color of Wire	Signal Name	Signal Name
--------------	---------------	-------------	-------------

64	R	DETENT SW
65	-	-
66	P	PUSH START SW
67	-	-
68	L	IGN SIGNAL
69	-	-
70	-	-
71	SB	HOOD SW2
72	W	E-CPLG (WITH KKS6V/D)

49	Y/B	A/C COMP - (WITH CUMMINS 5.0L)
49	GR/R	A/C COMP - (WITH VK56VD)
50	BR	TRAILER TOW
51	-	-
52	B	S-GND
53	-	-
54	-	-
55	-	-
56	-	-

Connector No.	ET124
Connector Name	IPDME/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M06FB-LC
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
57	WB	RR DEF
58	BR	FUEL PUMP - (WITH CUMMINS 5.0L)
59	BY	FUEL PUMP - (WITH V8 (6.6L))
60	-	-
61	-	-
62	B	PAUD

Connector No.	E130
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH10FB-NH
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
63	—	—

Revision: August 2016

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

## < WIRING DIAGRAM >

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

EC-33

Revision: August 2016

2017 Titan NAM

AAKIA4085GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
SEC  
L  
M  
N  
O  
P

# INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

## < WIRING DIAGRAM >

### INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

Connector No.	Signal Name	Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	G	1	G	ENG START SW/NO ESCL	41	Y/L	TRAILER LIGHT CHECK RELAY OUT
2	-	2	-	-	42	R/Y	CARGO LAMP OUT
3	R	3	-	A/L POWER SUPPLY 5V	43	-	-
4	W/R	4	-	A/L SIGNAL	44	-	-
5	-	5	-	-	45	-	-
6	-	6	-	-	46	-	-
7	-	7	-	-	47	-	-
8	-	8	-	-	48	R	HIGH SIDE START SW/ LED
9	-	9	-	-	49	-	-
10	SB	10	-	COMBI SW IN 5	50	-	-
11	GR/Y	11	-	COMBI SW IN 4	51	-	-
12	Y	12	-	COMBI SW IN 3	52	W	AUDIO DONGLE
13	GR/B	13	-	COMBI SW IN 2	53	-	-
14	V	14	-	COMBI SW IN 1	54	W/L	PW UART
15	-	15	-	-	55	W/B	L&R SENSOR K-LINE
16	-	16	-	-	56	-	-
17	P	17	-	GND RF A/L	57	-	-
18	V	18	-	SECURITY INDICATOR	58	-	-
19	-	19	-	-	59	-	-
20	R	20	-	SHIFT P	60	L	CAN-H
21	R/W	21	-	STEP LAMP/CONT	61	O	REAR DEFOGGER RELAY OUT
22	-	22	-	-	62	W	STARTER RELAY OUT
23	Y	23	-	AIRCON SW	63	-	-
24	-	24	-	-	64	P	BUZZER OUT
25	W	25	-	BRAKE SW/FUSE	65	-	-
26	L	26	-	SHORT IN PIN INPUT	66	W	BLOWER FAN RELAY OUT
27	R/G	27	-	BRAKE SW/LAMP	67	G	IGN ELEC RELAY OUT 2
28	-	28	-	-	68	L	MR OUTPUT
29	W	29	-	BLOWER FAN SW	69	R/B	AT DEVICE OUT
30	P	30	-	DR DOOR LOCK STATUS	70	P	IGN USM OUT 1
31	-	31	-	-	71	O	DR REQUEST SW
32	Y	32	-	REAR DEFOGGER SW	72	G	AS REQUEST SW
33	-	33	-	-	73	-	-
34	-	34	-	-	74	-	-
35	R/G	35	-	REVERSE SW			
36	W/B	36	-	HAZARD SW			
37	-	37	-	-			
38	-	38	-	-			

AAKIA4086GB

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

## < WIRING DIAGRAM >

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

Connector No.	M24	37	R	ILL DOWN SW
Connector Name	COMBINATION METER (WITH TYPE A)	38	G	8PIN OUTPUT
Connector Type	TH40FW-NH	39	-	-
Connector Color	WHITE	40	-	-
Connector No.	M25			
Connector Name	COMBINATION METER (WITH TYPE A)			
Connector Type	TH12FW-NH			
Connector Color	WHITE			

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	GND/STRG/SATELLITE SW (GND)	4	-	-
2	-	-	5	-	-
3	-	-	6	-	-
4	-	-	7	V	SECURITY
5	-	-	8	-	-
6	-	-	9	BG	AS BELT SW (W/O OUT)
7	V	SECURITY	10	LG	TOW MODE SW
8	-	-	11	BR	CHG
9	BG	AS BELT SW (W/O OUT)	12	BR	LED HEAD LAMP (R)
10	LG	TOW MODE SW	13	W	LED HEAD LAMP (L)
11	BR	CHG	14	R	ACC SW
12	BR	LED HEAD LAMP (R)	15	W	OUTSIDE TEMP SENSOR (WITH YK691D)
13	W	LED HEAD LAMP (L)	16	O	AIR BAG
14	R	ACC SW	17	-	-
15	W	OUTSIDE TEMP SENSOR (WITH YK691D)	18	P	TRIP RESET SW
16	O	AIR BAG	19	-	-
17	-	-	20	R	OUTSIDE TEMP GND (WITH YK691D)
18	P	TRIP RESET SW	21	-	-
19	-	-	22	P	STRG SW A
20	R	OUTSIDE TEMP GND (WITH YK691D)	23	R	STRG SW B
21	-	-	24	W	WASHER SW
22	P	STRG SW A	25	-	-
23	R	STRG SW B			
24	W	WASHER SW			
25	-	-			

AAKIA4087GE

# INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

< WIRING DIAGRAM >

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

Connector No.	M31	27G	Lg	TO ENGINE ROOM HARNESS	80G	R	TO ENGINE ROOM HARNESS
Connector Name	WIRE TO WIRE	28G	G/B	TO ENGINE ROOM HARNESS	81G	L	TO ENGINE ROOM HARNESS
Connector Type	·TH80FW-CS16-TM4	29G	G/B	TO ENGINE ROOM HARNESS	82G	R	TO ENGINE ROOM HARNESS
Connector Color	WHITE	30G	R	TO ENGINE ROOM HARNESS	83G	L	TO ENGINE ROOM HARNESS
		31G	R	TO ENGINE ROOM HARNESS	84G	L	TO ENGINE ROOM HARNESS
		32G	R	TO ENGINE ROOM HARNESS	85G	W	TO ENGINE ROOM HARNESS
		33G	Y/L	TO ENGINE ROOM HARNESS	86G	B/R	TO ENGINE ROOM HARNESS
		34G	GR	TO ENGINE ROOM HARNESS	87G	W	TO ENGINE ROOM HARNESS
		35G	G/R	TO ENGINE ROOM HARNESS	88G	G	TO ENGINE ROOM HARNESS
		36G	SB	TO ENGINE ROOM HARNESS	89G	P	TO ENGINE ROOM HARNESS
		37G	R/W	TO ENGINE ROOM HARNESS	90G	G	TO ENGINE ROOM HARNESS
		38G	BR	TO ENGINE ROOM HARNESS	91G	P	TO ENGINE ROOM HARNESS
		39G	BR	TO ENGINE ROOM HARNESS	92G	V/W	TO ENGINE ROOM HARNESS
		40G	-	TO ENGINE ROOM HARNESS	93G	BR	TO ENGINE ROOM HARNESS
		41G	R/G	TO ENGINE ROOM HARNESS	94G	B	TO ENGINE ROOM HARNESS
		42G	O	TO ENGINE ROOM HARNESS	95G	G	TO ENGINE ROOM HARNESS
		43G	G	TO ENGINE ROOM HARNESS	96G	R	TO ENGINE ROOM HARNESS
		44G	R/Y	TO ENGINE ROOM HARNESS	97G	R	TO ENGINE ROOM HARNESS
		45G	G	TO ENGINE ROOM HARNESS	98G	W/B	TO ENGINE ROOM HARNESS
		46G	LG	TO ENGINE ROOM HARNESS	99G	R	TO ENGINE ROOM HARNESS
		47G	R	TO ENGINE ROOM HARNESS	100G	GR/W	TO ENGINE ROOM HARNESS
		48G	-	TO ENGINE ROOM HARNESS			
		50G	BR	TO ENGINE ROOM HARNESS			
		51G	R	TO ENGINE ROOM HARNESS			
		52G	L	TO ENGINE ROOM HARNESS			
		53G	W	TO ENGINE ROOM HARNESS			
		54G	W	TO ENGINE ROOM HARNESS			
		55G	G	TO ENGINE ROOM HARNESS			
		56G	W	TO ENGINE ROOM HARNESS			
		57G	Y	TO ENGINE ROOM HARNESS			
		58G	B/G	TO ENGINE ROOM HARNESS			
		59G	B/G	TO ENGINE ROOM HARNESS			
		60G	B/G	TO ENGINE ROOM HARNESS			
		61G	O	TO ENGINE ROOM HARNESS			
		62G	W	TO ENGINE ROOM HARNESS			
		63G	O	TO ENGINE ROOM HARNESS			
		64G	W/L	TO ENGINE ROOM HARNESS			
		65G	W/R	TO ENGINE ROOM HARNESS			
		66G	B/G	TO ENGINE ROOM HARNESS			
		67G	O	TO ENGINE ROOM HARNESS			
		68G	B	TO ENGINE ROOM HARNESS			
		69G	W	TO ENGINE ROOM HARNESS			
		70G	L	TO ENGINE ROOM HARNESS			
		71G	R/W	TO ENGINE ROOM HARNESS			
		72G	L/W	TO ENGINE ROOM HARNESS			
		73G	SHIELD	TO ENGINE ROOM HARNESS			
		74G	W	TO ENGINE ROOM HARNESS			
		75G	R	TO ENGINE ROOM HARNESS			
		76G	R/G	TO ENGINE ROOM HARNESS			
		77G	B/G	TO ENGINE ROOM HARNESS			
		78G	P	TO ENGINE ROOM HARNESS			
		79G	-	TO ENGINE ROOM HARNESS			

AAKIA4088GB

# INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

## < WIRING DIAGRAM >

### INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

Connector No.	IM36	WIRE TO WIRE	TO BODY NO. 2 HARNESS	SHIELD	TO BODY NO. 2 HARNESS
Connector Name	22A	G	TO BODY NO. 2 HARNESS	R	TO BODY NO. 2 HARNESS
Connector Type	23A	Y	TO BODY NO. 2 HARNESS	L	TO BODY NO. 2 HARNESS
Connector Color	24A	L	TO BODY NO. 2 HARNESS	SHIELD	TO BODY NO. 2 HARNESS
GRAY	25A	GR	TO BODY NO. 2 HARNESS	GR	TO BODY NO. 2 HARNESS
	26A	LG	TO BODY NO. 2 HARNESS	V	TO BODY NO. 2 HARNESS
	27A	LG	TO BODY NO. 2 HARNESS	R	TO BODY NO. 2 HARNESS
	28A	GR	TO BODY NO. 2 HARNESS	SHIELD	TO BODY NO. 2 HARNESS
	29A	BR	TO BODY NO. 2 HARNESS	R	TO BODY NO. 2 HARNESS
	30A	BR	TO BODY NO. 2 HARNESS	SHIELD	TO BODY NO. 2 HARNESS
	31A	W/R	TO BODY NO. 2 HARNESS	O	TO BODY NO. 2 HARNESS
	32A	G/R	TO BODY NO. 2 HARNESS	SHIELD	TO BODY NO. 2 HARNESS
	33A	-	TO BODY NO. 2 HARNESS	W	TO BODY NO. 2 HARNESS
	34A	SHIELD	TO BODY NO. 2 HARNESS	B	TO BODY NO. 2 HARNESS
	35A	P	TO BODY NO. 2 HARNESS	W	TO BODY NO. 2 HARNESS
	36A	B	TO BODY NO. 2 HARNESS	SHIELD	TO BODY NO. 2 HARNESS
	37A	-	TO BODY NO. 2 HARNESS	G	TO BODY NO. 2 HARNESS
	38A	R/B	TO BODY NO. 2 HARNESS	W/L	TO BODY NO. 2 HARNESS
	39A	G/O	TO BODY NO. 2 HARNESS	BR	TO BODY NO. 2 HARNESS
	40A	V	TO BODY NO. 2 HARNESS	L/Y	TO BODY NO. 2 HARNESS
	41A	SHIELD	TO BODY NO. 2 HARNESS	R/L	TO BODY NO. 2 HARNESS
	42A	SHIELD	TO BODY NO. 2 HARNESS	BR	TO BODY NO. 2 HARNESS
	43A	R	TO BODY NO. 2 HARNESS	R	TO BODY NO. 2 HARNESS
	44A	G	TO BODY NO. 2 HARNESS	LG	TO BODY NO. 2 HARNESS
	45A	-	TO BODY NO. 2 HARNESS	B/Y	TO BODY NO. 2 HARNESS
	46A	-	TO BODY NO. 2 HARNESS	O/L	TO BODY NO. 2 HARNESS
	47A	Y	TO BODY NO. 2 HARNESS	BR/W	TO BODY NO. 2 HARNESS
	48A	R/W	TO BODY NO. 2 HARNESS		
	49A	R/L	TO BODY NO. 2 HARNESS		
	50A	B	TO BODY NO. 2 HARNESS		
	51A	-	TO BODY NO. 2 HARNESS		
	52A	-	TO BODY NO. 2 HARNESS		
	53A	-	TO BODY NO. 2 HARNESS		
	54A	-	TO BODY NO. 2 HARNESS		
	55A	-	TO BODY NO. 2 HARNESS		
	56A	-	TO BODY NO. 2 HARNESS		
	57A	-	TO BODY NO. 2 HARNESS		
	58A	-	TO BODY NO. 2 HARNESS		
	59A	-	TO BODY NO. 2 HARNESS		
	60A	G/W	TO BODY NO. 2 HARNESS		
	61A	-	TO BODY NO. 2 HARNESS		
	62A	-	TO BODY NO. 2 HARNESS		
	63A	-	TO BODY NO. 2 HARNESS		
	64A	-	TO BODY NO. 2 HARNESS		
	65A	-	TO BODY NO. 2 HARNESS		
	66A	-	TO BODY NO. 2 HARNESS		
	67A	-	TO BODY NO. 2 HARNESS		
	68A	-	TO BODY NO. 2 HARNESS		
	69A	Y/R	TO BODY NO. 2 HARNESS		
	70A	R/G	TO BODY NO. 2 HARNESS		
	71A	-	TO BODY NO. 2 HARNESS		
	72A	W	TO BODY NO. 2 HARNESS		
	73A	G	TO BODY NO. 2 HARNESS		
	74A	W	TO BODY NO. 2 HARNESS		

AAKIA4089GB



# INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

< WIRING DIAGRAM >

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

Connector No.	M40	28J	L	TO BODY HARNESS	81J	SHIELD	TO BODY HARNESS	Connector No.	M68	Connector Name	A/T SHIFT SELECTOR
Connector Name	WIRE TO WIRE	29J	G/O	TO BODY HARNESS	82J	L/R	TO BODY HARNESS	Connector Type	TK08FW	IGNITION	
Connector Type	•TH80FW-CS16-TM4	30J	SB	TO BODY HARNESS	83J	-	TO BODY HARNESS	Connector Color	WHITE		
Connector Color	WHITE	31J	L/G	TO BODY HARNESS	84J	-	TO BODY HARNESS				
		32J	R	TO BODY HARNESS	85J	W	TO BODY HARNESS				
		33J	BG	TO BODY HARNESS	86J	G	TO BODY HARNESS				
		34J	Y	TO BODY HARNESS	87J	W	TO BODY HARNESS				
		35J	P	TO BODY HARNESS	88J	SHIELD	TO BODY HARNESS				
		36J	G/R	TO BODY HARNESS	89J	R	TO BODY HARNESS				
		37J	LG	TO BODY HARNESS	90J	L	TO BODY HARNESS				
		38J	SB	TO BODY HARNESS	91J	L/B	TO BODY HARNESS				
		39J	Y	TO BODY HARNESS	92J	SB	TO BODY HARNESS				
		40J	SB	TO BODY HARNESS	93J	B	TO BODY HARNESS				
		41J	L	TO BODY HARNESS	94J	LG	TO BODY HARNESS				
		42J	43J	44J	45J	46J	47J	48J	49J	50J	
		51J	52J	53J	54J	55J	56J	57J	58J	59J	60J
		61J	62J	63J	64J	65J	66J	67J	68J	69J	70J
		71J	72J	73J	74J	75J	76J	77J	78J	79J	80J
		81J	82J	83J	84J	85J	86J	87J	88J	89J	90J
		91J	92J	93J	94J	95J	96J	97J	98J	99J	100J
Terminal	Color of Wire	Signal Name	Signal Name	Signal Name	Terminal	Color of Wire	Signal Name	Signal Name	Terminal	Color of Wire	Signal Name
1J	G	TO BODY HARNESS	53J	R	TO BODY HARNESS	1	B	GND	1J	M68	CONNECTOR
2J	R/Y	TO BODY HARNESS	54J	L	TO BODY HARNESS	2	B	GND	2J	CONNECTOR	NS10FW-C-S
3J	L	TO BODY HARNESS	55J	R	TO BODY HARNESS	3	L/R	SHIFT LOCK SOL OUT	3J	CONNECTOR	WHITE
4J	L/B	TO BODY HARNESS	56J	W	TO BODY HARNESS	4	R	SHIFT P	4J	CONNECTOR	
5J	B	TO BODY HARNESS	57J	R	TO BODY HARNESS	5	R/B	AT DEVICE OUT	5J	CONNECTOR	
6J	BR	TO BODY HARNESS	58J	B	TO BODY HARNESS	6	LG	TOW MODE SW	6J	CONNECTOR	
7J	BG	TO BODY HARNESS	59J	V	TO BODY HARNESS	7	BR	SHIFT UP	7J	CONNECTOR	
8J	SB	TO BODY HARNESS	60J	G/W	TO BODY HARNESS	8	V/W	SHIFT DOWN	8J	CONNECTOR	
9J	BR	TO BODY HARNESS		-	TO BODY HARNESS						
10J	R	TO BODY HARNESS			TO BODY HARNESS						
11J	OB	TO BODY HARNESS			TO BODY HARNESS						
12J	L	TO BODY HARNESS			TO BODY HARNESS						
13J	W	TO BODY HARNESS			TO BODY HARNESS						
14J	Y	TO BODY HARNESS			TO BODY HARNESS						
15J	-	TO BODY HARNESS			TO BODY HARNESS						
16J	R	TO BODY HARNESS			TO BODY HARNESS						
17J	G	TO BODY HARNESS			TO BODY HARNESS						
18J	SB	TO BODY HARNESS			TO BODY HARNESS						
19J	O	TO BODY HARNESS			TO BODY HARNESS						
20J	OB	TO BODY HARNESS			TO BODY HARNESS						
21J	Y	TO BODY HARNESS			TO BODY HARNESS						
22J	P	TO BODY HARNESS			TO BODY HARNESS						
23J	W	TO BODY HARNESS			TO BODY HARNESS						
24J	WR	TO BODY HARNESS			TO BODY HARNESS						
25J	P	TO BODY HARNESS			TO BODY HARNESS						
26J	L	TO BODY HARNESS			TO BODY HARNESS						
27J	R	TO BODY HARNESS			TO BODY HARNESS						

AAKIA4090GB

# INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

< WIRING DIAGRAM >

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

Connector No.	M70	Color of Wire	P	Signal Name	ACC LED	Terminal No.	2	R	RF NIMOCO
Connector Name	FUSE BLOCK (J/B)		112	-	-	3	B	-	GND
Connector Type	NS16FBR-CS		113	L	ACC RELAY OUT	4	-	-	-
Connector Color	BROWN		114	W	AS DOOR ANT A				
			115	BG	AS DOOR ANT B				
			116	W	ROOM ANT 2 A				
			117	GR/B	FL FLASHER				
			118	-	-				
			119	R	-				
			120	-	-				
			121	G	DR DOOR ANT B				
			122	P	DR DOOR ANT A				
			123	W	ROOM ANT 1 A				
			124	G	ROOM ANT 1 B				
			125	-	-				
			126	P	IMMO/START BUTTON ANT B	1	W	ROOM ANT 1A	
			127	BG	IMMO/START BUTTON ANT A	2	G	ROOM ANT 1B	
			128	B	ROOM ANT 2 B				
Terminal No.		Color of Wire		Signal Name		Terminal No.		Color of Wire	
1R	L					1			
2R	GR					2			
3R	Y/R								
4R	-								
5R	W								
6R	GR/W								
7R	-			ACCESSORY					
8R	-			-					
9R	-			-					
10R	W								
11R	-								
12R	BG								
13R	B								
14R	GR								
15R	Y								
16R	GR			ACCESSORY					
Connector No.	M80	Color of Wire		Signal Name		Terminal No.		Color of Wire	
Connector Name	BCM (BODY CONTROL MODULE)		R/G	BATTERY SAVER OUT		1	W		
Connector Type	TH24FB-NH		129	LG	SUPER LOCK/DOOR UNLOCK AS	2	B		ROOM ANT 2A
Connector Color	BLACK		130	W	BAT BCM FUSE				ROOM ANT 2B
			131	W	DOOR UNLOCK AS/R/R/L				
			132	Y	GND2				
			133	BR	DOOR LOCK AS/R/R/L				
			134	B	DOOR UNLOCK AS/R/R/L				
			135	O	DOOR LOCK DR/AS/F/L				
			136	L	DOOR UNLOCK DR/AS/F/L				
			137	V	DOOR UNLOCK DR/AS/F/L				
			138	V	BAT REAR DOOR				
			139	W	BAT POWER FIL				
			140	LG	P/W POWER SUPPLY IGN				
Terminal No.		Color of Wire		Signal Name		1	2	3	4
105	GR/Y			FR FLASHER					
106	-			-					
107	W			LOW SIDE START SW LED					
108	L/R			SHIFT LOCK SOLENOID OUT					
109	-			-					
110	-			-					

AAKIA4091GB

# INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

## < WIRING DIAGRAM >



### INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

Connector No.	M163
Connector Name	COMBINATION METER (WITH TYPE B)

Connector No.	M191
Connector Name	JOINT CONNECTOR-M01

Connector Type	TH40FW-NH
Connector Color	WHITE

Connector No.	MH24FW-J
Connector Name	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	GND (ILL)	1	-	-
2	B	GND (CIRCUIT)	2	B	GND
3	B	GND (POWER)	3	B	GND
4	-	-	4	B	GROUND
5	-	-	5	-	-
6	R	BAT	6	B	GND
7	V	SECURITY	7	B	GND
8	W	IGN	8	B	GND
9	BG	AS BELT SW (W/O ODS)	9	-	-
10	LG	TOW MODE SW	10	B	GND
11	BR	CHG	11	B	GND
12	B	SATELLITE SW GND	12	B	GND
13	B	STRG SW GND	13	B	GND
14	R	ACC	14	B	GND
15	W	OUTSIDE TEMP SENSOR	15	B	GND
16	O	AIR BAG	16	-	-
17	-	-	17	B	GND
18	P	TRIP RESET SW	18	B	GND
19	-	-	19	B	GND
20	R	OUTSIDE TEMP GND	20	B	GND
21	-	-	21	B	GND
22	P	STRG SW A	22	B	GND
23	R	STRG SW B	23	B	GND
24	W	WASHER SW	24	B	GROUND
25	-	-	25	B	GND
26	G	PKB SW	26	B	GND
27	P/L	AS BELT SW (W/O ODS)	27	B	GND
28	O/B	DR BELT SW	28	B	GROUND
29	-	-	29	B	GROUND
30	YV	FUEL SENSOR GND	30	B	GROUND
31	BR/Y	FUEL SENSOR	31	-	-
32	BR	AT SHIFT UP	32	-	-
33	V/W	AT SHIFT DOWN	33	-	-
34	L	CAN-H	34	-	-
35	P	CAN-L	35	-	-
36	W	ILL UP SW	36	-	-
37	R	ILL DOWN SW	37	-	-
38	G	8PR OUTPUT	38	-	-

AAKIA4092GB


## **NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS**

## < WIRING DIAGRAM >

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

## Wiring Diagram


INFOID:0000000014391293



AAKWA1569GE

## **NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS**


## < WIRING DIAGRAM >



AAKWA1570GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >



AAKWA1571GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

## < WIRING DIAGRAM >

### NVIS CONNECTORS

Connector No.	E112
Connector Name	STOP LAMP RELAY
Connector Type	MSU2FL-M2-LC
Connector Color	BLUE
	

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS16FW-CS
Connector Color	WHITE
	

Terminal No.	Signal Name
1	GROUND
2	W
3	R/G
4	R/Y
5	BATTERY
	

Terminal No.	Signal Name
1	STOP LAMP SWITCH
2	FR FOGL RH
3	FR FOGL LH
4	FR FOGL RH
5	FR FOGL LH
6	FR FOGL RH
7	FR FOGL LH
8	R/Y
9	G/W
10	G
11	O
12	P
13	Y/R
14	G
15	G/R
16	V/R
17	W
18	L/W
	

Terminal No.	Signal Name
1	RELAY CONT. (WITHOUT LED REAR COMBINATION LAMPS)
2	W
3	GR
4	R/B
	

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH12PM-NH
Connector Color	WHITE
	

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M06FB-LC
Connector Color	BLACK
	

Terminal No.	56
	

Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS08FBR-CS
Connector Color	BROWN
	

Terminal No.	49
	

Terminal No.	51
	

AAKIA4118GB

## **NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS**


## < WIRING DIAGRAM >

## ENVIS CONNECTORS


Connector No.	E130
Connector Name	IPD E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH10F-BH
Connector Color	BLACK

**H.S.**





24G	G/B	TO MAIN HARNESS
25G	R/W	TO MAIN HARNESS
26G	R	TO MAIN HARNESS
27G	L/G	TO MAIN HARNESS
28G	G/B	TO MAIN HARNESS
29G	G/R	TO MAIN HARNESS
30G	B/R	TO MAIN HARNESS
31G	P	TO MAIN HARNESS - (WITH CUMMINS 3.0L)
31G	R	TO MAIN HARNESS - (WITH YK66VD)
32G	P	TO MAIN HARNESS
33G	Y/L	TO MAIN HARNESS
34G	GR	TO MAIN HARNESS
35G	G/R	TO MAIN HARNESS
36G	SB	TO MAIN HARNESS
37G	R/W	TO MAIN HARNESS
38G	BR	TO MAIN HARNESS
39G	BR	TO MAIN HARNESS
40G	-	TO MAIN HARNESS
41G	R/G	TO MAIN HARNESS
42G	O	TO MAIN HARNESS
43G	B	TO MAIN HARNESS - (WITH CUMMINS 3.0L)
43G	G	TO MAIN HARNESS - (WITH YK66VD)
44G	R/Y	TO MAIN HARNESS
45G	G	TO MAIN HARNESS
46G	L/G	TO MAIN HARNESS
47G	R	TO MAIN HARNESS
48G	W	TO MAIN HARNESS
49G	-	TO MAIN HARNESS
50G	BR	TO MAIN HARNESS
51G	R	TO MAIN HARNESS
52G	L	TO MAIN HARNESS
53G	W	TO MAIN HARNESS
54G	W	TO MAIN HARNESS
55G	G	TO MAIN HARNESS
56G	W	TO MAIN HARNESS
57G	Y	TO MAIN HARNESS
58G	B/G	TO MAIN HARNESS
59G	B/G	TO MAIN HARNESS
60G	B/G	TO MAIN HARNESS
61G	B	TO MAIN HARNESS
62G	W	TO MAIN HARNESS
63G	R	TO MAIN HARNESS
64G	W/L	TO MAIN HARNESS
65G	W/R	TO MAIN HARNESS
66G	B/G	TO MAIN HARNESS
67G	B/G	TO MAIN HARNESS
68G	B	TO MAIN HARNESS
69G	Y	TO MAIN HARNESS
70G	L	TO MAIN HARNESS
71G	B/W	TO MAIN HARNESS



Revision: August 2016

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

## < WIRING DIAGRAM >

### NVIS CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS
Connector Color	WHITE
	

7	-	-	43	-	BG	IMMO START BUTTON ANT A
8	-	-	44	-	2	-
9	-	-	45	-	3	P
10	SB	COMBI SW IN 5	46	-	-	-
11	G/Y	COMBI SW IN 4	47	-	-	-
12	Y	COMBI SW IN 3	48	R	HIGH SIDE START SW LED	
13	G/B	COMBI SW IN 2	49	-	-	-
14	V	COMBI SW IN 1	50	-	-	-
15	-	-	51	-	-	-
16	-	-	52	W	AUDIO DONGLE	
17	P	GND RF A/L	53	-	-	-
18	V	SECURITY INDICATOR	54	W/L	PW UART	
19	-	-	55	W/B	L&R SENSOR K-LINE	
20	R	SHIFT P	56	-	-	-
21	R/W	STEP LAMP CONT	57	-	-	-
22	-	-	58	-	-	-
23	Y	AIRCON SW	59	P	CAN-L	
24	-	-	60	L	CAN-H	
25	W	BRAKE SW FUSE	61	O	REAR DEFOGGER RELAY OUT	
26	L	SHORT IN PIN INPUT	62	W	STARTER RELAY OUT	
27	R/G	BRAKE SW LAMP	63	-	-	-
28	-	-	64	P	BUZZER OUT	
29	W	BLOWER FAN SW	65	-	-	-
30	P	DR DOOR LOCK STATUS	66	W	BLOWER FAN RELAY OUT	
31	-	-	67	G	IGN ELEC RELAY OUT 2	
32	Y	REAR DEFOGGER SW	68	L	MR OUTPUT	
33	-	-	69	R/B	AT DEVICE OUT	
34	-	-	70	P	IGN USM OUT 1	
35	R/G	REVERSE SW	71	O	DR REQUEST SW	
36	W/B	HAZARD SW	72	G	AS REQUEST SW	
37	-	-	73	-	-	-
38	-	-	74	-	-	-
39	B/R	SHIFT N/P	75	U/W	COMBI SW OUT 5	
40	-	-	76	P	COMBI SW OUT 4	
			77	L	COMBI SW OUT 3	

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH
Connector Color	GREEN
	

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH
Connector Color	BLACK
	

Connector No.	M21
Connector Name	NATS ANTENNA AMP
Connector Type	NH03FW
Connector Color	WHITE

Terminal No.	1	Signal Name	
2	-	ENG START SW NO ESC	
3	R	ALU POWER SUPPLY 5V	
4	W/R	A/R SIGNAL	
5	-	TRAILER LIGHT CHECK RELAY OUT	
6	-	CARGO LAMP OUT	

Terminal No.	1	Color of Wire	Signal Name
2	-	-	-
3	R	A/R SIGNAL	
41	Y/L	TRAILER LIGHT CHECK RELAY OUT	
42	R/Y	CARGO LAMP OUT	

Terminal No.	1	Color of Wire	Signal Name
2	-	-	-
3	G	ENG START SW NO ESC	
4	-	-	-
5	-	-	-
6	-	-	-

Terminal No.	1	Color of Wire	Signal Name
2	-	-	-
3	R	A/R SIGNAL	
4	Y/L	TRAILER LIGHT CHECK RELAY OUT	
5	-	-	-
6	-	-	-

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS


< WIRING DIAGRAM >

## NVIS CONNECTORS


Terminal	Color of Wire	Signal Name
1	B	GND(SATELLITE SW/GND)
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	V	SECURITY
8	-	-
9	BG	AS BELT SW(W/O ODS)
10	LG	TOW MODE SW
11	BR	CHG
12	BR	LED HEAD LAMP (R)
13	W	LED HEAD LAMP (L)
14	R	ACC SW
15	W	OUTSIDE TEMP SENSOR (WITH VK651D)
16	O	AIR BAG
17	-	-
18	P	TRIP RESET SW
19	-	-
20	R	OUTSIDE TEMP GND (WITH VK651D)
21	-	-
22	P	STRO SW A
23	R	STRO SW B
24	W	WASHER SW
25	-	-
26	G	PKG SW
27	P/L	AS BELT SW (WITH ODS)
28	O/B	DR BELT SW
29	-	-
30	-	-
31	-	-
32	BR	AT SHIFT UP
33	V/W	AT SHIFT DOWN
34	-	-
35	-	-
36	W	ILL UP SW

AAKIA4121GB

Terminal No.	Color of Wire	Signal Name
1	4	5
2	5	6
3	7	8
4	9	10
5	11	12
6	13	14
7	15	16
8	17	18
9	19	20
10	21	22
11	23	24
12	25	26
13	27	28
14	29	30
15	31	32
16	33	34
17	35	36
18	37	38
19	39	40



Terminal No.	Color of Wire	Signal Name
1	B	GND(SATELLITE SW/GND)
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	V	SECURITY
8	-	-
9	BG	AS BELT SW(W/O ODS)
10	LG	TOW MODE SW
11	BR	CHG
12	BR	LED HEAD LAMP (R)
13	W	LED HEAD LAMP (L)
14	R	ACC SW
15	W	OUTSIDE TEMP SENSOR (WITH VK651D)
16	O	AIR BAG
17	-	-
18	P	TRIP RESET SW
19	-	-
20	R	OUTSIDE TEMP GND (WITH VK651D)
21	-	-
22	P	STRO SW A
23	R	STRO SW B
24	W	WASHER SW
25	-	-
26	G	PKG SW
27	P/L	AS BELT SW (WITH ODS)
28	O/B	DR BELT SW
29	-	-
30	-	-
31	-	-
32	BR	AT SHIFT UP
33	V/W	AT SHIFT DOWN
34	-	-
35	-	-
36	W	ILL UP SW



Terminal No.	Color of Wire	Signal Name
1	W	AUDIO DONGLE
2	-	-
3	-	-
4	B	GND

Terminal No.	Color of Wire	Signal Name
1	W	AUDIO DONGLE
2	-	-
3	-	-
4	B	GND

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
SEC  
Z  
M  
O  
P

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

## < WIRING DIAGRAM >

### NVIS CONNECTORS

Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name	Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name
M31	WIRE TO WIRE	G/B	27G	Lg	TO ENGINE ROOM HARNESS	80G	R	TO ENGINE ROOM HARNESS	81G	L	TO ENGINE ROOM HARNESS
		G/B	28G	G/B	TO ENGINE ROOM HARNESS	82G	R	TO ENGINE ROOM HARNESS	83G	L	TO ENGINE ROOM HARNESS
		G/R	29G	B/R	TO ENGINE ROOM HARNESS	84G	L	TO ENGINE ROOM HARNESS	85G	W	TO ENGINE ROOM HARNESS
		B/R	30G	R	TO ENGINE ROOM HARNESS	86G	B/R	TO ENGINE ROOM HARNESS	87G	W	TO ENGINE ROOM HARNESS
		R	31G	R	TO ENGINE ROOM HARNESS	88G	G	TO ENGINE ROOM HARNESS	89G	P	TO ENGINE ROOM HARNESS
		R	32G	R	TO ENGINE ROOM HARNESS	90G	G	TO ENGINE ROOM HARNESS	91G	P	TO ENGINE ROOM HARNESS
		Y/L	33G	Y/L	TO ENGINE ROOM HARNESS	92G	V/W	TO ENGINE ROOM HARNESS	93G	BR	TO ENGINE ROOM HARNESS
		Y/L	34G	G/R	TO ENGINE ROOM HARNESS	94G	B	TO ENGINE ROOM HARNESS	95G	G	TO ENGINE ROOM HARNESS
		G/R	35G	G/R	TO ENGINE ROOM HARNESS	96G	R	TO ENGINE ROOM HARNESS	97G	R	TO ENGINE ROOM HARNESS
		G/R	36G	SB	TO ENGINE ROOM HARNESS	98G	WB	TO ENGINE ROOM HARNESS	99G	R	TO ENGINE ROOM HARNESS
		SB	37G	R/W	TO ENGINE ROOM HARNESS	100G	GR/W	TO ENGINE ROOM HARNESS	101G	GR/W	TO ENGINE ROOM HARNESS
		R/W	38G	BR	TO ENGINE ROOM HARNESS						
		BR	39G	BR	TO ENGINE ROOM HARNESS						
		BR	40G	-	TO ENGINE ROOM HARNESS						
		-	41G	R/G	TO ENGINE ROOM HARNESS						
		R/G	42G	O	TO ENGINE ROOM HARNESS						
		O	43G	G	TO ENGINE ROOM HARNESS						
		G	44G	R/Y	TO ENGINE ROOM HARNESS						
		R/Y	45G	G	TO ENGINE ROOM HARNESS						
		G	46G	G	TO ENGINE ROOM HARNESS						
		G	47G	LG	TO ENGINE ROOM HARNESS						
		LG	48G	R	TO ENGINE ROOM HARNESS						
		R	49G	W	TO ENGINE ROOM HARNESS						
		W	50G	BR	TO ENGINE ROOM HARNESS						
		BR	51G	R	TO ENGINE ROOM HARNESS						
		R	52G	L	TO ENGINE ROOM HARNESS						
		L	53G	W	TO ENGINE ROOM HARNESS						
		W	54G	W	TO ENGINE ROOM HARNESS						
		W	55G	G	TO ENGINE ROOM HARNESS						
		G	56G	W	TO ENGINE ROOM HARNESS						
		W	57G	Y	TO ENGINE ROOM HARNESS						
		Y	58G	BG	TO ENGINE ROOM HARNESS						
		BG	59G	BG	TO ENGINE ROOM HARNESS						
		BG	60G	BG	TO ENGINE ROOM HARNESS						
		BG	61G	O	TO ENGINE ROOM HARNESS						
		O	62G	W	TO ENGINE ROOM HARNESS						
		W	63G	O	TO ENGINE ROOM HARNESS						
		O	64G	W/L	TO ENGINE ROOM HARNESS						
		W/L	65G	W/R	TO ENGINE ROOM HARNESS						
		W/R	66G	BG	TO ENGINE ROOM HARNESS						
		BG	67G	O	TO ENGINE ROOM HARNESS						
		O	68G	B	TO ENGINE ROOM HARNESS						
		B	69G	Y	TO ENGINE ROOM HARNESS						
		Y	70G	L	TO ENGINE ROOM HARNESS						
		L	71G	R/W	TO ENGINE ROOM HARNESS						
		R/W	72G	L/W	TO ENGINE ROOM HARNESS						
		L/W	73G	SHIELD	TO ENGINE ROOM HARNESS						
		SHIELD	74G	W	TO ENGINE ROOM HARNESS						
		W	75G	R	TO ENGINE ROOM HARNESS						
		R	76G	R/G	TO ENGINE ROOM HARNESS						
		R/G	77G	BG	TO ENGINE ROOM HARNESS						
		BG	78G	P	TO ENGINE ROOM HARNESS						
		P	79G	-	TO ENGINE ROOM HARNESS						

AAKIA4122GB

## **NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS**

## < WIRING DIAGRAM >


NVIS CONNECTORS



Connector No.	M70
Connector Name	FUSE BLOCK (JB)
Connector Type	NS16FBR-CS
Connector Color	BROWN



111	P	ACC LED
112	-	-
113	L	ACC RELAY OUT
114	W	AS DOOR ANT A
115	BG	AS DOOR ANT B
116	W	ROOM ANT 1 A
117	G/B	FL FLASHER
118	-	-
119	R	RF NMOCO
120	-	-
121	G	DR DOOR ANT B
122	P	DR DOOR ANT A
123	W	ROOM ANT 1 A
124	G	ROOM ANT 1 B
125	-	-
126	P	IMMO START BUTTON ANT B
127	BG	IMMO START BUTTON ANT A
128	B	ROOM ANT 2 B



Connector No.	M163	COMBINATION METER (WITH TYPE B)	39	-	-
Connector Name	TH40FW-NH		40	GR	ILL CONT OUT
Connector Type	TH40FW-NH	Connector No.	M191	JOINT CONNECTOR-M01	
Connector Color	WHITE	Connector Name	NH24FW-J		
		Connector Type	WHITE		
		Connector Color	WHITE		
					
Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	GND (ILL)	1	-	-
2	B	GND (CIRCUIT)	2	B	GND
3	B	GND (POWER)	3	B	GROUND
4	-	-	4	B	GROUND
5	-	-	5	-	-
6	R	BAT	6	B	GND
7	V	SECURITY	7	B	GND
8	W	IGN	8	B	GROUND
9	BG	AS BELT SW (W/O ODS)	9	B	GROUND
10	LG	TOW MODE SW	10	B	GROUND
11	BR	CHG	11	B	GROUND
12	B	SATELLITE SW/GND	12	B	GROUND
13	B	STRG SW/GND	13	B	GROUND
14	R	ACC	14	B	GROUND
15	W	OUTSIDE TEMP SENSOR	15	B	GROUND
16	O	AIR BAG	16	-	-
17	-	-	17	B	GROUND
18	P	TRIP RESET SW	18	B	GROUND
19	-	-	19	SHIELD	GROUND
20	R	OUTSIDE TEMP GND	20	B	GROUND
21	-	-	21	B	GROUND
22	P	STRG SW A	22	B	GROUND
23	R	STRG SW B	23	B	GROUND
24	W	WASHER SW	24	B	GROUND
25	-	-	25	PKB SW	GROUND
26	G	AS BELT SW (WITH ODS)	26	W	ILL UP SW
27	P/L	DR BELT SW	27	R	ILL DOWN SW
28	O/B	-	28	G	8P/8P OUTPUT
29	-	-	29	-	-
30	Y/N	FUEL SENSOR GND	30	-	-
31	BRY	FUEL SENSOR	31	-	-
32	BR	AT SHIFT UP	32	-	-
33	V/W	AT SHIFT DOWN	33	-	-
34	L	CAN-H	34	-	-
35	P	CAN-L	35	-	-
36	W	ILL UP SW	36	-	-
37	R	ILL DOWN SW	37	-	-
38	G	8P/8P OUTPUT	38	-	-



AAKIA4123GE


## VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

## VEHICLE SECURITY SYSTEM

## Wiring Diagram


INFOID:0000000014391294



AKWA1572GP

# VEHICLE SECURITY SYSTEM


## < WIRING DIAGRAM >



SEC

# VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >




AAKWA1574GB

## VEHICLE SECURITY SYSTEM


## < WIRING DIAGRAM >

VEHICLE SECURITY SYSTEM CONNECTORS

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Type	TH04FW-NH
Connector Color	WHITE



28J	L	TO MAIN HARNESS
29J	G/O	TO MAIN HARNESS
30J	SB	TO MAIN HARNESS
31J	LG	TO MAIN HARNESS
32J	R	TO MAIN HARNESS
33J	L	TO MAIN HARNESS
34J	Y	TO MAIN HARNESS
35J	P	TO MAIN HARNESS
36J	G/R	TO MAIN HARNESS
37J	L/G/B	TO MAIN HARNESS
38J	SB	TO MAIN HARNESS
39J	Y/L	TO MAIN HARNESS
40J	BR	TO MAIN HARNESS
41J	L	TO MAIN HARNESS
42J	L	TO MAIN HARNESS
43J	SB	TO MAIN HARNESS
44J	BR	TO MAIN HARNESS
45J	BG	TO MAIN HARNESS
46J	P/Y	TO MAIN HARNESS
47J	Y/G/R	TO MAIN HARNESS
48J	V	TO MAIN HARNESS
49J	B/R/Y	TO MAIN HARNESS
50J	G/W	TO MAIN HARNESS
51J	-	TO MAIN HARNESS
52J	SHIELD	TO MAIN HARNESS
53J	R	TO MAIN HARNESS
54J	L	TO MAIN HARNESS
55J	R	TO MAIN HARNESS
56J	W	TO MAIN HARNESS
57J	L/G	TO MAIN HARNESS
58J	O	TO MAIN HARNESS
59J	-	TO MAIN HARNESS
60J	SHIELD	TO MAIN HARNESS
61J	G	TO MAIN HARNESS
62J	-	TO MAIN HARNESS
63J	R/W	TO MAIN HARNESS
64J	L/W	TO MAIN HARNESS
65J	SHIELD	TO MAIN HARNESS
66J	B	TO MAIN HARNESS
67J	SHIELD	TO MAIN HARNESS
68J	O/L	TO MAIN HARNESS
69J	SHIELD	TO MAIN HARNESS
70J	BR	TO MAIN HARNESS
71J	L/W	TO MAIN HARNESS
72J	-	TO MAIN HARNESS
73J	-	TO MAIN HARNESS
74J	SHIELD	TO MAIN HARNESS
75J	L/G/B	TO MAIN HARNESS
76J	R	TO MAIN HARNESS
77J	SHIELD	TO MAIN HARNESS
78J	BR	TO MAIN HARNESS
79J	B	TO MAIN HARNESS



# VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

Connector No.	Signal Name	Color of Wire	Terminal No.	Color of Wire	Signal Name
B116	LG/Y	TO MAIN HARNESS (WITHOUT CLIMATE CONTROLLED SEATS)	57A	-	TO MAIN HARNESS
REAR DOOR SWITCH RH	LG	TO MAIN HARNESS (WITH CLIMATE CONTROLLED SEATS)	58A	-	TO MAIN HARNESS
TH04FW-NH	W	TO MAIN HARNESS	59A	-	TO MAIN HARNESS
Connector Type	B	TO MAIN HARNESS	60A	G/W	TO MAIN HARNESS
Connector Color	B	TO MAIN HARNESS	61A	-	TO MAIN HARNESS
WHITE	UB	TO MAIN HARNESS	62A	-	TO MAIN HARNESS
	W	TO MAIN HARNESS	63A	-	TO MAIN HARNESS
	LG	TO MAIN HARNESS	64A	-	TO MAIN HARNESS
11A	B/R/O	TO MAIN HARNESS	65A	-	TO MAIN HARNESS
12A	Y/W	TO MAIN HARNESS	66A	-	TO MAIN HARNESS
13A	R/G	TO MAIN HARNESS	67A	-	TO MAIN HARNESS
14A	Y/L	TO MAIN HARNESS	68A	-	TO MAIN HARNESS
15A	O/L	TO MAIN HARNESS	69A	Y/R	TO MAIN HARNESS
16A	L	TO MAIN HARNESS	70A	R/G	TO MAIN HARNESS
17A	Y	TO MAIN HARNESS	71A	-	TO MAIN HARNESS
18A	LG	TO MAIN HARNESS	72A	Y/B	TO MAIN HARNESS
19A	R	TO MAIN HARNESS	73A	G	TO MAIN HARNESS
20A	B/G	TO MAIN HARNESS	74A	B/R	TO MAIN HARNESS
21A	LG/R	TO MAIN HARNESS	75A	SHIELD	TO MAIN HARNESS
22A	Y/L/G	TO MAIN HARNESS	76A	G/R/R	TO MAIN HARNESS
23A	B/R/Y	TO MAIN HARNESS	77A	L	TO MAIN HARNESS
24A	-	TO MAIN HARNESS	78A	SHIELD	TO MAIN HARNESS
25A	GR	TO MAIN HARNESS	79A	Y	TO MAIN HARNESS
26A	LG	TO MAIN HARNESS	80A	L	TO MAIN HARNESS
27A	L/G/B	TO MAIN HARNESS	81A	R	TO MAIN HARNESS
28A	-	TO MAIN HARNESS	82A	SHIELD	TO MAIN HARNESS
29A	BR	TO MAIN HARNESS	83A	L/G/B	TO MAIN HARNESS
30A	Y/R	TO MAIN HARNESS	84A	R	TO MAIN HARNESS
31A	GR	TO MAIN HARNESS	85A	SHIELD	TO MAIN HARNESS
32A	LG/B	TO MAIN HARNESS	86A	G/R/B	TO MAIN HARNESS
33A	-	TO MAIN HARNESS	87A	B	TO MAIN HARNESS
34A	SHIELD	TO MAIN HARNESS	88A	W	TO MAIN HARNESS
35A	P	TO MAIN HARNESS	89A	SHIELD	TO MAIN HARNESS
36A	B	TO MAIN HARNESS	90A	G	TO MAIN HARNESS
37A	-	TO MAIN HARNESS	91A	WL	TO MAIN HARNESS
38A	R/B	TO MAIN HARNESS	92A	BR	TO MAIN HARNESS
39A	G/O	TO MAIN HARNESS	93A	L/Y	TO MAIN HARNESS
40A	V	TO MAIN HARNESS	94A	R/Y/L	TO MAIN HARNESS
41A	SHIELD	TO MAIN HARNESS	95A	BR	TO MAIN HARNESS
42A	SHIELD	TO MAIN HARNESS	96A	R	TO MAIN HARNESS
43A	R	TO MAIN HARNESS	97A	LG	TO MAIN HARNESS
44A	G	TO MAIN HARNESS	98A	B/V	TO MAIN HARNESS
45A	-	TO MAIN HARNESS	99A	OL	TO MAIN HARNESS
46A	Y	TO MAIN HARNESS	100A	BR/W	TO MAIN HARNESS
47A	R/W	TO MAIN HARNESS			
48A	R/L	TO MAIN HARNESS			
50A	B	TO MAIN HARNESS			
51A	-	TO MAIN HARNESS			
52A	-	TO MAIN HARNESS			
53A	-	TO MAIN HARNESS			
54A	-	TO MAIN HARNESS			
55A	-	TO MAIN HARNESS			
56A	-	TO MAIN HARNESS			
					AAKIA4125GB

## VEHICLE SECURITY SYSTEM CONNECTORS

Connector No.	Signal Name	Color of Wire	Terminal No.	Signal Name	Color of Wire
B149	WIRE TO WIRE	SB/G	1	TO MAIN HARNESS (WITHOUT CLIMATE CONTROLLED SEATS)	57A
TH80MDGY-CSU6-TM4			2	TO MAIN HARNESS (WITH CLIMATE CONTROLLED SEATS)	58A
GRAY			3	TO MAIN HARNESS	59A
			4	TO MAIN HARNESS	60A
			5	TO MAIN HARNESS	61A
			6	TO MAIN HARNESS	62A
			7	TO MAIN HARNESS	63A
			8	TO MAIN HARNESS	64A
			9	TO MAIN HARNESS	65A
			10	TO MAIN HARNESS	66A
			11	TO MAIN HARNESS	67A
			12	TO MAIN HARNESS	68A
			13	TO MAIN HARNESS	69A
			14	TO MAIN HARNESS	70A
			15	TO MAIN HARNESS	71A
			16	TO MAIN HARNESS	72A
			2	TO MAIN HARNESS	73A
			3	TO MAIN HARNESS	74A
			4	TO MAIN HARNESS	75A
			5	TO MAIN HARNESS	76A
			6	TO MAIN HARNESS	77A
			7	TO MAIN HARNESS	78A
			8	TO MAIN HARNESS	79A
			9	TO MAIN HARNESS	80A
			10	TO MAIN HARNESS	81A
			11	TO MAIN HARNESS	82A
			12	TO MAIN HARNESS	83A
			13	TO MAIN HARNESS	84A
			14	TO MAIN HARNESS	85A
			15	TO MAIN HARNESS	86A
			16	TO MAIN HARNESS	87A
			2	TO MAIN HARNESS	88A
			3	TO MAIN HARNESS	89A
			4	TO MAIN HARNESS	90A
			5	TO MAIN HARNESS	91A
			6	TO MAIN HARNESS	92A
			7	TO MAIN HARNESS	93A
			8	TO MAIN HARNESS	94A
			9	TO MAIN HARNESS	95A
			10	TO MAIN HARNESS	96A
			11	TO MAIN HARNESS	97A
			12	TO MAIN HARNESS	98A
			13	TO MAIN HARNESS	99A
			14	TO MAIN HARNESS	100A

# VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

## VEHICLE SECURITY SYSTEM CONNECTORS

Connector No.	D7	Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH	Connector Type	NS16FW-CS	Connector Color	WHITE

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Type	E06FGY-RS
Connector Color	GRAY

Connector No.	D129
Connector Name	POWER/WINDOW AND DOOR LOCK/UNLOCK SWITCH FH
Connector Type	NS12FW-CS
Connector Color	WHITE






Connector No.	EE56
Connector Name	HORN (LEFT)
Connector Type	P01FB-A
Connector Color	BLACK

SEC-55

# VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >

## VEHICLE SECURITY SYSTEM CONNECTORS

Connector No.	Connector Name	Connector No.	Connector Name	Connector No.	Connector Name
E04	HOOD SWITCH	E123	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	E130	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
RH03MB	BLACK	NS08FBR-CS	TH10FB-NH	TH10FB-NH	TH10FB-NH
BLACK	BROWN	BROWN	BLACK	BLACK	BLACK
					
Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	GND	49	Y/B	A/C COMP - (WITH CUMMINS 5.0L)
2	Y	HOOD SW	49	GR/BR	A/C COMP - (WITH VK56VD)
3	SB	HOOD SW 2	50	BR	TRAILER TOW
			51	-	-
			52	B	S-QND
			53	-	-
			54	-	-
			55	-	-
			56	-	-
			57	-	-
			58	-	-
			59	-	-
			60	-	-
			61	-	-
			62	-	-
			63	-	-
			64	R	DETENT SW
			65	-	-
			66	P	PUSH START SW
			67	-	-
			68	L	IGN SIGNAL
			69	-	-
			70	-	-
			71	SB	HOOD SW2
			72	W	E-QPLG - (WITH VK56VD)

AAKIA4127GB

## VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

## VEHICLE SECURITY SYSTEM CONNECTORS

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Type	TH80MMW-CS16-TM4
Connector Color	WHITE



**H.S.**

AAKIA4128GE

24G	GRB	TO MAIN HARNESS
25G	R/W	TO MAIN HARNESS
26G	R	TO MAIN HARNESS
27G	LG	TO MAIN HARNESS
28G	GRB	TO MAIN HARNESS
29G	GRB	TO MAIN HARNESS
30G	BRY	TO MAIN HARNESS
31G	P	TO MAIN HARNESS - (WITH CUMMINS 5.0L)
31G	R	TO MAIN HARNESS - (WITH YK66VJD)
32G	P	TO MAIN HARNESS
33G	Y/L	TO MAIN HARNESS
34G	GR	TO MAIN HARNESS
35G	GR	TO MAIN HARNESS
36G	SB	TO MAIN HARNESS
37G	R/W	TO MAIN HARNESS
38G	BR	TO MAIN HARNESS
39G	BR	TO MAIN HARNESS
40G	-	TO MAIN HARNESS
41G	R/G	TO MAIN HARNESS
42G	O	TO MAIN HARNESS
43G	B	TO MAIN HARNESS - (WITH CUMMINS 5.0L)
43G	G	TO MAIN HARNESS - (WITH YK66VJD)
44G	R/Y	TO MAIN HARNESS
45G	G	TO MAIN HARNESS
46G	LG	TO MAIN HARNESS
47G	R	TO MAIN HARNESS
48G	W	TO MAIN HARNESS
49G	-	TO MAIN HARNESS
50G	BR	TO MAIN HARNESS
51G	R	TO MAIN HARNESS
52G	L	TO MAIN HARNESS
53G	W	TO MAIN HARNESS
54G	W	TO MAIN HARNESS
55G	G	TO MAIN HARNESS
56G	W	TO MAIN HARNESS
57G	Y	TO MAIN HARNESS
58G	BG	TO MAIN HARNESS
59G	BG	TO MAIN HARNESS
60G	BG	TO MAIN HARNESS
61G	B	TO MAIN HARNESS
62G	W	TO MAIN HARNESS
63G	R	TO MAIN HARNESS
64G	W/L	TO MAIN HARNESS
65G	W/R	TO MAIN HARNESS
66G	BG	TO MAIN HARNESS
67G	BG	TO MAIN HARNESS
68G	B	TO MAIN HARNESS
69G	Y	TO MAIN HARNESS
70G	L	TO MAIN HARNESS
71G	R/W	TO MAIN HARNESS

P

P

# VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

## VEHICLE SECURITY SYSTEM CONNECTORS

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS
Connector Color	WHITE



7	-	-	-
8	-	-	-
9	-	-	-
10	SB	COMB SW IN 5	COMB SW IN 4
11	GY	COMB SW IN 3	COMB SW IN 2
12	Y	COMB SW IN 2	COMB SW IN 1
13	GB	-	-
14	V	-	-
15	-	-	-
16	-	-	-
17	P	GRND/RF ALL	SECURITY/INDICATOR
18	V	-	-
19	-	-	SHIFT P
20	R	STEP LAMP CONT	-
21	R/W	-	AIRCON SW
22	-	-	BRAKE SW FUSE
23	Y	-	SHORT IN PIN INPUT
24	-	-	BRAKE SW LAMP
25	W	-	BLOWER FAN SW
26	L	-	DR DOOR LOCK STATUS
27	R/G	-	-
28	-	-	REAR DEFOGGER SW
29	W	-	-
30	P	-	-
31	-	-	-
32	Y	-	-
33	-	-	-
34	-	-	-
35	R/G	REVERSE SW	-
36	WB	HAZARD SW	-
37	-	-	-
38	-	-	-
39	B/R	SHIFT N/P	-
40	-	-	-



43	-	-	Connector No.	M20
44	-	-	Connector Name	BCM (BODY CONTROL MODULE)
45	-	-	Connector Type	TH24FG1-NH
46	-	-	Connector Color	GRAY
47	-	-		
48	R	HIGH SIDE START SW LED		
49	-	-		
50	-	-		
51	-	-		
52	W	AUDIO DONGLE		
53	-	-		
54	W/L	PW UART		
55	W/B	L&R SENSOR K-LINE		
56	-	-		
57	-	-		
58	-	-		
59	P	CAN-L	Terminal No.	Color of Wire
60	L	CAN-H	81	-
61	O	REAR DEFROGER RELAY OUT	82	W
62	W	STARTER RELAY OUT	83	-
63	-	-	84	-
64	P	BUZZER OUT	85	-
65	-	-	86	GRB
66	W	BLOWER FAN RELAY OUT	87	Y/B
67	G	IGN ELEC RELAY OUT 2	88	-
68	L	MR OUTPUT	89	-
69	R/B	AT DEVICE OUT	90	-
70	P	IGN USM OUT 1	91	-
71	O	DR REQUEST SW	92	O
72	G	AS REQUEST SW	93	R
73	-	-	94	G
74	-	-	95	-
75	L/W	COMBI SW OUT 5	96	BG
76	P	COMBI SW OUT 4	97	PL
77	L	COMBI SW OUT 3	98	-
78	O/B	COMBI SW OUT 2	99	-
79	R/W	COMBI SW OUT 1	100	-
80	-	-	101	-
81	-	-	102	-
82	-	-	103	GRB
83	-	-	104	-
84	-	-	105	RL FLASHER
85	-	-	106	-
86	-	-	107	-
87	-	-	108	-
88	-	-	109	-
89	-	-	110	-
90	-	-	111	-
91	-	-	112	-
92	O	RR FLASHER	113	-
93	R	RR DOOR SW	114	-
94	G	AS DOOR SW	115	-
95	-	-	116	-
96	BG	DR DOOR SW	117	-
97	PL	CARGO LAMP SW	118	-
98	-	-	119	-
99	-	-	120	-
100	-	-	121	-
101	-	-	122	-
102	-	-	123	-



# VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >

## VEHICLE SECURITY SYSTEM CONNECTORS

Terminal	Color of Wire	Signal Name
1	B	GND(SATELLITE SW/GND)
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	V	SECURITY
8	-	-
9	BG	AS BELT SW(W/O ODS)
10	LG	TOW MODE SW
11	BR	CHG
12	BR	LED HEAD LAMP (R)
13	W	LED HEAD LAMP (L)
14	R	ACC SW
15	W	OUTSIDE TEMP SENSOR (WITH VK651D)
16	O	AIR BAG
17	-	-
18	P	TRIP RESET SW
19	-	-
20	R	OUTSIDE TEMP GND (WITH VK651D)
21	-	-
22	P	STRO SW A
23	R	STRO SW B
24	W	WASHER SW
25	-	-
26	G	PKG SW
27	P/L	AS BELT SW (WITH ODS)
28	O/B	DR BELT SW
29	-	-
30	-	-
31	-	-
32	BR	AT SHIFT UP
33	V/W	AT SHIFT DOWN
34	-	-
35	-	-
36	W	ILL UP SW

AAKIA4130GB


# VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

### VEHICLE SECURITY SYSTEM CONNECTORS

Terminal No.	Color of Wire	Signal Name	Wire to Wire	TO ENGINE ROOM HARNESS
1G	G	TO ENGINE ROOM HARNESS		80G R TO ENGINE ROOM HARNESS
2G	B/R	TO ENGINE ROOM HARNESS		81G L TO ENGINE ROOM HARNESS
3G	W	TO ENGINE ROOM HARNESS		82G R TO ENGINE ROOM HARNESS
4G	BR/W	TO ENGINE ROOM HARNESS		83G L TO ENGINE ROOM HARNESS
5G	-	TO ENGINE ROOM HARNESS		84G L TO ENGINE ROOM HARNESS
6G	R/W	TO ENGINE ROOM HARNESS		85G W TO ENGINE ROOM HARNESS
7G	Y/R	TO ENGINE ROOM HARNESS		86G B/R TO ENGINE ROOM HARNESS
8G	Y	TO ENGINE ROOM HARNESS		87G W TO ENGINE ROOM HARNESS
9G	GR	TO ENGINE ROOM HARNESS		88G G TO ENGINE ROOM HARNESS
10G	G/R	TO ENGINE ROOM HARNESS		89G P TO ENGINE ROOM HARNESS
11G	SB	TO ENGINE ROOM HARNESS		90G G TO ENGINE ROOM HARNESS
12G	R/W	TO ENGINE ROOM HARNESS		91G P TO ENGINE ROOM HARNESS
13G	BR	TO ENGINE ROOM HARNESS		92G V/W TO ENGINE ROOM HARNESS
14G	-	TO ENGINE ROOM HARNESS		93G BR TO ENGINE ROOM HARNESS
15G	R/G	TO ENGINE ROOM HARNESS		94G B TO ENGINE ROOM HARNESS
16G	O	TO ENGINE ROOM HARNESS		95G G TO ENGINE ROOM HARNESS
17G	G	TO ENGINE ROOM HARNESS		96G R TO ENGINE ROOM HARNESS
18G	R/Y	TO ENGINE ROOM HARNESS		97G R TO ENGINE ROOM HARNESS
19G	G	TO ENGINE ROOM HARNESS		98G W/B TO ENGINE ROOM HARNESS
20G	LG	TO ENGINE ROOM HARNESS		99G R TO ENGINE ROOM HARNESS
21G	R	TO ENGINE ROOM HARNESS		100G GR/W TO ENGINE ROOM HARNESS
22G	W	TO ENGINE ROOM HARNESS		
23G	-	TO ENGINE ROOM HARNESS		
24G	BR	TO ENGINE ROOM HARNESS		
25G	O	TO ENGINE ROOM HARNESS		
26G	Y/Y	TO ENGINE ROOM HARNESS		
27G	R	TO ENGINE ROOM HARNESS		

AAKIA4131GB



## VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

A

B

C

D

F

SEC.

L

54


41

0

P

VEHICLE SECURITY SYSTEM CONNECTORS

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Type	TH80FDGJ-CS16-TM4
Connector Color	GRAY



Connector No.	M36	Color of Wire	G	Signal Name	TO BODY NO. 2 HARNESS
Connector Name	WIRE TO WIRE		Y	TO BODY NO. 2 HARNESS	TO BODY NO. 2 HARNESS
Connector Type	TH80FDGY-CS16-TM4		L	TO BODY NO. 2 HARNESS	TO BODY NO. 2 HARNESS
Connector Color	GRAY		-	TO BODY NO. 2 HARNESS	TO BODY NO. 2 HARNESS
			GR	TO BODY NO. 2 HARNESS	TO BODY NO. 2 HARNESS
22A			GR	TO BODY NO. 2 HARNESS	75A SHIELD TO BODY NO. 2 HARNESS
23A			GR	TO BODY NO. 2 HARNESS	76A R TO BODY NO. 2 HARNESS
24A			GR	TO BODY NO. 2 HARNESS	77A L TO BODY NO. 2 HARNESS
25A			GR	TO BODY NO. 2 HARNESS	78A SHIELD TO BODY NO. 2 HARNESS
26A			GR	TO BODY NO. 2 HARNESS	79A GR TO BODY NO. 2 HARNESS
27A			LG	TO BODY NO. 2 HARNESS	80A V TO BODY NO. 2 HARNESS
28A			LG	TO BODY NO. 2 HARNESS	81A R TO BODY NO. 2 HARNESS
29A			GR	TO BODY NO. 2 HARNESS	82A SHIELD TO BODY NO. 2 HARNESS
30A			BR	TO BODY NO. 2 HARNESS	83A R TO BODY NO. 2 HARNESS
31A			WR	TO BODY NO. 2 HARNESS	84A O TO BODY NO. 2 HARNESS
32A			GR	TO BODY NO. 2 HARNESS	85A SHIELD TO BODY NO. 2 HARNESS
33A			-	TO BODY NO. 2 HARNESS	86A W TO BODY NO. 2 HARNESS
34A			SHIELD	TO BODY NO. 2 HARNESS	87A B TO BODY NO. 2 HARNESS
35A			P	TO BODY NO. 2 HARNESS	88A W SHIELD TO BODY NO. 2 HARNESS
36A			B	TO BODY NO. 2 HARNESS	89A SHIELD TO BODY NO. 2 HARNESS
37A			-	TO BODY NO. 2 HARNESS	90A G TO BODY NO. 2 HARNESS
38A			RB	TO BODY NO. 2 HARNESS	91A WL TO BODY NO. 2 HARNESS
39A			QI	TO BODY NO. 2 HARNESS	92A BR TO BODY NO. 2 HARNESS
40A			V	TO BODY NO. 2 HARNESS	93A LY TO BODY NO. 2 HARNESS
41A			SHIELD	TO BODY NO. 2 HARNESS	94A RL TO BODY NO. 2 HARNESS
42A			SHIELD	TO BODY NO. 2 HARNESS	95A BR TO BODY NO. 2 HARNESS
43A			R	TO BODY NO. 2 HARNESS	96A R TO BODY NO. 2 HARNESS
44A			G	TO BODY NO. 2 HARNESS	97A LG TO BODY NO. 2 HARNESS
45A			-	TO BODY NO. 2 HARNESS	98A BN TO BODY NO. 2 HARNESS
46A			-	TO BODY NO. 2 HARNESS	99A OVL TO BODY NO. 2 HARNESS
47A			Y	TO BODY NO. 2 HARNESS	100A BR/WV TO BODY NO. 2 HARNESS
48A			RW	TO BODY NO. 2 HARNESS	
49A			RL	TO BODY NO. 2 HARNESS	
50A			B	TO BODY NO. 2 HARNESS	
51A			-	TO BODY NO. 2 HARNESS	
52A			-	TO BODY NO. 2 HARNESS	
53A			-	TO BODY NO. 2 HARNESS	
54A			-	TO BODY NO. 2 HARNESS	
55A			-	TO BODY NO. 2 HARNESS	
56A			-	TO BODY NO. 2 HARNESS	
57A			-	TO BODY NO. 2 HARNESS	
58A			-	TO BODY NO. 2 HARNESS	
59A			-	TO BODY NO. 2 HARNESS	
60A			QW	TO BODY NO. 2 HARNESS	
61A			-	TO BODY NO. 2 HARNESS	
62A			-	TO BODY NO. 2 HARNESS	
63A			-	TO BODY NO. 2 HARNESS	
64A			-	TO BODY NO. 2 HARNESS	
65A			-	TO BODY NO. 2 HARNESS	
66A			-	TO BODY NO. 2 HARNESS	
67A			-	TO BODY NO. 2 HARNESS	
68A			-	TO BODY NO. 2 HARNESS	
69A			YR	TO BODY NO. 2 HARNESS	
70A			RG	TO BODY NO. 2 HARNESS	
71A			-	TO BODY NO. 2 HARNESS	
72A			W	TO BODY NO. 2 HARNESS	
73A			G	TO BODY NO. 2 HARNESS	
74A			W	TO BODY NO. 2 HARNESS	

AKTA4132GE

## VEHICLE SECURITY SYSTEM

## < WIRING DIAGRAM >

VEHICLE SECURITY SYSTEM CONNECTORS

Connector Type	NST010MW-CS								
Connector Color	WHITE								
Terminal No.	H.S.								
Color of Wire									
Signal Name									
5JU	TO BODY HARNESS								
53J	SHIELD								
53J	TO BODY HARNESS								
54J	R								
54J	TO BODY HARNESS								
55J	L								
55J	TO BODY HARNESS								
56J	W								
56J	TO BODY HARNESS								
57J	R								
58J	TO BODY HARNESS								
59J	B								
59J	TO BODY HARNESS								
60J	TO BODY HARNESS								
61J	SHIELD								
61J	TO BODY HARNESS								
61J	G								
62J	TO BODY HARNESS								
62J	-								
63J	TO BODY HARNESS								
64J	R/W								
64J	TO BODY HARNESS								
65J	TO BODY HARNESS								
66J	SHIELD								
66J	TO BODY HARNESS								
67J	B								
67J	TO BODY HARNESS								
68J	TO BODY HARNESS								
68J	W								
69J	TO BODY HARNESS								
70J	SHIELD								
70J	TO BODY HARNESS								
71J	TO BODY HARNESS								
71J	L/W								
72J	TO BODY HARNESS								
72J	-								
73J	TO BODY HARNESS								
74J	SHIELD								
75J	R								
76J	TO BODY HARNESS								
76J	O								
77J	TO BODY HARNESS								
78J	SHIELD								
78J	TO BODY HARNESS								
79J	W								
80J	TO BODY HARNESS								
81J	TO BODY HARNESS								
82J	TO BODY HARNESS								
83J	TO BODY HARNESS								
84J	TO BODY HARNESS								
85J	TO BODY HARNESS								
86J	TO BODY HARNESS								
87J	TO BODY HARNESS								
88J	TO BODY HARNESS								
89J	TO BODY HARNESS								
90J	TO BODY HARNESS								
91J	TO BODY HARNESS								
92J	TO BODY HARNESS								
93J	TO BODY HARNESS								
94J	TO BODY HARNESS								
95J	TO BODY HARNESS								
96J	TO BODY HARNESS								
97J	TO BODY HARNESS								
98J	TO BODY HARNESS								
99J	TO BODY HARNESS								
100J	TO BODY HARNESS								
101J	TO BODY HARNESS								
102J	TO BODY HARNESS								
103J	TO BODY HARNESS								
104J	TO BODY HARNESS								
105J	TO BODY HARNESS								
106J	TO BODY HARNESS								
107J	TO BODY HARNESS								
108J	TO BODY HARNESS								
109J	TO BODY HARNESS								
110J	TO BODY HARNESS								
111J	TO BODY HARNESS								
112J	TO BODY HARNESS								
113J	TO BODY HARNESS								
114J	TO BODY HARNESS								
115J	TO BODY HARNESS								
116J	TO BODY HARNESS								
117J	TO BODY HARNESS								
118J	-								
119J	-								
120J	-								
121J	-								
122J	P								
123J	TO BODY HARNESS								
124J	-								
125J	-								
126J	-								
127J	-								
128J	B								
129J	TO BODY HARNESS								
130J	-								
131J	-								
132J	-								
133J	-								
134J	-								
135J	-								
136J	-								
137J	-								
138J	-								
139J	-								
140J	-								
141J	-								
142J	-								
143J	-								
144J	-								
145J	-								
146J	-								
147J	-								
148J	-								
149J	-								
150J	-								
151J	-								
152J	-								
153J	-								
154J	-								
155J	-								
156J	-								
157J	-								
158J	-								
159J	-								

AAKIA4133GB


# VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >

## VEHICLE SECURITY SYSTEM CONNECTORS

		SECURITY	
Connector No.	M81	7	V
Connector Name	BCM (BODY CONTROL MODULE)	8	W
AS BELT SW (W/O ODS)		9	BG
'TOW MODE SW		10	LG
CHG		11	BR
SATELLITE SW/GND		12	B
STRG SW/GND		13	B
ACC		14	R
OUTSIDE TEMP SENSOR		15	W
AIR BAG		16	O
TRIP RESET SW		17	-
		18	P
		19	-
		20	R
		21	-
		22	P
		23	R
		24	W
		25	-
		26	G
		27	P/L
		28	O/B
		29	-
		30	Y/N
		31	BRY
		32	BR
		33	V/W
		34	L
		35	P
		36	W
		37	R
		38	G
		39	-
		40	GR

H.S.



AAKIA4134GB

Terminal No.	Color of Wire	Signal Name
1	B	GND (ILL)
2	B	GND (CIRCUIT)
3	B	GND (POWER)
4	-	-
5	-	-
6	R	BAT

2017 Titan NAM

Revision: August 2016

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

#### Work Flow

INFOID:000000014391295

#### OVERALL SEQUENCE



#### DETAILED FLOW

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

## 1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

## 2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

## 3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

## 4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

## 5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-51, "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

### NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included in Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-47, "Intermittent Incident"](#).

## 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

## 7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

## DIAGNOSIS AND REPAIR WORK FLOW

### < BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

#### Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-47, "Intermittent Incident"](#).

### 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.

2. Reconnect parts or connectors disconnected during Diagnosis Procedure after repair and replacement.

3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

### 9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

#### Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

# ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

## ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT ECM

### ECM : Description

INFOID:000000014391296

Performing the following procedure can automatically activate recommunication of ECM and BCM, but only when the ECM is replaced with a new one\*.

\*: New one means an ECM that has never been energized on-board.  
(In this step, initialization procedure by CONSULT is not necessary)

#### NOTE:

- If multiple keys are attached to the key holder, separate them before beginning work.
- Distinguish keys with unregistered key IDs from those with registered IDs.

### ECM : Work Procedure

INFOID:000000014391297

#### 1. PERFORM ECM RECOMMUNICATING FUNCTION

1. Install ECM.
2. Contact back side of registered Intelligent Key\* to push-button ignition switch, then turn ignition switch to ON.  
\*: To perform this step, use the key that is used before performing ECM replacement.
3. Maintain ignition switch in the ON position for at least 5 seconds.
4. Turn ignition switch to OFF.
5. Check that the engine starts.

>> GO TO 2.

#### 2. PERFORM ADDITIONAL SERVICE WHEN REPLACING ECM

Perform [EC-885, "Work Procedure"](#).

>> End.

## BCM

### BCM : Description

INFOID:000000014391298

#### BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement.

#### NOTE:

If "READ CONFIGURATION" can not be used, use the "WRITE CONFIGURATION - Manual selection" after replacing BCM.

#### AFTER REPLACEMENT

#### CAUTION:

When replacing BCM, always perform "WRITE CONFIGURATION" with CONSULT. Not doing so will cause the BCM control function to not operate normally.

- Complete the procedure of "WRITE CONFIGURATION" in order.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- If you set incorrect "WRITE CONFIGURATION", incidents might occur.

#### NOTE:

When replacing BCM, perform the system initialization (NATS).

### BCM : Work Procedure

INFOID:000000014391299

#### 1. SAVING VEHICLE SPECIFICATION

##### CONSULT Configuration

Perform "READ CONFIGURATION" to save or print current vehicle specification. Refer to [BCS-63, "CONFIGURATION \(BCM\) : Description"](#).

#### NOTE:

## ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

### < BASIC INSPECTION >

If “READ CONFIGURATION” can not be used, use the “WRITE CONFIGURATION - Manual selection” after replacing BCM.

>> GO TO 2.

### 2.REPLACE BCM

Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

>> GO TO 3.

### 3.WRITING VEHICLE SPECIFICATION

#### CONSULT Configuration

Perform “WRITE CONFIGURATION - Config file” or “WRITE CONFIGURATION - Manual selection” to write vehicle specification. Refer to [BCS-63, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 4.

### 4.INITIALIZE BCM (NATS)

Perform BCM initialization. (NATS)

>> Inspection End.

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### DTC Description

INFOID:000000014664557

##### Description

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. CAN Communication Signal Chart. Refer to [LAN-74, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

#### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
U1000	CAN COMM CIRCUIT (CAN communication circuit)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	2 seconds or more

#### POSSIBLE CAUSE

CAN communication system

#### FAIL-SAFE

—

#### Diagnosis Procedure

INFOID:000000014664558

##### 1. SELF DIAGNOSTIC RESULT

###### CONSULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" mode of "BCM".
3. Check DTC.

SEC

###### Is DTC "U1000" displayed?

YES >> Refer to [LAN-53, "Trouble Diagnosis Flow Chart"](#).  
 NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).  
 NO-2 >> Confirmation after repair: Inspection End.

L

M

N

O

P

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN)

### DTC Description

INFOID:000000014664559

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
U1010	CONTROL UNIT(CAN) (Control unit)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	2 seconds or more

### POSSIBLE CAUSE

- BCM

### FAIL-SAFE

—

### Diagnosis Procedure

INFOID:000000014664560

#### 1. REPLACE BCM

When DTC U1010 is detected, replace BCM.

>> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

**P1610 LOCK MODE****DTC Description**

INFOID:0000000014391304

ECM forcibly switches to the mode that inhibits engine start, when engine start operation is performed 5 times or more while communication between ECM and BCM is not normal.

**DTC DETECTION LOGIC****NOTE:**

If DTC P1610 is displayed with other DTC (for BCM or ENGINE), first perform the trouble diagnosis for other DTC.

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
P1610	LOCK MODE	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	When ECM detects a communication malfunction between ECM and BCM 5 times or more
		Diagnosis delay time	—

**POSSIBLE CAUSE**

Engine start operation is performed five times or more under the following conditions:

- Nissan Vehicle Immobilizer System malfunction
- Operation by unregistered key

**FAIL-SAFE**

Inhibit engine cranking

**DTC CONFIRMATION PROCEDURE****1. CHECK DTC PRIORITY**

If DTC P1610 is displayed with other DTC (for BCM or ENGINE), first perform the trouble diagnosis for other DTC.

Is applicable DTC detected?

YES >> Perform diagnosis of applicable. BCM: Refer to [BCS-52, "DTC Index"](#). ECM: Refer to [EC-837, "DTC Index"](#).

NO >> GO TO 2.

**2. PERFORM DTC CONFIRMATION PROCEDURE****CONSULT**

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" mode of "ENGINE".

Is DTC detected?

YES >> Refer to [SEC-71, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

**Diagnosis Procedure**

INFOID:0000000014391305

**1. CHECK DTC PRIORITY**

If DTC P1610 is displayed with other DTC (for BCM or ENGINE), first perform the trouble diagnosis for other DTC.

Is applicable DTC detected?

YES >> Perform diagnosis of applicable. BCM: Refer to [BCS-52, "DTC Index"](#). ECM: Refer to [EC-837, "DTC Index"](#).

NO >> GO TO 2.

**2. CHECK ENGINE START FUNCTION**

1. Check that DTC except for DTC P1610 is not detected.

## P1610 LOCK MODE

### < DTC/CIRCUIT DIAGNOSIS >

---

- 1. If detected, erase the DTC after fixing.
- 2. Turn ignition switch OFF.
- 3. Depress brake pedal and contact the registered Intelligent Key backside to push-button ignition switch, then wait 5 seconds.
- 4. Turn ignition switch ON.
- 5. Turn ignition switch OFF and wait 5 seconds.
- 6. Repeat steps 3 and 5 twice (a total of 3 times).
- 7. Check that engine can start.

>> Inspection End.

# P1611 ID DISCORD, IMMU-ECM

< DTC/CIRCUIT DIAGNOSIS >

## P1611 ID DISCORD, IMMU-ECM

### DTC Description

INFOID:000000014391306

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
P1611	ID DISCORD, IMMU-ECM	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	The ID verification results between BCM and ECM are not good
		Diagnosis delay time	—

### POSSIBLE CAUSE

- BCM
- Harness or connectors  
(The CAN communication line is open or shorted.)
- ECM

### FAIL-SAFE

Inhibit engine cranking

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" mode of "ENGINE".

##### Is DTC detected?

YES >> Refer to [SEC-73, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:000000014391307

SEC

#### 1. INTELLIGENT KEY REGISTRATION

##### CONSULT

Register all Intelligent Keys again.

##### Can engine be started with the registered Intelligent Key?

YES >> Inspection End.

NO >> GO TO 2.

#### 2. CHECK SELF DIAGNOSTIC RESULT

##### CONSULT

1. Select "Self Diagnostic Result" mode of "ENGINE".

2. Erase DTC.

3. Perform DTC CONFIRMATION PROCEDURE for DTC P1611. Refer to [SEC-73, "DTC Description"](#).

##### Is DTC detected?

YES >> GO TO 3.

NO >> Inspection End.

#### 3. REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

2. Perform DTC CONFIRMATION PROCEDURE for DTC P1611. Refer to [SEC-73, "DTC Description"](#).

##### Is DTC detected?

YES >> GO TO 4.

## P1611 ID DISCORD, IMMU-ECM

< DTC/CIRCUIT DIAGNOSIS >

NO      >> Inspection End.

### 4. REPLACE ECM

Replace ECM. Refer to [EC-1993, "Removal and Installation"](#).

>> Inspection End.

< DTC/CIRCUIT DIAGNOSIS >

## P1612 CHAIN OF ECM-IMMU

### DTC Description

INFOID:000000014391308

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
P1612	CHAIN OF BCM-ECM	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	Inactive communication between BCM and ECM
		Diagnosis delay time	—

### POSSIBLE CAUSE

- Harness or connectors  
(The CAN communication line is open or shorted.)
- BCM
- ECM

### FAIL-SAFE

Inhibit engine cranking

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK DTC PRIORITY

If DTC P1612 is displayed with DTC U1000 (for BCM) or U1010 (for BCM), first perform the trouble diagnosis for DTC U1000 (for BCM) or U1010 (for BCM).

##### Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000 (for BCM): Refer to [BCS-67, "DTC Description"](#). U1010 (for BCM): Refer to [BCS-68, "DTC Description"](#).

NO >> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" mode of "ENGINE".

##### Is DTC detected?

YES >> Refer to [SEC-75, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:000000014391309

#### 1. CHECK DTC PRIORITY

If DTC P1612 is displayed with DTC U1000 (for BCM) or U1010 (for BCM), first perform the trouble diagnosis for DTC U1000 (for BCM) or U1010 (for BCM).

##### Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000 (for BCM): Refer to [BCS-67, "DTC Description"](#). U1010 (for BCM): Refer to [BCS-68, "DTC Description"](#).

NO >> GO TO 2.

#### 2. REPLACE BCM

Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

##### Does the engine start?

YES >> Inspection End.

NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

---

**3.REPLACE ECM**

---

Replace ECM. Refer to [EC-1993, "Removal and Installation".](#)

>> Inspection End.

< DTC/CIRCUIT DIAGNOSIS >

## P1615 DIFFRENCE OF KEY

### DTC Description

INFOID:0000000014391310

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
P1615	DIFFERENCE OF KEY (Difference of key)	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	The ID verification results between combination meter (BCM) and ignition key are not good
		Diagnosis delay time	—

### POSSIBLE CAUSE

- Ignition key
- Combination meter

### FAIL-SAFE

Fuel cut

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

 CONSULT

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" mode of "ENGINE".

Is DTC detected?

YES >> Refer to [SEC-77, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:0000000014391311

#### 1. PERFORM INITIALIZATION

 CONSULT

Perform initialization of combination meter (BCM) and registration of all ignition keys.

Can the system be initialized and can the engine be started with registered ignition key?

YES >> Inspection End.

NO >> GO TO 2.

#### 2. REPLACE IGNITION KEY

 CONSULT

1. Replace ignition key.
2. Perform initialization of combination meter (BCM) and registration of all ignition keys.

Can the system be initialized and can the engine be started with registered ignition key?

YES >> Inspection End.

NO >> GO TO 3.

#### 3. REPLACE COMBINATION METER

 CONSULT

1. Replace combination meter. Refer to [MWI-108, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all ignition keys.

>> Inspection End.

## B2192 ID DISCORD, IMMU-ECM

< DTC/CIRCUIT DIAGNOSIS >

### B2192 ID DISCORD, IMMU-ECM

#### DTC Description

INFOID:0000000014391312

#### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2192	ID DISCORD BCM-ECM (Identification discord body control module - engine control module)	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	The ID verification results between BCM and ECM are not good
		Diagnosis delay time	—

#### POSSIBLE CAUSE

- BCM
- ECM

#### FAIL-SAFE

Inhibit engine cranking

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

 CONSULT

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" mode of "BCM".

Is DTC detected?

YES >> Refer to [SEC-78, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

#### Diagnosis Procedure

INFOID:0000000014391313

##### 1. INTELLIGENT KEY REGISTRATION

 CONSULT

Register all Intelligent Keys again.

Can engine be started with the registered Intelligent Key?

YES >> Inspection End.

NO >> GO TO 2.

##### 2. CHECK SELF-DIAGNOSIS RESULT

 CONSULT

1. Select "Self Diagnostic Result" mode of "BCM".

2. Erase DTC.

3. Perform DTC CONFIRMATION PROCEDURE for DTC B2192. Refer to [SEC-78, "DTC Description"](#).

Is DTC detected?

YES >> GO TO 3.

NO >> Inspection End.

##### 3. REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

2. Perform DTC CONFIRMATION PROCEDURE for DTC B2192. Refer to [SEC-78, "DTC Description"](#).

Is DTC detected?

YES >> GO TO 4.

NO >> Inspection End.

## B2192 ID DISCORD, IMMU-ECM

< DTC/CIRCUIT DIAGNOSIS >

### 4. REPLACE ECM

Replace ECM. Refer to [EC-1993, "Removal and Installation".](#)

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

## B2193 CHAIN OF ECM-IMMU

### DTC Description

INFOID:0000000014391314

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2193	CHAIN OF BCM-ECM (Chain of body control module - engine control module)	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	Inactive communication between BCM and ECM
		Diagnosis delay time	—

### POSSIBLE CAUSE

- Harness or connectors  
(The CAN communication line is open or shorted.)
- ECM
- BCM

### FAIL-SAFE

Inhibit engine cranking

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK DTC PRIORITY

If DTC B2193 is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

##### Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-67, "DTC Description"](#). U1010: Refer to [BCS-68, "DTC Description"](#).

NO >> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" mode of "BCM".

##### Is DTC detected?

YES >> Refer to [SEC-80, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:0000000014391315

#### 1. CHECK DTC PRIORITY

If DTC B2193 is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

##### Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-67, "DTC Description"](#). U1010: Refer to [BCS-68, "DTC Description"](#).

NO >> GO TO 2.

#### 2. REPLACE BCM

Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

##### Does the engine start?

YES >> Inspection End.

NO >> GO TO 3.

## B2193 CHAIN OF ECM-IMMU

< DTC/CIRCUIT DIAGNOSIS >

### 3.REPLACE ECM

Replace ECM. Refer to [EC-1993, "Removal and Installation".](#)

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B2195 ANTI-SCANNING

< DTC/CIRCUIT DIAGNOSIS >

## B2195 ANTI-SCANNING

### DTC Description

INFOID:000000014391316

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2195	ANTI-SCANNING (Anti-scanning)	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	ID verification between BCM and ECM that is out of the specified specification is detected
		Diagnosis delay time	—

### POSSIBLE CAUSE

ID verification request out of the specified specification

### FAIL-SAFE

Inhibits engine cranking

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### ④ CONSULT

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" mode of "BCM".

##### Is DTC detected?

YES >> Refer to [SEC-82, "Diagnosis Procedure"](#).  
NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).  
NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:000000014391317

#### 1. CHECK SELF DIAGNOSTIC RESULT 1

##### ④ CONSULT

1. Select "Self Diagnostic Result" mode of "BCM".
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B2195. Refer to [SEC-82, "DTC Description"](#).

##### Is DTC detected?

YES >> GO TO 2.  
NO >> Inspection End.

#### 2. CHECK EQUIPMENT OF THE VEHICLE

Check that unspecified accessory part related to engine start is not installed.

##### Is unspecified accessory part related to engine start installed?

YES >> GO TO 3.  
NO >> GO TO 4.

#### 3. CHECK SELF DIAGNOSTIC RESULT 2

##### ④ CONSULT

1. Obtain the customers approval to remove unspecified accessory part related to engine start, and then remove it.
2. Select "Self Diagnostic Result" mode of "BCM".
3. Erase DTC.
4. Perform DTC CONFIRMATION PROCEDURE for DTC B2195. Refer to [SEC-82, "DTC Description"](#).

##### Is DTC detected?

YES >> GO TO 4.

## B2195 ANTI-SCANNING

< DTC/CIRCUIT DIAGNOSIS >

NO    >> Inspection End.

### 4. REPLACE BCM

Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

## B2196 DONGLE UNIT

### DTC Description

INFOID:0000000014391318

BCM performs ID verification between BCM and dongle unit.  
When verification result is OK, BCM permits cranking.

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2196 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B2196 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2196	DONGLE NG	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	The ID verification results between BCM and dongle unit is not good
		Diagnosis delay time	—

### POSSIBLE CAUSE

- Dongle unit
- Harness or connector  
(Dongle unit circuit is open or shorted.)

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Turn ignition switch ON.
2. Turn ignition switch OFF.
3. Turn ignition switch ON.
4. Select "Self Diagnosis Result" mode.
5. Check DTC.

##### Is the DTC detected?

YES >> Refer to [SEC-84, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000014391319

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. PERFORM INITIALIZATION

1. Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT.
2. Start the engine.

##### Does the engine start?

YES >> Inspection End.  
NO >> GO TO 2.

#### 2. CHECK DONGLE UNIT CIRCUIT

1. Turn ignition switch OFF.

## B2196 DONGLE UNIT

### < DTC/CIRCUIT DIAGNOSIS >

2. Disconnect BCM connector and dongle unit connector.
3. Check continuity between BCM harness connector and dongle unit harness connector.

BCM		Dongle unit		Continuity
Connector	Terminal	Connector	Terminal	
M19	52	M27	1	Yes

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M19	52		No

#### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3.CHECK DONGLE UNIT GROUND CIRCUIT

Check continuity between dongle unit harness connector and ground.

Dongle unit		Ground	Continuity
Connector	Terminal		
M27	4		Yes

#### Is the inspection result normal?

YES >> Replace dongle unit.

NO >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

## B2198 NATS ANTENNA AMP.

### DTC Description

INFOID:0000000014391320

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2198	NATS ANTENNA AMP (Nissan Anti-Theft System antenna amplifier)	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	Inactive communication between NATS antenna amp. and BCM is detected when BCM enters in the low power consumption mode (BCM sleep condition)
		Diagnosis delay time	—

### POSSIBLE CAUSE

- Harness or connectors  
(NATS antenna amp. circuit is open or shorted.)
- NATS antenna amp.
- BCM

### FAIL-SAFE

Inhibit engine cranking

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Make the conditions that BCM enters in the low power consumption mode (BCM sleep condition). Refer to [BCS-16, "POWER CONSUMPTION CONTROL SYSTEM : System Description"](#).
2. Turn ignition switch ON.
3. Check DTC in "Self Diagnostic Result" mode of "BCM".

##### Is DTC detected?

YES >> Refer to [SEC-86, "Diagnosis Procedure"](#).  
NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).  
NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:0000000014391321

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).


#### 1. CHECK NATS ANTENNA COMMUNICATION SIGNAL

Check voltage signal between NATS antenna amp. harness connector and ground using an oscilloscope.

# B2198 NATS ANTENNA AMP.

## < DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition	Voltage (Approx.)
Connector	Terminals			
M21	1,3	Ground	Intelligent Key: Intelligent Key battery is removed	Brake pedal: Depressed <b>NOTE:</b> Waveform varies each time when brake pedal is depressed
				Brake pedal: Released



JMKIA6232JP

Is the inspection result normal?

YES >> Replace NATS antenna amp. Refer to [SEC-151, "Removal and Installation"](#).  
NO >> GO TO 2.

## 2. CHECK NATS ANTENNA AMP. OUTPUT SIGNAL CIRCUIT

1. Disconnect NATS antenna amp. connector and BCM connector.
2. Check continuity between NATS antenna amp. harness connector and BCM connector.

NATS antenna amp.		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M21	1	M80	127	Yes
	3		126	

3. Check continuity between NATS antenna amp. harness connector and ground.

NATS antenna amp.		Ground	Continuity
Connector	Terminal		
M21	1		No
	3		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).  
NO >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B2555 STOP LAMP

< DTC/CIRCUIT DIAGNOSIS >

## B2555 STOP LAMP

### DTC Description

INFOID:0000000014391322

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2555	STOP LAMP (Stop lamp)	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	BCM makes a comparison between the upper voltage and lower voltage of stop lamp switch. It judges from their values to detect the malfunctioning circuit
		Diagnosis delay time	—

### POSSIBLE CAUSE

- Harness or connectors  
(Stop lamp switch circuit is open or shorted.)
- Harness or connectors  
(Stop lamp relay circuit is open or shorted.)
- Stop lamp switch
- Stop lamp relay
- Fuse
- BCM

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Depress brake pedal and wait 1 second or more.
2. Check DTC in "Self Diagnostic Result" mode of "BCM".

##### Is DTC detected?

YES >> Refer to [SEC-88, "Diagnosis Procedure \(Without LED combination lamps\)"](#) or [SEC-90, "Diagnosis Procedure \(With LED combination lamps\)"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure (Without LED combination lamps)

INFOID:0000000014391323

Regarding Wiring Diagram information, refer to [SEC-41, "Wiring Diagram"](#).

#### 1. CHECK POWER SOURCE (STOP LAMP SWITCH)

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check voltage between stop lamp switch and ground.

Stop lamp switch		Ground	Voltage (Approx.)
Connector	Terminal		Battery voltage
E38	1		

##### Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the following:

# B2555 STOP LAMP

## < DTC/CIRCUIT DIAGNOSIS >

- Harness for short or open between fuse block (J/B) and stop lamp switch
- 10A fuse (No. 10, located in fuse block [J/B])

## 2.CHECK STOP LAMP SWITCH

Check stop lamp switch. Refer to [SEC-91, "Component Inspection \(Stop Lamp Switch\)".](#)

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace stop lamp switch. Refer to [BR-21, "Exploded View".](#)

## 3.CHECK GROUND CIRCUIT (STOP LAMP RELAY)

1. Remove the stop lamp relay.
2. Check continuity between stop lamp relay connector and ground.

Stop lamp relay		Ground	Continuity
Connector	Terminal		Yes
E12	2		

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

## 4.CHECK STOP LAMP RELAY

Check stop lamp relay. Refer to [SEC-92, "Component Inspection \(Stop Lamp Relay\)".](#)

### Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace stop lamp relay.

## 5.CHECK HARNESS BETWEEN STOP LAMP RELAY AND BCM

Check continuity between stop lamp relay and BCM.

BCM		Stop lamp relay		Continuity
Connector	Terminal	Connector	Terminal	
M18	27	E12	3	

### Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace damaged parts.

## 6.CHECK HARNESS BETWEEN STOP LAMP SWITCH AND STOP LAMP RELAY

Check continuity between stop lamp relay and stop lamp switch.

Stop lamp switch		Stop lamp relay		Continuity
Connector	Terminal	Connector	Terminal	
E38	2	E12	2	

### Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace damaged parts.

## 7.CHECK POWER SOURCE (STOP LAMP RELAY)

Check voltage between stop lamp relay and ground.

Stop lamp relay		Ground	Voltage (Approx.)
Connector	Terminal (+)		Battery voltage
E12	5		

### Is the inspection result normal?

# B2555 STOP LAMP

## < DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 8.

NO >> Repair or replace damaged parts.

## 8.CONNECTOR INSPECTION

Check BCM connectors and terminals for deformation, disconnection, looseness or damage.

### Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace as necessary.

## 9.REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

## Diagnosis Procedure (With LED combination lamps)

INFOID:0000000014391324

Regarding Wiring Diagram information, refer to [SEC-41, "Wiring Diagram"](#).

## 1.CHECK STOP LAMP SWITCH INPUT SIGNAL 1

1. Turn ignition switch OFF.

2. Disconnect BCM connector.

3. Check voltage between BCM harness connector and ground.

(+) BCM		(-)	Voltage (V) (Approx.)
Connector	Terminal		
M18	25	Ground	Battery voltage

### Is the inspection normal?

YES >> GO TO 2.

NO-1 >> Check 10 A fuse [No. 10, located in the fuse block (J/B)].

NO-2 >> Check harness for open or short between BCM and fuse.

## 2.CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Disconnect stop lamp switch connector.

2. Check voltage between stop lamp switch harness connector and ground.

(+) Stop lamp switch		(-)	Voltage (V) (Approx.)
Connector	Terminal		
E38	1	Ground	Battery voltage

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness for open or short between stop lamp switch and fuse.

## 3.CHECK STOP LAMP SWITCH INPUT SIGNAL 2

1. Connect stop lamp switch connector.

2. Check voltage between BCM harness connector and ground.

# B2555 STOP LAMP

## < DTC/CIRCUIT DIAGNOSIS >

(+) BCM		(-)	Condition	Voltage (V) (Approx.)
Connector	Terminal			
M18	27	Ground	Brake pedal	Depressed
				Not depressed

Is the inspecting result normal?

YES >> GO TO 4.

NO >> GO TO 5.

## 4.REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

## 5.CHECK STOP LAMP SWITCH CIRCUIT

1. Disconnect stop lamp switch connector.
2. Check continuity between stop lamp switch harness connector and BCM harness connector.

Stop lamp switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E38	2	M18	27	Yes

3. Check continuity between stop lamp switch harness connector and ground.

Stop lamp switch		Ground	Continuity
Connector	Terminal		
E38	2		No

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

## 6.CHECK STOP LAMP SWITCH

Refer to [SEC-91, "Component Inspection \(Stop Lamp Switch\)"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace stop lamp switch. Refer to [BR-21, "Exploded View"](#).

## 7.CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

## Component Inspection (Stop Lamp Switch)

INFOID:000000014391325

### 1.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch terminals.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B2555 STOP LAMP

## < DTC/CIRCUIT DIAGNOSIS >

Stop lamp switch		Condition		Continuity
Terminals		Brake pedal	Not depressed	No
1	2		Depressed	Yes

### Is the inspection result normal?

YES >> Inspection End.


NO >> Replace stop lamp switch. Refer to [BR-21, "Exploded View"](#).

## Component Inspection (Stop Lamp Relay)

INFOID:000000014391326

### 1. CHECK STOP LAMP RELAY

1. Disconnect stop lamp relay.
2. Check continuity between stop lamp relay terminals.



Stop lamp relay		Condition	Continuity
Terminals			
3	5	12 V direct current supply between terminals 1 and 2	Yes
		No current supply	No

### Is the inspection result normal?

YES >> Inspection End.

NO >> Replace stop lamp relay.

# B2556 PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## B2556 PUSH-BUTTON IGNITION SWITCH

### DTC Description

INFOID:0000000014391327

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2556	PUSH-BTN IGN SW (Push-button ignition switch)	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	BCM detects the push-button ignition switch stuck at ON for 100 seconds or more
		Diagnosis delay time	100 seconds

### POSSIBLE CAUSE

- Harness or connectors  
(Push-button ignition switch circuit is shorted.)
- Push-button ignition switch
- BCM

### FAIL-SAFE

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Press push-button ignition switch under the following condition:
  - Brake pedal: Not depressed
2. Release push-button ignition switch and wait 100 seconds or more.
3. Check DTC in "Self Diagnostic Result" mode of "BCM".

##### Is DTC detected?

YES >> Refer to [SEC-93, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:0000000014391328

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK PUSH-BUTTON IGNITION SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check voltage between push-button ignition switch harness connector and ground.

(+)		(-)	Voltage (Approx.)
Push-button ignition switch			
Connector	Terminal		
M46	8	Ground	Battery voltage

##### Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 2.

#### 2. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT

1. Disconnect BCM connector and IPDM E/R connector.

## B2556 PUSH-BUTTON IGNITION SWITCH

### < DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between push-button ignition switch harness connector and BCM harness connector.

Push-button ignition switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M46	8	M18	1	Yes

3. Check continuity between push-button ignition switch harness connector and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M46	8		
			No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3.REPLACE BCM

Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

>> Inspection End.

### 4.CHECK PUSH-BUTTON IGNITION SWITCH GROUND CIRCUIT

Check continuity between push-button ignition switch harness connector and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M46	4		
			Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

### 5.CHECK PUSH-BUTTON IGNITION SWITCH

Refer to [SEC-94, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace push-button ignition switch. Refer to [PCS-98, "Removal and Installation"](#).

### 6.CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End

## Component Inspection

INFOID:000000014391329

### 1.CHECK PUSH-BUTTON IGNITION SWITCH

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check continuity between push-button ignition switch terminals.

Push-button ignition switch		Condition	Continuity
Terminals			
4	8	Push-button ignition switch	Pressed
			Not pressed

Is the inspection result normal?

YES >> Inspection End.

## B2556 PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO    >> Replace push-button ignition switch. Refer to [PCS-98, "Removal and Installation".](#)

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B2557 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

## B2557 VEHICLE SPEED

### DTC Description

INFOID:0000000014391330

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2557	VEHICLE SPEED (Vehicle speed)	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	BCM detects one of the following conditions for 10 seconds continuously: <ul style="list-style-type: none"><li>Vehicle speed signal from "combination meter" is 10 km/h (6.2 MPH) or more and vehicle speed signal from "ABS actuator and electric unit (control unit)" is 4 km/h (2.5 MPH) or less</li><li>Vehicle speed signal from "combination meter" is 4 km/h (2.5 MPH) or less and vehicle speed signal from "ABS actuator and electric unit (control unit)" is 10 km/h (6.2 MPH) or more</li></ul>
		Diagnosis delay time	10 seconds

### POSSIBLE CAUSE

- Harness or connectors  
(The CAN communication line is open or shorted.)
- Combination meter
- ABS actuator and electric unit (control unit)

### FAIL-SAFE

Inhibit steering lock

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK DTC PRIORITY

If DTC B2557 is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-67, "DTC Description"](#). U1010: Refer to [BCS-68, "DTC Description"](#).

NO >> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Start engine and wait 10 seconds or more.
2. Drive the vehicle at a vehicle speed of 10 km/h (6.2 MPH) or more for 10 seconds or more.
3. Check DTC in "Self Diagnostic Result" mode of "BCM".

Is DTC detected?

YES >> Refer to [SEC-96, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:0000000014391331

#### 1. CHECK DTC PRIORITY

If DTC B2557 is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-67, "DTC Description"](#). U1010: Refer to [BCS-68, "DTC Description"](#).

## B2557 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 2.

### 2.CHECK DTC OF "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)"

#### CONSULT

Check DTC in "Self Diagnostic Result" mode of "ABS".

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [BRC-55. "DTC Index"](#).

NO >> GO TO 3.

### 3.CHECK DTC OF "COMBINATION METER"

#### CONSULT

Check DTC in "Self Diagnostic Result" mode of "METER/M&A".

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-36. "DTC Index"](#).

NO >> GO TO 4.

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B2560 STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

## B2560 STARTER CONTROL RELAY

### DTC Description

INFOID:0000000014391332

Starter control relay, integrated in IPDM E/R, permits the starter relay operation when in the N or P position and the steering is locked or unlocked. It is installed in parallel with the starter relay.

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2560	STARTER CONT RELAY (Starter control relay)	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	BCM detects a discrepancy between the OFF request of starter control relay to IPDM E/R and the feedback. (The feedback is ON instead of OFF.)
		Diagnosis delay time	2 seconds

### POSSIBLE CAUSE

IPDM E/R

### FAIL-SAFE

Inhibit engine cranking

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK DTC PRIORITY

If DTC B2560 is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

##### Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-67, "DTC Description"](#). U1010: Refer to [BCS-68, "DTC Description"](#).

NO >> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Turn ignition switch ON under the following conditions and wait for at least 2 seconds:

- Selector lever is in the P or N position
- Do not depress brake pedal

2. Check "Self diagnostic result" mode.

##### Is DTC detected?

YES >> Refer to [SEC-96, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:0000000014391333

#### 1. CHECK DTC PRIORITY

If DTC B2560 is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

##### Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-67, "DTC Description"](#). U1010: Refer to [BCS-68, "DTC Description"](#).

NO >> GO TO 2.

#### 2. CHECK DTC WITH IPDM E/R

##### CONSULT

Check "Self Diagnostic Result" mode. Refer to [BCS-52, "DTC Index"](#).

## B2560 STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES    >> GO TO 3.

NO    >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R".](#)

### 3. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident".](#)

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

## B2601 SHIFT POSITION

### DTC Description

INFOID:0000000014391334

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2601 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B2601 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2601	SHIFT POSITION	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	When there is a difference between P (Park) range signal from A/T shift selector (park position switch) and P (Park) position signal from IPDM E/R (CAN)
		Diagnosis delay time	—

#### POSSIBLE CAUSE

- A/T shift selector (park position switch)
- BCM
- Harness or connector  
(The CAN communication line is open or shorted.)
- Harness or connector  
[A/T shift selector (park position switch) circuit is open or shorted.]

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

###### CONSULT

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 2 seconds or more.
3. Shift the selector lever to any position other than P (Park) and wait 2 seconds or more.
4. Select "Self Diagnostic Result" mode of "BCM".
5. Check DTC.

###### Is DTC detected?

YES >> Go to [SEC-100, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000014391335

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

##### 1. CHECK A/T SHIFT SELECTOR SWITCH FUNCTION

###### CONSULT

1. Turn ignition switch ON.
2. Select "DETE/CANCEL SW" and "DETENT SW - IPDM" in "Data Monitor" mode.
3. Check "DETE/CANCEL SW" and "DETENT SW - IPDM" indication under the following conditions:

# B2601 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

Monitor item	Condition		Indication
DETE/CANCEL SW	A/T Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON
DETENT SW - IPDM	A/T Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON

Is the inspection result normal?

YES >> Refer to [GI-47, "Intermittent Incident"](#).

NO-1 >> If "DETE/CANCEL SW" function is incorrect. GO TO 2.

NO-2 >> If "DETENT SW - IPDM" function is incorrect. GO TO 5.

## 2.CHECK A/T SHIFT SELECTOR CIRCUIT (BCM)

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between A/T shift selector (park position switch) harness connector and BCM harness connector.

A/T shift selector (park position switch)		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M68	4	M18	20	Yes

3. Check continuity between A/T shift selector (park position switch) harness connector and ground.

A/T shift selector (park position switch)		Ground	Continuity
Connector	Terminal		
M68	4		No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

## 3.CONNECTOR INSPECTION

1. Disconnect BCM.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace as necessary.

## 4.REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

## 5.CHECK A/T SHIFT SELECTOR CIRCUIT (IPDM E/R)

Check continuity between A/T shift selector (park position switch) harness connector and IPDM E/R harness connector.

A/T shift selector (park position switch)		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
M68	4	E130	64	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

## 6.CONNECTOR INSPECTION

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

## B2601 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

1. Disconnect IPDM E/R.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

#### Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace as necessary.

## 7. REPLACE IPDM E/R

1. Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R".](#)

>> Inspection End.

### Component Inspection

INFOID:000000014391336

#### 1. CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector connector.
3. Check continuity between A/T shift selector (park position switch) terminals.

A/T shift selector (park position switch)		Condition	Continuity
Terminals			
5	4	Selector lever	P (Park) position
			Other than above

#### Is the inspection result normal?

YES >> Inspection End.

NO >> Replace A/T shift selector. Refer to [TM-219, "Removal and Installation".](#)

## B2602 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

### B2602 SHIFT POSITION

#### DTC Description

INFOID:0000000014391337

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2602 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B2602 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2602	SHIFT POSITION	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	BCM detects the following status for 10 seconds: <ul style="list-style-type: none"><li>• Selector lever is in the P (Park) position</li><li>• Vehicle speed is 4 km/h (2.5 MPH) or more</li><li>• Ignition switch is in the ON position</li></ul>
		Diagnosis delay time	—

#### POSSIBLE CAUSE

- Harness or connectors  
(CAN communication line is open or shorted.)
- Harness or connectors  
[A/T shift selector (park position switch) circuit is open or shorted.]
- A/T shift selector (park position switch)
- Combination meter
- BCM

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

SEC

###### CONSULT

1. Start engine.
2. Drive vehicle at a speed of 4 km/h (2.5 MPH) or more for 10 seconds or more.
3. Select "Self Diagnostic Result" mode of "BCM".
4. Check DTC.

###### Is DTC detected?

YES >> Go to [SEC-103, "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000014391338

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

##### 1. CHECK A/T SHIFT SELECTOR SWITCH FUNCTION

###### CONSULT

1. Turn ignition switch ON.
2. Select "DETE/CANCEL SW" and "VEH SPEED 1" in "Data Monitor" mode.
3. Check "DETE/CANCEL SW" and "VEH SPEED 1" indication under the following conditions:

## B2602 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

Monitor item	Condition		Indication
DETE/CANCEL SW	A/T Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON
VEH SPEED 1	Vehicle not moving		0
	Vehicle moving		Varies

#### Is the inspection result normal?

YES >> Refer to [GI-47, "Intermittent Incident"](#).

NO-1 >> If "DETE/CANCEL SW" is incorrect. GO TO 4.

NO-2 >> If "VEH SPEED 1" is incorrect. GO TO 2.

### 2.CHECK DTC OF COMBINATION METER

#### CONSULT

Check DTC in "Self Diagnostic Result" mode of "METER/M&A".

#### Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-36, "DTC Index"](#).

NO >> GO TO 3.

### 3.CHECK DTC OF ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

#### CONSULT

Check DTC in "Self Diagnostic Result" mode of "ABS".

#### Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [BCR-55, "DTC Index"](#).

NO >> GO TO 6.

### 4.CHECK A/T SHIFT SELECTOR CIRCUIT

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between A/T shift selector (park position switch) harness connector and BCM harness connector.

A/T shift selector (park position switch)		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M68	4	M18	20	Yes

3. Check continuity between A/T shift selector (park position switch) harness connector and ground.

A/T shift selector (park position switch)		Ground	Continuity
Connector	Terminal		
M68	4		No

#### Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

### 5.CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH)

Refer to [SEC-105, "Component Inspection"](#).

#### Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace A/T shift selector. Refer to [TM-219, "Removal and Installation"](#).

### 6.CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

## B2602 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

### Component Inspection

INFOID:000000014391339

#### 1. CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector connector.
3. Check continuity between A/T shift selector (park position switch) terminals.

A/T shift selector (park position switch)		Condition	Continuity
Terminals			
5	4	Selector lever	P (Park) position
			Other than above

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace A/T shift selector. Refer to [TM-219, "Removal and Installation".](#)

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

## B2603 SHIFT POSITION

### DTC Description

INFOID:0000000014391340

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2603 is displayed with DTC B2601, first perform the trouble diagnosis for DTC B2601. Refer to [SEC-100, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2603	SHIFT POSI STATUS	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	BCM detects the following status when ignition switch is in the ON position: <ul style="list-style-type: none"><li>• P (Park) position signal from TCM: approx. 0V</li><li>• A/T shift selector (park position switch) signal: approx. 0V</li></ul>
		Diagnosis delay time	—

#### POSSIBLE CAUSE

- Harness or connector  
[A/T shift selector (park position switch) circuit is open or shorted.]
- Harness or connectors  
(TCM circuit is open or shorted.)
- A/T shift selector (park position switch)
- A/T assembly (TCM)
- BCM

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE 1

###### ① CONSULT

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 1 second or more.
3. Select "Self Diagnostic Result" mode of "BCM".
4. Check DTC.

###### Is DTC detected?

YES >> Go to [SEC-106, "Diagnosis Procedure"](#).

NO >> GO TO 2.

##### 2. PERFORM DTC CONFIRMATION PROCEDURE 2

###### ② CONSULT

1. Shift the selector lever to any position other than P (Park) and wait 1 second or more.
2. Select "Self Diagnostic Result" mode of "BCM".
3. Check DTC.

###### Is DTC detected?

YES >> Go to [SEC-106, "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000014391341

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

# B2603 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

## 1. CHECK A/T SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "DETE/CANCEL SW" and "SFT PN/N SW" in "Data Monitor" mode.
3. Check "DETE/CANCEL SW" and "SFT PN/N SW" indication under the following conditions:

Monitor item		Condition	Indication
DETE/CANCEL SW	A/T Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON
SFT PN/N SW	A/T Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON

Is the inspection result normal?

YES >> Refer to [GI-47, "Intermittent Incident"](#).

NO-1 >> If "DETE/CANCEL SW" is incorrect. GO TO 6.

NO-2 >> If "SFT PN/N SW" is incorrect. GO TO 2.

## 2. CHECK BCM INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

(+) BCM		(-)	Condition		Voltage (Approx.)
Connector	Terminal		Selector lever		
M18	39	Ground		P or N position	Battery voltage
				Other than above	0

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

## 3. CHECK BCM INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Disconnect transmission range switch connector.
4. Check continuity between transmission range switch harness connector and BCM harness connector.

Transmission range switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
F212	8	M18	39	Yes

5. Check continuity between transmission range switch harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F212	8		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

## 4. REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

# B2603 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

## 5. CHECK DTC OF TCM

### CONSULT

Check DTC in "Self Diagnostic Result" mode of "TCM".

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [TM-69, "DTC Index"](#).

NO >> Perform the trouble diagnosis related to the TCM power and ground circuits. Refer to [TM-209, "Diagnosis Procedure"](#).

## 6. CHECK A/T SHIFT SELECTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect A/T shift selector (park position switch) connector.
3. Check voltage between A/T shift selector (park position switch) harness connector and ground.

(+) A/T shift selector (park position switch)		(-)	Voltage (Approx.)
Connector	Terminal		
M68	5	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace harness.

## 7. CHECK A/T SHIFT SELECTOR POWER SUPPLY CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between A/T shift selector (park position switch) harness connector and BCM harness connector.

A/T shift selector (park position switch)		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M68	5	M19	69	Yes

3. Check continuity between A/T shift selector (park position switch) harness connector and ground.

A/T shift selector (park position switch)		Ground	Continuity
Connector	Terminal		
M68	5		No

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

## 8. CHECK A/T SHIFT SELECTOR CIRCUIT

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between A/T shift selector (park position switch) harness connector and BCM harness connector.

A/T shift selector (park position switch)		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M68	4	M18	20	Yes

3. Check continuity between A/T shift selector (park position switch) harness connector and ground.

A/T shift selector (park position switch)		Ground	Continuity
Connector	Terminal		
M68	4		No

Is the inspection result normal?

## B2603 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 9.

NO >> Repair or replace harness.

A

### 9. CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH)

B

Refer to [TM-220, "Inspection and Adjustment"](#).

Is the inspection result normal?

C

YES >> GO TO 10.

NO >> Replace A/T shift selector. Refer to [TM-219, "Removal and Installation"](#).

D

### 10. REPLACE BCM

E

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

F

>> Inspection End.

G

### Component Inspection

INFOID:000000014391342

H

### 1. CHECK A/T SHIFT SELECTOR (PARK POSITION SWITCH)

I

1. Turn ignition switch OFF.

J

2. Disconnect A/T shift selector connector.

K

3. Check continuity between A/T shift selector (park position switch) terminals.

L

A/T shift selector (park position switch)		Condition	Continuity
Terminals			
5	4	Selector lever	P (Park) position
			Other than above

M

Is the inspection result normal?

N

YES >> Inspection End.

O

NO >> Replace A/T shift selector. Refer to [TM-219, "Removal and Installation"](#).

P

SEC

L

M

N

O

P

# B2604 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

## B2604 SHIFT POSITION

### DTC Description

INFOID:0000000014391343

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2604 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B2604 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2604	PNP/CLUTCH SW	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	The following states are detected for 5 seconds while ignition switch is ON: <ul style="list-style-type: none"><li>• P/N position signal is sent from TCM but shift position signal input (CAN) from TCM is other than P (Park) and N (Neutral)</li><li>• P/N position signal is not sent from TCM but shift position signal input (CAN) from TCM is P (Park) or N (Neutral)</li></ul>
		Diagnosis delay time	—

#### POSSIBLE CAUSE

- Harness or connectors  
(CAN communication line is open or shorted.)
- BCM
- TCM
- Harness or connector  
(TCM circuit is open or shorted.)

#### FAIL-SAFE

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

###### CONSULT

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 5 seconds or more.
3. Shift the selector lever to the N (Neutral) position and wait 5 seconds or more.
4. Shift the selector lever to any position other than P (Park) and N (Neutral) and wait 5 seconds or more.
5. Select "Self Diagnostic Result" mode of "BCM".
6. Check DTC.

###### Is DTC detected?

YES >> Go to [SEC-110, "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000014391344

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

##### 1. CHECK A/T SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "SFT P -MET", "SFT N -MET" and "SFT PN/N SW" in "Data Monitor" mode.
3. Check "SFT P -MET", "SFT N -MET" and "SFT PN/N SW" indication under the following conditions:

## B2604 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

Monitor item	Condition	Indication
SFT P -MET	A/T Shift selector	Selector lever is in any position except the P (Park) position
		Selector lever is in the P (Park) position
SFT N -MET	A/T Shift selector	Selector lever is in any position except the N (Neutral) position
		Selector lever is in the N (Neutral) position
SFT PN/N SW	A/T Shift selector	Selector lever is in and position except the P (Park) or N (Neutral) position
		Selector lever is in the P (Park) or N (Neutral) position

Is the inspection result normal?

YES >> Refer to [GI-47, "Intermittent Incident"](#).

NO-1 >> If "SFT N -MET" or "SFT P -MET" is incorrect. GO TO 7.

NO-2 >> If "SFT PN/N SW" is incorrect. GO TO 2.

### 2.CHECK DTC OF TCM

#### CONSULT

Check DTC in "Self Diagnostic Result" mode of "TCM".

Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [TM-69, "DTC Index"](#).

NO >> GO TO 3.

### 3.CHECK BCM INPUT SIGNAL

1. Turn ignition switch ON.

2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
BCM				Connector	Terminal
M18	39	Ground	Selector lever	P (Park) or N (Neutral) position	Battery voltage
				Other than above	0

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

### 4.REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

### 5.CHECK BCM INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.

2. Disconnect transmission range switch connector.

3. Disconnect BCM connector.

4. Check continuity between transmission range switch harness connector and BCM harness connector.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

## B2604 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

Transmission range switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
F212	8	M18	39	Yes

5. Check continuity between transmission range switch harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F212	8		No

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

## 6. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

## 7. CHECK TRANSMISSION RANGE SWITCH FUNCTION (METER)

### CONSULT

1. Turn ignition switch ON.
2. Select "SHIFT IND" in "Data Monitor" mode of "METER".
3. Check "SHIFT IND" indication under the following conditions:

Monitor item	Condition		Indication
SHIFT IND	A/T Shift selector	P (Park) position	P
		N (Neutral) position	N

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [SEC-109, "Component Inspection"](#).

## B2605 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

### B2605 SHIFT POSITION

#### DTC Description

INFOID:0000000014391345

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2605 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B2605 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2605	PNP/CLUTCH SW	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	When ignition switch is ON, P/N position signal input from TCM and P/N position signal (CAN) input from IPDM E/R do not match
		Diagnosis delay time	—

#### POSSIBLE CAUSE

- IPDM E/R
- BCM
- Harness or connectors  
(TCM circuit is open or shorted.)
- Harness or connector  
(The CAN communication line is open or shorted.)

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

###### ④ CONSULT

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 1 second or more.
3. Shift the selector lever to the N (Neutral) position and wait 1 second or more.
4. Shift the selector lever to any position other than P (Park) and N (Neutral) and wait 1 second or more.
5. Select "Self Diagnostic Result" mode of "BCM".
6. Check DTC.

SEC

###### Is DTC detected?

L

M

N

YES >> Go to [SEC-113, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000014391346

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

O

##### 1. CHECK A/T SHIFT SELECTOR SWITCH FUNCTION

P

###### ④ CONSULT

1. Turn ignition switch ON.
2. Select "SFT PN-IPDM" and "SFT PN/N SW" in "Data Monitor" mode.
3. Check "SFT PN-IPDM" and "SFT PN/N SW" indication under the following conditions:

## B2605 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

Monitor item	Condition		Indication
SFT PN-IPDM	A/T Shift selector	Any position other than P (Park) or N (Neutral) position	OFF
		P (Park) or N (Neutral) position	ON
SFT PN/N SW	A/T Shift selector	Any position other than P (Park) or N (Neutral) position	OFF
		P (Park) or N (Neutral) position	ON

Is the inspection result normal?

YES >> Refer to [GI-47, "Intermittent Incident"](#).

NO-1 >> If "SFT PN-IPDM" is incorrect. GO TO 2.

NO-2 >> If "SFT PN/N SW" is incorrect. GO TO 5.

### 2. CHECK IPDM E/R INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Turn ignition switch ON.
4. Check voltage between IPDM E/R harness connector and ground.

(+) IPDM E/R		(-)	Condition		Voltage (Approx.)
Connector	Terminal		Selector lever		
E119	4	Ground	P (Park) or N (Neutral) position	Battery voltage	0
			Other than above		

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> GO TO 3.

### 3. CHECK IPDM E/R INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between IPDM E/R harness connector and transmission range switch harness connector.

IPDM E/R		Transmission range switch		Continuity
Connector	Terminal	Connector	Terminal	
E119	4	F212	8	Yes

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E119	4		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 4. REPLACE IPDM E/R

1. Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

>> Inspection End.

### 5. CHECK BCM INPUT SIGNAL

## B2605 SHIFT POSITION

### < DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

(+) BCM		(-)	Condition		Voltage (Approx.)
Connector	Terminal		Selector lever	P (Park) or N (Neutral) position	
M18	39	Ground	Selector lever	P (Park) or N (Neutral) position	Battery voltage
				Other than above	0

Is the inspection result normal?

YES >> GO TO 6.  
NO >> GO TO 7.

### 6.REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

### 7.CHECK BCM INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect transmission range switch connector.
3. Disconnect BCM connector.
4. Check continuity between transmission range switch harness connector and BCM harness connector.

Transmission range switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
F212	8	M18	39	Yes

5. Check continuity between transmission range switch harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F212	8		No

Is the inspection result normal?

YES >> GO TO 8.  
NO >> Repair or replace harness.

### 8.CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

## B2608 STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

### B2608 STARTER RELAY

#### DTC Description

INFOID:0000000014391347

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2608 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B2608 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2608	STARTER RELAY	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	BCM outputs starter motor relay OFF signal but BCM receives starter motor relay ON signal from IPDM E/R (CAN)
		Diagnosis delay time	—

#### POSSIBLE CAUSE

- IPDM E/R
- Harness or connectors  
(Starter relay circuit is open or shorted.)
- Harness or connector  
(The CAN communication line is open or shorted.)

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

###### CONSULT

1. Press push-button ignition switch under the following conditions to start engine:
  - Shift selector lever: In the P (Park) position
  - Brake pedal: Depressed
2. Wait 1 second after engine started.
3. Select "Self Diagnostic Result" mode of "BCM".
4. Check DTC.

###### Is DTC detected?

YES >> Go to [SEC-116, "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000014391348

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

##### 1. CHECK DTC OF IPDM E/R

###### CONSULT

Check DTC in "Self Diagnostic Result" mode of "IPDM E/R".

###### Is DTC detected?

YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [PCS-23, "DTC Index"](#).  
NO >> GO TO 2.

##### 2. CHECK BCM POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.

## B2608 STARTER RELAY

### < DTC/CIRCUIT DIAGNOSIS >

2. Check voltage between BCM harness connector and ground.

(+) BCM		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
M19	62	Ground	Selector lever	N (Neutral) or P (Park) position
				Other than above

Is the inspection result normal?

YES >> GO TO 4.  
NO >> GO TO 3.

### 3. CHECK STARTER RELAY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Disconnect BCM connector.
4. Check continuity between IPDM E/R harness connector and BCM harness connector.

IPDM E/R		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E122	44	M19	62	Yes

5. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E122	44		No

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).  
NO >> Repair or replace harness.

### 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

SEC

>> Inspection End.

L

M

N

O

P

# B260F ENGINE STATUS

< DTC/CIRCUIT DIAGNOSIS >

## B260F ENGINE STATUS

### DTC Description

INFOID:0000000014391349

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B260F	ENG STATE SIG LOST	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	BCM has not yet received the engine status signal from ECM when ignition switch is in the ON position.
		Diagnosis delay time	—

### POSSIBLE CAUSE

- Harness or connectors  
(The CAN communication line is open or shorted.)
- ECM

### FAIL-SAFE

Inhibit engine cranking

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK DTC PRIORITY

If DTC B260F is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

##### Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-67, "DTC Description"](#). U1010: Refer to [BCS-68, "DTC Description"](#).

NO >> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait 2 seconds or more.
2. Check DTC in "Self Diagnostic Result" mode of "BCM" using CONSULT.

##### Is DTC detected?

YES >> Refer to [SEC-118, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:0000000014391350

#### 1. CHECK DTC PRIORITY

If DTC B260F is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

##### Is applicable DTC detected?

YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-67, "DTC Description"](#). U1010: Refer to [BCS-68, "DTC Description"](#).

NO >> GO TO 2.

#### 2. INSPECTION START

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" mode of "BCM" using CONSULT.
3. Touch "ERASE".
4. Perform DTC CONFIRMATION PROCEDURE for DTC B260F. Refer to [SEC-118, "DTC Description"](#).

##### Is DTC detected?

YES >> GO TO 3.

NO >> Inspection End.

## B260F ENGINE STATUS

< DTC/CIRCUIT DIAGNOSIS >

### 3.REPLACE ECM

Replace ECM. Refer [EC-1993, "Removal and Installation".](#)

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B261B REMOTE ENGINE START

< DTC/CIRCUIT DIAGNOSIS >

## B261B REMOTE ENGINE START

### DTC Description

INFOID:0000000014391351

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B261B is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B261B is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B261B	BCM	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	The BCM has requested ignition OFF but ECM keeps the engine running for more than 10 seconds after the OFF request was made
		Diagnosis delay time	—

#### POSSIBLE CAUSE

- ECM

#### FAIL-SAFE

### Diagnosis Procedure

INFOID:0000000014391352

#### 1. CHECK ECM IGNITION, POWER AND GROUND CIRCUITS

Check ECM ignition power and ground circuits.

Is the inspection result normal?

YES >> Replace ECM. Refer to [EC-1993, "Removal and Installation"](#). GO TO 2.

NO >> Repair or replace harness or connectors.

#### 2. INSPECTION

##### CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" mode.
3. Touch "ERASE".
4. Perform vehicle remote start operation.

Does DTC B261B return?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Inspection End.

< DTC/CIRCUIT DIAGNOSIS >

## B261E VEHICLE TYPE

### DTC Description

INFOID:000000014391353

There are two types of vehicles.

- HEV
- Conventional

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B261E is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B261E is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B261E	VEHICLE TYPE	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	Difference of BCM configuration
		Diagnosis delay time	—

### POSSIBLE CAUSE

- BCM mis-configuration
- Wrong ECM installed

### FAIL-SAFE

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Turn ignition switch ON under the following conditions:
  - Shift selector lever is in the P (Park) or N (Neutral) position.
  - Do not depress brake pedal.
2. Select "Self Diagnostic Result" mode.
3. Check DTC.

##### Is DTC detected?

YES >> GO TO [SEC-121, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000014391354

#### 1. INSPECTION START

##### CONSULT

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure. Refer to [SEC-121, "DTC Description"](#).

##### Is the 1st trip DTC B261E displayed again?

YES >> GO TO 2.

NO >> Inspection End.

#### 2. PERFORM BCM CONFIGURATION.

Perform the BCM configuration. Refer to [BCS-63, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 3.

## B261E VEHICLE TYPE

< DTC/CIRCUIT DIAGNOSIS >

---

### 3. INSPECTION START

---

#### ④ CONSULT

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure.  
Refer to [SEC-121, "DTC Description"](#).

Is the 1st trip DTC B261E displayed again?

YES    >> GO TO 4.  
NO      >> Inspection End.

---

### 4. CONFIRM ECM PART NUMBER.

---

Confirm the part number of the installed ECM is correct.

Is the ECM part number correct?

YES    >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).  
NO      >> Replace ECM. Refer to [EC-1993, "Removal and Installation"](#).

# B26F3 STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

## B26F3 STARTER CONTROL RELAY

### DTC Description

INFOID:000000014391355

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B26F3 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B26F3 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B26F3	START CONT RLY ON	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	BCM requests IPDM E/R to turn starter control relay OFF, but BCM cannot receive starter control relay OFF state signal from IPDM E/R (CAN)
		Diagnosis delay time	—

#### POSSIBLE CAUSE

- IPDM E/R
- Harness or connector  
(The CAN communication line is open or shorted.)

#### FAIL-SAFE

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

###### ④ CONSULT

1. Press push-button ignition switch under the following conditions to start engine:
  - Shift selector lever: In the P (Park) position.
  - Brake pedal: Depressed
2. Wait 2 seconds after engine started.
3. Select "Self Diagnostic Result" mode of "BCM".
4. Check DTC.

###### Is DTC detected?

YES >> GO TO [SEC-123, "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:000000014391356

##### 1. CHECK DTC OF IPDM E/R

###### ④ CONSULT

Check DTC in "Self Diagnostic Result" mode of "IPDM E/R".

###### Is DTC detected?

YES >> Perform the diagnosis procedure related to the detected DTC. Refer to [PCS-23, "DTC Index"](#).  
NO >> GO TO 2.

##### 2. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

# B26F4 STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

## B26F4 STARTER CONTROL RELAY

### DTC Description

INFOID:0000000014391357

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B26F4 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B26F4 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B26F4	START CONT RELAY OFF	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	BCM requests IPDM E/R to turn starter control relay ON, but BCM cannot receive starter control relay ON state signal from IPDM E/R
		Diagnosis delay time	—

#### POSSIBLE CAUSE

- IPDM E/R
- Harness or connector  
(The CAN communication line is open or shorted.)

#### FAIL-SAFE

DTC CONFIRMATION PROCEDURE	
<b>1. PERFORM DTC CONFIRMATION PROCEDURE</b>	
<b>Ⓐ CONSULT</b>	
1.	Press push-button ignition switch under the following conditions to start engine, and wait 1 second or more: - Shift selector lever: In the P (Park) position - Brake pedal: Depressed
2.	Select "Self Diagnostic Result" mode of "BCM".
3.	Check DTC.

##### Is DTC detected?

YES >> GO TO [SEC-124, "Diagnosis Procedure"](#).

NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000014391358

##### 1. CHECK DTC OF IPDM E/R

###### Ⓐ CONSULT

Check DTC in "Self Diagnostic Result" mode of "IPDM E/R".

##### Is DTC detected?

YES >> Perform the diagnosis procedure related to the detected DTC. Refer to [PCS-23, "DTC Index"](#).

NO >> GO TO 2.

##### 2. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

# B26FC KEY REGISTRATION

< DTC/CIRCUIT DIAGNOSIS >

## B26FC KEY REGISTRATION

### DTC Description

INFOID:000000014391359

### DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B26FC	KEY REGISTRATION	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	Intelligent Key that does not match the vehicle is registered
		Diagnosis delay time	—

### POSSIBLE CAUSE

- Improper registration operation
- Intelligent Key
- BCM

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Perform initialization of BCM and reregistration of all Intelligent Keys.
2. Select "Self Diagnostic Result" mode of "BCM".
3. Check DTC.

##### Is DTC detected?

YES >> Go to [SEC-125, "Diagnosis Procedure"](#)  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000014391360

#### 1. REPLACE INTELLIGENT KEY

##### CONSULT

1. Prepare Intelligent Key that matches the vehicle.
2. Perform initialization of BCM and registration of Intelligent Key using CONSULT.
3. Select "Self Diagnostic Result" mode of "BCM".
4. Check DTC.

##### Is DTC detected?

YES >> GO TO 2.  
NO >> Inspection End.

#### 2. REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys. For initialization and registration of Intelligent Keys, refer to CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

**B26F7 BCM****DTC Description**

INFOID:0000000014391361

**DTC DETECTION LOGIC**

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B26F7	BCM	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	Inside key antenna output circuit in BCM is malfunctioning
		Diagnosis delay time	—

**POSSIBLE CAUSE**

- BCM

**FAIL-SAFE****DTC CONFIRMATION PROCEDURE****1. PERFORM DTC CONFIRMATION PROCEDURE****④ CONSULT**

1. Press door request switch.
2. Turn ignition switch ON.
3. Select "Self Diagnostic Result" mode of "BCM".
4. Check DTC.

**Is DTC detected?**YES >> GO TO [SEC-126, "Diagnosis Procedure"](#).

NO &gt;&gt; Inspection End.

**Diagnosis Procedure**

INFOID:0000000014391362

**1. INSPECTION START****④ CONSULT**

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" mode of "BCM".
3. Touch "ERASE".
4. Perform DTC CONFIRMATION PROCEDURE for DTC B26F7. Refer to [SEC-126, "DTC Description"](#).

**Is DTC detected?**

YES &gt;&gt; GO TO 2.

NO &gt;&gt; Inspection End.

**2. REPLACE BCM**1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

&gt;&gt; Inspection End.

# B210B STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

## B210B STARTER CONTROL RELAY

### DTC Description

INFOID:0000000014391363

Starter control relay, integrated in IPDM E/R, permits the starter relay operation when in N (Neutral) or P (Park) position. It is installed in parallel with the starter relay.

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B210B is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B210B is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B210B	START CONT RLY ON	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	IPDM E/R detects that the relay is stuck at ON position even if the following conditions are met for about 1 second: <ul style="list-style-type: none"><li>• Starter control relay ON/OFF signal from BCM</li><li>• Transmission range switch input signal</li></ul>
		Diagnosis delay time	—

### POSSIBLE CAUSE

- IPDM E/R
- Harness or connector

### FAIL-SAFE

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### ④ CONSULT

1. Turn the power supply position to start under the following conditions and wait for at least 1 second:
  - A/T selector lever is in the P (Park) or N (Neutral) position.
  - Depress the brake pedal
2. Check "Self Diagnostic Result" mode.

SEC

##### Is DTC detected?

L

YES >> Refer to [SEC-127, "Diagnosis Procedure"](#).

M

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000014391364

#### 1. INSPECTION START

##### ④ CONSULT

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode.
3. Touch "ERASE".
4. **Perform DTC Confirmation Procedure.**  
See [PCS-23, "DTC Index"](#).

N

##### Is the DTC B210B displayed again?

O

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

P

NO >> Inspection End.

# B210C STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

## B210C STARTER CONTROL RELAY

### DTC Description

INFOID:0000000014391365

Starter control relay, integrated in IPDM E/R, permits the starter relay operation when in N (Neutral) or P (Park) position. It is installed in parallel with the starter relay.

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B210C is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B210C is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B210C	START CONT RLY OFF	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	IPDM E/R detects that the relay is stuck at OFF position even if the following conditions are met for about 1 second: <ul style="list-style-type: none"><li>• Starter control relay ON/OFF signal from BCM</li><li>• Transmission range switch input signal</li></ul>
		Diagnosis delay time	—

### POSSIBLE CAUSE

- IPDM E/R
- Harness or connector

### FAIL-SAFE

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### Ⓐ CONSULT

1. Turn the power supply position to start under the following conditions and wait for at least 1 second:
  - A/T selector lever is in the P (Park) or N (Neutral) position.
  - Depress the brake pedal
2. Check "Self Diagnostic Result" mode.

##### Is DTC detected?

YES >> Refer to [SEC-128, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000014391366

#### 1. INSPECTION START

##### Ⓐ CONSULT

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode.
3. Touch "ERASE".
4. **Perform DTC Confirmation Procedure.**  
Refer to [PCS-23, "DTC Index"](#).

##### Is the DTC B210C displayed again?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> Inspection End.

# B210D STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

## B210D STARTER RELAY

### DTC Description

INFOID:0000000014391367

Located in IPDM E/R, the starter relay runs the starter motor. The starter relay is turned ON by the BCM when the ignition switch is in START position. IPDM E/R transmits the starter relay ON signal to BCM via CAN communication.

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B210D is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B210D is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B210D	STARTER RELAY ON	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	IPDM E/R terminal 20
		Threshold	IPDM E/R detects that the relay is stuck at ON position even if the following conditions are met for about 1 second: <ul style="list-style-type: none"><li>• Starter control relay ON/OFF signal from BCM</li><li>• Transmission range switch input</li></ul>
		Diagnosis delay time	—

### POSSIBLE CAUSE

- IPDM E/R
- Harness or connector

### FAIL-SAFE

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Ignition switch ON under the following conditions and wait for at least 1 second:
  - A/T selector lever is in the P (Park) or N (Neutral) position
  - Do not depress the brake pedal
2. Select "Self Diagnostic Result" mode.
3. Check DTC.

SEC

##### Is DTC detected?

L

YES >> Refer to [SEC-129, "Diagnosis Procedure"](#).

M

NO >> Inspection End.

N

### Diagnosis Procedure

INFOID:0000000014391368

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

O

#### 1. CHECK STARTER RELAY POWER SUPPLY CIRCUIT

P

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check voltage between IPDM E/R harness connector and ground.

## B210D STARTER RELAY

### < DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E120	20		Battery voltage

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> Check harness for open or short between IPDM E/R and battery.

< DTC/CIRCUIT DIAGNOSIS >

## B210E STARTER RELAY

### DTC Description

INFOID:0000000014391369

Located in IPDM E/R, it runs the starter motor. The starter relay is turned ON by the BCM when the ignition switch is in START position. IPDM E/R transmits the starter relay ON signal to BCM via CAN communication.

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B210E is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B210E is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B210E	STARTER RELAY OFF	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	IPDM E/R detects that the relay is stuck at ON position even if the following conditions are met for about 1 second: <ul style="list-style-type: none"><li>• Starter control relay ON/OFF signal from BCM</li><li>• Transmission range switch input</li></ul>
		Diagnosis delay time	—

### POSSIBLE CAUSE

- IPDM E/R
- Harness or connector

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Turn ignition switch ON under the following conditions and wait for at least 1 second:
  - A/T selector lever is in the P (Park) or N (Neutral) position.
  - Do not depress the brake pedal.
2. Select "Self Diagnostic Result" mode.
3. Check DTC.

SEC

##### Is DTC detected?

YES >> Refer to [SEC-131, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000014391370

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK STARTER RELAY OUTPUT SIGNAL A/T MODELS

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector.
3. Check voltage between BCM harness connector ground.

L

M

N

O

P

## B210E STARTER RELAY

### < DTC/CIRCUIT DIAGNOSIS >

BCM connector		Ground	Condition			Voltage (Approx.)
Connector	Terminal		Ignition switch	Brake pedal	A/T selector lever	
M19	62	Ground	ON	Depressed	P (Park) or N (Neutral)	Battery voltage
					Other than above	0

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

### 2. CHECK STARTER RELAY OUTPUT SIGNAL CIRCUIT

1. Disconnect IPDM E/R harness connector.
2. Check continuity between IPDM E/R harness connector and BCM harness connector.

IPDM E/R		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E122	44	M19	62	Yes

3. Check continuity between BCM harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E122	44	Ground	No

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> Repair harness connector.

### 3. CHECK STARTER RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check voltage between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E122	44	Ground	Battery voltage

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> Check harness for open or short between IPDM E/R and battery.

# B210F TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## B210F TRANSMISSION RANGE SWITCH

### DTC Description

INFOID:000000014391371

IPDM E/R confirms the shift position with the following signals:

- Transmission range switch
- Shift position signal from BCM (CAN)

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B210F is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B210F is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B210F	TRANSMISSION RANGE SWITCH	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	—
		Threshold	IPDM E/R detects a mismatch between the signals below for 1 second or more: <ul style="list-style-type: none"><li>• Transmission range switch input signal</li><li>• Shift position signal from BCM (CAN)</li></ul>
		Diagnosis delay time	—

### FAIL-SAFE

### POSSIBLE CAUSE

- Transmission range switch
- Harness or connector
  - Transmission range switch circuit is open or shorted

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Turn ignition switch ON under the following conditions and wait for at least 1 second:
  - A/T selector lever is in the P (Park) or N (Neutral) position
  - Do not depress the brake pedal
2. Select "Self Diagnostic Result" mode.
3. Check DTC.

##### Is DTC detected?

SEC

YES >> Refer to [SEC-133, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000014391372

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK DTC WITH BCM

Refer to [BCS-52, "DTC Index"](#).

##### Is the inspection result normal?

YES >> GO TO 2.  
NO >> Repair or replace malfunctioning parts.

#### 2. CHECK TRANSMISSION RANGE SWITCH INPUT SIGNAL

## B210F TRANSMISSION RANGE SWITCH

### < DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Turn ignition switch ON.
4. Check voltage between IPDM E/R harness connector and ground under following condition:

IPDM E/R		Ground	Condition		Voltage (Approx.)
Connector	Terminal		A/T selector lever	P (Park) or N (Neutral)	
E119	4	Ground	A/T selector lever	P (Park) or N (Neutral)	Battery voltage
				Other than above	0

#### Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).  
NO >> GO TO 3.

### 3. CHECK TRANSMISSION RANGE SWITCH CIRCUIT FOR CONTINUITY

1. Turn ignition switch OFF.
2. Check continuity between IPDM E/R harness connector.

IPDM E/R		Condition	Continuity
Connector	Terminals		
E119	13	Transmission range switch	P or N
	4		Other

#### Is the inspection result normal?

YES >> GO TO 4.  
NO >> GO TO 5.

### 4. CHECK TRANSMISSION RANGE SWITCH CIRCUIT FOR SHORT

Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E119	13	Ground	No
	4		

#### Is the inspection result normal?

YES >> Replace the IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).  
NO >> Repair or replace harness.

### 5. CHECK TRANSMISSION RANGE SWITCH INPUT SIGNAL CIRCUIT

1. Disconnect transmission range switch harness connector.
2. Check continuity between transmission range switch and IPDM E/R harness connectors.

Transmission range switch		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F212	9	E119	13	Yes
	8		4	

3. Check continuity between transmission range switch harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F212	9	Ground	No
	8		

#### Is the inspection result normal?

## B210F TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 6.

NO >> Repair harness or connector.

### 6. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B2110 TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## B2110 TRANSMISSION RANGE SWITCH

### DTC Description

INFOID:0000000014391373

IPDM E/R confirms the shift position with the following signals:

- Transmission range switch
- Shift position signal from BCM (CAN)

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2110 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-67, "DTC Description"](#).
- If DTC B2110 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-68, "DTC Description"](#).

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC Detection Condition	
B2110	TRANSMISSION RANGE SWITCH	Diagnosis condition	When the ignition switch is ON.
		Signal (terminal)	IPDM E/R terminals 4 and 13
		Threshold	IPDM E/R detects mismatch between the signal below for 1 second or more: <ul style="list-style-type: none"><li>• Transmission range switch input signal</li></ul>
		Diagnosis delay time	—

### POSSIBLE CAUSE

- Transmission range switch
- Transmission range switch circuit is open or shorted.
- Harness or connector

### FAIL-SAFE

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

##### CONSULT

1. Turn the ignition switch ON under the following conditions and wait for at least 1 second:
  - A/T selector lever is in the P (Park) or N (Neutral) position.
  - Do not depress the brake pedal.
2. Select "Self Diagnostic Result" mode.
3. Check DTC.

##### Is DTC detected?

YES >> Refer to [SEC-136, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000014391374

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK DTC WITH BCM

Refer to [BCS-52, "DTC Index"](#).

##### Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

#### 2. CHECK TRANSMISSION RANGE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.

# B2110 TRANSMISSION RANGE SWITCH

## < DTC/CIRCUIT DIAGNOSIS >

2. Disconnect IPDM E/R harness connector.
3. Turn ignition switch ON.
4. Check voltage between IPDM E/R harness connector and ground under following condition:

IPDM E/R		Ground	Condition		Voltage (Approx.)
Connector	Terminal		A/T selector lever	P (Park) or N (Neutral)	
E119	4	Ground	A/T selector lever	P (Park) or N (Neutral)	Battery voltage
				Other than above	0

### Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> GO TO 3.

## 3.CHECK TRANSMISSION RANGE SWITCH CIRCUIT FOR CONTINUITY

1. Turn ignition switch OFF.
2. Check continuity between IPDM E/R harness connector.

IPDM E/R		Condition	Continuity
Connector	Terminals		
E119	13	Transmission range switch	P or N
	4		Other

### Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

## 4.CHECK TRANSMISSION RANGE SWITCH CIRCUIT FOR SHORT

Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E119	13	Ground	No
	4		

### Is the inspection result normal?

YES >> Replace the IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace harness.

## 5.CHECK TRANSMISSION RANGE SWITCH INPUT SIGNAL CIRCUIT

1. Disconnect transmission range switch harness connector.
2. Check continuity between transmission range switch and IPDM E/R harness connectors.

Transmission range switch		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F212	9	E119	13	Yes
	8		4	

3. Check continuity between transmission range switch harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F212	9	Ground	No
	8		

### Is the inspection result normal?

## B2110 TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 6.

NO >> Repair harness or connector.

### 6. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident".](#)

>> Inspection End.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT BCM

### BCM : Diagnosis Procedure

INFOID:000000014664561

Regarding Wiring Diagram information, refer to [BCS-54, "Wiring Diagram"](#).

#### 1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.	
	Cummins 5.0L	VK56VD
Fusible link battery power	R (50A)	N (50A)
BCM battery fuse	1 (10A)	1 (10A)

Is the fuse or fusible link blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2.

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.
2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M81	131	(-)	Battery voltage
	139		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

#### 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	134	—	Yes
	143		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000014664562

Regarding Wiring Diagram information, refer to [PCS-25, "CUMMINS 5.0L : Wiring Diagram"](#).

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## 1. CHECK FUSIBLE LINKS

Check that the following fusible links are not blown.

Terminal	Signal name	Fusible link No.	
		Cummins 5.0L	VK56VD
1	Battery power supply	A (250A), D (100A)	A (250A), B (80A)
2		C (100A)	E (60A)
20		F (250A), J (100A), P (40A)	A (250A), C (100A), U (40A)

Is the fusible link blown?

YES >> Replace the blown fusible link after repairing the affected circuit.  
NO >> GO TO 2.

## 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connectors E118 and E120.
2. Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E118	1	(-)	Battery voltage
	2		
E120	20		

Is the inspection result normal?

YES >> GO TO 3.  
NO >> Repair or replace harness or connectors.

## 3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R connectors E123 and E124.
2. Check continuity between IPDM E/R connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E123	52	—	Yes
	62		

Is the inspection result normal?

YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

# SECURITY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

## SECURITY INDICATOR LAMP

### Component Function Check

INFOID:0000000014391377

#### 1.CHECK FUNCTION

##### ①CONSULT

1. Perform "THEFT IND" in "Active Test" mode of "IMMU" of "BCM".
2. Check security indicator lamp operation.

Test item		Description	
THEFT IND	ON	Security indicator lamp	Illuminates
	OFF		Does not illuminate

Is the inspection result normal?

YES >> Inspection End.  
NO >> Go to [SEC-141, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000014391378

Regarding Wiring Diagram information, refer to [SEC-50, "Wiring Diagram"](#).

#### 1.CHECK FUSE

1. Turn power switch OFF.
2. Check that the following fuse in the fuse block (J/B) is not blown.

Signal name	Fuse No.
Battery power supply	13 (10 A)

Is the inspection result normal?

YES >> GO TO 2.  
NO >> Replace the blown fuse after repairing the cause of blowing.

#### 2.CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT

1. Disconnect combination meter connector.
2. Check voltage between combination meter harness connector and ground.

Type A meter		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
M25	42	Ground	Ignition switch	OFF
				ON

Type B meter		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
M163	6	Ground	Ignition switch	OFF
				ON

Is the inspection result normal?

YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3.CHECK SECURITY INDICATOR LAMP SIGNAL

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# SECURITY INDICATOR LAMP

## < DTC/CIRCUIT DIAGNOSIS >

1. Connect combination meter connector.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+) BCM		(-)	Voltage (Approx.)
Connector	Terminal		
M18	18	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.  
NO >> GO TO 5.

## 4.REPLACE BCM

Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

>> Inspection End.

## 5.CHECK SECURITY INDICATOR LAMP CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between combination meter harness connector and BCM harness connector.

Type A meter		BCM		Continuity
Combination meter	BCM	Connector	Terminal	
Connector	Terminal	M18	18	Yes
M24	7			

Type B meter		BCM		Continuity
Combination meter	BCM	Connector	Terminal	
Connector	Terminal	M18	18	Yes
M163	7			

3. Check continuity between combination meter harness connector and ground.

Type A meter		Ground	Continuity
Combination meter	Terminal		
Connector	Terminal		
M24	7		No

Type B meter		Ground	Continuity
Combination meter	Terminal		
Connector	Terminal		
M163	7		No

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-108, "Removal and Installation"](#) (type A meter) and [MWI-187, "Removal and Installation"](#) (type B meter)  
NO >> Repair or replace harness.

# HORN FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

## HORN FUNCTION

### Component Function Check

INFOID:0000000014391379

#### 1. CHECK FUNCTION

##### CONSULT

1. Perform "VEHICLE SECURITY HORN" in "Active Test" mode of "THEFT ALM" of "BCM".
2. Check the horn operation.

Test item		Description	
VEHICLE SECURITY HORN	ON	Horn	Sounds (for 0.5 sec.)

Is the operation normal?

YES >> Horn function is OK.  
NO >> Go to [SEC-143, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000014391380

Regarding Wiring Diagram information, refer to [SEC-50, "Wiring Diagram"](#).

#### 1. CHECK HORN FUNCTION

Check horn function with horn switch.

Do horns sound?

YES >> GO TO 2.  
NO >> Perform the trouble diagnosis for horn circuit. Refer to [HRN-3, "Wiring Diagram"](#).

#### 2. CHECK IPDM E/R POWER SUPPLY CIRCUIT

1. Disconnect horn relay connector.
2. Check continuity between IPDM E/R harness connector and horn relay harness connector.

IPDM E/R		Horn relay		Continuity
Connector	Terminal	Connector	Terminal	
E122	48	H-1	1	Yes

3. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E122	48		No

Is the inspection result normal?

YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

# INTELLIGENT KEY SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### INTELLIGENT KEY SYSTEM SYMPTOMS

#### Diagnosis Procedure

INFOID:0000000014391381

##### NOTE:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

#### SYMPTOM TABLE 1 (BOTH INTELLIGENT KEYS HAVE THE SAME SYMPTOMS)

No.	Door lock operation (remote keyless entry)	Door lock operation (request switch)	Engine started with push-button ignition switch operation (reg- istered Intelligent Key is within the detection area of inside key an- tenna)	Engine started with push-button ignition switch operation (reg- istered Intelligent Key placed next to push- button ignition switch)	Symptom
1	OK	OK	No start	No start	<a href="#">SEC-145</a>
2	OK	NG	OK	OK	<a href="#">DLK-135</a>
3	OK	NG	No crank, No start	OK	<a href="#">DLK-129</a>
4	NG	NG	No crank, No start	OK	<a href="#">DLK-131</a>
5	NG	NG	No start	No start	<a href="#">DLK-132</a>
6	OK	OK	No crank, No start	OK	<a href="#">SEC-146</a>
7	NG	OK	OK	OK	<a href="#">DLK-134</a>
8	NG	NG	OK	OK	<a href="#">DLK-135</a>
9	Poor range	OK	OK	OK	<a href="#">DLK-136</a>

#### SYMPTOM TABLE 2 (ONE INTELLIGENT KEY HAS THE SYMPTOM, OTHER KEYS OPERATE NORMALLY)

No.	Door lock operation (remote keyless entry)	Door lock operation (request switch)	Engine started with push-button ignition switch operation (In- telligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (reg- istered Intelligent Key placed next to push- button ignition switch)	Symptom
1	NG	OK	OK	OK	<a href="#">DLK-138</a>
2	NG	NG	No crank, No start	OK	<a href="#">DLK-139</a>
3	NG	NG	No crank, No start	No crank, No start	<a href="#">DLK-141</a>
4	OK	OK	No crank, No start	No crank, No start	<a href="#">SEC-148</a>
5	OK	NG	No crank, No start	OK	<a href="#">SEC-149</a>
6	Poor range	OK	OK	OK	<a href="#">DLK-143</a>

# ENGINE CAN NOT START

< SYMPTOM DIAGNOSIS >

## ENGINE CAN NOT START

### Description

INFOID:0000000014391382

Engine does not start when push-button ignition switch is pressed.

### SYMPTOM TABLE (BOTH INTELLIGENT KEYS HAVE THE SAME SYMPTOMS)

Door lock operation (remote keyless entry)	Door lock operation (request switch)	Engine started with push-button ignition switch operation (registered Intelligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch)
OK	OK	No start	No start

### CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

“ENGINE START BY I-KEY” setting in “Work support” mode of “INTELLIGENT KEY” of “BCM” is ON.

### DIAGNOSIS PROCEDURE

Refer to [SEC-145, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000014391383

#### 1. CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.

Refer to [SEC-144, "Diagnosis Procedure".](#)

>> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS RESULT

Select “Self Diagnostic Result” mode of all systems, and check if DTC is detected.

>> Follow troubleshooting for each DTC.

SEC

L

M

N

O

P

# ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE

< SYMPTOM DIAGNOSIS >

## ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE

### Description

INFOID:0000000014391384

Engine does not start when push-button ignition switch is pressed while carrying Intelligent Key.

#### NOTE:

- Before starting diagnosis check that vehicle condition is as shown in “Conditions of vehicle”, and check each symptom.
- The engine start function, door lock function, power distribution system, and NATS-IVIS/NVIS in the Intelligent Key system are closely related to each other regarding control. The vehicle security function can operate only when the door lock and power distribution system are operating normally.

### SYMPTOM TABLE (BOTH INTELLIGENT KEYS HAVE THE SAME SYMPTOMS)

Door lock operation (remote keyless entry)	Door lock operation (request switch)	Engine started with push-button ignition switch operation (registered Intelligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch)
OK	OK	No crank, No start	OK

### CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

- “ENGINE START BY I-KEY” setting in “Work support” mode of “INTELLIGENT KEY” of “BCM” is ON.
- One or more Intelligent Keys with a registered Intelligent Key ID are in the vehicle.

### DIAGNOSIS PROCEDURE

Refer to [SEC-146, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000014391385

#### 1. CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.

Refer to [SEC-144, "Diagnosis Procedure".](#)

>> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS RESULT

Select “Self Diagnostic Result” mode of “BCM”, and check if DTC is detected.

Is DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC.

NO >> GO TO 3.

#### 3. CHECK “ENGINE START BY I-KEY” SETTING IN “WORK SUPPORT”

1. Select “INTELLIGENT KEY” of “BCM” using CONSULT.
2. Select “ENGINE START BY I-KEY” of “Work support” mode.
3. Check “ENGINE START BY I-KEY” in “Work support”.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set “On” in “ENGINE START BY I-KEY”.

#### 4. CHECK INSIDE KEY ANTENNA

Use SIGNAL TECH II to check each inside key antenna. For the inspection method and how to use SIGNAL TECH II, refer to “NISSAN/INFINITI SIGNAL TECH II USER GUIDE”.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning parts.

# ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE

< SYMPTOM DIAGNOSIS >

## 5. REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE (ONE KEY)

< SYMPTOM DIAGNOSIS >

## ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE (ONE KEY)

### Description

INFOID:0000000014391386

Engine does not start when push-button ignition switch is pressed. (One Intelligent Key has the symptom, other keys operate normally.)

SYMPTOM TABLE (ONE INTELLIGENT KEY HAS THE SYMPTOM, OTHER KEYS OPERATE NORMALLY)

Door lock operation (remote keyless entry)	Door lock operation (request switch)	Engine started with push-button ignition switch operation (Intelligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch)
OK	OK	No crank, No start	No crank, No start

### DIAGNOSIS PROCEDURE

Refer to [SEC-148, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000014391387

#### 1. CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.

Refer to [SEC-144, "Diagnosis Procedure".](#)

>> GO TO 2.

#### 2. REGISTER INTELLIGENT KEY

1. Register the Intelligent Key.
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 3.

#### 3. REPLACE INTELLIGENT KEY

1. Replace the Intelligent Key and perform registration again.
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

#### 4. REPLACE BCM

1. Replace BCM. Refer to [BCS-79, "Removal and Installation".](#)
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident".](#)

# DOOR DOES NOT LOCK/UNLOCK AND ENGINE DOES NOT START (REQ SW/PUSH SW) (ONE KEY)

< SYMPTOM DIAGNOSIS >

## DOOR DOES NOT LOCK/UNLOCK AND ENGINE DOES NOT START (REQ SW/PUSH SW) (ONE KEY)

### Description

INFOID:0000000014391388

Door does not lock/unlock with door request switch, and engine does not start when push-button ignition switch is pressed while carrying Intelligent Key. (One Intelligent Key has the symptom, other keys operate normally.)

SYMPTOM TABLE (ONE INTELLIGENT KEY HAS THE SYMPTOM, OTHER KEYS OPERATE NORMALLY)

Door lock operation (remote keyless entry)	Door lock operation (request switch)	Engine started with push-button ignition switch operation (Intelligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch)
OK	NG	No crank, No start	OK

### DIAGNOSIS PROCEDURE

Refer to [SEC-149, "Diagnosis Procedure".](#)

### Diagnosis Procedure

INFOID:0000000014391389

#### 1. CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.

Refer to [SEC-144, "Diagnosis Procedure".](#)

>> GO TO 2.

#### 2. CHECK INTELLIGENT KEY LOW BATTERY WARNING

Check that the Intelligent Key low battery warning operates.

Is the Intelligent Key low battery warning operated?

YES >> Replace Intelligent Key battery. Refer to [DLK-198, "Removal and Installation".](#)  
NO >> GO TO 3.

SEC

#### 3. CHECK INTELLIGENT KEY BATTERY

Check the Intelligent Key battery.

Is the inspection result normal?

YES >> GO TO 4.  
NO >> Replace Intelligent Key battery. Refer to [DLK-198, "Removal and Installation".](#)

L

M

N

O

P

#### 4. REGISTER INTELLIGENT KEY

1. Register the Intelligent Key.
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.  
NO >> GO TO 5.

#### 5. REPLACE INTELLIGENT KEY

1. Replace the Intelligent Key and perform registration again.
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.  
NO >> GO TO 6.

#### 6. REPLACE BCM

## DOOR DOES NOT LOCK/UNLOCK AND ENGINE DOES NOT START (REQ SW/ PUSH SW) (ONE KEY)

### < SYMPTOM DIAGNOSIS >

1. Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
2. Check operation after replacement.

### Is the inspection result normal?

YES    >> Inspection End.

NO    >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

&lt; REMOVAL AND INSTALLATION &gt;

# REMOVAL AND INSTALLATION

## NATS ANTENNA AMP.

### Removal and Installation

INFOID:000000014391390


#### NATS ANTENNA AMP.

##### NOTE:

- If NATS antenna amp. is not installed correctly, NVIS (NATS) system will not operate properly and "SELF DIAGNOSTIC RESULT" on CONSULT screen will show "LOCK MODE" or "CHAIN OF IMMU-KEY".
- Initialization is not necessary when only the NATS antenna amp. is replaced with a new one.


#### Removal

1. Disconnect the battery or batteries. Refer to [PG-185, "Battery Disconnect"](#).
2. Remove the cluster lid C finisher (LH). Refer to [IP-16, "CLUSTER LID C FINISHER : Removal and Installation"](#).
3. Disconnect the harness connectors from the NATS antenna amp. and push-button ignition switch.
4. Remove the NATS antenna amp. and push-button ignition switch (1).



ALKIA4174Z2

5. Release the pawls and separate the push-button ignition switch (1) from the NATS antenna amp. (2).



ALKIA4175Z2

#### Installation

Installation is in the reverse order of removal.

# REMOTE KEYLESS ENTRY RECEIVER

< REMOVAL AND INSTALLATION >

## REMOTE KEYLESS ENTRY RECEIVER


### Removal and Installation

INFOID:0000000014391391

#### REMOTE KEYLESS ENTRY RECEIVER

##### Removal

1. Remove instrument upper panel. Refer to [IP-17, "INSTRUMENT UPPER PANEL : Removal and Installation".](#)
2. Disconnect the harness connector from the remote keyless entry receiver (1).
3. Remove screw (A) and remote keyless entry receiver.



4. Remove remote keyless entry receiver from bracket.

##### Installation

Installation is in the reverse order of removal.

# PUSH BUTTON IGNITION SWITCH

< REMOVAL AND INSTALLATION >

## PUSH BUTTON IGNITION SWITCH

### Removal and Installation

INFOID:0000000014391392

For removal and installation of the push-button ignition switch, refer to [PCS-98, "Removal and Installation".](#)

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

## **BCM (BODY CONTROL MODULE)**

< REMOVAL AND INSTALLATION >

---

## **BCM (BODY CONTROL MODULE)**

### **Removal and Installation**

INFOID:0000000014391393

For removal and installation of the Body Control Module (BCM), refer to [BCS-79. "Removal and Installation".](#)