

SECTION SN

SONAR SYSTEM

A
B
C
D
E

F
G
H
I
J
K
L
M

SN

O
P

CONTENTS

PRECAUTION	3	DIAGNOSIS AND REPAIR WORKFLOW	29
PRECAUTION	3	Work Flow	29
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3		
Precaution for Work	3		
PREPARATION	4	INSPECTION AND ADJUSTMENT	31
PREPARATION	4	ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT	31
Special Service Tool	4	ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT : Description	31
		ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT : Work Procedure	31
SYSTEM DESCRIPTION	5	CONFIGURATION (SONAR CONTROL UNIT)	31
COMPONENT PARTS	5	CONFIGURATION (SONAR CONTROL UNIT) : Description	32
Component Parts Location	5	CONFIGURATION (SONAR CONTROL UNIT) : Work Procedure	32
Sonar Control Unit	6	CONFIGURATION (SONAR CONTROL UNIT) : Configuration List	33
Sonar Sensor	6		
Buzzer	7		
Sonar System Off Switch	7		
SYSTEM	8	DTC/CIRCUIT DIAGNOSIS	34
System Description	8	U1000 CAN COMM CIRCUIT	34
DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)	11	DTC Description	34
CONSULT Function	11	Diagnosis Procedure	34
ECU DIAGNOSIS INFORMATION	14	U1010 CONTROL UNIT (CAN)	35
SONAR CONTROL UNIT	14	DTC Description	35
Reference Value	14	Diagnosis Procedure	35
Fail Safe	17		
DTC Index	18		
WIRING DIAGRAM	19	B2720 CORNER SENSOR [RL]	36
SONAR SYSTEM	19	DTC Description	36
Wiring Diagram	19	Diagnosis Procedure	36
BASIC INSPECTION	29	B2721 CENTER SENSOR [RL]	38
		DTC Description	38
		Diagnosis Procedure	38
		B2722 CENTER SENSOR [RR]	40
		DTC Description	40
		Diagnosis Procedure	40
		B2723 CORNER SENSOR [RR]	42

DTC Description	42	POWER SUPPLY AND GROUND CIRCUIT	57
Diagnosis Procedure	42	Diagnosis Procedure	57
B2724 SONAR CONTROL UNIT	44	SONAR SYSTEM OFF SWITCH CIRCUIT	58
DTC Description	44	Diagnosis Procedure	58
Diagnosis Procedure	44	SONAR SYSTEM OFF SWITCH INDICATOR	
B2728 LED	45	LAMP CIRCUIT	60
DTC Description	45	Diagnosis Procedure	60
Diagnosis Procedure	45	SYMPTOM DIAGNOSIS	62
B2729 CORNER SENSOR [FL]	47	SONAR SYSTEM	62
DTC Description	47	Symptom Table	62
Diagnosis Procedure	47	REMOVAL AND INSTALLATION	63
B272A CENTER SENSOR [FL]	49	SONAR SENSOR	63
DTC Description	49	Removal and Installation - Front Sonar Sensors ...	63
Diagnosis Procedure	49	Removal and Installation - Rear Sonar Sensors ...	64
B272B CENTER SENSOR [FR]	51	SONAR CONTROL UNIT	66
DTC Description	51	Removal and Installation	66
Diagnosis Procedure	51	BUZZER	67
B272C CORNER SENSOR [FR]	53	Removal and Installation	67
DTC Description	53	SONAR SYSTEM OFF SWITCH	68
Diagnosis Procedure	53	Exploded View	68
B272D FRONT BUZZER	55	Removal and Installation	68
DTC Description	55		
Diagnosis Procedure	55		

< PRECAUTION >

PRECAUTION

PRECAUTION

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000014386728

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- **When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.**
- **When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.**

Precaution for Work

INFOID:0000000014386729

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >


PREPARATION

PREPARATION

Special Service Tool

INFOID:000000014386730

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.)	Tool name	Description
— (J-46534) Trim Tool Set	 AWJIA0483ZZ	Removing trim components

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000014386731



A. Instrument lower panel LH (view with instrument lower panel LH removed)

A
B
C
D
E
F
G
H
I
J
K
L
M
SN
O
P

COMPONENT PARTS


< SYSTEM DESCRIPTION >

No.	Component	Function
1.	Rear sonar sensors	Refer to SN-6, "Sonar Sensor" .
2.	Combination meter	Refer to MWI-12, "METER SYSTEM : Combination Meter" . Displays the sonar indicator.
3.	AV control unit	Refer to AV-171, "AV Control Unit" . Displays an around view monitor image with sonar indicator.
4.	ADAS control unit	Refer to DAS-5, "ADAS Control Unit" . Supplies power and ground for the sonar system OFF switch, when equipped.
5.	TCM (Cummins 5.0L)	Refer to TM-17, "A/T CONTROL SYSTEM : TCM" . Supplies the P (park) or D (drive) signal to the sonar control unit via CAN communication.
6.	Front sonar sensors	Refer to SN-6, "Sonar Sensor" .
7.	TCM (integral to the control valve assembly, built into the A/T assembly) (VK56VD)	Refer to TM-267, "A/T CONTROL SYSTEM : TCM" . Supplies the P (park) or D (drive) signal to the sonar control unit via CAN communication.
8.	ABS actuator and electric unit (control unit)	Refer to BRC-10, "ABS Actuator and Electric Unit (Control Unit)" . Supplies the speed signal to the sonar control unit via CAN communication.
9.	Sonar system OFF switch	Refer to SN-7, "Sonar System Off Switch" .
10.	Around view monitor control unit	Refer to AV-296, "Around View Monitor Control Unit" . Renders the sonar indicator image for display on the AV control unit.
11.	Front sonar buzzer	Refer to SN-7, "Buzzer" .
12.	Sonar control unit	Refer to SN-6, "Sonar Control Unit" .

Sonar Control Unit

INFOID:000000014386732

- Sonar sensor signals are received by the sonar control unit and transmitted to the around view monitor control unit or combination meter via CAN communication for the indicator display.
- Sonar control unit outputs a buzzer signal for audible alert.




AWNIA40812Z

Sonar Sensor

INFOID:000000014386733

When a distance from an obstacle is detected, a signal is transmitted to the sonar control unit.



JSNIA5115ZZ


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Buzzer

INFOID:000000014386734


The front sonar buzzer sounds with the signal from the sonar control unit.



Sonar System Off Switch

INFOID:000000014386735

The sonar system off switch is used to turn the system ON/OFF.



A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM

System Description

INFOID:000000014386736


SYSTEM DIAGRAM

With Driver Assistance System



AWNIA4391GB

Without Driver Assistance System



AWNIA4403GB

DESCRIPTION

Camera Assistance Sonar Function (With Around View Monitor)

- Inner/outer sensors are installed on front bumper and rear bumper. When an obstacle is detected while around view monitor is displayed, a sonar indicator display and buzzer sound notify the driver of the proximity of an obstacle. When an obstacle is detected while around view monitor is not displayed, around view monitor screen is displayed automatically, and then the indicator displays and buzzer sounds.

SYSTEM

< SYSTEM DESCRIPTION >

- A sonar indicator is displayed in the combination meter information display also.
- The warning buzzer output frequency changes according to the detection distance.
- Sonar control unit receives shift position signals (P, R, N and D) from TCM and vehicle speed signal from ABS actuator control unit via CAN communication, and controls ON/OFF of sonar system.
- Sonar control unit transmits detection signal and detection distance signal to around view monitor and combination meter via CAN communication, according to signal from inner/outer sensors depending on conditions shown in the following table. Around view monitor and combination meter display the applicable sonar indicator.

Sonar system operation condition			Sonar operation	
Shift position	Vehicle speed	Obstacle	Sonar indicator	Buzzer
R position	Less than 10 km/h (6 MPH)	Yes	Detection status is displayed	Yes
D position	Less than 10 km/h (6 MPH)	Yes	Detection status is displayed	Yes
P or N position	Less than 10 km/h (6 MPH)	Yes	Detection status is displayed*	None
—	10 km/h (6 MPH) or more	Yes	Not displayed	None


*: Only when camera image is displayed.

Sonar Function (Without Around View Monitor)

- Inner/outer sensors are installed on front bumper and rear bumper. When an obstacle is detected, a sonar indicator is displayed in the combination meter and buzzer sounds to notify the driver of the proximity of an obstacle.
- Sonar control unit transmits the sonar operation signal via CAN communication to the combination meter to control the operation of sonar indicator.
- The warning buzzer output frequency changes according to the detection distance.

Obstacle Detection Distance

Obstacle detection image



A. Approx. 50 cm (19.6 in)

B. Approx. 15 cm (5.9 in)

AWNIA4281ZZ

SYSTEM

< SYSTEM DESCRIPTION >

Sonar Indicator Display

With Around View Monitor

- Around view monitor control unit receives the detection signal and detection distance signal from sonar control unit and displays the sonar indicator on AV control unit display.
- Around view monitor control unit changes the color or blinking cycle of the indicator according to the detection distance.

Without Around View Monitor

- Combination meter receives the detection signal and detection distance signal from sonar control unit and displays the sonar indicator on the information display.
- Combination meter changes the color or blinking cycle of the indicator according to the detection distance.

Sonar Buzzer Operation

- Each sonar sensor transmits a sensor signal to the sonar control unit when detecting an obstacle.
- The sonar control unit converts a signal received from each sonar sensor into distance and then sounds the buzzer accordingly.

DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

CONSULT Function

INFOID:000000014386737

CAUTION:

After disconnecting the CONSULT VI (vehicle interface) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes shown as follows:

Direct Diagnostic Mode	Description
Ecu Identification	The sonar control unit part number is displayed.
Self Diagnostic Result	The sonar control unit self diagnostic results are displayed.
Data Monitor	The sonar control unit input/output data is displayed in real time.
Active Test	The sonar control unit activates outputs to test components.
Work support	The settings for sonar control unit functions can be changed.
Configuration	<ul style="list-style-type: none">The vehicle specification can be read and saved.The vehicle specification can be written when replacing sonar control unit.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

ECU IDENTIFICATION

Displays the part number of sonar control unit.

SELF-DIAGNOSTIC RESULTS

For details, refer to [SN-18, "DTC Index"](#).

DATA MONITOR

Monitor Item	Description
VEHICLE SPEED [mph/km/h]	Indicates vehicle speed signal received from combination meter on CAN communication line.
SONAR C/U POWER SUPPLY [V]	Indicates condition of supply voltage signal to sonar control unit.
SENSOR VOLTAGE [V]	Indicates condition of voltage signal to sonar sensors.
DETECTION MODE [Mode 1/Mode 2]	Indicates condition of display detection mode.
SONAR TEMPORARY OFF [Yes/No]	Indicates condition of sonar system.
SONAR PERMANENT OFF [Yes/No]	Indicates condition of sonar system.
P N RANGE [On/Off]	Indicates condition of A/T shift selector P (park) or N (neutral) position.
LED [Yes/No]	Indicates condition of LED indicator.
TRAILER CONNECT [CON/N CON]	Indicates if trailer is connected.
REVERSE RANGE [On/Off]	Indicates condition of transmission range switch R (reverse) position.

DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

< SYSTEM DESCRIPTION >

Monitor Item	Description
SHRT DST FRM RR SENS [cm/in]	
SHRT DST FRM FR SENS [cm/in]	
COR[RL] [cm/in]	
COR[RL]>CEN[RL]/CEN[R] [cm/in]	
CEN[RL]/CEN[R]>COR[RL] [cm/in]	
CEN[RL]/CEN[R] [cm/in]	
CEN[RL]>CEN[RR] [cm/in]	
CEN[RR]>CEN[RL] [cm/in]	
CEN[RR] [cm/in]	
CEN[RR]/CEN[R]>COR[RR] [cm/in]	
COR[RR]>CEN[RR]/CEN[R] [cm/in]	
COR[RR] [cm/in]	
COR[FL] [cm/in]	
COR[FL]>CEN[FL]/CEN[F] [cm/in]	
CEN[FL]/CEN[F]>COR[FL] [cm/in]	
CEN[FL]/CEN[F] [cm/in]	Indicates distance to obstacle.
CEN[FL]>CEN[FR] [cm/in]	
CEN[FR]>CEN[FL] [cm/in]	
CEN[FR] [cm/in]	
CEN[FR]/CEN[F]>COR[FR] [cm/in]	
COR[FR]>CEN[FR]/CEN[F] [cm/in]	
COR[FR] [cm/in]	
RVRB TIME COR[RL] [ms/sec]	
RVRB TIME COR[RR] [ms/sec]	
RVRB TIME CEN[RL] [ms/sec]	
RVRB TIME CEN[RR] [ms/sec]	
RVRB TIME COR[FL] [ms/sec]	
RVRB TIME COR[FR] [ms/sec]	
RVRB TIME CEN[FL] [ms/sec]	
RVRB TIME CEN[FR] [ms/sec]	

ACTIVE TEST

Test Item	Description
FRONT BUZZER	This test is able to check front buzzer operation [On/Off].
LED	This test is able to check off indicator operation [On/Off].

WORK SUPPORT

DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

< SYSTEM DESCRIPTION >

Support Item	Setting	Description	
VOLUME SETTING	Vol.1	Allows you to set volume of warning tone.	A
	Low		B
	Vol.3		
	Middle		C
	Vol.5		
	High		D
TRAILER HITCH DETECTION RANGE ADJUSTMENT	Off	Allows you to adjust rear sonar sensors for trailer towing.	
	Qu		E
	UP		
	DOWN		
CONFIGURATION	Qd		
	Refer to SN-32, "CONFIGURATION (SONAR CONTROL UNIT) : Description".		F
	CAN DIAG SUPPORT MNTR		
	Refer to LAN-50, "CAN Diagnostic Support Monitor".		G
			H
			I
			J
			K
			L
			M
			SN
			O
			P

SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

SONAR CONTROL UNIT

Reference Value

INFOID:000000014386738

VALUES ON THE DIAGNOSIS TOOL


Monitor Item	Condition	Value/Status
COR[FL]		
COR[FR]		
COR[RL]		
COR[RR]		
COR[RL]->CEN[RL]/CEN[R] [cm/in]		
CEN[RL]/CEN[R]->COR[RL] [cm/in]		
CEN[RL]/CEN[R] [cm/in]		
CEN[RL]->CEN[RR] [cm/in]		
CEN[RR]->CEN[RL] [cm/in]		
CEN[RR] [cm/in]		
CEN[RR]/CEN[R]->COR[RR] [cm/in]	Key ON, A/T shift selector in R (reverse) position.	cm/in
COR[RR]->CEN[RR]/CEN[R] [cm/in]		
COR[FL]->CEN[FL]/CEN[F] [cm/in]		
CEN[FL]/CEN[F]->COR[FL] [cm/in]		
CEN[FL]/CEN[F] [cm/in]		
CEN[FL]->CEN[FR] [cm/in]		
CEN[FR]->CEN[FL] [cm/in]		
CEN[FR] [cm/in]		
CEN[FR]/CEN[F]->COR[FR] [cm/in]		
COR[FR]->CEN[FR]/CEN[F] [cm/in]		
DETECTION MODE	Key ON.	Mode 1 Mode 2
P N RANGE	When A/T shift selector is in any position other than P (park) or N (neutral).	Off
	When A/T shift selector in P (park) or N (neutral) position.	On
LED	When LED is off.	No
	When LED is on.	Yes
TRAILER CONNECT	When no trailer is connected.	N CONN
	When trailer is connected.	CONN
REVERSE RANGE	When transmission range switch is in any position other than R (reverse).	Off
	When transmission range switch is in R (reverse) position.	On

SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RVRB TIME CEN[FL]	Key ON, A/T shift selector in R (reverse) position.	ms/sec
RVRB TIME CEN[FR]		
RVRB TIME CEN[RL]		
RVRB TIME CEN[RR]		
RVRB TIME COR[FL]		
RVRB TIME COR[FR]		
RVRB TIME COR[RL]		
RVRB TIME COR[RR]		
SENSOR VOLTAGE		5.0 V
SHRT DST FRM FR SENS		cm/in
SHRT DST FRM RR SENS		
SONAR C/U POWER SUPPLY	Key ON.	Battery voltage
SONAR PERMANENT OFF	Key ON, A/T shift selector in R (reverse) position.	No
	When selector lever is in any position other than R (reverse).	Yes
SONAR TEMPORARY OFF	Key ON, A/T shift selector in R (reverse) position.	No
	When A/T shift selector is in any position other than R (reverse).	Yes
VEHICLE SPEED	While driving, equivalent to speedometer reading	mph, km/h

TERMINAL LAYOUT







AWNIA1727Z

PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
1 (W/L)	13 (W)	Front inner right sensor signal	Input	ON	Shift position is D (drive) or R (reverse). Obstacle within range of front sonar sensor RH inner.	 JSNIA0837GB
2 (W/R)	13 (W)	Front inner left sensor signal	Input	ON	Shift position is D (drive) or R (reverse). Obstacle within range of front sonar sensor LH inner.	 JSNIA0837GB



SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
3 (O)	13 (W)	Front outer left sensor signal	Input	ON	Shift position is D (drive) or R (reverse). Obstacle within range of front sonar sensor LH outer.	 JSNIA0837GB
4 (BG)	13 (W)	Front outer right sensor signal	Input	ON	Shift position is D (drive) or R (reverse). Obstacle within range of front sonar sensor RH outer.	 JSNIA0837GB
5 (L)	—	CAN high	Input/ Output	—	—	—
6 (R)	—	CAN low	Input/ Output	—	—	—
9 (L)	14 (BG)	Rear inner right sensor signal	Input	ON	Shift position is D (drive) or R (reverse). Obstacle within range of rear sonar sensor RH inner.	 JSNIA0837GB
10 (O)	14 (BG)	Rear outer right sensor signal	Input	ON	Shift position is D (drive) or R (reverse). Obstacle within range of rear sonar sensor RH outer.	 JSNIA0837GB
12 (G/R)	Ground	Ignition power supply	Input	ON	—	Battery voltage
15 (B)	Ground	Ground	—	ON	—	0 V
16 ¹ (G)	Ground	Switch input signal	Input	ON	Sonar system off switch pressed.	0 V
					Sonar system off switch released.	Battery voltage
17 ¹ (G/B)	Ground	Status LED	Output	ON	Sonar system off switch ON.	Battery voltage
18 (G)	Ground	Speaker signal	Output	ON	Shift position is D (drive) or R (reverse). Obstacle within range of any sonar sensor.	Battery voltage
19 (W)	Ground	Speaker power supply	Output	ON	—	Battery voltage

SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
21 (Y)	14 (BG)	Rear inner left sensor signal	Input	ON	Shift position is D (drive) or R (reverse). Obstacle within range of rear sonar sensor LH inner.	 JSNIA0837GB
22 (B)	14 (BG)	Rear outer left sensor signal	Input	ON	Shift position is D (drive) or R (reverse). Obstacle within range of rear sonar sensor LH outer.	 JSNIA0837GB
24 (G/W)	Ground	Reverse position input signal	Input	ON	Shift position is R (reverse).	Battery voltage

¹: Without driver assistance system

Fail Safe

INFOID:0000000014386739

Display contents of CONSULT	Fault	Fail-safe operation
U1000: CAN COMM CIRCUIT	<ul style="list-style-type: none"> Loss of communication with ABS actuator and electric unit (control unit) Loss of communication with TCU 	<ul style="list-style-type: none"> Front sonar system is OFF, rear sonar system is ON (selector lever in reverse) Front and rear sonar system are OFF
B2720: Rear left side external sensor		
B2721: Rear left side internal sensor	<ul style="list-style-type: none"> Open circuit/short circuit to ground Short circuit to voltage Sensor element malfunction 	<ul style="list-style-type: none"> Obstacle detection of the sensor in error is stopped Audible warning (front sonar buzzer) of all sensors is stopped Front sonar buzzer sounds for 3 seconds
B2722: Rear right side internal sensor		
B2723: Rear right side external sensor		
B2724: ECU	Configuration check	<ul style="list-style-type: none"> Off indicator blinks periodically (500ms ON, 500ms OFF) Front sonar buzzer sounds for 3 seconds
B2728: Led	<ul style="list-style-type: none"> Short circuit to ground Short circuit to voltage Open circuit 	<ul style="list-style-type: none"> Audible warning (front sonar buzzer) of all sensors is stopped Front sonar buzzer sounds for 3 seconds
B2729: Front left side external sensor		
B272A: Front left side internal sensor	<ul style="list-style-type: none"> Open circuit/short circuit to ground Short circuit to voltage Sensor element malfunction 	<ul style="list-style-type: none"> Obstacle detection of the sensor in error is stopped Audible warning (front sonar buzzer) of all sensors is stopped Front sonar buzzer sounds for 3 seconds
B272B: Front right side internal sensor		
B272C: Front right side external sensor		
B272D: Front buzzer	<ul style="list-style-type: none"> Open circuit/short circuit to ground Short circuit to voltage 	<ul style="list-style-type: none"> Off indicator blinks periodically (500ms ON, 500ms OFF) Audible warning (front sonar buzzer) of all sensors is stopped

SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

DTC Index

INFOID:000000014386740

CONSULT Display	Reference Page
U1000: CAN COMM CIRCUIT	SN-34. "DTC Description"
U1010: CONTROL UNIT(CAN)	SN-35. "DTC Description"
B2720: Rear left side external sensor	SN-36. "DTC Description"
B2721: Rear left side internal sensor	SN-38. "DTC Description"
B2722: Rear right side internal sensor	SN-40. "DTC Description"
B2723: Rear right side external sensor	SN-42. "DTC Description"
B2724: ECU	SN-44. "DTC Description"
B2728: Led	SN-45. "DTC Description"
B2729: Front left side external sensor	SN-47. "DTC Description"
B272A: Front left side internal sensor	SN-49. "DTC Description"
B272B: Front right side internal sensor	SN-51. "DTC Description"
B272C: Front right side external sensor	SN-53. "DTC Description"
B272D: Front Buzzer	SN-55. "DTC Description"

SONAR SYSTEM


< WIRING DIAGRAM >

WIRING DIAGRAM

SONAR SYSTEM


Wiring Diagram

INFOID:000000014386741



SONAR SYSTEM

< WIRING DIAGRAM >



AANWA1734GB

SONAR SYSTEM

< WIRING DIAGRAM >

SONAR SYSTEM CONNECTORS

Connector No.	WIRE TO WIRE
Connector Name	RK26FGY-RS20-X6
Connector Type	GRAY
Connector Color	

22C	SHIELD	TO ENGINE ROOM HARNESS
23C	G/B	TO ENGINE ROOM HARNESS
24C	G/B	TO ENGINE ROOM HARNESS
25C	W	TO ENGINE ROOM HARNESS
26C	B	TO ENGINE ROOM HARNESS
27C	LG	TO ENGINE ROOM HARNESS
28C	G/W	TO ENGINE ROOM HARNESS
29C	R/L/G	TO ENGINE ROOM HARNESS
30C	R/L	TO ENGINE ROOM HARNESS
31C	B	TO ENGINE ROOM HARNESS
32C	R	TO ENGINE ROOM HARNESS
33C	L/W	TO ENGINE ROOM HARNESS
34C	L	TO ENGINE ROOM HARNESS
35C	R/W	TO ENGINE ROOM HARNESS
36C	L	TO ENGINE ROOM HARNESS
37C	Y	TO ENGINE ROOM HARNESS
38C	GR	TO ENGINE ROOM HARNESS
39C	D	TO ENGINE ROOM HARNESS

1	BG	TO REAR SONAR SENSOR SUB HARNESS
2	L	TO REAR SONAR SENSOR SUB HARNESS
3	W	TO REAR SONAR SENSOR SUB HARNESS
4	LG	TO REAR SONAR SENSOR SUB HARNESS
5	Y	TO REAR SONAR SENSOR SUB HARNESS
6	B	TO REAR SONAR SENSOR SUB HARNESS
7	BG	TO REAR SONAR SENSOR SUB HARNESS
8	Y	TO REAR SONAR SENSOR SUB HARNESS

1	BG	GROUND
2	B	SIGNAL
3	-	-

Connector No.	C112
Connector Name	REAR SONAR SENSOR RH INNER
Connector Type	RH03FB
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	BG	GROUND
2	L	SIGNAL
3	-	

Connector No.	C113
Connector Name	REAR SONAR SENSOR LH INNER
Connector Type	RH03FB
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
1	BG	GROUND
2	Y	SIGNAL
3	-	-

Connector No.	C111
Connector Name	REAR SONAR SENSOR RH OUTER
Connector Type	RH03FB
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
1	BG	TO CHASSIS HARNESS
2	L	TO CHASSIS HARNESS
3	BG	TO CHASSIS HARNESS
4	B	TO CHASSIS HARNESS
5	Y	TO CHASSIS HARNESS
6	B	TO CHASSIS HARNESS
7	BG	TO CHASSIS HARNESS
8	Y	TO CHASSIS HARNESS

10C	GR	- TO ENGINE ROOM HARNESS - (WITH WASB50D)
11C	B	- TO ENGINE ROOM HARNESS - (WITH CUMMINS 5.0L)
11C	R/W	- TO ENGINE ROOM HARNESS - (WITH WASB50D)
12C	Y	- TO ENGINE ROOM HARNESS
13C	B	- TO ENGINE ROOM HARNESS
14C	BG	- TO ENGINE ROOM HARNESS
15C	Y	- TO ENGINE ROOM HARNESS
16C	B	- TO ENGINE ROOM HARNESS
17C	V	- TO ENGINE ROOM HARNESS
18C	BG	- TO ENGINE ROOM HARNESS
19C	L	- TO ENGINE ROOM HARNESS
20C	W	- TO ENGINE ROOM HARNESS
21C	LG	- TO ENGINE ROOM HARNESS

AANIA5294GE

SONAR SYSTEM


< WIRING DIAGRAM >

SONAR SYSTEM CONNECTORS

Connector No.	CT14	Color of Wire	Signal Name
Connector Name	REAR SONAR SENSOR LH OUTER	GR	TO ENGINE CONTROL HARNESS
		VR	TO ENGINE CONTROL HARNESS
Connector Type	RH03FB	B	TO ENGINE CONTROL HARNESS
Connector Color	BLACK	P	TO ENGINE CONTROL HARNESS



Connector No.	E5	Color of Wire	Signal Name
Connector Name	WIRE TO WIRE	Y	GROUND
Connector Type	TH24MW-NH	B	SIGNAL
Connector Color	WHITE	—	—



Terminal No.	20	Color of Wire	GR	TO ENGINE CONTROL HARNESS	7C	R	TO CHASSIS HARNESS - (WITH V66VD)	48C	Y/R	TO CHASSIS HARNESS
	21		VR	TO ENGINE CONTROL HARNESS	8C	B	TO CHASSIS HARNESS - (WITH CUMMINS 5.0L)	49C	R/Y	TO CHASSIS HARNESS - (WITH CUMMINS 5.0L)
Connector Name	REAR SONAR SENSOR LH OUTER				8C	B	TO CHASSIS HARNESS - (WITH CUMMINS 5.0L)	49C	V	TO CHASSIS HARNESS - (WITH V66VD)
Connector Type	RH03FB				8C	OB	TO CHASSIS HARNESS - (WITH V66VD)	50C	B	TO CHASSIS HARNESS - (WITH CUMMINS 5.0L)
Connector Color	BLACK				9C	WL	TO CHASSIS HARNESS - (WITH CUMMINS 5.0L)	50C	Y	TO CHASSIS HARNESS - (WITH V66VD)
Connector No.	E19				9C	SB	TO CHASSIS HARNESS - (WITH V66VD)	51C	V	TO CHASSIS HARNESS - (WITH CUMMINS 5.0L)
Connector Name	WIRE TO WIRE				10C	GR/R	TO CHASSIS HARNESS - (WITH CUMMINS 5.0L)	51C	B	TO CHASSIS HARNESS - (WITH V66VD)
Connector Type	NS04MMW-CS				10C	GR	TO CHASSIS HARNESS - (WITH V66VD)	52C	B	TO CHASSIS HARNESS - (WITHOUT FFV)
Connector Color	WHITE				11C	B	TO CHASSIS HARNESS - (WITH CUMMINS 5.0L)	52C	L	TO CHASSIS HARNESS - (WITHOUT FFV)
					11C	R/W	TO CHASSIS HARNESS - (WITH V66VD)	52C	V/W	TO CHASSIS HARNESS
					12C	Y	TO CHASSIS HARNESS			
					13C	B	TO CHASSIS HARNESS			
					14C	BG	TO CHASSIS HARNESS			
					15C	Y	TO CHASSIS HARNESS			
					16C	B	TO CHASSIS HARNESS			
					17C	V	TO CHASSIS HARNESS			
					18C	BG	TO CHASSIS HARNESS			
					19C	L	TO CHASSIS HARNESS			
					20C	BG	TO CHASSIS HARNESS			
					21C	B	TO CHASSIS HARNESS			
					22C	SHIELD	TO CHASSIS HARNESS			
					23C	G/B	TO CHASSIS HARNESS			
					24C	G/Y	TO CHASSIS HARNESS			
					25C	W	TO CHASSIS HARNESS			
					26C	B	TO CHASSIS HARNESS			
					27C	LG	TO CHASSIS HARNESS			
					28C	G/W	TO CHASSIS HARNESS			
					29C	R/G	TO CHASSIS HARNESS - (WITHOUT BULB CHECK)			
					30C	R/L	TO CHASSIS HARNESS			
					31C	B	TO CHASSIS HARNESS			
					32C	R	TO CHASSIS HARNESS			
					33C	L/W	TO CHASSIS HARNESS			
					34C	L	TO CHASSIS HARNESS			
					35C	R/W	TO CHASSIS HARNESS			
					36C	L	TO CHASSIS HARNESS			
					37C	Y	TO CHASSIS HARNESS			
					38C	BR	TO CHASSIS HARNESS			
					39C	R	TO CHASSIS HARNESS			
					40C	P	TO CHASSIS HARNESS			
					41C	V	TO CHASSIS HARNESS			
					42C	G/B	TO CHASSIS HARNESS			
					43C	Y/B	TO CHASSIS HARNESS			
					44C	R	TO CHASSIS HARNESS			
					45C	G	TO CHASSIS HARNESS			
					46C	BR	TO CHASSIS HARNESS			
					47C	B	TO CHASSIS HARNESS			

AANIA5295GB

SONAR SYSTEM

< WIRING DIAGRAM >

SONAR SYSTEM CONNECTORS

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1F	Y	TO ENGINE CONTROL NO. 2 HARNESS	2F	U/R	TO ENGINE CONTROL NO. 2 HARNESS
2F	L/W	TO ENGINE CONTROL NO. 2 HARNESS	3F	R/L	TO ENGINE CONTROL NO. 2 HARNESS
3F	W/L	TO ENGINE CONTROL NO. 2 HARNESS	4F	W/R	TO ENGINE CONTROL NO. 2 HARNESS
5F	1F	TO ENGINE CONTROL NO. 2 HARNESS	25F	1F	TO ENGINE CONTROL NO. 2 HARNESS
11F	10F	TO ENGINE CONTROL NO. 2 HARNESS	26F	1F	TO ENGINE CONTROL NO. 2 HARNESS
47F	46F	TO ENGINE CONTROL NO. 2 HARNESS	27F	1F	TO ENGINE CONTROL NO. 2 HARNESS
52F	51F	TO ENGINE CONTROL NO. 2 HARNESS	28F	1F	TO ENGINE CONTROL NO. 2 HARNESS
41F	40F	TO ENGINE CONTROL NO. 2 HARNESS	29F	1F	TO ENGINE CONTROL NO. 2 HARNESS
47F	46F	TO ENGINE CONTROL NO. 2 HARNESS	30F	1F	TO ENGINE CONTROL NO. 2 HARNESS
52F	51F	TO ENGINE CONTROL NO. 2 HARNESS	31F	1F	TO ENGINE CONTROL NO. 2 HARNESS
32F	V/W	TO ENGINE CONTROL NO. 2 HARNESS	32F	V/W	TO ENGINE CONTROL NO. 2 HARNESS
1F	Y	TO ENGINE CONTROL NO. 2 HARNESS	33F	GR	TO ENGINE CONTROL NO. 2 HARNESS
2F	B	TO ENGINE CONTROL NO. 2 HARNESS	34F	U/R	TO ENGINE CONTROL NO. 2 HARNESS
3F	BR	TO ENGINE CONTROL NO. 2 HARNESS	35F	R/W	TO ENGINE CONTROL NO. 2 HARNESS
4F	W/R	TO ENGINE CONTROL NO. 2 HARNESS	36F	U/B	TO ENGINE CONTROL NO. 2 HARNESS
5F	BR	TO ENGINE CONTROL NO. 2 HARNESS	37F	L	TO ENGINE CONTROL NO. 2 HARNESS
6F	O	TO ENGINE CONTROL NO. 2 HARNESS	38F	R/Y	TO ENGINE CONTROL NO. 2 HARNESS
7F	GR/Y	TO ENGINE CONTROL NO. 2 HARNESS	39F	R/Y	TO ENGINE CONTROL NO. 2 HARNESS
8F	V	TO ENGINE CONTROL NO. 2 HARNESS	40F	B/R	TO ENGINE CONTROL NO. 2 HARNESS
9F	BR	TO ENGINE CONTROL NO. 2 HARNESS	41F	W	TO ENGINE CONTROL NO. 2 HARNESS
10F	Y/B	TO ENGINE CONTROL NO. 2 HARNESS	42F	Y	TO ENGINE CONTROL NO. 2 HARNESS
11F	L	TO ENGINE CONTROL NO. 2 HARNESS	43F	B/P	TO ENGINE CONTROL NO. 2 HARNESS
12F	R	TO ENGINE CONTROL NO. 2 HARNESS	44F	Y/B	TO ENGINE CONTROL NO. 2 HARNESS
13F	Y	TO ENGINE CONTROL NO. 2 HARNESS	45F	L/Y	TO ENGINE CONTROL NO. 2 HARNESS
14F	V	TO ENGINE CONTROL NO. 2 HARNESS	46F	O	TO ENGINE CONTROL NO. 2 HARNESS
15F	SB	TO ENGINE CONTROL NO. 2 HARNESS	47F	W/R	TO ENGINE CONTROL NO. 2 HARNESS
16F	P	TO ENGINE CONTROL NO. 2 HARNESS	48F	L	TO ENGINE CONTROL NO. 2 HARNESS
17F	Y/R	TO ENGINE CONTROL NO. 2 HARNESS	49F	BR	TO ENGINE CONTROL NO. 2 HARNESS
18F	R	TO ENGINE CONTROL NO. 2 HARNESS	50F	SHIELD	TO ENGINE CONTROL NO. 2 HARNESS
19F	V	TO ENGINE CONTROL NO. 2 HARNESS	51F	L	TO ENGINE CONTROL NO. 2 HARNESS
20F	BR	TO ENGINE CONTROL NO. 2 HARNESS			

AANIA5296GB

SONAR SYSTEM

< WIRING DIAGRAM >

SONAR SYSTEM CONNECTORS

Connector No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
FE152	WIRE TO WIRE	TO MAIN HARNESS	24G	G/B	TO MAIN HARNESS
		TO MAIN HARNESS	25G	R/W	TO MAIN HARNESS
		TO MAIN HARNESS	26G	R	TO MAIN HARNESS
		TO MAIN HARNESS	27G	LG	TO MAIN HARNESS
		TO MAIN HARNESS	28G	G/B	TO MAIN HARNESS
		TO MAIN HARNESS	29G	G/B	TO MAIN HARNESS
		TO MAIN HARNESS	30G	BR/Y	TO MAIN HARNESS
		TO MAIN HARNESS	31G	P	TO MAIN HARNESS - (WITH CUMMINS 5.0L)
		TO MAIN HARNESS - (WITH CUMMINS 5.0L)	32G	P	TO MAIN HARNESS
		TO MAIN HARNESS	33G	Y/L	TO MAIN HARNESS
		TO MAIN HARNESS	34G	GR	TO MAIN HARNESS
		TO MAIN HARNESS	35G	G/R	TO MAIN HARNESS
		TO MAIN HARNESS	36G	SB	TO MAIN HARNESS
		TO MAIN HARNESS	37G	R/W	TO MAIN HARNESS
		TO MAIN HARNESS	38G	BR	TO MAIN HARNESS
		TO MAIN HARNESS	39G	BR	TO MAIN HARNESS
		TO MAIN HARNESS	40G	—	TO MAIN HARNESS
		TO MAIN HARNESS	41G	R/G	TO MAIN HARNESS
		TO MAIN HARNESS	42G	O	TO MAIN HARNESS
		TO MAIN HARNESS - (WITH CUMMINS 5.0L)	43G	B	TO MAIN HARNESS - (WITH CUMMINS 5.0L)
		TO MAIN HARNESS - (WITH CUMMINS 5.0L)	43G	G	TO MAIN HARNESS - (WITH CUMMINS 5.0L)
		TO MAIN HARNESS	44G	R/Y	TO MAIN HARNESS
		TO MAIN HARNESS	45G	G	TO MAIN HARNESS
		TO MAIN HARNESS	46G	LG	TO MAIN HARNESS
		TO MAIN HARNESS	47G	R	TO MAIN HARNESS
		TO MAIN HARNESS	48G	W	TO MAIN HARNESS
		TO MAIN HARNESS	49G	—	TO MAIN HARNESS
		TO MAIN HARNESS	50G	BR	TO MAIN HARNESS
		TO MAIN HARNESS	51G	R	TO MAIN HARNESS
		TO MAIN HARNESS - (WITH CUMMINS 5.0L)	52G	L	TO MAIN HARNESS
		TO MAIN HARNESS - (WITH CUMMINS 5.0L)	53G	W	TO MAIN HARNESS
		TO MAIN HARNESS	54G	W	TO MAIN HARNESS
		TO MAIN HARNESS	55G	G	TO MAIN HARNESS
		TO MAIN HARNESS	56G	W	TO MAIN HARNESS
		TO MAIN HARNESS	57G	Y	TO MAIN HARNESS
		TO MAIN HARNESS	58G	BG	TO MAIN HARNESS
		TO MAIN HARNESS	59G	BG	TO MAIN HARNESS
		TO MAIN HARNESS	60G	BG	TO MAIN HARNESS
		TO MAIN HARNESS	61G	B	TO MAIN HARNESS
		TO MAIN HARNESS	62G	W	TO MAIN HARNESS
		TO MAIN HARNESS	63G	R	TO MAIN HARNESS
		TO MAIN HARNESS	64G	W/L	TO MAIN HARNESS
		TO MAIN HARNESS	65G	W/R	TO MAIN HARNESS
		TO MAIN HARNESS	66G	BG	TO MAIN HARNESS
		TO MAIN HARNESS	67G	BG	TO MAIN HARNESS
		TO MAIN HARNESS	68G	B	TO MAIN HARNESS
		TO MAIN HARNESS	69G	Y	TO MAIN HARNESS
		TO MAIN HARNESS	70G	L	TO MAIN HARNESS
		TO MAIN HARNESS	71G	R/W	TO MAIN HARNESS

AANIA5297GB


SONAR SYSTEM

< WIRING DIAGRAM >

SONAR SYSTEM CONNECTORS

Connector No.	E223
Connector Name	FRONT SONAR SENSOR LH INNER
Connector Type	RH03FB
Connector Color	BLACK
	

Terminal No.	Color of Wire	Signal Name
1	W	GROUND
2	W/R	SIGNAL
3	-	-



H.S.

Terminal No.	Color of Wire	Signal Name
1	W	GROUND
2	W/L	SIGNAL
3	-	-



H.S.

Terminal No.	Color of Wire	Signal Name
1	W	GROUND
2	W/R	SIGNAL
3	-	-

Connector No.	E224
Connector Name	FRONT SONAR SENSOR RH INNER
Connector Type	RH03FB
Connector Color	BLACK
	

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	W	GROUND	1	Y/R	VIGN
2	W/R	SIGNAL	2	P	BATT
3	-	-	3	L	CAN-H
			4	BR	K-LINE
			5	B	GND
			6	Y/R	VIGN
			7	R	REV LAMP RELAY
			8	P	CAN-L
			9	BR	STARTER RELAY
			10	B	
				GND	

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	W	GROUND	1	Y/R	VIGN
2	W/R	SIGNAL	2	P	BATT
3	-	-	3	L	CAN-H
			4	BR	K-LINE
			5	B	GND
			6	Y/R	VIGN
			7	R	REV LAMP RELAY
			8	P	CAN-L
			9	BR	STARTER RELAY
			10	B	
				GND	

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH
Connector Color	WHITE
	

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	W	GROUND	1	W	TO ENGINE ROOM HARNESS
2	W/L	SIGNAL	2	P	TO ENGINE ROOM HARNESS
3	-	-	3	SB	TO ENGINE ROOM HARNESS

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH
Connector Color	WHITE
	

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
12	10	9	5	4	3
11	10	9	8	7	6
20	19	18	17	16	15
21	22	23	13	14	13


SONAR SYSTEM

< WIRING DIAGRAM >

SONAR SYSTEM CONNECTORS

Connector No.	M212
Connector Name	TRANSMISSION RANGE SWITCH
Connector Type	HS10FB
Connector Color	BLACK
	

Terminal	Color of Wire	Signal Name
1	L/W	RANGE SIGNAL C
2	P	RANGE SIGNAL B
3	R/Y	IGNITION
4	GR	RANGE SIGNAL PA
5	Y/R	RANGE SIGNAL A
6	OR	BATTERY
7	R	REVERSE RELAY CONT
8	B/R	NP SW
9	B/Y	IGNITION RELAY
10	-	-



13P	R	BATTERY	22G	G/R	TO ENGINE ROOM HARNESS
14P	Y	BATTERY	23G	Y/R	TO ENGINE ROOM HARNESS
15P	Y/LG	BATTERY	24G	G/B	TO ENGINE ROOM HARNESS
16P	W	BLOWER FAN RELAY OUT	25G	R/W	TO ENGINE ROOM HARNESS
			26G	R	TO ENGINE ROOM HARNESS
			27G	LG	TO ENGINE ROOM HARNESS
			28G	G/B	TO ENGINE ROOM HARNESS
			29G	G/B	TO ENGINE ROOM HARNESS
			30G	B/Y	TO ENGINE ROOM HARNESS
			31G	R	TO ENGINE ROOM HARNESS
			32G	R	TO ENGINE ROOM HARNESS
			33G	Y/L	TO ENGINE ROOM HARNESS
			34G	GR	TO ENGINE ROOM HARNESS
			35G	G/R	TO ENGINE ROOM HARNESS
			36G	SB	TO ENGINE ROOM HARNESS
			37G	R/W	TO ENGINE ROOM HARNESS
			38G	BR	TO ENGINE ROOM HARNESS
			39G	BR	TO ENGINE ROOM HARNESS
			40G	-	TO ENGINE ROOM HARNESS
			41G	R/G	TO ENGINE ROOM HARNESS
			42G	O	TO ENGINE ROOM HARNESS
			43G	G	TO ENGINE ROOM HARNESS
			44G	R/Y	TO ENGINE ROOM HARNESS
			45G	G	TO ENGINE ROOM HARNESS
			46G	LG	TO ENGINE ROOM HARNESS
			47G	R	TO ENGINE ROOM HARNESS
			48G	W	TO ENGINE ROOM HARNESS
			49G	-	TO ENGINE ROOM HARNESS
			50G	BR	TO ENGINE ROOM HARNESS
			51G	R	TO ENGINE ROOM HARNESS
			52G	L	TO ENGINE ROOM HARNESS
			53G	W	TO ENGINE ROOM HARNESS
			54G	G	TO ENGINE ROOM HARNESS
			55G	W	TO ENGINE ROOM HARNESS
			56G	Y	TO ENGINE ROOM HARNESS
			57G	B/G	TO ENGINE ROOM HARNESS
			58G	B/G	TO ENGINE ROOM HARNESS
			59G	B/G	TO ENGINE ROOM HARNESS
			60G	B/G	TO ENGINE ROOM HARNESS
			61G	O	TO ENGINE ROOM HARNESS
			62G	W	TO ENGINE ROOM HARNESS
			63G	O	TO ENGINE ROOM HARNESS
			64G	W/L	TO ENGINE ROOM HARNESS
			65G	W/R	TO ENGINE ROOM HARNESS
			66G	B/G	TO ENGINE ROOM HARNESS
			67G	O	TO ENGINE ROOM HARNESS
			68G	B	TO ENGINE ROOM HARNESS
			69G	Y	TO ENGINE ROOM HARNESS
			70G	L	TO ENGINE ROOM HARNESS
			71G	R/W	TO ENGINE ROOM HARNESS
			72G	L/W	TO ENGINE ROOM HARNESS
			73G	SHIELD	TO ENGINE ROOM HARNESS
			74G	W	TO ENGINE ROOM HARNESS

SONAR SYSTEM

< WIRING DIAGRAM >

SONAR SYSTEM CONNECTORS


Connector No.	M70
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FBR-CS
Connector Color	BROWN



Connector No.	M114
Connector Name	SONAR CONTROL UNIT
Connector Type	TH24FW-NH
Connector Color	WHITE




Connector No.	M128
Connector Name	ADAS CONTROL UNIT
Connector Type	TH24FW-NH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1R	L	TAIL LAMP 2	1	W/L	FRONT INNER RIGHT SENSOR SIGNAL
2R	Q/R	IGNITION	2	W/R	FRONT INNER LEFT SENSOR SIGNAL
3R	Y/R	BATTERY	3	O	FRONT OUTER LEFT SENSOR SIGNAL
4R	-	-	4	B/G	FRONT OUTER RIGHT SENSOR SIGNAL
5R	W	BATTERY	5	L	CAN-H
6R	Q/W	ACCESSORY	6	R	CAN-L
7R	-	-	7	-	-
8R	-	-	8	-	-
9R	-	-	9	L	REAR INNER RIGHT SENSOR SIGNAL
10R	W	BATTERY	10	O	REAR OUTER RIGHT SENSOR SIGNAL
11R	-	-	11	-	-
12R	B/G	BATTERY	12	G/R	IGN
13R	B	ACCESSORY			
14R	G/Y	BATTERY			
15R	Y	BATTERY			
16R	G/B	ACCESSORY			



Terminal No.	Color of Wire	Signal Name
1	L	ILLUMINATION +
2	-	
3	BR	IND -(WITH DRIVER ASSISTANCE)
3	B	IND -(WITHOUT DRIVER ASSISTANCE)
4	GR	ILLUMINATION -
5	G	IND -(WITH DRIVER ASSISTANCE)
5	GB	IND +(WITHOUT DRIVER ASSISTANCE)
6	G	BACKUP ECU
7	-	
8	B	GND



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	L	ITSCAN-H
3	G	IGN
4	GR	BUZZER OUTPUT
5	R	ITSCAN-L
6	R	CAN-L
7	GR	SIM/LED
8	-	-
9	L	CAN-H
10	P	CAN-L
11	G	N.C.
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	BR	N.C.
18	L	CAN-H
19	-	-
20	-	-
21	-	-
22	-	-
23	LG	BSW SW
24	-	-



SONAR SYSTEM

< WIRING DIAGRAM >

SONAR SYSTEM CONNECTORS

Connector No.	M191
Connector Name	JOINT CONNECTOR-M01
Connector Type	NH24FW-J
Connector Color	WHITE

H.S.

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	-	-	1	B	GROUND
2	B	GND	2	B	GND
3	B	GND	3	B	GROUND
4	B	GROUND	4	-	-
5	-	-	5	B	GROUND
6	B	GND	6	B	GND
7	B	GND	7	B	GROUND
8	B	GND	8	B	GROUND
9	-	-	9	B	GROUND
10	B	GND	10	B	GND
11	B	GND	11	B	GROUND
12	B	GND	12	B	GND
13	B	GND	13	-	-
14	B	GND	14	B	GND
15	B	GND	15	B	GROUND
16	-	-	16	B	GND
17	B	GND	17	-	-
18	B	GND	18	SHIELD	SHIELD
19	SHIELD	GROUND	19	SHIELD	SHIELD
20	B	GND	20	SHIELD	SHIELD
21	B	GND	21	B	GND
22	B	GND	22	B	GND
23	B	GROUND	23	B	GROUND
24	B	GROUND	24	B	GROUND

AANIA5301GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000014386742

OVERALL SEQUENCE



JSNIA4482GB

Reference 1: Refer to [SN-11, "CONSULT Function"](#).

Reference 2: Refer to [SN-18, "DTC Index"](#).

Reference 3: Refer to [SN-62, "Symptom Table"](#).

DETAILED FLOW

1. INTERVIEW AND SYMPTOM CONFIRMATION

Check the malfunction symptoms by performing the following items.

- Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred).
- Check the symptom.

Is the occurred symptom malfunction?

YES >> GO TO 2.

NO >> Inspection End.

2. DIAGNOSIS WITH CONSULT

1. Connect CONSULT and perform Self Diagnostic Result for SONAR. Refer to [SN-11, "CONSULT Function"](#).

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

NOTE:

Skip to step 4 of the diagnosis procedure if SONAR is not displayed.

2. When DTC is detected, follow the instructions below:
 - Record DTC and Freeze Frame Data.

Is DTC displayed?

YES >> GO TO 3.

NO >> GO TO 4.

3. TROUBLE DIAGNOSIS FOR DTC

1. Check the DTC indicated in the self-diagnosis results.
2. Perform the relevant diagnosis referring to the DTC Index. Refer to [SN-18, "DTC Index"](#).

>> GO TO 5.

4. TROUBLE DIAGNOSIS FOR SYMPTOMS

Perform the relevant diagnosis referring to the diagnosis chart by symptom. Refer to [SN-62, "Symptom Table"](#).

>> GO TO 5.

5. ERROR PART REPAIR

1. Repair or replace the identified malfunctioning parts.
2. Perform Self Diagnostic Result for SONAR with CONSULT.

NOTE:

Erase the stored self-diagnosis results after repairing or replacing the relevant components if any DTC has been indicated in the self-diagnosis results.

3. Check that the symptom does not occur.

Does the symptom occur?

YES >> GO TO 1.

NO >> Inspection End.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT : Description

INFOID:000000014386743

BEFORE REPLACEMENT

When replacing sonar control unit, save or print current vehicle specification with CONSULT configuration before replacement.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing sonar control unit.

AFTER REPLACEMENT

CAUTION:

When replacing sonar control unit, you must perform "After Replace ECU" with CONSULT.

- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.

ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT : Work Procedure

INFOID:000000014386744

1. SAVING VEHICLE SPECIFICATION

① CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing sonar control unit.

>> GO TO 2.

2. REPLACE SONAR CONTROL UNIT

Replace sonar control unit. Refer to [SN-66, "Removal and Installation"](#).

>> GO TO 3.

3. WRITING VEHICLE SPECIFICATION

② CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, an "Operation Log Selection" screen will automatically be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [SN-32, "CONFIGURATION \(SONAR CONTROL UNIT\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [SN-32, "CONFIGURATION \(SONAR CONTROL UNIT\) : Work Procedure"](#).

>> GO TO 4.

4. OPERATION CHECK

Check that the operation of the sonar control unit is normal.

>> Work End.

CONFIGURATION (SONAR CONTROL UNIT)

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

CONFIGURATION (SONAR CONTROL UNIT) : Description

INFOID:000000014386745

Vehicle specification needs to be written with CONSULT. Configuration has three functions as follows:

Function	Description
"Before Replace ECU"	<ul style="list-style-type: none">• Reads the vehicle configuration of current sonar control unit.• Saves the read vehicle configuration.
"After Replace ECU"	Writes the vehicle configuration with manual selection.
"Select Saved Data List"	Writes the vehicle configuration with saved data.

CAUTION:

- When replacing sonar control unit, you must perform "Select Saved Data List" or "After Replace ECU" with CONSULT.
- Complete the procedure of "Select Saved Data List" or "After Replace ECU" in order.
- If you set incorrect "Select Saved Data List" or "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Select Saved Data List" or "After Replace ECU" except for new sonar control unit.

CONFIGURATION (SONAR CONTROL UNIT) : Work Procedure

INFOID:000000014386746

1. WRITING MODE SELECTION

① CONSULT

Select "Reprogramming, Configuration" of sonar control unit.

When writing saved data>>GO TO 2.

When writing manually>>GO TO 3.

2. PERFORM "SAVED DATA LIST"

② CONSULT

Automatically "Operation Log Selection" window will display if "Before Replace ECU" was performed. Select applicable file from the "Save Data List" and press "Confirm".

>> Work End.

3. PERFORM "AFTER REPLACE ECU" OR "MANUAL CONFIGURATION"

③ CONSULT

1. Select "After Replace ECU" or "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [SN-33. "CONFIGURATION \(SONAR CONTROL UNIT\) : Configuration List"](#).
3. Confirm and/or change setting value for each item.

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

4. Select "Next".

CAUTION:

Make sure to select "Next", confirm each setting value and press "OK" even if the indicated configuration of brand new sonar control unit is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model can not be memorized.

5. When "Completed", select "End".

>> GO TO 4.

4. OPERATION CHECK

Confirm that each function controlled by sonar control unit operates normally.

>> Work End.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

CONFIGURATION (SONAR CONTROL UNIT) : Configuration List

INFOID:000000014386747

CAUTION:

Thoroughly read and understand the vehicle specification. Incorrect settings may result in abnormal control of ECU.

MANUAL SETTING ITEM

Items	Setting value
Fr Bumper Sonar	MODE 1 ⇔ MODE 2
BSW	WITH ⇔ WITHOUT
AVM	WITH ⇔ WITHOUT

⇒: Items which confirm vehicle specifications

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

DTC Description

INFOID:000000014386748

DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN high, CAN low) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-74, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
U1000	CAN COMM CIRCUIT (CAN COMM CIRCUIT)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	—

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

- When communication with the ABS actuator and electric unit (control unit) is lost, the front sonar system is OFF and rear sonar systems is ON (shift selector in reverse).
- When communication with the TCU is lost, front and rear sonar systems are OFF.

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC U1000 detected?

YES >> Proceed to [SN-34, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014386749

1. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

④ CONSULT

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC U1000 detected?

YES >> Perform the trouble diagnosis for CAN communication system. Refer to [LAN-53, "Trouble Diagnosis Flow Chart"](#).

NO >> Inspection End.

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

DTC Description

INFOID:000000014386750

DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN high, CAN low) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-74, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart".](#)

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
		Diagnosis condition	When ignition switch is ON.
U1010	CONTROL UNIT(CAN) [Control unit (CAN)]	Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	—

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

—

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

 CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC U1010 detected?

YES >> Proceed to [SN-35, "Diagnosis Procedure".](#)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident".](#)

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014386751

1. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

 CONSULT

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC U1010 detected?

YES >> Replace sonar control unit. Refer to [SN-66, "Removal and Installation".](#)

NO >> Inspection End.

SN

O

P

B2720 CORNER SENSOR [RL]

< DTC/CIRCUIT DIAGNOSIS >

B2720 CORNER SENSOR [RL]

DTC Description

INFOID:0000000014386752

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B2720	Rear left side external sensor (Rear sonar sensor LH outer)	1	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Rear outer left sensor signal (terminal 22) Threshold Rear outer left sensor signal circuit is open or short to ground Diagnosis delay time —
		2	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Rear outer left sensor signal (terminal 22) Threshold Rear outer left sensor signal circuit is short to voltage Diagnosis delay time —
		3	Diagnosis condition When ignition switch is ON and power supply voltage is 9.5V – 16.5V. Signal (terminal) Rear outer left sensor signal (terminal 22) Threshold Rear sonar sensor LH outer element malfunction Diagnosis delay time —

POSSIBLE CAUSE

- Harness or connectors
- Rear sonar sensor LH outer

FAIL-SAFE

- Obstacle detection of rear sonar sensor LH outer is stopped
- Audible warning (front sonar buzzer) of all sensors is stopped
- Front sonar buzzer sounds for 3 seconds

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B2720 detected?

YES >> Refer to [SN-36, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000014386753

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

1. CHECK REAR OUTER LEFT SENSOR SIGNAL CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.

B2720 CORNER SENSOR [RL]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect sonar control unit and rear sonar sensor LH outer connectors.
3. Check continuity between sonar control unit connector M114 and rear sonar sensor LH outer connector C114.

Sonar control unit		Rear sonar sensor LH outer		Continuity
Connector	Terminal	Connector	Terminal	
M114	22	C114	2	Yes

4. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	22	(-)	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2. CHECK REAR OUTER LEFT SENSOR SIGNAL CIRCUIT FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M114	22	(-)	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK REAR SENSOR GROUND CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M114 and rear sonar sensor LH outer connector C114.

Sonar control unit		Rear sonar sensor LH outer		Continuity
Connector	Terminal	Connector	Terminal	
M114	14	C114	1	Yes

Is the inspection result normal?

YES >> Replace rear sonar sensor LH outer. Refer to [SN-64, "Removal and Installation - Rear Sonar Sensors".](#)

NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

B2721 CENTER SENSOR [RL]

< DTC/CIRCUIT DIAGNOSIS >

B2721 CENTER SENSOR [RL]

DTC Description

INFOID:0000000014386754

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B2721	Rear left side internal sensor (Rear sonar sensor LH inner)	1	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Rear inner left sensor signal (terminal 21) Threshold Rear inner left sensor signal circuit is open or short to ground Diagnosis delay time —
		2	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Rear inner left sensor signal (terminal 21) Threshold Rear inner left sensor signal circuit is short to voltage Diagnosis delay time —
		3	Diagnosis condition When ignition switch is ON and power supply voltage is 9.5V – 16.5V. Signal (terminal) Rear inner left sensor signal (terminal 21) Threshold Rear sonar sensor LH inner element malfunction Diagnosis delay time —

POSSIBLE CAUSE

- Harness or connectors
- Rear sonar sensor LH inner

FAIL-SAFE

- Obstacle detection of rear sonar sensor LH inner is stopped
- Audible warning (front sonar buzzer) of all sensors is stopped
- Front sonar buzzer sounds for 3 seconds

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B2721 detected?

YES >> Refer to [SN-38, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000014386755

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

1.CHECK REAR INNER LEFT SENSOR SIGNAL CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.

B2721 CENTER SENSOR [RL]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect sonar control unit and rear sonar sensor LH inner connectors.
3. Check continuity between sonar control unit connector M114 and rear sonar sensor LH inner connector C113.

Sonar control unit		Rear sonar sensor LH inner		Continuity
Connector	Terminal	Connector	Terminal	
M114	21	C113	2	Yes

4. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	21	(-)	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2.CHECK REAR INNER LEFT SENSOR SIGNAL CIRCUIT FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M114	21	(-)	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK REAR SENSOR GROUND CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M114 and rear sonar sensor LH inner connector C113.

Sonar control unit		Rear sonar sensor LH inner		Continuity
Connector	Terminal	Connector	Terminal	
M114	14	C113	1	Yes

Is the inspection result normal?

YES >> Replace rear sonar sensor LH inner. Refer to [SN-64, "Removal and Installation - Rear Sonar Sensors".](#)

NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

B2722 CENTER SENSOR [RR]

< DTC/CIRCUIT DIAGNOSIS >

B2722 CENTER SENSOR [RR]

DTC Description

INFOID:0000000014386756

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B2722	Rear right side internal sensor (Rear sonar sensor RH inner)	1	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Rear inner right sensor signal (terminal 9) Threshold Rear inner right sensor signal circuit is open or short to ground Diagnosis delay time —
		2	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Rear inner right sensor signal (terminal 9) Threshold Rear inner right sensor signal circuit is short to voltage Diagnosis delay time —
		3	Diagnosis condition When ignition switch is ON and power supply voltage is 9.5V – 16.5V. Signal (terminal) Rear inner right sensor signal (terminal 9) Threshold Rear sonar sensor RH inner element malfunction Diagnosis delay time —

POSSIBLE CAUSE

- Harness or connectors
- Rear sonar sensor RH inner

FAIL-SAFE

- Obstacle detection of rear sonar sensor RH inner is stopped
- Audible warning (front sonar buzzer) of all sensors is stopped
- Front sonar buzzer sounds for 3 seconds

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B2722 detected?

YES >> Refer to [SN-40, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000014386757

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

1. CHECK REAR INNER RIGHT SENSOR SIGNAL CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.

B2722 CENTER SENSOR [RR]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect sonar control unit and rear sonar sensor RH inner connectors.
3. Check continuity between sonar control unit connector M114 and rear sonar sensor RH inner connector C112.

A

Sonar control unit		Rear sonar sensor RH inner		Continuity
Connector	Terminal	Connector	Terminal	
M114	9	C112	2	Yes

B

C

4. Check continuity between sonar control unit connector M114 and ground.

D

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	9	(-)	No

E

Is the inspection result normal?

F

G

H

YES >> GO TO 2.
NO >> Repair or replace harness or connectors.

I

2. CHECK REAR INNER RIGHT SENSOR SIGNAL CIRCUIT FOR SHORT TO VOLTAGE

J

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

K

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M114	9	(-)	0V

L

Is the inspection result normal?

M

SN

YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

O

3. CHECK REAR SENSOR GROUND CIRCUIT FOR OPEN

P

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M114 and rear sonar sensor RH inner connector C112.

Sonar control unit		Rear sonar sensor RH inner		Continuity
Connector	Terminal	Connector	Terminal	
M114	14	C112	1	Yes

Is the inspection result normal?

SN

SN

YES >> Replace rear sonar sensor RH inner. Refer to [SN-64, "Removal and Installation - Rear Sonar Sensors".](#)
NO >> Repair or replace harness or connectors.

B2723 CORNER SENSOR [RR]

< DTC/CIRCUIT DIAGNOSIS >

B2723 CORNER SENSOR [RR]

DTC Description

INFOID:000000014386758

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B2723	Rear right side external sensor (Rear sonar sensor RH outer)	1	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V.
		1	Signal (terminal) Rear outer right sensor signal (terminal 10)
		1	Threshold Rear outer right sensor signal circuit is open or short to ground
		1	Diagnosis delay time —
		2	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V.
		2	Signal (terminal) Rear outer right sensor signal (terminal 10)
		2	Threshold Rear outer right sensor signal circuit is short to voltage
		2	Diagnosis delay time —
		3	Diagnosis condition When ignition switch is ON and power supply voltage is 9.5V – 16.5V.
		3	Signal (terminal) Rear outer right sensor signal (terminal 10)
		3	Threshold Rear sonar sensor RH outer element malfunction
		3	Diagnosis delay time —

POSSIBLE CAUSE

- Harness or connectors
- Rear sonar sensor RH outer

FAIL-SAFE

- Obstacle detection of rear sonar sensor RH outer is stopped
- Audible warning (front sonar buzzer) of all sensors is stopped
- Front sonar buzzer sounds for 3 seconds

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

④ CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B2723 detected?

YES >> Refer to [SN-42, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014386759

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

B2723 CORNER SENSOR [RR]

< DTC/CIRCUIT DIAGNOSIS >

1. CHECK REAR OUTER RIGHT SENSOR SIGNAL CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.
2. Disconnect sonar control unit and rear sonar sensor RH outer connectors.
3. Check continuity between sonar control unit connector M114 and rear sonar sensor RH outer connector C111.

Sonar control unit		Rear sonar sensor RH outer		Continuity
Connector	Terminal	Connector	Terminal	
M114	10	C111	2	Yes

4. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	10	(-)	No

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace harness or connectors.

2. CHECK REAR OUTER RIGHT SENSOR SIGNAL CIRCUIT FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M114	10	(-)	0V

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

3. CHECK REAR SENSOR GROUND CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M114 and rear sonar sensor RH outer connector C111.

Sonar control unit		Rear sonar sensor RH outer		Continuity
Connector	Terminal	Connector	Terminal	
M114	14	C111	1	Yes

Is the inspection result normal?

YES >> Replace rear sonar sensor RH outer. Refer to [SN-64, "Removal and Installation - Rear Sonar Sensors"](#).
NO >> Repair or replace harness or connectors.

SN

O

P

B2724 SONAR CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

B2724 SONAR CONTROL UNIT

DTC Description

INFOID:0000000014386760

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B2724	ECU (Sonar control unit configuration)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	—
		Threshold	—
		Diagnosis delay time	—

POSSIBLE CAUSE

- Sonar control unit configuration
- Sonar control unit

FAIL-SAFE

- Off indicator blinks periodically (500ms ON, 500ms OFF)
- Front sonar buzzer sounds for 3 seconds

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B2724 detected?

YES >> Refer to [SN-44, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000014386761

1.PERFORM SONAR CONTROL UNIT CONFIGURATION PROCEDURE

CONSULT

Perform the sonar control unit configuration procedure. Refer to [SN-32, "CONFIGURATION \(SONAR CONTROL UNIT\) : Work Procedure"](#).

Was the configuration procedure successful?

YES >> GO TO 2.

NO >> Replace sonar control unit. Refer to [SN-66, "Removal and Installation"](#).

2.DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON.
2. Erase DTCs.
3. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B2724 detected?

YES >> Replace sonar control unit. Refer to [SN-66, "Removal and Installation"](#).

NO >> Inspection End.

< DTC/CIRCUIT DIAGNOSIS >

B2728 LED**DTC Description**

INFOID:000000014386762

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B2728	Led (Sonar system off switch)	1	Diagnosis condition When ignition switch is ON. Signal (terminal) Status LED circuit (terminal 17) Threshold Status LED circuit is short to ground Diagnosis delay time —
		2	Diagnosis condition When ignition switch is ON. Signal (terminal) Status LED circuit (terminal 17) Threshold Status LED circuit is short to voltage Diagnosis delay time —
		3	Diagnosis condition When ignition switch is ON. Signal (terminal) Status LED circuit (terminal 17) Threshold Status LED circuit is open Diagnosis delay time —

POSSIBLE CAUSE

- Harness or connectors
- Sonar system off switch

FAIL-SAFE

- Audible warning (front sonar buzzer) of all sensors is stopped
- Front sonar buzzer sounds for 3 seconds

DTC CONFIRMATION PROCEDURE**1.DTC CONFIRMATION PROCEDURE** **CONSULT**

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B2728 detected?YES >> Refer to [SN-45, "Diagnosis Procedure"](#).NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014386763

SNRegarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).**1.CHECK STATUS LED CIRCUIT FOR SHORT TO GROUND**

1. Turn ignition switch OFF.
2. Disconnect sonar control unit and sonar system off switch connectors.
3. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	17	(-)	No

B2728 LED

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2.CHECK STATUS LED CIRCUIT FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M114	17	(-)	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK STATUS LED CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M114 and sonar system off switch connector M117.

Sonar control unit		Sonar system off switch		Continuity
Connector	Terminal	Connector	Terminal	
M114	17	M117	5	Yes

Is the inspection result normal?

YES >> Replace sonar system off switch. Refer to [IP-20, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

B2729 CORNER SENSOR [FL]

< DTC/CIRCUIT DIAGNOSIS >

B2729 CORNER SENSOR [FL]

DTC Description

INFOID:000000014386764

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B2729	Front left side external sensor (Front sonar sensor LH outer)	1	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Front outer left sensor signal (terminal 3) Threshold Front outer left sensor signal circuit is open or short to ground Diagnosis delay time —
		2	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Front outer left sensor signal (terminal 3) Threshold Front outer left sensor signal circuit is short to voltage Diagnosis delay time —
		3	Diagnosis condition When ignition switch is ON and power supply voltage is 9.5V – 16.5V. Signal (terminal) Front outer left sensor signal (terminal 3) Threshold Front sonar sensor LH outer element malfunction Diagnosis delay time —

POSSIBLE CAUSE

- Harness or connectors
- Front sonar sensor LH outer

FAIL-SAFE

- Obstacle detection of front sonar sensor LH outer is stopped
- Audible warning (front sonar buzzer) of all sensors is stopped
- Front sonar buzzer sounds for 3 seconds

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B2729 detected?

YES >> Refer to [SN-47, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014386765

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

1.CHECK FRONT OUTER LEFT SENSOR SIGNAL CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.

B2729 CORNER SENSOR [FL]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect sonar control unit and front sonar sensor LH outer connectors.
3. Check continuity between sonar control unit connector M114 and front sonar sensor LH outer connector E221.

Sonar control unit		Front sonar sensor LH outer		Continuity
Connector	Terminal	Connector	Terminal	
M114	3	E221	2	Yes

4. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	3	(-)	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2. CHECK FRONT OUTER LEFT SENSOR SIGNAL CIRCUIT FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M114	3	(-)	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK FRONT SENSOR GROUND CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M114 and front sonar sensor LH outer connector E221.

Sonar control unit		Front sonar sensor LH outer		Continuity
Connector	Terminal	Connector	Terminal	
M114	13	E221	1	Yes

Is the inspection result normal?

YES >> Replace front sonar sensor LH outer. Refer to [SN-63, "Removal and Installation - Front Sonar Sensors"](#).

NO >> Repair or replace harness or connectors.

B272A CENTER SENSOR [FL]

< DTC/CIRCUIT DIAGNOSIS >

B272A CENTER SENSOR [FL]

DTC Description

INFOID:000000014386766

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B272A	Front left side internal sensor (Front sonar sensor LH inner)	1	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Front inner left sensor signal (terminal 2) Threshold Front inner left sensor signal circuit is open or short to ground Diagnosis delay time —
		2	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Front inner left sensor signal (terminal 2) Threshold Front inner left sensor signal circuit is short to voltage Diagnosis delay time —
		3	Diagnosis condition When ignition switch is ON and power supply voltage is 9.5V – 16.5V. Signal (terminal) Front inner left sensor signal (terminal 2) Threshold Front sonar sensor LH inner element malfunction Diagnosis delay time —

POSSIBLE CAUSE

- Harness or connectors
- Front sonar sensor LH inner

FAIL-SAFE

- Obstacle detection of front sonar sensor LH inner is stopped
- Audible warning (front sonar buzzer) of all sensors is stopped
- Front sonar buzzer sounds for 3 seconds

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B272A detected?

YES >> Refer to [SN-49, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014386767

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

1.CHECK FRONT INNER LEFT SENSOR SIGNAL CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.

B272A CENTER SENSOR [FL]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect sonar control unit and front sonar sensor LH inner connectors.
3. Check continuity between sonar control unit connector M114 and front sonar sensor LH inner connector E223.

Sonar control unit		Front sonar sensor LH inner		Continuity
Connector	Terminal	Connector	Terminal	
M114	2	E223	2	Yes

4. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	2	(-)	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2.CHECK FRONT INNER LEFT SENSOR SIGNAL CIRCUIT FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M114	2	(-)	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK FRONT SENSOR GROUND CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M114 and front sonar sensor LH inner connector E223.

Sonar control unit		Front sonar sensor LH inner		Continuity
Connector	Terminal	Connector	Terminal	
M114	13	E223	1	Yes

Is the inspection result normal?

YES >> Replace front sonar sensor LH inner. Refer to [SN-63. "Removal and Installation - Front Sonar Sensors"](#).

NO >> Repair or replace harness or connectors.

B272B CENTER SENSOR [FR]

< DTC/CIRCUIT DIAGNOSIS >

B272B CENTER SENSOR [FR]

DTC Description

INFOID:000000014386768

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B272B	Front right side internal sensor (Front sonar sensor RH inner)	1	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Front inner right sensor signal (terminal 1) Threshold Front inner right sensor signal circuit is open or short to ground Diagnosis delay time —
		2	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V. Signal (terminal) Front inner right sensor signal (terminal 1) Threshold Front inner right sensor signal circuit is short to voltage Diagnosis delay time —
		3	Diagnosis condition When ignition switch is ON and power supply voltage is 9.5V – 16.5V. Signal (terminal) Front inner right sensor signal (terminal 1) Threshold Front sonar sensor RH inner element malfunction Diagnosis delay time —

POSSIBLE CAUSE

- Harness or connectors
- Front sonar sensor RH inner

FAIL-SAFE

- Obstacle detection of front sonar sensor RH inner is stopped
- Audible warning (front sonar buzzer) of all sensors is stopped
- Front sonar buzzer sounds for 3 seconds

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B272B detected?

YES >> Refer to [SN-51, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014386769

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

1.CHECK FRONT INNER RIGHT SENSOR SIGNAL CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.

B272B CENTER SENSOR [FR]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect sonar control unit and front sonar sensor RH inner connectors.
3. Check continuity between sonar control unit connector M114 and front sonar sensor RH inner connector E224.

Sonar control unit		Front sonar sensor RH inner		Continuity
Connector	Terminal	Connector	Terminal	
M114	1	E224	2	Yes

4. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	1	(-)	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2. CHECK FRONT INNER RIGHT SENSOR SIGNAL CIRCUIT FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M114	1	(-)	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK FRONT SENSOR GROUND CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M114 and front sonar sensor RH inner connector E224.

Sonar control unit		Front sonar sensor RH inner		Continuity
Connector	Terminal	Connector	Terminal	
M114	13	E224	1	Yes

Is the inspection result normal?

YES >> Replace front sonar sensor RH inner. Refer to [SN-63, "Removal and Installation - Front Sonar Sensors"](#).

NO >> Repair or replace harness or connectors.

B272C CORNER SENSOR [FR]

< DTC/CIRCUIT DIAGNOSIS >

B272C CORNER SENSOR [FR]

DTC Description

INFOID:000000014386770

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B272C	Front right side external sensor (Front sonar sensor RH outer)	1	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V.
		1	Signal (terminal) Front outer right sensor signal (terminal 4)
		1	Threshold Front outer right sensor signal circuit is open or short to ground
		1	Diagnosis delay time —
		2	Diagnosis condition When ignition switch is ON and power supply voltage is 8.5V – 16.5V.
		2	Signal (terminal) Front outer right sensor signal (terminal 4)
		2	Threshold Front outer right sensor signal circuit is short to voltage
		2	Diagnosis delay time —
		3	Diagnosis condition When ignition switch is ON and power supply voltage is 9.5V – 16.5V.
		3	Signal (terminal) Front outer right sensor signal (terminal 4)
		3	Threshold Front sonar sensor RH outer element malfunction
		3	Diagnosis delay time —

POSSIBLE CAUSE

- Harness or connectors
- Front sonar sensor RH outer

FAIL-SAFE

- Obstacle detection of front sonar sensor RH outer is stopped
- Audible warning (front sonar buzzer) of all sensors is stopped
- Front sonar buzzer sounds for 3 seconds

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION PROCEDURE

CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

SN

Is DTC B272C detected?

YES >> Refer to [SN-53, "Diagnosis Procedure"](#).

O

NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).

P

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014386771

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

B272C CORNER SENSOR [FR]

< DTC/CIRCUIT DIAGNOSIS >

1. CHECK FRONT OUTER RIGHT SENSOR SIGNAL CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.
2. Disconnect sonar control unit and front sonar sensor RH outer connectors.
3. Check continuity between sonar control unit connector M114 and front sonar sensor RH outer connector E222.

Sonar control unit		Front sonar sensor RH outer		Continuity
Connector	Terminal	Connector	Terminal	
M114	4	E222	2	Yes

4. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	4	(-)	No

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace harness or connectors.

2. CHECK FRONT OUTER RIGHT SENSOR SIGNAL CIRCUIT FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M114	4	(-)	0V

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

3. CHECK FRONT SENSOR GROUND CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M114 and front sonar sensor RH outer connector E221.

Sonar control unit		Front sonar sensor RH outer		Continuity
Connector	Terminal	Connector	Terminal	
M114	13	E222	1	Yes

Is the inspection result normal?

YES >> Replace front sonar sensor RH outer. Refer to [SN-63, "Removal and Installation - Front Sonar Sensors".](#)
NO >> Repair or replace harness or connectors.

B272D FRONT BUZZER

< DTC/CIRCUIT DIAGNOSIS >

B272D FRONT BUZZER

DTC Description

INFOID:000000014386772

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	
B272D	Front buzzer (Front sonar buzzer)	Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	<ul style="list-style-type: none"> • Speaker power circuit (terminal 19) • Speaker signal (terminal 18)
		Threshold	<ul style="list-style-type: none"> • Speaker power circuit is open or short to ground • Speaker signal circuit is open or short to ground
		Diagnosis delay time	—
		Diagnosis condition	When ignition switch is ON.
		Signal (terminal)	<ul style="list-style-type: none"> • Speaker power circuit (terminal 19) • Speaker signal (terminal 18)
		Threshold	<ul style="list-style-type: none"> • Speaker power circuit is short to voltage • Speaker signal circuit is short to voltage
		Diagnosis delay time	—

POSSIBLE CAUSE

- Harness or connectors
- Front sonar buzzer

FAIL-SAFE

- Off indicator blinks periodically (500ms ON, 500ms OFF)
- Audible warning (front sonar buzzer) of all sensors is stopped

DTC CONFIRMATION PROCEDURE

1.DTC CONFIRMATION PROCEDURE

①CONSULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" mode of "SONAR".

Is DTC B272D detected?

YES >> Refer to [SN-55](#).
 NO-1 >> To check malfunction symptom before repair: Refer to [GI-47, "Intermittent Incident"](#).
 NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000014386773

SN

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

1.CHECK FRONT SONAR BUZZER SIGNAL CIRCUIT OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.
2. Disconnect sonar control unit and front sonar buzzer connectors.
3. Check continuity between sonar control unit connector M114 and front sonar buzzer connector M116.

Sonar control unit		Front sonar buzzer		Continuity
Connector	Terminal	Connector	Terminal	

B272D FRONT BUZZER

< DTC/CIRCUIT DIAGNOSIS >

M114	18	M116	3	Yes
	19		2	

4. Check continuity between sonar control unit connector M70 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	18	(-)	No
	19		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2.CHECK FRONT SONAR BUZZER SIGNAL CIRCUIT SHORT TO BATTERY

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M114	18	(-)	0V
	19		

Is the inspection result normal?

YES >> Replace front sonar buzzer. Refer to [SN-67, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000014386774

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

1. CHECK FUSE

Check that the following fuse is not blown:

Terminal No.	Signal name	Fuse No.
12	IGN power supply	29 (5A)

Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector.
3. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M114	12	(-)	Ignition switch: ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	15	(-)	Yes

Is the inspection result normal?

YES >> Inspection End.
NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

SONAR SYSTEM OFF SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

SONAR SYSTEM OFF SWITCH CIRCUIT

Diagnosis Procedure

INFOID:0000000014386775

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

WITH DRIVER ASSISTANCE SYSTEM

1. CHECK SONAR SYSTEM OFF SWITCH INPUT CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.
2. Disconnect ADAS control unit and sonar system off switch connectors.
3. Check continuity between ADAS control unit connector M128 and sonar system off switch connector M117.

ADAS control unit		Sonar system off switch		Continuity
Connector	Terminal	Connector	Terminal	
M128	11	M117	6	Yes

4. Check continuity between ADAS control unit connector M128 and ground.

ADAS control unit		Ground	Continuity
Connector	Terminal	Ground	
M128	11	(-)	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2. CHECK SONAR SYSTEM OFF SWITCH INPUT CIRCUIT FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between ADAS control unit connector M128 and ground.

ADAS control unit		Ground	Voltage (Approx.)
Connector	Terminal	Ground	
M128	11	(-)	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK SONAR SYSTEM OFF SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sonar system off switch connector M117 and ground.

Sonar system off switch		Ground	Continuity
Connector	Terminal	Ground	
M117	8	(-)	Yes

Is the inspection result normal?

YES >> Replace sonar system off switch. Refer to [IP-20, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

WITHOUT DRIVER ASSISTANCE SYSTEM

1. CHECK SONAR SYSTEM OFF SWITCH INPUT CIRCUIT FOR OPEN OR SHORT TO GROUND

SONAR SYSTEM OFF SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect sonar control unit and sonar system off switch connectors.
3. Check continuity between sonar control unit connector M114 and sonar system off switch connector M117.

Sonar control unit		Sonar system off switch		Continuity
Connector	Terminal	Connector	Terminal	
M114	16	M117	6	Yes

4. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal	Ground	
M114	16	(-)	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2.CHECK SONAR SYSTEM OFF SWITCH INPUT CIRCUIT FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Voltage (Approx.)
Connector	Terminal	Ground	
M114	16	(-)	0V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK SONAR SYSTEM OFF SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sonar system off switch connector M117 and ground.

Sonar system off switch		Ground	Continuity
Connector	Terminal	Ground	
M117	8	(-)	Yes

Is the inspection result normal?

YES >> Replace sonar system off switch. Refer to [IP-20, "Removal and Installation".](#)

NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

SONAR SYSTEM OFF SWITCH INDICATOR LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

SONAR SYSTEM OFF SWITCH INDICATOR LAMP CIRCUIT

Diagnosis Procedure

INFOID:0000000014386776

Regarding Wiring Diagram information, refer to [SN-19, "Wiring Diagram"](#).

WITH DRIVER ASSISTANCE SYSTEM

1. CHECK SONAR SYSTEM OFF SWITCH INDICATOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sonar system off switch connector.
3. Turn ignition switch ON.
4. Check voltage between sonar system off switch connector M117 and ground.

Sonar system off switch		Ground	Voltage (Approx.)
Connector	Terminal		
M117	5	(-)	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2. CHECK SONAR SYSTEM OFF SWITCH INDICATOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ADAS control unit connector.
3. Check continuity between ADAS control unit connector M128 and sonar system off switch connector M117.

ADAS control unit		Sonar system off switch		Continuity
Connector	Terminal	Connector	Terminal	
M128	17	M117	3	Yes

Is the inspection result normal?

YES >> Replace sonar system off switch. Refer to [IP-20, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

WITHOUT DRIVER ASSISTANCE SYSTEM

1. CHECK SONAR SYSTEM OFF SWITCH INDICATOR CIRCUIT FOR OPEN OR SHORT TO GROUND

1. Turn ignition switch OFF.
2. Disconnect sonar control unit and sonar system off switch connectors.
3. Check continuity between sonar control unit connector M114 and sonar system off switch connector M117.

Sonar control unit		Sonar system off switch		Continuity
Connector	Terminal	Connector	Terminal	
M114	17	M117	5	Yes

4. Check continuity between sonar control unit connector M114 and ground.

Sonar control unit		Ground	Continuity
Connector	Terminal		
M114	17	(-)	No

Is the inspection result normal?

SONAR SYSTEM OFF SWITCH INDICATOR LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2. CHECK SONAR SYSTEM OFF SWITCH INDICATOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sonar system off switch connector M117 and ground.

Sonar system off switch		Ground	Continuity
Connector	Terminal		
M117	3	(-)	Yes

Is the inspection result normal?

YES >> Replace sonar system off switch. Refer to [IP-20. "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

SONAR SYSTEM

Symptom Table

INFOID:000000014386777

NOTE:

If the front license plate is bent and not laying flat against the bumper, it can cause a false warning from the sonar system. Before performing diagnosis for a false warning, ensure that the front license plate is laying flat against the bumper and no other obstructions are within the detection range of the sonar sensors.

Symptom	Possible cause	Reference page
Malfunction is detected in only 1 sensor of display (Always displayed in red).	<ul style="list-style-type: none"> • Sonar sensor circuit • Sonar sensor • Sonar sensor obstruction 	<ul style="list-style-type: none"> • SN-47 (front sonar sensor LH outer) • SN-49 (front sonar sensor LH inner) • SN-51 (front sonar sensor RH inner) • SN-53 (front sonar sensor RH outer) • SN-36 (rear sonar sensor LH outer) • SN-38 (rear sonar sensor LH inner) • SN-40 (rear sonar sensor RH inner) • SN-42 (rear sonar sensor RH outer) • SN-63 (removal and installation - front sonar sensors) • SN-64 (removal and installation - rear sonar sensors) • Front license plate (if equipped) is bent and obstructing the sensor area.
Malfunction is detected in all 4 front sensors of display (Always displayed in red).	Sonar sensors ground circuit	<ul style="list-style-type: none"> • SN-47 (front sonar sensor LH outer) • SN-49 (front sonar sensor LH inner) • SN-51 (front sonar sensor RH inner) • SN-53 (front sonar sensor RH outer)
Malfunction is detected in all 4 rear sensors of display (Always displayed in red).	Sonar sensors ground circuit	<ul style="list-style-type: none"> • SN-36 (rear sonar sensor LH outer) • SN-38 (rear sonar sensor LH inner) • SN-40 (rear sonar sensor RH inner) • SN-42 (rear sonar sensor RH outer)
Malfunction is detected in all 8 sensors of display (Always displayed in red).	<ul style="list-style-type: none"> • Sonar control unit power supply and ground circuits • CAN communication circuits 	<ul style="list-style-type: none"> • SN-57 • LAN-53

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

SONAR SENSOR


Removal and Installation - Front Sonar Sensors

INFOID:000000014386778

REMOVAL (Inner Sensors)


1. Release clips using suitable tool and remove front bumper grill finisher [LH/RH (1)] from front bumper (2).

 : Clip



ALNIA1810ZZ


2. Disconnect the harness connector (A) from the front sonar inner sensor (1).



ALNIA1811ZZ

3. Release pawls using suitable tool and remove front sonar inner sensor (1) from sonar finisher (2).


 : Pawl



ALNIA1812ZZ

4. Squeeze pawls and remove front sonar sensor finisher (1) from front bumper grill finisher [2 (if necessary)].

 : Pawl



ALNIA1813ZZ

INSTALLATION


Installation is in the reverse order of removal.

SONAR SENSOR

< REMOVAL AND INSTALLATION >

REMOVAL (Outer Sensors)

1. Disconnect the harness connector (A) from the front sonar outer sensor (1).



2. Release pawls using suitable tool and remove front sonar outer sensor (1) from front sonar sensor finisher (2).


(○) : Pawl

3. Squeeze pawls and remove front sonar sensor finisher from front bumper (3).

(○) : Pawl

(A) : Front bumper shown

(B) : Rear bumper shown (front similar)



INSTALLATION


Installation is in the reverse order of removal.

Removal and Installation - Rear Sonar Sensors

INFOID:0000000014386779

REMOVAL

1. Disconnect the harness connector (A) from the rear sonar sensor (1).




SONAR SENSOR

< REMOVAL AND INSTALLATION >

- Release rear sonar sensor finisher (2) pawls using suitable tool and remove rear sonar sensor (1) from rear sonar sensor finisher.

○ : Pawl

- Remove rear sonar sensor finisher from rear bumper (3) (if necessary).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M

SN

O
P

SONAR CONTROL UNIT

< REMOVAL AND INSTALLATION >


SONAR CONTROL UNIT

Removal and Installation

INFOID:0000000014386780

REMOVAL

1. Remove Instrument lower panel LH. Refer to [IP-22, "Removal and Installation"](#).
2. Disconnect the harness connector from the sonar control unit (1).
3. Remove screw (A) and remove sonar control unit.



INSTALLATION

Installation is in the reverse order of removal.

< REMOVAL AND INSTALLATION >


BUZZER

Removal and Installation

INFOID:000000014386781

REMOVAL

1. Remove instrument panel lower LH. Refer to [IP-22, "Removal and Installation"](#).
2. Remove center console. Refer to [IP-24, "Removal and Installation"](#).
3. Disconnect the harness connector from the front sonar buzzer (1).
4. Remove screws (A) from front sonar buzzer and remove.



INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P


SONAR SYSTEM OFF SWITCH

< REMOVAL AND INSTALLATION >

SONAR SYSTEM OFF SWITCH

Exploded View

INFOID:0000000014386782




1. A/C switch assembly	2. Cluster lid C	3. Switch carrier
4. VDC OFF switch	5. Sonar system off switch	6. Hazard switch
7. Blind spot warning switch (if equipped)	8. Heated steering wheel switch (if equipped)	Front

Removal and Installation

INFOID:0000000014386783


REMOVAL

1. Remove cluster lid C. Refer to [IP-20, "Removal and Installation"](#).
2. Remove screws (A) and switch carrier (1) from cluster lid C.



3. Release pawls using suitable tool and remove sonar system off switch from switch carrier.

○ : Pawl



INSTALLATION

Installation is in the reverse order of removal.