

SECTION WIPER & WASHER

PRECAUTION	3	COMMON ITEM	15
PRECAUTIONS	3	COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	15
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	3	WIPER	16
Precaution for Procedure without Cowl Top Cover.....	3	WIPER : CONSULT Function (BCM - WIPER)	16
Precaution for Work	3	DIAGNOSIS SYSTEM (IPDM E/R)	18
PREPARATION	5	Diagnosis Description	18
PREPARATION	5	CONSULT Function (IPDM E/R)	19
Special Service Tools	5	ECU DIAGNOSIS INFORMATION	22
SYSTEM DESCRIPTION	6	BCM, IPDM E/R	22
COMPONENT PARTS	6	List of ECU Reference	22
Component Parts Location	6	WIRING DIAGRAM	23
Rain Sensor	7	FRONT WIPER AND WASHER SYSTEM	23
Washer Switch	7	Wiring Diagram	23
Front Wiper Motor	7	BASIC INSPECTION	29
Washer Fluid Level Switch	8	DIAGNOSIS AND REPAIR WORK FLOW	29
Front Washer Motor	8	Work Flow	29
SYSTEM	9	DTC/CIRCUIT DIAGNOSIS	31
FRONT WIPER AND WASHER SYSTEM	9	WIPER AND WASHER FUSE	31
FRONT WIPER AND WASHER SYSTEM : Sys- tem Description	9	Diagnosis Procedure	31
FRONT WIPER AND WASHER SYSTEM : Fail- Safe	12	FRONT WIPER MOTOR LO CIRCUIT	32
INFORMATION DISPLAY (COMBINATION METER)	12	Component Function Check	32
INFORMATION DISPLAY (COMBINATION METER) : Washer Fluid Warning	12	Diagnosis Procedure	32
WARNING/INDICATOR/CHIME LIST	14	FRONT WIPER MOTOR HI CIRCUIT	34
WARNING/INDICATOR/CHIME LIST : Warning/ Indicator (Information Display)	14	Component Function Check	34
DIAGNOSIS SYSTEM (BCM)	15	Diagnosis Procedure	34
		FRONT WIPER STOP POSITION SIGNAL CIRCUIT	36
		Component Function Check	36
		Diagnosis Procedure	36

FRONT WIPER MOTOR GROUND CIRCUIT ... 37	WIPER DRIVE ASSEMBLY : Removal and Installation 49
Diagnosis Procedure 37	
WASHER MOTOR CIRCUIT 38	WIPER MOTOR 50
Diagnosis Procedure 38	WIPER MOTOR : Removal and Installation 50
RAIN SENSOR 39	WASHER TANK 51
Component Function Check 39	Exploded View 51
Diagnosis Procedure 39	Removal and Installation 51
WASHER SWITCH 41	WASHER FLUID LEVEL SWITCH 53
Component Inspection 41	Exploded View 53
SYMPTOM DIAGNOSIS 42	Removal and Installation 53
WIPER AND WASHER SYSTEM SYMPTOMS 42	FRONT WASHER MOTOR 55
Symptom Table 42	Exploded View 55
NORMAL OPERATING CONDITION 44	Removal and Installation 55
Description 44	WASHER NOZZLE AND TUBE 57
FRONT WIPER DOES NOT OPERATE 45	Exploded View 57
Description 45	WASHER NOZZLE 57
Diagnosis Procedure 45	WASHER NOZZLE : Removal and Installation 57
REMOVAL AND INSTALLATION 47	WASHER NOZZLE : Adjustment 58
FRONT WIPER 47	WASHER TUBE 58
Exploded View 47	WASHER TUBE : Removal and Installation 58
WIPER ARM 47	RAIN SENSOR 60
WIPER ARM : Removal and Installation 47	Exploded View 60
WIPER ARM : Adjustment 48	Removal and Installation 60
WIPER BLADE 48	WIPER AND WASHER SWITCH 62
WIPER BLADE : Removal and Installation 48	Removal and Installation 62
WIPER REFILL 49	SERVICE DATA AND SPECIFICATIONS (SDS) 63
WIPER REFILL : Removal and Installation 49	SERVICE DATA AND SPECIFICATIONS (SDS) 63
WIPER DRIVE ASSEMBLY 49	Specifications 63

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000014388956

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:0000000014388957

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Precaution for Work

INFOID:0000000014388958

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.
- Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
- Oily dirt:
 - Use a solvent such as kerosene to remove the oil.
 - Dip a soft cloth into the solvent, wring the solvent out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.

PRECAUTIONS

< PRECAUTION >

- Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
- Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
- Then rub with a soft, dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tools

INFOID:000000014388959

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.)	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000014388960



ALLIA1941ZZ

A. View with washer tank removed from vehicle

No.	Component	Function
1.	Rain sensor*	Refer to WW-7, "Rain Sensor" .
2.	IPDM E/R	<ul style="list-style-type: none">Controls integrated relays according to the request (via CAN communication) from BCM.Performs the auto stop control of front wiper.Refer to PCS-5, "Component Parts Location" for detailed installation location.
3.	Front wiper motor	Refer to WW-7, "Front Wiper Motor" .

COMPONENT PARTS

< SYSTEM DESCRIPTION >


No.	Component	Function
4.	BCM	<ul style="list-style-type: none">Judges each switch status by the combination switch (wiper and washer switch) reading function.Requests (via CAN communication) the front wiper relay and the front wiper HI/LO relay ON to IPDM E/R.Refer to BCS-5, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
5.	Combination meter	<ul style="list-style-type: none">Transmits vehicle speed signal to BCM via CAN communication.Refer to MWI-8, "METER SYSTEM : Component Parts Location" for detailed installation location.
6.	Combination switch (wiper and washer switch)	<ul style="list-style-type: none">Combination switch (wiper and washer switch): Transmits the status of the combination switch (wiper and washer switch) to BCM.Washer switch: Refer to BCS-5, "BODY CONTROL SYSTEM : Component Parts Location".
7.	Washer fluid level switch	Refer to WW-8, "Washer Fluid Level Switch" .
8.	Front washer motor	Refer to WW-8, "Front Washer Motor" .

*: For vehicles equipped with rain sensing front wipers.

Rain Sensor

INFOID:0000000014388961

Detects water droplets on the windshield with infrared rays, and transmits the rain sensor signal to BCM via the rain sensor serial link.



INFOID:0000000014388962


Washer Switch

- Washer switch is integrated with combination switch (wiper and washer switch).
- Front washer motor is powered through the combination switch (wiper and washer switch) while the washer switch is ON. For a detailed description refer to [BCS-7, "BODY CONTROL SYSTEM : System Description"](#).

Front Wiper Motor

INFOID:0000000014388963

- Controls front wiper operation with IPDM E/R control.
- Transmits front wiper stop position signal to IPDM E/R.



WW

M

N

O

P


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Washer Fluid Level Switch

INFOID:000000014388964

Detects that washer fluid level is low and transmits washer level signal to combination meter.




ALLIA19382Z

Front Washer Motor

INFOID:000000014388965

Washer fluid is sprayed according to washer switch status.



ALLIA19372Z

SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM

FRONT WIPER AND WASHER SYSTEM

FRONT WIPER AND WASHER SYSTEM : System Description

INFOID:000000014388966

SYSTEM DIAGRAM



*:For vehicles equipped with rain sensing front wipers.

OUTLINE

The front wiper is controlled by each function of BCM and IPDM E/R.

Control by BCM:

- Combination switch (wiper and washer switch) reading function
- Front wiper control function

Control by IPDM E/R:

- Front wiper control function
- Relay control function

FRONT WIPER BASIC OPERATION

- BCM detects the combination switch (wiper and washer switch) condition by the combination switch (wiper and washer switch) reading function.
- BCM transmits the front wiper request signal to IPDM E/R via CAN communication depending on each operating condition of the front wiper.
- IPDM E/R turns ON/OFF the integrated front wiper relay and the front wiper HI/LO relay according to the front wiper request signal. IPDM E/R provides the power supply to operate the front wiper HI/LO operation.

FRONT WIPER LO OPERATION

- BCM transmits the front wiper request signal (LO) to IPDM E/R via CAN communication according to the front wiper LO operating condition.

Front wiper LO operating condition:

- Ignition switch ON
- Front wiper switch LO or front wiper switch MIST (while pressing)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

FRONT WIPER HI OPERATION

- BCM transmits the front wiper request signal (HI) to IPDM E/R via CAN communication according to the front wiper HI operating condition.

Front wiper HI operating condition:

- Ignition switch ON
- Front wiper switch HI
- IPDM E/R turns ON the integrated front wiper relay and the front wiper HI/LO relay according to the front wiper request signal (HI).

FRONT WIPER AUTO OPERATION

SYSTEM

< SYSTEM DESCRIPTION >

Rain Detection

Rain level and sensor conditions are detected by rain sensor.

- BCM transmits the vehicle conditions (vehicle speed, front wiper condition, rain sensor sensitivity setting, etc.) to the rain sensor via the rain sensor serial link.
- Rain sensor judges a wiping speed for front wiper by rain condition and the vehicle conditions. It transmits the wiping speed request signal to the BCM via the rain sensor serial link.

Auto Wiping Operation

- BCM receives the wiping speed request signal from the rain sensor via the rain sensor serial link.
- BCM controls front wiper operation according to the wiping speed request signals. It transmits the front wiper request signals (LO or HI) to the IPDM E/R via CAN communication line.

Front wiper AUTO operating condition

- Ignition switch ON
- Front wiper switch AUTO

NOTE:

- When the front wiper switch is turned to AUTO position, the front wiper operates once regardless of rainy conditions.
- Factory setting of the front wiper AUTO operation is the operation linked with rain sensor. Front wiper AUTO operation can be set to operation linked or not linked with rain sensor using CONSULT. Refer to [BCS-24, "WIPER : CONSULT Function \(BCM - WIPER\)"](#).

Rain Sensor Sensitivity Setting

BCM determines rain sensor sensitivity according to wiper volume dial position.

Wiper volume dial position	Sensitivity
1	High sensitivity
2	Medium-high sensitivity
3	Low-medium sensitivity
4	Low sensitivity

NOTE:

When the wiper volume dial position is turned up by 1 level under front wiper AUTO operating condition, the front wiper operates once.

Splash mode operation

The front wiper is operated at HI regardless of the wiper volume adjustment position when water drops are instantaneously sprayed over the windshield glass due to water splash from oncoming vehicles or other causes. After that, AUTO operation is performed depending on the amount of water drops.

SPLASH MODE OPERATION CONDITIONS

- Front wiper switch AUTO
- Ignition switch ON

NOTE:

Splash mode is not operated and auto wiping operation is performed while the vehicle is stopped.

FRONT WIPER INT OPERATION

- BCM transmits the front wiper request signal (INT) to IPDM E/R via CAN communication depending on the front wiper INT operating condition and intermittent operation delay interval according to the wiper volume dial position.


Front wiper INT operating condition:

- Ignition switch ON
- Front wiper switch INT
- IPDM E/R turns ON the integrated front wiper relay so that the front wiper is operated only once according to the front wiper request signal (INT).
- BCM detects stop position/except stop position of the front wiper motor according to the front wiper stop position signal received from IPDM E/R via CAN communication.

SYSTEM

< SYSTEM DESCRIPTION >

- BCM transmits the front wiper request signal (INT) again after the intermittent operation delay interval.



NOTE:

Front wiper intermittent operation can be set to operation linked or not linked with vehicle speed using CONSULT. Refer to [BCS-24, "WIPER : CONSULT Function \(BCM - WIPER\)"](#).

Front wiper intermittent operation with vehicle speed

- BCM calculates the intermittent operation delay interval from the following:
 - Vehicle speed signal
 - Wiper volume dial position

Intermittent operation delay Interval


Unit: Second

Wiper volume dial position	Intermittent operation interval	Vehicle speed		
		0 – 5 km/h (0 – 3.1 MPH)	5 – 65 km/h (3.1 – 40.4 MPH)*	65 km/h (40.4 MPH) or more
1	Short ↑	1	0.4	0.24
2		2.5	1	0.6
3		5	2	1.2
4		7.5	3	1.8
5		12.5	5	3
6		25	10	6
7		40	16	9.6

*: When operation setting is not linked with vehicle speed.

FRONT WIPER AUTO STOP OPERATION

- BCM stops transmitting the front wiper request signal when the front wiper switch is turned OFF.
- IPDM E/R detects the front wiper stop position signal from the front wiper motor and detects the front wiper motor position (stop position/except stop position).
- When the front wiper request signal is stopped, IPDM E/R turns ON the front wiper relay until the front wiper motor returns to the stop position.



NOTE:

- BCM stops the transmitting of the front wiper request signal when the ignition switch is OFF.
- IPDM E/R turns the front wiper relay OFF when the ignition switch is OFF.

SYSTEM

< SYSTEM DESCRIPTION >

FRONT WIPER OPERATION LINKED WITH WASHER

- BCM transmits the front wiper request signal (LO) to IPDM E/R via CAN communication according to the washer linked operating condition of the front wiper.
- BCM transmits the front wiper request signal (LO) so that the front wiper operates approximately 2 times when the front washer switch OFF is detected.

Washer linked operating condition of front wiper:

- Ignition switch ON
- Front washer switch ON (0.4 second or more)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).
- The washer pump is grounded through the combination switch (wiper and washer switch) with the front washer switch ON.

FRONT WIPER AND WASHER SYSTEM : Fail-Safe

INFOID:000000014388967

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Front wiper motor	<ul style="list-style-type: none">The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.Automatically returns wiper to stop position when ignition switch is turned ON if fail-safe control is activated while front wiper motor is operated and wiper stop is in any other position than stop position.

FRONT WIPER PROTECTION FUNCTION

IPDM E/R detects front wiper stop position by a front wiper stop position signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop.

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) can not be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

INFORMATION DISPLAY (COMBINATION METER)

INFORMATION DISPLAY (COMBINATION METER) : Washer Fluid Warning

INFOID:000000014388968

DESIGN/PURPOSE

Washer fluid warning reminds driver the washer fluid is insufficient.

SYSTEM


< SYSTEM DESCRIPTION >

Symbol	Message	
	Low Washer Fluid	

SYNCHRONIZATION WITH MASTER WARNING LAMP

Not applicable

SYSTEM DIAGRAM



ALLIA1772GB

SIGNAL PATH

- When washer fluid level is low, washer fluid level switch turns ON and transmits washer fluid level switch signal to combination meter.
- Combination meter displays washer fluid warning according to washer fluid level switch signal.

WARNING/INDICATOR OPERATING CONDITION

When all of the conditions listed below are satisfied:

- Ignition switch is ON.
- Washer fluid is insufficient. (Washer fluid level switch is ON and 3 minutes have passed)

WW

WARNING/INDICATOR CANCEL CONDITION


When any of the condition listed below is satisfied:

- Ignition switch is OFF.
- After the washer fluid is refilled. (Washer fluid level switch is OFF and 30 seconds have passed)

M

N

TIMING CHART



JMLIA4124GB

O

P

A

B

C

D

E

F

G

H

I

J

K

SYSTEM

< SYSTEM DESCRIPTION >

WARNING/INDICATOR/CHIME LIST

WARNING/INDICATOR/CHIME LIST : Warning/Indicator (Information Display)

INFOID:000000014388969

Item	Reference
Low windshield-washer fluid warning light	Refer to WW-12, "INFORMATION DISPLAY (COMBINATION METER) : Washer Fluid Warning".

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000014666390

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions:

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×				

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays it on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed at the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) at the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK").
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF").
	LOCK>ACC	While turning power supply position from "LOCK" *to "ACC"
	ACC>ON	While turning power supply position from "ACC" to "IGN"
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopped and selector lever is in P position.)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF"
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC	While turning power supply position from "OFF" to "ACC"
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK"*.) to low power consumption mode
	LOCK	Power supply position is "LOCK" (Ignition switch OFF)*
	OFF	Power supply position is "OFF" (Ignition switch OFF)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> The number is 0 when a malfunction is detected now. The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition is switched OFF → ON. The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met:

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

WIPER

WIPER : CONSULT Function (BCM - WIPER)

INFOID:0000000014666391

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.
FR WIPER HI [On/Off]	Indicates condition of wiper operation of combination switch.
FR WIPER LOW [On/Off]	
FR WASHER SW [On/Off]	
FR WIPER INT [On/Off]	
FR WIPER STOP [On/Off]	Indicates front wiper auto stop signal received from IPDM E/R on CAN communication line.
INT VOLUME [1 – 5]	Indicates condition of intermittent wiper [1 - 5] or auto wiper [1 - 4] operation of combination switch.
RAIN SENSOR [On/Off]	Indicates condition of rain sensor.

ACTIVE TEST

Test Item	Description
FR WIPER	This test is able to check front wiper operation [Hi/Lo/INT/Off].

WORK SUPPORT

Support Item	Setting	Description
WIPER SPEED SETTING	On	Front wiper intermittent time linked with vehicle speed and wiper dial position.
	Off*	Front wiper intermittent time linked with wiper dial position.
RAIN SENSOR	On*	Rain sensor function ON.
	Off	Rain sensor function OFF.

*: Initial setting

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:000000014663797

AUTO ACTIVE TEST

Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation:

- Rear window defogger
- Front wipers (HI, LO)
- Front fog lamps (if equipped)
- Tail, license and parking lamps
- Daytime running lamps (if equipped)
- Headlamps (HI, LO)
- A/C compressor (magnetic clutch)

Operation Procedure

1. Close the hood and front door RH, and lift the wiper arms from the windshield (to prevent windshield damage due to wiper operation).
- NOTE:**
When auto active test is performed with hood opened, sprinkle water on windshield before hand.
2. Turn ignition switch OFF.
3. Turn the ignition switch ON and, within 20 seconds, press the front door switch LH 10 times. Then turn the ignition switch OFF.
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.

CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-98, "Component Function Check"](#).
- Do not start the engine.

Inspection in Auto Active Test Mode


When auto active test mode is actuated, the following 6 steps are repeated 3 times.

Operation sequence	Inspection Location	Operation
1	Rear window defogger	10 seconds
2	Front wipers	HI for 5 seconds → LO for 5 seconds
3	Front fog lamps (if equipped), tail, license and parking lamps and daytime running lamps (if equipped)	10 seconds
4	Headlamps	LO for 10 seconds → HI on-off for 5 seconds
5	A/C compressor (magnetic clutch)	ON ⇔ OFF 5 times

Concept of auto active test

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >



*: If equipped

- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger (if equipped) operate?	YES	BCM signal input circuit
		NO	CAN communication signal between BCM and IPDM E/R
Any of the following components do not operate: • Front wipers (HI, LO) • Front fog lamps (if equipped) • Tail lamps • License plate lamps • Parking lamps • Daytime running lamps (if equipped) • Headlamps (HI, LO)	Perform auto active test. Does the applicable system operate?	YES	BCM signal input system
		NO	<ul style="list-style-type: none"> Lamp or front wiper motor malfunction Lamp or front wiper motor ground circuit Harness or connector between IPDM E/R and applicable system IPDM E/R (integrated relay malfunction)
A/C compressor does not operate	Perform auto active test. Does the A/C compressor operate?	YES	<ul style="list-style-type: none"> BCM signal input circuit CAN communication signal between BCM and ECM CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> Magnetic clutch malfunction Harness or connector between IPDM E/R and magnetic clutch IPDM E/R (integrated relay malfunction)

CONSULT Function (IPDM E/R)

INFOID:0000000014663798

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R:

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

Direct Diagnostic Mode	Description
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SELF DIAGNOSTIC RESULT

Refer to [PCS-23, "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line.
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
INTER/NP SW [On/Off]		Indicates condition of AT shift position.
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line.
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line.
ST/INHI RLY [Off/ ST /INHI]		Indicates condition of starter relay and starter control relay.
DETENT SW [On/Off]		Indicates condition of AT shift selector (park position switch).
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch.
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line
HOOD SW 2 [On/Off]		Indicates condition of hood switch 2.

ACTIVE TEST

Test item	Description
REAR DEFOGGER	This test is able to check rear defogger operation [On/Off].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

Test item	Description
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].
HORN	This test is able to check horn operation [On].

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM, IPDM E/R

List of ECU Reference

INFOID:000000014388974

ECU	Reference
BCM	BCS-32, "Reference Value"
	BCS-51, "Fail_Safe"
	BCS-51, "DTC_Inspection_Priority_Chart"
	BCS-52, "DTC_Index"
IPDM E/R	PCS-14, "Reference Value"
	PCS-22, "Fail_Safe"
	PCS-23, "DTC_Index"

FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >

WIRING DIAGRAM


FRONT WIPER AND WASHER SYSTEM

Wiring Diagram

INFOID:000000014388975

FRONT WIPER AND WASHER SYSTEM

- : CAN COMMUNICATION LINE FOR DIAGNOSIS
- LF : WITH RAIN SENSING FRONT WIPERS
- V2 : WITH VK56VD AND WITH DRIVER ASSISTANCE SYSTEM
- V3 : WITH VK56VD AND WITHOUT DRIVER ASSISTANCE SYSTEM
- V4 : WITH Cummins 5.0L AND WITH CAN GATEWAY SYSTEM
- V5 : WITH Cummins 5.0L AND WITHOUT NAVIGATION SYSTEM
- V6 : WITH Cummins 5.0L AND WITH NAVIGATION WITH BLINDSPOT WARNING SYSTEMS
- V7 : WITH Cummins 5.0L AND WITH NAVIGATION WITHOUT BLINDSPOT WARNING SYSTEMS
- V8 : WITH VK56VD
- V9 : WITH Cummins 5.0L



FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >

FRONT WIPER AND WASHER SYSTEM CONNECTORS

Connector No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
EE23	B	GROUND	1	Y	FR WIPER HI	25	BR	ECM VB - (WITH CUMMINS 5.0L)
	Y	FR WIPER LO	2	BR		25	W	ECM VB - (WITH VKS6V1D)
	-	-	3	-		25	W	02 SENS - (WITH VKS6V1D)
	-	-	4	-		26	V	PARKING RH
	-	-	5	-		27	R/L	TAIL 1
	L/Y	WIPER AUTOSTOP	6	-		28	R/L	FR WIPER HI
			29	Y		30	-	
			31	L	ECM RLY CONT	32	L	ECM BAT - (WITH VKS6V1D)
			33	R/L	PARKING LH	34	R/W	TAIL 2
			35	BR	FR WIPER LO	36	-	-
			37	-	-	38	-	-
			39	-	-	40	-	-
			41	40	39 38 37	42	41 40	39 38 37
			42	47	45 44 43	43	47	45 44 43
			44	BR		45	BR	
			46	BR		46	BR	
			47	BR		47	BR	
			48	BR		48	BR	
			49	BR		49	BR	
			50	BR		51	-	
			52	B	S-GND	53	-	
			54	-	-	55	-	
			56	-	-	56	-	
			57	SB		57	SB	
			58	W	E-CPLG - (WITH VKS6V1D)	59	SB	
			59	W		60	W/B	
			61	W/B		62	W/B	
			63	W/B		64	R	
			65	R		66	R	
			67	R		68	R	
			69	-		70	-	
			71	-		72	-	
			73	-		74	-	
			75	-		76	-	
			77	-		78	-	
			79	-		80	-	
			81	-		82	-	
			83	-		84	-	
			85	-		86	-	
			87	-		88	-	
			89	-		90	-	
			91	-		92	-	
			93	-		94	-	
			95	-		96	-	
			97	-		98	-	
			99	-		100	-	
			101	-		102	-	
			103	-		104	-	
			105	-		106	-	
			107	-		108	-	
			109	-		110	-	
			111	-		112	-	
			113	-		114	-	
			115	-		116	-	
			117	-		118	-	
			119	-		120	-	
			121	-		122	-	
			123	-		124	-	
			125	-		126	-	
			127	-		128	-	
			129	-		130	-	
			131	-		132	-	
			133	-		134	-	
			135	-		136	-	
			137	-		138	-	
			139	-		140	-	
			141	-		142	-	
			143	-		144	-	
			145	-		146	-	
			147	-		148	-	
			149	-		150	-	
			151	-		152	-	
			153	-		154	-	
			155	-		156	-	
			157	-		158	-	
			159	-		160	-	
			161	-		162	-	
			163	-		164	-	
			165	-		166	-	
			167	-		168	-	
			169	-		170	-	
			171	-		172	-	
			173	-		174	-	
			175	-		176	-	
			177	-		178	-	
			179	-		180	-	
			181	-		182	-	
			183	-		184	-	
			185	-		186	-	
			187	-		188	-	
			189	-		190	-	
			191	-		192	-	
			193	-		194	-	
			195	-		196	-	
			197	-		198	-	
			199	-		200	-	
			201	-		202	-	
			203	-		204	-	
			205	-		206	-	
			207	-		208	-	
			209	-		210	-	
			211	-		212	-	
			213	-		214	-	
			215	-		216	-	
			217	-		218	-	
			219	-		220	-	
			221	-		222	-	
			223	-		224	-	
			225	-		226	-	
			227	-		228	-	
			229	-		230	-	
			231	-		232	-	
			233	-		234	-	
			235	-		236	-	
			237	-		238	-	
			239	-		240	-	
			241	-		242	-	
			243	-		244	-	
			245	-		246	-	
			247	-		248	-	
			249	-		250	-	
			251	-		252	-	
			253	-		254	-	
			255	-		256	-	
			257	-		258	-	
			259	-		260	-	
			261	-		262	-	
			263	-		264	-	
			265	-		266	-	
			267	-		268	-	
			269	-		270	-	
			271	-		272	-	
			273	-		274	-	
			275	-		276	-	
			277	-		278	-	
			279	-		280	-	
			281	-		282	-	
			283	-		284	-	
			285	-		286	-	
			287	-		288	-	
			289	-		290	-	
			291	-		292	-	
			293	-		294	-	
			295	-		296	-	
			297	-		298	-	
			299	-		300	-	
			301	-		302	-	
			303	-		304	-	
			305	-		306	-	
			307	-		308	-	
			309	-		310	-	
			311	-		312	-	
			313	-		314	-	
			315	-		316	-	
			317	-		318	-	
			319	-		320	-	
			321	-		322	-	
			323	-		324	-	
			325	-		326	-	
			327	-		328	-	
			329	-		330	-	
			331	-		332	-	
			333	-		334	-	
			335	-		336	-	
			337	-		338	-	
			339	-		340	-	
			341	-		342	-	
			343	-		344	-	
			345	-		346	-	
			347	-		348	-	
			349	-		350	-	
			351	-		352	-	
			353	-		354	-	
			355	-		356	-	
			357	-		358	-	
			359	-		360	-	
			361	-		362	-	
			363	-		364	-	
			365	-		366	-	
			367	-		368	-	
			369	-		370	-	
			371	-		372	-	
			373	-		374	-	
			375	-		376	-	
			377	-		378	-	
			379	-		380	-	
			381	-		382	-	
			383	-		384	-	
			385	-		386	-	
			387	-		388	-	
			389	-		390	-	
			391	-		392	-	
			393	-		394	-	
			395	-		396	-	
			397	-		398	-	
			399	-		400	-	
			401	-		402	-	
			403	-		404	-	
			405	-		406	-	
			407	-		408	-	
			409	-		410	-	
			411	-		412	-	
			413	-		414	-	
			415	-		416	-	
			417	-		418	-	
			419	-		420	-	
			421	-		422	-	
			423	-		424	-	
			425	-		426	-	
			427	-		428	-	
			429	-		430	-	
			431	-		432	-	
			433	-		434	-	
			435	-		436	-	
			437	-		438	-	

FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >

FRONT WIPER AND WASHER SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS
Connector Color	WHITE
	

7	-	-	43	-	W/R	IGNITION
8	-	-	44	-	G/Y	COMBI SW/OUTPUT 4
9	-	-	45	-	-	-
10	SB	COMBI SW/IN 5	46	-	-	-
11	G/Y	COMBI SW/IN 4	47	-	-	-
12	Y	COMBI SW/IN 3	48	R	HIGH SIDE START SW/LED	COMBI SW/OUTPUT 3
13	G/B	COMBI SW/IN 2	49	-	-	FRONT WASHER MOTOR +
14	V	COMBI SW/IN 1	50	-	-	COMBI SW/INPUT 3
15	-	-	51	-	-	COMBI SW/OUTPUT 5
16	-	-	52	W	O/B	COMBI SW/INPUT 2
17	P	GND RF A/L	53	-	P	COMBI SW/INPUT 4
18	V	SECURITY INDICATOR	54	W/L	R/W	COMBI SW/INPUT 1
19	-	-	55	W/B	V	COMBI SW/OUTPUT 1
20	R	SHIFT P	56	-	L/W	COMBI SW/INPUT 5
21	R/W	STEP LAMP CONT	57	-	G/B	COMBI SW/OUTPUT 2
22	-	-	58	-	-	-
23	Y	AIRCON SW	59	P	CAN-L	-
24	-	-	60	L	CAN-H	-
25	W	BRAKE SW/FUSE	61	O	REAR DEFOGGER RELAY OUT	-
26	L	SHORT IN PIN INPUT	62	W	STARTER RELAY OUT	-
27	R/G	BRAKE SW/LAMP	63	-	-	-
28	-	-	64	P	BUZZER OUT	-
29	W	BLOWER FAN SW	65	-	-	-
30	P	DR DOOR LOCK STATUS	66	W	BLOWER FAN RELAY OUT	-
31	-	-	67	G	IGN ELEC RELAY OUT 2	-
32	Y	REAR DEFOGGER SW	68	L	MR OUTPUT	-
33	-	-	69	R/B	AT DEVICE OUT	-
34	-	-	70	P	IGN USM OUT 1	-
35	R/G	REVERSE SW	71	O	DR REQUESTS SW	-
36	W/B	HAZARD SW	72	G	AS REQUESTS SW	-
37	-	-	73	-	-	-
38	-	-	74	-	-	-
39	B/R	SHIFT N/P	75	L/W	COMBI SW/OUT 5	-
40	-	-	76	P	COMBI SW/OUT 4	-
			77	L	COMBI SW/OUT 3	-

20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

1	G	ENG START SW/NO ESCL
2	-	-
3	R	ALU POWER SUPPLY 5V
4	W/R	A/R SIGNAL
5	-	-
6	-	-

59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	
60	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61

1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW/NO ESCL
2	-	-
3	R	ALU POWER SUPPLY 5V
4	W/R	A/R SIGNAL
5	-	-
6	-	-

1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW/NO ESCL
2	-	-
3	R	ALU POWER SUPPLY 5V
4	W/R	A/R SIGNAL
5	-	-
6	-	-

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6
7	8	9	10	11	12

<table border="1

FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >

FRONT WIPER AND WASHER SYSTEM CONNECTORS

Terminal No.	Color of Wire	Signal Name	Connector No.	Connector Name	Connector Type	Connector Color
1G	G	TO ENGINE ROOM HARNESS	80G	R	TO ENGINE ROOM HARNESS	
2G	G/B	TO ENGINE ROOM HARNESS	81G	L	TO ENGINE ROOM HARNESS	
29G	G/B	TO ENGINE ROOM HARNESS	82G	R	TO ENGINE ROOM HARNESS	
30G	B/R	TO ENGINE ROOM HARNESS	83G	L	TO ENGINE ROOM HARNESS	
31G	R	TO ENGINE ROOM HARNESS	84G	L	TO ENGINE ROOM HARNESS	
32G	R	TO ENGINE ROOM HARNESS	85G	W	TO ENGINE ROOM HARNESS	
33G	Y/L	TO ENGINE ROOM HARNESS	86G	B/R	TO ENGINE ROOM HARNESS	
34G	GR	TO ENGINE ROOM HARNESS	87G	W	TO ENGINE ROOM HARNESS	
35G	G/R	TO ENGINE ROOM HARNESS	88G	G	TO ENGINE ROOM HARNESS	
36G	SB	TO ENGINE ROOM HARNESS	89G	P	TO ENGINE ROOM HARNESS	
37G	R/W	TO ENGINE ROOM HARNESS	90G	G	TO ENGINE ROOM HARNESS	
38G	BR	TO ENGINE ROOM HARNESS	91G	P	TO ENGINE ROOM HARNESS	
39G	BR	TO ENGINE ROOM HARNESS	92G	W/N	TO ENGINE ROOM HARNESS	
40G	-	TO ENGINE ROOM HARNESS	93G	BR	TO ENGINE ROOM HARNESS	
41G	R/G	TO ENGINE ROOM HARNESS	94G	B	TO ENGINE ROOM HARNESS	
42G	O	TO ENGINE ROOM HARNESS	95G	G	TO ENGINE ROOM HARNESS	
43G	G	TO ENGINE ROOM HARNESS	96G	R	TO ENGINE ROOM HARNESS	
44G	R/Y	TO ENGINE ROOM HARNESS	97G	R	TO ENGINE ROOM HARNESS	
45G	G	TO ENGINE ROOM HARNESS	98G	W/R	TO ENGINE ROOM HARNESS	
46G	LG	TO ENGINE ROOM HARNESS	99G	R/Y	TO ENGINE ROOM HARNESS	
47G	R	TO ENGINE ROOM HARNESS	100G	GR/W	TO ENGINE ROOM HARNESS	
48G	-	TO ENGINE ROOM HARNESS				
50G	BR	TO ENGINE ROOM HARNESS				
51G	R	TO ENGINE ROOM HARNESS				
52G	L	TO ENGINE ROOM HARNESS				
53G	W	TO ENGINE ROOM HARNESS				
54G	W	TO ENGINE ROOM HARNESS				
55G	W	TO ENGINE ROOM HARNESS				
56G	Y	TO ENGINE ROOM HARNESS				
57G	Y	TO ENGINE ROOM HARNESS				
58G	B/G	TO ENGINE ROOM HARNESS				
59G	B/G	TO ENGINE ROOM HARNESS				
60G	B/G	TO ENGINE ROOM HARNESS				
61G	O	TO ENGINE ROOM HARNESS				
62G	W	TO ENGINE ROOM HARNESS				
63G	O	TO ENGINE ROOM HARNESS				
64G	W/L	TO ENGINE ROOM HARNESS				
65G	W/R	TO ENGINE ROOM HARNESS				
66G	B/G	TO ENGINE ROOM HARNESS				
67G	O	TO ENGINE ROOM HARNESS				
68G	W/L	TO ENGINE ROOM HARNESS				
69G	Y	TO ENGINE ROOM HARNESS				
70G	L	TO ENGINE ROOM HARNESS				
71G	R/W	TO ENGINE ROOM HARNESS				
72G	L/W	TO ENGINE ROOM HARNESS				
73G	SHIELD	TO ENGINE ROOM HARNESS				
74G	W	TO ENGINE ROOM HARNESS				
75G	R	TO ENGINE ROOM HARNESS				
76G	R/G	TO ENGINE ROOM HARNESS				
77G	B/G	TO ENGINE ROOM HARNESS				
78G	P	TO ENGINE ROOM HARNESS				
79G	-	TO ENGINE ROOM HARNESS				

AALIA5569GB

FRONT WIPER AND WASHER SYSTEM

< WIRING DIAGRAM >

FRONT WIPER AND WASHER SYSTEM CONNECTORS

Connector No.	M81	8	L	TO MAIN HARNESS
Connector Name	BCM (BODY CONTROL MODULE)	9	R/G	TO MAIN HARNESS
Connector Type	FEA09FW-FHA6-SA	10	G	TO MAIN HARNESS
Connector Color	WHITE	11	L/W	TO MAIN HARNESS
		12	L	TO MAIN HARNESS
		13	GR	TO MAIN HARNESS
		14	R	TO MAIN HARNESS
		15	W/B	TO MAIN HARNESS
		16	U/B	TO MAIN HARNESS
		17	-	TO MAIN HARNESS
		18	P	TO MAIN HARNESS
		19	W/L	TO MAIN HARNESS
		20	W/B	TO MAIN HARNESS
		21	-	TO MAIN HARNESS
		22	-	TO MAIN HARNESS
		23	-	TO MAIN HARNESS
		24	-	TO MAIN HARNESS
		25	-	TO MAIN HARNESS
		26	-	TO MAIN HARNESS
		27	-	TO MAIN HARNESS
		28	Y/R	TO MAIN HARNESS
		29	G/R	TO MAIN HARNESS
		30	G/W	TO MAIN HARNESS
		31	L/G/B	TO MAIN HARNESS
		32	Y/W	TO MAIN HARNESS



Terminal No.	Color of Wire	Signal Name
-29	R/G	BATTERY SAVER OUT
-30	L/G	SUPER LOCK/DOOR UNLOCK AS
-31	W	BAT. BOM. FUSE
-32	Y	DOOR LOCK AS/FR/RL
-33	BR	DOOR UNLOCK AS/FR/RL
-34	B	GND2
-35	O	DOOR LOCK DR/AS/FL
-36	L	ROOM LAMP CONT
-37	V	DOOR UNLOCK DR/AS/FL
-38	V	BAT REAR DOOR
-39	W	BAT-POWER FL
-40	L/G	P/W POWER SUPPLY GN
-41	V	P/W POWER SUPPLY BAT
-42	Y	BAT FRONT DOOR
-43	B	GND1

Connector No.	R1	1	2	3
Connector Name	WIRE TO WIRE			
Connector Type	TH32NM-NH			
Connector Color	WHITE			



Connector No.	R17	1	2	3
Connector Name	RAIN SENSOR			
Connector Type	AAB03FB			
Connector Color	BLACK			



Terminal No.	Color of Wire	Signal Name
1	Y/R	BATTERY
2	W/B	L&R SENSOR K LINE
3	B	GROUND



1	2	3
2	3	4
3	4	5
4	5	6
5	6	7
6	7	8
7	8	9
8	9	10
9	10	11
10	11	12
11	12	13
12	13	14
13	14	15
14	15	16

Terminal No.	Color of Wire	Signal Name
1	SHIELD	TO MAIN HARNESS
2	R	TO MAIN HARNESS
3	W	TO MAIN HARNESS
4	Y/R	TO MAIN HARNESS
5	G/W	TO MAIN HARNESS
6	G/R	TO MAIN HARNESS
7	B	TO MAIN HARNESS

AALIA5570GB

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000014388976

OVERALL SEQUENCE



A
B
C
D
E
F
G
H
I
J
K
WW
M
N
O
P

ALKIA1982GB

DETAILED FLOW

1. INTERVIEW CUSTOMER

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

>> GO TO 2.

2. REPRODUCE THE MALFUNCTION

Reproduce the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3. SYMPTOM DIAGNOSIS

Use Symptom diagnosis from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4. COMPONENT DIAGNOSIS

Perform the diagnosis with Component diagnosis of the applicable system.

>> GO TO 5.

5. REPAIR OR REPLACE THE MALFUNCTIONING PART

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6. PERFORM FINAL OPERATIONAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> Inspection End.

NO >> GO TO 3.

< DTC/CIRCUIT DIAGNOSIS >

DT/CIRCUIT DIAGNOSIS

WIPER AND WASHER FUSE

Diagnosis Procedure

INFOID:000000014388977

1. CHECK FUSES

Check that the following fuses are not blown:

Component	Capacity	Fuse No.	Location
Front wiper motor	30A	41	IPDM E/R
Front washer motor	10A	33	Fuse block J/B

Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.
NO >> Inspection End.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

FRONT WIPER MOTOR LO CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER MOTOR LO CIRCUIT

Component Function Check

INFOID:000000001438978

1. CHECK FRONT WIPER LO OPERATION

CONSULT

1. Select "FRONT WIPER" in "Active Test" mode of "IPDM E/R".
2. While operating the test item, check front wiper operation.

Lo : Front wiper (LO) operation

Off : Stop the front wiper.

Is front wiper (LO) operation normal?

YES >> Front wiper motor LO circuit is normal.

NO >> Refer to [WW-32, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000001438979

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram"](#).

1. CHECK FRONT WIPER MOTOR (LO) OUTPUT VOLTAGE

CONSULT

1. Turn ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn ignition switch ON.
4. Select "FRONT WIPER" in "Active Test" mode of "IPDM E/R".
5. While operating the test item, check voltage between front wiper motor harness connector and ground.

(+) Front wiper motor		(-)	Condition	Voltage (Approx.)	
Connector	Terminal			Lo	Off
E23	3	Ground	FRONT WIPER	Battery voltage	0 V

Is the inspection result normal?

YES >> Replace front wiper motor. Refer to [WW-50, "WIPER MOTOR : Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK FRONT WIPER MOTOR (LO) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E121	35	E23	3	Yes

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		—	Continuity
Connector	Terminal		
E121	35	Ground	No

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

FRONT WIPER MOTOR LO CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

FRONT WIPER MOTOR HI CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER MOTOR HI CIRCUIT

Component Function Check

INFOID:0000000014388980

1. CHECK FRONT WIPER HI OPERATION

CONSULT

1. Select "FRONT WIPER" in "Active Test" mode of "IPDM E/R".
2. While operating the test item, check front wiper operation.

Hi : Front wiper (HI) operation

Off : Stop the front wiper.

Is front wiper (HI) operation normal?

YES >> Front wiper motor HI circuit is normal.
NO >> Refer to [WW-34, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000014388981

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram"](#).

1. CHECK FRONT WIPER MOTOR (HI) OUTPUT VOLTAGE

CONSULT

1. Turn ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn ignition switch ON.
4. Select "FRONT WIPER" in "Active Test" mode of "IPDM E/R".
5. While operating the test item, check voltage between front wiper motor harness connector and ground.

(+) Front wiper motor		(-)	Condition	Voltage (Approx.)	
Connector	Terminal			Hi	Off
E23	2	Ground	FRONT WIPER	Battery voltage	0 V

Is the inspection result normal?

YES >> Replace front wiper motor. Refer to [WW-50, "WIPER MOTOR : Removal and Installation"](#).
NO >> GO TO 2.

2. CHECK FRONT WIPER MOTOR (HI) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E121	29	E23	2	Yes

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		—	Continuity
Connector	Terminal		
E121	29	Ground	No

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).

FRONT WIPER MOTOR HI CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

FRONT WIPER STOP POSITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER STOP POSITION SIGNAL CIRCUIT

Component Function Check

INFOID:0000000014388982

1. CHECK FRONT WIPER STOP POSITION SIGNAL

CONSULT

1. Select "WIP AUTO STOP" in "Data Monitor" mode of "IPDM E/R".
2. Operate the front wiper.
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition		Monitor status
WIP AUTO STOP	Front wiper motor	Stop position	STOP P
		Except stop position	ACT P

Is the status of item normal?

YES >> Front wiper stop position signal circuit is normal.

NO >> Refer to [WW-36, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000014388983

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram"](#).

1. CHECK IPDM E/R OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn ignition switch ON.
4. Check voltage between front wiper motor harness connector and ground.

(+) Front wiper motor		(-)	Voltage (Approx.)
Connector	Terminal		
E23	6	Ground	Battery voltage

Is the inspection result normal?

YES >> Replace front wiper motor. Refer to [WW-50, "WIPER MOTOR : Removal and Installation"](#).
NO >> GO TO 2.

2. CHECK FRONT WIPER MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E122	39	E23	6	Yes

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		—	Continuity
Connector	Terminal		
E122	39	Ground	No

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).
NO >> Repair or replace harness.

FRONT WIPER MOTOR GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT WIPER MOTOR GROUND CIRCUIT

Diagnosis Procedure

INFOID:00000001438984

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram"](#).

1. CHECK FRONT WIPER MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Check continuity between front wiper motor harness connector and ground.

Front wiper motor		—	Continuity
Connector	Terminal		
E23	1	Ground	Yes

Is the inspection result normal?

YES >> Inspection End.
NO >> Repair or replace harness.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

WASHER MOTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

WASHER MOTOR CIRCUIT

Diagnosis Procedure

INFOID:000000001438985

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram"](#)

1. CHECK FRONT WASHER MOTOR FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown:

Component	Capacity	Fuse No.	Location
Front washer motor	10A	33	Fuse block J/B

Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK FRONT WASHER MOTOR POWER SUPPLY

1. Disconnect the front washer motor.
2. Turn ignition switch ON.
3. Check voltage between front washer motor harness connector and ground.

(+) (+)		(-)	Washer switch	Voltage (Approx.)
Front washer motor	Connector	Terminal		
E105		1	Ground	ON Battery voltage
				OFF 0 V

Is the inspection result normal?

YES >> Inspection End.
NO >> GO TO 3.

3. CHECK WASHER SWITCH

Check washer switch. Refer to [WW-62, "Removal and Installation"](#).

Is the inspection result normal?

YES >> Repair harness between fuse and the front washer motor.
NO >> Replace washer switch. Refer to [WW-62, "Removal and Installation"](#).

RAIN SENSOR

< DTC/CIRCUIT DIAGNOSIS >

RAIN SENSOR

Component Function Check

INFOID:0000000014388986

1. CHECK FRONT WIPER AUTO OPERATION

1. Clean rain sensor detection area of windshield fully.
2. When the front wiper switch is turned to AUTO position, front wiper operates once regardless of a rainy condition.

Is the inspection result normal?

YES >> Rain sensor circuit is normal.
NO >> Refer to [WW-39, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000014388987

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram"](#).

1. CHECK RAIN SENSOR FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown:

Component	Location	Fuse No.	Capacity
Rain sensor	Fuse block (J/B)	14	5A

Is the inspection result normal?

YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the applicable circuit.

2. CHECK RAIN SENSOR POWER SUPPLY

1. Disconnect rain sensor connector.
2. Check voltage between rain sensor harness connector and ground.

(+) Rain sensor		(-)	Voltage (Approx.)
Connector	Terminal		
R17	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace the harness or connectors.

3. CHECK RAIN SENSOR GROUND CIRCUIT

Check continuity between rain sensor harness connector and ground.

Rain sensor		-	Continuity
Connector	Terminal		
R17	3	Ground	Yes

Is the inspection result normal?


YES >> GO TO 4.
NO >> Repair or replace the harness or connectors.

4. CHECK RAIN SENSOR SIGNAL

1. Connect rain sensor connector.
2. Turn ignition switch ON.
3. Check signal between BCM harness connector and ground with oscilloscope.

RAIN SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Connector	Terminal	(+)	(-)	Condition	Signal (Reference value)
		BCM			
M19	55	Ground		Ignition switch ON	 Approx. 8.7V

Is the inspection result normal?

YES >> Replace rain sensor. Refer to [WW-60, "Removal and Installation"](#).

NO >> GO TO 5.

5. CHECK RAIN SENSOR SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM connector and rain sensor connector.
3. Check continuity between BCM harness connector and rain sensor harness connector.

BCM		Rain sensor		Continuity
Connector	Terminal	Connector	Terminal	
M19	55	R17	2	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the harness or connectors.

6. CHECK RAIN SENSOR SIGNAL CIRCUIT FOR SHORT

Check continuity between BCM harness connector and ground.

BCM		-	Continuity
Connector	Terminal		
M19	55	Ground	No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace the harness connectors.

< DTC/CIRCUIT DIAGNOSIS >

WASHER SWITCH

Component Inspection

INFOID:00000001438988

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram"](#)

1. CHECK COMBINATION SWITCH (WIPER AND WASHER SWITCH) FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown:

Component	Capacity	Fuse No.	Location
Front washer motor	10A	33	Fuse block J/B

Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.
NO >> GO TO 2.

2. CHECK FRONT WASHER MOTOR POWER SUPPLY

1. Disconnect the front washer motor.
2. Turn ignition switch ON.
3. Check voltage between front washer motor harness connector and ground.

(+)	(-)	Washer switch	Voltage (Approx.)
Front washer motor	Ground		
Connector	Terminal	ON	Battery voltage
E105	1	OFF	0 V

Is the inspection result normal?

YES >> Inspection End.
NO >> Replace washer switch. Refer to [WW-62, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

WIPER AND WASHER SYSTEM SYMPTOMS

Symptom Table

INFOID:000000014388989

NOTE:

Perform the "Self Diagnostic Result" with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Probable malfunction location	Inspection item
Front wiper does not operate	HI only	• Combination switch (wiper and washer switch) • Harness between combination switch (wiper and washer switch) and BCM • BCM
		• IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor
		Front wiper request signal • BCM • IPDM E/R
	LO and INT	• IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor
		• Combination switch (wiper and washer switch) • Harness between combination switch and BCM • BCM
	LO only	Front wiper request signal • BCM • IPDM E/R
		• Combination switch (wiper and washer switch) • Harness between combination switch (wiper and washer switch) and BCM • BCM
	INT only	Front wiper request signal • BCM • IPDM E/R
		SYMPTOM DIAGNOSIS Refer to WW-45, "Diagnosis Procedure" .
	HI, LO and INT	

WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

Symptom	Probable malfunction location	Inspection item
Front wiper does not stop	HI only	• Combination switch (wiper and washer switch) • BCM Front wiper request signal • BCM • IPDM E/R
		IPDM E/R
		—
	LO only	• Combination switch (wiper and washer switch) • BCM Front wiper request signal • BCM • IPDM E/R
		IPDM E/R
		—
	INT only	• Combination switch (wiper and washer switch) • BCM Front wiper request signal • BCM • IPDM E/R
		IPDM E/R “Data Monitor” “FR WIP REQ”
Front wiper does not operate normally	Intermittent adjustment cannot be performed	• Combination switch (wiper and washer switch) • Harness between combination switch and BCM • BCM
		—
	Intermittent control linked with vehicle speed cannot be performed	Check the wiper setting is linked with vehicle speed. Refer to BCS-24, "WIPER : CONSULT Function (BCM - WIPER)".
	Wiper is not linked to the washer operation	• Combination switch (wiper and washer switch) • Harness between combination switch and BCM • BCM
		—
	Does not return to stop position [Re-peatedly operates for 10 seconds and then stops for 20 seconds. (Fail-safe)]	• IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor
		Front wiper stop position signal circuit Refer to WW-36, "Component Function Check".

A
B
C
D
E
F
G
H
I
J
K
WW
M
N
O
P

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:000000001438990

FRONT WIPER MOTOR PROTECTION FUNCTION

- IPDM E/R may stop the front wiper to protect the front wiper motor if any obstruction (operation resistance) such as a large amount of snow is detected during the front wiper operation.
- At that time, turn OFF the front wiper and remove the foreign object. Then wait for approximately 20 seconds or more and reactivate the front wiper. The wiper will operate normally.

FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

FRONT WIPER DOES NOT OPERATE

Description

INFOID:0000000014388991

The front wiper does not operate under any operation conditions.

Diagnosis Procedure

INFOID:0000000014388992

Regarding Wiring Diagram information, refer to [WW-23, "Wiring Diagram"](#).

1. CHECK WIPER RELAY OPERATION

① CONSULT

1. Select "FRONT WIPER" in "Active Test" mode of "IPDM E/R".
2. While operating the test item, check front wiper operation.

LO : Front wiper LO operation
HI : Front wiper HI operation
Off : Stop the front wiper.

Is front wiper operation normally?

YES >> GO TO 4.
NO >> GO TO 2.

2. CHECK FRONT WIPER MOTOR FUSE

Check that the following IPDM E/R fuse is not blown:

Component	Location	Fuse No.	Capacity
Front wiper motor	IPDM E/R	41	30A

Is the fuse blown?

YES >> GO TO 3.
NO >> Replace the blown fuse after repairing the affected circuit.

3. CHECK FRONT WIPER MOTOR GROUND CIRCUIT

Check front wiper motor ground circuit. Refer to [WW-37, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK FRONT WIPER REQUEST SIGNAL INPUT

① CONSULT

1. Select "FR WIP REQ" in "Data Monitor" mode of "IPDM E/R".
2. Switch the front wiper switch to HI and LO.
3. While operating the front wiper switch, check the status of "FR WIP REQ".

Monitor item	Condition		Monitor status
FR WIP REQ	Front wiper switch	HI	Hi
		LO	Low
		INT	1Low
		OFF	Stop

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-43, "Removal and Installation of IPDM E/R"](#).
NO >> GO TO 5.

5. CHECK COMBINATION SWITCH (WIPER AND WASHER SWITCH)

FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Perform the inspection of the combination switch (wiper and washer switch). Refer to [WW-42, "Symptom Table"](#).

Is combination switch normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace the applicable parts.


FRONT WIPER

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION FRONT WIPER

Exploded View

INFOID:0000000014388993



- 1. Wiper blade (RH)
- 2. Wiper arm (RH)
- 3. Wiper drive assembly
- 4. Wiper arm (LH)
- 5. Wiper arm cover
- 6. Wiper blade (LH)
- 7. Wiper motor
- 8. Link 1
- 9. Link 2
- A. Refer to INSTALLATION

WIPER ARM

WIPER ARM : Removal and Installation

INFOID:0000000014388994

REMOVAL

1. Operate wiper arms into the auto stop position.
2. Open hood.
3. Remove wiper arm cover.
4. Remove wiper arm nut.
5. Raise wiper arm, then remove wiper arm.

INSTALLATION


FRONT WIPER

< REMOVAL AND INSTALLATION >

1. Clean wiper arm mount as shown.

NOTE:

This will reduce the possibility of wiper arm looseness.




2. Operate wiper motor to move the wiper to the auto stop position.
3. Adjust wiper blade position. Refer to [WW-48, "WIPER ARM : Adjustment"](#).
4. Install wiper arm and wiper arm nut.
5. Install wiper arm cover.
6. Check that the wiper blades stop at the specified position. Refer to [WW-48, "WIPER ARM : Adjustment"](#).

WIPER ARM : Adjustment

INFOID:000000014388995

WIPER BLADE POSITION ADJUSTMENT

Clearance between the end of cowl top cover/ front fender cover and the top of wiper blade center.



1. Windshield glass	2. Wiper blade (RH)	3. Cowl top cover
4. Wiper blade (LH)	A. 78 mm (3.1 in)	B. 40 mm (1.6 in)

WIPER BLADE

WIPER BLADE : Removal and Installation

INFOID:000000014388996

REMOVAL

1. Lift wiper arm and blade assembly away from the windshield glass.


FRONT WIPER

< REMOVAL AND INSTALLATION >

2. Rotate wiper blade and push the release tab (A) of wiper blade (1), slide wiper blade in the sequence shown and remove from wiper arm (2).

CAUTION:

Be careful not to drop the wiper arm onto the windshield glass.



INSTALLATION

1. Insert wiper blade onto wiper arm until it clicks into place.
2. Lower wiper arm and blade assembly onto windshield glass.


WIPER REFILL

WIPER REFILL : Removal and Installation

INFOID:0000000014388997

REMOVAL

1. Remove wiper blade. Refer to [WW-48, "WIPER BLADE : Removal and Installation"](#).
2. Release portion (A) of wiper refill (1), from wiper blade portion (B) and remove wiper refill as shown.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Check that wiper refill is inserted properly.

WIPER DRIVE ASSEMBLY

WW

WIPER DRIVE ASSEMBLY : Removal and Installation

INFOID:0000000014388998

M

REMOVAL

1. Remove cowl top cover. Refer to [EXT-35, "Removal and Installation - Cowl Top Cover"](#).
2. Remove cowl top extension bracket. Refer to [EXT-35, "Exploded View"](#)
3. Disconnect harness connector from wiper motor.
4. Remove bolts from wiper drive assembly.
5. Remove wiper drive assembly.
6. Disconnect link 1 from wiper motor and wiper drive (if necessary).
7. Disconnect link 2 from wiper drive (if necessary).

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

N

O


P

FRONT WIPER

< REMOVAL AND INSTALLATION >

Tighten the bolts to specification in the sequence shown.

Bolts 1-3 : 5.74 N·m (0.59 kg·m, 51 in-lb)



WIPER MOTOR


WIPER MOTOR : Removal and Installation

INFOID:0000000014388999

REMOVAL

1. Remove front wiper drive assembly. Refer to [WW-49, "WIPER DRIVE ASSEMBLY : Removal and Installation".](#)
2. Disconnect link 1 from wiper motor.
3. Remove wiper motor bolts (B) and remove wiper motor.

(A) : Wiper motor bracket bolt



INSTALLATION

Installation is in the reverse order of removal.


WASHER TANK

< REMOVAL AND INSTALLATION >

WASHER TANK

Exploded View

INFOID:0000000014389000




- 1. Washer tank
- 2. Front washer motor
- 3. Washer fluid level switch
- 4. Washer tank inlet cap
- 5. Washer tank inlet
- A. Refer to INSTALLATION

Removal and Installation

INFOID:0000000014389001

REMOVAL

1. Remove clip (A) and pull washer tank inlet (1) out of washer tank.




ALLIA1906ZZ

WASHER TANK


< REMOVAL AND INSTALLATION >

2. Remove front fender protector (RH). Refer to [EXT-41, "Removal and Installation - Front Fender Protector".](#)
3. Disconnect washer tube (3).
4. Disconnect harness connector from front washer motor (1) and washer fluid level switch (2).



5. Remove washer tank bolts.
6. Remove washer tank as shown.

◀ :Front




INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Lubricate washer tank inlet tip with suitable water-based lubricant before installing.
- Add water up to the top of washer tank inlet after installing. Check that no leaks exist.
- Fill washer tank with specified amount of fluid. Refer to [WW-63, "Specifications".](#)
- Tighten the bolts to specification in the sequence shown.

Bolts 1-3 : 4.5 N·m (0.46 kg·m, 40 in·lb)




WASHER FLUID LEVEL SWITCH

< REMOVAL AND INSTALLATION >

WASHER FLUID LEVEL SWITCH

Exploded View

INFOID:0000000014389002



1. Washer tank inlet cap
2. Washer tank inlet
3. Washer tank
4. Washer fluid level switch
5. Front washer motor

Removal and Installation

INFOID:0000000014389003


WW

REMOVAL

1. Drain washer fluid.
2. Remove fender protector. Refer to [EXT-41, "Removal and Installation - Front Fender Protector"](#).
3. Disconnect harness connector from washer fluid level switch (2).

(1) : Front washer motor
(3) : Washer tube

4. Remove washer fluid level switch from washer tank.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

WASHER FLUID LEVEL SWITCH

< REMOVAL AND INSTALLATION >

- Add water up to the top of washer tank inlet after installing. Check that no leaks exist.
- Fill washer tank with specified amount of fluid. Refer to [WW-63, "Specifications"](#).


FRONT WASHER MOTOR

< REMOVAL AND INSTALLATION >

FRONT WASHER MOTOR

Exploded View

INFOID:0000000014389004



1. Washer tank inlet cap
2. Washer tank inlet
3. Washer tank
4. Washer fluid level switch
5. Front washer motor


Removal and Installation

INFOID:0000000014389005

WW

REMOVAL

1. Remove fender protector. Refer to [EXT-41, "Removal and Installation - Front Fender Protector"](#).
2. Drain washer fluid.
3. Disconnect harness connector from front washer motor (1).
- (2) : Washer fluid level switch
4. Disconnect washer tube (3).
5. Remove front washer motor from washer tank.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Add water up to the top of washer tank inlet after installing. Check that no leaks exist.

FRONT WASHER MOTOR

< REMOVAL AND INSTALLATION >

- Fill washer tank with specified amount of fluid. Refer to [WW-63, "Specifications"](#).


WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

WASHER NOZZLE AND TUBE

Exploded View

INFOID:0000000014389006



1. Washer nozzle
A. To front washer motor

2. Washer tube
△ Clip

3. Cowl top cover
○ Pawl

WASHER NOZZLE

WASHER NOZZLE : Removal and Installation

INFOID:0000000014389007


A
B
C
D
E
F
G
H
I
J
K

WW
M
N
O
P

REMOVAL

1. Remove cowl top cover. Refer to [EXT-35, "Removal and Installation - Cowl Top Cover"](#).
2. Disconnect washer tube from washer nozzle.
3. While pressing pawls on washer nozzle (1), remove washer nozzle from cowl top cover.

○ : Pawl



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Adjust the front nozzles to their proper position. Refer to [WW-58, "WASHER NOZZLE : Adjustment"](#).


WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

WASHER NOZZLE : Adjustment

INFOID:0000000014389008

ADJUSTMENT




1. Windshield glass	2. Black printed area line	3. Wiping area
A. Center line	B. 568 mm (22.4 in)	C. 58 mm (2.3 in)
D. 618 mm (24.3 in)	E. 208 mm (8.2 in)	F. 135 mm (5.3 in)
G. 436 mm (17.2 in)	H. 170 mm (6.7 in)	J. 457 mm (18.0 in)

NOTE:

Spray positions for LH shown, RH is symmetrical.

Insert a suitable tool (A) into washer nozzle hole (1) and move up/down and left/right to adjust the spray position of each nozzle.



WASHER TUBE

WASHER TUBE : Removal and Installation

INFOID:0000000014389009

REMOVAL


1. Drain washer fluid.
2. Remove cowl top cover. Refer to [EXT-35, "Removal and Installation - Cowl Top Cover"](#).
3. Disconnect washer tube from washer nozzles (LH/RH).

WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

4. Remove fender protector (RH). Refer to [EXT-41, "Removal and Installation - Front Fender Protector"](#).
5. Disconnect washer tube (3) from front washer motor (1).

(2) : Washer fluid level switch



6. Realease washer tube from clips and remove.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Add water up to the top of washer tank inlet after installing. Check that no leaks exist.
- Fill washer tank with specified amount of fluid. Refer to [WW-63, "Specifications"](#).

A
B
C
D

E

F

G

H

I

J

K

WW

M

N

O

P


RAIN SENSOR

< REMOVAL AND INSTALLATION >

RAIN SENSOR

Exploded View

INFOID:0000000014389010



1. Rain sensor bracket

2. Rain sensor

3. Rain sensor finisher

○ Pawl

Removal and Installation

INFOID:0000000014389011


CAUTION:

When the rain sensor is removed from the windshield, the rain sensor cannot be reused.

REMOVAL

1. Release rain sensor finishers pawls using a suitable tool, then remove the rain sensor finisher.
2. Disconnect harness connector from rain sensor.
3. Release metal bracket from pawls, then remove rain sensor from the windshield glass.

○ : Pawl



INSTALLATION

Installation is in the reverse order of removal.


CAUTION:

- Do not reuse rain sensor.


RAIN SENSOR

< REMOVAL AND INSTALLATION >

- Do not reuse rain sensor if dropped.
- The surface of the windshield should be cleaned.
- Remove protective cover from sensor just before installation.
- Do not touch gel/adhesive (A) after removing protective cover.



- Install rain sensor with connector facing upward.
- Press rain sensor at point (A), flush against the glass surface.
- Be sure the metal bracket fully engages the pawls and locked securely.



WIPER AND WASHER SWITCH

< REMOVAL AND INSTALLATION >

WIPER AND WASHER SWITCH

Removal and Installation

INFOID:0000000014389012

The wiper and washer switch is serviced as an assembly with the combination switch assembly. Refer to [BCS-80, "Removal and Installation".](#)

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications

INFOID:000000014389013

WINDSHIELD WASHER FLUID

Windshield washer fluid capacity	4.5 ℓ (4 3/4 US qt, 4 Imp qt)
Windshield washer fluid specification	Refer to MA-62, "Cummins 5.0L Engine : Fluids and Lubricants" (Cummins 5.0L) or MA-13, "VK56VD Gasoline Engine : Fluids and Lubricants" (VK56VD).

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P