

SECTION **LT** LIGHTING SYSTEM

CONTENTS

PRECAUTIONS	5	Sides)	21
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5	Headlamp High Beam Does Not Illuminate (One Side)	23
Maintenance Information	5	Headlamp Low Beam Does Not Illuminate (Both Sides)	25
RHD MODELS	5	Headlamp Low Beam Does Not Illuminate (One Side)	27
LHD MODELS	5	Headlamps Do Not Turn OFF	29
General Precautions for Service Operations	5	Aiming Adjustment	30
HEADLAMP - CONVENTIONAL TYPE-	7	PREPARATION BEFORE ADJUSTING	30
Component Parts and Harness Connector Location	7	LOW BEAM AND HIGH BEAM	30
System Description	7	Bulb Replacement	32
OUTLINE	7	HEADLAMP (HIGH/LOW)	32
HEADLAMP OPERATION	8	PARKING (CLEARANCE) LAMP	32
COMBINATION SWITCH READING FUNCTION	9	FRONT TURN SIGNAL LAMP	32
AUTO LIGHT OPERATION	9	Removal and Installation	32
FRIENDLY LIGHTING FUNCTION	9	REMOVAL	32
EXTERIOR LAMP BATTERY SAVER CONTROL	9	INSTALLATION	33
FAIL-SAFE FUNCTION	9	Disassembly and Assembly	34
CAN Communication System Description	9	DISASSEMBLY	34
CAN Communication Unit	9	ASSEMBLY	34
Schematic	10	HEADLAMP - DAYTIME LIGHT SYSTEM -	35
Wiring Diagram — H/LAMP —	11	Component Parts and Harness Connector Location	35
Terminals and Reference Values for BCM	15	System Description	35
Terminals and Reference Values for IPDM E/R	17	OUTLINE	35
How to Perform Trouble Diagnoses	17	HEADLAMP OPERATION	36
Preliminary Check	18	DAYTIME LIGHT OPERATION	37
CHECK POWER SUPPLY AND GROUND CIRCUIT	18	COMBINATION SWITCH READING FUNCTION	37
CONSULT-II Functions (BCM)	19	AUTO LIGHT OPERATION	37
CONSULT-II INSPECTION PROCEDURE	19	FRIENDLY LIGHTING FUNCTION	37
CONSULT-II Application Items (BCM)	19	EXTERIOR LAMP BATTERY SAVER CONTROL	37
WORK SUPPORT	19	FAIL-SAFE FUNCTION	37
DATA MONITOR	19	CAN Communication System Description	37
ACTIVE TEST	20	CAN Communication Unit	37
CONSULT-II Functions (IPDM E/R)	20	Schematic	38
CONSULT-II INSPECTION PROCEDURE	20	Wiring Diagram — DTRL —	39
CONSULT-II Application Items (IPDM E/R)	20	Terminals and Reference Values for BCM	42
DATA MONITOR	20	Terminals and Reference Values for IPDM E/R	43
ACTIVE TEST	20	How to Perform Trouble Diagnosis	43
Headlamp High Beam Does Not Illuminate (Both		Preliminary Check	44

INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT	44	Wiring Diagram—H/AIM—	69
CONSULT-II Functions (BCM)	45	Removal and Installation	72
CONSULT-II INSPECTION PROCEDURE	45	REMOVAL	72
CONSULT-II Application Items (BCM)	45	INSTALLATION	72
WORK SUPPORT	45	Switch Circuit Inspection	72
DATA MONITOR	45	FRONT FOG LAMP	73
ACTIVE TEST	46	Component Parts and Harness Connector Location ..	73
CONSULT-II Functions (IPDM E/R)	46	System Description	73
CONSULT-II INSPECTION PROCEDURE	46	OUTLINE	73
CONSULT-II Application Items (IPDM E/R)	46	FOG LAMP OPERATION	74
DATA MONITOR	46	COMBINATION SWITCH READING FUNCTION ..	74
ACTIVE TEST	46	EXTERIOR LAMP BATTERY SAVER CONTROL ..	74
Daytime Light Control Does Not Operate Properly ..	47	FAIL-SAFE FUNCTION	74
RH High beam Does Not Illuminate	48	CAN Communication System Description	74
RH Low Beam Does Not Illuminate	50	CAN Communication Unit	74
Headlamp High Beam Does Not Illuminate (Both Sides)	51	Schematic	75
Headlamp Low Beam Does Not Illuminate (Both Sides)	51	Wiring Diagram — F/FOG —	76
Headlamp LH High Beam Does Not Illuminate	51	Terminals and Reference Values for BCM	79
Headlamp LH Low Beam Does Not Illuminate	51	Terminals and Reference Values for IPDM E/R	80
Headlamps Do Not Turn OFF	51	How to Proceed With Trouble Diagnosis	80
Aiming Adjustment	51	Preliminary Check	81
Bulb Replacement	51	CHECK POWER SUPPLY AND GROUND CIR-	
Removal and Installation	51	CUIT	81
Disassembly and Assembly	51	CONSULT-II Functions (BCM)	82
AUTO LIGHT SYSTEM	52	CONSULT-II Functions (IPDM E/R)	82
Component Parts and Harness Connector Location ..	52	Front Fog lamps Do Not Illuminate (Both Sides) ...	82
System Description	52	Front Fog Lamp Does Not Illuminate (One Side) ...	85
OUTLINE	52	Aiming Adjustment	86
COMBINATION SWITCH READING FUNCTION ..	53	Bulb Replacement	86
FRIENDLY LIGHTING FUNCTION	53	Removal and Installation	87
EXTERIOR LAMP BATTERY SAVER CONTROL ..	53	REMOVAL	87
CAN Communication System Description	53	INSTALLATION	87
CAN Communication Unit	53	REAR FOG LAMP	88
Major Components and Functions	53	Component Parts and Harness Connector Location ..	88
Schematic	54	System Description	88
Wiring Diagram — AUTO/L —	55	OUTLINE	88
Terminals and Reference Values for BCM	59	COMBINATION SWITCH READING FUNCTION ..	89
Terminals and Reference Values for IPDM E/R	61	CAN Communication System Description	89
How to Proceed With Trouble Diagnosis	61	CAN Communication Unit	89
Preliminary Check	62	Wiring Diagram — R/FOG —	90
CHECK POWER SUPPLY AND GROUND CIR-		Terminals and Reference Values for BCM	92
CUIT	62	How to Proceed With Trouble Diagnosis	93
CONSULT-II Functions (BCM)	63	Preliminary Check	94
CONSULT-II INSPECTION PROCEDURE	63	CHECK POWER SUPPLY AND GROUND CIR-	
CONSULT-II Application Items	63	CUIT	94
WORK SUPPORT	63	CONSULT-II Functions (BCM)	94
DATA MONITOR	64	Rear Fog Lamp Does Not Operate	95
ACTIVE TEST	64	Bulb Replacement	97
Light and rain sensor System Inspection	65	Removal and Installation	97
Removal and Installation of Light and Rain Sensor ..	67	REMOVAL	97
REMOVAL	67	INSTALLATION	97
INSTALLATION OF LIGHT AND RAIN SENSOR ..	67	TURN SIGNAL AND HAZARD WARNING LAMPS...98	
INSTALLATION OF LIGHT AND RAIN SENSOR		Component Parts and Harness Connector Location ..	98
HOUSING	67	System Description	98
HEADLAMP AIMING CONTROL	68	TURN SIGNAL OPERATION	98
Schematic	68	HAZARD LAMP OPERATION	99
		COMBINATION SWITCH READING FUNCTION ..	100
		CAN Communication System Description	100
		CAN Communication Unit	100

Wiring Diagram — TURN —	101	Component Parts and Harness Connector Location	134	
Terminals and Reference Values for BCM	103	System Description	134	A
How to Proceed With Trouble Diagnosis	104	OPERATION BY LIGHTING SWITCH	134	
Preliminary Check	105	COMBINATION SWITCH READING FUNCTION	135	B
CHECK POWER SUPPLY AND GROUND CIR- CUIT	105	EXTERIOR LAMP BATTERY SAVER CONTROL	135	
CONSULT-II Functions (BCM)	106	FAIL-SAFE FUNCTION	135	C
CONSULT-II INSPECTION PROCEDURE	106	CAN Communication System Description	135	
CONSULT-II Application Items	106	CAN Communication Unit	135	D
WORK SUPPORT	106	Schematic	136	
DATA MONITOR	106	Wiring Diagram — TAIL/L —	137	E
ACTIVE TEST	106	Terminals and Reference Values for BCM	140	
Turn Signal Lamp Does Not Operate	107	Terminals and Reference Values for IPDM E/R ...	141	F
Hazard Warning Lamp Does Not Operate But Turn Signal Lamp Operates	109	How to Proceed With Trouble Diagnosis	141	
Bulb Replacement (Front Turn Signal Lamp)	111	Preliminary Check	142	G
Bulb Replacement (Rear Turn Signal Lamp)	111	CHECK POWER SUPPLY AND GROUND CIR- CUIT	142	
Bulb Replacement (Side Turn Signal Lamp)	111	CONSULT-II Functions (BCM)	143	H
Removal and Installation of Front Turn Signal Lamp	111	CONSULT-II Functions (IPDM E/R)	143	
Removal and Installation of Rear Turn Signal Lamp	111	Parking, License Plate and Tail Lamps Do Not Illu- minate	143	I
Removal and Installation of Side Turn Signal Lamp	111	Parking, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)	147	
REMOVAL	111	Bulb Replacement	148	J
INSTALLATION	111	PARKING LAMP	148	
LIGHTING AND TURN SIGNAL SWITCH	112	LICENSE PLATE LAMP	148	LT
Removal and Installation	112	TAIL LAMP	148	
REMOVAL	112	Removal and Installation	148	
INSTALLATION	112	PARKING LAMP	148	
HAZARD SWITCH	113	LICENSE PLATE LAMP	148	
Removal and Installation	113	TAIL LAMP	148	
REMOVAL	113	REAR COMBINATION LAMP	149	
INSTALLATION	113	Bulb Replacement	149	
COMBINATION SWITCH	114	Removal and Installation	149	
System Description	114	REMOVAL	149	
COMBINATION SWITCH READING FUNCTION	114	INSTALLATION	149	
Wiring Diagram — COMBSW —	117	INTERIOR ROOM LAMP	150	
Terminals and Reference Values for BCM	118	Component Parts and Harness Connector Location	150	
Reference Values for BCM (Input)	121	System Description	150	L
CONSULT-II Function (BCM)	124	POWER SUPPLY AND GROUND	150	
CONSULT-II INSPECTION PROCEDURE	124	SWITCH OPERATION	151	
CONSULT-II Application Items	124	INTERIOR ROOM LAMP TIMER OPERATION	152	M
DATA MONITOR	124	INTERIOR ROOM LAMP BATTERY SAVER CONTROL	152	
Combination Switch Inspection	125	Schematic	153	
Removal and Installation	128	—MODELS WITHOUT PERSONAL LAMP— ..	153	
STOP LAMP	129	—MODELS WITH PERSONAL LAMP—	154	
Wiring Diagram — STOP/L —	129	Wiring Diagram — ROOM/L —	155	
Bulb Replacement of High-Mounted Stop Lamp .	130	—MODELS WITHOUT PERSONAL LAMP— ..	155	
Bulb Replacement of Rear Combination Lamp (Stop Lamp)	130	—MODELS WITH PERSONAL LAMP—	159	
Removal and Installation of High-Mounted Stop Lamp	130	Terminals and Reference Values for BCM	163	
REMOVAL	130	How to Proceed With Trouble Diagnosis	164	
INSTALLATION	130	Preliminary Check	165	
Removal and Installation of Rear Combination Lamp (Stop Lamp)	130	CHECK POWER SUPPLY AND GROUND CIR- CUIT	165	
BACK-UP LAMP	131	CONSULT-II Functions (BCM)	166	
Wiring Diagram — BACK/L —	131	CONSULT-II INSPECTION PROCEDURE	166	
Bulb Replacement	133	CONSULT-II Application Items	166	
Removal and Installation	133	DATA MONITOR	166	
PARKING, LICENSE PLATE AND TAIL LAMPS ..	134	ACTIVE TEST	166	

Map Lamp Control Does Not Operate	167	ILLUMINATION OPERATION BY LIGHTING	
Personal Lamp Control Does Not Operate (Models		SWITCH	173
With Personal Lamp)	169	EXTERIOR LAMP BATTERY SAVER CONTROL	174
Bulb Replacement	171	CAN Communication System Description	174
MAP LAMP, PERSONAL LAMP	171	CAN Communication Unit	174
LUGGAGE LOOM LAMP	171	Schematic	175
Removal and Installation	171	Wiring Diagram — ILL —	176
MAP LAMP, PERSONAL LAMP	171	BULB SPECIFICATIONS	183
LUGGAGE ROOM LAMP	172	Headlamp	183
ILLUMINATION	173	Exterior Lamp	183
System Description	173	Interior Lamp/Illumination	183

PRECAUTIONS

PRECAUTIONS

PFP:00011

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

BKS001CE

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Maintenance Information

BKS002BK

If any of following part is replaced, always replace with new* one.

If it's not (or fail to do so), the electrical system may not be operated properly.

*: New one means a virgin control unit that has never been energized on-board.

RHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM
- IPDM E/R
- Combination meter
- EPS control unit


LHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM

General Precautions for Service Operations


BKS001CF

- Never work with wet hands.
- Xenon headlamp includes high voltage generating part. Be sure to disconnect battery negative cable (negative terminal) or power fuse before removing, installing, or touching the xenon headlamp (including lamp bulb).
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- When turning the xenon headlamp on and while it is illuminated, never touch the harness, bulb, and socket of the headlamp.
- When checking the headlamp on/off operation, check it on vehicle and with the power connected to the vehicle-side connector.
- Do not touch the headlamp bulb glass surface with bare hands or allow oil or grease to get on it. Do not touch the headlamp bulb just after the headlamp is turned off, because it is very hot.



PRECAUTIONS

- Install the xenon headlamp bulb socket correctly. If it is installed improperly, high-voltage leak or corona discharge may occur that can melt the bulb, connector, and housing. Do not illuminate the xenon headlamp bulb out of the headlamp housing. Doing so can cause fire and harm your eyes.
- When the bulb has burned out, wrap it in a thick vinyl bag and discard. Do not break the bulb.
- Leaving the bulb removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- When adjusting the headlamp aiming, turn the aiming adjustment screw only in the tightening direction. (If it is necessary to loosen the screw, first fully loosen the screw, and then turn it in the tightening direction.)
- Do not use organic solvent (paint thinner or gasoline) to clean lamps and to remove old sealant.




HEADLAMP -CONVENTIONAL TYPE-

HEADLAMP -CONVENTIONAL TYPE-

PFP:26010

Component Parts and Harness Connector Location

BKS001CH



1. IPDM E/R E8,E11,E12

2. BCM M57,M59 (View with instrument upper panel removed)

3. Combination switch M38

4. Combination meter M27

MKIB2268E

System Description

BKS001CI

The control of the headlamp system operation is dependent upon the position of the combination switch (lighting switch). When the lighting switch is placed in the 2ND position, the BCM (body control module) receives input signal requesting the headlamps (and tail lamps) illuminate. This input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication. The CPU (central processing unit) located in the IPDM E/R controls the headlamp high and headlamp low relay coils. These relays, when energized, direct power to the respective headlamps, which then illuminate.

OUTLINE

Power is supplied at all times

- to ignition relay (located in IPDM E/R),
- to headlamp high RH and LH relay (located in IPDM E/R)
- to headlamp low relay (located in IPDM E/R) from battery directly,
- through 20A fuse (No. 61, located in IPDM E/R),
- through 20A fuse (No. 62, located in IPDM E/R),
- through 40A fusible link (letter J, located in fuse, fusible link and relay box)
- to BCM terminals 74 and 79,
- through 10A fuse [No. 7, located in fuse block (J/B)]
- to combination meter terminal 27.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay (located in IPDM E/R) from battery directly,
- through 10A fuse [No. 5, located in fuse block (J/B)]
- to BCM terminal 24,
- through 10A fuse [No. 4, located in fuse block (J/B)]
- to combination meter terminal 28.

Ground is supplied

- to BCM terminals 2 and 70
- to combination meter terminals 21, 22 and 23

A
B
C
D
E
F
G
H

LT

L
M

HEADLAMP -CONVENTIONAL TYPE-

- through grounds M21 and M66,
- to IPDM E/R terminals 3 and 54
- through grounds E45 (CR and HR engine models),E28 and E44.

HEADLAMP OPERATION

Low Beam Operation

With the lighting switch in 2ND position, the BCM receives input signal requesting the headlamps to illuminate. This input signal is communicated to the IPDM E/R via the CAN communication. The CPU located in the IPDM E/R controls the headlamp low relay coil, which when energized, directs power

- through 15A fuse (No. 50, located in IPDM E/R)
- through IPDM E/R terminal 48
- to headlamp RH terminal 1,
- through 15A fuse (No. 49, located in IPDM E/R)
- through IPDM E/R terminal 50
- to headlamp LH terminal 1.

Ground is supplied

- to headlamp RH and LH terminals 3
- through grounds E45 (CR and HR engine models),E28 and E44.

With power and ground supplied, low beam headlamps illuminate.

High Beam Operation/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH or PASS position, the BCM receives input signal requesting the headlamp high beams to illuminate. This input signal is communicated to the IPDM E/R via the CAN communication. The CPU located in the IPDM E/R controls the headlamp high relay coil, which when energized, directs power

- through 10A fuse (No. 43, located in IPDM E/R)
- through IPDM E/R terminal 46
- to headlamp RH terminal 2,
- through 10A fuse (No. 44, located in IPDM E/R)
- through IPDM E/R terminal 47
- to headlamp LH terminal 2.

Ground is supplied

- to headlamp RH and LH terminals 3
- through grounds E45 (CR and HR engine models),E28 and E44.

With power and ground supplied, the high beam headlamps illuminate.

The combination meter that received the high beam request signal by BCM via the CAN communication makes a high beam indicator lamp turn ON in combination meter.

HEADLAMP -CONVENTIONAL TYPE-

COMBINATION SWITCH READING FUNCTION

Refer to [LT-114, "COMBINATION SWITCH READING FUNCTION"](#) .

AUTO LIGHT OPERATION

Refer to [LT-52, "System Description"](#) .

FRIENDLY LIGHTING FUNCTION

Low beam headlamps will illuminate for 30 seconds when,

- ignition switch is in OFF position,
- lighting switch is placed in OFF position, and
- lighting switch is placed in PASS position.

Each activation of the switch adds 30 seconds to a maximum of 2 minutes.

EXTERIOR LAMP BATTERY SAVER CONTROL

To avoid flat battery caused by user leaving exterior lamps ON. When ignition is OFF and the driver side door is opened, all exterior lamps will be turned OFF. If the user wants some lamps to remain ON then they must switch these lamps OFF then ON again with the combination switch once the driver side door has been opened. A buzzer will sound if any exterior lamps are ON with the driver side door opened and ignition OFF.

*:This setting can be changed by CONSULT-II. Refer to [LT-19, "WORK SUPPORT"](#) .

FAIL-SAFE FUNCTION

When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. If the fail-safe system is operating, headlamps illuminate when the ignition switch is turned from OFF to ON and headlamps are turned off when the ignition switch is turn from ON to OFF. If the fail-safe system is operating, headlamps does not operate when the combination switch is in any position. After CAN communication recovers normally, it also returns to normal control. (Refer to [PG-18, "Fail-safe Control"](#) .)

CAN Communication System Description

BKS001CJ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit


BKS001CK

Refer to [LAN-27, "CAN Communication Unit"](#) .

HEADLAMP -CONVENTIONAL TYPE-

Schematic

BKS001CL




MKWA4318E

HEADLAMP -CONVENTIONAL TYPE-

Wiring Diagram — H/LAMP —

BKS001CM



REFER TO THE FOLLOWING.

(M1) - SUPER MULTIPLE

JUNCTION (SMJ)

(M7) - FUSE BLOCK -



JUNCTION BOX (J/B)

MKWA4319E

HEADLAMP -CONVENTIONAL TYPE-

CH : CR AND HR ENGINE MODELS

LT-H/LAMP-02





MKW44320E

HEADLAMP -CONVENTIONAL TYPE-

LT-H/LAMP-03


CH : CR AND HR ENGINE MODELS



MKWA4321E

HEADLAMP -CONVENTIONAL TYPE-

LT-H/LAMP-04



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M14)
W

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M27)
W

REFER TO THE FOLLOWING.

(M7) - FUSE BLOCK - JUNCTION BOX (J/B)






HEADLAMP -CONVENTIONAL TYPE-

Terminals and Reference Values for BCM






BKS001CN

CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-19, "DATA MONITOR"](#) .

Ter- minal No.	Wire color	Signal name	Signal input/ output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
2	B	Ground	—	ON	—	Approx. 0V
8	L	Combination switch output 3	Output	ON	Lighting, turn, wiper switch (Wiper intermit- tent dial position 4) OFF	 <p>PKIB4958J</p> <p>Approx. 1.2V</p>
					Any of the conditions below <ul style="list-style-type: none"> ● Lighting switch 2ND ● Lighting switch HI beam (Operates only HI beam switch) 	 <p>PKIB4959J</p> <p>Approx. 1.0V</p>
15	W	Combination switch input 5	Input	ON	Lighting, turn, wiper switch (Wiper intermit- tent dial position 4) OFF	 <p>PKIB4956J</p> <p>Approx. 0.9V</p>
					Lighting switch 2ND	 <p>PKIB8639J</p> <p>Approx. 2.5 - 3.0V</p>
					Lighting switch HIGH beam (Operates only HIGH beam switch)	 <p>PKIB8644J</p> <p>Approx. 1.5 - 2.0V</p>
19	L	CAN - H	Input/ Output	ON	—	Approx. 2.6V

HEADLAMP -CONVENTIONAL TYPE-

Ter- minal No.	Wire color	Signal name	Signal input/ output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
24	O	Ignition switch (ON)	Input	ON	—	Battery voltage
28	G	Combination switch output 2	Output	ON	Lighting, turn, wiper switch (Wiper intermit- tent dial position 4)	<div> OFF  <p>PKIB4958J</p> <p>Approx. 1.2V</p> </div>
					Any of the conditions below <ul style="list-style-type: none"> ● Lighting switch 2ND ● Lighting switch PASSING (Operates only PASSING switch) 	<div>  <p>PKIB4959J</p> <p>Approx. 1.0V</p> </div>
34	Y	Combination switch input 4	Input	ON	Lighting, turn, wiper switch (Wiper intermit- tent dial position 4)	<div> OFF  <p>PKIB4958J</p> <p>Approx. 1.0V</p> </div>
					Lighting switch 2ND	<div>  <p>PKIB8628J</p> <p>Approx. 1.5 - 2.0V</p> </div>
					Lighting switch PASSING (Operates only PASSING switch)	<div>  <p>PKIB8629J</p> <p>Approx. 2.0V</p> </div>
39	Y	CAN - L	Input/ Output	ON	—	Approx. 2.4V
70	B	Ground	—	ON	—	Approx. 0V
74 79	Y	Battery power supply	Input	OFF	—	Battery voltage

HEADLAMP -CONVENTIONAL TYPE-

Terminals and Reference Values for IPDM E/R

BKS001CO

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition			Reference value
				Ignition switch	Operation or condition		
3	B	Ground	—	ON	—		Approx. 0V
46	Y	Headlamp HIGH RH	Output	ON	Lighting switch HIGH beam or PASSING position	OFF	Approx. 0V
						ON	Battery voltage
47	G	Headlamp HIGH LH		ON	Lighting switch HIGH beam or PASSING position	OFF	Approx. 0V
						ON	Battery voltage
48	P	Headlamp LOW RH		ON	Lighting switch 2ND position	OFF	Approx. 0V
						ON	Battery voltage
50	L	Headlamp LOW LH		ON	Lighting switch 2ND position	OFF	Approx. 0V
						ON	Battery voltage
52	L	CAN – H	Input/Output	—	—		—
54	B	Ground	—	ON	—		Approx. 0V
58	Y	CAN – L	Input/Output	—	—		—

How to Perform Trouble Diagnoses

BKS001CP

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-7, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-18, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the headlamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

LT

L

M

HEADLAMP -CONVENTIONAL TYPE-

Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

BKS001CQ

1. CHECK FUSE

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	J
	Ignition switch ON or START position	5
IPDM E/R	Battery	43
		44
		49
		50
		61
		62

Refer to [LT-11, "Wiring Diagram — H/LAMP —"](#).

OK or NG


OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+) Terminal		(-) Ground	OFF	ACC	ON
BCM Connector	Terminal				
M57	24	Ground	Approx. 0V	Approx. 0V	Battery voltage
M59	74		Battery voltage	Battery voltage	Battery voltage
	79		Battery voltage	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M57	2	Ground	Yes
M59	70		

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



HEADLAMP -CONVENTIONAL TYPE-

CONSULT-II Functions (BCM)

BKS001CR

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

CONSULT-II INSPECTION PROCEDURE

Refer to [GI-36, "CONSULT-II Start Procedure"](#) .

CONSULT-II Application Items (BCM)

BKS001LZ

WORK SUPPORT

Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "BATTERY SAVER SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Select exterior lamp battery saver control mode between ON and OFF.	ON	×
		OFF	—

DATA MONITOR

Monitor item	UNIT.	Display content
IGN ON SW	[ON/OFF]	Displays status (Ignition switch ON: ON/Others OFF, ACC: OFF) as judged from the ignition switch signal.
HI BEAM SW	[ON/OFF]	Displays status (High beam switch: ON/Others: OFF) as judged from lighting switch signal.
H/L SW POS	[ON/OFF]	Displays status (Headlamp switch: ON/Others: OFF) as judged from lighting switch signal.
LIGHT SW 1ST	[ON/OFF]	Displays status (Lighting switch 1st position: ON/Others: OFF) as judged from lighting switch signal.
PASSING SW	[ON/OFF]	Displays status (Flash-to-pass switch: ON/Others: OFF) as judged from lighting switch signal.
FR FOG SW	[ON/OFF]	Displays status (Front fog lamp switch: ON/Others: OFF) as judged from lighting switch signal.
RR FOG SW	[ON/OFF]	Displays status (Rear fog lamp switch: ON/Others: OFF) as judged from lighting switch signal.
DOOR SW-DR	[ON/OFF]	Displays status (Door open: ON/door closed: OFF) as judged from the door switch DR signal.
H/L WASH SW	[ON/OFF]	Displays status (Headlamp washer switch: ON/Others: OFF) as judged from headlamp washer switch signal.
ENGINE STATUS	[STOP/ STALL/ RUN/ CRA]	Displays status (Engine stop: STOP/engine stall: STALL/engine running: RUN/engine cranking: CRA) as judged from the engine status.

HEADLAMP -CONVENTIONAL TYPE-

ACTIVE TEST

Test item	CONSULT-II screen display	Description
Tail lamp relay output	TAIL LAMP	Tail lamp relay can be operated by any ON–OFF operation.
Headlamp relay output	HEAD LAMP	Headlamp relay can be operated by any ON–OFF operation.
Front fog lamp relay output	FR FOG LAMP	Front fog lamp relay can be operated by any ON–OFF operation.
Rear fog lamp relay output	RR FOG LAMP	Rear fog lamp relay can be operated by any ON–OFF operation.

CONSULT-II Functions (IPDM E/R)

BKS001LC

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to PG-20, "SELF-DIAG RESULTS" .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

CONSULT-II INSPECTION PROCEDURE

Refer to [GI-36, "CONSULT-II Start Procedure"](#) .

CONSULT-II Application Items (IPDM E/R)

BKS001M0

DATA MONITOR

All Signals, Main Signals, Selection From Menu

Monitor item name	Display and unit	Monitor item selection			Display content
		All signals	Main signals	selection from menu	
TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
IGN RLY	ON/OFF	×	×	×	Status of ignition relay being monitored by IPDM E/R

ACTIVE TEST

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	HEAD LAMP	Headlamp relay (LO, HI) can be operated using random operation (OFF, HI ON, LO ON).
Front fog lamp relay output	FRONT FOG LAMP	Fog lamp relay can be operated by any ON–OFF operation.
Tail lamp relay output	TAIL LAMP	Tail lamp relay can be operated by any ON–OFF operation.

HEADLAMP -CONVENTIONAL TYPE-

Headlamp High Beam Does Not Illuminate (Both Sides)

BKS001CT

1. CHECK COMBINATION SWITCH INPUT SIGNAL

① With CONSULT-II

1. Select "BCM" on CONSULT-II. Select "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR" on "SELECT DIAG MODE" screen. Make sure that "HI BEAM SW" turns ON-OFF linked with operation of lighting switch.

When lighting switch is high : HI BEAM SW ON position

② Without CONSULT-II

Refer to [LT-125, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-125, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
HI BEAM SW	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7585E

2. HEADLAMP ACTIVE TEST

① With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II. Select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "HEADLAMP" on "SELECT TEST ITEM" screen.
3. Touch "HI" screen.
4. Make sure headlamp high beam operates.

Headlamp high beam should operate

② Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. Make sure headlamp high beam operates.

Headlamp high beam should operate.

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST			
HEAD LAMP		OFF	
HI	LO		
MODE	BACK	LIGHT	COPY

SKIA2339E

3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II. Select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL HI REQ" turns ON when lighting switch is in high position.

When lighting switch is high : HL HI REQ ON position

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#).

NG >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

DATA MONITOR			
MONITOR			
HL HI REQ	ON		
		RECORD	
MODE	BACK	LIGHT	COPY

PKIB8696E


HEADLAMP -CONVENTIONAL TYPE-

4. CHECK HEADLAMP INPUT SIGNAL

④ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect headlamp RH and LH connector.
3. Select "IPDM E/R" on CONSULT-II. Select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "HEADLAMP" on "SELECT TEST ITEM" screen.
5. Touch "HI" screen.
6. When headlamp high beam is operating, check voltage between headlamp RH and LH harness connector and ground.

Terminal				Voltage
(+)		(-)		
Headlamp connector	Terminal			
RH	E26	2	Ground	Battery voltage
LH	E46			



⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect headlamp RH and LH connector.
3. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
4. When headlamp high beam is operating, check voltage between headlamp RH and LH harness connector and ground.

Terminal				Voltage
(+)		(-)		
Headlamp connector	Terminal			
RH	E26	2	Ground	Battery voltage
LH	E46			

OK or NG

- OK >> GO TO 5.
NG >> GO TO 6.


5. CHECK HEADLAMP GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between headlamp RH and LH harness connector and ground.

Headlamp connector		Terminal	Ground	Continuity
RH	E26	3	Ground	Yes
LH	E46			

OK or NG

- OK >> Check headlamp bulb.
NG >> Repair harness or connector.



HEADLAMP -CONVENTIONAL TYPE-

6. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector (A) and headlamp RH and LH harness connector (B).


Circuit	A		B		Continuity
	Connector	Terminal	Connector	Terminal	
RH	E8	46	E26	2	Yes
LH		47	E46		

4. Check continuity between IPDM E/R harness connector (A) and ground.

Circuit	A		Ground	Continuity
	Connector	Terminal		
RH	E8	46		No
LH		47		

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#) .
- NG >> Repair harness or connector.



Headlamp High Beam Does Not Illuminate (One Side)

BKS001CU

1. CHECK BULB

Check headlamp bulb which does not illuminate.

OK or NG

- OK >> GO TO 2.
- NG >> Replace bulb.


2. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect headlamp RH or LH connector.
3. Turn ignition switch ON.
4. Lighting switch is turned to HIGH position.
5. Check voltage between headlamp RH or LH harness connector and ground.

Terminal			Voltage
(+) Terminal		(-) Terminal	
Headlamp connector	Terminal		
RH	E26	2	Ground
LH	E46		

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 4.



HEADLAMP -CONVENTIONAL TYPE-


3. CHECK HEADLAMP GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between headlamp RH or LH harness connector and ground.

Headlamp connector		Terminal	Ground	Continuity
RH	E26	3		Yes
LH	E46			

OK or NG

- OK >> Check connecting condition headlamp harness connector.
- NG >> Repair harness or connector.



4. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector (A) and headlamp RH or LH harness connector (B).


Circuit	A		B		Continuity
	Connector	Terminal	Connector	Terminal	
RH	E8	46	E26	2	Yes
LH		47	E46		

4. Check continuity between IPDM E/R harness connector (A) and ground.

Circuit	A		Ground	Continuity
	Connector	Terminal		
RH	E8	46		No
LH		47		

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.



HEADLAMP -CONVENTIONAL TYPE-

Headlamp Low Beam Does Not Illuminate (Both Sides)

BKS001CV

1. CHECK COMBINATION SWITCH INPUT SIGNAL

① With CONSULT-II

1. Select "BCM" on CONSULT-II. Select "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR" on "SELECT DIAG MODE" screen. Make sure that "H/L SW POS" turns ON-OFF linked with operation of lighting switch.

When lighting switch is 2nd position : H/L SW POS ON

When lighting switch is OFF position : H/L SW POS OFF

DATA MONITOR			
MONITOR			
H/L SW POS		ON	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

MKIB2276E

② Without CONSULT-II

Refer to [LT-125, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-125, "Combination Switch Inspection"](#).

2. CHECK HEADLAMP ACTIVE TEST

① With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II. Select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "HEADLAMP" on "SELECT TEST ITEM" screen.
3. Touch "LO" screen.
4. Make sure headlamp low beam operates.

Headlamp low beam should operate.

② Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. Make sure headlamp low beam operates.

Headlamp low beam should operate.

ACTIVE TEST			
HEAD LAMP		OFF	
HI		LO	
MODE	BACK	LIGHT	COPY

SKIA2339E

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II. Select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" turns ON when lighting switch is in 2ND position.

When lighting switch is 2ND position : HL LO REQ ON

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#).

NG >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

DATA MONITOR			
MONITOR			
HL LO REQ		ON	
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7644E


HEADLAMP -CONVENTIONAL TYPE-

4. CHECK HEADLAMP INPUT SIGNAL

 With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect headlamp RH and LH connector.
3. Select "IPDM E/R" on CONSULT-II. Select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "HEADLAMP" on "SELECT TEST ITEM" screen.
5. Touch "LO" screen.
6. When headlamp low beam is operating, check voltage between headlamp RH and LH harness connector and ground.

Terminal				Voltage
(+)		(-)		
Headlamp connector	Terminal			
RH	E26	1	Ground	Battery voltage
LH	E46			



 Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect headlamp RH and LH connector.
3. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
4. When headlamp low beam is operating, check voltage between headlamp RH and LH harness connector and ground.

Terminal				Voltage
(+) Terminal		(-)		
Headlamp connector	Terminal			
RH	E26	1	Ground	Battery voltage
LH	E46			

OK or NG

- OK >> GO TO 5.
NG >> GO TO 6.


5. CHECK HEADLAMP GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between headlamp RH and LH harness connector and ground.

Headlamp connector		Terminal	Ground	Continuity
RH	E26	3	Ground	Yes
LH	E46			

OK or NG

- OK >> Check headlamp bulbs.
NG >> Repair harness or connector.



HEADLAMP -CONVENTIONAL TYPE-

6. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector (A) and headlamp RH or LH harness connector (B).


Circuit	A		B		Continuity
	Connector	Terminal	Connector	Terminal	
RH	E8	48	E26	1	Yes
LH		50	E46		

4. Check continuity between IPDM E/R harness connector (A) and ground.

Circuit	A		Ground	Continuity
	Connector	Terminal		
RH	E8	48		No
LH		50		

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#) .
 NG >> Repair harness or connector.



Headlamp Low Beam Does Not Illuminate (One Side)

BKS001CW

1. CHECK BULB

Check bulb of headlamp which does not illuminate.

OK or NG

- OK >> GO TO 2.
 NG >> Replace bulb.


2. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect headlamp RH or LH connector.
3. Turn ignition switch ON.
4. Lighting switch is turned to 2ND position.
5. Check voltage between headlamp RH or LH harness connector and ground.

Terminal			Voltage
(+) Terminal		(-) Terminal	
Headlamp connector	Terminal		
RH	E26	1	Ground
LH	E46		

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 4.



HEADLAMP -CONVENTIONAL TYPE-


3. CHECK HEADLAMP GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between headlamp RH or LH harness connector and ground.

Headlamp connector		Terminal	Ground	Continuity
RH	E26	3		Yes
LH	E46			

OK or NG

- OK >> Check connecting condition headlamp harness connector.
- NG >> Repair harness or connector.



4. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector (A) and headlamp RH or LH harness connector (B).


Circuit	A		B		Continuity
	Connector	Terminal	Connector	Terminal	
RH	E8	48	E26	1	Yes
LH		50	E46		

4. Check continuity between IPDM E/R harness connector (A) and ground.

Circuit	A		Ground	Continuity
	Connector	Terminal		
RH	E8	48		No
LH		50		

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.



HEADLAMP -CONVENTIONAL TYPE-

Headlamps Do Not Turn OFF

BKS001CX

1. CHECK HEADLAMP TURN OFF

Make sure that lighting switch is OFF. And make sure headlamp turns off when ignition switch is turned OFF.

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.

2. CHECK COMBINATION SWITCH INPUT SIGNAL

1. Select "BCM" on CONSULT-II. Select "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR" on "SELECT DIAG MODE" screen. Make sure that "H/L SW POS" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

When lighting switch is : H/L SW POS OFF
OFF position

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#) .
- NG >> Check combination switch (lighting switch). Refer to [LT-125, "Combination Switch Inspection"](#) .

DATA MONITOR			
MONITOR			
H/L SW POS		OFF	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

MKIB2279E

3. CHECKING CAN COMMUNICATIONS BETWEEN BCM AND IPDM E/R

Select "BCM" on CONSULT-II, and perform self-diagnosis for "BCM".

Display of self-diagnosis results

- NO DTC>> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#) .
- CAN COMM CIRCUIT>> Refer to [BCS-17, "CAN Communication Inspection With CONSULT-II \(Self-Diagnosis\)"](#) .


SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]			
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA7627E

HEADLAMP -CONVENTIONAL TYPE-

Aiming Adjustment

BKS001M7



- Turn the aiming adjusting screw to adjust.
- For positions of the adjustment screws, refer to the figures.

CAUTION:

Adjustment with the aiming adjusting screw must be done in the tightening direction. (When adjusting in the loosening direction, first loosen the screw, then tighten again.)

PREPARATION BEFORE ADJUSTING

For details, refer to the regulations in your own country.

Before performing aiming adjustment, check the following.

1. Keep all tires inflated to correct pressures.
2. Place vehicle on flat surface.
3. Set that there is no-load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant, engine oil filled up to correct level and full fuel tank.

LOW BEAM AND HIGH BEAM

NOTE:

Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.

1. Turn headlamp low beam ON.
2. Use adjusting screws to perform aiming adjustment.
 - First tighten the adjusting screw all the way and then make adjustment by loosening the screw. If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

HEADLAMP -CONVENTIONAL TYPE-

- Adjust headlamps so that main axis of light is parallel to center line of body and is aligned with point P shown in illustration.
- Figure shows headlamp aiming pattern for driving on right side of road; for driving on left side of road, aiming pattern is reversed.
- Dotted lines to point P in illustration show center of headlamp.

"H" : Horizontal center line of headlamps

"WL" : Distance between each headlamp center


"L" : 25,000 mm (984.25 in)

"C" : 250 mm (9.84 in) – 310 mm (12.20 in)

- Elbow point for LHD models must be in 300 mm (11.81 in) to the right from point P.
- Elbow point for RHD models must be in 300 mm (11.81 in) to the left from point P.
- Basic illuminating area for adjustment should be within the range shown in the figure. Adjust headlamps accordingly.

CAUTION:

Be sure aiming switch is set to "0" when performing aiming adjustment.



HEADLAMP -CONVENTIONAL TYPE-

BKS001CZ

Bulb Replacement

CAUTION:

After installing bulb, be sure to install plastic cap and bulb socket securely to ensure watertightness.

HEADLAMP (HIGH/LOW)

1. Turn lighting switch OFF.
2. Remove the socket connected to the bulb.
3. Remove back cover.
4. Unlock retaining spring and remove bulb from headlamp.

Headlamp (High/Low)

: 12V - 60/55W (H4)

PARKING (CLEARANCE) LAMP

1. Turn lighting switch OFF.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb from its socket.

Parking (Clearance) lamp

: 12V - 5W

FRONT TURN SIGNAL LAMP


1. Turn lighting switch OFF.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb from its socket.

Front turn signal lamp

: 12V - 21W (amber)

Removal and Installation

BKS001D0



1. Bolt

2. Headlamp

REMOVAL

1. Disconnect the battery cable from the negative terminal.
2. Remove front bumper. Refer to [EI-4, "FRONT BUMPER"](#).
3. Remove headlamp mounting bolts.
4. Pull headlamp toward the vehicle front, disconnect connector, and remove headlamp.

CAUTION:

When removing headlamps, put a shop cloth or something similar between headlamps and bumper to protect bumper.

HEADLAMP -CONVENTIONAL TYPE-

INSTALLATION

Installation is the reverse order of removal.

Headlamp mounting bolt  : 5.5 N·m (0.56 kg-m, 49 in-lb)

NOTE:

After installation, perform aiming adjustment. Refer to [LT-30, "Aiming Adjustment"](#) .

A

B

C

D

E

F

G

H

I

J

LT


L

M

HEADLAMP -CONVENTIONAL TYPE-

Disassembly and Assembly

BKS001D1



- | | | |
|---------------------------------------|----------------------------------|---|
| 1. Retaining spring | 2. Parking (clearance) lamp bulb | 3. Parking (clearance) lamp bulb socket |
| 4. Halogen bulb (High/Low) | 5. Back cover | 6. Front turn signal lamp bulb |
| 7. Front turn signal lamp bulb socket | 8. Headlamp housing assembly | |

DISASSEMBLY

1. Disconnect the socket connected to the bulb (High/low).
2. Remove back cover.
3. Unlock retaining spring and remove bulb (High/Low).
4. Turn parking (clearance) lamp bulb socket counterclockwise and unlock it.
5. Remove parking (clearance) lamp bulb from its socket.
6. Turn front turn signal lamp bulb socket counterclockwise and unlock it.
7. Remove front turn signal lamp bulb from its socket.

ASSEMBLY

Assembly is the reverse order of disassembly.

CAUTION:

- After installing bulb, be sure to install plastic cap and bulb socket securely to insure watertightness.


HEADLAMP - DAYTIME LIGHT SYSTEM -

HEADLAMP - DAYTIME LIGHT SYSTEM -

PFP:26010

Component Parts and Harness Connector Location

BKS001D2



1. IPDM E/R E8,E11,E12

2. BCM M57,M59 (View with instrument upper panel removed)

3. Combination switch M38

4. Combination meter M27

5. Daytime light relay E54

System Description

BKS001D3

DAYTIME LIGHT SYSTEM turns on daytime light lamps while engine is running.

Engine run or stop signal are sent to BCM (body control module) by CAN communication line, and control daytime light system.

OUTLINE

Power is supplied at all times

- to ignition relay (located in IPDM E/R),
- to headlamp high RH and LH relay (located in IPDM E/R)
- to headlamp low relay (located in IPDM E/R) from battery directly,
- through 20A fuse (No. 61, located in IPDM E/R),
- through 20A fuse (No. 62, located in IPDM E/R),
- through 40A fusible link (letter J, located in fuse and fusible link block)
- to BCM terminals 74 and 79,
- through 10A fuse [No. 7, located in fuse block (J/B)]
- to combination meter terminal 27,
- through 10A fuse (No. 37, located in fuse and fusible link block)
- to daytime light relay terminals 1 and 5.

When the ignition switch is in ON or START position, power is supplied

- to ignition relay (located in IPDM E/R),
- through 10A fuse [No. 5, located in fuse block (J/B)]
- to BCM terminal 24,
- through 10A fuse [No. 4, located in fuse block (J/B)]
- to combination meter terminal 28.

Ground is supplied

- to BCM terminals 2 and 70
- to combination meter terminals 21, 22, and 23
- through grounds E21 and M66,

A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP - DAYTIME LIGHT SYSTEM -

- to IPDM E/R terminals 3 and 54
- through grounds E45 (CR and HR engine models), E28 and E44.

HEADLAMP OPERATION

Low Beam Operation

With the lighting switch in 2ND position, the BCM receives input signal requesting the headlamps to illuminate. This input signal is communicated to IPDM E/R across the CAN communication lines. The CPU located in the IPDM E/R controls the headlamp low relay coil, which when energized, directs power

- through 15A fuse (No. 50, located in IPDM E/R)
- through IPDM E/R terminal 48
- to headlamp RH terminal 1,
- through 15A fuse (No. 49, located in IPDM E/R)
- through IPDM E/R terminal 50
- to headlamp LH terminal 1.

Ground is supplied

- to headlamp RH terminals 3
- through daytime light relay terminal 3 and 4,
- to headlamp LH terminal 3
- through grounds E45 (CR and HR engine models), E28 and E44.

With power and ground supplied, low beam headlamps illuminate.

High Beam Operation (When Daytime Light Does Not Operate)/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH BEAM or PASSING position, the BCM receives input signal requesting headlamp high beams to illuminate. High beam request signal is communicated to the IPDM E/R across the CAN communication lines. The CPU located in the IPDM E/R controls headlamp high relay coil and low relay coil, which when energized, directs power

- through 10A fuse (No. 43, located in IPDM E/R)
- through IPDM E/R terminal 46
- through headlamp RH terminals 2
- through 10A fuse (No. 44, located in IPDM E/R)
- through IPDM E/R terminal 47
- to headlamp LH terminal 2,
- through 15A fuse (No. 50, located in IPDM E/R)
- through IPDM E/R terminal 48
- to headlamp RH terminal 1,
- through 15A fuse (No. 49, located in IPDM E/R)
- through IPDM E/R terminal 50
- to headlamp LH terminal 1.

Ground is supplied

- to headlamp RH terminal 3
- to daytime light relay terminals 3 and 4
- to headlamp LH terminal 3
- through grounds E45 (CR and HR engine models), E28 and E44.

With the power and ground supplied, the headlamp high beam and low headlamp illuminate.

High beam indicator illuminates when combination meter receives input signal requesting high beam indicator to illuminate. This is communicated to BCM across the CAN communication lines.

HEADLAMP - DAYTIME LIGHT SYSTEM -

DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or AUTO position (headlamp is not illuminate) and parking brake released, the IPDM E/R receives input request signal from BCM to turn on daytime light. This input is communicated across the CAN communication lines. The CPU of the IPDM E/R controls the daytime light relay coil. When energized, this relay directs power

- through 10A fuse (No. 37, located in fuse and fusible link block)
- through daytime light relay terminals 5 and 3
- through headlamp RH terminals 3 and 1
- through IPDM E/R terminal 48
- through 15A fuse (No. 50, located in IPDM E/R)
- through 15A fuse (No. 49, located in IPDM E/R)
- through IPDM E/R terminal 50
- to headlamp LH terminal 1.

Ground is supplied

- to headlamp LH terminal 3
- through grounds E45 (CR and HR engine models), E28 and E44.

Because the low beam headlamps are now wired in series, they operate at half illumination. If the lighting switch is in the 1st and 2nd position, daytime light operation is canceled.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-114, "COMBINATION SWITCH READING FUNCTION"](#) .

AUTO LIGHT OPERATION

Refer to [LT-52, "System Description"](#) .

FRIENDLY LIGHTING FUNCTION

Low beam headlamps will illuminate for 30 seconds when,

- ignition switch is in OFF position,
- lighting switch is placed in OFF position, and
- lighting switch is placed in PASS position.

Each activation of the switch adds 30 seconds to a maximum of 2 minutes.

EXTERIOR LAMP BATTERY SAVER CONTROL

To avoid flat battery caused by user leaving exterior lamps ON. When ignition is OFF and the driver side door is opened, all exterior lamps will be turned OFF. If the user wants some lamps to remain ON then they must switch these lamps OFF then ON again with the combination switch once the driver side door has been opened. A buzzer will sound if any exterior lamps are ON with the driver side door opened and ignition OFF.

*:This setting can be changed by CONSULT-II. Refer to [LT-45, "WORK SUPPORT"](#) .

FAIL-SAFE FUNCTION

When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. If the fail-safe system is operating, headlamps illuminate when the ignition switch is turned from OFF to ON and headlamps are turned off when the ignition switch is turn from ON to OFF. If the fail-safe system is operating, headlamps does not operate when the combination switch is in any position. After CAN communication recovers normally, it also returns to normal control. (Refer to [PG-18, "Fail-safe Control"](#) .)

CAN Communication System Description

BKS001M4

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit


BKS001M5

Refer to [LAN-27, "CAN Communication Unit"](#) .

HEADLAMP - DAYTIME LIGHT SYSTEM -

Schematic

BKS001D5




MKWA4323E

HEADLAMP - DAYTIME LIGHT SYSTEM -

Wiring Diagram — DTRL —

BKS001D6

LT-DTRL-01



A
B
C
D
E
F
G
H
I
J
LT
L
M

LT

L

M

16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

M14
W

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40




M27
W

REFER TO THE FOLLOWING.

- M1 - SUPER MULTIPLE JUNCTION (SMJ)
- M7 - FUSE BLOCK - JUNCTION BOX (J/B)
- E40 - ELECTRICAL UNITS

MKWA4324E

LT-DTRL-02



REFER TO THE FOLLOWING.




(M1) - SUPER MULTIPLE
JUNCTION (SMJ)
(M7) - FUSE BLOCK -
JUNCTION BOX (J/B)



HEADLAMP - DAYTIME LIGHT SYSTEM -

LT-DTRL-03

A
B
C
D
E
F
G
H
I
J
LT
L
M



MKWA4326E




HEADLAMP - DAYTIME LIGHT SYSTEM -

Terminals and Reference Values for BCM

BKS001D7

CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-45, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal designation	Signal input/output	Measuring condition		Voltage [V] (Approx.)
				Ignition switch	Operation or condition	
2	B	Ground	—	ON	—	0
13	SB	Combination switch input 1	Input	ON	Headlamps, turn signal, wipers OFF	
14	P	Combination switch input 3				
15	W	Combination switch input 5				
33	R	Combination switch input 2				
34	Y	Combination switch input 4				
7	BR	Combination switch output 5	Output	ON	Headlamps, turn signal, wipers OFF (wiper volume is 1 or 7)	
8	L	Combination switch output 3				
9	V	Combination switch output 1			Headlamps, turn signal, wipers OFF (wiper volume is other than 1 or 7)	
27	GR	Combination switch output 4				
28	G	Combination switch output 2				
19	L	CAN- H	Input/Output	ON	—	Approx. 2.6V
24	O	Ignition power supply	Input	ON	—	Battery voltage
39	Y	CAN- L	Input/Output	ON	—	Approx. 2.4V
70	B	Ground	—	ON	—	0
74 79	Y	Battery power supply	Input	OFF	—	Battery voltage

HEADLAMP - DAYTIME LIGHT SYSTEM -

Terminals and Reference Values for IPDM E/R

BKS001D8

Terminal No.	Wire color	Signal designation	Signal input/output	Measuring condition			Voltage [V] (Approx.)
				Ignition switch	Operation or condition		
3	B	Ground	—	ON	—		0
46	Y	Headlamp HI (RH)	Output	ON	Lighting switch (high beam)	ON	Battery voltage
47	G	Headlamp HI (LH)		ON		OFF	0
48	P	Headlamp LO (RH)		ON	Lighting switch (low beam)	ON	Battery voltage
50	L	Headlamp LO (LH)		ON		OFF	0
52	L	CAN- H	Input/Output	—	—		—
54	B	Ground	—	ON	—		0
58	Y	CAH- L	Input/Output	—	—		—
65	L	Daytime light relay	Input	ON	Engine status (Lighting switch OFF)	RUNNING	0
						STOP	Battery voltage

How to Perform Trouble Diagnosis

BKS001D9

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-35, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-44, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the headlamp operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. INSPECTION END

LT

L

M

HEADLAMP - DAYTIME LIGHT SYSTEM -

Preliminary Check INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT

BKS001DA

1. CHECK FUSES

Check for blown fuses or fusible link.

Unit	Power source	Fuse No.
BCM	Battery	J
	Ignition switch ON or START position	5
IPDM E/R	Battery	43
		44
		49
		50
		61
		62

Refer to [LT-39, "Wiring Diagram — DTRL —"](#).

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+)		(−)	OFF	ACC	ON
BCM Connector	Terminal				
M57	24	Ground	Approx. 0V	Approx. 0V	Battery voltage
M59	74		Battery voltage	Battery voltage	Battery voltage
	79		Battery voltage	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M57	2	Ground	Yes
M59	70		

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



HEADLAMP - DAYTIME LIGHT SYSTEM -

CONSULT-II Functions (BCM)

BKS001DB

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

CONSULT-II INSPECTION PROCEDURE

Refer to [GI-36, "CONSULT-II Start Procedure"](#).

CONSULT-II Application Items (BCM)

BKS001M1

WORK SUPPORT

Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "BATTERY SAVER SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Select exterior lamp battery saver control mode between ON and OFF.	ON	×
		OFF	—

DATA MONITOR

Monitor item	UNIT.	Display content
IGN ON SW	[ON/OFF]	Displays status (Ignition switch ON: ON/Others OFF, ACC: OFF) as judged from the ignition switch signal.
HI BEAM SW	[ON/OFF]	Displays status (High beam switch: ON/Others: OFF) as judged from lighting switch signal.
H/L SW POS	[ON/OFF]	Displays status (Headlamp switch: ON/Others: OFF) as judged from lighting switch signal.
LIGHT SW 1ST	[ON/OFF]	Displays status (Lighting switch 1st position: ON/Others: OFF) as judged from lighting switch signal.
PASSING SW	[ON/OFF]	Displays status (Flash-to-pass switch: ON/Others: OFF) as judged from lighting switch signal.
FR FOG SW	[ON/OFF]	Displays status (Front fog lamp switch: ON/Others: OFF) as judged from lighting switch signal.
RR FOG SW	[ON/OFF]	Displays status (Rear fog lamp switch: ON/Others: OFF) as judged from lighting switch signal.
DOOR SW-DR	[ON/OFF]	Displays status (Door open: ON/door closed: OFF) as judged from the door switch DR signal.
H/L WASH SW	[ON/OFF]	Displays status (Headlamp washer switch: ON/Others: OFF) as judged from headlamp washer switch signal.
ENGINE STATUS	[STOP/ STALL/ RUN/ CRA]	Displays status (Engine stop: STOP/engine stall: STALL/engine running: RUN/engine cranking: CRA) as judged from the engine status.

HEADLAMP - DAYTIME LIGHT SYSTEM -

ACTIVE TEST

Test item	CONSULT-II screen display	Description
Tail lamp relay output	TAIL LAMP	Tail lamp relay can be operated by any ON–OFF operation.
Headlamp relay output	HEADLAMP	Headlamp relay can be operated by any ON–OFF operation.
Front fog lamp relay output	FR FOG LAMP	Front fog lamp relay can be operated by any ON–OFF operation.
Rear fog lamp relay output	RR FOG LAMP	Rear fog lamp relay can be operated by any ON–OFF operation.

CONSULT-II Functions (IPDM E/R)

BKS001DC

CONSULT-II can display each diagnostic item using the diagnostic test mode shown following.

Diagnosis Mode	Description
SELF-DIAGNOSTIC RESULTS	Refer to PG-20, "SELF-DIAG RESULTS" .
DATA MONITOR	The input/output data of IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	IPDM E/R sends a drive signal to electronic components to check their operation.

CONSULT-II INSPECTION PROCEDURE

Refer to [GI-36, "CONSULT-II Start Procedure"](#) .

CONSULT-II Application Items (IPDM E/R)

BKS001M2

DATA MONITOR

All Signals, Main Signals, Selection From Menu

Monitor item name	Display and unit	Monitor item selection			Display content
		All signals	Main signals	selection from menu	
TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
IGN RLY	ON/OFF	×	×	×	Status of ignition relay being monitored by IPDM E/R

ACTIVE TEST

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	HEAD LAMP	Headlamp relay (LO, HI) can be operated using random operation (OFF, HI ON, LO ON).
Front fog lamp relay output	FRONT FOG LAMP	Fog lamp relay can be operated by any ON–OFF operation.
Tail lamp relay output	TAIL LAMP	Tail lamp relay can be operated by any ON–OFF operation.

HEADLAMP - DAYTIME LIGHT SYSTEM -

Daytime Light Control Does Not Operate Properly

BKS001LO

1. CHECK HEADLAMP OPERATION

Lighting switch is turned to 2nd position.

Does headlamp operate normally?

Yes >> GO TO 2.

No >> Check the following.

- Headlamp does not illuminate (both sides). GO TO [LT-25, "Headlamp Low Beam Does Not Illuminate \(Both Sides\)"](#).
- Headlamp does not illuminate (one side). GO TO [LT-27, "Headlamp Low Beam Does Not Illuminate \(One Side\)"](#).

2. CHECK DAYTIME LIGHT RELAY

1. Turn ignition switch OFF.
2. Disconnect daytime light relay connector.
3. Check voltage between daytime light relay harness connector and ground.


Terminals			Voltage [V] (Approx.)
(+)		(-)	
Connector	Terminal		
E54	1	Ground	Battery voltage
	5		

OK or NG

OK >> GO TO 3.

NG >> Check the following.

- 10A fuse (No. 37, located in fuse and fusible link box).
- Harness for open or short between daytime relay and fuse.



3. CHECK IPDM E/R OUTPUT SIGNAL


1. Connect daytime light relay.
2. Disconnect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector E5 terminal 65 and ground.

65 - Ground : Battery voltage

OK or NG

OK >> GO TO 4.

NG >> GO TO 5.



HEADLAMP - DAYTIME LIGHT SYSTEM -


4. CHECK IPDM E/R OUTPUT SIGNAL

1. Connect IPDM E/R connector.
2. Check voltage between IPDM and ground.

Terminals			Condition	Voltage [V] (Approx.)
(+)		(-)		
Connector	Terminal			
E5	65	Ground	Engine stop	Battery voltage
			Engine running	0

OK or NG

- OK >> Replace daytime relay.
 NG >> Replace IPDM E/R.




5. CHECK IPDM E/R OUTPUT SIGNAL CIRCUIT

1. Disconnect daytime light relay connector.
2. Check continuity between daytime light relay harness connector E54 terminal 2 and IPDM E/R harness connector E5 terminal 65.

2 - 65 : Continuity should exist.

OK or NG

- OK >> Replace daytime light relay.
 NG >> Repair or replace harness or connector.



RH High beam Does Not Illuminate

1. CHECK BULB

Check bulb of headlamp RH.

OK or NG

- OK >> GO TO 2.
 NG >> Replace bulb of headlamp.


2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect headlamp RH connector.
3. Check voltage between headlamp RH harness connector E26 terminal 2 and ground.

Terminals			Condition	Voltage [V] (Approx.)
(+)		(−)		
Connector	Terminal			
E26	2	Ground	Lighting switch high beam ON	Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 3.



HEADLAMP - DAYTIME LIGHT SYSTEM -

3. CHECK IPDM E/R CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector (A) and headlamp RH harness connector (B).


A		B		Continuity
Connector	Terminal	Connector	Terminal	
E8	46	E26	2	Yes

3. Check continuity between IPDM E/R harness connector (A) and ground.

A		Ground	Continuity
Connector	Terminal		
E8	46		No

OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace harness or connector.



4. CHECK FUSE

Check 10A fuse [No. 43, located in IPDM E/R].

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Replace fuse. If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.


5. CHECK HEADLAMP RH GROUND CIRCUIT

Check continuity between daytime light relay harness connector E54 terminal 3 and headlamp RH harness connector E26 terminal 3.

3 - 3 : Continuity should exist.

OK or NG

- OK >> GO TO 6.
 NG >> Repair or replace harness or connector.




6. CHECK DAYTIME LIGHT GROUND CIRCUIT

Check continuity daytime light relay harness connector E54 terminal 4 and ground.

4 - Ground : Continuity should exist.

OK or NG

- OK >> Replace daytime light relay.
 NG >> Repair or replace harness or connector.



HEADLAMP - DAYTIME LIGHT SYSTEM -

BKS001LT

RH Low Beam Does Not Illuminate

1. CHECK BULB

Check bulb of headlamp RH.

OK or NG

OK >> GO TO 2.

NG >> Replace bulb of lamp.

2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect headlamp RH connector.
3. Check voltage between headlamp RH harness connector E26 terminal 1 and ground.

Terminals		Condition	Voltage [V] (Approx.)
(+)	(-)		
Connector	Terminal		
E26	1	Lighting switch low beam ON	Battery voltage

OK or NG

OK >> GO TO 5.

NG >> GO TO 3.



3. CHECK IPDM E/R CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector (A) and headlamp RH harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
E8	48	E26	1	Yes

3. Check continuity between IPDM E/R harness connector (A) and ground.

A		Ground	Continuity
Connector	Terminal		
E8	48		No

OK or NG

OK >> GO TO 4.

NG >> Repair or replace harness or connector.


4. CHECK FUSE

Check 15A fuse (No. 50 located in IPDM E/R). Refer to [PG-34, "IPDM E/R Terminal Inspection"](#) .

OK or NG

OK >> Replace IPDM E/R.

NG >> Replace fuse. If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.



HEADLAMP - DAYTIME LIGHT SYSTEM -

5. CHECK HEADLAMP RH GROUND CIRCUIT


Check continuity between daytime light relay harness connector E54 terminal 3 and headlamp RH harness connector E26 terminal 3.

3 - 3 : Continuity should exist.

OK or NG

OK >> GO TO 6.

NG >> Repair or replace harness or connector.



6. CHECK DAYTIME LIGHT GROUND CIRCUIT


Check continuity daytime light relay harness connector E54 terminal 4 and ground.

4 - Ground : Continuity should exist.

OK or NG

OK >> Replace daytime light relay.

NG >> Repair or replace harness connector.



Headlamp High Beam Does Not Illuminate (Both Sides)

Refer to [LT-21, "Headlamp High Beam Does Not Illuminate \(Both Sides\)"](#) .

Headlamp Low Beam Does Not Illuminate (Both Sides)

Refer to [LT-25, "Headlamp Low Beam Does Not Illuminate \(Both Sides\)"](#) .

Headlamp LH High Beam Does Not Illuminate

Refer to [LT-23, "Headlamp High Beam Does Not Illuminate \(One Side\)"](#) .

Headlamp LH Low Beam Does Not Illuminate

Refer to [LT-27, "Headlamp Low Beam Does Not Illuminate \(One Side\)"](#) .

Headlamps Do Not Turn OFF

Refer to [LT-29, "Headlamps Do Not Turn OFF"](#) .

Aiming Adjustment

Refer to [LT-30, "Aiming Adjustment"](#) .

Bulb Replacement

Refer to [LT-32, "Bulb Replacement"](#) .

Removal and Installation

Refer to [LT-32, "Removal and Installation"](#) .

Disassembly and Assembly

Refer to [LT-34, "Disassembly and Assembly"](#) .


AUTO LIGHT SYSTEM

AUTO LIGHT SYSTEM

PFP:28491

Component Parts and Harness Connector Location

BKS001DR



MKIB2270E

1. IPDM E/R E8,E12

2. BCM M57,M59 (View with instrument upper panel removed)

3. Light and rain sensor R2

4. Combination switch M38

5. Front door switch driver side
[B14 (LHD models)]
[B29 (RHD models)]

System Description

BKS001DS

Automatically turns ON/OFF the parking lamps and the headlamps in accordance with ambient light.

OUTLINE

The auto light control system has an light and rain sensor inside it that detects outside brightness.

When the lighting switch is in AUTO position, it automatically turns ON/OFF the parking lamps and the headlamps in accordance with ambient light.

Light and rain sensor, power is supplied

- through BCM terminal 73
- to light and rain sensor terminal 1.

Light and rain sensor, ground is supplied

- to light and rain sensor terminal 3
- through grounds M21 and M66.

When ignition switch is turn to ON position and

When outside brightness is darker than prescribed level, input is supplied

- to light and rain sensor terminal 2
- through BCM terminal 63.

The headlamps will then illuminate. For a description of headlamp operation, Refer to [LT-52, "System Description"](#).

AUTO LIGHT SYSTEM

COMBINATION SWITCH READING FUNCTION

Refer to [LT-114, "COMBINATION SWITCH READING FUNCTION"](#) .

FRIENDLY LIGHTING FUNCTION

Low beam headlamps will illuminate for 30 seconds when,

- ignition switch is in OFF position,
- lighting switch is placed in OFF position, and
- lighting switch is placed in PASS position.

Each activation of the switch adds 30 seconds to a maximum of 2 minutes.

EXTERIOR LAMP BATTERY SAVER CONTROL

To avoid flat battery caused by user leaving exterior lamps ON. When ignition is OFF and the driver side door is opened, all exterior lamps will be turned OFF. If the user wants some lamps to remain ON then they must switch these lamps OFF then ON again with the combination switch once the driver side door has been opened. A buzzer will sound if any exterior lamps are ON with the driver side door opened and ignition OFF.

*:This setting can be changed by CONSULT-II. Refer to [LT-63, "WORK SUPPORT"](#) .

CAN Communication System Description

BKS001DT

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

BKS001DU

Refer to [LAN-27, "CAN Communication Unit"](#) .

Major Components and Functions


BKS001DV

Components	Functions
BCM	● Turns ON/OFF circuits of tail light and headlamp according to signals from light sensor, lighting switch (AUTO), driver's door switch, passenger's door switch and ignition switch (ON, OFF).
Light and rain sensor	● Converts outside brightness (lux) to voltage, and sends it to BCM. (Detects brightness of 50 to 1,300 lux)

AUTO LIGHT SYSTEM

Schematic

BKS001DW




MKWA4333E

A
B
C
D
E
F
G
H
I
J
K
L
M




BKS001DX

 : DATA LINE



(M1) - SUPER MULTIPLE
JUNCTION (SMJ)
(M7) - FUSE BLOCK -
JUNCTION BOX (J/B)


LT-AUTO/L-02



AUTO LIGHT SYSTEM

LT-AUTO/L-03

A
B
C
D
E
F
G
H
I
J
LT
L
M





REFER TO THE FOLLOWING.
(M1) - SUPER MULTIPLE JUNCTION (SMJ)

AUTO LIGHT SYSTEM

LT-AUTO/L-04

 : CR AND HR
ENGINE
MODELS







AUTO LIGHT SYSTEM

Terminals and Reference Values for BCM


BKS001DY

CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-64, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
2	B	Ground	—	ON	—	Approx. 0V
14	P	Combination switch input 3	Input	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	<div>OFF</div>  <p>PKIB4958J</p> <p>Approx. 1.0V</p>
					Lighting switch AUTO	 <p>PKIB8631J</p> <p>Approx. 2.0V</p>
19	L	CAN – H	Input/Output	ON	—	Approx. 2.6V
24	O	Ignition switch (ON)	Input	ON	—	Battery voltage
27	GR	Combination switch output 4	Output	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	<div>OFF</div>  <p>PKIB4958J</p> <p>Approx. 1.2V</p>
					Lighting switch AUTO	 <p>PKIB4959J</p> <p>Approx. 1.0V</p>

AUTO LIGHT SYSTEM

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
29	LG*1 BR*2	Front door switch (driver side) signal	Input	OFF	ON (open)	Approx. 0V
					Front door switch (driver side) OFF (closed)	 <p style="text-align: right;">PKIB4950J</p>
39	Y	CAN – L	Input/Output	ON	—	Approx. 2.4V
63	BR	Light and rain sensor signal	Input	ON	When light and rain sensor is illuminated.	Approx. 8.9V ^{NOTE}
70	B	Ground	—	ON	—	Approx. 0V
73	V	Light and rain sensor power supply	Output	ON	—	Approx. 5V
74 79	Y	Battery power supply	Input	OFF	—	Battery voltage

*1:LHD models

*2:RHD models

NOTE:

Light and rain sensor must be securely subjected to work lamp light. If the light and rain sensor is insufficiently illuminated, the measured value may not satisfy standard.

AUTO LIGHT SYSTEM

Terminals and Reference Values for IPDM E/R

BKS001DZ

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
3	B	Ground	—	ON	—	Approx. 0V
15	GR	Rear combination lamp LH (Tail)	Output	ON	Lighting switch 1ST position	OFF ON Approx. 0V Battery voltage
16	V	Rear combination lamp RH (Tail) and license plate lamp RH and LH		ON	Lighting switch 1ST position	OFF ON Approx. 0V Battery voltage
45	BR	Parking lamp RH		ON	Lighting switch 1ST position	OFF ON Approx. 0V Battery voltage
46	Y	Headlamp HIGH RH		ON	Lighting switch HIGH beam or PASSING position	OFF ON Approx. 0V Battery voltage
47	G	Headlamp HIGH LH		ON	Lighting switch HIGH beam or PASSING position	OFF ON Approx. 0V Battery voltage
48	P	Headlamp LOW RH		ON	Lighting switch 2ND position	OFF ON Approx. 0V Battery voltage
49	O	Parking lamp LH		ON	Lighting switch 1ST position	OFF ON Approx. 0V Battery voltage
50	L	Headlamp LOW LH		ON	Lighting switch 2ND position	OFF ON Approx. 0V Battery voltage
52	L	CAN – H	Input/Output	—	—	—
54	B	Ground	—	ON	—	Approx. 0V
58	Y	CAN – L	Input/Output	—	—	—

How to Proceed With Trouble Diagnosis

BKS001E0

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-52, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-62, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the auto light system operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

AUTO LIGHT SYSTEM

Preliminary Check

BKS001E1

CHECK POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	J
	Ignition switch ON or START position	5
IPDM E/R	Battery	43
		44
		45
		46
		49
		50
		61
		62

Refer to [LT-55, "Wiring Diagram — AUTO/L —"](#).

OK or NG


OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+) Terminal		(-) Ground	OFF	ACC	ON
BCM Connector	Terminal				
M57	24	Ground	Approx. 0V	Approx. 0V	Battery voltage
M59	74		Battery voltage	Battery voltage	Battery voltage
	79		Battery voltage	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

AUTO LIGHT SYSTEM


3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M57	2		Yes
M59	70		

OK or NG

- OK >> INSPECTION END
 NG >> Repair harness or connector.



BKS001E2

CONSULT-II Functions (BCM)

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnosis part	Diagnosis mode	Description
HEADLAMP	WORK SUPPORT	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
BCM	SELF-DIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

CONSULT-II INSPECTION PROCEDURE

Refer to [GI-36, "CONSULT-II Start Procedure"](#) .

CONSULT-II Application Items

BKS001L1

WORK SUPPORT

Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "BATTERY SAVER SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SET".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Select exterior lamp battery saver control mode between ON and OFF.	ON	×
		OFF	—

AUTO LIGHT SYSTEM

DATA MONITOR

Monitor item UNIT.		Display content
IGN ON SW	[ON/OFF]	Displays status (Ignition switch ON: ON/Others OFF, ACC: OFF) as judged from the ignition switch signal.
HI BEAM SW	[ON/OFF]	Displays status (High beam switch: ON/Others: OFF) as judged from lighting switch signal.
H/L SW POS	[ON/OFF]	Displays status (Headlamp switch: ON/Others: OFF) as judged from lighting switch signal.
LIGHT SW 1ST	[ON/OFF]	Displays status (Lighting switch 1st position: ON/Others: OFF) as judged from lighting switch signal.
PASSING SW	[ON/OFF]	Displays status (Flash-to-pass switch: ON/Others: OFF) as judged from lighting switch signal.
FR FOG SW	[ON/OFF]	Displays status (Front fog lamp switch: ON/Others: OFF) as judged from lighting switch signal.
RR FOG SW	[ON/OFF]	Displays status (Rear fog lamp switch: ON/Others: OFF) as judged from lighting switch signal.
DOOR SW-DR	[ON/OFF]	Displays status (Door open: ON/door closed: OFF) as judged from the door switch DR signal.
H/L WASH SW	[ON/OFF]	Displays status (Headlamp washer switch: ON/Others: OFF) as judged from headlamp washer switch signal.
ENGINE STATUS	[STOP/ STALL/ RUN/ CRA]	Displays status (Engine stop: STOP/engine stall: STALL/engine running: RUN/engine cranking: CRA) as judged from the engine status.

ACTIVE TEST

Test item	CONSULT-II screen display	Description
Tail lamp relay output	TAIL LAMP	Tail lamp relay can be operated by any ON-OFF operation.
Headlamp relay output	HEAD LAMP	Headlamp relay can be operated by any ON-OFF operation.
Front fog lamp relay output	FR FOG LAMP	Front fog lamp relay can be operated by any ON-OFF operation.
Rear fog lamp relay output	RR FOG LAMP	Rear fog lamp relay can be operated by any ON-OFF operation.

AUTO LIGHT SYSTEM

Light and rain sensor System Inspection


BKS001E5

1. CHECK LIGHT AND RAIN SENSOR INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector M58 terminal 63 and ground.

Illuminated

LIGHT AND RAIN SENSOR : Approx. 8.9V



CAUTION:

Light and rain sensor must be securely subjected to work lamp light. If light and rain sensor is insufficiently illuminated, the measured value may not satisfy the standard.

OK or NG

- OK >> INSPECTION END
NG >> GO TO 2.


2. CHECK LIGHT AND RAIN SENSOR VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

Terminals			Voltage
(+)		(–)	
Connector	Terminal		
M59	73	Ground	Approx. 5 V

OK or NG

- OK >> GO TO 3.
NG >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#) .



AUTO LIGHT SYSTEM

3. CHECK LIGHT AND RAIN SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and light and rain sensor connector.
3. Check continuity between BCM harness connector (A) and light and rain sensor harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	Yes
M59	73	R2	1	

4. Check continuity between BCM harness connector (A) and ground.

A		Ground	Continuity
Connector	Terminal		No
M59	73		

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness or connector.

4. CHECK LIGHT AND RAIN SENSOR SIGNAL CIRCUIT

1. Check continuity between BCM harness connector (A) and light and rain sensor harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	Yes
M58	63	R2	2	

2. Check continuity between BCM harness connector (A) and ground.

A		Ground	Continuity
Connector	Terminal		No
M58	63		

OK or NG

- OK >> GO TO 5.
 NG >> Repair harness or connector.


5. CHECK LIGHT AND RAIN SENSOR GROUND CIRCUIT

Check continuity between light and rain sensor harness connector R2 terminal 3 and ground.


Light and rain sensor Connector	Terminal	Ground	Continuity
R2	3		Yes

OK or NG


- OK >> Replace light and rain sensor.
 NG >> Repair harness or connector.



MKIB2283E



MKIB2284E



MKIB2285E

AUTO LIGHT SYSTEM


Removal and Installation of Light and Rain Sensor REMOVAL

BKS001E6

1. Remove inside mirror. Refer to [GW-104, "INSIDE MIRROR"](#) .
2. Remove clip and pawl.
3. Pull out the light and rain sensor.
4. Remove light and rain sensor harness connector.

CAUTION:

Do not touch the electronic circuit board on rain sensor.



INSTALLATION OF LIGHT AND RAIN SENSOR

Install in the reverse order of removal.

INSTALLATION OF LIGHT AND RAIN SENSOR HOUSING


CAUTION:

When windshield is replaced, always replace rain sensor housing.

1. Clean the surface of bonded area on the windshield.
2. Fix rain sensor housing against light and rain sensor bracket from the top, then press it in a downward motion until it is completely attach together.

CAUTION:

Do not touch the adhesive.



A
B
C
D
E
F
G
H
I
J
LT
L
M


HEADLAMP AIMING CONTROL

HEADLAMP AIMING CONTROL

PFP:26010

Schematic

BKS001E7



MKWA4342E

HEADLAMP AIMING CONTROL



Wiring Diagram—H/AIM—

BKS001H8


LT-H/AIM-01

— : DATA LINE


A
B
C
D
E
F
G
H
I
J
LT
L
M




(M14)
W



(M38)
W



(M57)
W





(M59)
B

REFER TO THE FOLLOWING.

- (M1) - SUPER MULTIPLE JUNCTION (SMJ)
- (M7) - FUSE BLOCK - JUNCTION BOX (J/B)

MKWA4343E


HEADLAMP AIMING CONTROL



HEADLAMP AIMING CONTROL

LT-H/AIM-03

CH : CR AND HR ENGINE MODELS




REFER TO THE FOLLOWING.
(M1) - SUPETR, MULTIPLE JUNCTION (SMJ)

HEADLAMP AIMING CONTROL

Removal and Installation

REMOVAL

1. Remove the switch panel assembly. Refer to [IP-4, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Spread pawls (A) of switch panel assembly to remove headlamp aiming switch(1).




INSTALLATION

Installation is the reverse order of removal.

Switch Circuit Inspection

Using a circuit tester, check resistance between the headlamp aiming switch connector terminals in each operation status of the aiming switch.




FRONT FOG LAMP

FRONT FOG LAMP

PFP:26150

Component Parts and Harness Connector Location

BKS001EA



1. IPDM E/R E8,E11,E12

2. BCM M57,M59 (View with instrument upper panel removed)

3. Combination switch M38

4. Combination meter M27

MKIB2268E

System Description

BKS001EB

The control of the front fog lamps is dependent upon the position of the lighting switch. The lighting switch must be in the 1ST/ 2ND position or AUTO position (headlamp is ON) for front fog lamp operation. When the lighting switch is placed in front fog lamp switch ON position the BCM (body control module) receives input signal requesting the front fog lamps to illuminate. When the headlamps are illuminated, this input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication. The CPU (central processing unit) located in the IPDM E/R controls the front fog lamp relay coil. When activated, this relay directs power to the front fog lamps.

OUTLINE

Power is supplied at all times

- to front fog lamp relay, located in IPDM E/R, and
- to ignition relay, located in IPDM E/R, from battery directly,
- through 20A fuse (No. 61, located in IPDM E/R),
- through 20A fuse (No. 62, located in IPDM E/R),
- through 40A fusible link (letter J, located in fuse, fusible link and relay box)
- to BCM terminals 74 and 79,
- through 10A fuse [No. 7, located in fuse block (J/B)]
- to combination meter terminal 27.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay, located in IPDM E/R, from battery directly,
- through 10A fuse [No. 5, located in fuse block (J/B)]
- to BCM terminal 24,
- through 10A fuse [No. 4, located in fuse block (J/B)]
- to combination meter terminal 28.

Ground is supplied

- to BCM terminal 2 and 70
- to combination meter terminals 21, 22 and 23
- through grounds M21 and M66,

FRONT FOG LAMP

- to IPDM E/R terminals 3 and 54
- through grounds E45 (CR and HR engine models), E28 and E44.

FOG LAMP OPERATION

The front fog lamp switch is built in lighting switch. The lighting switch must be in 1ST/2ND position or AUTO position (headlamp is ON) and front fog lamp switch must be ON position for front fog lamp operation.

With the front fog lamp switch in the ON position, the CPU located in the IPDM E/R grounds coil side of the front fog lamp relay. Front fog lamp relay then directs power

- through 20A fuse (No. 65, located in IPDM E/R),
- through IPDM E/R terminal 44
- to front fog lamp LH terminal 1,
- through IPDM E/R terminal 43
- to front fog lamp RH terminal 1.

Ground is supplied

- to front fog lamp LH and RH terminals 2
- through grounds E45 (CR and HR engine models), E28 and E44.

With power and grounds supplied, front fog lamps illuminate.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-114, "COMBINATION SWITCH READING FUNCTION"](#) .

EXTERIOR LAMP BATTERY SAVER CONTROL

Refer to [LT-9, "EXTERIOR LAMP BATTERY SAVER CONTROL"](#) .

FAIL-SAFE FUNCTION

When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. If the fail-safe system is operating, front fog lamps does not operate when the combination switch is in any position. After CAN communication recovers normally, it also returns to normal control. (Refer to [PG-18, "Fail-safe Control"](#) .)

CAN Communication System Description

BKS001EC

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit


BKS001ED

Refer to [LAN-27, "CAN Communication Unit"](#) .

FRONT FOG LAMP

Schematic

BKS001EE



A
B
C
D
E
F
G
H
I
J
LT
L
M

MKWA4349E





FRONT FOG LAMP

Wiring Diagram — F/FOG —

BKS001EF

LT-F/FOG-01

— : DATA LINE





REFER TO THE FOLLOWING.

- (M1) - SUPER MULTIPLE JUNCTION (SMJ)
- (M7) - FUSE BLOCK - JUNCTION BOX (J/B)

FRONT FOG LAMP

LT-F/FOG-02


A
B
C
D
E
F
G
H
I
J
LT
L
M



MKWA4351E

FRONT FOG LAMP

LT-F/FOG-03



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	M27
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	W

REFER TO THE FOLLOWING.

M7 - FUSE BLOCK -
 JUNCTION BOX (J/B)

MKWA4352E





FRONT FOG LAMP

Terminals and Reference Values for BCM

BKS001EG

CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-19, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
2	B	Ground	—	ON	—	Approx. 0V
7	BR	Combination switch output 5	Output	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	<div> <p>OFF</p>  <p>PKIB8643J</p> <p>Approx. 1.2V</p> </div>
					Front fog lamp switch ON (Operates only front fog lamp switch)	<div>  <p>PKIB4956J</p> <p>Approx. 1.0V</p> </div>
19	L	CAN – H	Input/Output	ON	—	Approx. 2.6V
24	O	Ignition switch (ON)	Input	ON	—	Battery voltage
34	Y	Combination switch input 4	Input	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	<div> <p>OFF</p>  <p>PKIB4958J</p> <p>Approx. 1.0V</p> </div>
					Front fog lamp switch ON (Operates only front fog lamp switch)	<div>  <p>PKIB8627J</p> <p>Approx. 1.5 - 2.0V</p> </div>
39	Y	CAN – L	Input/Output	ON	—	Approx. 2.4V
70	B	Ground	—	ON	—	Approx. 0V
74 79	Y	Battery power supply	Input	OFF	—	Battery voltage

FRONT FOG LAMP

Terminals and Reference Values for IPDM E/R

BKS001EH

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
3	B	Ground	—	ON	—	Approx. 0V
43	W	Front fog lamp RH	Output	ON	Lighting switch must be in the 2ND position or AUTO position (headlamp is ON)	Front fog lamp switch: OFF
						Front fog lamp switch: ON
44	V	Front fog lamp LH	Output	ON	Lighting switch must be in the 2ND position or AUTO position (headlamp is ON)	Front fog lamp switch: OFF
						Front fog lamp switch: ON
52	L	CAN – H	Input/Output	—	—	—
54	B	Ground	—	ON	—	Approx. 0V
58	Y	CAN – L	Input/Output	—	—	—

How to Proceed With Trouble Diagnosis

BKS001EI

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-73, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-81, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Does the front fog lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

FRONT FOG LAMP

Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

BKS001EJ

1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	J
	Ignition switch ON or START position	5
IPDM E/R	Battery	61
		62
		65

Refer to [LT-76, "Wiring Diagram — F/FOG —"](#) .

OK or NG


OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+)		(-)	OFF	ACC	ON
BCM Connector	Terminal				
M57	24	Ground	Approx. 0V	Approx. 0V	Battery voltage
M59	74		Battery voltage	Battery voltage	Battery voltage
	79		Battery voltage	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM Connector	Terminal	Ground	Continuity
M57	2		Yes
M59	70		

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



FRONT FOG LAMP

CONSULT-II Functions (BCM)

BKS001EK

Refer to [LT-19, "CONSULT-II Functions \(BCM\)"](#) in "HEADLAMP - CONVENTIONAL TYPE -".

CONSULT-II Functions (IPDM E/R)

BKS001EL

Refer to [LT-20, "CONSULT-II Functions \(IPDM E/R\)"](#) in "HEADLAMP - CONVENTIONAL TYPE -".

Front Fog lamps Do Not Illuminate (Both Sides)

BKS001EM

1. CHECK COMBINATION SWITCH INPUT SIGNAL

④ With CONSULT-II

1. Select "BCM" on CONSULT-II. Select "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR" on "SELECT DIAG MODE" screen. Make sure that "FR FOG SW" turns ON-OFF linked with operation of fog lamp switch.

When fog lamp switch is ON : FR FOG SW ON

⊗ Without CONSULT-II

Refer to [LT-125, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-125, "Combination Switch Inspection"](#).

DATA MONITOR			
MONITOR			
FR FOG SW		ON	
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7598E

2. FOG LAMP ACTIVE TEST

④ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II. Select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "FR FOG LAMP" on "SELECT TEST ITEM" screen.
3. Touch "ON" screen.
4. Make sure front fog lamp operates.

Front fog lamp should operate.

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. Make sure front fog lamp operates.

Front fog lamp should operate.

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II. Select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "FR FOG REQ" turns ON when front fog lamp switch is in ON position.

When front fog lamp switch is ON position : FR FOG REQ ON

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#).

NG >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

DATA MONITOR			
MONITOR			
FR FOG REQ		ON	
		Page Down	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5898E

FRONT FOG LAMP

4. CHECK FOG LAMP INPUT SIGNAL

 With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front fog lamp RH and LH connector.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "FR FOG LAMP" on "SELECT TEST ITEM" screen.
5. Touch "ON" screen.
6. When front fog lamp relay is operating, check voltage between front fog lamp RH and LH harness connector and ground.

(+) Front fog lamp connector		Terminal	(-)	Voltage
RH	E23			
LH	E14	1	Ground	Battery voltage

 Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front fog lamp RH and LH connector.
3. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
4. When front fog lamp relay is operating, check voltage between front fog lamp (RH and LH) harness connector and ground.

(+) Front fog lamp connector		Terminal	(-)	Voltage
RH	E23			
LH	E14	1	Ground	Battery voltage

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. CHECK FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector (A) and front fog lamp RH and LH harness connector (B).



Circuit	A		B		Continuity
	Connector	Terminal	Connector	Terminal	
RH	E8	43	E23	1	Yes
LH		44	E14		

4. Check continuity between IPDM E/R harness connector (A) and ground.

Circuit	A		Ground	Continuity
	Connector	Terminal		
RH	E8	43		No
LH		44		

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#).
NG >> Repair harness or connector.



FRONT FOG LAMP


6. CHECK FOG LAMP GROUND

1. Check continuity between front fog lamp RH and LH harness connector and ground.

Front fog lamp connector		Terminal	Ground	Continuity
RH	E23	2		Yes
LH	E14			

OK or NG

- OK >> Check front fog lamp bulbs.
NG >> Repair harness or connector.



FRONT FOG LAMP

Front Fog Lamp Does Not Illuminate (One Side)

BKS001EN

1. CHECK BULB

Check bulb of lamp with does not illuminate which does not illuminate.

OK or NG

OK >> GO TO 2.

NG >> Replace front fog lamp bulb.

2. CHECK FOG LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front fog lamp RH or LH connector.
3. Check continuity between IPDM E/R harness connector (A) and front fog lamp RH or LH harness connector (B).

Circuit	A		B		Continuity
	Connector	Terminal	Connector	Terminal	
RH	E8	43	E23	1	Yes
LH		44	E14		

4. Check continuity between IPDM E/R harness connector (A) and ground.

Circuit	A		Ground	Continuity
	Connector	Terminal		
RH	E8	43		No
LH		44		

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

3. CHECK FOG LAMP GROUND



1. Check continuity between front fog lamp RH or LH harness connector and ground.

Front fog lamp connector		Terminal	Ground	Continuity
RH	E23	2		Yes
LH	E14			

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#).

NG >> Repair harness or connector.



FRONT FOG LAMP


Aiming Adjustment

BKS001EO


The front fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb. Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.
- Place vehicle on level surface.
- Set that there is no-load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant, engine oil filled up to correct level and full fuel tank.

Adjust aiming in the vertical direction by turning the adjusting screw (A).



1. Set the distance between the screen and the center of front fog lamp lens as shown.
2. Turn front fog lamps ON.
3. Adjust front fog lamps using adjusting screws so that the top edge of the high intensity zone is in the figure. When performing adjustment, if necessary, cover the headlamps and opposite front fog lamp.




Bulb Replacement

BKS001EP

1. Turn lighting switch OFF.
2. Turn off the fender protector (front) to obtain work space between the fender protector and fender.
3. Disconnect front fog lamp connector (1).
4. Turn bulb socket (2) counterclockwise unlock and remove it.
5. Remove bulb from its socket.

Front fog lamp : 12V-35W (H8)




FRONT FOG LAMP

Removal and Installation

BKS001EQ

REMOVAL

1. Turn front fog lamp switch OFF.
2. Turn over the fender protector and undercover to obtain work space between the fender protector and fender.
3. Remove pawl (A), and front bumper finisher (1) from front bumper.
4. Disconnect front fog lamp connector.
5. Remove screw (3) and remove front fog lamp (2) from bracket.



INSTALLATION

- Installation is the reverse order of removal.

Tightening torque



: 5.5 N·m (0.56 kg-m, 49 in-lb)

A

B

C

D

E

F

G

H

I

J

LT

L

M


REAR FOG LAMP

REAR FOG LAMP

PFP:26550

Component Parts and Harness Connector Location

BKS001ER



1. BCM M57, M59 (View with instrument upper panel removed)

2. Combination switch M38

3. Combination meter M27

System Description

BKS001ES

The control of the rear fog lamps is dependent upon the position of the lighting switch. The lighting switch must be in the 1ST/2ND position for rear fog lamp operation. When the lighting switch is placed in the rear fog lamp position* the BCM (body control module) receives input signal requesting the rear fog lamps to illuminate.

*:Rear fog lamp switch is an auto return switch. BCM reads a change when rear fog lamp switch is operated. It switches between ON and OFF every time when rear fog lamp switch is operated.

OUTLINE

Power is also supplied at all times

- through 40A fusible link (letter J, located in the fuse and fusible link block),
- to BCM terminals 74 and 79,
- through 10A fuse [No. 7, located in the fuse block (J/B)]
- to combination meter terminal 27.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 5 located in the fuse block (J/B)]
- to BCM terminal 24,
- through 10A fuse [No. 4, located in the fuse block (J/B)]
- to combination meter terminal 28.

Ground is supplied

- to BCM terminals 2 and 70
- to combination meter terminals 21, 22 and 23
- through grounds M21 and M66.

REAR FOG LAMP OPERATION

The lighting switch must be in the 1ST or 2ND position for rear fog lamp operation.

With the rear fog lamp switch in the ON position, the BCM directs power

- through BCM terminal 69
- to rear combination lamp RH (rear fog lamp) terminal 2.

Ground is supplied

- to rear combination lamp RH (rear fog lamp) terminal 1
- through grounds B13, B28, B38 and B48.

With power and grounds supplied, the rear fog lamp illuminate.

The unified meter control unit that received the rear fog lamp request signal by BCM via the CAN communication makes a rear fog lamp indicator lamp turn on in combination meter.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-114, "COMBINATION SWITCH READING FUNCTION"](#) .

CAN Communication System Description

BKS001ET

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

BKS001EU

Refer to [LAN-27, "CAN Communication Unit"](#) .



A
B
C
D
E
F
G
H
I
J
LT
L
M

REAR FOG LAMP

Wiring Diagram — R/FOG —

BKS001EW

LT-R/FOG-01



REFER TO THE FOLLOWING.


(M1) - SUPER MULTIPLE
JUNCTION (SMJ)

M7 - FUSE BLOCK -
JUNCTION BOX (J/B)

A
B
C
D
E
F
G
H
I
J
K
L
M

LT

L
M







REAR FOG LAMP

Terminals and Reference Values for BCM

BKS001EX

CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-19, "DATA MONITOR"](#) .

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
2	B	Ground	—	ON	—	Approx. 0V
7	BR	Combination switch output 5	Output	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4) OFF	 <p>PKIB8643J</p> <p>Approx. 1.2V</p>
					Rear fog lamp switch ON (Operates only rear fog lamp switch)	 <p>PKIB4956J</p> <p>Approx. 1.0V</p>
14	P	Combination switch input 3	Input	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4) OFF	 <p>PKIB4958J</p> <p>Approx. 1.0V</p>
					Rear fog lamp switch ON (Operates only rear fog lamp switch)	 <p>PKIC1030E</p> <p>Approx. 1.5V</p>
19	L	CAN – H	Input/Output	ON	—	Approx. 2.6V
24	O	Ignition switch (ON)	Input	ON	—	Battery voltage
39	Y	CAN – L	Input/Output	ON	—	Approx. 2.4V
69	R	Rear fog lamp	Output	ON	Rear fog lamp switch ON	Battery voltage
					OFF	Approx. 0V

REAR FOG LAMP

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
70	B	Ground	—	ON	—	Approx. 0V
74 79	Y	Battery power supply	Input	OFF	—	Battery voltage

How to Proceed With Trouble Diagnosis

BKS001EY

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-88, "System Description"](#).
3. Perform the Preliminary Check. Refer to [LT-94, "Preliminary Check"](#).
4. Check symptom and repair or replace the cause of malfunction.
5. Does the rear fog lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

A

B

C

D

E

F

G

H

I

J

LT

L

M

REAR FOG LAMP

Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

BKS001EZ

1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	J
	Ignition switch ON or START position	5

Refer to [LT-90, "Wiring Diagram — R/FOG —"](#) .

OK or NG


OK >> GO TO 2.

NO >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+)		(-)	OFF	ACC	ON
BCM Connector	Terminal				
M57	24	Ground	Approx. 0V	Approx. 0V	Battery voltage
M59	74		Battery voltage	Battery voltage	Battery voltage
	79		Battery voltage	Battery voltage	Battery voltage



OK or NG


OK >> GO TO 3.

NG >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM Connector	Terminal	Ground	Continuity
M57	2		Yes
M59	70		



OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.

CONSULT-II Functions (BCM)

BKS001F0

Refer to [LT-19, "CONSULT-II Functions \(BCM\)"](#) in "HEADLAMP - CONVENTIONAL TYPE -."

REAR FOG LAMP

Rear Fog Lamp Does Not Operate

BKS001F1

1. CHECK BULB

Check bulb of lamp which does not illuminate.

OK or NG

OK >> GO TO 2.

NG >> Replace rear fog lamp bulb.

2. CHECK COMBINATION SWITCH INPUT SIGNAL


1. Select "BCM" on CONSULT-II. Select "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR" on "SELECT DIAG MODE" screen. Make sure "RR FOG SW" turns ON-OFF linked with operation of rear fog lamp switch.

When lighting switch 1ST or 2ND position and rear fog lamp switch ON position : RR FOG SW ON

OK or NG

OK >> GO TO 3.

NG >> Replace combination switch (lighting switch).



3. ACTIVE TEST


1. Select "BCM" on CONSULT-II. Select "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch "RR FOG LAMP" screen.
4. Make sure rear fog lamp operates.

Rear fog lamp should operate.

OK or NG

OK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

NG >> GO TO 4.



4. CHECK REAR FOG LAMP CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector and rear combination lamp RH (rear fog lamp) connector.
3. Check continuity between BCM harness connector (A) and rear combination lamp RH (rear fog lamp) harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M59	69	B44	2	Yes

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.



REAR FOG LAMP


5. CHECK REAR FOG LAMP GROUND

Check continuity between rear combination lamp RH (rear fog lamp) harness connector and ground.

connector	Terminal	Ground	Continuity
B44	1		Yes

OK or NG

- OK >> GO TO 6.
- NG >> Repair harness or connector.




6. CHECK SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M59	69		No

OK or NG

- OK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).
- NG >> After repairing harness be sure to disconnect battery negative cable, and then reconnect it.




REAR FOG LAMP

Bulb Replacement

1. Remove rear bumper fascia. Refer to [EI-8, "REAR BUMPER"](#).
2. Disconnect rear fog lamp connector.
3. Turn bulb socket (2) counterclockwise and unlock it.
4. Remove bulb (1) from its socket.

Rear fog lamp


: 12V - 21W



Removal and Installation

REMOVAL

1. Remove rear bumper fascia. Refer to [EI-8, "REAR BUMPER"](#).
2. Disconnect rear fog lamp connector.
3. While pressing metal clip (A) on the reverse side of the bumper fascia.



INSTALLATION

Installation is the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
LT
L
M


TURN SIGNAL AND HAZARD WARNING LAMPS

TURN SIGNAL AND HAZARD WARNING LAMPS

PFP:26120

Component Parts and Harness Connector Location

BKS001F4



MKIB2253E

1. BCM M57,M59 (View with instrument upper panel removed)

2. Combination switch M38

3. Hazard switch M63

4. Combination meter M27

System Description

TURN SIGNAL OPERATION

BKS001F5

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 5, located in fuse block (J/B)]
- to BCM terminal 24,
- through 10A fuse [No. 4, located in fuse block (J/B)]
- to combination meter terminal 28.

Ground is supplied

- to BCM terminals 2 and 70
- to combination meter terminals 21, 22 and 23
- through grounds M21 and M66.

LH Turn Signal Lamp

When turn signal switch is moved to left position, BCM receives input signal requesting left turn signals to flash. BCM then supplies power

- through BCM terminal 65
- to front combination lamp LH (turn signal) terminal 1
- to side turn signal lamp LH terminal 1
- to rear combination lamp LH (turn signal) terminal 3.

Ground is supplied

- to front combination lamp LH (turn signal) terminal 2
- to side turn signal lamp LH terminal 2
- through grounds E45 (CR and HR engine models), E28 and E44,
- to rear combination lamp LH (turn signal) terminal 2
- through grounds B13, B28, B38 and B48.

The BCM also supplies input to combination meter terminals 1 and 2 via the CAN communication. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the left turn signal indicator lamp.

TURN SIGNAL AND HAZARD WARNING LAMPS

With power and input supplied, BCM controls flashing of LH turn signal lamps.

RH Turn Signal Lamp

When turn signal switch is moved to right position, BCM receives input signal requesting right turn signals to flash. BCM then supplies power

- through BCM terminal 66
- to front combination lamp RH (turn signal) terminal 1
- to side turn signal lamp RH terminal 1
- to rear combination lamp RH (turn signal) terminal 3.

Ground is supplied

- to front combination lamp RH (turn signal) terminal 2
- to side turn signal lamp RH terminal 2
- through grounds E45 (CR and HR engine models), E28 and E44,
- to rear combination lamp RH (turn signal) terminal 2
- through grounds B13, B28, B38 and B48.

The BCM also supplies input to combination meter terminals 1 and 2 via the CAN communication. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the right turn signal indicator lamp.

With power and input supplied, BCM controls flashing of RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times

- through 40A fusible link (letter J, located in fuse, fusible link and relay box)
- to BCM terminals 74 and 79,
- through 10A fuse [No. 7, located in fuse block (J/B)]
- to BCM terminal 27.

Ground is supplied

- to hazard switch terminal 1
- to BCM terminals 2 and 70
- to combination meter terminals 21, 22 and 23
- through grounds M21 and M66.

When hazard switch is depressed, ground is supplied

- to BCM terminal 26
- through hazard switch terminal 2.

BCM then supplies power

- through BCM terminal 65
- to front combination lamp LH (turn signal) terminal 1
- to side turn signal lamp LH terminal 1
- to rear combination lamp LH (turn signal) terminal 3,
- through BCM terminal 66
- to front combination lamp RH (turn signal) terminal 1
- to side turn signal lamp RH terminal 1
- to rear combination lamp RH (turn signal) terminal 3.

Ground is supplied

- to front combination lamp LH and RH (turn signal) terminal 2
- to side turn signal lamp LH and RH terminals 2
- through grounds E45 (CR and HR engine models), E28 and E44,
- to rear combination lamp LH and RH (turn signal) terminal 2
- through grounds B13, B28, B38 and B48.

A

B

C

D

E

F

G

H

I

J

LT

L

M

TURN SIGNAL AND HAZARD WARNING LAMPS

The BCM also supplies input to combination meter terminals 1 and 2 across CAN communication lines. This input is processed by unified meter control unit in combination meter, which in turn supplies ground to the left and right turn signal indicator lamps.

With power and input supplied, BCM controls flashing of hazard warning lamps.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-114, "COMBINATION SWITCH READING FUNCTION"](#) .

CAN Communication System Description

BKS001F6

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

BKS001F7



Refer to [LAN-27, "CAN Communication Unit"](#) .

TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —



BKS001F9

LT-TURN-01



REFER TO THE FOLLOWING.

- (M1) - SUPER MULTIPLE JUNCTION (SMJ)
- (M7) - FUSE BLOCK - JUNCTION BOX (J/B)



LT-TURN-02



TURN SIGNAL AND HAZARD WARNING LAMPS

Terminals and Reference Values for BCM





BKS001FA

CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-106, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
2	B	Ground	—	ON	—	Approx. 0V
9	V	Combination switch output 1	Output	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	<div> <div>OFF</div> <p>PKIB4958J</p> <p>Approx. 1.2V</p> </div>
					Any of the conditions below	<div> <div>Any of the conditions below</div> <ul style="list-style-type: none"> ● Turn signal switch to right ● Turn signal switch to left <p>PKIB4959J</p> <p>Approx. 1.0V</p> </div>
15	W	Combination switch input 5	Input	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	<div> <div>OFF</div> <p>PKIB4956J</p> <p>Approx. 0.9V</p> </div>
					Turn signal switch to right	<div> <div>Turn signal switch to right</div> <p>PKIB8625J</p> <p>Approx. 1.5 - 2.0V</p> </div>
19	L	CAN - H	Input/Output	ON	—	Approx. 2.6V
24	O	Ignition switch (ON)	Input	ON	—	Battery voltage
26	L	Hazard switch signal	Input	OFF	Hazard switch	ON
					OFF	Battery voltage

TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition			Reference value
				Ignition switch	Operation or condition		
34	Y	Combination switch input 4	Input	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	OFF	 <p>PKIB4958J</p> <p>Approx. 1.0V</p>
						Turn signal switch to left	 <p>PKIB8630J</p> <p>Approx. 2.0V</p>
39	Y	CAN – L	Input/Output	ON	—		Approx. 2.4V
65	LG	Flasher output (Left)	Output	ON	Turn signal switch	OFF	Approx. 0V
						To left	 <p>SKIA3009J</p>
66	W	Flasher output (Right)	Output	ON	Turn signal switch	OFF	Approx. 0V
						To right	 <p>SKIA3009J</p>
70	B	Ground	—	ON	—		Approx. 0V
74 79	Y	Battery power supply	Input	OFF	—		Battery voltage

How to Proceed With Trouble Diagnosis

BKS001FB

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-98, "System Description"](#).
3. Perform the preliminary check. Refer to [LT-105, "Preliminary Check"](#).
4. Check symptom and repair or replace the malfunctioning parts.
5. Do turn signal and hazard warning lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

TURN SIGNAL AND HAZARD WARNING LAMPS

Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

BKS001FC

1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	J
	Ignition switch ON or START position	5

Refer to [LT-101, "Wiring Diagram — TURN —"](#).

OK or NG


OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+)		(-)	OFF	ACC	ON
BCM Connector	Terminal				
M57	24	Ground	Approx. 0V	Approx. 0V	Battery voltage
M59	74		Battery voltage	Battery voltage	Battery voltage
	79		Battery voltage	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM Connector	Terminal	Ground	Continuity
M57	2	Ground	Yes
M59	70		

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



TURN SIGNAL AND HAZARD WARNING LAMPS

CONSULT-II Functions (BCM)

BKS001FD

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnosis part	Diagnosis mode	Description
FLASHER	Work Support	Changes the setting for each function.
	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.

CONSULT-II INSPECTION PROCEDURE

Refer to [GI-36, "CONSULT-II Start Procedure"](#) .

CONSULT-II Application Items WORK SUPPORT

BKS001KZ

Supported Item	All items will be monitored.
HAZARD LAMP SET	hazard reminder function mode can be changed in this mode.

Hazard Lamp Set

	MODE1		MODE2		MODE3		MODE4	
Remote controller operation	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock
Hazard warning lamp flash	-	-	-	Twice	Once	-	Once	Twice

DATA MONITOR

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays status (ignition switch IGN position: ON/other: OFF) of ignition switch judged from the ignition switch signal.
HAZARD SW "ON/OFF"	Displays status (hazard switch ON position: ON/other: OFF) of hazard switch judged from the hazard switch signal.
TURN SIGNAL R "ON/OFF"	Displays status (turn signal switch right position: ON/other: OFF) of turn RH switch judged from the turn signal switch signal.
TURN SIGNAL L "ON/OFF"	Displays status (turn signal switch left position: ON/other: OFF) of turn LH switch judged from the turn signal switch signal.
TURN/L MNTR "ON/OFF"	Displays status (One bulb blown: ON/Others: OFF) as judged from bulb signal.

ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check left or right turn signal lamp operation. The turn signal lamp turned ON when "LH" or "RH" on CONSULT-II screen is touched.

A
B
C
D
E
F
G
H
I
J
K
L
M

BKS001FE

L
M
T

J

H

F

D

B

- E

C

A

J

- H

F

E

C

A


J

TURN SIGNAL AND HAZARD WARNING LAMPS

4. CHECK TURN SIGNAL LAMP CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM connector and all turn signal lamp connectors.
3. Check continuity between BCM harness connector (A) and front combination lamp LH and RH (turn signal) harness connector (B).

Circuit	A		B		Continuity
	connector	Terminal	connector	Terminal	
LH	M59	65	E13	1	Yes
RH		66	E22		




4. Check continuity between BCM harness connector (A) and side turn signal lamp LH and RH harness connector (B).

Circuit	A		B		Continuity
	connector	Terminal	connector	Terminal	
LH	M59	65	E41	1	Yes
RH		66	E31		



5. Check continuity between BCM harness connector (A) and rear combination lamp LH and RH (turn signal) harness connector (B).

Circuit	A		B		Continuity
	connector	Terminal	connector	Terminal	
LH	M59	65	B17	3	Yes
RH		66	B39		



OK >> GO TO 5.

NG >> Repair harness or connector.

5. CHECK SIGNAL LAMP CIRCUIT (SHORT CIRCUIT)


Check continuity between BCM harness connector and ground.

BCM connector		Terminal	Ground	Continuity
LH	M59	65		
RH		66		No

OK or NG

OK >> Replace BCM if turn signal lamps does not work after setting the connector again. Refer to [BCS-17, "Removal and Installation of BCM"](#) .

NG >> Repair harness or connector.



TURN SIGNAL AND HAZARD WARNING LAMPS

Hazard Warning Lamp Does Not Operate But Turn Signal Lamp Operates

BKS001FF

1. CHECK BULB

Make sure bulb standard of each turn signal lamp is correct.

OK or NG


- OK >> GO TO 2.
NG >> Replace bulb.

2. CHECK HAZARD SWITCH INPUT SIGNAL

With CONSULT-II

1. Select "BCM" on CONSULT-II. Select "FLASHER" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR" on "SELECT DIAG MODE" screen. Make sure that "HAZARD SW" turns ON-OFF linked with operation of malfunction switch (hazard switch).

When hazard switch is ON position : HAZARD SW ON




Without CONSULT-II

Check voltage between BCM harness connector and ground.

Terminal		Condition	Voltage
(+)	(-)		
BCM connector	Terminal		
M57	26	Hazard switch is ON	Approx. 0V
		Hazard switch is OFF	Battery voltage

OK or NG

- OK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.




3. CHECK HAZARD SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and hazard switch connector.
3. Check continuity between BCM harness connector M57 terminal 26 and hazard switch harness connector M63 terminal 2.

26 - 2 : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness or connector.



TURN SIGNAL AND HAZARD WARNING LAMPS


4. CHECK GROUND

Check continuity hazard switch harness connector M63 terminal 1 and ground.

1 – Ground : Continuity should exist.

OK or NG

- OK >> GO TO 5.
- NG >> Repair harness or connector.




5. CHECK HAZARD SWITCH

- 1. Disconnect hazard switch connector.
- 2. Check continuity hazard switch terminal.

Terminal		Condition	Continuity
Hazard switch			
1	2	Hazard switch is ON	Yes
		Hazard switch is OFF	No

OK or NG

- OK >> Replace BCM if turn signal lamps does not work after setting the connector again. Refer to [BCS-17, "Removal and Installation of BCM"](#) .
- NG >> Replace hazard switch.



TURN SIGNAL AND HAZARD WARNING LAMPS

Bulb Replacement (Front Turn Signal Lamp)

BKS001FG

Refer to [LT-32, "Bulb Replacement"](#) in "HEADLAMP - CONVENTIONAL TYPE -".

Bulb Replacement (Rear Turn Signal Lamp)

BKS001FH


Refer to [LT-149, "Bulb Replacement"](#) .

Bulb Replacement (Side Turn Signal Lamp)

BKS001FI

1. Remove side turn signal lamp (2). Refer to [LT-111, "Removal and Installation of Side Turn Signal Lamp"](#) .
2. Turn bulb socket (1) counterclockwise and unlock it.
3. Remove the bulb (3) from the socket.

Side turn signal lamp : 12V - 5W



Removal and Installation of Front Turn Signal Lamp

BKS001FJ

Refer to [LT-32, "Removal and Installation"](#) in "HEADLAMP - CONVENTIONAL TYPE -".

Removal and Installation of Rear Turn Signal Lamp

BKS001FK

Refer to [LT-149, "Removal and Installation"](#) .

Removal and Installation of Side Turn Signal Lamp REMOVAL

BKS001FL


1. Insert a spatula or the similar tool under the side turn signal lamp (1). While pushing the pawl (A) of the lamp, pull off the lamp from the vehicle.
2. Disconnect side turn signal lamp.

NOTE:

Support side turn signal lamp harness with tape so that it won't fall into the front fender.

CAUTION:

Install the lamp housing with the bead facing up.



INSTALLATION

Installation is the reverse order of removal.

LIGHTING AND TURN SIGNAL SWITCH

LIGHTING AND TURN SIGNAL SWITCH


PFP:25540

Removal and Installation

BKS001FM

REMOVAL

1. Remove steering column cover. Refer to [IP-4, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. While pressing pawls (A) in direction as shown in the figure, pull lighting and turn signal switch (1) toward driver door and disconnect from the base.



INSTALLATION

Installation is the reverse order of removal.

HAZARD SWITCH

HAZARD SWITCH


PPF:25290

Removal and Installation

BKS001FN

REMOVAL

1. Remove controller (1). Refer to [ATC-112, "CONTROLLER"](#) .
2. Disconnect hazard switch connector.
3. Press pawl (A) on reverse side and remove the hazard switch (2).



INSTALLATION

Installation is the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
LT
L
M

COMBINATION SWITCH

COMBINATION SWITCH

PFP:25567

System Description

BKS00271


COMBINATION SWITCH READING FUNCTION

Description

- BCM reads combination switch (wiper) status, and controls related systems such as headlamps and wipers, according to the results.
- BCM reads information for a maximum of 20 switches by combining 5 output terminals (OUTPUT 1-5) and 5 input terminals (INPUT 1-5).

Operation Description

- BCM activates transistors of output terminals (OUTPUT 1-5) periodically, and allows current to flow in turn.
- If any (1 or more) switches are turned ON, the circuit of output terminals (OUTPUT 1-5) and input terminals (INPUT 1-5) becomes active.
- At this time, transistors of output terminals (OUTPUT 1-5) are activated to allow current to flow. When voltage of the input terminal (INPUT 1-5) corresponding to that switch changes, the interface in the BCM detects a voltage change, and the BCM determines that the switch is ON.



※1 : LIGHTING SWITCH 1ST POSITION

※2 : FR WIPER INT (without light and rain sensor), AUTO WIPER (with light and rain sensor)

MKIB2223E

COMBINATION SWITCH

BCM - Operation Table of Combination Switches


- BCM reads operation status of the combination switch using combinations shown in the table below.

	COMB SW OUTPUT 1		COMB SW OUTPUT 2		COMB SW OUTPUT 3		COMB SW OUTPUT 4		COMB SW OUTPUT 5	
	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF
COMB SW INPUT 1	—	—	FR WIPER HI ON	FR WIPER HI OFF	INT VOLUME 1 ON	INT VOLUME 1 OFF	RR WIPER INT ON	RR WIPER INT OFF	INT VOLUME 2 ON	INT VOLUME 2 OFF
COMB SW INPUT 2	FR WASHER ON	FR WASHER OFF	—	—	RR WASHER ON	RR WASHER OFF	INT VOLUME 3 ON	INT VOLUME 3 OFF	RR WIPER ON	RR WIPER OFF
COMB SW INPUT 3	FR WIPER LO ON	FR WIPER LO OFF	FR WIPER INT ON	FR WIPER INT OFF	—	—	AUTO LIGHT ON	AUTO LIGHT OFF	RR FOG ON	RR FOG OFF
COMB SW INPUT 4	TURN LH ON	TURN LH OFF	PASSING ON	PASSING OFF	HEAD-LAMP 2 ON	HEAD-LAMP 2 OFF	—	—	FR FOG ON	FR FOG OFF
COMB SW INPUT 5	TURN RH ON	TURN RH OFF	HEAD-LAMP 1 ON	HEAD-LAMP 1 OFF	HI BEAM ON	HI BEAM OFF	LIGHTING SW (1ST) ON	LIGHTING SW (1ST) OFF	—	—

PKIC0420E

Sample Operation: (When Lighting Switch 1st Position Turned ON)

- When lighting switch 1st position is turned ON, contact in combination switch turns ON. At this time if OUTPUT 4 transistor is activated, BCM detects that voltage changes in INPUT 5.
- When OUTPUT 4 transistor is ON, BCM detects that voltage changes in INPUT 5, and judges lighting switch 1st position is ON. Then BCM sends tail lamp ON signal to IPDM E/R using CAN communication.
- When OUTPUT 4 transistor is activated again, BCM detects that voltage changes in INPUT 5 and recognizes that lighting switch 1st position is continuously ON.



※1 : LIGHTING SWITCH 1ST POSITION

※2 : FR WIPER INT (without light and rain sensor), AUTO WIPER (with light and rain sensor)

MKIB2289E

NOTE:


Each output terminal transistor operates at 20 ms intervals. Therefore, after a switch is turned ON, the electrical loads are activate with a time delay, However, this delay is too small to be detected.

COMBINATION SWITCH

Operation Mode

Combination switch reading function has operation modes shown below.

1. Normal status
 - When BCM is not in sleep status, output terminals (OUTPUT 1-5) send out ON signal every 10 ms.
2. Sleep status
 - When BCM is in sleep status, BCM enters low power mode. Mean while out put terminals (OUTPUT 1-5) send out ON signal every 60ms, and accept only input from light switch system.



COMBINATION SWITCH




Wiring Diagram — COMBSW —

BKS001FO

LT-COMBSW-01

DATA LINE

A
B
C
D
E
F
G
H
I
J
LT
L
M



REFER TO THE FOLLOWING.

(M1) - SUPER MULTIPLE JUNCTION (SMJ)

(M7) - FUSE BLOCK - JUNCTION BOX (J/B)



MKWA4364E





COMBINATION SWITCH

Terminals and Reference Values for BCM



BKS001FQ

CAUTION:





- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-124, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
2	B	Ground	—	ON	—	Approx. 0V
7	BR	Combination switch output 5	Output	ON	Lighting, turn, wiper switch	<p>OFF (Wiper intermittent dial position 4)</p>  <p>PKIB8643J</p> <p>Approx. 1.2V</p>
					Any of several conditions below	<p>Any of several conditions below</p> <ul style="list-style-type: none"> ● Front fog lamp switch (Operates only front fog lamp switch) (Wiper intermittent dial position 4) ● Rear fog lamp switch (Wiper intermittent dial position 4) ● Rear wiper ON (Wiper intermittent dial position 4) ● Wiper intermittent dial position 1 ● Wiper intermittent dial position 2 ● Wiper intermittent dial position 6 ● Wiper intermittent dial position 7  <p>PKIB4956J</p> <p>Approx. 1.0V</p>
8	L	Combination switch output 3	Output	ON	Lighting, turn, wiper switch	<p>OFF (Wiper dial position 4)</p>  <p>PKIB4958J</p> <p>Approx. 1.2V</p>
					Any of several conditions below	<p>Any of several conditions below</p> <ul style="list-style-type: none"> ● Lighting switch 2ND (Wiper intermittent dial position 4) ● Lighting switch HI beam (Operates only HI beam switch) (Wiper intermittent dial position 4) ● Wiper intermittent dial position 1 ● Wiper intermittent dial position 2 ● Wiper intermittent dial position 3  <p>PKIB4959J</p> <p>Approx. 1.0V</p>

COMBINATION SWITCH

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
9	V	Combination switch output 1	Output	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	 <p>Approx. 1.2V</p>
					OFF Any of several conditions below <ul style="list-style-type: none"> • Turn signal switch to right • Turn signal switch to left • Front wiper switch MIST • Front wiper switch LO • Front washer switch 	 <p>Approx. 1.0V</p>
13	SB	Combination switch input 1	Input	ON	Lighting, turn, wiper switch <ul style="list-style-type: none"> • OFF • Front wiper switch HI (Wiper intermittent dial position 4) • Wiper intermittent dial position 1 • Wiper intermittent dial position 2 • Wiper intermittent dial position 3 • Wiper intermittent dial position 6 • Wiper intermittent dial position 7 	Refer to LT-121. "Reference Values for BCM (Input)" .
14	P	Combination switch input 3	Input	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4) <ul style="list-style-type: none"> • OFF • Lighting switch AUTO • Rear fog lamp switch • Front wiper switch MIST • Front wiper switch INT • Front wiper switch LO 	Refer to LT-121. "Reference Values for BCM (Input)" .
15	W	Combination switch input 5	Input	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4) <ul style="list-style-type: none"> • OFF • Lighting switch 1ST • Lighting switch 2ND • Lighting switch HIGH beam (Operates only HIGH beam switch) • Turn signal switch to right 	Refer to LT-121. "Reference Values for BCM (Input)" .
19	L	CAN - H	Input/Output	ON	—	Approx. 2.6V
22	Y	Battery safety line	Input	OFF	—	—
24	O	Ignition switch (ON)	Input	ON	—	Battery voltage

COMBINATION SWITCH

Ter- minal No.	Wire color	Signal name	Signal input/ output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
27	GR	Combi- nation switch output 4	Output	ON	Lighting, turn, wiper switch	 <p>PKIB4958J</p> <p>Approx. 1.2V</p>
					OFF (Wiper intermittent dial position 4) Any of several conditions below <ul style="list-style-type: none"> ● Lighting switch AUTO (Wiper intermittent dial position 4) ● Lighting switch 1ST (The same result with lighting switch 2ND) (Wiper intermittent dial position 4) ● Wiper intermittent dial position 1 ● Wiper intermittent dial position 5 ● Wiper intermittent dial position 6 	 <p>PKIB4959J</p> <p>Approx. 1.0V</p>
28	G	Combi- nation switch output 2	Output	ON	Lighting, turn, wiper switch (Wiper intermit- tent dial position 4)	 <p>PKIB4958J</p> <p>Approx. 1.2V</p>
					Any of several conditions below <ul style="list-style-type: none"> ● Lighting switch 2ND ● Lighting switch PASSING (Operates only PASSING switch) ● Front wiper switch INT ● Front wiper switch HI 	 <p>PKIB4959J</p> <p>Approx. 1.0V</p>
33	R	Combi- nation switch input 2	Input	ON	Lighting, turn, wiper switch	<ul style="list-style-type: none"> ● OFF ● Front washer switch (Wiper intermittent dial position 4) ● Wiper intermittent dial position 1 ● Wiper intermittent dial position 5 ● Wiper intermittent dial position 6 <p>Refer to LT-121, "Reference Values for BCM (Input)" .</p>
34	Y	Combi- nation switch input 4	Input	ON	Lighting, turn, wiper switch (Wiper intermit- tent dial position 4)	<ul style="list-style-type: none"> ● OFF ● Front fog lamp switch ON ● Lighting switch 2ND ● Lighting switch PASSING (Operates only PASSING switch) ● Turn signal switch to left <p>Refer to LT-121, "Reference Values for BCM (Input)" .</p>
39	Y	CAN – L	Input/ Output	ON	—	Approx. 2.4V

COMBINATION SWITCH

Ter- minal No.	Wire color	Signal name	Signal input/ output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
70	B	Ground	—	ON	—	Approx. 0V
74 79	Y	Battery power supply	Input	OFF	—	Battery voltage

Reference Values for BCM (Input)











BKS001FR

CAUTION:






- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-124, "DATA MONITOR"](#).

INPUT	Condition and reference value		
INPUT 5 (Wiper intermittent dial position 4)	<p>OFF</p> <p>Approx. 0.9V</p>	<p>Lighting switch 1ST</p> <p>Approx. 1.5 - 2.0V</p>	<p>Lighting switch 2ND</p> <p>Approx. 2.5 - 3.0V</p>
	<p>Lighting switch HI beam (Operates only HI beam switch)</p> <p>Approx. 1.5 - 2.0V</p>	<p>Turn signal switch to right</p> <p>Approx. 1.5 - 2.0V</p>	—
	<p>OFF</p> <p>Approx. 1.0V</p>	<p>Lighting switch 2ND</p> <p>Approx. 1.5 - 2.0V</p>	<p>Turn signal switch to left</p> <p>Approx. 2.0V</p>
	<p>Front fog lamp switch (Operates only front fog lamp switch)</p> <p>Approx. 1.5 - 2.0V</p>	<p>Lighting switch PASSING (Operates only PASSING switch)</p> <p>Approx. 2.0V</p>	—

COMBINATION SWITCH

INPUT	Condition and reference value		
INPUT 3 (Wiper intermittent dial position 4)	<p>OFF</p>  <p>PKIB4958J</p> <p>Approx. 1.0V</p>	<p>Lighting switch AUTO</p>  <p>PKIB8631J</p> <p>Approx. 2.0V</p>	<p>Front wiper switch INT</p>  <p>PKIB8632J</p> <p>Approx. 2.0V</p>
	<p>Any of several conditions below</p> <ul style="list-style-type: none"> ●Front wiper switch LO ●Front wiper switch MIST  <p>PKIB8629J</p> <p>Approx. 2.0V</p>	<p>Rear fog lamp switch</p>  <p>PKIC1030E</p> <p>Approx. 1.5V</p>	<p>—</p>
INPUT 2	<p>OFF (Wiper intermittent dial position 4)</p>  <p>PKIB4958J</p> <p>Approx. 1.0V</p>	<p>Front washer switch (Wiper intermittent dial position 4)</p>  <p>PKIB8632J</p> <p>Approx. 2.0V</p>	<p>Rear washer switch (Wiper intermittent dial position 4)</p>  <p>PKIB8631J</p> <p>Approx. 2.0V</p>
	<p>Rear wiper switch ON (Wiper intermittent dial position 4)</p>  <p>PKIB8634J</p> <p>Approx. 1.5 - 2.0V</p>	<p>Any of the conditions below</p> <ul style="list-style-type: none"> ●Wiper intermittent dial position 1 ●Wiper intermittent dial position 5 ●Wiper intermittent dial position 6  <p>PKIB8633J</p> <p>Approx. 2.0V</p>	<p>—</p>

COMBINATION SWITCH

INPUT	Condition and reference value		
INPUT 1	<p>OFF (Wiper intermittent dial position 4)</p>  <p>PKIB4958J</p> <p>Approx. 1.0V</p>	<p>Front wiper switch HI (Wiper intermittent dial position 4)</p>  <p>PKIB8635J</p> <p>Approx. 2.0V</p>	<p>Any of the conditions below</p> <ul style="list-style-type: none">●Rear wiper switch INT (Wiper intermittent dial position 4)●Wiper intermittent dial position 3  <p>PKIB8636J</p> <p>Approx. 2.0V</p>
	<p>Any of the conditions below</p> <ul style="list-style-type: none">●Wiper intermittent dial position 1●Wiper intermittent dial position 2  <p>PKIB8637J</p> <p>Approx. 2.5 - 3.0V</p>	<p>Any of the conditions below</p> <ul style="list-style-type: none">●Wiper intermittent dial position 6●Wiper intermittent dial position 7  <p>PKIB8638J</p> <p>Approx. 2.0V</p>	—

A
B
C
D
E
F
G
H
I
J
LT
L
M

COMBINATION SWITCH

CONSULT-II Function (BCM)

BKS001FS

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnosis part	Diagnosis mode	Description
COMB SW	DATA MONITOR	Displays BCM input data in real time.

CONSULT-II INSPECTION PROCEDURE

Refer to [GI-36, "CONSULT-II Start Procedure"](#).

CONSULT-II Application Items DATA MONITOR

BKS001KX

Monitor item "UNIT"	Display content
TURN SIGNAL R [ON/OFF]	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L [ON/OFF]	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
HI BEAM SW [ON/OFF]	Displays status (High beam switch: ON/Others: OFF) as judged from lighting switch signal.
H/L SW POS [ON/OFF]	Displays status (Headlamp switch 1: ON/Others: OFF) as judged from lighting switch signal.
LIGHT SW 1ST [ON/OFF]	Displays status (Lighting switch 1st position: ON/Others: OFF) as judged from lighting switch signal.
PASSING SW [ON/OFF]	Displays status (Flash-to-pass switch: ON/Others: OFF) as judged from lighting switch signal.
FR FOG SW [ON/OFF]	Displays status (Front fog lamp switch: ON/Others: OFF) as judged from lighting switch signal. (ON is also displayed when rear fog lamp switch is on.)
RR FOG SW [ON/OFF]	Displays status (Rear fog lamp switch: ON/Others: OFF) as judged from lighting switch signal.
FR WIPER HI [ON/OFF]	Displays status (Front Wiper HI: ON/Others: OFF) as judged from wiper switch signal.
FR WIPER LOW [ON/OFF]	Displays status (Front Wiper LOW: ON/Others: OFF) as judged from wiper switch signal.
FR WIPER INT [ON/OFF]	Displays status (Front Wiper INT: ON/Others: OFF) as judged from wiper switch signal.
FR WASHER SW [ON/OFF]	Displays status (Front Washer Switch: ON/Others: OFF) as judged from wiper switch signal.
INT VOLUME [1 - 7]	Displays intermittent operation dial position setting (1 - 7) as judged from wiper switch signal.
RR WIPER ON [ON/OFF]	Displays status (Rear Wiper ON: ON/Others: OFF) as judged from wiper switch signal.
RR WIPER INT [ON/OFF]	Displays status (Rear Wiper INT: ON/Others: OFF) as judged from wiper switch signal.
RR WASHER SW [ON/OFF]	Displays status (Rear Washer Switch: ON/Others: OFF) as judged from wiper switch signal.

COMBINATION SWITCH

Combination Switch Inspection

BKS001FT

1. SYSTEM CHECK 1

Check which systems (INPUT and OUTPUT) the malfunctioning switch belongs to. Refer to the table below.

	INPUT1	INPUT2	INPUT3	INPUT4	INPUT5
OUTPUT1	—	FRONT WASHER	FRONT WIPER LO	TURN LH	TURN RH
OUTPUT2	FRONT WIPER HI	—	*1	PASSING	HEAD LAMP 1
OUTPUT3	INT VOLUME 1	RR WASHER	—	HEAD LAMP 2	HI BEAM
OUTPUT4	REAR WIPER INT	INT VOLUME 3	AUTO LIGHT	—	LIGHT SW 1ST
OUTPUT5	INT VOLUME 2	RR WIPER	REAR FOG	FRONT FOG	—

*1: FRONT WIPER INT (without light and rain sensor), AUTO WIPER (with light and rain sensor)

>> GO TO 2.

2. SYSTEM CHECK 2

1. Connect CONSULT-II and select "COMB SW" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR".
3. Select "START".

DATA MONITOR	
MONITOR	
TURN SIGNAL R	OFF
TURN SIGNAL L	OFF
HIBEAM SW	OFF
HEAD LAMP SW1	OFF
HEAD LAMP SW2	OFF
LIGHT SW 1ST	OFF
PASSING SW	OFF
AUTO LIGHT SW	OFF
FR FOG SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIA7602E

4. Confirm that other switches in malfunctioning system operate normally.

Example: When "TURN RH" is malfunctioning, confirm other switches in malfunctioning system operate properly as described below.

- INPUT5
Confirm that "HEAD LAMP1", "HI BEAM" and "LIGHT SW 1ST" can be turned ON and OFF properly.
- OUTPUT1
Confirm that "TURN LH", "FRONT WIPER LO" and "FRONT WASHER" can be turned ON and OFF properly.

OK or NG

- OK >> Replace malfunctioning lighting switch or wiper switch. Refer to [LT-112, "LIGHTING AND TURN SIGNAL SWITCH"](#) or [WW-46, "Removal and Installation of Front Wiper and Washer Switch"](#).
- NG >> GO TO 3.

COMBINATION SWITCH

3. HARNESS INSPECTION

1. Turn ignition switch OFF.
2. Disconnect BCM connector and combination switch connector.
3. Check for continuity between BCM harness connector of the suspected system and the corresponding combination switch harness connector.

BCM		Combination switch		Continuity
Connector	Terminal	Connector	Terminal	
M57	INPUT1	M38	6	Yes
	INPUT2		7	
	INPUT3		10	
	INPUT4		9	
	INPUT5		8	
	OUTPUT1		1	
	OUTPUT2		2	
	OUTPUT3		3	
	OUTPUT4		4	
	OUTPUT5		5	

4. Check for continuity between BCM harness connector of the suspected system and ground.

BCM			Continuity
Connector	Terminal		
M57	INPUT1	Ground	No
	INPUT2		
	INPUT3		
	INPUT4		
	INPUT5		
	OUTPUT1		
	OUTPUT2		
	OUTPUT3		
	OUTPUT4		
	OUTPUT5		

OK or NG

OK >> GO TO4.

NG >> Repair or replace harness connector.


4. SELECTION MALFUNCTION SYSTEM

Which system does malfunction system belong to?

INPUT or OUTPUT

INPUT >> GO TO 5.



OUTPUT >>GO TO 6.



COMBINATION SWITCH

5. CHECK BCM INPUT TERMINAL

- 1. Connect BCM and combination switch connectors.
- 2. Turn ignition switch ON.
- 3. Turn "lighting", "wiper" and "turn" switch OFF.
- 4. Set wiper intermittent dial to position 4.
- 5. Check BCM input terminal voltage waveform of the suspected malfunctioning system.

INPUT	BCM			Voltage
	Connector	Terminal		
1	M57	13	Ground	 Approx. 1.2V
2		33		
3		14		
4		34		
5		15		 Approx. 1.2V



OK or NG

- OK >> Replace BCM.Refer to [BCS-17, "Removal and Installation of BCM"](#) .
- NG (0V) >>GO TO 7.
- NG (Other than 0V) >>Replace BCM.Refer to [BCS-17, "Removal and Installation of BCM"](#) .

COMBINATION SWITCH

6. CHECK BCM OUTPUT TERMINAL

1. Connect BCM and combination switch connectors.
2. Turn ignition switch ON.
3. Turn "lighting", "wiper" and "turn" switch OFF.
4. Set wiper intermittent dial to position 4.
5. Check BCM input terminal voltage waveform of the suspected malfunctioning system.

OUTPUT	BCM			Voltage
	Connector	Terminal		
1	M57	9	Ground	 <p>Approx. 1.0V</p>
2		28		
3		8		
4		27		
5		7		 <p>Approx. 0.9V</p>

OK or NG

OK >> GO TO 7.

NG >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#) .

7. COMBINATION SWITCH INSPECTION

Perform combination switch inspection. Refer to the table below.

Procedure									
1	2		3	4		5	6		7
Replace lighting switch	Confirm check results	OK	INSPECTION END	Confirm check results	OK	INSPECTION END	Confirm check results	OK	INSPECTION END
		NG	Replace wiper switch		NG	Replace switch base		NG	Confirm symptom again

>> INSPECTION END

Removal and Installation

Refer to [LT-112, "LIGHTING AND TURN SIGNAL SWITCH"](#) .

BKS001FU

STOP LAMP



STOP LAMP

PFP:26550

Wiring Diagram — STOP/L —

BKS001FV

LT-STOP/L-01



REFER TO THE FOLLOWING.

- (M1) - SUPER MULTIPLE JUNCTION (SMJ)
- (M7) - FUSE BLOCK - JUNCTION BOX (J/B)


STOP LAMP

Bulb Replacement of High-Mounted Stop Lamp

BKS001FW

1. Remove high-mounted stop lamp (1). Refer to [LT-130, "Removal and Installation of High-Mounted Stop Lamp"](#).
2. Turn bulb socket (2) counter clock and unlock it.
3. Remove the bulb (3) from the socket.

High-mounted stop lamp : 12V - 16W



Bulb Replacement of Rear Combination Lamp (Stop Lamp)


BKS001FX

Refer to [LT-149, "Bulb Replacement"](#).

Removal and Installation of High-Mounted Stop Lamp REMOVAL

BKS001FY

1. Open the back door and remove seal cover (1).
2. Remove nuts (A).



3. Pull the high-mounted stop lamp toward rear of the vehicle and remove from the back door.
4. Disconnect high-mounted stop lamp connector.

INSTALLATION

Installation is the reverse order of removal.

Removal and Installation of Rear Combination Lamp (Stop Lamp)

BKS001FZ

Refer to [LT-149, "Removal and Installation"](#).

BACK-UP LAMP

PFP:26550


Wiring Diagram — BACK/L —

BKS001G0




LT-BACK/L-01

- (A) : WITH A/T
- (M) : WITH M/T
- (C) : CR ENGINE MODELS
- (H) : HR ENGINE MODELS
- (K) : K9K ENGINE MODELS

- *1 20: (C), (K)
9H: (H)
- *2 19: (C), (K)
8H: (H)




27	28	29	30	31	32	33
34	35	36	37	38	39	40
41	42					



REFER TO THE FOLLOWING.
(F1) - SUPER MULTIPLE JUNCTION (SMJ)

BACK-UP LAMP

LT-BACK/L-02



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

(M11)
W

27	28	29	30	31	32	33
34	35	36	37	38	39	40
41	42					

(E7)
W

15	16	17	18	19
20	21	22	23	24
25	26			

(E10)
BR



2	1
6	5
4	3

(B17) (B39)
W W

REFER TO THE FOLLOWING.
(M1) - SUPER MULTIPLE
JUNCTION (SMJ)

Bulb Replacement

BKS001G1

Refer to [LT-149, "Bulb Replacement"](#) .

Removal and Installation

BKS001G2

Refer to [LT-149, "Removal and Installation"](#) .

A

B

C

D

E

F

G

H

I

J

LT

L


M

PARKING, LICENSE PLATE AND TAIL LAMPS

PFP:26550

Component Parts and Harness Connector Location

BKS001G3



1. IPDM E/R E8,E10,E11,E12

2. BCM M57,M59 (View with instrument upper panel removed)

3. Combination switch M38

System Description

BKS001G4

The control of the parking, license plate and tail lamp operation is dependent upon the position of lighting switch. When the lighting switch is placed in the 1ST position, the BCM (body control module) receives input signal requesting the parking, license plate and tail lamps to illuminate. This input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication. The CPU (central processing unit) located in the IPDM E/R controls the tail lamp relay coil. This relay, when energized, directs power to parking, license plate and tail lamps, which then illuminate.

Power is supplied at all times

- to ignition relay located in IPDM E/R and
- to tail lamp relay located in IPDM E/R from battery directly,
- through 20A fuse (No. 61, located in IPDM E/R),
- through 20A fuse (No. 62, located in IPDM E/R),
- through 40A fusible link (letter J, located in fuse, fusible link and relay box)
- to BCM terminals 74 and 79.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay located in IPDM E/R, from battery directly and
- through 10A fuse [No. 5, located in fuse block (J/B)]
- to BCM terminal 24.

Ground is supplied

- to BCM terminals 2 and 70,
- through grounds M21 and M66,
- to IPDM E/R terminals 3 and 54
- through grounds E45 (CR and HR engine models), E28 and E44.

OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST or 2ND position (or if auto light system is activated), the BCM receives input signal requesting parking, license plate and tail lamps to illuminate. This input signal is communicated to the IPDM E/R via CAN communication. The CPU located in the IPDM E/R controls tail lamp relay coil, which when energized, directs power

- through 10A fuse (No. 45, located in IPDM E/R),
- through IPDM E/R terminal 45
- to parking lamp RH terminal 1,
- through IPDM E/R terminal 16
- to rear combination lamp RH (tail) terminal 5 and
- to license plate lamp LH and RH terminals 1,
- through 10A fuse (No. 46, located in IPDM E/R),
- through IPDM E/R terminal 49

PARKING, LICENSE PLATE AND TAIL LAMPS

- to parking lamp LH terminal 1 and
- through IPDM E/R terminal 15
- to rear combination lamp LH (tail) terminal 5.

Ground is supplied

- to parking lamp LH and RH terminals 2
- through grounds E45 (CR and HR engine models), E28 and E44,
- to rear combination lamp LH (tail) and RH (tail) terminal 2,
- to license plate lamp LH and RH terminals 2
- through grounds B13,B28,B38 and B48.

With power and ground supplied, parking, license plate and tail lamps illuminate.

COMBINATION SWITCH READING FUNCTION

Refer to [LT-114, "COMBINATION SWITCH READING FUNCTION"](#) .

EXTERIOR LAMP BATTERY SAVER CONTROL

Refer to [LT-135, "EXTERIOR LAMP BATTERY SAVER CONTROL"](#) .

FAIL-SAFE FUNCTION

When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. If the fail-safe system is operating, parking, license plate and tail lamps illuminate when the ignition switch is turned from OFF to ON and parking, license plate and tail lamps are turned off when the ignition switch is turn from ON to OFF. If the fail-safe system is operating, parking, license plate and tail lamps does not operate when the combination switch is in any position. After CAN communication recovers normally, it also returns to normal control. (Refer to [PG-18, "Fail-safe Control"](#) .)

CAN Communication System Description

BKS001G5

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

BKS001G6

Refer to [LAN-27, "CAN Communication Unit"](#) .

A

B

C

D

E

F

G

H

I

J

LT


L

M

PARKING, LICENSE PLATE AND TAIL LAMPS

Schematic

BKS001G7





MKWA4357E

Wiring Diagram — TAIL/L —

BKS001G8

LT-TAIL/L-01






REFER TO THE FOLLOWING.


(M1) - SUPER MULTIPLE
JUNCTION (SMJ)
(M7) - FUSE BLOCK -
JUNCTION BOX (J/B)

PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-02



A
B
C
D
E
F
G
H
I
J
LT
L
M







PARKING, LICENSE PLATE AND TAIL LAMPS

Terminals and Reference Values for BCM

BKS001G9

CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF not to be fluctuated by overloaded.
- Turn wiper dial position to 4 except when checking waveform or voltage of wiper dial position. Wiper dial position can be confirmed on CONSULT-II. Refer to [LT-19, "DATA MONITOR"](#).

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value
				Ignition switch	Operation or condition	
2	B	Ground	—	ON	—	Approx. 0V
15	W	Combination switch input 5	Input	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	 <p>PKIB4956J</p> <p>Approx. 0.9V</p>
					Lighting switch 1ST	 <p>PKIB8624J</p> <p>Approx. 1.5 - 2.0V</p>
19	L	CAN - H	Input/Output	—	—	—
24	O	Ignition switch (ON)	Input	ON	—	Battery voltage
27	GR	Combination switch output 4	Output	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	 <p>PKIB4958J</p> <p>Approx. 1.2V</p>
					Lighting switch 1ST (The same result with lighting switch 2ND)	 <p>PKIB4959J</p> <p>Approx. 1.0V</p>
39	Y	CAN - L	Input/Output	—	—	—
70	B	Ground	—	ON	—	Approx. 0V
74 79	Y	Battery power supply	Input	OFF	—	Battery voltage

PARKING, LICENSE PLATE AND TAIL LAMPS

Terminals and Reference Values for IPDM E/R

BKS001GA

Terminal No.	Wire color	Signal name	Signal input/output	Measuring condition		Reference value	
				Ignition switch	Operation or condition		
3	B	Ground	—	ON	—		Approx. 0V
15	GR	Rear combination lamp LH	Output		Lighting switch 1ST position	OFF	Approx. 0V
						ON	Battery voltage
16	V	Rear combination lamp RH, license plate lamp RH and LH	Output			OFF	Approx. 0V
						ON	Battery voltage
45	BR	Parking lamp RH	Output			OFF	Approx. 0V
						ON	Battery voltage
49	O	Parking lamp LH	Output			OFF	Approx. 0V
				ON		Battery voltage	
52	L	CAN – H	Input/Output	—	—		—
54	B	Ground	—	ON	—		Approx. 0V
58	Y	CAN – L	Input/Output	—	—		—

How to Proceed With Trouble Diagnosis

BKS001GB

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-134, "System Description"](#) .
3. Perform the preliminary check. Refer to [LT-142, "Preliminary Check"](#) .
4. Check symptom and repair or replace the malfunctioning parts.
5. Do the parking, license plate and tail lamps operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

LT

L

M

PARKING, LICENSE PLATE AND TAIL LAMPS

Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

BKS001GC

1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	J
	Ignition switch ON or START position	5
IPDM E/R	Battery	45
		46
		61
		62

Refer to [LT-137, "Wiring Diagram — TAIL/L —"](#) .

OK or NG


OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+)		(-)	OFF	ACC	ON
BCM Connector	Terminal				
M57	24	Ground	Approx. 0V	Approx. 0V	Battery voltage
M59	74		Battery voltage	Battery voltage	Battery voltage
	79		Battery voltage	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM Connector	Terminal	Ground	Continuity
M57	2	Ground	Yes
M59	70		

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



PARKING, LICENSE PLATE AND TAIL LAMPS

CONSULT-II Functions (BCM)

BKS001GD

Refer to [LT-19, "CONSULT-II Functions \(BCM\)"](#) in "HEADLAMP - CONVENTIONAL TYPE -".

CONSULT-II Functions (IPDM E/R)

BKS001GE

Refer to [LT-20, "CONSULT-II Functions \(IPDM E/R\)"](#) in "HEADLAMP - CONVENTIONAL TYPE -".

Parking, License Plate and Tail Lamps Do Not Illuminate

BKS001GF

1. CHECK COMBINATION SWITCH INPUT SIGNAL

⑧ With CONSULT-II

1. Select "BCM" on CONSULT-II. Select "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR" on "SELECT DIAG MODE" screen. Make sure "LIGHT SW 1ST" turns ON-OFF linked with operation of lighting switch.

When lighting switch is 1ST : LIGHT SW 1ST ON position

DATA MONITOR			
MONITOR			
LIGHT SW 1ST		ON	
		RECORD	
MODE	BACK	LIGHT	COPY

PKIA7607E

⊗ Without CONSULT-II

Refer to [LT-125, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check combination switch (lighting switch). Refer to [LT-125, "Combination Switch Inspection"](#).

2. ACTIVE TEST

⑧ With CONSULT-II

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
3. Touch "ON" screen.
4. Make sure parking, license plate and tail lamp operates.

Parking, license plate and tail lamp should operate.

⊗ Without CONSULT-II

1. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. Make sure parking, license plate and tail lamp operates.

Parking, license plate and tail lamp should operate.

ACTIVE TEST			
TAIL LAMP		OFF	
ON			
MODE	BACK	LIGHT	COPY

SKIA2348E

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

3. CHECK IPDM E/R

- 1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
- 2. Make sure "TAIL&CLR REQ" turns ON when lighting switch is in 1ST position.

When lighting switch is 1ST : TAIL&CLR REQ ON position

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#).
- NG >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

DATA MONITOR			
MONITOR			
TAIL&CLR REQ		ON	
		RECORD	
MODE	BACK	LIGHT	COPY

SKIA5958E

PARKING, LICENSE PLATE AND TAIL LAMPS

4. CHECK INPUT SIGNAL


 With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect parking lamp RH and LH, license plate lamp RH and LH, and rear combination lamp RH and LH connectors.
3. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
4. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
5. Touch "ON" screen.
6. When tail lamp relay is operating, check voltage between parking lamp, license plate lamp and rear combination lamp harness connector and ground.


 Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect parking lamp RH and LH, license plate lamp RH and LH, and rear combination lamp RH and LH connectors.
3. Start auto active test. Refer to [PG-22, "Auto Active Test"](#).
4. When tail lamp relay is operating, check voltage between parking lamp, license plate lamp and rear combination lamp harness connector and ground.


Terminal				Voltage
(+)		(-)		
Parking lamp connector	Terminal			
RH	E30	1	Ground	Battery voltage
LH	E43			



Terminal				Voltage
(+)		(-)		
License plate lamp connector	Terminal			
RH	D103	1	Ground	Battery voltage
LH	D105			



Terminal				Voltage
(+)		Terminal	(-)	
Rear combination lamp connector (tail)				
RH	B39	5	Ground	Battery voltage
LH	B17			



OK or NG


- OK >> GO TO 6.
NG >> GO TO 5.

PARKING, LICENSE PLATE AND TAIL LAMPS

5. CHECK PARKING, LICENSE PLATE AND TAIL LAMP CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector (A) and parking lamp harness connector (B).

Circuit	A		B		Continuity
	Connector	Terminal	Connector	Terminal	
RH	E8	45	E30	1	Yes
LH		49	E43		




4. Check continuity between IPDM E/R harness connector (A) and license plate lamp harness connector (B).

Circuit	A		B		Continuity
	Connector	Terminal	Connector	Terminal	
RH	E10	16	D103	1	Yes
LH			D105		



5. Check continuity between IPDM E/R harness connector (A) and rear combination lamp harness connector (B).

Circuit	A		B		Continuity
	Connector	Terminal	Connector	Terminal	
RH	E10	16	B39	5	Yes
LH		15	B17		



OK or NG


- OK >> Replace IPDM E/R. Refer to [PG-37, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.

PARKING, LICENSE PLATE AND TAIL LAMPS

6. CHECK PARKING, LICENSE PLATE AND TAIL LAMPS GROUND CIRCUIT


1. Check continuity between parking harness connector and ground.

Parking lamp connector		Terminal	Ground	Continuity
RH	E30	2		Yes
LH	E43			




2. Check continuity between license plate lamp harness connector and ground.

License plate lamp connector		Terminal	Ground	Continuity
RH	D103	2		Yes
LH	D105			



3. Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp connector		Terminal	Ground	Continuity
RH	B39	2		Yes
LH	B17			



OK or NG

- OK >> Check bulbs.
- NG >> Repair harness or connector.

Parking, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)

BKS001GG

- This symptom indicates the malfunction of ignition relay in IPDM E/R. Refer to [PG-19, "Function of Detecting Ignition Relay Malfunction"](#).
- Select "BCM" on CONSULT-II. Select "HEADLAMP" on "SELECT TEST ITEM" screen and select "DATA MONITOR" on "SELECT DIAG MODE" screen. If "LIGHT SW 1ST" is OFF when lighting switch is OFF, replace IPDM E/R.

PARKING, LICENSE PLATE AND TAIL LAMPS


Bulb Replacement PARKING LAMP

BKS001GH

Refer to [LT-149, "Bulb Replacement"](#).


LICENSE PLATE LAMP

1. Insert a screwdriver A or the like wrapped in a cloth into the lens (1) notch.



2. Remove bulb (1) from license plate lamp bulb socket.

License plate lamp : 12V - 5W



TAIL LAMP

Refer to [LT-149, "Bulb Replacement"](#).

Removal and Installation PARKING LAMP


BKS001GI

Refer to [LT-149, "Removal and Installation"](#).

LICENSE PLATE LAMP

Removal

1. Remove license plate finisher. Refer to [EI-24, "Removal and Installation"](#).
2. Disconnect the license plate lamp connector.
3. While pressing pawl on the reverse side of the back door finisher.



Installation

Installation is the reverse order of removal.

TAIL LAMP

Removal

Refer to [LT-149, "Removal and Installation"](#).

REAR COMBINATION LAMP

REAR COMBINATION LAMP


PFP:26554

Bulb Replacement

BKS001GJ

1. Remove rear combination lamp. Refer to [LT-149, "Removal and Installation"](#).
2. Turn bulb socket (1), (2), (3) counterclockwise and unlock it.
3. Remove bulb (4), (5), (6).

Stop/tail lamp (5)	: 12V - 21/5W
Rear turn signal lamp (4)	: 12V - 16W (amber)
Back-up lamp (6)	: 12V - 16W




BKS001GK


Removal and Installation

REMOVAL

1. Remove rear pillar garnish. Refer to [EI-26, "BODY SIDE TRIM"](#).
2. Disconnect rear combination lamp connector.
3. Remove rear combination lamp mounting bolts (A).
4. Pull the rear combination lamp (1) toward rear of the vehicle and remove from the vehicle.



5. While pressing pawls (A) in direction as shown in the figure, remove the rear combination lamp finisher (2) from the rear combination lamp body (1).



INSTALLATION

Installation is the reverse order of removal.

Rear combination lamp mounting nut  : 5.5 N·m (0.56 kg-m, 49 in-lb)


INTERIOR ROOM LAMP

INTERIOR ROOM LAMP

PFP:26410

Component Parts and Harness Connector Location

BKS001GO



1. BCM M57, M59 (View with instrument upper panel removed)

2. Key switch M33 (without Intelligent Key system)

3. Key switch and ignition knob switch M34 (with Intelligent Key system)

4. Front door switch driver side [B14 (LHD models)] [B29 (RHD models)] Front door switch passenger side [B29 (LHD models)] [B14 (RHD models)]

5. Rear door switch LH B19 Rear door switch RH B42

6. Door lock/unlock switch M54

System Description

BKS001GP

When interior room lamp switch is in DOOR position, interior room lamp ON/OFF is controlled by timer according to signals from switches including key switch, front door switch driver side, unlock signal from key fob, door lock and unlock switch, key cylinder lock and unlock switch, ignition switch.

When interior room lamp turns ON, there is a gradual brightening over 1 second.

When interior room lamp turns OFF, there is a gradual dimming over 1 second.

Interior room lamp timer is controlled by BCM.

POWER SUPPLY AND GROUND

Power is supplied at all times:

- through 40A fusible link (letter J, located in the fuse and fusible link box)
- to BCM terminals 74 and 79,
- through 10A fuse [No. 9, located in the fuse block (J/B)]
- to luggage room lamp terminal 1,
- to BCM terminal 72,
- to key switch terminal 2 (without Intelligent Key system) or
- through 10A fuse [No. 13, located in the fuse block (J/B)]
- to key switch and ignition knob switch terminal 2 and 4 (with Intelligent Key system).

When the key is removed from ignition key cylinder, power is interrupted

- through key switch terminal 1 (without Intelligent Key system) or
- through key switch and ignition knob switch terminal 1 (with Intelligent Key system)
- to BCM terminal 3.

With the ignition key switch in the ON or START position, power is supplied:

- through 10A fuse [No. 5, located in the fuse block (J/B)]
- to BCM terminal 24.

INTERIOR ROOM LAMP

Ground is supplied:

- to BCM terminals 2 and 70.
- through grounds M21 and M66.

When any door is opened, ground is supplied:

- to BCM terminal 29
- to front door switch (driver side) terminal 1
- through case ground of front door switch (driver side),
- to BCM terminal 30
- to front door switch (passenger side) terminal 1
- through case ground of front door switch (passenger side),
- to BCM terminal 59
- to rear door switch LH terminal 1
- through case ground of rear door switch LH,
- to BCM terminal 60
- to rear door switch RH terminal 1
- through case ground of rear door switch RH,
- to BCM terminal 10
- to back door switch terminal 2
- to back door switch terminal 1
- through grounds B13,B28,B38 and B48.

SWITCH OPERATION

When map lamp switch is ON, power is supplied:

- through BCM terminal 73
- to map lamp terminal 4.

Ground is supplied:

- to map lamp terminal 3
- through grounds M21 and M66.

With power and ground are supplied, the map lamp illuminates.

When map lamp switch is DOOR, power is supplied:

- through BCM terminal 73
- to map lamp terminal 4.

Ground is supplied:

- through map lamp terminal 2
- to BCM terminal 21.

With power and ground are supplied, the map lamp illuminates.

When back door is opened, ground supplied:

- to luggage room lamp terminal 2
- through back door switch terminals 2 and 1
- through grounds B13,B28,B38 and B48.

With power and ground are supplied, the luggage room lamp illuminates.

A

B

C

D

E

F

G

H

I

J

LT

L

M

INTERIOR ROOM LAMP

Models With Personal Lamp

When personal lamp switch is ON, power is supplied:

- through BCM terminal 73
- to personal lamp terminal 4.

Ground is supplied:

- to personal lamp terminal 3
- through grounds M21 and M66.

With power and ground are supplied, the personal lamp illuminates.

When personal lamp switch is DOOR, power is supplied:

- through BCM terminal 73
- to personal lamp terminal 4.

Ground is supplied:

- through personal lamp terminal 2
- to BCM terminal 21.

With power and ground are supplied, the personal lamp illuminates.

INTERIOR ROOM LAMP TIMER OPERATION

When interior room lamp switch is in the "DOOR" position, the BCM keeps the interior room lamp illuminated for Approx. 28 seconds when:

- unlock signal is received from Intelligent Key, while all doors are closed and key is out of the ignition key cylinder (with Intelligent Key system).
- unlock signal is received from key fob while all doors are closed and key is out of the ignition key cylinder (without Intelligent Key system).
- key is removed from ignition key cylinder while all doors are closed (without Intelligent Key system)
- any door is opened and then closed while key is out of the ignition key cylinder.

The timer is canceled when:

- ignition switch is turned ON.
- lock signal is received from Intelligent Key, while all doors are closed and key is out of the ignition key cylinder (with Intelligent Key system).
- lock signal is received from remote controller while all doors are closed and key is out of the ignition key cylinder (without Intelligent Key system).

INTERIOR ROOM LAMP BATTERY SAVER CONTROL

If interior room lamp is left ON, it will not be turned off even when door is closed.

BCM turns off interior room lamp automatically to save battery 15 minutes after ignition switch is turned off.

BCM controls interior room lamps listed below:

- Interior room lamp

After lamps turn OFF by the battery saver system, the lamps illuminate again when

- door lock switch is operated,
- Intelligent Key lock or unlock,
- door is opened,
- key is removed from ignition key cylinder.

—MODELS WITHOUT PERSONAL LAMP—

A

B

C

D

E

F

G

4


1

J

LT


L

M



INTERIOR ROOM LAMP

—MODELS WITH PERSONAL LAMP—



MKWA4448E



INTERIOR ROOM LAMP

Wiring Diagram — ROOM/L — —MODELS WITHOUT PERSONAL LAMP—

BKS001GR

A
B
C
D
E
F
G
H
I
J
LT
L
M

LT-INT/L-01







REFER TO THE FOLLOWING.

- (M1) - SUPER MULTIPLE JUNCTION (SMJ)
- (M7) - FUSE BLOCK - JUNCTION BOX (J/B)

MKWA4366E

INTERIOR ROOM LAMP





LT-INT/L-02



MKWA4367E

INTERIOR ROOM LAMP




LT-INT/L-03



MKWA4368E

INTERIOR ROOM LAMP

LT-INT/L-04



MKWA4369E

A
B
C
D
E
F
G
H
I
J
K
L
M





LT-INT/L-05



(M1) - SUPER MULTIPLE
JUNCTION (SMJ)
(M7) - FUSE BLOCK -
JUNCTION BOX (J/B)

INTERIOR ROOM LAMP



LT-INT/L-06



MKWA4450E

INTERIOR ROOM LAMP

LT-INT/L-07



A

B

C

D

E

F

G

H

I

J


LT

L

M

INTERIOR ROOM LAMP

LT-INT/L-08



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

(M11)
W

5	4
3	2
1	

(M54)
W

20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

(M57)
W

65	66	67	68	69	70	71	72	73
74	75	76	77	78	79			

(M59)
B



1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24

(M73)
W

1	2

(B36)
B

(B37)
B

4	3	2	1

(B46)
W

INTERIOR ROOM LAMP

Terminals and Reference Values for BCM

BKS001GS

Terminal No.	Wire color	Signal designation	Signal input/output	Measuring condition					Voltage [V] (Approx.)	
				Ignition switch	Operation or condition					
2	B	Ground	—	ON	—				0	
3	GR* ¹	Key switch signal	Input	OFF	Remove key.				0	
	O* ²				Key is inserted.				Battery voltage	
6	LG	Door lock / unlock switch (Lock signal)	Input	OFF	Lock operation (ON)				0	
					Other than above (OFF)				5	
10	P	Back door switch signal	Input	OFF	Back door switch signal	ON (open)		0		
						OFF (close)		Battery voltage		
19	L	CAN- H	Input/Output	—	—				—	
21	Y	Logical lighting control	Input	OFF	Interior room lamp switch: DOOR position	Key is inserted	Any door switch	ON (Open)	0	
								OFF (Close)	Battery voltage	
						Close all doors	Key is removed from key cylinder		0	
							Turn ignition switch ON		Battery voltage	
						Key is removed				0
						Interior room lamp timer		OFF	Battery voltage	
								ON	0	
24	O	Ignition power supply	Input	ON	—				Battery voltage	
25	BR	Door lock/unlock switch (Unlock signal)	Input	OFF	Unlock operation (ON)				0	
					Other than above (OFF)				5	
29	LG* ³	Driver door switch signal	Input	OFF	Driver door switch signal	ON (open)		0		
	OFF (closed)					Battery voltage				
30	BR* ³	Passenger door switch signal	Input	OFF	Passenger door switch signal	ON (open)		0		
	OFF (close)					Battery voltage				
39	Y	CAN- L	Input/Output	—	—				—	
59	G	Rear door switch LH signal	Input	OFF	Rear door switch LH signal	ON (open)		0		
						OFF (close)		Battery voltage		
60	L	Rear door switch RH signal	Input	OFF	Rear door switch RH signal	ON (open)		0		
						OFF (close)		Battery voltage		
70	B	Ground	—	ON	—				0	
72	Y	Power source (Fuse)	Input	OFF	—				Battery voltage	

INTERIOR ROOM LAMP

Terminal No.	Wire color	Signal designation	Signal input/output	Measuring condition					Voltage [V] (Approx.)
				Ignition switch	Operation or condition				
73	V	Interior room lamp signal	Output	OFF	Interior room lamp switch: DOOR position	Key is inserted.	Any door switch	ON (open)	0
								OFF (closed)	Battery voltage
				—		Close all doors.	Key is removed after being fully inserted.		0
							Turn ignition switch ON.		Battery voltage
74 79	Y	Power supply (Fusible link)	Input	OFF	—				Battery voltage

*1: With Intelligent Key system

*2: Without Intelligent Key system

*3: LHD models

*4: RHD models

How to Proceed With Trouble Diagnosis

BKS001GT

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-150, "System Description"](#).
3. Perform the preliminary check. Refer to [LT-165, "Preliminary Check"](#).
4. Check symptom and repair or replace the malfunctioning parts.
5. Does the interior room lamp operate normally? If YES, GO TO 6. If NO, GO TO 4.
6. INSPECTION END

INTERIOR ROOM LAMP

Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

BKS001GU

1. CHECK FUSES

Check for blown fuses.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	J
	Ignition switch ON or START position	5

Refer to [LT-155, "Wiring Diagram — ROOM/L —"](#).

OK or NG


OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check voltage between BCM harness connector and ground.

Terminal		Ignition switch position			
(+) (–)					
BCM Connector	Terminal	OFF	ACC	ON	
M57	24	Approx. 0V	Approx. 0V	Battery voltage	
M59	74	Battery voltage	Battery voltage	Battery voltage	
	79	Battery voltage	Battery voltage	Battery voltage	



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

BCM Connector	Terminal	Ground	Continuity
M57	2	Ground	Yes
M59	70		

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



INTERIOR ROOM LAMP

CONSULT-II Functions (BCM)

BKS001GV

- CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnosis part	Diagnosis mode	Description
INT LAMP	DATA MONITOR	Displays BCM input data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.
BCM	SELFDIAG RESULTS	BCM performs self-diagnosis of CAN communication.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

CONSULT-II INSPECTION PROCEDURE

Refer to [GI-36, "CONSULT-II Start Procedure"](#).

CONSULT-II Application Items DATA MONITOR

BKS001KV

Monitor item "UNIT"	Display content
IGN ON SW [ON/OFF]	Displays status (Ignition switch ON: ON/Others OFF, ACC: OFF) as judged from the ignition switch signal.
PUSH SW (*1) [ON/OFF]	Displays status (Ignition knob is pushed: ON/ released: OFF) as judged from the ignition knob switch signal.
KEY IN SW (*2) [ON/OFF]	Displays status (Key inserted: ON/Key removed: OFF) as judged from the key switch signal.
DOOR SW-DR [ON/OFF]	Displays status (Door open: ON/door closed: OFF) as judged from the front door switch RH signal.
DOOR SW-AS [ON/OFF]	Displays status (Door open: ON/Door closed: OFF) as judged from the front door switch LH signal.
DOOR SW-RR [ON/OFF]	Displays status (Door open: ON/door closed: OFF) as judged from the rear door switch RH signal.
DOOR SW-RL [ON/OFF]	Displays status (Door open: ON/Door closed: OFF) as judged from the rear door switch LH signal.
BACK DOOR SW [ON/OFF]	Displays status (Door open: ON/Door closed: OFF) as judged from the back door switch signal.
CDL LOCK SW [ON/OFF]	Displays status (Locked: ON/Others: OFF) as judged from lock signal.
CDL UNLOCK SW [ON/OFF]	Displays status (Unlocked: ON/Others: OFF) as judged from unlock signal.
KEYLESS LOCK (*2) [ON/OFF]	Displays status (Locked: ON/Others: OFF) as judged from lock signal. (Locked by Multi-Remote control system)
KEYLESS UNLOCK(*2) [ON/OFF]	Displays status (Unlocked: ON/Others: OFF) as judged from unlock signal. (Unlocked by Multi-Remote control system)
I-KEY LOCK (*1) [ON/OFF]	Displays status (Locked: ON/Others: OFF) as judged from lock signal. (Locked by Intelligent Key system)
I-KEY UNLOCK (*1) [ON/OFF]	Displays status (Unlocked: ON/Others: OFF) as judged from unlock signal. (Unlocked by Intelligent Key system)
I-KEY ALL UNL (*1) [ON/OFF]	Displays status (Unlocked: ON/Others: OFF) as judged from unlock signal. (Unlocked by Intelligent Key system)

*1: Displayed for models with Intelligent Key system.

*2: Displayed for models without Intelligent Key system.

ACTIVE TEST

Test item	Description
INT LAMP	Interior room lamp can be operated by any ON-OFF operations.

INTERIOR ROOM LAMP

Map Lamp Control Does Not Operate

BKS001GW

1. CHECK EACH SWITCH

1. Select "BCM" on CONSULT-II. Select "INT LAMP" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR" on "SELECT DIAG MODE" screen. Make sure switches listed in display item list turn ON-OFF linked with switch operation.

OK or NG

OK >> GO TO 2.

NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	OFF
DOOR SW-DR	ON
DOOR SW-AS	OFF
DOOR SW-RR	OFF
DOOR SW-RL	OFF
LOCK STATUS	ON
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIB0263E

2. ACTIVE TEST

1. Select "BCM" on CONSULT-II. Select "INT LAMP" on "SELECT TEST ITEM" screen.
2. Select "ACTIVE TEST" on "SELECT DIAG MODE" screen. Select "INT LAMP" on "SELECT TEST ITEM" screen.
3. When map lamp switch is in DOOR position, make sure map lamp operates.

Map lamp should operate.

OK or NG

OK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

NG >> GO TO 3.

ACTIVE TEST	
INT LAMP	ON
OFF	
MODE	BACK
LIGHT	COPY

PKIA6881E

3. CHECK MAP LAMP INPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect map lamp connector.
3. Check voltage between map lamp harness connector R3 terminal 4 and ground.


4 - Ground

: Battery voltage.

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.



INTERIOR ROOM LAMP

4. CHECK MAP LAMP INPUT CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector (A) terminal and map lamp harness connector (B).


A		B		Continuity
Connector	Terminal	Connector	Terminal	
M59	73	R3	4	Yes

3. Check continuity between BCM harness connector (A) and ground.

A		Ground	Continuity
Connector	Terminal		
M59	73		No

OK or NG

- OK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#) .
 NG >> Repair harness or connector.




5. CHECK MAP LAMP

1. Check continuity between map lamp terminals.

Terminal		Condition	Continuity
Map lamp			
2	4	Map lamp switch is DOOR	Yes
		Other than above	No

OK or NG

- OK >> GO TO 6.
 NG >> Replace map lamp or check bulb.



6. CHECK CIRCUIT BETWEEN MAP LAMP AND BCM

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector (A) and map lamp harness connector (B).


A		B		Continuity
Connector	Terminal	Connector	Terminal	
M57	21	R3	2	Yes

3. Check continuity between BCM harness connector (A) and ground.

A		Ground	Continuity
Connector	Terminal		
M57	21		No

OK or NG

- OK >> Replace BCM if map lamp does not work after setting the connector again. Refer to [BCS-17, "Removal and Installation of BCM"](#) .
 NG >> Repair harness or connector.



INTERIOR ROOM LAMP

Personal Lamp Control Does Not Operate (Models With Personal Lamp)

BKS0026H

1. CHECK EACH SWITCH

1. Select "BCM" on CONSULT-II. Select "INT LAMP" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR" on "SELECT DIAG MODE" screen. Make sure switches listed in display item list turn ON-OFF linked with switch operation.

OK or NG

OK >> GO TO 2.

NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	OFF
DOOR SW-DR	ON
DOOR SW-AS	OFF
DOOR SW-RR	OFF
DOOR SW-RL	OFF
LOCK STATUS	ON
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

PKIB0263E

2. ACTIVE TEST

1. Select "BCM" on CONSULT-II. Select "INT LAMP" on "SELECT TEST ITEM" screen.
2. Select "ACTIVE TEST" on "SELECT DIAG MODE" screen. Select "INT LAMP" on "SELECT TEST ITEM" screen.
3. When personal lamp switch is in DOOR position, make sure personal lamp operates.

Personal lamp should operate.

OK or NG

OK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

NG >> GO TO 3.

ACTIVE TEST	
INT LAMP	ON
OFF	
MODE	BACK
LIGHT	COPY

PKIA6881E

3. CHECK PERSONAL LAMP INPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect personal lamp connector.
3. Check voltage between personal lamp harness connector R4 terminal 4 and ground.


4 - Ground

: Battery voltage.

OK or NG

OK >> GO TO 5.

NG >> GO TO 4.



INTERIOR ROOM LAMP

4. CHECK PERSONAL LAMP INPUT CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector (A) terminal and personal lamp harness connector (B).


A		B		Continuity
Connector	Terminal	Connector	Terminal	
M59	73	R4	4	Yes

3. Check continuity between BCM harness connector (A) and ground.

A		Ground	Continuity
Connector	Terminal		
M59	73		No

OK or NG

- OK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#) .
 NG >> Repair harness or connector.




5. CHECK PERSONAL LAMP

1. Check continuity between personal lamp terminals.

Terminal		Condition	Continuity
Personal lamp			
2	4	Personal lamp switch is DOOR	Yes
		Other than above	No

OK or NG

- OK >> GO TO 6.
 NG >> Replace personal lamp or check bulb.



6. CHECK CIRCUIT BETWEEN PERSONAL LAMP AND BCM

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector (A) and personal lamp harness connector (B).


A		B		Continuity
Connector	Terminal	Connector	Terminal	
M57	21	R4	2	Yes

3. Check continuity between BCM harness connector (A) and ground.

A		Ground	Continuity
Connector	Terminal		
M57	21		No

OK or NG

- OK >> Replace BCM if personal lamp does not work after setting the connector again. Refer to [BCS-17, "Removal and Installation of BCM"](#) .
 NG >> Repair harness or connector.



INTERIOR ROOM LAMP


Bulb Replacement MAP LAMP, PERSONAL LAMP

BKS001GX

1. Remove lamp lens. Refer to [LT-171, "MAP LAMP, PERSONAL LAMP"](#) .
2. Remove bulb.

Map lamp : 12V - 5W


Personal lamp : 12V - 5W



LUGGAGE LOOM LAMP

1. Remove luggage room lamp lens. Refer to [LT-172, "LUGGAGE ROOM LAMP"](#) .
2. Remove bulb.

Luggage room lamp : 12V - 10W




Removal and Installation MAP LAMP, PERSONAL LAMP


BKS001GY

Removal

1. Insert a screwdriver A or the like wrapped in a cloth into the lens notch and remove lamp lens (1).



2. Pull the lamp (1) out forward while shifting the tabs with a screwdriver A or similar tool.
3. Disconnect lamp connector.



Installation


Installation is the reverse order of removal.

INTERIOR ROOM LAMP

LUGGAGE ROOM LAMP

Removal

1. Pull the luggage room lamp.
2. Disconnect luggage room lamp connector.



Installation

Installation is the reverse order of removal.

ILLUMINATION

PFP:27545

System Description

BKS001GZ

The control of the illumination lamps operation is dependent upon the position of the lighting switch. When the lighting switch is placed in the 1ST or 2ND position (or if the auto light system is activated) BCM (body control module) receives input signal requesting the illumination lamps to illuminate. This input signal is communicated to IPDM E/R (intelligent power distribution module engine room) across CAN communication lines. CPU (central processing unit) located in the IPDM E/R controls the tail lamp relay coil. This relay, when energized, directs power to the illumination lamps, which then illuminate.

Power is supplied at all times

- to ignition relay, located in IPDM E/R and
- to tail lamp relay, located in IPDM E/R, from battery directly,
- through 20A fuse (No. 61, located in IPDM E/R),
- through 20A fuse (No. 62, located in IPDM E/R),
- through 40A fusible link (letter J, located in fuse, fusible link and relay box)
- to BCM terminals 74 and 79
- to power window main switch (illumination) terminal 5 [with front power window (LHD models)], 6 [with front power window (RHD models)] or 19 (with front & rear power window),
- through 10A fuse [No. 9, located in fuse block (J/B)]
- to BCM terminal 72,
- through 10A fuse [No. 7, located in fuse block (J/B)]
- to combination meter terminal 27.

With the ignition switch in the ON or START position, power is supplied

- to ignition relay, located in IPDM E/R,
- through 10A fuse [No. 5, located in fuse block (J/B)]
- to BCM terminal 24 and
- through 10A fuse [No. 4, located in fuse block (J/B)]
- to combination meter terminal 28.

Ground is supplied

- to BCM terminals 2 and 70
- to combination meter terminals 21, 22 and 23
- to power window main switch (illumination) terminal 12 (with front power window) or 17 (with front & rear power window)
- through grounds M21 and M66,
- to IPDM E/R terminals 3 and 54
- through grounds E45 (CR and HR engine models), E28 and E44.

ILLUMINATION OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST or 2ND position (or if the auto light system is activated), BCM receives input signal requesting the illumination lamps to illuminate. This input signal is communicated to IPDM E/R across CAN communication lines. CPU located in the IPDM E/R controls the tail lamp relay coil, which, when energized, directs power

- through 10A fuse (No. 46, located in IPDM E/R),
- through IPDM E/R terminal 15
- to door lock/unlock switch (illumination) terminal 4
- to heated seat switch RH and LH (illumination) terminal 5 (with heated seat)
- through 10A fuse (No. 45, located in IPDM E/R),
- through IPDM E/R terminal 16
- to audio unit (illumination) terminal 36 (with audio)
- to heater control panel (illumination) terminal 5 (without auto A/C)

A

B

C

D

E

F

G

H

I

J

LT

L

M

ILLUMINATION

- to A/C auto amplifier (illumination) terminal 16 (with auto A/C)
- to mirror control switch (illumination) terminal 10 (with retract)
- to hazard switch (illumination) terminal 3
- to power socket for cigarette lighter (illumination) terminal 3
- to headlamp aiming switch (illumination) terminal 3
- to A/T device (illumination) terminal 3 (with A/T)
- to ESP OFF switch (illumination) terminal 3 (with ESP)
- to headlamp washer switch (illumination) terminal 3 (with headlamp washer).

Ground is supplied

- to door lock/unlock switch (illumination) terminal 3
- to audio unit (illumination) terminal 4 (with audio)
- to heater control panel (illumination) terminal 6 (without auto A/C)
- to A/C auto amplifier (illumination) terminal 5 (with auto A/C)
- to mirror control switch (illumination) terminal 3 (with retract)
- to hazard switch (illumination) terminal 4
- to power socket for cigarette lighter (illumination) terminal 2
- to headlamp aiming switch (illumination) terminal 4
- to A/T device (illumination) terminal 4 (with AT)
- to ESP OFF switch (illumination) terminal 4 (with ESP)
- to headlamp washer switch (illumination) terminal 4 (with headlamp washer)
- through grounds M21 and M66,
- to heated seat switch RH and LH (illumination) terminal 6 (with heated seat)
- through grounds B13, B28, B38 and B48

With power and ground supplied, illumination lamps illuminate.

EXTERIOR LAMP BATTERY SAVER CONTROL

Refer to [LT-9, "EXTERIOR LAMP BATTERY SAVER CONTROL"](#).

CAN Communication System Description

BKS001H0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit


BKS001H1

Refer to [LAN-27, "CAN Communication Unit"](#).

ILLUMINATION

Schematic

BKS001H2




MKWA4370E

ILLUMINATION

Wiring Diagram — ILL —

BKS001H3

LT-ILL-01



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

(M27) W

20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

(M57) W

65	66	67	68	69	70	71	72	73
74	75	76	77	78	79			

(M59) B

H.S.

REFER TO THE FOLLOWING.

(M1) - SUPER MULTIPLE


JUNCTION (SMJ)

(M7) - FUSE BLOCK -

JUNCTION BOX (J/B)




A
B
C
D
E
F
G
H
I
J
K
L
M

LT





ILLUMINATION

LT-ILL-03







MKWA4373E

A
B
C
D
E
F
G
H
I
J
T
L
M



ILLUMINATION

LT-ILL-05




MKWA4375E

ILLUMINATION

LT-ILL-06

A
B
C
D
E
F
G
H
I
J
LT
L
M



10	2		9	8
6	1	4	3	7

M15
W

4	3	1	2
---	---	---	---

M17
W

3
B

M48

2	
1	

M49
B

1		6
2	3	4
5		

M52
W




4	2	1	3
---	---	---	---

M63
W

MKWA4376E

ILLUMINATION

LT-ILL-07



MKWA4377E

BULB SPECIFICATIONS

BULB SPECIFICATIONS

PFP:26297

Headlamp

BKS001H5

Item	Wattage (W)
High/Low (Halogen type)	60/55 (H4)

Exterior Lamp

BKS001H6

Item	Wattage (W)
Front combination lamp	Turn signal lamp
	21 (amber)
Rear combination lamp	Parking lamp
	5
	Stop/Tail lamp
	21/5
	Turn signal lamp
	16 (amber)
	Back-up lamp
	16
Front fog lamp	35 (H8)
Side turn signal lamp	5
Rear fog lamp	21
License plate lamp	5
High-mounted stop lamp	16

Interior Lamp/Illumination

BKS001H7

Item	Wattage (W)
Map lamp	5
Personal lamp	5
Luggage room lamp	10

A

B

C

D

E

F

G

H

I

J

LT

L

M

BULB SPECIFICATIONS
