

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

PRECAUTIONS	3	READ CONFIGURATION PROCEDURE	25
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	WRITE CONFIGURATION PROCEDURE	27
Maintenance Information	3	Schematic	31
RHD MODELS	3	IPDM E/R Terminal Arrangement	32
LHD MODELS	3	Inspection With CONSULT-II (Self-Diagnosis)	33
POWER SUPPLY ROUTING CIRCUIT	4	IPDM E/R Terminal Inspection	34
Schematic	4	Check IPDM E/R Power Supply and Ground Circuit..	34
Wiring Diagram — POWER —	5	Diagnosis of IPDM E/R Integrated Relay	36
BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION	5	Removal and Installation of IPDM E/R	37
ACCESSIONARY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"	11	REMOVAL	37
IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"	12	INSTALLATION	37
Fuse	17	GROUND	38
Fusible Link	17	Ground Distribution	38
Circuit Breaker	17	MAIN HARNESS	38
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	18	ENGINE ROOM HARNESS	41
System Description	18	ENGINE CONTROL HARNESS/CR AND HR MODELS	45
SYSTEMS CONTROLLED BY IPDM E/R	18	BODY HARNESS	46
CAN COMMUNICATION LINE CONTROL	18	HARNESS	48
IPDM E/R STATUS CONTROL	18	Harness Layout	48
CAN Communication System Description	19	HOW TO READ HARNESS LAYOUT	48
CAN Communication Unit	19	HARNESS OUTLINE/CR AND HR ENGINE MODELS	49
Function of Detecting Ignition Relay Malfunction	19	HARNESS OUTLINE/K9K ENGINE MODELS	50
CONSULT-II Function (IPDM E/R)	20	MAIN HARNESS/LHD MODELS	51
CONSULT-II BASIC OPERATION	20	MAIN HARNESS/RHD MODELS	53
SELF-DIAG RESULTS	20	ENGINE ROOM HARNESS/CR ENGINE MODELS	55
DATA MONITOR	20	ENGINE ROOM HARNESS/HR ENGINE MODELS	57
CAN DIAG SUPPORT MNTR	21	ENGINE ROOM HARNESS/K9K ENGINE MODELS	59
ACTIVE TEST	21	ENGINE CONTROL HARNESS/CR ENGINE MODELS	61
Auto Active Test	22	ENGINE CONTROL HARNESS/HR ENGINE MODELS	63
DESCRIPTION	22	ENGINE CONTROL HARNESS/K9K ENGINE MODELS	65
OPERATION PROCEDURE	22	BODY HARNESS (RH SIDE)	67
INSPECTION IN AUTO ACTIVE TEST MODE...	23	BODY HARNESS (LH SIDE)	69
Configuration	25		
DESCRIPTION	25		

ROOM LAMP HARNESS	71	HARNESS CONNECTOR	88
FRONT DOOR HARNESS LH SIDE/LHD MOD- ELS	72	Description	88
FRONT DOOR HARNESS LH SIDE/RHD MOD- ELS	73	HARNESS CONNECTOR (TAB-LOCKING TYPE)	88
FRONT DOOR HARNESS RH SIDE/LHD MOD- ELS	74	HARNESS CONNECTOR (SLIDE-LOCKING TYPE)	89
FRONT DOOR HARNESS RH SIDE/RHD MOD- ELS	75	ELECTRICAL UNITS	90
REAR DOOR HARNESS LH SIDE	76	Terminal Arrangement	90
REAR DOOR HARNESS RH SIDE	77	SMJ (SUPER MULTIPLE JUNCTION)	92
BACK DOOR HARNESS	78	Terminal Arrangement	92
Wiring Diagram Codes (Cell Codes)	79	STANDARDIZED RELAY	93
ELECTRICAL UNITS LOCATION	82	Description	93
Electrical Units Location	82	NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS	93
ENGINE COMPARTMENT	82	TYPE OF STANDARDIZED RELAYS	93
PASSENGER COMPARTMENT/LHD MODELS..	84	FUSE BLOCK	95
PASSENGER COMPARTMENT/RHD MODELS..	86	Terminal Arrangement	95
		FUSE, FUSIBLE LINK AND RELAY BOX	96
		Terminal Arrangement	96

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

BKS00268

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Maintenance Information

BKS00269

If any of following part is replaced, always replace with new* one.

If it's not (or fail to do so), the electrical system may not be operated properly.

*: New one means a virgin control unit that has never been energized on-board.

RHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM
- IPDM E/R
- Combination meter
- EPS control unit

LHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM

A

B

C

D

E

F

G

H

I

J

PG

L

M


POWER SUPPLY ROUTING CIRCUIT

POWER SUPPLY ROUTING CIRCUIT

Schematic

PFP:24110

BKS00251






POWER SUPPLY ROUTING CIRCUIT

Wiring Diagram — POWER — BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION

BKS0025J




PG-POWER-01



MKWA4393E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-02



MKWA4394E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-03


: CR AND HR ENGINE MODELS

: CR ENGINE MODELS

: K9K ENGINE MODELS

*1 P :

BR :




MKWA4395E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-04

■ : DATA LINE




MKWA4396E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-05

CH : CR AND HR ENGINE MODELS

A
B
C
D
E
F
G
H
I
J
PG
L
M





MKWA4397E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-06

KA : K9K ENGINE MODELS, WITH A/C FOR CR AND HR ENGINE MODELS




MKWA4398E

POWER SUPPLY ROUTING CIRCUIT



ACCESSORY POWER SUPPLY — IGNITION SW. IN “ACC” OR “ON”

PG-POWER-07



FUSE BLOCK
(J/B)
(M7) , (M12)


REFER TO THE FOLLOWING.
(M1) - SUPER MULTIPLE
JUNCTION (SMJ)




POWER SUPPLY ROUTING CIRCUIT

IGNITION POWER SUPPLY — IGNITION SW. IN “ON” AND/OR “START”

PG-POWER-08






REFER TO THE FOLLOWING.
 (M1) - SUPER MULTIPLE
 JUNCTION (SMJ)



POWER SUPPLY ROUTING CIRCUIT

PG-POWER-09





REFER TO THE FOLLOWING.

M1 - SUPER MULTIPLE JUNCTION (SMJ)

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-10




MKWA4402E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-11


A : WITH A/T
CH : CR AND HR ENGINE MODELS



MKWA4403E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-12




MKWA4404E

POWER SUPPLY ROUTING CIRCUIT

Fuse

BKS0025K

- If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.



CEL083


Fusible Link

BKS0025L

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of malfunction.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.




CKIT0163E

Circuit Breaker

BKS0025M

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



SEL109W

A
B
C
D
E
F
G
H
I
J
PG
L
M

System Description

BKS0025N

- IPDM E/R (Intelligent Power Distribution Module Engine Room) integrates the relay box and fuse block which were originally placed in engine compartment. It controls integrated relay via IPDM E/R control circuit.
- IPDM E/R-integrated control circuit performs ON-OFF operation of relay, CAN communication control and oil pressure switch signal reception, etc.
- It controls operation of each electrical part via ECM, BCM and CAN communication lines.

CAUTION:

None of the IPDM E/R-integrated relays can be removed.

SYSTEMS CONTROLLED BY IPDM E/R

IPDM E/R receives a request signal from each Control unit with CAN communication. It controls each system.

Control system	Transmit control unit	Control part
Lamp control	BCM	<ul style="list-style-type: none"> Head lamps (HI,LO) Tail lamps, parking and license plate lamps Front fog lamps
Wiper control	BCM	<ul style="list-style-type: none"> Front wipers
Headlamp washer control	BCM	<ul style="list-style-type: none"> Headlamp washer
Rear window defogger control	BCM	<ul style="list-style-type: none"> Rear window defogger
A/C compressor control	ECM	<ul style="list-style-type: none"> A/C compressor
Cooling fan control	ECM	<ul style="list-style-type: none"> Cooling fan

CAN COMMUNICATION LINE CONTROL

With CAN communication, by connecting each control unit using two communication lines (CAN L-line, CAN H-line), it is possible to transmit maximum amount of information with minimum wiring. Each control unit can transmit and receive data, and reads necessary information only.

Fail-safe Control

- When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.
- Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled system	Fail-safe mode
Headlamps	<ul style="list-style-type: none"> With the ignition switch ON, the headlamp low is ON. With the ignition switch OFF, the headlamp low is OFF.
Tail, parking and license plate lamps	<ul style="list-style-type: none"> With the ignition switch ON, the tail lamp is ON. With the ignition switch OFF, the tail lamp is OFF.
Cooling fan	<ul style="list-style-type: none"> With the ignition switch ON, the cooling fan HI operates. With the ignition switch OFF, the cooling fan stops.
Front wiper	Until the ignition switch is turned off, the front wiper LO and HI remains in the same status it was in just before fail-safe control was initiated.
Rear window defogger	Rear window defogger OFF
Front fog lamps	Front fog lamp OFF
Headlamp washer	Headlamp washer is OFF
A/C compressor	A/C compressor OFF

IPDM E/R STATUS CONTROL

In order to save power, IPDM E/R switches status by itself based on each operating condition.

- CAN communication status
 - CAN communication is normally performed with other control units.
 - Individual unit control by IPDM E/R is normally performed.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

- A status is changed into sleep transient status when receiving a sleep request signal from BCM while all the systems controlled by IPDM E/R are under suspension.

2. Sleep transient status

- Process to stop CAN communication is activated.
- All systems controlled by IPDM E/R are stopped, when 3 seconds have elapsed after CAN communication with other control units is stopped, mode switches to sleep status.

3. Sleep status

- IPDM E/R operates in low power mode.
- CAN communication is stopped.
- When a change in CAN communication line is detected, mode switches to CAN communication status.
- When a change in ignition switch signal is detected, mode switches to CAN communication status.

CAN Communication System Description

BKS00250

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

BKS0025P

Refer to [LAN-27, "CAN Communication Unit"](#) .

Function of Detecting Ignition Relay Malfunction

BKS0027F

- When integrated ignition relay cannot be turned OFF and ignition switch is turned OFF, IPDM E/R turns ON tail and parking lamps for 10 minutes. The lamps indicate ignition relay malfunction.
- When a state of ignition relay having built-in does not agree with a state of Ignition switch signal input by a CAN communication from BCM, IPDM E/R lets tail lamp relay operate.

Ignition switch signal	Ignition relay status	Tail lamp relay
ON	ON	—
OFF	OFF	—
ON	OFF	—
OFF	ON	ON (10 minutes)

NOTE:

When the ignition switch is turned ON, the tail lamps are OFF.

A

B

C

D

E

F

G

H

I

J

PG

L

M

CONSULT-II Function (IPDM E/R)

BKS0025R

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	The IPDM E/R performs diagnosis of CAN communication and self-diagnosis.
DATA MONITOR	The input/output data of the IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	The IPDM E/R sends a drive signal to electronic components to check their operation.
CONFIGURATION	Performs IPDM E/R configuration read/write functions.

CONSULT-II BASIC OPERATION

Refer to [GI-36, "CONSULT-II Start Procedure"](#).

SELF-DIAG RESULTS

Operation Procedure

1. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.
2. Check display content in self-diagnostic results.

Display Item List

Display Items	CONSULT-II display code	Malfunction detecting condition	TIME		Possible causes
			CRNT	PAST	
NO DTC IS DETECTED.FUR- THER TESTING MAY BE REQUIRED.	—	-	-	-	-
CAN COMM CIRC	U1000	<ul style="list-style-type: none"> • If CAN communication reception/transmission data has a malfunction, or if any of the control units malfunction, data reception/transmission cannot be confirmed. • When the data in CAN communication is not received before the specified time 	×	×	Any of or the items below have errors. <ul style="list-style-type: none"> • TRANSMIT DIAG • ECM • BCM
IGN RELAY ON	B2098	Where the ignition switch is not ON position, the ignition relay in the IPDM E/R is ON.	×	×	Ignition relay (integrated in IPDM E/R)
IGN RELAY OFF	B2099	Where the ignition switch is ON position, the ignition relay in the IPDM E/R is OFF.	×	×	Ignition relay (integrated in IPDM E/R)
EEPROM	B2100	Malfunction is detected with the integrated EEPROM memory diagnosis.	×	×	IPDM E/R

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

DATA MONITOR

Operation Procedure

1. Touch "DATA MONITOR" on "SELECT MONITOR ITEM" screen.
2. Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Select any item for monitoring.

3. Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

4. Touch "START".
5. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Motor fan request	MOTOR FAN REQ	1/2/3/4	×	×	×	Signal status input from ECM
A/C Compressor request	AC COMP REQ	ON/OFF	×	×	×	Signal status input from ECM
Tail & clearance request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp LO request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp HI request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog lamp request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp washer request	HL WASHER REQ	ON/OFF	×		×	This item cannot be monitored. (No change of display)
Front wiper request	FR WIP REQ	STOP/1LOW/LOW/HI	×	×	×	Signal status input from BCM
Wiper auto stop	WIP AUTO STOP	ACT P/STOP P	×	×	×	Output status of IPDM E/R
Wiper protection	WIP PROT	OFF/BLOCK	×	×	×	Control status of IPDM E/R
Starter request	ST RLY REQ*	ON/OFF	×		×	Signal status input from BCM
Ignition relay status	IGN RLY	ON/OFF	×	×	×	Ignition relay status monitored with IPDM E/R
Rear window defogger request	RR DEF REQ	ON/OFF	×	×	×	Signal status input from BCM
Rear window defogger stop request	DEF STOP REQ	ON/OFF	×		×	Input signal status
Alternator load	ALT LOAD	%	×		×	This item cannot be monitored (No change of display)
Alternator current	ALT CRNT	A	×		×	
Alternator number	ALT NO	##	×		×	
Battery voltage	BAT VOLT	V	×		×	Value measured with IPDM E/R
Engine coolant temperature	ENG COOL TEMP	°C	×		×	Signal status input from ECM
Oil pressure switch	OIL P SW	OPEN/CLOSE	×		×	Signal status input in IPDM E/R
Reverse switch	REV SW	OPEN/CLOSE	×		×	Signal status input in IPDM E/R

NOTE:

- Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.
- *: The vehicle without Intelligent Key system displays only ON without change.

CAN DIAG SUPPORT MNTR

Refer to [LAN-15, "CAN Diagnostic Support Monitor"](#) .

ACTIVE TEST

Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested.
3. Touch "START", and confirm its operation.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

4. Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp (HI, LO) output	HEAD LAMP	With a certain operation (OFF, HI ON, LO ON), the headlamp relay (Lo, Hi) can be operated.
Front fog lamp output	FRONT FOG LAMP	With a certain ON-OFF operation, the fog lamp relay can be operated.
Tail lamp output	TAIL LAMP	With a certain ON-OFF operation, the tail lamp relay can be operated.
Rear window defogger operation	REAR DEFOGGER	With a certain ON-OFF operation, the rear window defogger relay can be operated.
Front wiper (HI, LO) operation	FRONT WIPER	With a certain operation (OFF, HI ON, LO ON), the front wiper relay (Lo, Hi) can be operated.
Cooling fan operation	MOTOR FAN	With a certain operation (1, 2, 3, 4), the cooling fan can be operated.
Headlamp washer output	HEAD LAMP WASHER	With a certain ON-OFF operation, the headlamp washer can be operated.

Auto Active Test

DESCRIPTION

BKS0025S

In auto active test mode, operation inspection can be performed when IPDM E/R sends a drive signal to the following systems:

- Rear window defogger
- Front wiper (LO, HI)
- Tail lamps, parking lamps, license plate lamps
- Front fog lamps
- Headlamps (LO, HI)
- Headlamp washer
- A/C compressor (magnetic clutch)
- Cooling fan

OPERATION PROCEDURE

1. Close hood and front door (passenger side), and then lift wiper arms away from windshield (to prevent glass damage by wiper operation).

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn ignition switch OFF.
3. Turn ignition switch ON, and within 20 seconds, press driver's door switch 10 times (close other doors). Then turn ignition switch OFF.
4. Turn ignition switch ON within 10 seconds after ignition switch OFF.
5. When auto active test mode is actuated, horn chirps once. Oil pressure warning lamp starts blinking.
6. After a series of operations is repeated three times, auto active test is completed.

NOTE:


When auto active test mode has to be cancelled halfway, turn ignition switch OFF.

CAUTION:

Be sure to inspect [BL-46, "Check Door Switch"](#) when the auto active test cannot be performed.

INSPECTION IN AUTO ACTIVE TEST MODE

When auto active test mode is actuated, the following nine steps are repeated three times.



(A): Oil pressure warning lamp is blinking when the auto active test operating.

Operation steps

Step	Test item	Operation time/ frequency
1	Rear window defogger	10 seconds
2	Front wiper	LO 5 seconds → HI 5 seconds
3	Tail lamps, parking lamps, license plate lamps	10 seconds
4	Front fog lamps	10 seconds
5	Headlamp (LO)	10 seconds
6	Headlamp (HI)	LO←→HI repeats every 2 seconds, 5 times
7	Headlamp washer	Left 1 seconds → Right 1 second
8	A/C compressor (magnetic clutch)	ON←→OFF repeat every 2 seconds, 5 times
9	Cooling fan	LO 5 seconds → HI 5 seconds (Petrol engine models with air conditioner and diesel engine models) LO 10 seconds (Petrol engine models without air conditioner)

Concept of Auto Active Test

- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any of systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Diagnosis Chart in Auto Active Test Mode

Symptom	Inspection contents	Possible cause
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES ● BCM signal input circuit malfunction
		NO ● Harness/connector malfunction between IPDM E/R and rear window defogger ● Open circuit of rear window defogger ● IPDM E/R (integrated relay) malfunction (Rear window defogger relay)
Front wiper does not illuminate.	Perform auto active test. Does rear window defogger operate?	YES ● BCM signal input circuit malfunction
		NO ● Wiper motor malfunction ● Front wiper motor ground.
Either of parking lamp, license plate lamp and tail lamp does not illuminate.	Perform auto active test. Does parking lamp, license plate lamp and tail lamp illuminate?	YES ● BCM signal input circuit malfunction
		NO ● Bulb ● Harness/connector malfunction between IPDM E/R and parking, license plate or tail lamp. ● IPDM E/R (integrated relay) malfunction
Front fog lamp does not illuminate.	Perform auto active test. Does the front fog lamp illuminate?	YES ● BCM signal input circuit malfunction
		NO ● Bulb ● Harness/connector malfunction between IPDM E/R and front fog lamp ● IPDM E/R (integrated relay) malfunction
Headlamp (Hi, Lo) does not illuminate.	Perform auto active test. Does headlamp illuminate?	YES ● BCM signal input circuit malfunction
		NO ● Bulb ● Headlamp ground system malfunction ● Harness/connector malfunction between IPDM E/R and headlamps ● IPDM E/R (integrated relay) malfunction (headlamp relay)
Headlamp washer does not operate.	Perform auto active test. Does the headlamp washer operate?	YES ● BCM signal input circuit malfunction
		NO ● Harness/connector malfunction between IPDM E/R and headlamp washer ● Headlamp washer relay is malfunction
Cooling fan does not operate.	Perform auto active test. Does magnetic clutch operate?	YES ● CAN communication signal malfunction between ECM and IPDM E/R* ● ECM signal input circuit malfunction
		NO ● Cooling fan motor malfunction ● Harness/connector malfunction between cooling fan motor and IPDM E/R ● IPDM E/R (integrated relay) malfunction
A/C compressor is inoperative.	Perform auto active test. Does magnetic clutch operate?	YES ● CAN communication signal malfunction between BCM and ECM* ● CAN communication signal malfunction between ECM and IPDM E/R* ● BCM signal input circuit malfunction ● ECM signal input circuit malfunction
		NO ● Magnetic clutch inoperative ● Harness/connector malfunction between IPDM E/R and magnetic clutch ● IPDM E/R (integrated relay) malfunction
Oil pressure warning lamp does not operate.	Perform auto active test. Does oil pressure warning lamp blink?	YES ● Harness/connector malfunction between IPDM E/R and oil pressure switch ● Oil pressure switch malfunction ● IPDM E/R malfunction
		NO ● CAN communication signal malfunction between IPDM E/R and combination meter * ● Combination meter malfunction

*: Perform IPDM E/R self-diagnosis with CONSULT-II. Refer to [PG-33, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#).

Configuration DESCRIPTION

BKS0026I

There are two CONFIGURATION functions, as follows.

READ CONFIGURATION is a function for confirming the vehicle configuration written on IPDM E/R.

WRITE CONFIGURATION is a function for writing a vehicle configuration to IPDM E/R.

CAUTION:


- When replacing IPDM E/R, completely perform WRITE CONFIGURATION with CONSULT-II.
- Orderly complete the procedure of WRITE CONFIGURATION.
- If you set incorrect WRITE CONFIGURATION, vehicle operation will not be correct.
- Configuration is different by each vehicle model, confirm configuration in each case.

READ CONFIGURATION PROCEDURE


CAUTION:

If CONSULT-II is used with no connection of CONSULT CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

- With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn the ignition switch ON.




- Touch "START(NISSAN BASED VHCL)".




- Touch "IPDM E/R" on "SELECT SYSTEM" screen.

If "IPDM E/R" is not indicated, go to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

4. Touch “CONFIGURATION” on “SELECT DIAG MODE” screen.




MKIB2361E

5. Touch “K12”, and “OK” on “VEHICLE SELECT” screen.
For canceling, touch “CANCEL” on “VEHICLE SELECT” screen.


NOTE:

Confirm vehicle model on IDENTIFICATION PLATE, refer to GI section.



MKIB2358E


6. Touch “READ CONFIGURATION” on “SELECT CONFIG ITEM” screen.



MKIB2362E

7. Configuration of current IPDM E/R are printed out automatically.
Configuration of brand-new IPDM E/R before executing “WRITE CONFIGURATION” is as follows.

MANUAL SET ITEM	
Items	Setting Value
ALT TYPE	TYPE 1
AUTO SET ITEM	
Items	Setting Value
STARTER MODE	MODE 1



MKIB2363E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

8. Touch “BACK” on “READ CONFIGURATION”screen.


READ CONFIGURATION	
ITEM	SET VAL
ALT TYPE	TYPE 1
MODE	BACK
LIGHT	COPY

WRITE CONFIGURATION PROCEDURE

CAUTION:

If CONSULT-II is used with no connection of CONSULT CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn the ignition switch ON.



2. Touch “START(NISSAN BASED VHCL)”. ---


The diagram illustrates the CONSULT-II menu structure. It is a vertical stack of rectangular boxes, each representing a menu level. The top box is labeled 'CONSULT-II'. Below it is a horizontal line, followed by a box labeled 'ENGINE'. Another horizontal line follows, then a box labeled 'START (NISSAN BASED VHCL)'. Another horizontal line follows, then a box labeled 'START (X-BADGE VHCL)'. Another horizontal line follows, then a box labeled 'SUB MODE'. The bottom box is divided into three vertical columns: an empty column on the left, a column labeled 'LIGHT' in the middle, and a column labeled 'COPY' on the right. The entire structure is enclosed in a large rectangular frame.

3. Touch “IPDM E/R” on “SELECT SYSTEM” screen.

If "IPDM E/R" is not indicated, go to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


4. Touch “CONFIGURATION” on “SELECT DIAG MODE” screen.




5. Touch “K12”, and “OK” on “VEHICLE SELECT” screen.
For canceling, touch “CANCEL” on “VEHICLE SELECT” screen.

NOTE:


Confirm vehicle model on IDENTIFICATION PLATE, refer to GI section.



6. Touch “WRITE CONFIGURATION” on “SELECT CONFIG ITEM” screen.



7. Touch “YES”.
For canceling, touch “NO”.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


8. Touch “TYPE 1”, “TYPE 2” or “TYPE 3” on “WRITE CONFIGURATION”screen based on the following ITEM LIST.

< ITEM LIST >

ITEM	SET VAL	NOTE
Alternator type	TYPE 1	Petrol engine models
	TYPE 2	Diesel engine models without PTC heater*
	TYPE 3	Diesel engine models with PTC heater*

*: Models with PTC heater have PTC heater relays. Refer to Harness Layout, [PG-59, "ENGINE ROOM HARNESS/K9K ENGINE MODELS"](#), to confirm whether PTC heater relays are equipped or not.

WRITE CONFIGURATION	
PLEASE CHANGE THE BELOW SETTING VALUE TO CONNECTED VEHICLE CONFIGURATION, REFERRING TO S/M	
ITEM	SET VAL
ALT TYPE	TYPE 1
Page Up	Page Down
CHNG SETTING	CANCEL



MKIB0763E

For canceling, touch “CANCEL”.

9. Touch “CHNG SETTING” on “WRITE CONFIGURATION”screen.

CAUTION:

Make sure to touch “CHNG SETTING even if the indicated configuration of brand new IPDM E/R is same as the desirable configuration.

If not, configuration which is set automatically by selecting vehicle model can not be memorized.

10. Touch “OK” on “WRITE CONFIGURATION”screen.

When touched “CANCEL”, go to previous screen.

WRITE CONFIGURATION	
ARE YOU SURE TO CHANGE THE SETTING? PRESS 'OK' THEN SETTING VALUE IS CHANGED	
ITEM	SET VAL
ALT TYPE	TYPE 2
Page Up	Page Down
CHNG SETTING	CANCEL

MKIB0764E

11. Wait until the next screen during setting.

WRITE CONFIGURATION	
NOW SETTING...	
ITEM	SET VAL
ALT TYPE	TYPE 1
OK	

MKIB0765E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

12. WRITE CONFIGURATION results are printed out automatically. Check "WRITE CONFIGURATION" is correctly executed by comparing sheet automatically printed out with desirable configuration.

NISSAN CONSULT-II WRITE CONFIGURATION	
SYSTEM IPDM E/R DATE MM/DD/YYYY HH:MM:SS VEHICLE XX	
MANUAL SET ITEM	
Items	Setting Value
ALTTYPE	TYPE 1
AUTO SET ITEM	
Items	Setting Value
STARTER MODE	MODE 1

MKIB2364E

13. Touch “OK” on “WRITE CONFIGURATION”screen.
WRITE CONFIGURATION is completed.


WRITE CONFIGURATION	
PLEASE CHECK THE PRINTOUT AND PRESS 'OK' TO RETURN SYSTEM SELECTION SCREEN	
ITEM	SET VAL
ALT TYPE	TYPE 1
OK	

MKIB0767E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Schematic


BKS0025T



MKWA4405E

IPDM E/R Terminal Arrangement

BKS0025U



MKWA4445E

Inspection With CONSULT-II (Self-Diagnosis)

BKS0025W

1. CHECK SELF DIAGNOSTIC RESULT

1. Connect CONSULT-II and select "IPDM E/R" on the "SELECT SYSTEM" screen.
2. Select "SELF-DIAG RESULTS" on the "SELECT DIAG MODE" screen.
3. Check display content in self diagnostic results.

CONSULT-II display	CONSULT-II display code	TIME		Details of diagnosis result
		CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	-	-	-	No malfunction
CAN COM CIRC	U1000	×	×	Any of or several items below have errors. ● TRANSMIT ● RECEIVE (ECM) ● RECEIVE (BCM)
IGN RELAY ON	B2098	×	×	Ignition relay malfunction (integrated in IPDM E/R)
IGN RELAY OFF	B2099	×	×	Ignition relay malfunction (integrated in IPDM E/R)
EEPROM	B2100	×	×	IPDM E/R malfunction

CAUTION:

If errors of the CAN communication system and the ignition relay ON or OFF are displayed at the same time after the self-diagnostic result, replace the IPDM E/R and perform the self-diagnosis again.

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

Contents displayed

NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.>>INSPECTION END

CAN COMM CIRC>>After print-out of the monitor items, refer to [LAN-3. "Precautions When Using CONSULT-II"](#) .

IGN RELAY ON>>Replace IPDM E/R.

IGN RELAY OFF>>Replace IPDM E/R.

EEPROM>>Replace IPDM E/R.

A

B

C

D

E

F

G

H

I

J

PG

L


M

IPDM E/R Terminal Inspection


BKS00260

CAUTION:**This is performed when the IPDM E/R is checked without removing the battery.**

1. Remove the headlamp (LH). Refer to [LT-32, "Removal and Installation"](#) (Conventional type), [LT-51, "Removal and Installation"](#) (Daytime light system).
2. Remove tabs of the IPDM E/R and place the IPDM E/R with its connector facing upward. Check each terminal.



SKIA2151E



SKIA2152E

Check IPDM E/R Power Supply and Ground Circuit

BKS0025V

1. CHECK FUSE AND FUSIBLE LINK

Make sure that the following fusible links or IPDM E/R fuses are not blown.

Terminal No.	Power source	Fuse, fusible link No.
1	Battery	Letter C
2	Battery	Letter D
40	Ignition switch (ON)	5

OK or NG


OK >> GO TO 2.

NG >> Replace fuse or fusible link.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R harness connector.
2. Check voltage between IPDM E/R and ground.

Terminals		Ignition switch position		
Connector	Terminal (wire color)	(-)	OFF	ACC
E9	1 (R)	Ground	Battery voltage	Battery voltage
	2 (G)		Battery voltage	Battery voltage
E7	40 (O)		0V	0V



OK or NG

OK >> GO TO 3.
 NG >> Check harness between fuse, fusible link and IPDM E/R.

3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R harness connectors.
2. Check continuity between IPDM E/R harness connectors E11 terminal 3 (B), E12 terminal 54 (B) and ground.

3 (B) – Ground


:Continuity should exist.

54 (B) – Ground

:Continuity should exist.

OK or NG

OK >> INSPECTION END.
 NG >> Repair harness for ground circuit.



Diagnosis of IPDM E/R Integrated Relay

BKS0026P

1. CHECK SYMPTOM

Check the symptom of the malfunction relay.

What is the symptom?

No operation>>GO TO 2.

No stop>> GO TO 4.

2. CHECK RELAY TYPE

Which is the relay with error?

Front fog lamp relay, headlamp relay (Hi, Lo), tail lamp relay, front wiper relay (main, Hi/Lo), rear window defogger relay, A/C relay, starter motor relay, cooling fan relay (Hi, Lo)>>GO TO 5.

Ignition relay>> Go to [PG-33. "Inspection With CONSULT-II \(Self-Diagnosis\)"](#)

ECM relay>>Go to [EC-128, "POWER SUPPLY AND GROUND CIRCUIT"](#) (CR engine models with EURO-OBD), [EC-543, "POWER SUPPLY AND GROUND CIRCUIT"](#) (CR engine models without EURO-OBD), [EC-918, "POWER SUPPLY AND GROUND CIRCUIT"](#) (HR engine models with EURO-OBD), [EC-1337, "POWER SUPPLY AND GROUND CIRCUIT"](#) (HR engine models without EURO-OBD) or [EC-1698, "POWER SUPPLY AND GROUND CIRCUIT"](#) (K9K engine models).

Throttle motor relay>>Go to [EC-299, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (CR engine models with EURO-OBD), [EC-643, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (CR engine models without EURO-OBD), [EC-1090, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (HR engine models with EURO-OBD) or [EC-1439, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (HR engine models without EURO-OBD).

Fuel pump relay>>Go to [EC-427, "FUEL PUMP"](#) (CR engine models with EURO-OBD), [EC-750, "FUEL PUMP"](#) (CR engine models without EURO-OBD), [EC-1215, "FUEL PUMP"](#) (HR engine models with EURO-OBD) or [EC-1543, "FUEL PUMP"](#) .(HR engine models without EURO-OBD).

3. CHECK RELAY

Send an operation signal to the relay using a diagnosis tool. Check the voltage at the input and output terminals of inoperative relays according to the table below or check for continuity between input and output terminals. Refer to [PG-21, "ACTIVE TEST"](#) or [PG-22, "Auto Active Test"](#) .

Relay name	IPDM E/R terminal number		Voltage [V]	Diagnosis tool	
	Input side	Output side		CONSULT-II ACTIVE TEST	Auto ACTIVE TEST
Front fog lamp relay	1	43, 44	Battery voltage	×	×
Headlamp Hi relay		46, 47		×	×
Headlamp Lo relay		48, 50		×	×
Tail lamp relay		15, 16, 45, 49		×	×
Front wiper main relay		23		×	×
Front wiper HI/LO relay		24		×	×
A/C relay		41			×
Rear windows defogger relay	2	8	14	×	×
Cooling fan Lo relay	10	×		×	
Cooling fan Hi relay	12	×		×	

×: Applicable

OK or NG

OK >> Check the control unit that controls the inoperative relay. (system)

NG >> Replace the IPDM E/R. (malfunction of relay)

4. CHECK RELAY TYPE

Which is the relay with error?

Front fog lamp relay, headlamp relay (Hi, Lo), tail lamp relay, front wiper relay (main, Hi/Lo), rear window defogger relay, A/C relay, starter motor relay, cooling fan relay (Hi, Lo)>>GO TO 5.

Ignition relay>> Go to [PG-33, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#)

ECM relay>>Go to [EC-128, "POWER SUPPLY AND GROUND CIRCUIT"](#) (CR engine models with EURO-OBD), [EC-543, "POWER SUPPLY AND GROUND CIRCUIT"](#) (CR engine models without EURO-OBD), [EC-918, "POWER SUPPLY AND GROUND CIRCUIT"](#) (HR engine models with EURO-OBD), [EC-1337, "POWER SUPPLY AND GROUND CIRCUIT"](#) (HR engine models without EURO-OBD) or [EC-1698, "POWER SUPPLY AND GROUND CIRCUIT"](#) (K9K engine models).

Throttle motor relay>>Go to [EC-299, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (CR engine models with EURO-OBD), [EC-643, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (CR engine models without EURO-OBD), [EC-1090, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (HR engine models with EURO-OBD) or [EC-1439, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (HR engine models without EURO-OBD).

Fuel pump relay>>Go to [EC-427, "FUEL PUMP"](#) (CR engine models with EURO-OBD), [EC-750, "FUEL PUMP"](#) (CR engine models without EURO-OBD), [EC-1215, "FUEL PUMP"](#) (HR engine models with EURO-OBD) or [EC-1543, "FUEL PUMP"](#) (HR engine models without EURO-OBD).

5. CHECK INPUT SIGNAL

Check the control signal status of the relay on the IPDM E/R that receives from each control unit with the data monitor of CONSULT-II. Refer to [PG-20, "DATA MONITOR"](#).

What is the data monitor result?

Other than OFF>>Check the control unit that controls the relay (system) not deactivated.

OFF >> Replace the IPDM E/R. (error of relay ON)


Removal and Installation of IPDM E/R

BKS0025X

⇨: Vehicle front

REMOVAL

1. Lift up the IPDM E/R while pushing and opening pawls (A) or (B), and remove the IPDM E/R while pushing and opening the other side pawls.
2. Disconnect harness connector.



INSTALLATION

Installation is the reverse order of removal.

A
B
C
D
E
F
G
H
I
J

PG
L
M


GROUND

GROUND

Ground Distribution MAIN HARNESS

PFP:00011

BKS0025Y




Next page


MKWA4382E

GROUND


Preceding page



LHD models



RHD models



A
B
C
D
E
F
G
H
I
J

PG


L

M

CONNECTOR NUMBER	CONNECT TO
(M17)	Headlamp aiming switch (Terminal No. 2) • Switch
(M17)	Headlamp aiming switch (Terminal No. 4) • Illumination
(M30)	Power transistor (With auto A/C)
(M34)	Key switch and ignition knob switch (With Intelligent Key system)
(M40)	Steering angle sensor (With ESP)
(M45)	Audio unit (Terminal No. 4) (With audio)
(M49)	Power socket (For cigarette lighter)
(M52)	A/T device (Terminal No. 2) (With A/T) • Overdrive control switch
(M52)	A/T device (Terminal No. 4) (With A/T) • Illumination
(M57)	BCM (Body control module) (Terminal No. 2)
(M59)	BCM (Body control module) (Terminal No. 70)
(M60)	Intelligent Key unit (With Intelligent Key system)
(M61)	Passenger air bag cut off telltale
(M62)	Heater control panel (Without auto A/C) (Terminal No. 6) • Illumination
(M62)	Heater control panel (Without auto A/C) (Terminal No. 8) • Switch
(M62)	Heater control panel (Without auto A/C) (Terminal No. 9) • Switch
(M64)	A/C auto amp. (Terminal No. 5) (With auto A/C) • Illumination
(M64)	A/C auto amp. (Terminal No. 10) (With auto A/C)
(M69)	Front passenger air bag cutoff switch
(M77)	After market alarm unit (Option connector)
(D5)	Door mirror actuator (Driver side) (With door mirror defogger)
(D8)	Power window main switch (Front 2D models)
(D9)	Power window main switch (Front & rear 4D models)
(D12)	Door request switch (Driver side) (With Intelligent Key system)
(D25)	Door mirror actuator (Passenger side) (With door mirror defogger)
(D29)	Door request switch (Passenger side) (With Intelligent Key system)
(M5) (D2)	Driver side door harness
(M5) (D2)	Driver side door harness
(M5) (D2)	Driver side door harness
(M5) (D2)	Driver side door harness
(M70) (D22)	Passenger side door harness
(M70) (D22)	Passenger side door harness


MKWA4383E

GROUND



GROUND

ENGINE ROOM HARNESS



B
Next page

A
B
C
D
E
F
G
H
I
J

PG


L

M


GROUND

Preceding page

B



Body ground



E44

CONNECTOR NUMBER	CONNECT TO
E11	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 3)
E12	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 54)
E13	Front combination lamp LH • Turn signal
E16	Cooling fan motor
E19	Horn
E23	Front fog lamp RH
E26	Headlamp RH
E41	Side turn signal lamp LH
E47	Front combination lamp LH • Headlamp aiming motor
E54	Daytime light relay
F129	Compressor (With K9K engine models)

E48 F101

Engine control harness

C

Next page



MKWA4386E

GROUND


A
B
C
D
E
F
G
H
I
J

PG

Preceding page




CONNECTOR NUMBER	CONNECT TO
(E40)	ECM (Terminal No. 115) (With CR engine model)
(E40)	ECM (Terminal No. 116) (With CR engine model)
(F2)	ECM (Terminal No. 1) (With CR engine model)
(E107)	TCM (Transmission control module) (Terminal No. 25) (With A/T)
(E107)	TCM (Transmission control module) (Terminal No. 48) (With A/T)
(F16)	Shield wire (Manifold absolute pressure sensor) (For circuit from terminal No. 1)
(F39)	Shield wire [Electric throttle control actuator (Throttle position sensor)] (For circuit from terminal No. 1, 2, 4, 5)
(F50)	ECM (Terminal No. 10) (With HR engine model)
(F50)	ECM (Terminal No. 11) (With HR engine model)
(E40)	ECM (Terminal No. 108) (With HR engine model)




Body ground
K9K ENGINE MODELS

CONNECTOR NUMBER	CONNECT TO
(E40)	ECM (Terminal No. 25)
(E40)	ECM (Terminal No. 26)
(E40)	ECM (Terminal No. 27)
(E40)	ECM (Terminal No. 32)

GROUND



CONNECTOR NUMBER	CONNECT TO
(E32)	ABS actuator and electric unit (Control unit) (Terminal No. 1) (Without ESP)
(E32)	ABS actuator and electric unit (Control unit) (Terminal No. 4) (Without ESP)




CONNECTOR NUMBER	CONNECT TO
(E33)	ABS actuator and electric unit (Control unit) (Terminal No. 1) (With ESP)
(E33)	ABS actuator and electric unit (Control unit) (Terminal No. 4) (With ESP)



GROUND

ENGINE CONTROL HARNESS/CR AND HR ENGINE MODELS


C : CR ENGINE MODELS
H : HR ENGINE MODELS




Engine ground



CONNECTOR NUMBER	CONNECT TO
F26	Condenser
F33	Ignition coil No. 1 (With power transistor)
F34	Ignition coil No. 2 (With power transistor)
F35	Ignition coil No. 3 (With power transistor)
F36	Ignition coil No. 4 (With power transistor)




Body ground
CR ENGINE MODELS



CONNECTOR NUMBER	CONNECT TO
F31	Alternator (E)

GROUND


BODY HARNESS





D
Next page

GROUND

Preceding page



CONNECTOR NUMBER	CONNECT TO
(B33)	Fuel level sensor unit and fuel pump (CR and HR engine models) • Fuel pump
(B39)	Rear combination lamp RH • Turn signal • Tail • Stop • Back-up
(B44)	Rear combination lamp RH • Rear fog lamp
(B46)	Back door release actuator (Terminal No. 1)
(B46)	Back door release actuator (Terminal No. 3)
(D102)	Door request switch (Back door) (With Intelligent Key system)
(D103)	License plate lamp RH
(D104)	Back door switch
(D105)	License plate lamp LH
(D452)	High mounted stop lamp



A
B
C
D
E
F
G
H
I
J

PG

L

M

MKWA4391E

HARNESS

PFP:00011


Harness Layout

HOW TO READ HARNESS LAYOUT

BKS0025Z

The following Harness Layouts use a map style grid to help locate connectors on the figures:

- Main Harness
- Engine Room Harness
- Engine Control Harness
- Body Harness
- Room Lamp Harness
- Front Door Harness
- Rear Door Harness
- Back Door Harness



To Use the Grid Reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the figure, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL


Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9				
• Ground terminal etc.	—			

CKIT0108E

HARNESS

HARNESS OUTLINE/CR AND HR ENGINE MODELS




A
B
C
D
E
F
G
H
I
J

PG
L
M

MKWA4406E


HARNESS

HARNESS OUTLINE/K9K ENGINE MODELS



HARNESS

MAIN HARNESS/LHD MODELS




MKWA4408E

HARNESS

A3	M1	SMJ	: To E101	D3	M41	Y/6	: Combination switch (Spiral cable) (Air bag)
A3	M2	GR/2	: To E102	D3	M42	GR/8	: Combination switch (Spiral cable) (Steering switch)
A3	M3	B/2	: To E104	E3	M43	W/2	: In vehicle sensor (With auto A/C)
A3	M4	Y/4	: To E103	D4	M44	W/3	: Thermo control amp
A4	M5	W/12	: To D2	E2	M45	-/20	: Audio unit
A4	M6	W/16	: To D1	E2	M46	B/16	: Audio unit
C4	M7	-	: Fuse block (J/B)	D4	M47	GR/2	: Console antenna
A5	M9	GR/1	: Towbar kit	D4	M48	B/1	: Power socket illumination
A5	M10	W/6	: To B1	E4	M49	B/2	: Power socket
A5	M11	W/16	: To B2	E4	M50	-/6	: Mode door motor (With auto A/C)
C4	M12	W/1	: Fuse block (J/B)	D4	M51	-/6	: Air mix door motor (With auto A/C)
C4	M13	W/1	: Fuse block (J/B)	F5	M52	W/6	: A/T device (With A/T)
B5	M14	W/16	: Data link connector	F5	M53	Y/20	: Air bag diagnosis sensor unit
B4	M15	W/10	: Door mirror remote control switch	G5	M54	W/6	: Door lock/unlock switch
A3	M16	GR/6	: ESP off switch	F5	M55	B/1	: Parking brake switch
A4	M17	W/4	: Headlamp aiming switch	E2	M56	GR/2	: Blower motor
C4	M18	GR/8	: Headlamp washer switch (With headlamp washer)	E1	M57	W/40	: BCM (Body control module)
A4	M19	W/4	: Headlamp washer relay	E1	M58	W/24	: BCM (Body control module)
A4	M20	B/5	: Door lock relay (With intelligent key system)	E1	M59	B/15	: BCM (Body control module)
A2	M21	-	: Body ground	E2	M60	W/40	: Intelligent key unit (With intelligent key system)
B2	M22	-	: Body ground	F2	M61	B/4	: Passenger air bag cut off telltale
B2	M23	W/2	: Sunload sensor (With auto A/C)	F4	M62	B/15	: Heater control panel (Without auto A/C)
B3	M24	B/2	: EPS control unit	F4	M63	W/4	: Hazard switch
B3	M25	W/16	: EPS control unit	F3	M64	B/18	: A/C auto amp. (With auto A/C)
B3	M26	W/4	: Torque sensor	F3	M65	W/18	: A/C auto amp. (With auto A/C)
C2	M27	W/40	: Combination meter	F1	M66	-	: Body ground
C3	M28	-/6	: Intake door motor (With auto A/C)	F1	M67	Y/2	: Front passenger air bag module
D2	M29	-/4	: Fan resistor (Without auto A/C)	F1	M68	W/12	: To R1
D2	M30	-/2	: Power transister (With auto A/C)	G2	M69	-/6	: Passenger air bag cut off switch
D2	M31	-/6	: Power transister (With auto A/C)	F3	M70	W/8	: To D22
C3	M32	W/2	: Key switch	G3	M71	W/12	: To D21
C3	M34	GR/6	: Key switch and ignition knob switch (With Intelligent key system)	F3	M72	W/16	: To B21
C3	M35	GR/4	: NATS antenna amp. (With Intelligent key system)	F4	M73	W/24	: To B22
C4	M36	-/4	: NATS antenna amp. (Without intelligent key system)	F4	M74	GR/2	: To B23
D3	M37	W/4	: Steering lock unit (With intelligent key system)	E2	M75	B/2	: Blower motor (Without A/C)
D3	M38	W/16	: Combination switch	C4	M77	W/6	: After market alarm sub harness (Option connector)
C3	M39	W/6	: Ignition switch				
D4	M40	W/8	: Steering angle sensor				

HARNESS

MAIN HARNESS/RHD MODELS



MKWA4410E

A
B
C
D
E
F
G
H
I
J
K
L
M
N
PG


Harness

B2 ★	M1	SMJ	: To (E101)	D4	W/2	: In vehicle sensor (With auto A/C)
B2	M2	GR/2	: To (E102)	D4	W/3	: Thermo control amp
B2	M3	B/2	: To (E104)	C2	M45	-/20
B2	M4	Y/4	: To (E103)	D2	M46	B/16
G4	M5	W/12	: To D2	D4	M47	GR/2
G6	M6	W/16	: To D1	B4	M48	B/1
E4 ★	M7	-	: Fuse block (J/B)	B4	M49	B/2
G2 ★	M8	W/12	: To (M20)	C4	M50	-/6
G5	M9	GR/1	: Towbar kit	C4	M51	-/6
B3	M10	W/6	: To (B1)	B5 ★	M52	W/6
B4	M11	W/16	: To (B2)	B5	M53	Y/20
E4	M12	W/1	: Fuse block (J/B)	A5	M54	W/6
F5	M13	W/1	: Fuse block (J/B)	B5	M55	B/1
F5	M14	W/16	: Data link connector	E2	M56	GR/2
F5	M15	W/10	: Door mirror remote control switch	C1	M57	W/40
G4	M16	GR/6	: ESP off switch	C1	M58	W/24
G4	M17	W/4	: Headlamp aiming switch	C1	M59	B/15
G4	M20	B/5	: Door lock relay (With intelligent key system)	D3	M60	W/40
F2	M21	-	: Body ground	B3	M61	B/4
E2	M22	-	: Body ground	B3	M62	B/15
F2	M23	W/2	: Sunload sensor (With auto A/C)	B3	M63	W/4
F3	M24	B/2	: EPS control unit	B3	M64	B/18
F3	M25	W/16	: EPS control unit	B3	M65	W/18
F3	M26	W/4	: Torque sensor	B1 ★	M66	-
E2 ★	M27	W/40	: Combination meter	B1	M67	Y/2
C2	M28	-/6	: Intake door motor (With auto A/C)	G2	M68	W/12
C2	M29	-/4	: Fan resistor (Without auto A/C)	A3	M69	-/6
C3	M30	-/2	: Power transistor (With auto A/C)	B3	M70	W/8
B2	M31	-/6	: Power transistor (With auto A/C)	A3	M71	W/12
E3	M33	W/2	: Key switch	F5	M72	W/16
E4	M34	GR/6	: Key switch and ignition knob switch (With Intelligent key system)	F5	M73	W/24
E4	M35	GR/4	: NATS antenna amp. (With intelligent key system)	F5	M74	GR/2
E4	M36	-/4	: NATS antenna amp. (Without intelligent key system)	E2	M75	B/2
D3	M37	W/4	: Steering lock unit (With intelligent key system)	E3	M77	W/6
D3	M38	W/16	: Combination switch	G2 ★	M201	W/12
E3	M39	W/6	: Ignition switch	G3 ★	M203	To (M8)
D4	M40	W/8	: Steering angle sensor	G3 ★	M203	B/2
D4	M41	Y/6	: Combination switch (Spiral cable) (Air bag)	G3 ★	M203	W/4
D4	M42	GR/8	: Combination switch (Spiral cable) (Steering switch)	G4 ★	M205	B/6
Pedal sub harness						
G2	W/12	: To (M8)				
G3	B/2	: Stop lamp switch (With M/T)				
G3	B/2	: Stop lamp switch (With A/T)				
G4	B/6	: Accelerator pedal position sensor				

MKWA4411E

HARNESS

ENGINE ROOM HARNESS/CR ENGINE MODELS



HARNESS


F2	E1	-	Fuse, fusible link and relay box	E1	(E39)	-/5	Front wiper motor (LHD models)
B1	E2	W/3	Horn relay	E1	*(E40)	SMJ	ECM
D2	E3	BR/2	Fusible link holder	F1	(E41)	-/2	Side turn signal lamp LH
E2	E4	GR/2	Fusible link holder	G1	(E42)	B/2	Front wheel sensor LH
G2	*E5	W/8	IPDM E/R (Intelligent power distribution module engine room)	G1	(E43)	B/2	Parking lamp LH
G2	*E6	W/6	IPDM E/R (Intelligent power distribution module engine room)	F1	*(E44)	-	Body ground
E2	*E7	W/16	IPDM E/R (Intelligent power distribution module engine room)	F1	*(E45)	-	Body ground
F3	E8	BR/8	IPDM E/R (Intelligent power distribution module engine room)	G1	(E46)	B/3	Headlamp LH
F3	E9	B/2	IPDM E/R (Intelligent power distribution module engine room)	G1	(E47)	-/3	Headlamp aiming motor LH
G3	*E10	BR/12	IPDM E/R (Intelligent power distribution module engine room)	E2	*(E48)	-/24	To (F1)
G2	*E11	B/6	IPDM E/R (Intelligent power distribution module engine room)	B1	(E54)	W/5	Daytime light relay (LHD models with daytime light system)
G2	*E12	W/12	IPDM E/R (Intelligent power distribution module engine room)	C1	(E61)	B/1	After market alarm unit (Hood switch) (RHD models)
G3	E13	GR/2	Front turn signal lamp LH	E3	*(E62)	-/2	Resistor
G3	*E14	-/2	Front fog lamp LH	E1	(E66)	GR/5	Front wiper motor (RHD models)
E3	E15	-/2	Cooling fan motor				
E3	E16	-/2	Ambient sensor				
F3	E17	B/4					
F3	E18	B/1	Horn (+)	F5	(E36)	B/6	Accelerator pedal position sensor (LHD models)
F3	E19	B/1	Horn (-)	E4	(E38)	B/2	Stop lamp switch (LHD models)
D2	E20	Y/2	Crash zone sensor	E3	*(E101)	SMJ	To (M1)
E3	*E21	B/3	Refrigerent pressure sensor	F4	(E102)	GR/2	To (M2)
D3	E22	GR/2	Front turn signal lamp RH	E4	(E103)	Y/4	To (M4)
C4	E23	-/2	Front fog lamp RH	E3	(E104)	B/2	To (M3)
C4	E24	-/2	Washer motor				
C4	E25	-/2	Headlamp washer motor				
C2	E26	B/3	Headlamp RH				
C2	E27	-/3	Headlamp aiming motor RH				
B2	*E28	-	Body ground				
B2	E29	B/2	Front wheel sensor RH				
B1	E30	B/2	Parking lamp RH				
B1	E31	-/2	Side turn signal lamp RH				
D1, C2	E32	B/26	ABS actuator and electric unit (Control unit)				
E1, D2	E33	B/26	ABS actuator and electric unit (Control unit) (With ESP)				
B2	E34	-	Body ground (For ABS)				
B2	E35	-	Body ground (For ESP)				
D2, C1	E37	GR/2	Brake fluid level switch				

HARNESS

MKWA4415E

Harness

ENGINE ROOM HARNESS/K9K ENGINE MODELS



★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


MKWA4416E

HARNESS

MKWA4417E

HARNESS

ENGINE CONTROL HARNESS/CR ENGINE MODELS



MKWA4418E


HARNESS

F1 ★ (F1)	SMJ	: To (E48)			
F2 ★ (F2)	SMJ	: ECM			
F2 (F3)	-	: Fusible link holder			
F2 (F4)	-	: Fusible link holder			
F2 (F6)	-	: Starter motor (Except for cold area)			
D2 (F6)	-	: Starter motor (For cold area)			
D2 (F7)	-	: Starter motor (For cold area)			
E2 (F8)	-	: Starter motor (Except for cold area)			
E3 (F9)	B/1	: Starter motor (For cold area)			
F3 ★ (F10)	G/3	: Park/neutral position switch			
E1 ★ (F14)	B/3	: Camshaft position sensor			
E2 (F15)	-	: Engine ground			
D2 ★ (F16)	GR/4	: Manifold absolute pressure sensor			
E2 ★ (F17)	L/2	: EVAP canister purge volume control solenoid valve			
C3 ★ (F18)	GR/2	: Fuel injection No. 1			
D3 ★ (F19)	GR/2	: Fuel injection No. 2			
E2 ★ (F20)	GR/2	: Fuel injection No. 3			
E2 ★ (F21)	GR/2	: Fuel injection No. 4			
D3 ★ (F22)	G/2	: Intake valve timing control solenoid valve			
E2 ★ (F23)	GR/2	: Engine coolant temperature sensor			
E4 ★ (F24)	G/4	: Heated oxygen sensor 2			
D3 (F25)	B/1	: Oil pressure switch			
C3 (F26)	GR/2	: Condenser			
D3 ★ (F27)	B/2	: Knock sensor			
D5 (F28)	B/1	: Compressor (With A/C)			
E4 (F29)	B/2	: Alternator			
E4 (F30)	-	: Alternator			
E4 (F31)	-	: Alternator (E)			
E4 (F32)	-	: Body ground			
D4 (F33)	GR/3	: Ignition coil No. 1			
E3 (F34)	GR/3	: Ignition coil No. 2			
E3 (F35)	GR/3	: Ignition coil No. 3			
E3 (F36)	GR/3	: Ignition coil No. 4			
E1 ★ (F37)	B/4	: Heated oxygen sensor 1			
E1 ★ (F38)	G/3	: Crankshaft position sensor			
C2 ★ (F39)	B/6	: Electric throttle control actuator			

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS

ENGINE CONTROL HARNESS/HR ENGINE MODELS




HARNESS

F2 ★ F1	SMJ	: To (E59)		
F2 (F3)	-	: Fusible link holder		
F2 (F4)	-	: Fusible link holder		
F2 (F6)	-	: Starter motor		
F3 (F8)	-	: Starter motor		
F3 ★ F10	G/3	: Park/neutral position switch (With M/T)		
F4 ★ F11	B/3	: Power train sensor (With A/T)		
F4 ★ F12	B/10	: Park/neutral position switch (With A/T)		
G4 ★ F13	B/8	: Terminal cord assembly (With A/T)		
E1 ★ F14	B/3	: Camshaft position sensor		
D2 ★ F17	L/2	: EVAP canister purge volume control solenoid valve		
C3 ★ F18	GR/2	: Fuel injector No. 1		
D4 ★ F19	GR/2	: Fuel injector No. 2		
D4 ★ F20	GR/2	: Fuel injector No. 3		
D4 ★ F21	GR/2	: Fuel injector No. 4		
C3 ★ F22	GR/2	: Intake valve timing control solenoid valve		
E1 ★ F23	GR/2	: Engine coolant temperature sensor		
C3 ★ F24	B/4	: Heated oxygen sensor 2		
E3 F26	GR/2	: Condenser		
F4 ★ F27	B/2	: Knock sensor		
D4 F28	B/1	: Compressor (With A/C)		
D4 F30	-	: Alternator		
C2 ★ F33	GR/3	: Ignition coil No. 1		
C2 ★ F34	GR/3	: Ignition coil No. 2		
C2 ★ F35	GR/3	: Ignition coil No. 3		
D2 F36	GR/3	: Ignition coil No. 4		
E1 ★ F37	B/4	: Heated oxygen sensor 1		
E4 ★ F38	B/3	: Crankshaft position sensor		
E1 ★ F39	B/6	: Electric throttle control actuator		
G2 ★ F41	BR/3	: Revolution sensor		
D4 F43	B/3	: Alternator		
E4 F44	SB/3	: Oil level sensor		
D4 F45	GR/1	: Oil pressure switch		
F3 F46	-	: Engine ground		
E2 ★ F49	B/6	: Mass air flow sensor		
F1 ★ F50	SMJ	: ECM		
F2 ★ F51	SMJ	: ECM		

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS

ENGINE CONTROL HARNESS/K9K ENGINE MODELS




MKWA4422E

HARNESS

G2	(F101)	SMJ	:	To (E60)
E2	(F102)	B/8	:	Glow control unit
F2	(F103)	GR/1	:	To (E62)
F2	(F104)	-	:	Fusible link holder
C3	(F105)	-	:	Starter motor
C3	(F106)	-	:	Starter motor
E4	(F107)	G/3	:	Park/neutral position switch
D3	(F110)	B/2	:	Crankshaft position sensor
D2	(F111)	-/4	:	Engine coolant temperature sensor
B1	(F113)	-/6	:	EGR volume control solenoid valve
D2	(F114)	-/3	:	Turbocharger boost sensor
C1	(F115)	-/2	:	Fuel injector No. 1
C1	(F116)	-/2	:	Fuel injector No. 2
C2	(F117)	-/2	:	Fuel injector No. 3
B2	(F118)	-/2	:	Fuel injector No. 4
D2	(F119)	B/1	:	Glow plug No. 1
C2	(F120)	B/1	:	Glow plug No. 2
C2	(F121)	B/1	:	Glow plug No. 3
B2	(F122)	B/1	:	Glow plug No. 4
D3	(F123)	B/3	:	Fuel rail pressure sensor
D3	(F129)	B/2	:	Knock sensor (Accelerometer)
C4	(F128)	B/2	:	Oil level sensor
B4	(F127)	-	:	Alternator (B)
B3	(F128)	B/2	:	Alternator (S), (L)
B5	(F129)	GR/C	:	Compressor (With A/C)
B3	(F130)	B/3	:	Camshaft position sensor
B3	(F131)	BR/2	:	Fuel pump
B2	(F132)	G/2	:	Fuel pump temperature sensor
F2	(F134)	SMJ	:	ECM
E1	(F135)	B/6	:	Intake air temperature sensor
				(Built into mass air flow sensor)
D4	(F136)	B/2	:	Turbocharger boost control solenoid valve
C4	(F137)	B/2	:	Oil pressure switch

HARNESS

BODY HARNESS (RH SIDE)



A
B
C
D
E
F
G
H
I
J
L
M
PG

MKWA4424E

HARNESS


Body harness RH side

G2	<u>(B21)</u>	W/16	: To <u>(M72)</u>
G4	<u>(B22)</u>	W/24	: To <u>(M73)</u>
F3	<u>(B23)</u>	W/2	: To <u>(M74)</u>
F2	<u>(B24)</u>	W/3	: Heated seat RH
F2	<u>(B25)</u>	W/3	: Seat belt buckle switch RH
F2	<u>(B26)</u>	Y/2	: Front RH side air bag module
F3	<u>(B27)</u>	W/8	: To <u>(D61)</u>
F3	<u>(B28)</u>	-	: Body ground
F3	<u>(B29)</u>	W/2	: Front door switch RH
E3	<u>(B30)</u>	W/3	: RH side air bag (satellite) sensor
E3	<u>(B31)</u>	Y/2	: Front RH seat belt pre-tensioner
C3	<u>(B32)</u>	BR/2	: Inside key antenna (Rare seat)
C3	<u>(B33)</u>	GR/4	: Fuel sensor unit and fuel pump
D4	<u>(B34)</u>	B/2	: Rear wheel sensor RH
A3	<u>(B35)</u>	B/2	: Rear wheel sensor LH
C3	<u>(B36)</u>	B/1	: Luggage room lamp (+)
C3	<u>(B37)</u>	B/1	: Luggage room lamp (-)
D1	<u>(B38)</u>	-	: Body ground
C2	<u>(B39)</u>	W/6	: Rear combination lamp RH
B1	<u>(B40)</u>	Y/2	: LH side curtain air bag module
C1	<u>(B41)</u>	Y/2	: RH side curtain air bag module
D3	<u>(B42)</u>	W/3	: Rear door switch RH
A3	<u>(B43)</u>	GR/2	: Inside key antenna (Rare bumper)
B3	<u>(B44)</u>	GR/2	: Rear fog lamp RH
A2	<u>(B45)</u>	W/4	: Rear wiper motor
A3	<u>(B46)</u>	W/4	: Back door release actuator
B3	<u>(B47)</u>	W/8	: To <u>(D10)</u>
B3	<u>(B48)</u>	-	: Body ground
B2	<u>(B49)</u>	GR/1	: Rear window defogger
B1	<u>(B50)</u>	BR/2	: To <u>(B45)</u>
E3	<u>(B61)</u>	O/2	: Lap outer RH

MKWA4425E

HARNESS

BODY HARNESS (LH SIDE)



MKWA4426E


HARNESS

A3	B1	W/6	:	To (M10)
	B2	W/16	:	To (M11)
C3	B3	Y/12	:	Air bag diagnosis sensor unit
C3	B4	Y/12	:	Air bag diagnosis sensor unit
C2	B5	BR/6	:	Heated seat switch RH
D2	B6	W/6	:	Heated seat switch LH
D3	B7	B/6	:	Yaw rate/side G sensor
C3	B8	B/2	:	Power socket
B2	B9	W/3	:	Heated seat LH
B2	B10	W/3	:	Seat belt buckle switch LH
B3	B11	Y/2	:	Front LH side air bag module
B3	B12	W/8	:	To (D41)
C3	B13	-	:	Body ground
B4	B14	W/3	:	Front door switch LH
C3	B15	Y/2	:	Front LH seat belt per-tensioner
B4	B16	Y/2	:	LH side air bag (satellite) sensor
E2	B17	W/6	:	Rear combination lamp LH
E3	B18	B/2	:	Power socket
D3	B19	W/3	:	Rear door switch LH
D2	B20	GR/2	:	Inside antenna (Center console)
C3	B60	O/2	:	Lap outer LH

MKWA4427E

HARNESS

ROOM LAMP HARNESS




A
B
C
D
E
F
G
H
I
J

PG
L
M

MKWA4428E

HARNESS


FRONT DOOR HARNESS LH SIDE/LHD MODELS



- D1** W/16 : To **M6**
- D2** W/12 : To **M5**
- D4** B/6 : Front power window motor (Driver side)
- D5** W/8 : Door mirror actuator (Driver side)
- D6** BR/2 : Tweeter RH (With 6 speakers)
- D7** W/2 : Front door speaker RH (Driver side)
- D8** W/16 : Power window main switch
- D9** W/3 : Power window main switch
- D10** BR/2 : Intelligent key warning buzzer (With Intelligent key system)
- D11** B/6 : Door lock actuator (Driver side)
- D12** GR/2 : Door request switch (Driver side) (With Intelligent key system)
- D13** GR/2 : Outside antenna (Driver side) (With Intelligent key system)

HARNESS


FRONT DOOR HARNESS LH SIDE/RHD MODELS



- D21** W/12 : To **(M71)**
- D22** W/8 : To **(M70)**
- D23** GR/2 : Front power window motor (Passenger side)
- D24** BR/2 : Tweeter RH (With 6 speakers)
- D25** W/8 : Door mirror actuator (Passenger side)
- D26** W/2 : Front door speaker RH
- D27** W/8 : Front power window switch (Passenger side)
- D28** B/6 : Door lock actuator (Passenger side)
- D29** GR/2 : Door request switch (Passenger side) (With Intelligent key system)
- D30** W/2 : Outside antenna (Passenger side) (With Intelligent key system)

HARNESS


FRONT DOOR HARNESS RH SIDE/LHD MODELS



- D21 W/12 : To **(M71)**
- D22 W/8 : To **(M70)**
- D23 GR/2 : Front power window motor (Passenger side)
- D24 BR/2 : Tweeter RH (With 6 speakers)
- D25 W/8 : Door mirror actuator (Passenger side)
- D26 W/2 : Front door speaker RH
- D27 W/8 : Front power window switch (Passenger side)
- D28 B/6 : Door lock actuator (Passenger side)
- D29 GR/2 : Door request switch (Passenger side) (With Intelligent key system)
- D30 W/2 : Outside antenna (Passenger side) (With Intelligent key system)

HARNESS

FRONT DOOR HARNESS RH SIDE/RHD MODELS



- D1** W/16 : To **M6**
- D2** W/12 : To **M5**
- D4** B/6 : Front power window motor (Driver side)
- D5** W/8 : Door mirror actuator (Driver side)
- D6** BR/2 : Tweeter RH (With 6 speakers)
- D7** W/2 : Front door speaker RH (Driver side)
- D8** W/16 : Power window main switch
- D9** W/3 : Power window main switch
- D10** BR/2 : Intelligent key warning buzzer (With Intelligent key system)
- D11** B/6 : Door lock actuator (Driver side)
- D12** GR/2 : Door request switch (Driver side) (With Intelligent key system)
- D13** GR/2 : Outside antenna (Driver side) (With Intelligent key system)

A
B
C
D
E
F
G
H
I
J


PG

L

M

HARNESS


REAR DOOR HARNESS LH SIDE



- D41** W/8 : To **B12**
- D42** W/2 : Rear door speaker LH side
- D43** W/8 : Rear power window switch LH side
- D44** B/2 : Rear power window motor LH side
- D45** B/6 : Rear door lock actuator LH side

HARNESS

REAR DOOR HARNESS RH SIDE



- D61** W/8 : To **(B27)**
- D62** W/2 : Rear door speaker RH side
- D63** W/8 : Rear power window switch RH side
- D64** B/2 : Rear power window motor RH side
- D65** B/6 : Rear door lock actuator RH side

A

B

C

D

E

F

G

H

I

J

PG


L

M

MKWA4434E

HARNESS

BACK DOOR HARNESS



D101 W/8 : To B47

D102 -/2 : Back door request switch (With Intelligent key system)

D103 B/2 : License plate lamp RH

D104 GR/2 : Back door switch

D105 B/2 : License plate lamp LH

HARNESS

Wiring Diagram Codes (Cell Codes)

BKS0026Q

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
A/C	ATC	Air Conditioner
A/C	MTC	Air Conditioner
A/WIP	WW	Front Wiper and Washer System (With Rain Sensor)
ABS	BRC	Anti-lock Brake System
AP/SEN	EC	Absolute Pressure Sensor
APPS	EC	Accelerator Pedal Position Sensor
APPS1	EC	Accelerator Pedal Position Sensor
APPS2	EC	Accelerator Pedal Position Sensor
APPS3	EC	Accelerator Pedal Position Sensor
AT/IND	DI	A/T Indicator Lamp
AUDIO	AV	Audio
AUTO/L	LT	Auto Light Control
BA/FTS	AT	A/T Fluid Temperature Sensor and TCM Power Supply
BACK/L	LT	Back-up Lamp
BRK/SW	EC	Brake Switch
CAN	AT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
CIGAR	WW	Cigarette Lighter
CKPS	EC	Crankshaft Position Sensor
CMPS	EC	Camshaft Position Sensor
COMBSW	LT	Combination Switch
COOL/F	EC	Cooling Fan Control
CRFPS	EC	Common Rail Fuel Pressure Sensor
D/COMP	DI	Drive Computer
D/LOCK	BL	Power Door Lock
DEF	GW	Rear Window Defogger
DTRL	LT	Headlamp - With Daytime Light System
ECMRLY	EC	ECM Relay
ECM/PW	EC	ECM Power Supply For Back-up
ECTS	EC	Engine Coolant Temperature Sensor
EGRC/V	EC	EGR Control System
ENGSS	AT	Engine Speed Signal
EPS	STC	Electric Controlled Power Steering System
ESP	BRC	Electronic Stability Program System
ETC1	EC	Electric Throttle Control Function
ETC2	EC	Throttle Control Motor Relay
ETC3	EC	Throttle Control Motor
F/FOG	LT	Front Fog Lamp

A
B
C
D
E
F
G
H
I
J
PG
L
M

HARNESS

Code	Section	Wiring Diagram Name
F/PUMP	EC	Fuel Pump
FRO2	EC	Front Heated Oxygen Sensor
FRPS	EC	Fuel Rail Pressure Sensor
FTS	AT	A/T Fluid Temperature Sensor
FTS	EC	Fuel Temperature Sensor
FUEL	EC	Fuel Injection System Function
GLOW	EC	Quick Glow System
H/AIM	LT	Headlamp Aiming Control System
H/LAMP	LT	Headlamp
H/SEAT	SE	Heated Seat
HEATER	MTC	Heater System
HLC	WW	Headlamp Washer
HO2S1	EC	Heated Oxygen Sensor 1
HO2S1H	EC	Heated Oxygen Sensor 1 Heater
HO2S2	EC	Rear Heated Oxygen Sensor 2
HO2S2H	EC	Rear Heated Oxygen Sensor 2 Heater
HORN	WW	Horn
I/KEY	BL	Intelligent Key System
IATS	EC	Intake Air Temperature Sensor
IATSEN	EC	Intake Air Temperature Sensor
IGNSYS	EC	Ignition System
ILL	LT	Illumination
IMV/D	EC	Fuel Flow Actuator
INJECT	EC	Fuel Injector
INT/L	LT	Stop, Vanity Mirror and Trunk Room Lamps
IVC	EC	Intake Valve Timing Control Solenoid Valve
KS	EC	Knock Sensor
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
METER	DI	Speed Meter, Tachometer, Temp, Oil and Fuel Gauge
MIL/DL	EC	MIL & Data Link Connector
MIRROR	GW	Door Mirror
MULTI	BL	Multi-remote Control System
NATS	BL	Nissan Anti-Theft System
NONDTC	AT	NON-detective Items
OVRCSV	AT	Overrun Clutch Solenoid Valve
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHASE	EC	Camshaft Position Sensor (PHASE)
PNP/SW	AT	Park/Neutral Position Switch
PNP/SW	EC	Park/Neutral Position Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	PG	Power Supply Routing Circuit

HARNESS

Code	Section	Wiring Diagram Name
PRGVLV	EC	EVAP Canister Purge Volume Control Solenoid Valve
PRWIRE	BL	After Market Alarm - Prewire
PTC/H	ATC	PTC Heater
PTC/H	MTC	PTC Heater
PT/SEN	AT	Turbine Revolution Sensor
R/FOG	LT	Rear Fog Lamp
RP/SEN	EC	Refrigerant Pressure Sensor
RRO2	EC	Rear Heated Oxygen Sensor 2
S/LOCK	BL	Power Door Lock-Super Lock
SEN/PW	EC	Sensor Power Supply
SHIFT	AT	A/T Shift Lock System
SRS	SRS	Supplemental Restraint System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STOP/L	LT	Stop Lamp
TAIL/L	LT	Parking, License Tail and Stop Lamps
TCBST	EC	TC Boost Pressure Sensor
TCC/V	EC	Turbocharger Boost Control Solenoid Valve
TCV	AT	Torque Converter Clutch Solenoid Valve
TPS1	EC	Throttle Position Sensor (Sensor 1)
TPS2	EC	Throttle Position Sensor (Sensor 2)
TPS3	EC	Throttle Position Sensor
TURN	LT	Turn Signal and Hazard Warning Lamps
VSSAT	AT	Vehicle Speed Sensor A/T (Revolution Senor)
VSSMTR	AT	Vehicle Speed Sensor MTR
WARN	DI	Warning Lamps
WINDOW	GW	Power Window
WIP/R	WW	Rear Wiper and Washer

A

B

C

D

E

F

G

H

I

J

PG

L

M


ELECTRICAL UNITS LOCATION

ELECTRICAL UNITS LOCATION


PFP:25230

Electrical Units Location ENGINE COMPARTMENT


BKS00261



IPDM E/R (Intelligent power distribution module engine room)




Fuse, fusible link and relay box




MKWA4436E

ELECTRICAL UNITS LOCATION

Fusible link box (With K9K engine models)



PTC relay box (With PTC heater)



A
B
C
D
E
F
G
H
I
J

PG



L

M

MKWA4437E

ELECTRICAL UNITS LOCATION


PASSENGER COMPARTMENT/LHD MODELS




MKWA4438E

ELECTRICAL UNITS LOCATION


B View with console box removed




C View with glove box removed




D View with instrument panel removed




E View with instrument panel removed



F View with column cover removed



G View with instrument panel removed



A
B
C
D
E
F
G
H
I
J



PG

L
M

MKWA4439E







ELECTRICAL UNITS LOCATION

PASSENGER COMPARTMENT/RHD MODELS



MKWA4440E

ELECTRICAL UNITS LOCATION



A
B
C
D
E
F
G
H
I
J

PG

L
M

MKWA4441E

HARNESS CONNECTOR

HARNESS CONNECTOR

PFP:00011

Description

HARNESS CONNECTOR (TAB-LOCKING TYPE)

BKS00262


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Never pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR


HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.

CAUTION:

- **Do not pull the harness or wires when disconnecting the connector.**
- **Be careful not to damage the connector support bracket when disconnecting the connector.**

[Example]




ELECTRICAL UNITS

ELECTRICAL UNITS


PFP:00011

Terminal Arrangement

BKS00263



ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)




-  : CR engine models
-  : HR engine models
-  : K9K engine models
-  : With ESP
-  : Without ESP


MKWA4443E

ELECTRICAL UNITS

BCM (BODY CONTROL MODULE)



A/C AUTO AMP.



A

B

C

D

E

F

G

H

I

J

PG

L

M

MKWA4444E


SMJ (SUPER MULTIPLE JUNCTION)

SMJ (SUPER MULTIPLE JUNCTION)

PFP:B4341

Terminal Arrangement

BKS00264



H : HR engine models

C : CR engine models

K : K9K engine models

MKWA4442E

STANDARDIZED RELAY

STANDARDIZED RELAY


PFP:00011

Description

BKS00265

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H


TYPE OF STANDARDIZED RELAYS

1M 1 Make

2M 2 Make















1T 1 Transfer

1M-1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W



FUSE BLOCK

FUSE BLOCK

Terminal Arrangement


PFP:24010

BKS00266



To main harness

2 M13



MKWA4446E



FUSE, FUSIBLE LINK AND RELAY BOX

FUSE, FUSIBLE LINK AND RELAY BOX

PFP:24382

Terminal Arrangement

BKS00267



: CR engine models

: HR engine models

: K9K engine models

MKWA4447E