

ELECTRICAL SYSTEM

SECTION **EL**

GI
MA
EM
LC
EC

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

- Check for any service bulletins before servicing the vehicle.

CONTENTS

FE
AT

PRECAUTIONS	5	Service Data and Specifications (SDS).....	41
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5	COMBINATION SWITCH	42
HARNES CONNECTOR	6	Check.....	42
Description	6	Replacement.....	43
STANDARDIZED RELAY	8	STEERING SWITCH	44
Description	8	Check.....	44
POWER SUPPLY ROUTING	10	HEADLAMP (FOR U.S.A.) - XENON TYPE -	46
Schematic	10	Component Parts and Harness Connector	
Wiring Diagram - POWER -	11	Location	46
Fuse	20	System Description.....	46
Fusible Link.....	20	Schematic	49
Circuit Breaker Inspection	20	Wiring Diagram - H/LAMP -	50
GROUND DISTRIBUTION	21	CONSULT-II (For auto light operation).....	53
Engine Room Harness	21	Trouble Diagnoses/Auto Light Operation	54
Main Harness.....	23	Trouble Diagnoses/Headlamp (Xenon Type)	60
Engine Control Harness	25	Bulb Replacement/Xenon Type	62
Engine Harness	27	Aiming Adjustment/Xenon Type.....	63
Body Harness	28	HEADLAMP (FOR CANADA) - XENON TYPE -	65
Body No. 2 Harness	30	Component Parts and Harness Connector	
BATTERY	31	Location	65
How to Handle Battery	31	Daytime Light System/System Description	65
Service Data and Specifications (SDS).....	33	Operation (Daytime light system with xenon headlamp)	67
STARTING SYSTEM	34	Schematic	68
System Description.....	34	Wiring Diagram - DTRL -	69
Wiring Diagram - START -	35	Trouble Diagnoses.....	73
Construction.....	36	Bulb Replacement/Xenon Type	74
Removal and Installation	36	Aiming Adjustment/Xenon Type.....	74
Pinion/Clutch Check	37	HEADLAMP - Headlamp Aiming Control -	75
Service Data and Specifications (SDS).....	37	Wiring Diagram - H/AIM -	75
CHARGING SYSTEM	38	PARKING, LICENSE AND TAIL LAMPS	76
System Description.....	38	System Description.....	76
Wiring Diagram - CHARGE -	39	Wiring Diagram - TAIL/L -	77
Trouble Diagnoses.....	40	Trouble Diagnoses.....	79
Removal and Installation	40	STOP LAMP	80
Construction.....	41	Wiring Diagram - STOP/L -	80

PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CONTENTS (Cont'd)


BACK-UP LAMP81	System Description.....142
Wiring Diagram - BACK/L -81	Schematic144
FRONT FOG LAMP82	Wiring Diagram - WIPER -145
System Description.....82	CONSULT-II148
Wiring Diagram - F/FOG -83	Trouble Diagnoses.....151
Aiming Adjustment.....85	Removal and Installation157
Bulb Specifications85	Washer Nozzle Adjustment158
TURN SIGNAL AND HAZARD WARNING LAMPS86	Washer Tube Layout159
System Description.....86	HORN160
Schematic88	Wiring Diagram - HORN -160
Wiring Diagram - TURN -89	CIGARETTE LIGHTER161
Trouble Diagnoses.....92	Wiring Diagram - CIGAR -161
Electrical Components Inspection92	CLOCK162
ILLUMINATION93	Wiring Diagram - CLOCK -162
System Description.....93	REAR WINDOW DEFOGGER163
Schematic94	Component Parts and Harness Connector
Wiring Diagram - ILL -95	Location163
TRUNK ROOM AND VANITY MIRROR LAMP100	System Description.....163
Wiring Diagram - INT/L -100	Wiring Diagram - DEF -164
METER AND GAUGES101	CONSULT-II166
Component Parts and Harness Connector	Trouble Diagnoses.....167
Location101	Filament Check.....170
System Description.....101	Filament Repair171
Combination Meter103	AUDIO172
Wiring Diagram - METER -104	System Description.....172
Meter/Gauge Operation and Odo/Trip Meter	Schematic173
Segment Check in Diagnosis Mode.....106	Wiring Diagram - AUDIO -174
Flexible Print Circuit (FPC).....107	Trouble Diagnoses.....181
Trouble Diagnoses.....108	Wiring Diagram - REMOTE -183
Electrical Components Inspection112	AUDIO ANTENNA184
WARNING LAMPS115	System Description.....184
System Description.....115	Wiring Diagram - P/ANT -185
Schematic118	Trouble Diagnoses.....186
Wiring Diagram - WARN -119	Location of Antenna.....186
CONSULT-II (For door warning lamp).....123	Antenna Rod Replacement186
Trouble Diagnoses/Door Warning Lamp124	Window Antenna Repair187
Trouble Diagnoses/Stop and Tail Lamp Sensor.....126	TELEPHONE (Pre wire)188
Electrical Components Inspection127	Wiring Diagram - PHONE -188
A/T INDICATOR128	TRUNK LID AND FUEL FILLER LID OPENER190
Schematic128	Wiring Diagram - T&FLID -190
Wiring Diagram - AT/IND -129	TRUNK CLOSURE192
WARNING CHIME132	Component Parts and Harness Connector
Component Parts and Harness Connector	Location192
Location132	System Description.....192
System Description.....132	Wiring Diagram - T/CLOS -193
Wiring Diagram - CHIME -134	Trouble Diagnosis.....195
CONSULT-II136	ELECTRIC SUNROOF198
Trouble Diagnoses.....137	Component Parts and Harness Connector
Electrical Components Inspection141	Location198
WIPER AND WASHER142	System Description.....198
Component Parts and Harness Connector	Wiring Diagram - SROOF -199
Location142	CONSULT-II201

CONTENTS (Cont'd)

Trouble Diagnoses.....	202	CONSULT-II.....	279
DOOR MIRROR	203	Trouble Diagnoses.....	280
Wiring Diagram - MIRROR -	203	POWER DOOR LOCK - IVMS	288
AUTO ANTI-DAZZLING INSIDE MIRROR	204	Component Parts and Harness Connector	GI
Wiring Diagram - I/MIRR -	204	Location	288
POWER SEAT (Passenger side)	205	System Description.....	289
Schematic	205	Schematic	290
Wiring Diagram - SEAT -	206	Wiring Diagram - D/LOCK -	291
HEATED SEAT	210	CONSULT-II	295
Wiring Diagram - HSEAT -	210	On board Diagnosis - Mode III (Power door lock	
REAR SUNSHADE	212	operation).....	298
Component Parts and Harness Connector		Trouble Diagnoses.....	300
Location	212	MULTI-REMOTE CONTROL SYSTEM - IVMS	309
System Description.....	213	Component Parts and Harness Connector	EC
Wiring Diagram - SHADE -	214	Location	309
Trouble Diagnoses.....	216	System Description.....	310
AUTOMATIC SPEED CONTROL DEVICE (ASCD)	218	Schematic	312
Component Parts and Harness Connector		Wiring Diagram - MULTI -	313
Location	218	CONSULT-II	319
System Description.....	219	Trouble Diagnoses.....	320
Schematic	221	Electrical Components Inspection	329
Wiring Diagram - ASCD -	222	ID Code Entry Procedure	330
CONSULT-II	227	INTERIOR ILLUMINATION CONTROL - IVMS	333
Fail-safe System Description.....	229	System Description.....	333
Fail-safe System Check.....	230	Schematic	337
Trouble Diagnoses.....	231	Wiring Diagram - ROOM/L -	338
Electrical Components Inspection	239	CONSULT-II	345
ASCD Wire Adjustment	240	Trouble Diagnoses.....	346
IVMS (LAN)	241	STEP LAMP - IVMS	355
Overall Description	241	Component Parts and Harness Connector	BR
Component Parts Location.....	242	Locations.....	355
System Diagram	243	System Description.....	356
Sleep/Wake-up Control.....	244	Schematic	357
Fail-safe System.....	244	Wiring Diagram - STEP/L -	358
CONSULT-II	245	CONSULT-II	363
On board Diagnosis.....	252	Trouble Diagnoses.....	364
On board Diagnosis - Mode I (IVMS		REAR POWER WINDOW SWITCH ILLUMINATION	
communication diagnosis).....	253	- IVMS	366
On board Diagnosis - Mode II (Switch monitor).....	255	System Description.....	366
Schematic	257	Wiring Diagram - SW/ILL -	367
Wiring Diagram - COMM -	258	CONSULT-II	369
Trouble Diagnoses.....	262	Trouble Diagnoses.....	370
BCM (Body Control Module)	266	THEFT WARNING SYSTEM - IVMS	371
Schematic	266	Component Parts Harness Connector Location.....	371
LOCAL CONTROL UNITS (LCUs)	268	System Description.....	372
Schematic	268	Schematic	374
POWER WINDOW - IVMS	272	Wiring Diagram - THEFT -	375
Component Parts and Harness Connector		CONSULT-II	383
Location	272	Trouble Diagnoses.....	384
System Description.....	273	AUTOMATIC DRIVE POSITIONER - IVMS	397
Schematic	274	Component Parts and Harness Connector	
Wiring Diagram - WINDOW -	275	Location	397

CONTENTS (Cont'd)

System Description.....	398	Engine Compartment.....	496
Schematic	402	Luggage Compartment.....	497
Wiring Diagram - AUT/DP -	403	Passenger Compartment.....	498
CONSULT-II.....	410	HARNES LAYOUT	500
On board Diagnosis - Mode IV (Automatic drive positioner operation)	414	Outline.....	500
Trouble Diagnoses.....	416	How to Read Harness Layout	501
IVIS (Infiniti Vehicle Immobilizer System - NATS) ..	442	Engine Room Harness	502
Component Parts and Harness Connector		Instrument Harness	505
Location	442	Main Harness.....	506
System Description.....	443	Engine Control Harness	508
System Composition.....	443	Body Harness and Tail Harness.....	510
Wiring Diagram - NATS -	444	Body No. 2 Harness	512
CONSULT-II.....	445	Engine Harness	514
Trouble Diagnoses.....	447	Room Lamp Harness.....	515
How to Replace IVIS (NATS) Antenna Amp.	459	Air Bag Harness	516
INTEGRATED HOMELINK TRANSMITTER	460	Front Door Harness	517
Wiring Diagram - TRNSMT -	460	Rear Door Harness.....	518
Trouble Diagnoses.....	461	SPLICE LOCATION	519
INFINITI COMMUNICATOR (IVCS)	462	How to Read Splice Location	519
Precaution.....	462	Engine Room Harness	520
Communicator Response Center Telephone		Main Harness.....	522
Number for Technicians.....	462	Instrument Harness	523
Component Parts and Harness Connector		Engine Control Harness	524
Location	463	Engine Harness	525
System Description.....	464	Body Harness and Tail Harness.....	526
Schematic	470	Body No. 2 Harness	527
Wiring Diagram - IVCS -	471	Room Lamp Harness.....	528
CONSULT-II.....	475	Front Door Harness	529
Trouble Diagnoses.....	479	Rear Door Harness.....	530
Trouble Diagnoses for Intermittent Incident	489	BULB SPECIFICATIONS	531
Demonstration Mode	490	Headlamp.....	531
System Setting (When IVCS unit is replaced)	492	Exterior Lamp	531
LOCATION OF ELECTRICAL UNITS	496	Interior Lamp.....	531
		WIRING DIAGRAM CODES (Cell codes)	532



Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER” used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to INFINITI Q45 is as follows:

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by intentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses (except satellite sensor and side air bag module) covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Description

HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



HARNESS CONNECTOR

Description (Cont'd)

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

- Do not pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]

Waterproof type

- ① Firmly grasp shell of connector housing at A.
- ② Push slider until connector pops or snaps apart.
- ③ Disconnect harness connector.

Non-waterproof type

- ① Firmly grasp shell of connector housing at A.
- ② Pull back on the slider while pulling apart male and female halves of connector.
- ③ Disconnect harness connector.

SEL769V

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

TYPE OF STANDARDIZED RELAYS

- 1M 1 Make 2M 2 Make
- 1T 1 Transfer 1M·1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M-1B				GRAY
1M				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT


HA

EL

IDX







Schematic



POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-02



REFER TO THE FOLLOWING.

(M4), (E66) -SUPER MULTIPLE JUNCTION (SMJ)


(M1), (E64), (B1), (B2) -FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11	12	13	14
15	16	17	18	19	20	21	22	23	24	25	26	27	28
		29	30	31	32	33	34	35	36	37	38	39	40

POWER SUPPLY ROUTING


Wiring Diagram — POWER — (Cont'd)

EL-POWER-03



<US> : For U.S.A.
<CA> : For Canada

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX





POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-04

US : For U.S.A.


CA : For Canada






POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-05



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX





POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

IGNITION POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"

NOTE: For detailed ground distribution information, refer to "GROUND DISTRIBUTION", EL-21.

EL-POWER-06



REFER TO THE FOLLOWING.

M1, E61, E63, B2 - FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11	12	13	14
15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40		

POWER SUPPLY ROUTING


Wiring Diagram — POWER — (Cont'd)

IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"


NOTE: For detailed ground distribution information, refer to "GROUND DISTRIBUTION", EL-21.

EL-POWER-07

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA



REFER TO THE FOLLOWING.




EL
IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-08

: With active damper suspension



REFER TO THE FOLLOWING.


, , -FUSE BLOCK-
 JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11	12	13	14
15	16	17	18	19	20	21	22	23	24	25	26	27	28
		29	30	31	32	33	34	35	36	37	38	39	40

POWER SUPPLY ROUTING


Wiring Diagram — POWER — (Cont'd)

EL-POWER-09




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT


HA
EL
IDX



REFER TO THE FOLLOWING.




POWER SUPPLY ROUTING



Fuse

- a. If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- b. Use fuse of specified rating. Never use fuse of more than specified rating.
- c. Do not partially install fuse; always insert it into fuse holder properly.
- d. Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.





Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:


- a. If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- b. Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker Inspection

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.


Engine Room Harness




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

GROUND DISTRIBUTION

Engine Room Harness (Cont'd)



Main Harness





GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


(B)

GROUND DISTRIBUTION

Main Harness (Cont'd)



Engine Control Harness




J/C: Joint connector

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX


GROUND DISTRIBUTION

Engine Control Harness (Cont'd)




GROUND DISTRIBUTION

Engine Control Harness (Cont'd)



GI
MA
EM
LC
EC
FE
AT
PD


Engine Harness



CEL989
FA
RA
BR
ST
RS
BT
HA
EL
IDX









CEL990

Body Harness



GROUND DISTRIBUTION




Body Harness (Cont'd)



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

GROUND DISTRIBUTION

Body No. 2 Harness



CAUTION:

- a. If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- b. After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- c. Never add distilled water through the hole used to check specific gravity.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




How to Handle Battery


METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level. This also applies to batteries designated as “low maintenance” and “maintenance-free”.



- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)



- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

CHECKING ELECTROLYTE LEVEL



WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

BATTERY

How to Handle Battery (Cont'd)

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.




SULPHATION

A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulphation on the cell plates.

To determine if a battery has been “sulphated”, note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulphated batteries.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.



SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.
2. Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (130)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012
4 (40)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

BATTERY

How to Handle Battery (Cont'd)

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

GI

MA

EM

CHARGING THE BATTERY

CAUTION:

- Do not “quick charge” a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

LC

EC

FE

Charging rates:

AT

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

PD

FA

Do not charge at more than 50 ampere rate.

Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

RA

BR

- If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced.

ST

Service Data and Specifications (SDS)

RS

Type		80D26R
Capacity	V-AH	12-55
Cold cranking current (For reference value)	A	582

BT

HA

EL

IDX

System Description

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **g**, located in the fuse, fusible link and relay box).


With the ignition switch in the START position, power is supplied

- from ignition switch terminal ④
- to park/neutral position switch terminal ①
- through park/neutral position switch terminal ②, with the selector lever in the P or N position
- to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

Wiring Diagram — START —

EL-START-01



- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA





EL

IDX

STARTING SYSTEM


Construction



Removal and Installation

REMOVAL

1. Remove steering gear and linkage assembly. (Refer to "ST section".)
2. Remove harness connector.
3. Remove starter by moving it in the direction of the arrow.



INSTALLATION

To install, reverse the removal procedure.

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident, replace.

GI

MA

EM

Service Data and Specifications (SDS)

LC

STARTER

Type	M2T84671		EC
	MITSUBISHI make		
	Reduction gear type		
System voltage	V	12	FE
No-load			AT
Terminal voltage	V	11.0	
Current	A	Less than 145	
Revolution	rpm	More than 3,300	PD
Minimum diameter of commutator	mm (in)	31.4 (1.236)	FA
Minimum length of brush	mm (in)	11.0 (0.433)	
Brush spring tension	N (kg, lb)	30.9 - 37.7 (3.15 - 3.85, 6.95 - 8.47)	RA
Clearance between pinion front edge and pinion stopper	mm (in)	0.5 - 2.0 (0.020 - 0.079)	BR

BR

ST

RS

BT

HA

EL

IDX

System Description

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to alternator terminal ⑤ through:

- 120A fusible link (letter **a**, located in the fuse, fusible link and relay box), and
- 7.5A fuse (No. **62**, located in the fuse, fusible link and relay box).

Terminal ⑥ supplies power to charge the battery and operate the vehicle's electrical system. Output voltage is controlled by the IC regulator at terminal ⑤ detecting the input voltage. The charging circuit is protected by the 120A fusible link.

Terminal ⑦ of the alternator supplies ground through body ground **E112**.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. **4**, located in the fuse block (J/B)]
- to combination meter terminal **41** for the charge warning lamp.


Ground is supplied to terminal **25** of the combination meter through terminal **L** of the alternator. With power and ground supplied, the charge warning lamp will illuminate. When the alternator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a fault is indicated.

CHARGING SYSTEM



Wiring Diagram — CHARGE —

EL-CHARGE-01



Refer to EL-POWER.

- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA



REFER TO THE FOLLOWING.
 (M6), (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)


- EL
- IDX

Trouble Diagnoses

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.

- Before starting, inspect the fusible link.
- Use fully charged battery.

WITH IC REGULATOR



Warning lamp: "CHARGE" warning lamp in combination meter


Note:

- If the inspection result is OK even though the charging system is malfunctioning, check the B terminal connection. (Check the tightening torque.)
- When field circuit is open, check condition of rotor coil, rotor slip ring and brush. If necessary, replace faulty parts with new ones.

MALFUNCTION INDICATOR

The IC regulator warning function activates to illuminate "CHARGE" warning lamp, if any of the following symptoms occur while alternator is operating:

- Excessive voltage is produced.
- No voltage is produced.



Removal and Installation


REMOVAL

1. Remove engine upper cover.
2. Remove drive belt from alternator.
3. Disconnect harness connector.
4. Remove alternator.

INSTALLATION

To install, reverse the removal procedure.

Construction



GI
MA
EM
LC
EC
FE
AT
PD
FA

RA
BR
ST

RS
BT
HA

EL
IDX



Service Data and Specifications (SDS)

ALTERNATOR

Type		LR1110-707J HITACHI make
Nominal rating	V-A	12-110
Ground polarity		Negative
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	Less than 950
Hot output current (When 13.5 volts is applied)	A/rpm	More than 34/1,300 More than 82/2,500 More than 105/5,000
Regulated output voltage	V	14.1 - 14.7
Minimum length of brush	mm (in)	6.0 (0.236)
Brush spring pressure	N (g, oz)	1.000 - 3.432 (102 - 350, 3.60 - 12.34)
Slip ring minimum outer diameter	mm (in)	26.0 (1.024)
Rotor (Field coil) resistance	Ω	2.31


COMBINATION SWITCH

Check



FRONT WIPER SWITCH

	OFF	INT	LO	HI	WASH
13	<input type="checkbox"/>	<input type="checkbox"/>			
14	<input type="checkbox"/>	<input type="checkbox"/>			
15		<input type="checkbox"/>			
16		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
17		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
18					<input type="checkbox"/>



FRONT FOG LAMP SWITCH

	ON	OFF
31	<input type="checkbox"/>	<input type="checkbox"/>
32	<input type="checkbox"/>	<input type="checkbox"/>




TURN SIGNAL SWITCH

	L	N	R
1	<input type="checkbox"/>		<input type="checkbox"/>
2	<input type="checkbox"/>		<input type="checkbox"/>
3	<input type="checkbox"/>		<input type="checkbox"/>

LIGHTING SWITCH

	OFF	AUTO	1ST	2ND
5			<input type="checkbox"/>	<input type="checkbox"/>
11			<input type="checkbox"/>	<input type="checkbox"/>
8				<input type="checkbox"/>
12				<input type="checkbox"/>
42		<input type="checkbox"/>		
(8)		<input type="checkbox"/>		

	A	B	C
(5)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
(8)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
10	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
9	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
(12)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>



Replacement

For removal and installation of spiral cable, refer to RS section ["SUPPLEMENTAL RESTRAINT SYSTEM (SRS)", "Installation — Air Bag Module and Spiral Cable"].



- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw.
- Before installing steering wheel, align the steering wheel guide pins with the screws which secure the combination switch, as shown in the left figure.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

STEERING SWITCH

Check


WITH INFINITI COMMUNICATOR (IVCS)




STEERING SWITCH

Check (Cont'd)


WITHOUT INFINITI COMMUNICATOR (IVCS)



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Component Parts and Harness Connector Location



SEL856W

System Description

Power is supplied at all times

- through 15A fuse [No. 54, located in the fuse, fusible link and relay box]
- to headlamp relay terminal ① and
- to headlamp relay terminal ⑦, and
- through 15A fuse [No. 53, located in the fuse, fusible link and relay box]
- to headlamp relay terminal ⑤, and
- through 7.5A fuse [No. 14, located in the fuse block (J/B)].
- to BCM terminal ⑩⑤.

Power is also supplied at all times

- to HID relay terminal ①, and
- through 20A fuse (No. 61, located in the fuse, fusible link and relay box)
- to HID relay terminal ③, and
- through 20A fuse (No. 59, located in the fuse, fusible link and relay box)
- to HID relay terminal ⑥, and

When the ignition switch is in the ACC or ON position, power is supplied

- through 7.5A fuse [No. 23, located in the fuse block (J/B)]
- to BCM terminal ⑩.

When the ignition switch is in the ON or START position, power is supplied

- through 7.5A fuse [No. 32, located in the fuse block (J/B)]
- to BCM terminal ⑩.

Ground is supplied

- to BCM terminals ⑤⑥ and ⑩③
- to illumination time control switch terminal ③
- through body grounds ⑩④ and ⑩④⑦, and
- to the lighting switch terminals ⑧ and ⑤
- through body grounds ⑩②② and ⑩③⑥.

HEADLAMP SWITCH OPERATION

Low beam operation

When the lighting switch is turned to 2ND (LOW or HI) or PASS ("C") position, ground is supplied

- to HID relay terminal ②
- from the lighting switch terminal ⑩②.

HEADLAMP (FOR U.S.A.) — XENON TYPE —

System Description (Cont'd)

HID relay is then energized, and power is supplied.

- from the HID relay terminal ⑤
- to terminal ② LH headlamp

Power is also supplied

- from the HID relay terminal ⑦
- to terminal ② RH headlamp

Ground is supplied at all times.

- to LH headlamp terminal ④ and RH headlamp terminal ④
- through body ground (E22) and (E36).

With power and ground supplied, the low beam headlamps illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is turned to 2ND and HIGH (“A”) or PASS (“C”) position, ground is supplied

- to headlamp relay terminal ②
- from the lighting switch terminal ⑫.

Headlamp relay is then energized, and power is supplied

- from the headlamp relay terminal ⑥
- to terminal ① of the LH headlamp, and
- to combination meter terminal ⑳ for the HIGH BEAM indicator
- from headlamp relay terminal ③
- to terminal ① of the RH headlamp.

Ground is supplied

- to terminal ③ of the LH headlamp, and
- to combination meter terminal ㉓
- from the lighting switch terminal ⑥
- to terminal ③ of the RH headlamp
- from the lighting switch terminal ⑨.

With power and ground supplied, the high beam headlamps illuminate.

AUTO LIGHT OPERATION

BCM is connected to the optical sensor. The optical sensor sends a signal to BCM according to outside brightness.

When the lighting switch is turned to AUTO position, ground is supplied

- to BCM terminal ⑭
- from the lighting switch terminal ④.

When ignition switch is set to ON or START and outside is darker than the prescribed level, ground is supplied

- to HID relay terminal ② and headlamp relay terminal ②
- from the BCM terminal ⑤.

HID relay and headlamp relay are energized.

Then the low beam headlamps illuminate.

And the high beam headlamps illuminate when the lighting switch is turned to HIGH (“A”) or PASS (“C”) positions.

Auto light operation allows headlamps to turn off when outside is brighter than the prescribed level.

Or the ignition switch is turned to OFF position.

For parking, license and tail lamp auto operation, refer to “PARKING, LICENSE AND TAIL LAMPS” (EL-76).

SHUT OFF DELAY

While the headlamps are lit in the auto-light operation mode, the ignition switch is turned from the “ON” to the “OFF” position. The BCM no longer receives a voltage signal at terminal ⑥⑧. This starts the auto light shut off delay timer. The timer is set based on the resistance value at BCM terminal ⑤⑦. With the timer running, the headlamps remain lit. When the timer reaches the end of its cycle, the headlamps turn off. Headlamp lighting time can be adjusted from about 0 to 3 minutes. (This function is not applicable to the tail lamps.)

THEFT WARNING SYSTEM

The theft warning system will flash the high beams if the system is triggered. Refer to “THEFT WARNING SYSTEM — IVMS” (EL-371).

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

HEADLAMP (FOR U.S.A.) — XENON TYPE —


System Description (Cont'd)

XENON HEADLAMP


Xenon type headlamp is adopted to the low beam headlamps. Xenon bulbs do not use a filament. Instead, they produce light when a high voltage current is passed between two tungsten electrodes through a mixture of xenon (an inert gas) and certain other metal halides. In addition to added lighting power, electronic control of the power supply gives the headlamps stable quality and tone color.

Following are some of the many advantage of the xenon type headlamp.

- The light produced by the headlamps is white color approximating sunlight that is easy on the eyes.
- Light output is nearly double that of halogen headlamps, affording increased area of illumination.
- The light features a high relative spectral distribution at wavelengths to the human eye is most sensitive, which means that even in the rain, more light is reflected back from the road surface toward the vehicle, for added visibility.
- Power consumption is approximately 25 percent less than halogen headlamps, reducing battery load.






Schematic



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP (FOR U.S.A.) — XENON TYPE —

Wiring Diagram — H/LAMP —






REFER TO THE FOLLOWING.
(M6), (E66) -SUPER MULTIPLE JUNCTION (SMJ)


HEADLAMP (FOR U.S.A.) — XENON TYPE —

Wiring Diagram — H/LAMP — (Cont'd)

EL-H/LAMP-03




REFER TO THE FOLLOWING.
 (M6) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUZE BLOCK-JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS




CONSULT-II (For auto light operation)

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "AUTO LIGHT SYSTEM".



- DATA MONITOR and ACTIVE TEST are available for the auto light.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses/Auto Light Operation

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

Trouble Diagnoses/Auto Light Operation
(Cont'd)

SYMPTOM CHART

PROCEDURE	DIAGNOSTIC PROCEDURE					
REFERENCE PAGE	EL-56	EL-56	EL-57	EL-58	EL-59	
	DIAGNOSTIC PROCEDURE 1 (Lighting switch "AUTO" check)	DIAGNOSTIC PROCEDURE 2 (Auto light output check)	DIAGNOSTIC PROCEDURE 3 (Optical sensor check)	DIAGNOSTIC PROCEDURE 4 (IGN input signal check)	DIAGNOSTIC PROCEDURE 5 (Illumination time control switch check)	GI MA EM LC EC
SYMPTOM						
When outside is dark, neither tail lamps nor headlamps turn on by auto light operation.	X		X	X		FE
When outside is dark, tail lamps turn on but headlamps do not turn on by auto light operation.		X				AT
When outside is dark, headlamps turn on but tail lamps do not turn on by auto light operation.		X				PD
Light does not turn off when ignition key switch is turned to "OFF". (when shut off delay is canceled.)				X		FA
When outside is bright, neither tail lamps nor headlamps turn off by auto light operation.			X			RA
Shut off delay does not work properly.				X	X	RA

BR

ST

RS

BT

HA

EL


IDX

HEADLAMP (FOR U.S.A.) — XENON TYPE —

Trouble Diagnoses/Auto Light Operation (Cont'd)

DIAGNOSTIC PROCEDURE 1

[Lighting switch (AUTO) check]



CHECK LIGHTING SWITCH (AUTO) INPUT SIGNAL.

A CONSULT-II

See "AUTO LIGHT SW" in DATA MONITOR mode.

When lighting switch is in AUTO:
AUTO LIGHT SW ON
 When lighting switch is OFF:
AUTO LIGHT SW OFF

OR


B ON BOARD

Perform On board diagnosis — Mode II (Switch monitor) for light switch. Refer to EL-255.

Refer to wiring diagram in EL-51.

- NG → Check the following.
- Lighting switch
 - Harness for open or short between BCM and lighting switch
 - Ground circuit for lighting switch

OK ↓
 Lighting switch (AUTO) is OK.



DIAGNOSTIC PROCEDURE 2 (Auto light output check)

CHECK AUTO LIGHT OUTPUT SIGNAL/CIRCUIT.

A CONSULT-II

See "HEADLAMP RELAY" and "TAIL LAMP RELAY" in ACTIVE TEST mode, and turn lighting switch to AUTO position. **Headlamp and tail lamp should turn on.**

OR

B TESTER


1. Turn the ignition switch to ON position or lighting switch to AUTO position.
2. Check voltage between BCM terminal ⑤ or ⑪ and ground.

Output condition	Voltage V
Sensor not struck by light (Determined to be "dark" by sensor)	0
Sensor struck by light	Approx. 12

Refer to wiring diagram in EL-51.

- NG → Check harness for open or short between BCM and headlamp relay or tail lamp relay.

OK ↓
 Auto light output is OK.







HEADLAMP (FOR U.S.A.) — XENON TYPE —

Trouble Diagnoses/Auto Light Operation (Cont'd)

DIAGNOSTIC PROCEDURE 3

(Optical sensor check)



CHECK OPTICAL SENSOR INPUT SIGNAL.

A CONSULT-II

See "OPTICAL SEN" in DATA MONITOR mode.

When optical sensor is struck by light:

More than 3V

When optical sensor is not struck by light:

Approx. 0.5V

B TESTER

1. Turn the ignition switch to ACC position.
2. Check voltage between BCM terminal 52 and ground.

Condition of optical sensor	Voltage V
Sensor struck by light	More than 3
Sensor not struck by light	Approx. 0.5

Refer to wiring diagram in EL-52.

OK → Optical sensor is OK.

GI

MA

EM

LC

EC

FE

AT

PD

NG

C

CHECK OPTICAL SENSOR OPEN CIRCUIT.

1. Disconnect BCM connector and optical sensor connector.
2. Check harness continuity between BCM connector and optical sensor connector.

Terminals		Continuity
BCM	Optical sensor	
52	3	Yes
52	2	
52	1	

NG → Repair harness.

FA

RA

BR

ST

RS

OK

D

CHECK OPTICAL SENSOR SHORT CIRCUIT.

Check harness continuity between BCM connector and body ground.

Terminals	Continuity
52 - ground	No
52 - ground	
52 - ground	

NG → Repair harness.

BT

HA

EL



IDX

OK

Replace optical sensor.

Trouble Diagnoses/Auto Light Operation (Cont'd)

DIAGNOSTIC PROCEDURE 4 (IGN input signal check)



CHECK ACC AND IGN INPUT SIGNAL.

A CONSULT-II

See "IGN ON SW" in DATA MONITOR mode.

When ignition switch is ON:

IGN ON SW ON

When ignition switch is OFF:

IGN ON SW OFF

OR

B TESTER

Check voltage between BCM terminal ⑥ and ground.

Terminals	Ignition switch position			
	OFF	ACC	ON	START
⑥ - Ground	Approx. 0V		Battery voltage	

Refer to wiring diagram in EL-52.

OK

IGN input signal is OK.

NG




Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM

Trouble Diagnoses/Auto Light Operation (Cont'd)

DIAGNOSTIC PROCEDURE 5

(Illumination time control switch check)



CHECK ILLUMINATION TIME CONTROL SWITCH INPUT SIGNAL.

A CONSULT-II

See "ILLUM TIME" in DATA MONITOR mode.

When time control switch is fully turned to short time

Approx. 0 kΩ

When time control switch is fully turned to long time

Approx. 1 kΩ

B TESTER

1. Disconnect BCM connector.
2. Check resistance between BCM terminal ⑤ and ground.

Time control switch condition	Resistance kΩ
Fully short	Approx. 0
Fully long	Approx. 1

Refer to wiring diagram in EL-52.

OK → Illumination time control switch is OK.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

C

CHECK ILLUMINATION TIME CONTROL SWITCH.


1. Disconnect illumination time control switch.
2. Check resistance between illumination time control switch terminals ① and ③.

Time control switch condition	Resistance kΩ
Fully short	Approx. 0
Fully long	Approx. 1

NG → Replace illumination time control switch.

OK →

- Check the following:
- Illumination time control switch ground circuit
 - Harness for open or short between BCM and illumination time control switch



WARNING:

- The xenon headlamp has a high-tension current generating area. Be extremely careful when removing and installing. Be certain to disconnect the battery negative cable prior to removing or installing.
- When the xenon headlamp is lit, do not touch the harness (covered with red or amber insulation), bulb itself or the bulb socket with your bare hands.
- Never service a xenon headlamp with wet hands.
- When checking body side harness with a circuit tester, be certain to disconnect the harness connector from the xenon headlamp.
- When the xenon headlamp is lit, the xenon bulb must be installed in the headlamp housing. (Never turn on xenon headlamp, if the bulb is out of the headlamp housing.)

CAUTION:

Make sure to install the bulb securely; if the xenon bulb is improperly installed in its socket, high-tension current leaks occur. This may lead to a melted bulb and/or bulb socket.

Trouble Diagnoses/Headlamp (Xenon Type)

Symptom	Possible cause	Repair order
Any beam does not illuminate.	<ol style="list-style-type: none"> 1. Lighting switch 2. Lighting switch ground circuit 3. Open in the HID relay and headlamp relay circuits 	<ol style="list-style-type: none"> 1. Check lighting switch. 2. Check lighting switch ground circuit. 3. Check harness between HID relay terminal ② /headlamp relay terminal ② and lighting switch terminal ⑩/BCM terminal ⑤ .
Neither high beam illuminates, but low beam operates.	<ol style="list-style-type: none"> 1. Headlamp relay 2. Open in the headlamp relay circuit 	<ol style="list-style-type: none"> 1. Check headlamp relay. 2. Check harness between headlamp relay terminal ② and lighting switch terminal ⑩/BCM terminal ⑤ .
Neither low beam illuminates, but high beam operates.	<ol style="list-style-type: none"> 1. HID relay 2. Open in the HID relay circuit 	<ol style="list-style-type: none"> 1. Check HID relay. 2. Check harness between HID relay terminal ② and lighting switch terminal ⑩/BCM terminal ⑤ .
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. 15A fuse 2. Bulb 3. Headlamp relay 4. Open in LH high beam circuit 5. Lighting switch 	<ol style="list-style-type: none"> 1. Check 15A fuse. (No. 54, located in fuse, fusible link and relay box.) Verify battery positive voltage is present at terminal ⑦ of headlamp relay. 2. Check bulb. 3. Check headlamp relay. 4-1. Check harness between headlamp relay terminal ⑥ and LH headlamp for open or short circuit. 4-2. Check harness between lighting switch terminal ⑥ and LH headlamp for open or short circuit. 5. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. 20A fuse 2. HID relay 3. Open in LH low beam circuit 4. Xenon bulb 5. HID control unit 6. Booster 	<ol style="list-style-type: none"> 1. Check 20A fuse. (No. 61, located in fuse, fusible link and relay box.) Verify battery positive voltage is present at terminal ③ of HID relay. 2. Check HID relay. 3. Check harness between HID relay terminal ⑤ and LH headlamp and harness between LH headlamp and ground for open or short circuit. (Before inspecting headlamp terminal, disconnect headlamp connector with ignition switch "OFF" position.) 4. Replace the xenon bulb with the other side bulb or new one. (If headlamps illuminate correctly, replace the bulb.) 5. Replace the HID control unit with the other side control unit or new one. (If headlamps illuminate correctly, replace the control unit.) 6. Replace booster as a headlamp assembly.

HEADLAMP (FOR U.S.A.) — XENON TYPE —

Trouble Diagnoses/Headlamp (Xenon Type) (Cont'd)

Symptom	Possible cause	Repair order
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. 15A fuse 2. Bulb 3. Headlamp relay 4. Open in RH high beam circuit 5. Lighting switch 	<ol style="list-style-type: none"> 1. Check 15A fuse. (No. 53, located in fuse, fusible link and relay box.) Verify battery positive voltage is present at terminal 5 of headlamp relay. 2. Check bulb. 3. Check headlamp relay. 4-1. Check harness between headlamp relay terminal 3 and RH headlamp for open or short circuit. 4-2. Check harness between lighting switch terminal 9 and RH headlamp for open or short circuit. 5. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. 20A fuse 2. HID relay 3. Open in RH low beam circuit 4. Xenon bulb 5. HID control unit 6. Booster 	<ol style="list-style-type: none"> 1. Check 20A fuse. (No. 59, located in fuse, fusible link and relay box.) Verify battery positive voltage is present at terminal 6 of HID relay. 2. Check HID relay. 3. Check harness between HID relay terminal 7 and RH headlamp and harness between RH headlamp and ground for an open circuit. (Before inspecting headlamp terminal, disconnect headlamp connector with ignition switch in "OFF" position.) 4. Replace the xenon bulb with the other side bulb or new one. (If headlamps illuminate correctly, replace the bulb.) 5. Replace the HID control unit with the other side control unit or new one. (If headlamps illuminate correctly, replace the control unit.) 6. Replace booster as a headlamp assembly.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2-1. Check harness between lighting switch and combination meter for an open circuit. 2-2. Verify battery positive voltage is present at terminal 22 of combination meter, when high beam illuminates.

HID: High Intensity Discharge

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


Bulb Replacement/Xenon Type

CAUTION:

- After replacing a new xenon bulb, be sure to make aiming adjustments.
 - Hold only the plastic base when handling the bulb. Never touch the glass envelope.
 - Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.
1. Disconnect negative battery cable.
 2. Disconnect headlamp connector.
 3. Remove headlamp assembly.


WARNING:

Never service a xenon headlamp with wet hands.



XENON BULB (LOW BEAM)


1. Remove tamper proof torx bolt (size: T20), then remove headlamp seal cover.



2. Turn bulb socket counterclockwise with keep pushing, then remove it.

HEADLAMP (FOR U.S.A.) — XENON TYPE —


Bulb Replacement/Xenon Type (Cont'd)



3. Release retaining pin.
4. Remove the xenon bulb.
5. Install in the reverse order of removal.


CAUTION:

- When disposing of the xenon bulb, do not break it; always dispose of it as is.
- Make sure to install the bulb securely; if the xenon bulb is improperly installed in its socket, high-tension current leaks occur. This may lead to a melted bulb and/or bulb socket.



HIGH BEAM

1. Remove headlamp seal cover by turning it counterclockwise.
2. Disconnect bulb connector.
3. Release retaining pin.
4. Remove the bulb.
5. Install in the reverse order of removal.



Aiming Adjustment/Xenon Type



LOW BEAM

1. Turn headlamp low beam on.
 2. Use adjusting screw to perform aiming adjustment.
- First tighten the adjusting screw all the way and then make adjustment by loosening the screw.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


HEADLAMP (FOR U.S.A.) — XENON TYPE —

Aiming Adjustment/Xenon Type (Cont'd)



CAUTION:
Be sure aiming switch is set to "0" when performing aiming adjustment.

Component Parts and Harness Connector Location



SEL857W

Daytime Light System/System Description

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

Power is supplied at all times

- through 15A fuse (No. 54, located in the fuse, fusible link and relay box)
- to headlamp relay terminal ①, and
- to headlamp relay terminal ⑦, and
- through 15A fuse (No. 53, located in the fuse, fusible link and relay box)
- to headlamp relay terminal ⑤.

Power is also supplied at all times

- to HID relay terminal ①, and
- through 20A fuse (No. 61, located in the fuse, fusible link and relay box)
- to HID relay terminal ③, and
- through 20A fuse (No. 59, located in the fuse, fusible link and relay box)
- to HID relay terminal ⑥, and

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 20, located in the fuse block (J/B)]
- to daytime light control unit terminal ③.

With the ignition switch in the START position, power is supplied

- through 7.5A fuse [No. 34, located in the fuse block (J/B)]
- to daytime light control unit terminal ②.

Ground is supplied to daytime light control unit terminal ⑩ through body grounds (E22) and (E36).

HEADLAMP SWITCH OPERATION

When the lighting switch is turned to 2ND or PASS ("C") positions, ground is supplied

- to headlamp relay terminal ② and HID relay terminal ②
- from the lighting switch terminal ⑫.

Headlamp relay is then energized, and power is supplied

- from the headlamp relay terminal ⑥
- to combination meter terminal ⑳ for the HIGH BEAM indicator and
- through daytime light control unit terminals ⑤ and ⑥

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

**Daytime Light System/System Description
(Cont'd)**

- to terminal ① of the LH headlamp.
- Power is also supplied
- from the headlamp relay terminal ③
 - through daytime light control unit terminals ④ and ⑦
 - to terminal ① of the RH headlamp.

HID relay is also energized, and power is supplied.

- from the HID relay terminal ⑤
- to terminal ② LH headlamp

Power is also supplied

- from the HID relay terminal ⑦
- to terminal ② RH headlamp

Ground is supplied at all times.

- to LH headlamp terminal ④ and RH headlamp terminal ④
- through body ground (E22) and (E36).

Low beam operation

When the lighting switch is turned to 2ND (LOW or HI) or PASS (“C”) position, the low beam headlamps illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is turned to 2ND and HIGH (“A”) or PASS (“C”) position, ground is supplied

- to terminal ③ of LH headlamp and combination meter terminal ② for the HIGH BEAM indicator
- through daytime light control unit terminals ⑩ and ⑬
- through lighting switch terminals ⑨ and ⑧
- through body grounds (E22) and (E36).

Ground is also supplied

- to terminal ③ of RH headlamp
- through daytime light control unit terminals ⑨ and ⑭
- through lighting switch terminals ⑥ and ⑤
- through body grounds (E22) and (E36).

With power and ground supplied, the high beam headlamps illuminate.

XENON HEADLAMP

For description regarding xenon headlamp, refer to EL-48.

AUTO LIGHT OPERATION

For auto light operation, refer to EL-47.

DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- through daytime light control unit terminal ⑦
- to terminal ① of RH headlamp
- through terminal ③ of RH headlamp
- to daytime light control unit terminal ⑨
- through daytime light control unit terminal ⑥
- to terminal ① of LH headlamp.

Ground is supplied to terminal ③ of LH headlamp.

- through daytime light control unit terminals ⑩ and ⑬
- through body grounds (E22) and (E36).

Because the high beam headlamps are now wired in series, they operate at half illumination.

Operation (Daytime light system with xenon headlamp)

After starting the engine with the lighting switch in the “OFF” or “1ST” position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	○	X	X	○	○	X	○	△*	△*	○	△*	△*	○	○	X	○
	Low beam	X	X	X	X	X	X	○	○	○	X	X	X	X	X	X	○	○	○
Parking and tail lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○
License and instrument illumination lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○

○ : Lamp “ON”

X : Lamp “OFF”

△ : Lamp dims.

□ : Added functions

*: When starting the engine with the parking brake released, the daytime light will come ON.
 When starting the engine with the parking brake pulled, the daytime light won't come ON.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL


IDX

Schematic



HEADLAMP (FOR CANADA) — XENON TYPE —

Wiring Diagram — DTRL —



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA





EL

IDX

HEADLAMP (FOR CANADA) — XENON TYPE —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02





REFER TO THE FOLLOWING.
 (M6), (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (E64) -FUSE BLOCK-JUNCTION BOX (J/B)

HEADLAMP (FOR CANADA) — XENON TYPE —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-03



REFER TO THE FOLLOWING.
 (E66), (E81) -SUPER MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Trouble Diagnoses

DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE


(Data are reference values.)

Terminal No.	Wire color	Item	Condition		Judgement standard
1	W/R	Alternator		When turning ignition switch to "ON"	Less than 1V
				When engine is running	Battery voltage
				When turning ignition switch to "OFF"	Less than 1V
2	SB	Start signal		When turning ignition switch to "ST"	Battery voltage
				When turning ignition switch to "ON" from "ST"	Less than 1V
				When turning ignition switch to "OFF"	Less than 1V
3	R/G	Power source		When turning ignition switch to "ON"	Battery voltage
				When turning ignition switch to "ST"	Battery voltage
				When turning ignition switch to "OFF"	Less than 1V
4	G	Power source		When lighting switch is turned to "2ND" or PASS ("C") position	Battery voltage
				Except the above	1V or less
5	L/W	Power source		When lighting switch is turned to "2ND" or PASS ("C") position	Battery voltage
				Except the above	Less than 1V
6	L/R	LH head-lamp control		When lighting switch is turned to "2ND" or PASS ("C") position	Battery voltage
				When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
				Except the above	Less than 1V
7	L/Y	RH head-lamp control		When lighting switch is turned to "2ND" or PASS ("C") position	Battery voltage
				When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Battery voltage
				Except the above	Less than 1V

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP (FOR CANADA) — XENON TYPE —

Trouble Diagnoses (Cont'd)

Terminal No.	Wire color	Item	Condition		Judgement standard
9	L	RH high beam (Ground)		When turning lighting switch to "2ND" and HIGH ("A") or PASS ("C") positions	Less than 1V
				When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
10	R	LH high beam (Ground)		When turning lighting switch to "2ND" and HIGH ("A") or PASS ("C") positions	Less than 1V
				When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Less than 1V
13	W	Lighting switch (LH high beam)		When turning lighting switch HIGH ("A") or PASS ("C") position	Less than 1V
14	B/W	Lighting switch (RH high beam)		When turning lighting switch HIGH ("A") or PASS ("C") position	Less than 1V
16	B	Ground		—	—
17	OR	Parking brake switch		When parking brake is released	Battery voltage
				When parking brake is set	Less than 1.5V

Bulb Replacement/Xenon Type

For bulb replacement, refer to EL-62.


Aiming Adjustment/Xenon Type

For aiming adjustment, refer to EL-63.


HEADLAMP — Headlamp Aiming Control —

Wiring Diagram — H/AIM —

EL-H/AIM-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA



REFER TO THE FOLLOWING.
E66, E81 -SUPER MULTIPLE JUNCTION (SMJ)

EL
IDX

System Description

Power is supplied at all times

- to tail lamp relay terminals ① and ⑥
- through 15A fuse [No. ⑥3, located in the fuse, fusible link and relay box].

Ground is supplied

- to the lighting switch terminals ⑤ and ⑧
- through body grounds ②22 and ②36.

SWITCH OPERATION

When the lighting switch is turned to 1ST or 2ND position, ground is supplied

- to tail lamp relay terminal ②
- from the lighting switch terminal ⑪.

Tail lamp relay is then energized, and power is supplied

- from tail lamp relay terminal ⑦
- to power terminals of parking, license and tail lamps through stop and tail lamp sensor terminal ⑧.

With power supplied, parking, license and tail lamps illuminate.

AUTO LIGHT OPERATION

BCM is connected to the optical sensor. The optical sensor sends a signal to BCM according to outside brightness.

When the lighting switch is turned to AUTO position, ground is supplied

- to BCM terminal ⑭
- from the lighting switch terminal ④2.

When ignition switch is set to ON or START and outside is darker than the prescribed level, ground is supplied

- to tail lamp relay terminal ②
- from the BCM terminal ⑪.

Tail lamp relay is then energized, and parking, license and tail lamps illuminate.

Auto light operation allows these lamps to turn off when outside is brighter than the prescribed level.

Or the ignition switch is turned to the OFF position.

For detailed wiring diagram of auto light, refer to "HEADLAMP" (EL-50).


TAIL AND STOP WARNING LAMP

When one of the stop lamp bulbs is burned out with the stop lamp switch depressed, or one of the tail bulbs is burned out with the lighting switch in the 1ST or 2ND position, the tail and stop warning lamp illuminate. For details, refer to "WARNING LAMPS" (EL-116).

PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L —


EL-TAIL/L-01



(US) : For U.S.A.
 (CA) : For Canada
 *1 LW: (US) *2 W/PU: (US)
 LY: (CA) Y/R: (CA)

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA

Next page




REFER TO THE FOLLOWING.
 (M4), (E66), (E81) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

EL
 IDX

PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-02



Trouble Diagnoses

Symptom	Possible cause	Repair order
Parking, license and tail lamps do not operate.	1. 15A fuse 2. Tail lamp relay 3. Lighting switch 4. Open in tail lamp relay circuit 5. Lighting switch ground circuit	1. Check 15A fuse (No. 63, located in fuse, fusible link and relay box). 2. Check tail lamp relay. 3. Check lighting switch. 4-1. Check harness between tail lamp relay terminal ② and lighting switch terminal ⑩ for an open circuit. 4-2. Check harness between tail lamp relay terminal ⑦ and joint connector-13 for open circuit. 5. Check lighting switch ground circuit.
Individual parking or license lamps do not operate.	1. Bulb 2. Lamp ground 3. Open circuit	1. Check bulb. 2. Check lamp ground circuit. 3. Check harness between power supply terminal of lamp and tail lamp relay terminal ⑦ for an open circuit.
Tail lamps do not operate. (See note.)	1. Bulb 2. Lamp ground 3. Stop and tail lamp sensor - related circuit	1. Check bulb. 2. Check lamp ground circuit. 3. Check stop and tail lamp sensor. (Refer to EL-126.)
Auto light malfunctioning.	—	Refer to trouble diagnoses in "HEADLAMP" (EL-54).

Note: If one of the tail lamp bulbs is burned out or if one of the circuits between the tail lamps and stop and tail lamp sensor is open, tail and stop warning lamp in the combination meter will illuminate with the lighting switch in the 1ST or 2ND position.



GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

STOP LAMP

Wiring Diagram — STOP/L —

NOTE: For "System Description" and "Trouble Diagnoses", refer to "PARKING, LICENSE AND TAIL LAMPS" (EL-76).

EL-STOP/L-01




REFER TO THE FOLLOWING.
 (M4) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)

BACK-UP LAMP


Wiring Diagram — BACK/L —

EL-BACK/L-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL
IDX



REFER TO THE FOLLOWING.
 B1 - FUSE BLOCK-JUNCTION BOX (J/B)

System Description

Power is supplied at all times

- to fog lamp relay terminal ③
- through 15A fuse [No. 40], located in the fuse block (J/B)],
- to headlamp relay terminal ⑤
- through 15A fuse (No. 53, located in the fuse, fusible link and relay box) and
- to headlamp relay terminals ① and ⑦
- through 15A fuse (No. 54, located in the fuse, fusible link and relay box).

When the lighting switch in the 2ND position, ground is supplied

- to headlamp relay terminal ②
- through lighting switch terminal ⑫
- to lighting switch terminal ⑧
- through body grounds E22 and E36.

The headlamp relay is energized and power is supplied

- to fog lamp relay terminal ②
- from headlamp relay terminal ③ .

FOG LAMP OPERATION

The fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for fog lamp operation. With the fog lamp switch in the ON position, ground is supplied

- to fog lamp relay terminal ①
- through front fog lamp switch terminal ③①
- to front fog lamp switch terminal ③②
- through lighting switch terminal ⑩
- to lighting switch terminal ⑧
- through body grounds E22 and E36.

The fog lamp relay is energized and power is supplied


- from fog lamp relay terminal ⑤
- to terminal ① of each fog lamp.

Ground is supplied to terminal ② of each fog lamp through body grounds E22 and E36. With power and ground supplied, the fog lamps illuminate.

FRONT FOG LAMP


Wiring Diagram — F/FOG —

EL-F/FOG-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL
IDX





REFER TO THE FOLLOWING.
E81 -SUPER MULTIPLE JUNCTION (SMJ)

FRONT FOG LAMP


Wiring Diagram — F/FOG — (Cont'd)

EL-F/FOG-02



REFER TO THE FOLLOWING.
 (M4), (E66), (E81), (F63)
 -SUPER MULTIPLE JUNCTION (SMJ)
 (B2) -FUSE BLOCK-JUNCTION BOX (J/B)

FRONT FOG LAMP




Aiming Adjustment


Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- Check that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

Adjust aiming in the vertical direction by turning the adjusting screw.



- Set the distance between the screen and the center of the fog lamp lens as shown at left.
- Turn front fog lamps ON.



- Adjust front fog lamps so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown at left.
 - When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.

Bulb Specifications

Item	Wattage W
Front fog lamp	55

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

System Description

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 19], located in the fuse block (J/B)]
- to hazard switch terminal ②
- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit
- to turn signal switch terminal ①.

Ground is supplied to combination flasher unit terminal ② through body grounds (M14) and (M47).

LH turn

When the turn signal switch is moved to the L position, power is supplied from turn signal switch terminal ③ to

- front combination lamp LH terminal ③
- rear combination lamp LH terminal ②
- combination meter terminal ⑳.

Ground is supplied to the front combination lamp LH terminal ② through body grounds (E22) and (E36).

Ground is supplied to the rear combination lamp LH terminal ④ through body grounds (T12), (B22) and (B35).

Ground is supplied to combination meter terminal ⑳ through body grounds (M14) and (M47).

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH turn

When the turn signal switch is moved to the R position, power is supplied from turn signal switch terminal ② to

- front combination lamp RH terminal ③
- rear combination lamp RH terminal ②
- combination meter terminal ⑳.

Ground is supplied to the front combination lamp RH terminal ② through body grounds (E22) and (E36).

Ground is supplied to the rear combination lamp RH terminal ④ through body grounds (T12), (B22) and (B35).

Ground is supplied to combination meter terminal ⑳ through body grounds (M14) and (M47).

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal ③ through:

- 10A fuse [No. 13], located in the fuse block (J/B)].

With the hazard switch in the ON position, power is supplied

- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit
- to hazard switch terminal ④.

Ground is supplied to combination flasher unit terminal ② through body grounds (M14) and (M47).

Power is supplied through terminal ⑤ of the hazard switch to

- front combination lamp LH terminal ③
- rear combination lamp LH terminal ②
- combination meter terminal ⑳.

Power is supplied through terminal ⑥ of the hazard switch to

- front combination lamp RH terminal ③
- rear combination lamp RH terminal ②
- combination meter terminal ⑳.

Ground is supplied to terminal ② of each front combination lamp through body grounds (E22) and (E36).

Ground is supplied to terminal ④ of each rear combination lamp through body grounds (T12), (B22) and (B35).

Ground is supplied to combination meter terminal ⑳ through body grounds (M14) and (M47).

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

WITH MULTI-REMOTE CONTROL SYSTEM

Power is supplied at all times

- through 10A fuse [No. 13], located in the fuse block (J/B)]

TURN SIGNAL AND HAZARD WARNING LAMPS

System Description (Cont'd)

- to multi-remote control relay terminals ① , ③ and ⑥ .

Ground is supplied to multi-remote control relay terminal ② , when the multi-remote control system is triggered through the BCM (Body Control Module).

Refer to "MULTI-REMOTE CONTROL SYSTEM" (EL-310).

The multi-remote control relay is energized.

Power is supplied through terminal ⑤ of the multi-remote control relay

- to front combination lamp LH terminal ③ ,
- to rear combination lamp LH terminal ② and
- to combination meter terminal ②① .

Power is supplied through terminal ⑦ of the multi-remote control relay

- to front combination lamp RH terminal ③ ,
- to rear combination lamp RH terminal ② and
- to combination meter terminal ③① .

Ground is supplied to terminal ② of each front combination lamp through body grounds E22 and E36 .

Ground is supplied to terminal ④ of each rear combination lamp through body grounds T12, B22 and B35 .

Ground is supplied to combination meter terminal ③② through body grounds M14 and M47 .

With power and ground supplied, the BCM controls the flashing of the hazard warning lamps.

GI

MA

EM

LG

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX


Schematic




TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN — (Cont'd)

EL-TURN-03



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT




REFER TO THE FOLLOWING.
 (E81) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1, E62, E64, B1) -FUSE BLOCK-JUNCTION BOX (J/B)

HA
EL
IDX

Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> 1. Hazard switch 2. Combination flasher unit 3. Open in combination flasher unit circuit 	<ol style="list-style-type: none"> 1. Check hazard switch. 2. Refer to combination flasher unit check. (EL-92) 3. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 19], located in the fuse block (J/B). Turn ignition switch ON and verify battery positive voltage is present at terminal ② of hazard switch. 2. Check hazard switch. 3. Check turn signal switch. 4. Check L/B wire between combination flasher unit and turn signal switch for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> 1. 10A fuse 2. Hazard switch 3. Open in hazard switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse [No. 13], located in the fuse block (J/B). Verify battery positive voltage is present at terminal ③ of hazard switch. 2. Check hazard switch. 3. Check L/B wire between combination flasher unit and hazard switch for open circuit.
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (E22) and (E36) 3. Open in front turn signal lamp LH or RH circuit 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (E22) and (E36). 3. Check wire between fuse block and front turn signal lamp LH or RH for open circuit.
Rear turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (T12), (B22) and (B35) 3. Open in rear turn signal lamp LH or RH circuit 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (T12), (B22) and (B35). 3. Check wire between fuse block and rear turn signal lamp LH or RH for open circuit.
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> 1. Grounds (M14) and (M47) 	<ol style="list-style-type: none"> 1. Check grounds (M14) and (M47).
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Open in turn indicator circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check wire between hazard switch and combination meter (turn indicator) for open circuit.



Electrical Components Inspection

COMBINATION FLASHER UNIT CHECK

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

System Description

Power is supplied at all times

- through 15A fuse (No. 63, located in the fuse, fusible link and relay box)
- to tail lamp relay terminals ① and ⑥.

Ground is supplied to tail lamp relay terminal ②, when the lighting switch is moved to the 1ST or 2ND position. The tail lamp relay is energized.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Combination meter	N12, N14	16, 41	17, 38
Rear cigarette lighter	D45, D65	3	— (Unit ground)
Rear ashtray	D44, D64	1	2
Glove box lamp	M26	1	2
TCS switch	N7	5	6
Active damper suspension select switch	N5	7	8
Audio unit	N20	8	7
Illumination time control switch	N8	2	4
Front cigarette lighter	N6	2	— (Unit ground)
Headlamp aiming switch	N4	3	4
A/T device	M36	3	4
Front power window main switch	D12	2	1
Auto anti-dazzling inside mirror	R4	3	4
IVCS switch	R10	2	12
Driver's door control unit	D13	9	2
Passenger door control unit	D29	9	2
Clock	N28	3	2
A/C control unit	N17	1	4
Hazard switch	N22	7	8
Telephone switch	N25	24	23
Rear sunshade switch	N30	4	5
Illumination control switch	N23	1	5

The ground for all of the components except for rear ashtray, and rear cigarette lighter, glove box lamp and front cigarette lighter are controlled through terminals ④ and ⑤ of the illumination control switch and body grounds M14 and M47.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

ILLUMINATION


Schematic




ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-03




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-04



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M15), (D13), (D29)
W W W

9	3	1
8	7	6
5	4	2

(M36)
W

1	2	3	4	5	6
---	---	---	---	---	---

(M64)
W

2	4	3	1
---	---	---	---

(R4)
W

12	10	4	2
11	9	8	7
6	5	3	1

(R10)
W

1	2
---	---


(D12)
W

REFER TO THE FOLLOWING.
(M6), (D1), (D21) -SUPER
MULTIPLE JUNCTION (SMJ)

ILLUMINATION


Wiring Diagram — ILL — (Cont'd)

EL-ILL-05



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

HA
EL
IDX







REFER TO THE FOLLOWING.
(M6) -SUPER MULTIPLE JUNCTION (SMJ)




TRUNK ROOM AND VANITY MIRROR LAMP

Wiring Diagram — INT/L —


EL-INT/L-01



REFER TO THE FOLLOWING.
 (M1), (B1) - FUSE BLOCK-JUNCTION BOX (J/B)



Component Parts and Harness Connector Location



GI
MA
EM
LC
EC
FE
AT

SEL858W


System Description

UNIFIED CONTROL METER

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit combined with speedometer.
- Digital meter is adopted for odo/trip meter.*
*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

FA
RA
BR
ST

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER



RS
BT
HA
EL
IDX

SEL253V

Note: Turn ignition switch to the "ON" position to operate odo/trip meter.

METER AND GAUGES

System Description (Cont'd)

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 4], located in the fuse block (J/B)
- to combination meter terminal 41.

Ground is supplied

- to combination meter terminal 39
- through body grounds M14 and M47.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 8 for the fuel gauge
- from terminal 5 of the fuel level sensor unit
- through terminal 4 of the fuel level sensor unit and
- through ECM terminal 129.

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 7 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal 52 of the ECM
- to combination meter terminal 13 for the tachometer.

SPEEDOMETER

The vehicle speed sensor sends a voltage signal to the combination meter for the speedometer.



The voltage signal is sent

- to combination meter terminals 12 and 14 for the speedometer
- from terminals 1 and 2 of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.

METER AND GAUGES

Combination Meter







GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

METER AND GAUGES

Wiring Diagram — METER —

EL-METER-01




REFER TO THE FOLLOWING.
 (M6), (F63) - SUPER MULTIPLE JUNCTION (SMJ)
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B)
 (F69) - ELECTRICAL UNITS


METER AND GAUGES

Wiring Diagram — METER — (Cont'd)

EL-METER-02



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



REFER TO THE FOLLOWING.
 (M4), (M6), (F63), (F64)
 -SUPER MULTIPLE JUNCTION (SMJ)
 (F69) -ELECTRICAL UNITS


Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

DIAGNOSIS FUNCTION

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.

HOW TO ALTERNATE DIAGNOSIS MODE


1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
2. Turn ignition switch to OFF.
3. Turn ignition switch to ON when pushing odo/trip meter switch.
4. Confirm that trip meter indicates "000.0".
5. Push odo/trip meter switch more than three times within 5 seconds.



6. All odo/trip meter segments should be turned on.

NOTE: If some segments are not turned on, speedometer (unified meter control unit) with odo/trip meter should be replaced.

At this point, the unified control meter is turned to diagnosis mode.



7. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

NOTE: It takes about 1 minute for indication of fuel gauge to become stable.

Flexible Print Circuit (FPC)

Tachometer, fuel gauge and water temperature gauge are connected with unified meter control unit (speedometer) by Flexible Print Circuit (FPC) connector. When replace or remove and install unified control unit (speedometer), disconnect and connect FPC connector according to the following steps.

GI

MA


EM

LC

EC

FE


AT



DISCONNECT

1. Open connector cover.
2. Release connector lock by holding both ends of it and pulling it up.
3. Disconnect FPC by pulling it up.

PD



CONNECT

1. Insert FPC into connector and lock connector pushing FPC downward.
2. Check secure connection of FPC.
3. Check continuity of check land terminal for secure connection of FPC.

Resistance: 0Ω

4. Close connector cover.

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses

PRELIMINARY CHECK



METER AND GAUGES

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

Symptom chart 1 (Malfunction is indicated in Diagnosis mode)

Symptom	Possible causes	Repair order
Speedometer and/or odo/trip meter indicate(s) malfunction in Diagnosis mode.	<ul style="list-style-type: none"> Speedometer (Unified meter control unit) 	<ul style="list-style-type: none"> Replace speedometer (unified meter control unit).
Multiple meter/gauge indicate malfunction in Diagnosis mode.		
One of tachometer/fuel gauge/water temp. gauge indicates malfunction in Diagnosis mode.	<ul style="list-style-type: none"> Meter/Gauge Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check resistance of meter/gauge indicating malfunction. If the resistance is NG, replace the meter/gauge. Refer to "METER/GAUGE RESISTANCE CHECK", EL-112. If the resistance is OK, replace speedometer (unified meter control unit).


GI
MA
EM
LC

Symptom chart 2 (No malfunction is indicated in Diagnosis mode)

Symptom	Possible causes	Repair order
Speedometer and odo/trip meter are malfunctioning.	<ol style="list-style-type: none"> Sensor <ul style="list-style-type: none"> Speedometer, Odo/Trip meter FPC connector Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check vehicle speed sensor. INSPECTION/VEHICLE SPEED SENSOR (Refer to EL-110.) Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-107. Replace speedometer (unified meter control unit).
Multiple meter/gauge are malfunctioning. (except speedometer, odo/trip meter)	<ol style="list-style-type: none"> FPC connector Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-107. Replace speedometer (unified meter control unit).
One of tachometer/fuel gauge/water temp. gauge is malfunctioning.	<ol style="list-style-type: none"> Sensor/Engine revolution signal <ul style="list-style-type: none"> Tachometer Fuel gauge Water temp. gauge FPC connector Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check the sensor for malfunctioning meter/gauge. INSPECTION/ENGINE REVOLUTION SIGNAL (Refer to EL-111.) INSPECTION/FUEL LEVEL SENSOR UNIT (Refer to EL-111.) INSPECTION/THERMAL TRANSMITTER (Refer to EL-112.) Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-107. Replace speedometer (unified meter control unit).

EC
FE
AT
PD
FA
RA
BR

Before starting trouble diagnoses above, perform PRELIMINARY CHECK, EL-108.



POWER SUPPLY AND GROUND CIRCUIT CHECK

Power supply circuit check

Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
Ⓜ	Ground	Battery voltage	Battery voltage	Battery voltage
Ⓜ	Ground	0V	0V	Battery voltage

If NG, check the following.


- 7.5A fuse [No. 4], located in fuse block (J/B)
- 10A fuse [No. 28], located in fuse block (J/B)
- Harness for open or short between fuse and combination meter

EL
IDX


METER AND GAUGES

Trouble Diagnoses (Cont'd)



Ground circuit check



Terminals	Continuity
③⑨ - Ground	Yes




INSPECTION/VEHICLE SPEED SENSOR



METER AND GAUGES

Trouble Diagnoses (Cont'd) INSPECTION/ENGINE REVOLUTION SIGNAL



A

CHECK ECM OUTPUT.

1. Start engine.
2. Check voltage between combination meter terminal ⑬ and ground at idle and 2,000 rpm.


Higher rpm = Higher voltage
Lower rpm = Lower voltage
Voltage should change with rpm.

OK → Engine revolution signal is OK.

NG

Check the following.

- Harness for open or short between ECM and combination meter



INSPECTION/FUEL LEVEL SENSOR UNIT

A

CHECK GROUND CIRCUIT FOR FUEL LEVEL SENSOR UNIT.

Check harness continuity between fuel level sensor unit terminal ④ and ground.
Continuity should exist.


NG → Check harness for open or short between ECM and fuel level sensor unit.

OK

CHECK FUEL LEVEL SENSOR UNIT.

Refer to "FUEL LEVEL SENSOR UNIT CHECK" (EL-113).

NG → Repair or replace. Refer to FE section. ("FUEL SYSTEM")



B

CHECK HARNESS FOR OPEN OR SHORT.

1. Disconnect combination meter connector and fuel level sensor unit connector.
2. Check continuity between combination meter terminal ⑧ and fuel level sensor unit terminal ⑤.

Continuity should exist.

3. Check continuity between combination meter terminal ⑧ and ground.

Continuity should not exist.

NG → Repair harness or connector.


OK

Fuel level sensor unit is OK.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

METER AND GAUGES

Trouble Diagnoses (Cont'd) INSPECTION/THERMAL TRANSMITTER



CHECK THERMAL TRANSMITTER. Refer to "THERMAL TRANSMITTER CHECK" (EL-113).

NG → Repair or replace.

OK

A

CHECK HARNESS FOR OPEN OR SHORT.

1. Disconnect combination meter connector and thermal transmitter connector.
2. Check continuity between combination meter terminal ⑦ and thermal transmitter terminal ①.

Continuity should exist.

3. Check continuity between combination meter terminal ⑦ and ground.

Continuity should not exist.

NG → Repair harness or connector.

OK


Thermal transmitter is OK.

Electrical Components Inspection

METER/GAUGE RESISTANCE CHECK

1. Disconnect FPC connector. Refer to "Flexible Print Circuit (FPC)" (EL-107).
2. Check resistance between installation screws of meter/gauge after removing meter/gauge.

Screws		Resistance Ω
Tachometer	Fuel/Temp. gauge	
A - C	A - C	Approx. 70 - Approx. 140
B - D	B - C	Approx. 90 - Approx. 170




METER AND GAUGES

Electrical Components Inspection (Cont'd)

FUEL LEVEL SENSOR UNIT CHECK

- For removal, refer to FE section "FUEL SYSTEM".
- Check the resistance between terminals ⑤ and ④.




Ohmmeter		Float position		Resistance value Ω
(+)	(-)	mm (in)		
⑤	④	*3	Full	70 (2.76)
		*2	1/2	189 (7.44)
		*1	Empty	308 (12.13)

*1 and *3: When float rod is in contact with stopper.


THERMAL TRANSMITTER CHECK

Check the resistance between the terminals of thermal transmitter and body ground.



Water temperature	Resistance
60°C (140°F)	Approx. 170 - 210Ω
100°C (212°F)	Approx. 47 - 53Ω

OIL PRESSURE SWITCH CHECK




	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 20 - 29 (0.2 - 0.3, 3 - 4)	NO
Engine stop	Less than 20 - 29 (0.2 - 0.3, 3 - 4)	YES

Check the continuity between the terminals of oil pressure switch and body ground.

VEHICLE SPEED SENSOR SIGNAL CHECK


- Remove vehicle speed sensor from transmission.
- Turn vehicle speed sensor pinion quickly with fingers and measure voltage across ② and ①.



DIODE CHECK

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

METER AND GAUGES

Electrical Components Inspection (Cont'd)



- Diodes for warning lamps are built into the combination meter printed circuit.

System Description

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 4], located in the fuse block (J/B)]
- to combination meter terminal 41.

Ground is supplied

- to combination meter terminal 39 and
- A/T device (OD control switch) terminal 2
- through body grounds M14 and M47.

Ground is supplied

- to fuel level sensor unit terminal 4
- through ECM terminal 129.

Ground is supplied

- seat belt buckle switch terminal 14
- through body grounds B22 and B35.

Ground is supplied

- to brake fluid level switch terminal 2 and
- washer level switch terminal 2
- through body grounds E22 and E36.

AIR BAG WARNING LAMP

During prove out or when an air bag malfunction occurs, the ground path is interrupted

- from the air bag diagnosis sensor unit terminal 15
- to combination meter terminal 6.

Ground is supplied

- through combination meter terminal 39.

With power and ground supplied, the air bag warning lamp (LEDs) illuminate.

For further information, refer to RS section ("TROUBLE DIAGNOSES").

DOOR WARNING LAMP

Door warning lamp is controlled by BCM.

When one of the passenger door is opened, ground is supplied to the BCM terminals 28, 32, 33 or 37.

And then ground is supplied

- to combination meter terminal 35
- from BCM terminal 111.

With power and ground supplied, the door warning lamp illuminates.

ACTIVE DAMPER INDICATOR LAMP (SPORT)

When an active damper suspension system malfunction occurs, or "SPORT" mode is selected by active damper suspension select switch, ground is supplied

- to combination meter terminal 2
- from active damper suspension control unit terminal 16.

With power and ground supplied, the active damper indicator lamp (SPORT) blinks or illuminates.

For further information, refer to FA section ("TROUBLE DIAGNOSES FOR ACTIVE DAMPER SUSPENSION").

LOW OIL PRESSURE WARNING LAMP

Low oil pressure causes oil pressure switch terminal 1 to provide ground to combination meter terminal 33.

With power and ground supplied, the low oil pressure warning lamp illuminates.

CHARGE WARNING LAMP

During prove out or when a alternator malfunction occurs, ground is supplied

- to combination meter terminals 31 and 40
- from alternator terminal 3.

With power and ground supplied, the charge warning lamp and brake lamp illuminate.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

WARNING LAMPS

System Description (Cont'd)

LOW WASHER LEVEL WARNING LAMP

When the washer fluid level is low, ground is supplied

- to combination meter terminal ⑤
- from washer fluid level switch terminal ①.

With power and ground supplied, the low washer level warning lamp illuminates.

OD OFF WARNING LAMP

When an A/T system malfunction occurs, or OD control switch is in OFF position, ground is supplied

- to combination meter terminal ③⑦
- from TCM (transmission control module) terminal ③.

With power and ground supplied, the OD warning lamp blinks or illuminates.

For further information, refer to AT section ("TROUBLE DIAGNOSES").

LOW FUEL LEVEL WARNING LAMP

The amount of fuel in the fuel tank is determined by the fuel level sensor in the fuel tank. A signal is sent from fuel level sensor unit terminal ⑥ to combination meter terminal ③. The fuel level sensor will illuminate the low fuel level warning lamp when the fuel level is low.

With power and ground supplied, the low fuel level warning lamp illuminates.

ABS WARNING LAMP

When an ABS malfunction occurs, ground is supplied

- to combination meter terminal ⑨
- from ABS/TCS control unit terminal ②②.

With power and ground supplied, the ABS warning lamp illuminates.

For further information, refer to BR section ("TROUBLE DIAGNOSES").

TCS OFF WARNING LAMP

When TCS off switch is in OFF position, or an ABS/TCS malfunction occurs, ground is supplied

- to combination meter terminal ①
- from ABS/TCS control unit terminal ①①.

With power and ground supplied, the TCS off warning lamp illuminates.

For further information, refer to BR section ("TROUBLE DIAGNOSES").

SLIP WARNING LAMP

When TCS is in operation, or a TCS malfunction occurs, ground is supplied

- to combination meter terminal ④
- from ABS/TCS control unit terminal ①⑩.

With power and ground supplied, the slip warning lamp illuminates.

For further information, refer to BR section ("TROUBLE DIAGNOSES").

SEAT BELT WARNING LAMP

When the driver's seat belt is unfastened, ground is supplied

- to air bag diagnoses sensor unit terminal ②②
- from seat belt buckle switch terminal ④①.

And then ground is supplied

- to combination meter terminal ③⑥
- from air bag diagnoses sensor unit terminal ①⑥.

With power and ground supplied, the seat belt warning lamp illuminates.

BRAKE WARNING LAMP

When the parking brake is applied, or the brake fluid level is low, ground is supplied

- to combination meter terminal ③④
- from parking brake switch terminal ①, or
- brake fluid level switch terminal ①.

With power and ground supplied, the brake warning lamp illuminates.

TAIL AND STOP WARNING LAMP

When one of the stop lamp bulbs is burned out with the stop lamp switch depressed, or one of the tail lamp bulbs is burned out with the lighting switch in the 1ST or 2ND position, ground is supplied.

- to combination meter terminal ③②
- from stop and tail lamp sensor terminal ③.

With power and ground is supplied, the tail and stop lamp warning lamp illuminates.

WARNING LAMPS

System Description (Cont'd)

MALFUNCTION INDICATOR LAMP

During prove out or when an engine control malfunction occurs, ground is supplied

- to combination meter terminal ④2
- from ECM terminal ④8 .

With power and ground supplied, the malfunction indicator lamp illuminates.

For further information, refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

WARNING LAMPS

Schematic



WARNING LAMPS

Wiring Diagram — WARN —

EL-WARN-01

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST



RS

BT

HA

EL

IDX






REFER TO THE FOLLOWING.

- M6 B4 -SUPER MULTIPLE JUNCTION (SMJ)
- M1 -FUSE BLOCK-JUNCTION BOX (J/B)
- M22 -ELECTRICAL UNITS

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-02




REFER TO THE FOLLOWING.
 (M4), (M6), (E66) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (B9) -ELECTRICAL UNITS

WARNING LAMPS


Wiring Diagram — WARN — (Cont'd)

EL-WARN-03



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

HA
EL
IDX




REFER TO THE FOLLOWING.
 (M4), (M6), (M50), (F64)
 -SUPER MULTIPLE JUNCTION (SMJ)
 (F69), (B103) -ELECTRICAL UNITS

* : This connector is not shown in "HARNES LAYOUT", EL section.

WARNING LAMPS


Wiring Diagram — WARN — (Cont'd)

EL-WARN-04




To EL-WARN-02

US : For U.S.A.
CA : For Canada



REFER TO THE FOLLOWING.
 (M4), (M6), (E66), (F63)
 -SUPER MULTIPLE JUNCTION (SMJ)
 (F69) -ELECTRICAL UNITS


WARNING LAMPS




CONSULT-II (For door warning lamp)

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "DOOR OPEN WARNING".



- DATA MONITOR and ACTIVE TEST are available for door open warning lamp.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses/Door Warning Lamp

WORK FLOW



NOTICE:


- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B).

WARNING LAMPS

Trouble Diagnoses/Door Warning Lamp (Cont'd)

DIAGNOSTIC PROCEDURE

SYMPTOM: Door warning lamp is not operating correctly.



CHECK WARNING LAMP OPERATION.

A CONSULT-II

Perform "DR OPN WARN LAMP" in ACTIVE TEST mode.
Check warning lamp operation.
Warning lamp should illuminate.


NG →

OR

Check the following.

- Bulb
- Power supply circuit for warning lamp
- Harness for open or short between BCM and warning lamp

GI
MA
EM
LC
EC
FE



B DISCONNECT

1. Disconnect BCM connector.
2. Turn ignition switch to "ON" position.
3. Apply ground to BCM terminal (111).


Warning lamp should illuminate.

OK →

Check the following.

- Door switch
- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between door switch and BCM

AT
PD
FA



CHECK DOOR SWITCH INPUT SIGNAL.

C CONSULT-II

See "DOOR SW" in DATA MONITOR mode.
When door is open:
DOOR SW ON
When door is closed:
DOOR SW OFF


NG →

OR

Check the following.

- Door switch
- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between door switch and BCM

RA
BR
ST
RS
BT
HA



E ON BOARD

Check all doors switches in Switch monitor (Mode II) mode.
(Refer to On board Diagnosis, EL-255.)

OK →

Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM

D CONSULT-II

See "IGN ON SW" in DATA MONITOR mode.
When ignition switch is ON:
IGN ON SW ON
When ignition switch is ACC or OFF:
IGN ON SW OFF

NG →

OR


E ON BOARD

Check voltage between BCM terminal (68) and ground.

Condition of ignition switch	Voltage V
ON	Approx. 12
ACC or OFF	0

OK →


Replace BCM.



EL
IDX

WARNING LAMPS

Trouble Diagnoses/Stop and Tail Lamp Sensor




SEL810V

STOP AND TAIL LAMP SENSOR INSPECTION TABLE

Terminal No.	Wire color	Connections	Operated condition		Voltage (Approximate values)
3	L	Stop and tail warning lamp		When sensing one of the bulbs burned out (See note.)	Less than 1.5V
				Other than above condition	12V
4	R	Stop lamp switch	Depressed		12V
			Released		0V
5	R/W	High-mounted stop lamp	Stop lamp switch	Depressed	11V
				Released	0V
6	L	Tail lamp RH (Fender side)	Lighting switch or auto lamp	Turned ON	11V
7	G/R	Tail lamp LH (Fender side)		Turned OFF	0V
8	R/G	Tail lamp relay	Lighting switch or auto lamp	Turned ON	11V
				Turned OFF	0V
9	B	Ground	—		—
10	R/L	Stop lamp LH and RH (Fender side)	Stop lamp switch	Depressed	11V
				Released	0V
12	R	Stop lamp switch	Depressed		12V
			Released		0V

Note: The system senses bulb burnout only when the stop lamp switch is depressed for stop lamps or tail lamp relay is energized for tail lamps.


WARNING LAMPS



Electrical Components Inspection

FUEL WARNING LAMP SENSOR CHECK


- It will take a short time for the bulb to light.



OIL PRESSURE SWITCH CHECK

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 20 - 29 (0.2 - 0.3, 3 - 4)	NO
Engine stop	Less than 20 - 29 (0.2 - 0.3, 3 - 4)	YES


Check the continuity between the terminals of oil pressure switch and body ground.



DIODE CHECK

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.



- Diodes for warning lamps are built into the combination meter printed circuit.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

A/T INDICATOR


Schematic




A/T INDICATOR

Wiring Diagram — AT/IND —

EL-AT/IND-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA




REFER TO THE FOLLOWING.
(M4) -SUPER MULTIPLE JUNCTION (SMJ)
(B1) -FUSE BLOCK-JUNCTION BOX (J/B)

EL
IDX

A/T INDICATOR


Wiring Diagram — AT/IND — (Cont'd)

EL-AT/IND-03



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT


HA
EL
IDX



REFER TO THE FOLLOWING.
 (E66), (E81) -SUPER MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

WARNING CHIME

Component Parts and Harness Connector Location



SEL859W

System Description

FUNCTION

- The following warning chime functions are controlled by BCM.

Item	Details of control
Ignition key warning chime	Sounds warning chime when driver's door is opened with key in ignition key cylinder and ignition switch "OFF" or "ACC" position.
Light warning chime	Sounds warning chime when driver's door is opened with light switch in the 1st or 2nd position and ignition switch "OFF" or "ACC" position.
Seat belt warning chime	Sounds warning chime for about 6 seconds if ignition switch is turned "ON" when driver's seat belt is unfastened

IGNITION KEY WARNING CHIME

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)
- to key switch terminal ③.
- through 10A fuse [No. 12], located in the fuse block (J/B)
- to warning chime terminal ①.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 32], located in the fuse block (J/B)
- to BCM terminal ⑥.

Ground is supplied to BCM terminal ③ through driver side door switch terminal ① when driver side switch is in OPEN position.

With the key in the ignition key cylinder, the ignition switch in the ACC or OFF position, and the driver's door open, ground is supplied to warning chime terminal ③ from BCM terminal ⑫. The warning chime will then sound.

LIGHT WARNING CHIME

Power is supplied at all times

- through 10A fuse [No. 12], located in the fuse block (J/B)
- to warning chime terminal ①.
- Through 15A fuse [No. 63], located in the fuse, fusible link and relay box
- to tail lamp relay terminals ① and ⑥.

WARNING CHIME

System Description (Cont'd)

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 32], located in the fuse block (J/B)
- to BCM terminal 68.

When the lighting switch is in the 1ST or 2ND position, ground is supplied

- to tail lamp relay terminal 2
- from body grounds E22 and E36
- through lighting switch terminals 11 and 5.

Tail lamp relay is then energized, and power is supplied

- to BCM terminal 3
- from tail lamp relay terminal 7
- through 7.5A fuse [No. 22], located in the fuse block (J/B)].

With the lighting switch in the 1ST, 2ND position, the ignition switch in ACC or OFF position, and the driver's door OPEN, the warning chime will sound in the same manner as ignition key warning chime.

SEAT BELT WARNING CHIME

Power is supplied at all times

- through 10A fuse [No. 12], located in the fuse block (J/B)]
- to warning chime terminal 1.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 32], located in the fuse block (J/B)]
- to BCM terminal 68.

Ground is supplied to BCM terminal 34 through seat belt buckle switch terminals 41 and 14, when seat belt buckle switch is in UNFASTENED position, and body grounds B22 and B35.

The warning chime sounds for about 6 seconds, when ignition switch is turned from OFF to ON and seat belt is unfastened.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

WARNING CHIME

Wiring Diagram — CHIME —

EL-CHIME-01




REFER TO THE FOLLOWING.
 (M4), (M6), (E66) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M1), (E64), (B1) -FUSE
 BLOCK-JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS

*: This connector is not shown in "HARNESS LAYOUT", EL section.

WARNING CHIME

Wiring Diagram — CHIME — (Cont'd)

EL-CHIME-02




Refer to EL-POWER.

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT

HA


EL

IDX



REFER TO THE FOLLOWING.
 (E66), (E81) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1), (E62) -FUSE BLOCK-JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS


WARNING CHIME




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".




6. Touch "IGN KEY WARN ALM", "LIGHT WARN ALM" or "SEAT BELT TIMER".



- DATA MONITOR and ACTIVE TEST are available for the warning chime.

Trouble Diagnoses

WORK FLOW



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14 located in the fuse block (J/B)].

BT

HA

EL


IDX

WARNING CHIME

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

REFERENCE PAGE	EL-138	EL-139	EL-139	EL-140
SYMPTOM	DIAGNOSTIC PROCEDURE 1 (Lighting switch input signal check)	DIAGNOSTIC PROCEDURE 2 (Key switch input signal check)	DIAGNOSTIC PROCEDURE 3 (Seat belt buckle switch input signal check)	DIAGNOSTIC PROCEDURE 4
Light warning chime does not activate.	X			X
Ignition key warning chime does not activate.		X		X
Seat belt warning chime does not activate.			X	X
All warning chimes do not activate.				X



DIAGNOSTIC PROCEDURE 1

(Lighting switch input signal check)

CHECK LIGHTING SWITCH INPUT SIGNAL.

A CONSULT-II

See "HD/LMP 1ST SW" in DATA MONITOR mode.

When lighting switch is in 1ST or 2ND:

HD/LMP 1ST SW ON

When lighting switch is OFF:

HD/LMP 1ST SW OFF

OR

ON BOARD

Check lighting switch in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

NG

Check the following.

- 7.5A fuse [No. 22], located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM

OK



Go to Procedure 4.

WARNING CHIME

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

(Key switch input signal check)



CHECK KEY SWITCH INPUT SIGNAL.

A CONSULT-II

See "IGN KEY SW" in DATA MONITOR mode.
When key is inserted in ignition key cylinder:
IGN KEY SW ON
When key is removed from ignition key cylinder:
IGN KEY SW OFF

B TESTER

Check voltage between BCM terminal 69 and ground.


Condition of key switch	Voltage V
Key is inserted	Approx. 12
Key is removed	0

- NG → Check the following.
- Key switch
Refer to "Electrical Components Inspection" (EL-141).
 - 10A fuse [No. 28], located in the fuse block (J/B)]
 - Harness for open or short between key switch and fuse
 - Harness for open or short between BCM and key switch

GI
MA
EM
LC
EC
FE
AT

OK ↓
Go to Procedure 4.

PD
FA
RA
BR
ST



DIAGNOSTIC PROCEDURE 3

(Seat belt buckle switch input signal check)

CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL.

A CONSULT-II

See "SEAT BELT SW" in DATA MONITOR mode.
When driver's seat belt is not fastened:
SEAT BELT SW ON
When driver's seat belt is fastened:
SEAT BELT SW OFF

ON BOARD

Check seat belt buckle switch in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

- NG → Check the following.
- Seat belt buckle switch
Refer to "Electrical Components Inspection" (EL-141).
 - Seat belt buckle switch ground circuit
 - Harness for open or short between BCM and seat belt buckle switch


RS
BT
HA
EL
IDX

OK ↓
Go to procedure 4.

WARNING CHIME

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4



CHECK DOOR SWITCH INPUT SIGNAL.



CONSULT-II

See "DOOR SW-DR" in DATA MONITOR mode.

When driver's door is open:

DOOR SW-DR ON

When driver's door is closed:

DOOR SW-DR OFF




ON BOARD

Check driver side door switch in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

NG

Check the following.

- Driver door switch
Refer to "Electrical Components Inspection" (EL-141).
- Driver door switch ground condition
- Harness for open or short between driver door switch and BCM



CHECK IGNITION SWITCH ON SIGNAL.



CONSULT-II

See "IGN ON SW" in DATA MONITOR mode.

When ignition switch is ON:

IGN ON SW ON

When ignition switch is ACC or OFF:

IGN ON SW OFF



TESTER


Check voltage between BCM terminal 68 and ground.

Condition of ignition switch	Voltage V
ON	Approx. 12
ACC or OFF	0

NG

Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM



D




Perform "WARN ALM" in ACTIVE TEST mode.
Check chime operation.

If CONSULT-II is not available, skip this procedure and go to the next procedure below.

OK

System is OK.

NG



E


CHECK WARNING CHIME.

1. Disconnect warning chime connector.
2. Apply 12V direct current to warning chime and check operation.

NG


Replace chime.

OK



Check the following.

- 10A fuse [No. 12] located in the fuse block (J/B)]
- Harness for open or short between fuse and chime
- Harness for open or short between chime and BCM




Electrical Components Inspection

KEY SWITCH (Insert)

Check continuity between terminals when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.


Terminal No.	Condition	Continuity
③ - ④	Key is inserted	Yes
	Key is removed	No



DRIVER SIDE DOOR SWITCH

Check continuity between terminal and switch body ground when door switch is pushed and released.

Terminal No.	Condition	Continuity
① - ground	Door switch is pushed.	No
	Door switch is released.	Yes



SEAT BELT BUCKLE SWITCH

Check continuity between terminals when seat belt is fastened and unfastened.

Terminal No.	Condition	Continuity
⑭ - ④①	Seat belt is fastened.	No
	Seat belt is unfastened.	Yes

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Component Parts and Harness Connector Location



SEL854W

System Description

WIPER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 11], located in the fuse block (J/B)
- to front wiper motor terminal ③.

Ground is supplied to front wiper switch terminals ⑰ and ⑳ through body grounds (E22) and (E36).

Low and high speed wiper operation

When the front wiper switch is placed in the LO position, ground is supplied

- through terminal ⑭ of the front wiper switch
- to front wiper motor terminal ⑤.

With power and ground supplied, the front wiper motor operates at low speed.

When the front wiper switch is placed in the HI position, ground is supplied

- through terminal ⑯ of the front wiper switch
- to front wiper motor terminal ④.

With power and ground supplied, the front wiper motor operates at high speed.

Auto stop operation

When the front wiper switch is placed in the OFF position, the front wiper motor will continue to operate until the wiper arms reach the base of the windshield (Auto stop).

When the front wiper switch is placed in the OFF position, ground is supplied

- from terminal ⑭ of the front wiper switch
- to front wiper motor terminal ⑤, in order to continue front wiper motor operation at low speed.

Ground is also supplied until the wiper arms reaches the base of the windshield

- through terminal ⑬ of the front wiper switch
- to wiper relay terminal ③
- through terminal ④ of the wiper relay
- to front wiper motor terminal ②
- through terminal ① of the front wiper motor, and
- through body grounds (E22) and (E36).

When the wiper arms reach the base of the windshield, the switch in the front wiper motor moves to the "STOP" position. The ground path is interrupted and the front wiper motor stops.

Intermittent operation

Intermittent operation is controlled by the BCM.

When the front wiper switch is placed in the INT position, ground is supplied

WIPER AND WASHER

System Description (Cont'd)

- to BCM terminal ⑨
- from front wiper switch terminal ⑮
- through body grounds ②② and ③⑥.

The desired interval time is input

- to BCM terminal ④⑧
- from front wiper switch terminal ⑲ and
- to BCM terminal ④⑨
- from combination meter terminal ⑱ (vehicle speed pulse).

Based on these three inputs, an intermittent ground is supplied

- to front wiper relay terminal ②
- from BCM terminal ⑦.

With power and ground supplied, the front wiper relay is activated.

When activated, an intermittent ground is supplied

- to front wiper motor terminal ⑤
- through the front wiper switch terminal ⑭
- to front wiper switch terminal ⑬
- through front wiper relay terminal ③
- to front wiper relay terminal ⑤
- through body grounds ②② and ③⑥.

Front wiper motor operates at desired interval with BCM terminal ⑨ grounded.

Intermittent operation can be adjusted from:

Approx. 4 - 19 sec.: (when vehicle is stopped)

Approx. 0.4 - 12 sec.: (when vehicle is moving)

Judgement on vehicle stopped or moving:

Stopped → Moving: More than 4 km/h (2 MPH)

Moving → Stopped: Less than 2 km/h (1 MPH)

WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. ⑪], located in the fuse block (J/B)]
- to front washer motor terminal ②.

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal ①, and
- to BCM terminal ④
- from terminal ⑱ of the front wiper switch
- through terminal ⑰ of the front wiper switch, and
- through body grounds ②② and ③⑥.

With power and ground supplied, the washer motor operates.

The front wiper motor operates at low speed for about 3 seconds. This feature is controlled by the BCM in the same manner as the intermittent operation.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

WIPER AND WASHER


Schematic



WIPER AND WASHER


Wiring Diagram — WIPER —

EL-WIPER-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL
IDX




REFER TO THE FOLLOWING.
 (E66), (E81), (F63) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M1), (E61) -FUSE BLOCK-
 JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS

WIPER AND WASHER


Wiring Diagram — WIPER — (Cont'd)

EL-WIPER-02



REFER TO THE FOLLOWING.
 (E66), (E81) -SUPER MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS


WIPER AND WASHER




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "WIPER".





- WORK SUPPORT, DATA MONITOR and ACTIVE TEST are available for the wiper and washer.

WIPER AND WASHER


CONSULT-II (Cont'd)

CONSULT-II CUSTOMIZING PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "WIPER".



7. Touch "WORK SUPPORT".

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14 located in the fuse block (J/B)].




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

WIPER AND WASHER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Intermittent wiper does not operate.



CHECK INTERMITTENT WIPER SWITCH INPUT SIGNAL.

A CONSULT-II

See "INT SW" in DATA MONITOR mode.

When wiper switch is in INT position:

INT SW ON

When wiper switch is in OFF position:

INT SW OFF

OR

ON BOARD

Check wiper switch (INT) in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-146.

NG

Check the following.

- Front wiper switch
- Harness for open or short between BCM and wiper switch
- Front wiper switch ground circuit.

Note: When "Data monitor" is operating, intermittent wiper do not operate.

OK

CHECK WIPER AUTO STOP SIGNAL.

B CONSULT-II

See "WIP AUTO STOP" in DATA MONITOR mode, and turn wiper switch to LO or HI position.

When wiper switch is in INT or OFF:

WIP AUTO STOP ACC

When wiper switch is in LO or HI:

WIP AUTO STOP GND

OR

C TESTER

1. Turn ignition switch to ACC.
2. Turn wiper switch to LO or HI position.
3. Check voltage between BCM connector terminal ③⑧ and ground.

Wiper condition	Voltage V
Moving	0
Stop	Approx. 12

Refer to wiring diagram in EL-145.

NG

Check the following.


- Wiper motor
- Wiper ground circuit
- Harness for open or short between BCM and wiper motor

OK

A

WIPER AND WASHER

Trouble Diagnoses (Cont'd)



A

CHECK IGNITION SWITCH ACC SIGNAL.

D CONSULT-II

See "IGN ACC SW" in DATA MONITOR mode.

When ignition switch is ACC or ON
IGN ACC SW ON


When ignition switch is OFF
IGN ACC SW OFF

OR

NG

Check the following.

- 7.5A fuse [No. 23], located in the fuse block (J/B)
- Harness for open or short between fuse and BCM




E TESTER

Check voltage between BCM terminal ⑥ and ground.

Condition of ignition switch	Voltage V
ACC or ON	Approx. 12
OFF	0

Refer to wiring diagram in EL-145.



OK

F

CHECK WIPER OPERATION.

CONSULT-II

See "WIPER AMP" in ACTIVE TEST mode.

Perform operation shown on display.

Wiper motor should operate.

Note:
If CONSULT-II is not available, skip this procedure and go to procedure 5.

OK

Replace BCM.

NG

Go to procedure 5.


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

WIPER AND WASHER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Intermittent time of wiper cannot be adjusted.




CHECK INTERMITTENT WIPER VOLUME INPUT SIGNAL.

A CONSULT-II

See "INT RESIST" in DATA MONITOR mode while turning intermittent wiper volume.

Position of wiper knob	Resistance kΩ
Short interval	Approx. 0
Long interval	Approx. 1

OK → Replace BCM.



B TESTER

Measure resistance between BCM terminal ④⑧ and ground while turning intermittent wiper volume.

Position of wiper knob	Resistance kΩ
Short interval	Approx. 0
Long interval	Approx. 1

Refer to wiring diagram in EL-146.

NG

Check front wiper switch.

NG → Replace intermittent wiper volume.

OK

Check the following.


- Harness for open or short between BCM and intermittent wiper volume
- Intermittent wiper volume ground circuit

WIPER AND WASHER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Wiper and washer activate individually but not in combination.



CHECK WASHER SWITCH INPUT SIGNAL.

A CONSULT-II

See "WASH SW" in DATA MONITOR mode.

When washer switch is ON:

WASH SW ON

When washer switch is OFF:

WASH SW OFF

OR

ON BOARD

Check wiper switch (WASH) in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255).

Refer to wiring diagram in EL-146.

NG → Check the following.
 ● Harness for open or short between BCM and wiper switch

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

OK ↓

Replace BCM.



DIAGNOSTIC PROCEDURE 4

SYMPTOM: Intermittent wiper operates, but there is no change in intermittent time between when vehicle is stopped and moving.

Does speedometer operate normally? No → Check vehicle speed sensor circuit. Refer to EL-110.

A

CHECK VEHICLE SPEED SENSOR PULL UP VOLTAGE.

1. Turn ignition switch to ACC.
2. Check voltage between BCM terminal ④ and ground.

Approx. 5V should exist.

Refer to wiring diagram in EL-147.

NG → Replace BCM.

OK ↓




Check harness for open or short between BCM terminal ④ and combination meter terminal ⑩.

WIPER AND WASHER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Wiper and washer activate individually but intermittent wiper and washer combination does not operate.



A

CHECK POWER SUPPLY CIRCUIT FOR FRONT WIPER RELAY.

1. Disconnect front wiper relay.
2. Turn wiper switch to OFF or INT position.
3. Turn ignition switch to ACC position.
4. Check voltage between front wiper relay connector terminal ① or ③ and ground.

Battery voltage should exist.

Refer to wiring diagram in EL-145.

NG

Check the following.

- 20A fuse [No. 11], located in the fuse block (J/B)]
- Harness for open or short

OK

B

CHECK GROUND CIRCUIT FOR FRONT WIPER RELAY.

Check continuity between front wiper connector terminal ⑤ and ground.

Continuity should exist.

NG

Repair harness.

OK

Check front wiper relay.

NG

Replace relay.

OK

C

CHECK BCM OUTPUT SIGNAL.

1. Connect front wiper relay.
2. Turn ignition switch to ACC.
3. Check voltage between BCM connector terminal ⑦ and ground.


OK

Check harness for open or short between front wiper relay and BCM.

Wiper switch condition	Voltage V
Wash	0 (for 0.7 sec.)
OFF	Approx. 12

NG


Replace BCM.



Removal and Installation

WIPER ARMS

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
 2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" & "L₂" immediately before tightening nut.
 3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
 4. Ensure that wiper blades stop within clearance "L₁" & "L₂".
 - **Clearance "L₁": 20 - 34 mm (0.79 - 1.34 in)**
 - **Clearance "L₂": 23 - 37 mm (0.91 - 1.46 in)**
- Tighten wiper arm nuts to specified torque.
 - **Front wiper: 21 - 26 N·m (2.1 - 2.7 kg-m, 15 - 20 ft-lb)**



- **Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.**

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

WIPER AND WASHER

Removal and Installation (Cont'd)

WIPER LINKAGE



Removal

1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

Be careful not to break ball joint rubber boot.



Installation

- Grease ball joint portion before installation.
1. Installation is the reverse order of removal.

Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range: $\pm 10^\circ$




Unit: mm (in)

*1	236 (9.29)	*8	136 (5.35)
*2	337 (13.27)	*9	8 (0.31)
*3	606 (23.86)	*10	216 (8.50)
*4	422 (16.61)	*11	149 (5.87)
*5	198 (7.80)	*12	482 (18.98)
*6	286 (11.26)	*13	376 (14.80)
*7	436 (17.17)	*14	385 (15.16)

*1: The diameter of a circle is less than 80 mm (3.15 in).

*2 - 7: The radius of the arc across the end of these areas is less than 40 mm (1.57 in).



Washer Tube Layout

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

Wiring Diagram — HORN —

EL-HORN-01



REFER TO THE FOLLOWING.


(E66) -SUPER MULTIPLE JUNCTION (SMJ)

*: This connector is not shown in "HARNESS LAYOUT", EL section.

CIGARETTE LIGHTER


Wiring Diagram — CIGAR —

EL-CIGAR-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA


EL
IDX



REFER TO THE FOLLOWING.
 (M4), (M6) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1), (B2) -FUSE BLOCK-JUNCTION BOX (J/B)


Wiring Diagram — CLOCK —

EL-CLOCK-01



REFER TO THE FOLLOWING.
 (M6) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)

Component Parts and Harness Connector Location



SEL860W

System Description

FUNCTION

- The following time control function is controlled by BCM.

Item	Details of control
Rear window defogger timer	Turn off rear window defogger about 15 minutes after the rear window defogger switch is turned "ON".

REAR WINDOW DEFOGGER TIMER

The rear window defogger system is controlled by the BCM.

Power is supplied at all times

- through 15A fuse [No. 38], located in the fuse block (J/B)
- to the rear window defogger relay terminal ⑥, and
- through 15A fuse [No. 39], located in the fuse block (J/B)
- to the rear window defogger relay terminal ③.

With the ignition switch in the ON or START position, power is supplied

- to the rear window defogger relay terminal ① and,
- to BCM terminal ⑥
- through 7.5A fuse [No. 32], located in the fuse block (J/B).

When the rear window defogger switch is ON, ground is supplied

- through terminal ② of the rear window defogger switch (A/C control unit)
- to BCM terminal ⑩.

Terminal ① of the BCM then supplies ground to the rear window defogger relay terminal ②.

With power and ground supplied, the rear window defogger relay is energized to operate rear window defogger for about 15 minutes.

When the system is activated, the rear window defogger indicator in the rear window defogger switch illuminates.

Power is supplied

- from rear window defogger relay terminal ⑤
- to A/C auto amp. terminal ⑤.

Then A/C auto amp. sends an indicator signal to A/C control unit combined with rear window defogger switch.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA







EL

IDX

REAR WINDOW DEFOGGER

Wiring Diagram — DEF —

EL-DEF-01




*: This connector is not shown in "HARNESS LAYOUT", EL section.

REFER TO THE FOLLOWING.

- (M4) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (B1), (B2) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M22) -ELECTRICAL UNITS


REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

HA
EL
IDX



REFER TO THE FOLLOWING.
 (M4), (M6), (D1), (D21)
 -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS


REAR WINDOW DEFOGGER




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".




6. Touch "REAR DEFOGGER".



- DATA MONITOR and ACTIVE TEST are available for the rear window defogger.

Trouble Diagnoses

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B).


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE

SYMPTOM: Rear window defogger does not activate or does not turn off after activating.



CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL.

A **CONSULT-II**

See "DEFOGGER SW" in DATA MONITOR mode.
When defogger switch is pushed (turned ON):
DEFOGGER SW ON
When defogger switch is pushed again (turned OFF):
DEFOGGER SW OFF

OR

ON BOARD


Check rear window defogger switch in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

NG → Check harness for open or short between BCM and rear window defogger switch.

OK →

NG → Repair harness.

Replace rear window defogger switch (combined with A/C control unit).



CHECK IGNITION SWITCH ON SIGNAL.

B **CONSULT-II**

See "IGN ON SW" in DATA MONITOR mode.
When ignition switch is ON:
IGN ON SW ON
When ignition switch is ACC or OFF:
IGN ON SW OFF

OR


C **TESTER**

Check voltage between BCM terminal ⑥ and ground.

Condition of ignition switch	Voltage V
ON	Approx. 12
ACC or OFF	0

NG → Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)
- Harness for open or short between fuse and BCM



CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL.

1. Disconnect BCM connector.
2. Check voltage between BCM terminal ① and ground.

Condition of ignition switch	Voltage V
ON	Approx. 12
OFF	0


NG → Check rear window defogger relay.

OK →

NG → Replace relay.

Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)
- Harness for open or short between fuse and rear window defogger relay
- Harness for open or short between rear window defogger relay and BCM





OK →

Connect BCM connector.

→ **A**

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)



(A)

REAR WINDOW DEFOGGER ACTIVE TEST.

E **CONSULT-II**

Perform "RR DEFOGGER RLY" in ACTIVE TEST mode. Check rear defogger relay operation.

OR

F **TESTER**

1. Turn ignition switch to ON.
2. Check voltage between BCM terminal ① and ground.

Condition of rear defogger switch	Voltage V
ON	0
OFF	Approx. 12

NG → Replace BCM.

OK ↓

Check rear window defogger circuit.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS





BT

HA

EL

IDX

REAR WINDOW DEFOGGER



Filament Check

1. Attach probe circuit tester (in volt range) to middle portion of each filament.

- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate burned out point, move probe along filament. Tester needle will swing abruptly when probe passes the point.

Filament Repair


REPAIR EQUIPMENT

1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth

GI

MA

EM



REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

LC

EC

Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

FE

AT



PD

Do not touch repaired area while test is being conducted.

FA

RA

BR



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

ST

RS

BT

HA

EL

IDX

System Description

BOSE SYSTEM

Refer to Owner's Manual for audio system operating instructions.

Power is supplied at all times

- through 15A fuse (No. 58), located in the fuse, fusible link and relay box)
- to audio unit terminal 6.
- to BOSE speaker amp. terminal 27 and
- to audio amp. relay terminal 3.
- through 10A fuse [No. 12, located in the fuse block (J/B)]
- to CD auto changer terminal 52.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to audio unit terminal 10 and
- to CD auto changer terminal 56.

Ground is supplied through the case of the audio unit and BOSE speaker amp.

Ground is also supplied to CD auto changer terminal 55 through body grounds B105 and B118.

When the audio unit is turned to the ON position, power is supplied

- through audio unit terminal 12
- to BOSE speaker amp. terminal 25, and
- to audio amp. relay terminal 1.


The audio amp. relay is energized, power is supplied

- through audio amp. relay terminal 5
- to LH and RH rear speaker terminal 3.

When the audio unit is turned to the ON position, audio signals are supplied

- through terminals 13, 14, 15, 16, 1, 2, 3 and 4 of audio unit
- to terminals 21, 34, 23, 36, 20, 33, 22 and 35 of the BOSE speaker amp.
- through terminals 30, 31, 28, 29, 37, 24, 18, 17, 32, 19, 41 and 42 of the BOSE speaker amp.
- to tweeters and the front and rear door speakers and rear speakers terminals 1 and 2.

Schematic





- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

AUDIO

Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-02





REFER TO THE FOLLOWING.
 (M4), (M6) -SUPER MULTIPLE JUNCTION (SMJ)

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

AUDIO

Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-03





REFER TO THE FOLLOWING.
 (M4), (M6) -SUPER MULTIPLE
 JUNCTION (SMJ)

AUDIO

Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-04










REFER TO THE FOLLOWING.
 (M4), (D1), (D21) -SUPER
 MULTIPLE JUNCTION (SMJ)

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

AUDIO

Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-05




REFER TO THE FOLLOWING.
 (M4), (M50) -SUPER MULTIPLE JUNCTION (SMJ)


AUDIO

Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-06





GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX



AUDIO

Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-07



REFER TO THE FOLLOWING.
 (M4), (M6), (M50) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (B1) -FUSE BLOCK-JUNCTION
 BOX (J/B)

Trouble Diagnoses

AUDIO UNIT (BOSE SYSTEM)

Symptom	Possible causes	Repair order
Audio unit inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> 10A fuse Poor audio unit case ground Audio unit 	<ol style="list-style-type: none"> Check 10A fuse [No. 8], located in the fuse block (J/B). Turn ignition switch ACC or ON and verify that battery positive voltage is present at terminal 10 of audio unit. Check audio unit case ground. Remove audio unit for repair.
Audio unit controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> AMP ON signal Audio amp. relay Audio amp. relay ground Poor speaker amp. case ground Speaker amp. output Speaker amp. 	<ol style="list-style-type: none"> Turn ignition switch ACC and radio ON. Verify battery positive voltage is present from audio unit terminal 10 to BOSE speaker amp. terminal 20 and audio amp. relay terminal 1. Check audio amp. relay. Check audio amp. relay ground (Terminal 2). Check speaker amp. case ground. Check speaker amp. output voltage. Remove speaker amp. for repair.
Audio unit presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> 15A fuse Audio unit 	<ol style="list-style-type: none"> Check 15A fuse [No. 58], located in the fuse, fusible link and relay box] and verify that battery positive voltage is present at terminal 6 of audio unit. Remove audio unit for repair.
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> Speaker Speaker ground Power supply Audio unit/speaker amp. output Speaker circuit Audio unit/speaker amp. Speaker 	<ol style="list-style-type: none"> Check speaker. Check speaker ground (Terminal 4: RR LH, 4: RR RH). Check power supply for speaker (Terminal 3: RR LH, 3: RR RH). Check radio/speaker amp. output voltage. Check wires for open or short between audio unit, amp. and speaker. Remove audio unit or speaker amp. for repair. Replace speaker.
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> Antenna Poor audio unit ground Audio unit 	<ol style="list-style-type: none"> Check antenna. Check audio unit ground. Remove audio unit for repair.
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> Window antenna Audio unit 	<ol style="list-style-type: none"> Check window antenna. Remove audio unit for repair.
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> Poor audio unit ground Loose or missing ground bonding straps Ignition condenser or rear window defogger noise suppressor condenser Alternator Ignition coil or secondary wiring Audio unit 	<ol style="list-style-type: none"> Check audio unit ground. Check ground bonding straps. Replace ignition condenser or rear window defogger noise suppressor condenser. Check alternator. Check ignition coil and secondary wiring. Remove audio unit for repair.
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> Poor audio unit ground Antenna Accessory ground Faulty accessory 	<ol style="list-style-type: none"> Check audio unit ground. Check antenna. Check accessory ground. Replace accessory.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

AUDIO

Trouble Diagnoses (Cont'd)

CD AUTOCHANGER

Symptom	Possible causes	Repair order
No play of the CD after CD play button is pushed.		
There is no error code shown on the audio unit.	<ol style="list-style-type: none"> 1. Audio unit (The audio unit is not working.) 2. Harness connection (Magazine does not eject.) 3. Changer 	<ol style="list-style-type: none"> 1. Remove the audio unit for repair. 2. Check harness connection. 3. Remove the changer for repair.
Error code [CD Err] is shown on the audio unit.	<ol style="list-style-type: none"> 1. Discs 2. Magazine does not eject or a disc remains in CD player. 3. Changer 	<ol style="list-style-type: none"> 1. Inspect discs. (Refer to testing magazines and discs.) 2. Reset the changer. (Disconnect harness connector at the changer and reconnect after 30 sec.) 3. Remove the changer for repair.
CD skipping.	<ol style="list-style-type: none"> 1. Rough road driving 2. Discs 3. Bracket 4. Changer 	<ol style="list-style-type: none"> 1. System is not malfunctioning. 2. Inspect discs. (Refer to testing magazines and discs.) 3. Check and repair bracket and installation of changer. 4. Remove the changer for repair.
Error code [CD no disk] is shown on the audio unit after CD play button is pressed.	<ol style="list-style-type: none"> 1. Magazine setting 2. Magazine 3. Changer 	<ol style="list-style-type: none"> 1. Confirm the magazine is pushed completely. 2. Inspect magazine. (Refer to testing magazines and discs.) 3. Remove the changer for repair.
Error code [CD HHHH] is shown on the audio unit after CD play button is pressed.	<ol style="list-style-type: none"> 1. Overheat 2. Reset the Error code 3. Audio unit or changer 	<ol style="list-style-type: none"> 1. Turn the radio off. Open the trunk lid to lower the trunk room and changer temperature. 2. Reset the audio unit or changer. (Disconnect harness connector at the audio unit or changer and reconnect.) 3. Remove the audio unit or changer for repair.

Testing magazines and discs


1. Confirm discs are installed correctly into the magazine (not upside down).
2. Visually inspect/compare the customer's discs with each other and other discs.
Identify any of the following conditions:
 - Discs with a large outside diameter. [Normal size is 120 mm (4.72 in).]
 - Discs with rough or lipped edges.
 - Discs with excessive thickness [Normal size is 1.2 mm (0.047 in).]
 - Discs with scratches, abrasions, or pits on the surface.
 - Discs with grease/oil, fingerprints, foreign material.
 - Discs are warped due to excessive heat exposure.
3. Slide/place the discs in and out of the various magazine positions.
Identify any discs and/or positions that require additional force for placement/ejection. If interference (sticking, excessive tensions) is found, replace the magazine or the discs.

Note


- Discs which are marginally out of specification (ex. dirty, scratched and so on) may play correctly on a home stereo.
However, when used in the automotive environment skipping may occur due to the added vehicle movement and/or vibration due to road conditions. Autochangers should not be replaced when discs are at fault.
- Use a soft damp cloth to wipe the discs starting from the center outward in radial direction. Never use chemical cleaning solutions to clean the discs.

Wiring Diagram — REMOTE —

EL-REMOTE-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA



REFER TO THE FOLLOWING.
 (M4), (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (B1) -FUSE BLOCK-JUNCTION BOX (J/B)

*: This connector is not shown in "HARNESS LAYOUT", EL section.

EL
IDX

System Description

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)
- to power antenna timer and motor terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 8], located in the fuse block (J/B)
- to audio unit terminal 10.

Ground is supplied to the power antenna timer and motor terminal 2 through body grounds B22 and B35.

When the audio unit is turned to the ON position, battery positive voltage is supplied

- through audio unit terminal 5
- to power antenna timer and motor terminal 4.

The antenna raises and is held in the extended position.

When the audio unit is turned to the OFF position, battery positive voltage is interrupted


- from audio unit terminal 5
- to power antenna timer and motor terminal 4.

The antenna retracts.

AUDIO ANTENNA

Wiring Diagram — P/ANT —

EL-P/ANT-01



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST




RS

BT

HA

EL

IDX



REFER TO THE FOLLOWING.
 (M4), (M6) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1), (B1) -FUSE BLOCK-JUNCTION BOX (J/B)


AUDIO ANTENNA

Trouble Diagnoses


POWER ANTENNA

Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none"> 10A fuse Audio signal Grounds B22 and B35 Power antenna timer and motor 	<ol style="list-style-type: none"> Check 10A fuse [No. 28], located in the fuse block (J/B). Verify that battery positive voltage is present at terminal 6 of power antenna timer and motor. Turn ignition switch to ACC or ON and radio ON. Verify that battery positive voltage is present at terminal 4 of power antenna timer and motor. Check grounds B22 and B35. Check power antenna timer and motor.

Location of Antenna



CEL427




CEL428

Antenna Rod Replacement

REMOVAL

1. Remove antenna nut and antenna base.



CEL429


2. Withdraw antenna rod while raising it by operating antenna motor.

AUDIO ANTENNA

Antenna Rod Replacement (Cont'd)

INSTALLATION


1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.



Window Antenna Repair

ELEMENT CHECK

1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.
2. If an element is broken, no continuity will exist.
3. To locate broken point, move probe along element. Tester needle will swing abruptly when probe passes the point.



ELEMENT REPAIR

Refer to REAR WINDOW DEFOGGER "Filament Repair" (EL-171).

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

TELEPHONE (Pre wire)

Wiring Diagram — PHONE — (Cont'd)

EL-PHONE-02



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(N3) W

16	14	12		25	23	22
13	11	10	28	27	26	

(N29) W

2	23	●	18	1		
28	27	8	11	12	24	6

(B15) W

9	8	12	24	○	15	22	19
23	11	18	1	6	14	20	2

(B32) W

		10
25	13	26

(B33) W






REFER TO THE FOLLOWING.
(B4) -SUPER MULTIPLE JUNCTION (SMJ)

HA
EL
IDX

TRUNK LID AND FUEL FILLER LID OPENER

Wiring Diagram — T&FLID —

EL-T&FLID-01




REFER TO THE FOLLOWING.

- (M4) -SUPER MULTIPLE JUNCTION (SMJ)
- (B2) -FUSE BLOCK-JUNCTION BOX (J/B)

TRUNK LID AND FUEL FILLER LID OPENER


Wiring Diagram — T&FLID — (Cont'd)

EL-T&FLID-02



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT


HA
EL
IDX



REFER TO THE FOLLOWING.
 (M50), (D1) -SUPER MULTIPLE
 JUNCTION (SMJ)

TRUNK CLOSURE

Component Parts and Harness Connector Location



SEL861W

System Description

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)]
- to trunk closure control unit terminal ② .

Ground is supplied at all times

- to trunk closure control unit terminal ④
- through body ground (T12).

Power is supplied at all times

- through 10A fuse [No. 27], located in the fuse block (J/B)] and trunk room lamp
- to trunk room lamp switch (lock switch).

OPERATION

When trunk is closed

1. CLOSED (LOCK) signal is supplied from trunk room lamp switch (lock switch) to trunk closure control unit terminal ① (Battery voltage is supplied to trunk closure control unit terminal ① when trunk room lamp switch is turned to CLOSED (LOCK)).
2. When trunk closure control unit receive CLOSED (LOCK) signal from trunk room lamp switch, power is supplied to trunk closure motor from trunk closure control unit within 40 msec.
3. When stop switch in trunk closure control unit is turned to OFF during closing operation, trunk closure motor stops within 40 msec.

When trunk is opened


1. OPEN (UNLOCK) signal is supplied from trunk room lamp switch (lock switch) to trunk closure control unit terminal ① (Battery voltage to trunk closure control unit terminal ① is cut off when trunk room lamp switch is turned to OPEN (UNLOCK)).
2. OPEN signal is supplied to trunk closure control unit terminal ③ from striker switch.
3. When trunk closure control unit receives OPEN signal from striker switch, power is supplied to trunk closure motor from trunk closure control unit within 40 msec.
4. When stop switch in trunk closure control unit is turned to ON during opening operation, trunk closure motor stops within 40 msec.

TRUNK CLOSURE

Trouble Diagnosis

SYMPTOM CHART


REFERENCE PAGE	EL-195	EL-196	—	
	MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK	DIAGNOSTIC PROCEDURE 1	Replace Trunk Closure Unit	GI
				MA
				EM
				LC
				EC
				FE
				AT
SYMPTOM				
Trunk closure does not operate for closing and opening trunk lid.	X	X		PD
Trunk closure operation does not stop.			X	
Trunk closure operation stops in an unstable trunk lid position.			X	FA



POWER SUPPLY AND GROUND CIRCUIT CHECK

Power supply circuit check

Terminal		Ignition switch		
⊕	⊖	OFF	ACC	ON
②	Ground	Battery voltage	Battery voltage	Battery voltage



Ground circuit check








Terminals	Continuity
④ - Ground	Yes

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TRUNK CLOSURE




Trouble Diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE 1



TRUNK CLOSURE

Trouble Diagnosis (Cont'd)



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Component Parts and Harness Connector Location



SEL943W

System Description

OUTLINE

Electric sunroof system consists of

- Sunroof switch
- Sunroof motor assembly
- Sunroof relay
- BCM (Body Control Module)

BCM controls the operation of sunroof relay. Power is supplied to sunroof motor assembly through sunroof relay. Sunroof will be operated depending on sunroof switch condition.

OPERATION

- Sunroof can be opened or closed and tilted up or down with sunroof switch.

Auto operation

The power sunroof AUTO feature makes it possible to open and close the sunroof without holding the sunroof switch in the down or up position.

Delayed power operation

When the ignition switch is turned to the "OFF" position, the sunroof will still operate for up to approximately 45 seconds unless driver's side or passenger side door is opened.

Interruption detection function

The CPU of sunroof motor monitors the sunroof motor operation and the sunroof position (full closed or other) for sunroof by the signals from sunroof motor.

When sunroof motor detects interruption during the following close operation,



- automatic close operation when ignition switch is in the "ON" position
- automatic close operation during retained power operation

sunroof switch controls the motor for open and the sunroof will operate about 150 mm (5.91 in).

ELECTRIC SUNROOF

Wiring Diagram — SROOF —

EL-SROOF-01



REFER TO THE FOLLOWING.
 (M4), (M50), (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA


EL

IDX

ELECTRIC SUNROOF

Wiring Diagram — SROOF — (Cont'd)

EL-SROOF-02



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M15) W

1	1	1	1	1	1
---	---	---	---	---	---


(M61) GY

5	4	1
2	6	3

(R12) BR

5	4	3	1
12	11	9	8
			6


(R13) W




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "SUN ROOF RELAY".



- DATA MONITOR and ACTIVE TEST are available for the sun-roof relay.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



Trouble Diagnoses

Symptom	Possible cause	Repair order
Power sunroof cannot be operated using any switch.	<ol style="list-style-type: none"> 1. 10A fuse, 40A fusible link and B5 circuit breaker 2. Sunroof relay 3. Grounds M14 and M47 4. Sunroof switch 5. Sunroof switch circuit 6. Sunroof motor 	<ol style="list-style-type: none"> 1. Check 10A fuse [No. 28, located in fuse block (J/B)], 40A fusible link (letter h, located in fuse, fusible link and relay box) and B5 circuit breaker. Turn ignition switch "ON" and verify battery positive voltage is present at terminals 1 and 6 of sunroof motor. 2. Check sunroof relay 3. Check grounds M14, M47. 4. Check sunroof switch. 5. Check harness between sunroof switch and sunroof motor. 6. Check sunroof motor.
Power sunroof cannot be operated using one of the sunroof switches.	<ol style="list-style-type: none"> 1. Sunroof switch 2. Sunroof switch circuit 	<ol style="list-style-type: none"> 1. Check sunroof switch. 2. Check the harness between sunroof motor and sunroof switch.
Power sunroof auto function cannot be operated properly.	<ol style="list-style-type: none"> 1. Sunroof slide mechanism 2. Sunroof switch 3. Sunroof switch circuit 4. Sunroof motor 	<ol style="list-style-type: none"> 1-1. Check obstacles in sunroof, etc. 1-2. Check worn or deformed sunroof. 1-3. Check sunroof sash tilted too far inward or outward. 2. Check sunroof switch. 3. Check harness between sunroof motor and sunroof switch. 4. Replace sunroof motor.
Delayed power operation does not operate properly.	<ol style="list-style-type: none"> 1. Driver or passenger side door switch circuit 2. BCM 	<ol style="list-style-type: none"> 1-1. Check harness between smart entrance control unit and driver or passenger side door switch for short circuit. 1-2. Check driver or passenger side door switch ground circuit. 1-3. Check driver or passenger side door switch. 2. Check BCM

DOOR MIRROR

Wiring Diagram — MIRROR —

EL-MIRROR-01

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST



RS

BT

HA

EL

IDX





REFER TO THE FOLLOWING.

(D1), (D21) -SUPER MULTIPLE JUNCTION (SMJ)


(M1) -FUSE BLOCK-JUNCTION BOX (J/B)

Wiring Diagram — I/MIRR —


EL-I/MIRR-01



(M15)
W



(M53)
G



(M61)
GY





(R4)
W

REFER TO THE FOLLOWING.
(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

POWER SEAT (Passenger side)

Wiring Diagram — SEAT —

EL-SEAT-01




REFER TO THE FOLLOWING.
 (M4), (M50), (E66) -SUPER
 MULTIPLE JUNCTION (SMJ)

* : This connector is not shown in "HARNESS LAYOUT", EL section.


POWER SEAT (Passenger side)

Wiring Diagram — SEAT — (Cont'd)

EL-SEAT-02



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX





* : This connector is not shown in "HARNESS LAYOUT", EL section.

POWER SEAT (Passenger side)

Wiring Diagram — SEAT — (Cont'd)

EL-SEAT-03




* : This connector is not shown in "HARNESS LAYOUT", EL section.


POWER SEAT (Passenger side)

Wiring Diagram — SEAT — (Cont'd)

EL-SEAT-04



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX





*: This connector is not shown in "HARNES LAYOUT", EL section.

HEATED SEAT

Wiring Diagram — HSEAT —

EL-HSEAT-01




* : This connector is not shown in "HARNES LAYOUT", EL section.

REFER TO THE FOLLOWING.
 (B1) - FUSE BLOCK-JUNCTION BOX (J/B)

HEATED SEAT


Wiring Diagram — HSEAT — (Cont'd)

EL-HSEAT-02



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA


EL
IDX



* : This connector is not shown in "HARNES LAYOUT", EL section.

REAR SUNSHADE

Component Parts and Harness Connector Location



SEL862W

System Description

Power is supplied at all times.

- through 7.5A fuse [No. 10], located in the fuse block (J/B)
- to rear sunshade unit terminal 5 .

Ground is supplied at all times

- to rear sunshade unit terminal 6
- through body ground B105 and B118.

GI

MA

OPEN OPERATION

When rear sunshade switch is turned to “OPEN”, the ground is supplied to rear sunshade unit terminal 1 . Based on the ground signal to control unit terminal 6 through rear sunshade unit terminal 1 , power is supplied

EM

- to motor terminal 2
- from control unit terminal 9

LC

and ground is supplied

- to motor terminal 1
- from control unit terminal 8 .

EC

When sunshade is fully opened, control unit stops to supply power to motor based on the signal from UP/DOWN limit switch.

FE

CLOSE OPERATION

When rear sunshade switch is turned to “CLOSE”, ground is supplied to rear sunshade unit terminal 2 . Based on the ground signal to control unit terminal 7 through rear sunshade unit terminal 2 , power is supplied

AT

- to motor terminal 1
- from control unit terminal 8

PD

and ground is supplied

- to motor terminal 2
- from control unit terminal 9 .

FA

When sunshade is fully closed, control unit stops to supply power to motor based on the signal from UP/DOWN limit switch.

RA

Once the sunshade switch is pushed, the open or close operation will be continued until the control unit detects full open or full close based on the signal from UP/DOWN limit switch. During open or close operation of sunshade, the input signal from sunshade switch is ignored.

BR

When control unit detects the slack of sunshade based on the signal from slack detection switch, the motor will be stopped. When control unit detects no slack of sunshade based on the signal from slack detection switch, power is supplied again to motor after 1 sec. after no slack is detected.

ST

RS

BT

HA


EL

IDX


REAR SUNSHADE

Wiring Diagram — SHADE —


EL-SHADE-01




(M68)
W




(B123)
GY




(B151)
W




(B155)
W




(EL16)
W




(EL17)
B



(EL18)
W



(EL19)
W



(EL20)
W


*: This connector is not shown in "HARNES LAYOUT", EL section.

REFER TO THE FOLLOWING.
(M1) - FUSE BLOCK-JUNCTION BOX (J/B)


REAR SUNSHADE

Wiring Diagram — SHADE — (Cont'd)

EL-SHADE-02




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT



REFER TO THE FOLLOWING.
 (M6) -SUPER MULTIPLE JUNCTION (SMJ)

HA
EL
IDX

REAR SUNSHADE



Trouble Diagnoses


POWER SUPPLY CIRCUIT CHECK

Check voltage between rear sunshade unit terminal ⑤ and ground.

Terminals	Ignition switch position			
	OFF	ACC	ON	START
⑤ - Ground	0V	Battery voltage		

If NG, check the following.

- 7.5A fuse [No. ⑩], located in fuse block (J/B)]
- Harness for open or short between 7.5A fuse [No. ⑩], located in fuse block (J/B)] and rear sunshade unit.




GROUND CIRCUIT CHECK

Check continuity between rear sunshade unit terminal ⑥ and ground.

Terminals	Continuity
⑥ - Ground	Yes

If NG, check harness for open between rear sunshade unit terminal ⑥ and body ground (B105) and (B118).



REAR SUNSHADE SIGNAL CIRCUIT CHECK

1. Disconnect rear sunshade unit connector.
2. Check the following continuity.

Terminals	Switch position	Continuity
① - Ground	Open	Yes
	Neutral	No
	Close	No
② - Ground	Open	No
	Neutral	No
	Close	Yes

If NG, check the following.


- Harness for open or short between rear sunshade unit and rear sunshade switch
- Harness for open or short between rear sunshade switch and ground
- Rear sunshade switch

REAR SUNSHADE

Trouble Diagnoses (Cont'd)

REAR SUNSHADE SWITCH CHECK

1. Disconnect rear sunshade switch.
2. Check continuity between rear sunshade switch terminals.



Terminals	Switch position	Continuity
① - ③	Open	Yes
	Neutral	No
	Close	No
② - ③	Open	No
	Neutral	No
	Close	Yes

If NG, replace rear sunshade switch.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Component Parts and Harness Connector Location



SEL864W

System Description

POWER SUPPLY AND GROUND

When ignition switch is in the ON or START position, power is supplied

- through 7.5A fuse [No. 32], located in the fuse block (J/B)
- to ASCD hold unit terminal ① .

GI

When MAIN switch is depressed, ground is supplied

- to ASCD hold unit terminal ②
- through ASCD steering switch terminal ④ .

MA

If those two signals are input, ASCD hold unit supplies power

- to ASCD control unit terminal ④ ,
- to ASCD control unit terminal ⑤ (through ASCD brake switch and park/neutral position relay) and
- to combination meter terminal ④⑤ to illuminate CRUISE indicator.

EM

ASCD hold unit keeps power supply until any of following condition exists.

- Ignition switch is returned to the ACC or OFF position.
- MAIN switch is depressed again.

LC

Ground is supplied

- to ASCD hold unit terminal ④ and
- to ASCD control unit terminal ③
- through body grounds (M14) and (M47).

EC

FE

OPERATION

Set operation

AT

To activate the ASCD, all of following conditions must exist.

- Power supply to ASCD control unit terminal ④
- Power supply to ASCD control unit terminal ⑤ (Brake pedal is released and A/T selector lever is in other than P and N position.)
- Vehicle speed is between 48 km/h (30 MPH) and 144 km/h (89 MPH). (Signal from combination meter)

PD

FA

When the SET/COAST switch is depressed, power is supplied

- from ASCD steering switch terminal ②
- to ASCD control unit terminal ② .

RA

And then ASCD pump is activated to control throttle wire and ASCD control unit supply power

- to combination meter terminal ④⑥ to illuminate SET indicator.

A/T overdrive control during cruise control driving

BR

When the vehicle speed is approximately 8 km/h (5 MPH) below set speed, a signal is sent

- from ASCD control unit terminal ⑫
- to TCM (transmission control module) terminal ④⑩ .

ST

When this occurs, the TCM (transmission control module) cancels overdrive.

After vehicle speed is approximately 3 km/h (2 MPH) above set speed, overdrive is reactivated.

Coast operation

RS

When the SET/COAST switch is depressed during cruise control driving, ASCD actuator returns the throttle cable to decrease vehicle set speed until the switch is released. And then ASCD will keep the new set speed.

Accel operation

BT

When the RESUME/ACCEL switch is depressed, power is supplied

- from ASCD steering switch terminal ③
- to ASCD control unit terminal ① .

HA

If the RESUME/ACCEL switch is depressed during cruise control driving, ASCD actuator pulls the throttle cable to increase the vehicle speed until the switch is released or vehicle speed is reached to maximum controlled speed by the system. And then ASCD will keep the new set speed.

EL

Cancel operation

When any of following condition exists, cruise operation will be canceled. (CRUISE indicator will continue to illuminate.)

IDX

- CANCEL switch is depressed. (Power supply to ASCD control unit terminals ① and ②)
- Brake pedal is depressed. (Power supply to ASCD control unit terminal ⑪ from stop lamp switch)
- Brake pedal is depressed or A/T selector lever is shifted to P or N position. (Power supply to ASCD control unit terminal ⑤ is interrupted.)

If MAIN switch is depressed during ASCD is activated, all of ASCD operation will be canceled and vehicle speed memory will be erased.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description (Cont'd)

Resume operation

When the RESUME/ACCEL switch is depressed after cancel operation other than depressing MAIN switch is performed, vehicle speed will return to last set speed. To resume vehicle set speed, vehicle condition must meet following conditions.

- Brake pedal is released.
- A/T selector lever is in other than P and N position.
- Vehicle speed is between 48 km/h (30 MPH) and 144 km/h (89 MPH).

ASCD PUMP OPERATION

The ASCD pump consists of a vacuum motor, an air valve and a release valve. When the ASCD activates, power is supplied

- from terminal ⑧ of ASCD control unit
- to ASCD pump terminal ①.


Ground is supplied to vacuum motor, air valve and release valve from ASCD control unit depending on the operated condition as shown in the below table.

The pump is connected to ASCD actuator by vacuum hose. When the ASCD pump is activated, the ASCD pump vacuum the diaphragm of ASCD actuator to control throttle cable.

		Air valve*	Release valve*	Vacuum motor	Actuator inner pressure
ASCD not operating		Open	Open	Stopped	Atmosphere
ASCD operating	Releasing throttle cable	Open	Closed	Stopped	Vacuum (decrease)
	Holding throttle position	Closed	Closed	Stopped	Vacuum (hold)
	Pulling throttle cable	Closed	Closed	Operated	Vacuum (increase)

*: When power and ground is supplied, valve is closed.



Schematic



GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Wiring Diagram — ASCD —

EL-ASCD-01



REFER TO THE FOLLOWING.
 (M6) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)


*: This connector is not shown in "HARNESS LAYOUT", EL section.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-02

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Refer to EL-POWER.








REFER TO THE FOLLOWING.
(E66) -SUPER MULTIPLE JUNCTION (SMJ)
(M1) -FUSE BLOCK-JUNCTION BOX (J/B)

* : This connector is not shown in "HARNESS LAYOUT", EL section.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-03









REFER TO THE FOLLOWING.
 (M4), (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (B1) -FUSE BLOCK-JUNCTION BOX (J/B)


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-05




REFER TO THE FOLLOWING.
 (M4), (M6) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)
 (B9) -ELECTRICAL UNITS




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" to data link connector.




3. Turn ignition switch ON.
4. Turn ASCD main switch ON.
5. Touch START (on CONSULT-II display).
6. Touch ASCD.
7. Touch SELF-DIAG RESULTS.



- Self-diagnostic results are shown on display. Refer to table on the next page.



8. Touch DATA MONITOR. The items on the next page are available as data monitor items.



- Touch START.
- Data monitor results are shown on display. Refer to table on the next page.

For further information, read the CONSULT-II Operation Manual.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


CONSULT-II (Cont'd)

SELF-DIAGNOSTIC RESULTS

Diagnostic item	Description	Repair/Check order
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	<ul style="list-style-type: none"> Even if no self diagnostic code is indicated, further testing may be required as far as the customer complains. 	—
POWER SUPPLY-VALVE	<ul style="list-style-type: none"> The power supply circuit for the ASCD pump is open. (An abnormally high voltage is entered.) 	Diagnostic procedure 6 (EL-237)
VACUUM PUMP	<ul style="list-style-type: none"> The vacuum pump circuit is open or shorted. (An abnormally high or low voltage is entered.) 	Diagnostic procedure 6 (EL-237)
AIR VALVE	<ul style="list-style-type: none"> The air valve circuit is open or shorted. (An abnormally high or low voltage is entered.) 	Diagnostic procedure 6 (EL-237)
RELEASE VALVE	<ul style="list-style-type: none"> The release valve circuit is open or shorted. (An abnormally high or low voltage is entered.) 	Diagnostic procedure 6 (EL-237)
VHCL SP-S/FAILSAFE	<ul style="list-style-type: none"> The vehicle speed sensor or the fail-safe circuit is malfunctioning. 	Diagnostic procedure 5 (EL-236)
CONTROL UNIT	<ul style="list-style-type: none"> The ASCD control unit is malfunctioning. 	Replace ASCD control unit.
BRAKE SW/STOP/L SW	<ul style="list-style-type: none"> The brake switch or stop lamp switch is malfunctioning. 	Diagnostic procedure 3 (EL-234)

DATA MONITOR

Monitored item	Description
BRAKE SW	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the brake switch circuit.
STOP LAMP SW	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the stop lamp switch circuit.
SET SW	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the set switch circuit.
RESUME/ACC SW	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the resume/accelerate switch circuit.
CANCEL SW	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the cancel circuit.
VHCL SPEED SE	<ul style="list-style-type: none"> The present vehicle speed computed from the vehicle speed sensor signal is displayed.
SET VHCL SPD	<ul style="list-style-type: none"> The preset vehicle speed is displayed.
VACUUM PUMP	<ul style="list-style-type: none"> The operation time of the vacuum pump is displayed.
AIR VALVE	<ul style="list-style-type: none"> The operation time of the air valve is displayed.
PW SUP-VALVE	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the circuit for the air valve and the release valve.
CRUISE LAMP	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the cruise lamp circuit.
A/T-OD CANCEL	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the OD cancel circuit.
AT OD MONITOR	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of over drive.
FAIL SAFE-LOW	<ul style="list-style-type: none"> The fail-safe (LOW) circuit function is displayed.
FAIL SAFE-SPD	<ul style="list-style-type: none"> The fail-safe (SPEED) circuit function is displayed.
TCS MONITOR	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of traction control system.



Fail-safe System Description

When the fail-safe system senses a malfunction, it deactivates ASCD operation. The SET indicator in the combination meter will then flash.

MALFUNCTION DETECTION CONDITIONS

Detection conditions	ASCD operation during malfunction detection
<ul style="list-style-type: none"> ● ASCD steering (RESUME/ACCEL, CANCEL, SET/COAST) switch is stuck. ● Vacuum motor ground circuit or power circuit is open or shorted. ● Air valve ground circuit or power circuit is open or shorted. ● Release valve ground circuit or power circuit is open or shorted. ● Vehicle speed sensor is faulty. ● ASCD control unit internal circuit is malfunctioning. 	<ul style="list-style-type: none"> ● ASCD is deactivated. ● Vehicle speed memory is canceled.
<ul style="list-style-type: none"> ● ASCD brake switch or stop lamp switch is faulty. 	<ul style="list-style-type: none"> ● ASCD is deactivated. ● Vehicle speed memory is not canceled.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST




RS

BT

HA

EL

IDX



Fail-safe System Check

1. Turn ignition switch to ON position.
2. Turn ASCD main switch to ON and check if the "SET indicator" blinks.

If the indicator lamp blinks, check the following.

- ASCD steering switch. Refer to "DIAGNOSTIC PROCEDURE 4" (EL-235).

3. Drive the vehicle at more than 48 km/h (30 MPH) and push SET/COAST switch.

If the indicator lamp blinks, check the following.

- Vehicle speed sensor. Refer to "DIAGNOSTIC PROCEDURE 5" (EL-236).
- ASCD pump circuit. Refer to "DIAGNOSTIC PROCEDURE 6" (EL-237).
- Replace control unit.

4. Depress brake pedal slowly (brake pedal should be depressed more than 5 seconds).

If the indicator lamp blinks, check the following.

- ASCD brake/stop lamp switch. Refer to "DIAGNOSTIC PROCEDURE 3" (EL-234).

5. END. (System is OK.)

Trouble Diagnoses

SYMPTOM CHART

PROCEDURE	—		Diagnostic procedure							
REFERENCE PAGE	EL-227	EL-230	EL-232	EL-233	EL-234	EL-235	EL-236	EL-237	EL-238	
SYMPTOM	Self-diagnosis in CONSULT-II	Fail-safe system check	DIAGNOSTIC PROCEDURE 1 (POWER SUPPLY AND GROUND CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 2 (ASCD HOLD UNIT CHECK)	DIAGNOSTIC PROCEDURE 3 (ASCD BRAKE/STOP LAMP SWITCH CHECK)	DIAGNOSTIC PROCEDURE 4 (ASCD STEERING SWITCH CHECK)	DIAGNOSTIC PROCEDURE 5 (VEHICLE SPEED SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 6 (ASCD PUMP CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 7 (ASCD ACTUATOR/PUMP CHECK)	GI MA EM LC EC FE AT
ASCD cannot be set. ("SET" indicator lamp does not blink.)	X		X	X		X	X			PD
ASCD cannot be set. ("SET" indicator lamp blinks.★1)	X	X			X	X	X	X		FA
Vehicle speed does not decrease after SET/COAST switch has been pressed.	X					X			X	RA
Vehicle speed does not return to the set speed after RESUME/ACCEL switch has been pressed.★2	X					X			X	BR
Vehicle speed does not increase after RESUME/ACCEL switch has been pressed.	X					X			X	ST
System is not released after CANCEL switch (steering) has been pressed.	X					X			X	RS
Large difference between set speed and actual vehicle speed.	X						X	X	X	BT
Deceleration is greatest immediately after ASCD has been set.	X						X	X	X	HA

★1: It indicates that system is in fail-safe. After completing diagnostic procedures, perform "Fail-safe System Check" (EL-230) to verify repairs.

★2: If vehicle speed is greater than 48 km/h (30 MPH) after system has been released, pressing RESUME/ACCEL switch returns vehicle speed to the set speed previously achieved. However, doing so when the ASCD main switch is turned to "OFF", vehicle speed will not return to the set speed since the memory is canceled.

EL




IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

(POWER SUPPLY AND GROUND CIRCUIT CHECK)







AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

(ASCD HOLD UNIT CHECK)



A

CHECK HOLD UNIT OUTPUT.

1. Turn ignition switch ON.
2. Depress ASCD main switch.
3. Check voltage between hold unit terminal ③ and ground.

Does battery voltage exist?

Yes → ASCD hold unit is OK.

No → Refer to wiring diagram in EL-222.

B

CHECK POWER SUPPLY CIRCUIT FOR HOLD UNIT.

1. Turn ignition switch ON.
2. Check voltage between hold unit terminal ① and ground.

Does battery voltage exist?

Yes →

No → Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)
- Harness for open or short between fuse and hold unit

C

CHECK GROUND CIRCUIT FOR HOLD UNIT.

Check continuity between hold unit terminal ④ and ground.

Does continuity exist?

Yes →

No → Repair harness.

D

CHECK MAIN SWITCH INPUT.

1. Disconnect hold unit connector.
2. Check continuity between hold unit connector terminal ② and ground.

Condition of main switch	Continuity
Pressed	Yes
Released	No

OK →

NG → Check the following.

- ASCD steering switch
Refer to "Electrical Components Inspection" (EL-239).
- Harness for open or short between ASCD hold unit and ASCD steering switch
- ASCD steering switch ground circuit

Replace ASCD hold unit.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL





IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

(ASCD BRAKE/STOP LAMP SWITCH CHECK)



A

CHECK ASCD BRAKE SWITCH INPUT. See "BRAKE SW" in "Data monitor" mode.
When brake pedal is depressed or A/T selector lever is in "N" or "P" range:
BRAKE SW OFF
When brake pedal is released and A/T selector lever is not in "N" or "P" range:
BRAKE SW ON

OR

1. Disconnect ASCD control unit connector.
2. Turn ignition switch ON.
3. Turn ASCD main switch "ON".
4. Check voltage between control unit connector terminal ⑤ and ground.
When brake pedal is depressed or A/T selector lever is in "N" or "P" range:
Approx. 0V
When brake pedal is released and A/T selector lever is not in "N" or "P" range:
Battery voltage should exist.

Refer to wiring diagram in EL-224.

NG

Check the following.

- ASCD brake switch
Refer to "Electrical Components Inspection" (EL-239).
- Park/Neutral position switch
Refer to "Electrical Components Inspection" (EL-239).
- Park/Neutral position relay
- Diode
Refer to "Electrical Components Inspection" (EL-239).
- Harness for open or short

OK

B

CHECK STOP LAMP SWITCH INPUT. See "STOP LAMP SW" in "Data monitor" mode.
When brake pedal is released:
STOP LAMP SW OFF
When brake pedal is depressed:
STOP LAMP SW ON

OR

1. Disconnect ASCD control unit connector.
2. Check voltage between ASCD control unit terminal ⑪ and ground.

Condition		Voltage V
Stop lamp switch	Depressed	Approx. 12
	Released	0

Refer to wiring diagram in EL-223.

NG

Check the following.

- 15A fuse [No. 37], located in the fuse block (J/B)]
- Stop lamp switch
Refer to "Electrical Components Inspection" (EL-239).
- Harness for open or short.

OK

ASCD brake/stop lamp switch is OK.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 4

(ASCD STEERING SWITCH CHECK)

A

DATA MONITOR	
MONITOR	NO DTC
SET SW	OFF
RESUME/ACC SW	OFF
CANCEL SW	OFF
RECORD	

SEL515W



A

CHECK ASCD STEERING SWITCH INPUT.

See "SET SW", "RESUME/ACC SW" and "CANCEL SW" in "Data monitor" mode.
SET SW, RESUME/ACC SW and CANCEL SW
When switch is pressed: ON
When switch is released: OFF

OR

1. Disconnect ASCD control unit connector.
2. Check voltage between control unit terminals and ground.

	Terminal No.		Switch condition	
	+	-	Pressed	Released
SET/COAST SW	②	Ground	12V	0V
RESUME/ACC SW	①	Ground	12V	0V
CANCEL SW	②	Ground	12V	0V
	①	Ground	12V	0V

Refer to wiring diagram in EL-223.

OK → ASCD steering switch is OK.

NG

CHECK POWER SUPPLY FOR ASCD STEERING SWITCH.
Does horn work?

NG → Check the following.

- 15A fuse (No. 64, located in the fuse, fusible link and relay box)
- Horn relay
- Harness for open or short between horn relay and fuse

B

CHECK ASCD STEERING SWITCH.
Check continuity between terminals by pushing each switch.

Switch	Terminal		
	①	③	②
SET/COAST	○	—	○
RESUME/ACCEL	○	○	—
CANCEL	○	→	○
	○	→	○

NG → Replace ASCD steering switch.




OK

Check the following.

- Harness for open or short between ASCD steering switch and ASCD control unit
- Harness for open or short between ASCD steering switch and spiral cable

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 5 (VEHICLE SPEED SIGNAL CHECK)




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

(ASCD PUMP CIRCUIT CHECK)



A

CHECK ASCD PUMP.

1. Disconnect ASCD pump connector.
2. Measure resistance between ASCD pump terminals ① and ②, ③, ④.

Terminals		Resistance Ω
①	④	Approx. 3
	②	Approx. 65
	③	Approx. 65

Refer to wiring diagram in EL-225.

NG

Replace ASCD pump.

OK

Check harness for open or short between ASCD pump and ASCD control unit.



If a self-diagnostic result has already been accomplished, check using the following table.

CONSULT-II self-diagnostic result	Check circuit	
	ASCD control unit terminal	ASCD pump terminal
POWER SUPPLY-VALVE	⑧	①
VACUUM PUMP	⑨	④
AIR VALVE	⑩	②
RELEASE VALVE	⑪	③

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL




IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

(ASCD ACTUATOR/PUMP CHECK)



A

CHECK VACUUM HOSE. Check vacuum hose (between ASCD actuator and ASCD pump) for breakage, cracks or fracture.

NG → Repair or replace hose.

OK ↓

CHECK ASCD WIRE. Check wire for improper installation, rust formation or breaks.

NG → Repair or replace wire. Refer to "ASCD Wire Adjustment" (EL-240).

OK ↓

B

CHECK ASCD ACTUATOR.

1. Disconnect vacuum hose from ASCD actuator.
2. Apply -40 kPa (-0.41 kg/cm^2 , -5.8 psi) vacuum to ASCD actuator with hand vacuum pump.
3. Wait 10 seconds and check for decrease in vacuum pressure.

ASCD wire should move to pull throttle drum.

Vacuum pressure decrease:
Less than 2.7 kPa (0.028 kg/cm^2 , 0.39 psi)

NG → Replace ASCD actuator.

OK ↓

C

CHECK ASCD PUMP.

1. Disconnect vacuum hose from ASCD pump and ASCD pump connector.
2. If necessary remove ASCD pump.
3. Connect vacuum gauge to ASCD pump.
4. Apply 12V direct current to ASCD pump and check operation.


	12V direct current supply terminals		Operation
	⊕	⊖	
Air valve	①	②	Close
Release valve		③	Close
Vacuum motor		④	Operate

A vacuum pressure of at least -35 kPa (-0.36 kg/cm^2 , -5.1 psi) should be generated.

NG → Replace ASCD pump.

OK ↓

ASCD actuator/pump is OK.




Electrical Components Inspection

ASCD STEERING SWITCH

Check continuity between terminals by pushing each button.


Button	Terminal				
	①	③	②	④	⑤
SET/COAST	○		○		
RESUME/ACCEL	○	○			
CANCEL	○	▶	○		
	○	▶	○		
MAIN				○	○



ASCD BRAKE SWITCH AND STOP LAMP SWITCH

Condition	Continuity	
	ASCD brake switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No


Check each switch after adjusting brake pedal — refer to BR section, “BRAKE PEDAL AND BRACKET”.



PARK/NEUTRAL POSITION SWITCH

Check continuity between terminals by setting selector lever to each position.

Selector lever position	Terminal		
	③	⑦	⑨
“N”	○		○
“P”	○	○	
Others			



DIODE


- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specifications may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for your tester.

Terminals		Continuity
①	②	Yes

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

ASCD Wire Adjustment



CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Adjust the tension of ASCD wire in the following manner.

1. Loosen lock nut and adjusting nut.
2. Make sure that accelerator wire is properly adjusted. (Refer to FE section, "ACCELERATOR CONTROL SYSTEM".)
3. Tighten adjusting nut until throttle drum just starts to move.
4. Loosen adjusting nut again 1/2 to 1 turn.
5. Tighten lock nut.

Overall Description

OUTLINE

The In-Vehicle Multiplexing System, IVMS (LAN system), consists of a BCM (Body Control Module) and five LCUs (Local Control Units). Some switches and electrical loads are connected to each LCU. Some electrical systems are directly connected to the BCM. Control of each LCU, (which is provided by a switch and electrical load), is accomplished by the BCM, via multiplex data lines (A-1, A-2 or A-3) connected between them.

GI

BCM (Body Control Module)

The BCM, which is a master unit of the IVMS (LAN), consists of microprocessor, memory and communication LSI sections and has communication and control functions. It receives data signals from the LCUs and sends electrical load data signals to them.

MA

EM

LCU (Local Control Unit)

The LCUs, which are slave units of the BCM, have only a communication function and consist of communication LSI and input-output interface circuits. They receive data signals from the BCM, control the ON/OFF operations of electrical loads and the sleep operation, as well as send switch signals to the BCM.

LG

EC

CONTROLLED SYSTEMS

The IVMS controls several body-electrical systems. The systems included in the IVMS are as follows:

FE

- Power window
- Power door lock
- Multi-remote control system
- Theft warning system
- Interior illumination control system
- Step lamp
- Illumination (Power window switch illumination)
- Auto drive positioner
- Auto light (Refer to "HEADLAMP", EL-47.)
- Door open warning (Refer to "WARNING LAMPS", EL-115.)
- Ignition key warning (Refer to "WARNING CHIME", EL-132.)
- Light warning (Refer to "WARNING CHIME", EL-132.)
- Seat belt warning (Refer to "WARNING CHIME", EL-133.)
- Wiper amp. (Refer to "WIPER AND WASHER", EL-142.)
- Rear window defogger timer (Refer to "REAR WINDOW DEFOGGER", EL-163.)
- Trouble-diagnosing system
 - with CONSULT-II
 - ON BOARD

AT

PD

FA

RA

BR

ST

Also, IVMS has the "sleep/wake-up control" function. IVMS puts itself (the whole IVMS system) to sleep under certain conditions to prevent unnecessary power consumption. Then, when a certain input is detected, the system wakes itself up. For more detailed information, refer to "Sleep/Wake-up Control".

RS








BT

HA

EL

IDX

Component Parts Location




System Diagram

● : Output
○ : Input


- | | | | |
|----------------------------------|---|--------------------------------|------------------------------------|
| ● Telescopic motor | ● Horn relay | ○ Telescopic switch (Forward) | ○ Interior lamp switch (ON) |
| ● Tilt motor | ● Sunroof relay | ○ Telescopic switch (Backward) | ○ Interior lamp switch (OFF) |
| ● Seat memory indicator-1 | ● Multi-remote control relay | ○ Tilt switch (Up) | ○ Rear personal lamp switch (Full) |
| ● Seat memory indicator-2 | ● Security indicator | ○ Tilt switch (Down) | ○ Lighting switch (1st) |
| ● Trunk lid opener actuator | ● Theft warning horn relay | ○ ADP cancel switch | ○ Lighting switch (Auto) |
| ● Ignition key hole illumination | ● Theft warning lamp relay | ○ Tilt sensor | ○ Front wiper switch (INT) |
| ● Door warning lamp | ● Warning chime | ○ Telescopic sensor | ○ Front wiper switch (WASH) |
| ● Rear window defogger relay | ○ Trunk room lamp switch | ○ Seat memory switch-1 | ○ Front wiper volume switch |
| ● Console lamp | ○ Hood switch | ○ Seat memory switch-2 | ○ Front wiper relay (Auto stop) |
| ● Map lamp LH | ○ Trunk lid key cylinder switch (Unlock) | ○ Seat set switch | ○ Vehicle speed sensor |
| ● Map lamp RH | ○ Seat belt buckle switch (Driver side) | ○ Driver side door switch | ○ Rear window defogger switch |
| ● Footwell lamp | ○ Front door key cylinder switch (Driver side) (Unlock) | ○ Passenger side door switch | ○ Antenna for multi-remote control |
| ● Rear personal lamp LH | ○ Door key cylinder switch (Passenger side) (Unlock) | ○ Rear door switch LH | ○ Optical sensor |
| ● Rear personal lamp RH | ○ Illumination time control switch | ○ Rear door switch RH | |
| ● Front wiper relay | | ○ Ignition switch (START) | |
| ● Headlamp relay | | ○ Ignition switch (ON) | |
| ● Tail lamp relay | | ○ Ignition switch (ACC) | |
| | | ○ Key switch (Insert) | |

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Sleep/Wake-up Control


SLEEP CONTROL



“Sleep” control prevents unnecessary power consumption. After the following conditions are met, the BCM suspends the communication between itself and all LCU’s. The whole IVMS is set in the “sleep” mode.

- Ignition switch “OFF”
- All electrical loads (in the IVMS) “OFF”
- Timer “OFF”

WAKE-UP CONTROL



As shown above, when the BCM detects a “wake-up” signal, it wakes up the whole system and starts communicating again. The “sleep” mode of all LCUs is now canceled, and the BCM returns to the normal control mode. When any one of the following switches are turned ON, the “sleep” mode is canceled:

- | | |
|--|---|
| <ul style="list-style-type: none"> ● Ignition key switch (Insert)* ● Ignition switch “ACC” or “ON” ● Lighting switch (1st) ● Interior lamp switch ● Rear personal lamp switch ● Door switches (all doors) ● Multi-remote controller ● Trunk room lamp switch | <ul style="list-style-type: none"> ● Hood switch ● Driver’s side door key cylinder switch (Unlock) ● Passenger side door key cylinder switch (Unlock) ● Trunk lid key cylinder switch (Unlock) ● Steering tilt switch ● Steering telescopic switch ● All switches combined or connected with LCU |
|--|---|

* Also, when key is pulled out of ignition (ignition key switch is turned from ON to OFF), the “sleep” mode is canceled.

Fail-safe System

Fail-safe system operates when the signal from LCU is judged to be malfunctioning by BCM. If LCU sends no signal or an abnormal signal to BCM a certain number of times in succession, the IVMS is set in a fail-safe condition. In the fail-safe condition, the electrical loads controlled by the switch on the questionable LCU will be operated at fail-safe side.

CONSULT-II

DIAGNOSTIC ITEMS APPLICATION

Test item	Diagnosed system	MODE						
		IVMS COMM DIAGNOSIS	WAKE-UP DIAGNOSIS	SELF-DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST	WORK SUPPORT	
IVMS-COMM CHECK	IVMS communication and wake-up function	X	X					GI
POWER WINDOW	Power window				X	X		MA
DOOR LOCK	Power door lock			X	X	X		EM
AUTO DRIVE POSITIONER	Automatic drive positioner			X	X	X		LC
WIPER	Wiper and washer				X	X	X	EC
REAR DEFOGGER	Rear window defogger				X	X		FE
IGN KEY WARN ALM	Warning chime				X	X		AT
LIGHT WARN ALM	Warning chime				X	X		PD
SEAT BELT TIMER	Warning chime				X	X		FA
THEFT WARNING SYSTEM	Theft warning system				X	X		RA
STEP LAMP	Step lamps				X	X		BR
ILLUM LAMP	Illumination				X	X		ST
MULTI-REMOTE CONT SYS	Multi-remote control				X	X	X	RS
INTERIOR ILLUMINATION	Interior illumination control system				X	X		BT
SUNROOF RELAY	Sunroof				X	X		HA
DOOR OPEN WARNING	Warning lamps				X	X		EL
AUTO LIGHT SYSTEM	Headlamp				X	X		IDX

X: Applicable

For diagnostic item in each control system, read the CONSULT-II Operation Manual.

DIAGNOSTIC ITEMS DESCRIPTION


MODE	Description
IVMS COMM DIAGNOSIS	Diagnosis of continuity in the communication line(s), and of the function of the communication interface between the body control module and the local control units, accomplished by transmitting a signal from the body control module to the local control units.
WAKE-UP DIAGNOSIS	Diagnosis of the "wake-up" function of local control units by having a technician input the switch data into the local control unit that is in the temporary "sleep" condition.
SELF-DIAGNOSTIC RESULTS	—
DATA MONITOR	Displays data relative to the body control module (BCM) input signals and various control related data for each system.
ACTIVE TEST	Turns on/off actuators, relay and lamps according to the commands transmitted by the CONSULT-II unit.
WORK SUPPORT for WIPER	Wiper intermittent speed control by vehicle speed can be canceled or resumed.
WORK SUPPORT for MULT-REMOTE CONT SYS	ID code of multi-remote controller can be registered and erased.

NOTE: When CONSULT-II diagnosis is operating, some systems under IVMS control do not operate.


IVMS (LAN)

CONSULT-II (Cont'd)


CONSULT-II INSPECTION PROCEDURE




1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.



3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Perform each diagnostic item according to the item application chart as follows:

For further information, read the CONSULT-II Operation Manual.

IVMS (LAN)

CONSULT-II (Cont'd)

WAKE-UP DIAGNOSIS

WAKE-UP DIAGNOSIS	
TOUCH START. DIAGNOSE WAKE-UP FUNCTION FOR ALL LCUs IN ORDER.	
START	

SEL476W

1. Touch "WAKE-UP DIAGNOSIS" in "IVMS-COMM CHECK".
2. Touch "START" for "WAKE-UP DIAGNOSIS".

WAKE-UP DIAGNOSIS	
CONTROL UNIT	POWER WINDOW C/U-DR
TOUCH 'START' AND TURN THE FOLLOWING SWITCH (ES) ON WITHIN 15 SECONDS.	
P/W SW DR-UP	
NEXT	START

SEL477W

3. After touching "START", turn ON switch designated on CONSULT-II display within 15 seconds.

WAKE-UP DIAGNOSIS		
DTC RESULTS		
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.		
END	PRINT	NEXT

SEL478W

4. If no DTC is detected, touch "NEXT" and perform wake-up diagnosis for next LCU or touch "END". (INSPECTION END)

WAKE-UP DIAGNOSIS		
DTC RESULTS		
POWER WINDOW C/U-DR		
END	PRINT	NEXT

SEL479W

If any problem is displayed, replace the LCU.

WAKE-UP DIAGNOSIS		
DTC RESULTS		
SW DATA UNMATCH		
END	PRINT	RETEST

SEL517W

If "SW DATA UNMATCH" is displayed, touch "RETEST" and perform wake-up diagnosis again.

IVMS (LAN)

CONSULT-II (Cont'd)

IVMS COMMUNICATION DIAGNOSES RESULTS LIST — 1

Diagnostic item	Number of malfunctioning LCU	CONSULT-II diagnosis result	On board diagnosis (Mode 1) code No.	Expected cause	Service procedure	
IVMS system is in good order	—	NO FAILURE	11	—	—	GI
Communication malfunctioning	One	POWER WINDOW C/U-DR [COMM FAIL]	24	1. Malfunctioning LCU	1. Replace LCU.*	MA
		POWER WINDOW C/U-AS [COMM FAIL]	34			EM
		POWER WINDOW C/U-RR [COMM FAIL]	41			LC
		POWER WINDOW C/U-RL [COMM FAIL]	44			EC
		POWER SEAT C/U-DR [COMM FAIL]	47			FE
	Two or more	Combination of POWER WINDOW C/U-DR [COMM FAIL] POWER WINDOW C/U-AS [COMM FAIL] POWER WINDOW C/U-RR [COMM FAIL] POWER WINDOW C/U-RL [COMM FAIL] POWER SEAT C/U-DR [COMM FAIL]	Combination of 24 34 41 44 47	1. Malfunctioning LCU	1. Replace LCU.*	AT
						PD
						FA
						RA
						BR
All	BCM [COMM FAIL]	24, 34, 41, 44 and	1. Malfunctioning BCM 2. Malfunctioning all LCUs	1. Replace BCM.* 2. Replace all LCUs.*	ST	
	BCM [COMM FAIL 2]	47			RS	

*: Before replacing BCM/LCU, clear the memory of diagnoses result and perform communication diagnoses again.

If the diagnoses result is still NG, replace BCM/LCU.

NOTE: When CONSULT-II indicates [PAST COMM FAIL] or [PAST NO RESPONSE], erase the memory and perform communication diagnoses again.

To erase the memory, perform the procedure below.

Erase the memory by CONSULT-II or turn the ignition to "OFF" position and remove 7.5A fuse [No. 14], located in the fuse block (J/B).

EL

IDX

IVMS (LAN)

CONSULT-II (Cont'd)

IVMS COMMUNICATION DIAGNOSES RESULTS LIST — 2

Diagnostic item	Number of malfunctioning LCU	CONSULT-II diagnosis result	On board diagnosis (Mode 1) code No.	Expected cause	Service procedure (Reference page)
	One	POWER WINDOW C/U-DR [NO RESPONSE]	25	1. Power supply circuit for LCU 2. Poor connection at LCU connector 3. Ground circuit of the LCU 4. Open circuit in the data line 5. Malfunctioning LCU	1. Check power supply circuit of the LCU in question. (EL-264) 2. Check connector connection of LCU in question. 3. Check ground circuit of the LCU in question. (EL-263) 4. Check open circuit in the data line between BCM and LCU in question. (EL-265) 5. Replace LCU.*
		POWER WINDOW C/U-AS [NO RESPONSE]	35		
		POWER WINDOW C/U-RR [NO RESPONSE]	42		
POWER WINDOW C/U-RL [NO RESPONSE]		45			
POWER SEAT C/U-DR [NO RESPONSE]		48			
Communication via data line not responded	Two or more	Combination of POWER WINDOW C/U-DR [NO RESPONSE] POWER WINDOW C/U-AS [NO RESPONSE] POWER WINDOW C/U-RR [NO RESPONSE] POWER WINDOW C/U-RL [NO RESPONSE] POWER SEAT C/U-DR [NO RESPONSE]	Combination of 25 35 42 45 48	Combination of causes below 1. Power supply circuit for LCU 2. Poor connection at LCU connector 3. Open circuit in the data line	1. Check power supply circuit of the LCU in question. (EL-264) 2. Check connector connection of LCU in question. 3. Check open circuit in the data line between BCM and LCU in question. (EL-265)
	All	BCM/HARNESS [COMM LINE]	25, 35, 42, 45, 48 and 62	1. Short circuit in the data line 2. Poor connection at BCM connector 3. Open circuit in the data line between BCM and all LCUs. 4. Malfunctioning BCM 5. Short circuit in the data line of LCU internal circuit	1. Short circuit in the data line between BCM and any LCU. (EL-265) 2. Check connector connection of BCM. 3. Check open circuit in the data line between BCM and all LCUs. (EL-265) 4. Replace BCM.* 5. Disconnect each LCUs one by one to check whether the other LCUs operate properly.

*: Before replacing BCM/LCU, clear the memory of diagnoses result and perform communication diagnoses again.
If the diagnoses result is still NG, replace BCM/LCU.

NOTE: When CONSULT-II indicates [PAST COMM FAIL] or [PAST NO RESPONSE], erase the memory and perform communication diagnoses again.

To erase the memory, perform the procedure below.

Erase the memory by CONSULT-II or turn the ignition to "OFF" position and remove 7.5A fuse [No. 14], located in the fuse block (J/B).

IVMS (LAN)

CONSULT-II (Cont'd)

IVMS COMMUNICATION DIAGNOSES RESULTS LIST — 3

Diagnostic item	Number of malfunctioning LCU	CONSULT-II diagnosis result	On board diagnosis (Mode 1) code No.	Expected cause	Service procedure
Sleep control of LCU is malfunctioning	One	POWER WINDOW C/U-DR [SLEEP]	—	1. Malfunctioning LCU	1. Replace LCU.*
		POWER WINDOW C/U-AS [SLEEP]			
	POWER WINDOW C/U-RR [SLEEP]	—	1. Malfunctioning LCU	1. Replace LCU.*	
	Two or more	POWER WINDOW C/U-RL [SLEEP]	—	1. Malfunctioning LCU	1. Replace LCU.*
		POWER SEAT C/U-DR [SLEEP]			


*: Before replacing BCM/LCU, clear the memory of diagnoses result and perform communication diagnoses again.
If the diagnoses result is still NG, replace BCM/LCU.

NOTE: When CONSULT-II indicates [PAST COMM FAIL] or [PAST NO RESPONSE], erase the memory and perform communication diagnoses again.

To erase the memory, perform the procedure below.

Erase the memory by CONSULT-II or turn the ignition to "OFF" position and remove 7.5A fuse [No. 14], located in the fuse block (J/B).


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



On board Diagnosis

ON BOARD DIAGNOSTIC RESULTS INDICATOR LAMP

Front map lamps and step lamps (all seats) act as the indicators for the on board diagnosis Mode I, II and III. Seat memory indicator-1 and 2 act as the indicators for the on board diagnosis Mode IV. These lamps blink simultaneously in response to diagnostic results.




ON BOARD DIAGNOSTIC FUNCTION

Mode	Function		Self-diagnostic results indicator lamp			Reference page
			Interior lamp	Step lamps (all seats)	Automatic drive positioner indicator lamps	
Mode I	IVMS communication diagnosis	Diagnosing any abnormality or inability of communication between BCM and LCUs (DATA LINES A-1, A-2 and A-3).	X	X	—	EL-253
Mode II	Switch monitor	Monitoring conditions of switches connected to BCM and LCUs.	X	X	—	EL-255
Mode III	Power door lock self-diagnosis	—	X	X	—	EL-298
Mode IV	Automatic drive positioner self-diagnosis	—	—	—	X	EL-414

X: Applicable
 —: Not applicable

- NOTE:
- When on board diagnosis Mode I, II or III is operating, all systems under IVMS control do not operate.
 - When on board diagnosis Mode IV is operating, automatic drive positioner does not operate.
 - The step lamp of malfunctioning LCU does not blink.




On board Diagnosis — Mode I (IVMS communication diagnosis)

HOW TO PERFORM MODE I

Condition

- Ignition switch: OFF
- **Lighting switch: OFF**
- Rear window defogger switch: OFF
- Doors: Closed
- Interior lamp switch: AUTO
- Driver side map lamp switch: OFF
- Passenger side map lamp switch: OFF
- Selector lever: "P" range



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


*: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

IVMS (LAN)

On board Diagnosis — Mode I (IVMS communication diagnosis) (Cont'd)

DESCRIPTION

In this mode, a malfunction code is indicated by the number of flashes from the front map lamps and step lamps as shown below:




After indicator lamp turns on for 2 seconds then off for 2 seconds, it flashes [cycling ON (0.5 sec.)/OFF (0.5 sec.)] to indicate a malfunction code of the first digit. Then, 1 second after indicator lamp turns off, it again flashes [cycling ON (0.5 sec.)/OFF (0.5 sec.)] to indicate a malfunction code of the second digit.

For example, the indicator lamp goes on and off for 0.5 seconds twice and after 1.0 seconds, it goes on and off for 0.5 seconds four times. This indicates malfunction code “24”.

MALFUNCTION CODE TABLE

Code No.	Malfunctioning LCU	Detected items	Diagnostic procedure
24	Driver door control unit (LCU01)	Malfunctioning communication	Refer to CONSULT-II DIAGNOSTIC CHART, “COMM FAIL” (EL-249).
25		No response from data line A-1	Refer to CONSULT-II DIAGNOSTIC CHART, “NO RESPONSE” (EL-250).
34	Passenger door control unit (LCU02)	Malfunctioning communication	Refer to CONSULT-II DIAGNOSTIC CHART, “COMM FAIL” (EL-249).
35		No response from data line A-2	Refer to CONSULT-II DIAGNOSTIC CHART, “NO RESPONSE” (EL-250).
41	Rear RH door control unit (LCU03)	Malfunctioning communication	Refer to CONSULT-II DIAGNOSTIC CHART, “COMM FAIL” (EL-249).
42		No response from data line A-1	Refer to CONSULT-II DIAGNOSTIC CHART, “NO RESPONSE” (EL-250).
44	Rear LH door control unit (LCU04)	Malfunctioning communication	Refer to CONSULT-II DIAGNOSTIC CHART, “COMM FAIL” (EL-249).
45		No response from data line A-2	Refer to CONSULT-II DIAGNOSTIC CHART, “NO RESPONSE” (EL-250).
47	Driver’s seat control unit (LCU05)	Malfunctioning communication	Refer to CONSULT-II DIAGNOSTIC CHART, “COMM FAIL” (EL-249).
48		No response from data line A-3	Refer to CONSULT-II DIAGNOSTIC CHART, “NO RESPONSE” (EL-250).
11	No malfunction		—



On board Diagnosis — Mode II (Switch monitor)

HOW TO PERFORM MODE II

Condition

- Ignition switch: OFF
- **Lighting switch: OFF**
- Rear window defogger switch: OFF
- Doors: Closed
- Interior lamp switch: AUTO
- Driver side map lamp switch: OFF
- Passenger side map lamp switch: OFF
- Selector lever: "P" range

GI

MA

EM

LC

Turn ignition switch "ON".

EC

Return ignition switch to "ACC" and press rear window defogger switch more than 10 times during 10 seconds.

FE

AT

Self-diagnostic results indicator lamps should turn on.

PD

Keep rear window defogger switch pressed, and turn ignition switch "ON" within 5 seconds after the indicator lamps turn on.

FA

RA

Indicator lamps turn ON.

BR

Mode II can be performed.

ST

Turn each switch ON and OFF. Note that the indicator lamp and/or buzzer goes on or off in response to switch position.

RS

BT

Turn ignition switch "OFF".
or
Drive the vehicle more than 7 km/h (4 MPH).

HA

EL

DIAGNOSIS END


IDX

IVMS (LAN)

On board Diagnosis — Mode II (Switch monitor) (Cont'd)

DESCRIPTION

In this mode, when BCM detects the input signal from a switch in IVMS as shown below, the detection is indicated by the front map lamp and front step lamps with buzzer.




SWITCH MONITOR ITEM

BCM	<ul style="list-style-type: none"> ● Lighting switch (1st) ● Lighting switch (AUTO) ● Wiper switch (INT) ● Wiper switch (WASH) ● Door switch (driver's side) ● Door switch (passenger side) ● Door switch (Rear LH) ● Door switch (Rear RH) ● Rear window defogger switch ● Detention switch ● Driver's side seat belt buckle switch ● Trunk room lamp switch ● Hood switch ● Trunk lid key cylinder switch (UNLOCK) ● Steering tilt switch (UP/DOWN) ● Steering telescopic switch (FORWARD/BACKWARD) ● Auto drive positioner cancel switch ● Seat memory switch-1 ● Seat memory switch-2 ● Seat set switch ● Multi remote controller switch 	LCU 02	<ul style="list-style-type: none"> ● Door unlock sensor ● Passenger power window sub-switch (UP/DOWN)
		LCU 03	<ul style="list-style-type: none"> ● Door unlock sensor ● Power window sub-switch (Rear RH) (UP/DOWN)
		LCU 04	<ul style="list-style-type: none"> ● Door unlock sensor ● Power window sub-switch (Rear LH) (UP/DOWN)
		LCU 05	Power seat switch (Driver's side) <ul style="list-style-type: none"> ● Slide switch (FR/RR) ● Reclining switch (FR/RR) ● Front lifter switch (UP/DOWN) ● Rear lifter switch (UP/DOWN)
	LCU 01		<ul style="list-style-type: none"> ● Power window lock switch ● Power window main switches (UP/DOWN) ● Power window automatic switch ● Door lock & unlock switch (LOCK/UNLOCK) ● Door unlock sensor

Schematic

POWER SUPPLY, GROUND AND COMMUNICATION CIRCUITS





- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

Wiring Diagram — COMM —

POWER SUPPLY, GROUND AND COMMUNICATION CIRCUITS

EL-COMM-01





REFER TO THE FOLLOWING.

- (E66) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M22) -ELECTRICAL UNITS

IVMS (LAN) Wiring Diagram — COMM — (Cont'd)

EL-COMM-02

Refer to EL-POWER.





REFER TO THE FOLLOWING.
(M4), (E66), (D1), (D21)
 -SUPER MULTIPLE JUNCTION (SMJ)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

IVMS (LAN)

Wiring Diagram — COMM — (Cont'd)


EL-COMM-03




REFER TO THE FOLLOWING.
 (M4), (M50) -SUPER MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

IVMS (LAN) Wiring Diagram — COMM — (Cont'd)

EL-COMM-04



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT




REFER TO THE FOLLOWING.
M4 - SUPER MULTIPLE JUNCTION (SMJ)

*: This connector is not shown in "HARNESS LAYOUT", EL section.

HA
EL
IDX

Trouble Diagnoses

WORK FLOW






NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

IVMS (LAN)

Trouble Diagnoses (Cont'd)

GROUND CIRCUIT CHECK



Control unit	Terminals	Continuity
BCM	56 - Ground	Yes
	113 - Ground	
LCU01, LCU02, LCU03 and LCU04	14 - Ground	
	15 - Ground	

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT




HA

EL

IDX

IVMS (LAN)

Trouble Diagnoses (Cont'd) POWER SUPPLY CIRCUIT CHECK



Control unit	Terminals	Ignition switch position			
		OFF	ACC	ON	START
BCM	(104) - Ground	Battery voltage			
	(105) - Ground				
	(60) - Ground	Approx. 0V	Battery voltage		Approx. 0V
	(68) - Ground	Approx. 0V		Battery voltage	
	(55) - Ground	Approx. 0V			Battery voltage
LCU01, LCU02, LCU03 and LCU04	(15) - Ground	Battery voltage			
LCU05	(16) - Ground	Battery voltage			

Note:
CONSULT-II (data monitor) may be used to check for the ignition switch input (ACC, ON, START).

IVMS (LAN)





Trouble Diagnoses (Cont'd)

DATA LINES CIRCUIT CHECK

Data lines open circuit check

NOTE: When checking data line circuit, disconnect BCM and all LCU connectors.

1. Disconnect BCM and LCU connectors.
2. Check continuity between BCM and LCU terminals.



Control unit	Terminals		Continuity
	LCU	BCM	
LCU01	③	⑦⑩	Yes
LCU02	③	⑥①	
LCU03	③	⑦⑩	
LCU04	③	⑥①	
LCU05	②②	⑥⑦	

Data lines short circuit check

1. Disconnect BCM and all LCU connectors.
2. Check continuity between BCM terminal and body ground.

Terminals	Continuity
⑥① - Ground	No
⑥⑦ - Ground	
⑦⑩ - Ground	

3. Check voltage between BCM terminal and body ground.

Terminals	Voltage [V]
⑥① - Ground	0
⑥⑦ - Ground	
⑦⑩ - Ground	

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL


IDX

Schematic



BCM (BODY CONTROL MODULE)

BCM (Body Control Module) Schematic (Cont'd)




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

LOCAL CONTROL UNITS (LCUs)

Schematic


DRIVER'S DOOR CONTROL UNIT (LCU01)



LOCAL CONTROL UNITS (LCUs)

Schematic (Cont'd)

PASSENGER DOOR CONTROL UNIT (LCU02)




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


LOCAL CONTROL UNITS (LCUs)

Schematic (Cont'd)

REAR RH DOOR CONTROL UNIT (LCU03)




REAR LH DOOR CONTROL UNIT (LCU04)



LOCAL CONTROL UNITS (LCUs)


Schematic (Cont'd)

DRIVER'S SEAT CONTROL UNIT (LCU05)



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Component Parts and Harness Connector Location



SEL866W

System Description

OUTLINE

Power window system consists of

- a BCM (Body Control Module)
- four LCUs (Local Control Module)
- four power window regulators

BCM is connected to each LCU via DATA LINE A-1 or A-2 and LCUs supply power and ground to each power window regulator.

When ignition switch is in the “ON” position, power window will be operated depending on power window sub/main switch (which is combined with each LCU) condition.

OPERATIVE CONDITION

- Power windows can be raised or lowered with each sub-switch or the power window main switch located on the driver’s door trim when ignition key is in the “ON” position and power window lock switch on the driver’s door trim is unlocked.
- When power window lock switch is locked, no windows can be raised or lowered except for driver side window.
- When ignition key is in the “ON” position, to fully open/close the front windows, press down/pull completely on the automatic switch (main switch/front sub-switch) and release it; it needs not be held. The window will automatically open/close all the way. To stop the window, pull up/press down then release the switch.

Delayed power operation

When the ignition switch is turned to the “OFF” position, the power window will still operate for up to approximately 45 seconds unless the driver side or passenger side door is opened.

(Power window timer)

Interruption detection function

Driver’s door control unit (LCU01)/passenger door control unit (LCU02) monitor the power window regulator motor operation and the power window position (full closed or other) for front power window by the signals from encoder and limit switch in front power window regulator (driver’s side/passenger side).

When driver’s door control unit (LCU01)/passenger door control unit (LCU02) detect interruption during the following close operation in the each door,

- automatic close operation when ignition switch is in the “ON” position
- automatic close operation during power window timer operation

driver’s door control unit (LCU01)/passenger door control unit (LCU02) control each power window regulator motor for open and the power window will be lowered about 150 mm (5.91 in).

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL


IDX

Schematic




Wiring Diagram — WINDOW —

EL-WINDOW-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA




REFER TO THE FOLLOWING.
 (M4), (M50), (D1) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS

EL
IDX




POWER WINDOW — IVMS

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-03



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT




REFER TO THE FOLLOWING.
M4, D21 -SUPER MULTIPLE JUNCTION (SMJ)

HA
EL
IDX

POWER WINDOW — IVMS


Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-04



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		


- (B25), (B106), (D46), (D66), (B123), (D43), (D63)
- W, W, W, W, GY, B, B




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "POWER WINDOW".



- DATA MONITOR and ACTIVE TEST are available for the power window.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses

WORK FLOW




NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B).

POWER WINDOW — IVMS

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK



SYMPTOM CHART


PROCEDURE	Diagnostic procedure							
	EL-282	EL-282	EL-283	EL-283	EL-284	EL-285	EL-286	EL-287
REFERENCE PAGE								
SYMPTOM	Procedure 1 (Ignition switch ON signal check)	Procedure 2 (Power window lock switch check)	Procedure 3 (Power window main switch check)	Procedure 4 (Power window sub-switch check)	Procedure 5 (Power window regulator check)	Procedure 6 (Power window automatic switch check)	Procedure 7 (Front door switch check)	Procedure 8 (Encoder and limit switch check)
1	X							
2					X			
3				X				
4			X					
5		X						
6						X		X
—	X						X	

POWER WINDOW — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

(Ignition switch ON signal check)



CHECK IGNITION SWITCH ON SIGNAL.

A CONSULT-II

See "IGN ON SW" in DATA MONITOR mode.

When ignition switch is ON:

IGN ON SW ON

When ignition switch is ACC or OFF:

IGN ON SW OFF

OR

B TESTER

Check voltage between BCM terminal 68 and ground.


Condition of ignition switch	Voltage V
ON	Approx. 12
ACC or OFF	0

Refer to wiring diagram in EL-275.

NG


Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM



OK

Ignition switch ON signal is OK.



DIAGNOSTIC PROCEDURE 2

(Power window lock switch check)

CHECK POWER WINDOW LOCK SWITCH INPUT SIGNAL.

A CONSULT-II

See "MAIN SW LOCK" in DATA MONITOR mode.

"MAIN SW LOCK" should change from "OFF" to "ON" when pushing power window lock switch.

OR

B ON BOARD

Check power window lock switch operation in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

NG

Replace LCU01.

OK

Power window lock switch is OK.

POWER WINDOW — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

[Power window main switch (Driver side, Passenger side, Rear LH, RH) check]

DATA MONITOR	
MONITOR	
MAIN SW AS-UP	OFF
MAIN'S AS-DWN	OFF
MAIN SW RR-UP	OFF
MAIN'S RR-DWN	OFF
MAIN SW RL-UP	OFF
MAIN'S RL-DWN	OFF
P/W SW DR-UP	OFF
P/W SW DR-DWN	OFF
P/W SW DR-AUT	OFF
	Scroll Down
	RECORD

SEL519W

CHECK DRIVER'S DOOR TRIM POWER WINDOW MAIN SWITCH INPUT SIGNAL.

A CONSULT-II

See "MAIN SW UP or DOWN" in DATA MONITOR mode.

"MAIN SW UP or DOWN" should change from "OFF" to "ON" when pushing power window main switches.

OR

ON BOARD

Check power window main switch operation in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

OK

Power window main switch is OK.

NG → Replace LCU01.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

DATA MONITOR	
MONITOR	
P/W SW AS-UP	OFF
P/W SW AS-DWN	OFF
P/W SW RR-UP	OFF
P/W SW RR-DWN	OFF
P/W SW RL-UP	OFF
P/W SW RL-DWN	OFF
	Scroll Down
	RECORD

SEL520W

DIAGNOSTIC PROCEDURE 4

[Power window sub-switch (Passenger side, Rear LH, RH) check]

CHECK POWER WINDOW SUB-SWITCH INPUT SIGNAL.

A CONSULT-II

See "P/W SW UP or DOWN" in DATA MONITOR mode.

"P/W SW UP or DOWN" should change from "OFF" to "ON" when each sub-switch is turned ON.

OR

ON BOARD

Check power window sub-switch operation in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

OK

Power window sub-switch is OK.

NG → Replace LCU for malfunctioning portion.

- Passenger: LCU02
- Rear LH: LCU04
- Rear RH: LCU03

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 5

(Power window regulator check)

A

ACTIVE TEST	
P/W MOTOR-DRIVER	OFF
OR	
P/W MOTOR-ASSIST	OFF
P/W MOTOR-RR-RH	OFF
P/W MOTOR-RR-LH	OFF
UP	DOWN

SEL521W



A

POWER WINDOW REGULATOR ACTIVE TEST.

CONSULT-II

See "P/W MOTOR" in ACTIVE TEST mode. Perform operation shown on display. **Power window motor should operate.**

NOTE: If CONSULT-II is not available, start with diagnostic procedure B .

OK → Power window regulator is OK.

NG

B

CHECK LCU OUTPUT SIGNAL TO POWER WINDOW REGULATOR.

Check voltage between LCU connector terminals ⑪ or ⑱ and ground.

Operation	Terminals		Voltage
	+	-	
Up	⑪	Ground	Battery voltage
Down	⑱	Ground	Battery voltage

NG → Replace LCU for malfunctioning portion.

OK →

Refer to wiring diagram in EL-275, 277 or 278.

OK

C

CHECK POWER WINDOW REGULATOR MOTOR.

1. Disconnect power window regulator motor connector.
2. Apply 12V DC direct current to motor and check operation.

	Terminals		Operation
	+	-	
Front	①	③	Upward
	③	①	Downward
Rear	①	②	Downward
	②	①	Upward

NG → Replace power window regulator motor.

OK

Check harness for open or short between power window switch and power window regulator motor.

POWER WINDOW — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

(Power window automatic switch check)

A

DATA MONITOR	
MONITOR	
P/W SW DR-AUT	OFF
P/W SW AS-AUT	OFF
MAIN SW AS-AUT	OFF
RECORD	

SEL949W

CHECK POWER WINDOW AUTO SWITCH INPUT SIGNAL.

A CONSULT-II

See "P/W SW DR-AUT/AS-AUT" and "MAIN SW AS-AUT" in DATA MONITOR mode.

"P/W SW DR-AUT/AS-AUT" and "MAIN SW AS-AUT" should change from "ON" to "OFF" when completely pushing in or pulling out each power window switch.

OR

ON BOARD

Check power window switch auto operation in switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

OK

Check encoder and limit switch. (Refer to EL-287.)

NG

Replace LCU for malfunctioning portion.

- Driver: LCU01
- Passenger: LCU02

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 7

(Front door switch check)

A

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
RECORD	

SEL524W



CHECK FRONT DOOR SWITCH INPUT SIGNAL.

A CONSULT-II

See "DOOR SW" in DATA MONITOR mode.

When door is open:

DOOR SW ON

When door is closed:

DOOR SW OFF

OR

ON BOARD

Check front door switches in Switch monitor (Mode II) mode.

(Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-275.

OK

Door switch is OK.

NG

B

CHECK DOOR SWITCH.

1. Disconnect door switch connector.
2. Check continuity between terminal and switch body ground.

	Terminals	Condition	Continuity
Front door switch	① - Ground	Pressed	No
		Released	Yes

NG

Replace door switch.

OK

Check the following.


- Door switch ground condition
- Harness for open or short between door switch and BCM

POWER WINDOW — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

(Encoder and limit switch check)



CHECK DOOR WINDOW SLIDE MECHANISM


Check the following.

- Obstacles in window, glass molding, etc.
- Worn or deformed glass molding
- Door sash tilted too far inward or outward
- Door window regulator

NG

Remove obstacles or repair door window slide mechanism.

OK



CHECK POWER SUPPLY TO LIMIT SWITCH

1. Disconnect driver side/front passenger side power window regulator connectors.
2. Turn ignition switch ON.
3. Check voltage between LCU01/LCU02 connectors terminal ④ and ground. **Approx. 5V should exist.**

NG

Replace LCU for malfunctioning portion.

OK

CHECK LIMIT SWITCH OPERATION

1. Turn ignition switch OFF.
2. Connect driver side/front passenger side power window regulator connectors.
3. Turn ignition switch ON.
4. Check voltage between LCU01/LCU02 connectors terminal ④ and ground during power window closing operation.

OK

CHECK ENCODER

Measure voltage between LCU01/LCU02 connectors terminal ⑩ and ground with oscilloscope when power window is in automatic closing operation. If check result is NG, replace power window regulator for malfunctioning portion. If check result is OK, replace LCU for malfunctioning portion.

Terminal No.	Condition	Voltage (DCV)
④	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5
	Other positions	Approx. 0

NG

RESET LIMIT SWITCH

Reset limit switch. Refer to BT section. Then check voltage between LCU01/LCU02 connectors terminal ④ and ground during power window closing operation at least ten times.

NG

Replace power window regulator for malfunctioning portion.

Terminal No.	Condition	Voltage (DCV)
④	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5
	Other positions	Approx. 0

OK

B

CHECK ENCODER

Measure voltage between LCU01/LCU02 connectors terminal ⑩ and ground with oscilloscope when power window is in automatic closing operation.

NG

Replace power window regulator for malfunctioning portion.

OK

Replace LCU for malfunctioning portion.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Component Parts and Harness Connector Location



System Description

POWER SUPPLY AND GROUND

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)
- to key switch terminal 3.

Power is supplied to BCM terminal 69 through key switch terminal 4 when key switch is in ON position (key is inserted in the ignition key cylinder).

BCM is connected to LCU01, LCU02, LCU03 and LCU04 as DATA LINE A-1 or A-2.

When door switch is in OPEN position, ground is supplied

- to BCM terminal 32 or 37
- through front LH or RH door switch terminal 1.

When door is unlocked, ground is supplied

- to each door LCU terminal 5
- from terminal 2 of each door unlock sensor.

When the door is locked with the key, ground is supplied

- to LCU01 or LCU02 terminal 1
- from terminal 3 of the key cylinder switch LH or
- from terminal 1 of the key cylinder switch RH
- through body grounds M14 and M47.

When the door is unlocked with the key, ground is supplied

- to BCM terminal 31 or 27
- from terminal 1 of the key cylinder switch LH or
- from terminal 3 of the key cylinder switch RH
- through body grounds M14 and M47.

When lock/unlock signal is sent to BCM or LCU, BCM sends a lock/unlock signal to LCUs via DATA LINE A-1 or A-2. LCUs then supply power and ground to each door lock actuator.

OPERATION

- The lock & unlock switch (SW) on driver's door trim can lock and unlock all doors.
- With the lock knob on front LH or RH door set to "LOCK", all doors are locked. (Signals from front door unlock sensor)
- With the door key inserted in the key cylinder on front LH or RH door, turning it to "LOCK", will lock all doors; turning it to "UNLOCK" once unlocks the corresponding door; turning it to "UNLOCK" again within 5 seconds after the first unlock operation unlocks all of the other doors. (Signals from front door key cylinder switch)

However, if the ignition key is in the ignition key cylinder and one or more of the front doors are open, setting the lock & unlock switch, lock knob, or the door key to "LOCK" locks the doors once but then immediately unlocks them. (Combination signals from key switch, front LH or RH door switch and front LH or RH door unlock sensor) — (KEY REMINDER DOOR SYSTEM)

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX



Schematic



POWER DOOR LOCK — IVMS

Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-02




REFER TO THE FOLLOWING.
 (M4), (M50), (E66), (D1)
 -SUPER MULTIPLE JUNCTION (SMJ)

POWER DOOR LOCK — IVMS


Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-03



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

HA
EL
IDX





REFER TO THE FOLLOWING.
 (M4), (D21) -SUPER MULTIPLE
 JUNCTION (SMJ)


POWER DOOR LOCK — IVMS

Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-04




REFER TO THE FOLLOWING.
(M4), (M50) -SUPER MULTIPLE JUNCTION (SMJ)




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to Data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "DOOR LOCK".



- DATA MONITOR, ACTIVE TEST, and SELF-DIAGNOSIS are available for the power door lock.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CONSULT-II (Cont'd)

HOW TO PERFORM SELF-DIAGNOSIS

<p>SELF-DIAG RESULTS</p> <p>TOUCH START. DOOR LOCK OPERATES LOCKING AND UNLOCKING AUTOMATICALLY TO DIAGNOSE.</p>
<p>START</p>

SEL482W

1. Choose "DOOR LOCK" in SELECT TEST ITEM.
2. Touch "SELF-DIAG RESULTS" of SELECT DIAG MODE.
3. Touch "START".

<p>SELF-DIAG RESULTS</p>
<p>NOW CHECKING</p>

SEL483W

4. Start self-diagnosis on all door motors. Lock and unlock all doors by operating door motors automatically.

<p>SELF-DIAG RESULTS</p> <p>DTC RESULTS</p> <p>NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.</p>
<p>PRINT</p>

SEL484W

- When no malfunction is detected.

<p>SELF-DIAG RESULTS</p> <p>DTC RESULTS</p> <p>DOOR LOCK MOTOR-DR</p>
<p>ERASE PRINT</p>

SEL560W

- When malfunction is detected.
A summary of diagnostic results is given in the following chart.

POWER DOOR LOCK — IVMS

CONSULT-II (Cont'd)

SELF DIAGNOSTIC RESULT LIST

Diagnostic result	Explanation	Diagnostic procedure	Reference page
DOOR LOCK MOTOR-DR	The circuit for the driver side door lock actuator/unlock sensor is malfunctioning.	Procedure 5 (Door unlock sensor check)	EL-307
DOOR LOCK MOTOR-AS	The circuit for the passenger side door lock actuator/unlock sensor is malfunctioning.		
DOOR LOCK MOTOR-RR/RH	The circuit for the rear RH side door lock actuator/unlock sensor is malfunctioning.	Procedure 6 (Door lock actuator check)	EL-308
DOOR LOCK MOTOR-RR/LH	The circuit for the rear LH side door lock actuator/unlock sensor is malfunctioning.		
NO DTC IS DETECTED/ FURTHER TESTING MAY BE REQUIRED.	No malfunction in the above items	—	—

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




On board Diagnosis — Mode III (Power door lock operation)

HOW TO PERFORM MODE III

Condition

- Ignition switch: OFF
- **Lighting switch: 1st**
- Rear window defogger switch: OFF
- Doors: Closed
- Interior lamp switch: AUTO
- Driver side map lamp switch: OFF
- Passenger side map lamp switch: OFF
- Selector lever: "P" range




*1: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

POWER DOOR LOCK — IVMS

On board Diagnosis — Mode III (Power door lock operation) (Cont'd)

DESCRIPTION

In this mode, a malfunction code is indicated by the number of flashes from the front map lamps and step lamps as shown below:



After indicator lamp turns ON for 2 seconds and then turns OFF, it flashes to indicate a malfunction code. For example, the indicator lamp goes on and off for 0.5 seconds three times. This indicates malfunction code "3".

MALFUNCTION CODE TABLE

Code No.	Detected items	Diagnostic procedure	Reference page
1	Driver door lock actuator/unlock sensor	Procedure 5 (Door unlock sensor check)	EL-307
2	Passenger door lock actuator/unlock sensor		
3	Rear RH door lock actuator/unlock sensor		
4	Rear LH door lock actuator/unlock sensor	Procedure 6 (Door lock actuator check)	EL-308
9	No malfunction in the above items	—	—

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14 located in the fuse block (J/B)].

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

PROCEDURE	Self-diagnosis		Diagnostic procedure						—	
REFERENCE PAGE	EL-296	EL-298	EL-302	EL-303	EL-304	EL-305	EL-307	EL-308	EL-248	
SYMPTOM	CONSULT-II	On board diagnosis (Mode III)	Procedure 1 (Door switch check)	Procedure 2 (Key switch check)	Procedure 3 (Lock & unlock switch check)	Procedure 4 (Door key cylinder switch check)	Procedure 5 (Door unlock sensor check)	Procedure 6 (Door lock actuator check)	Wake-up diagnosis	
Key reminder door system does not operate properly.	X	X	X	X			X	X		GI MA EM LC EC
Specific door lock actuator does not operate.	X	X					X	X		FE
Power door lock does not operate with door lock & unlock switch on power window main switch.	X	X			X				X (LCU01)	AT
Power door lock does not operate with front door key cylinder operation.	X	X				X			X (LCU01, LCU02)	PD
Power door lock does not operate with front door lock knob switch.	X	X					X		X (LCU01, LCU02)	FA RA BR ST RS BT HA

EL

IDX

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 1

(Front door switch check)

A

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
RECORD	

SEL524W



CHECK FRONT DOOR SWITCH INPUT SIGNAL.

A CONSULT-II

See "DOOR SW" in DATA MONITOR mode.

When door is open:

DOOR SW ON

When door is closed:

DOOR SW OFF

OR

ON BOARD

Check front door switches in Switch monitor (Mode II) mode.

(Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-291.

OK

Door switch is OK.

NG

B

CHECK DOOR SWITCH.

1. Disconnect door switch connector.
2. Check continuity between terminal and switch body ground.

	Terminals	Condition	Continuity
Front door switch	① - Ground	Pressed	No
		Released	Yes

NG

Replace door switch.

OK

Check the following.


- Door switch ground condition
- Harness for open or short between door switch and BCM

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

[Key switch (Insert) check]



CHECK KEY SWITCH INPUT SIGNAL.

A CONSULT-II

See "IGN KEY SW" in DATA MONITOR mode.
When key is inserted in ignition key cylinder:

IGN KEY SW ON

When key is removed from ignition key cylinder:

IGN KEY SW OFF



B TESTER

Check voltage between BCM terminal ⑥ and ground.

Condition of key switch	Voltage V
Key is inserted.	Approx. 12
Key is removed.	0

Refer to wiring diagram in EL-291.

OK → Ignition key switch is OK.



CHECK KEY SWITCH.

1. Disconnect key switch connector.
2. Check continuity between key switch (insert) terminals ③ and ④ when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.

Condition	Continuity
Key is inserted.	Yes
Key is removed.	No

NG → Replace key switch (insert).

OK

Check the following.

- 10A fuse [No. 28], located in fuse block (J/B)
- Harness for open or short between key switch and fuse
- Harness for open or short between BCM and key switch

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

(Lock & unlock switch check)

A

DATA MONITOR	
MONITOR	
DOOR LK SW-LK	OFF
DOOR LK SW-UN	OFF
RECORD	

SEL561W

CHECK DOOR LOCK & UNLOCK SWITCH INPUT SIGNAL.

A CONSULT-II

See "DOOR LK SW-LK or UN" in DATA MONITOR mode.
 When lock & unlock switch is turned to lock:
DOOR LK SW-LK ON
 When lock & unlock switch is turned to unlock:
DOOR LK SW-UN ON

ON BOARD

Check door lock & unlock switch operation in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

↓ NG


Replace driver door control unit (LCU01).

OK → Lock & unlock switch is OK.

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4-(1) (Door key cylinder lock switch check)




CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK SIGNAL).

A CONSULT-II

See "KEY CYL LK" in DATA MONITOR mode.
"KEY CYL LK" should be "ON" when key inserted in door key cylinder was turned to lock.

OK → Door key cylinder switch (lock) is OK.




B TESTER

Check voltage between LCU01/02 terminal ① and ground.



Key position	Voltage V
Neutral/Unlock	Approx. 5
Lock	0

Refer to wiring diagram in EL-292 or 293.

NG



NG → Replace door key cylinder switch.



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4-(2)

(Door key cylinder unlock switch check)



CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (UNLOCK SIGNAL).


A CONSULT-II

See "KEY CYL UN" in DATA MONITOR mode.

"KEY CYL UN" should be "ON" when key inserted in door key cylinder was turned to unlock.

OK

Door key cylinder switch (unlock) is OK.



B TESTER

Check voltage between BCM terminals ②⑦ or ③① and ground.

	Terminals		Key position	Voltage V
	+	-		
LH	③①	Ground	Neutral/Lock	Approx. 12
			Unlock	0
RH	②⑦	Ground	Neutral/Lock	Approx. 12
			Unlock	0

Refer to wiring diagram in EL-291.

NG

C

CHECK DOOR KEY CYLINDER SWITCH.

1. Disconnect door key cylinder switch connector.
2. Check continuity between door key cylinder switch terminals.

Terminals	Key position	Continuity
LH: ① - ②	Neutral/Lock	No
RH: ③ - ②	Unlock	Yes


NG

Replace door key cylinder switch.

OK

Check the following.

- Door key cylinder switch ground circuit
- Harness for open or short between BCM and door key cylinder switch



POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 5

(Door unlock sensor check)

A

DATA MONITOR	
MONITOR	
LOCK SIG-DR	UNLK
LOCK SIG-AS	UNLK
LOCK SG-RR/RH	UNLK
LOCK SG-RR/LH	UNLK
RECORD	

SEL525W



CHECK DOOR UNLOCK SENSOR INPUT SIGNAL.
 OK → Door unlock sensor is OK.

A CONSULT-II

See "LOCK SIG" in DATA MONITOR mode.

When door is locked:
LOCK SIG LOCK

When door is unlocked:
LOCK SIG UNLK

OR

ON BOARD

Check door lock knob operation in Switch monitor (Mode II) mode.
 (Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-292, 293 or 294.

NG ↓

B NG → Replace door lock actuator.

CHECK DOOR UNLOCK SENSOR.

1. Disconnect door lock actuator connector.
2. Check continuity between door lock actuator (door unlock sensor) terminals ② and ④.

Condition	Continuity
Locked	No
Unlocked	Yes

OK ↓

Check the following.

- Harness for open or short between LCU and door unlock sensor
- Ground circuit for door unlock sensor

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

(Door lock actuator check)

A

ACTIVE TEST	
DR LOCK MTR-DRVR	OFF
OR	
DR LOCK MTR-ASST	OFF
DR LOCK MTR-R/RH	OFF
DR LOCK MTR-R/LH	OFF
LOCK	UNLOCK

SEL526W

CHECK DOOR LOCK MOTOR OPERATION.

A CONSULT-II

See "DR LOCK MTR" in ACTIVE TEST mode.
Perform operation shown on display.
Door lock motor should operate.

OK → Door lock actuator is OK.

B

LCU connector

LCU01: (D13)
LCU02: (D29)
LCU03: (D66)
LCU04: (D46)

SEL572UB

ON BOARD

Perform On board Diagnosis Mode III.
(Refer to EL-298.)
Door lock motor should operate.

NG →

B

Check voltage between LCU connector terminals ⑰ or ⑫ and body ground.

Door lock operation	Terminals		Voltage
	⊕	⊖	
Lock	⑫	Ground	Battery voltage
Unlock	⑰	Ground	

Refer to wiring diagram in EL-292, 293 or 294.

NG → Replace LCU for malfunctioning portion.

OK →

C

Door lock actuator connector

Front LH: (D7)
Front RH: (D26)
Rear LH: (D48)
Rear RH: (D68)

SEL024V

C

CHECK DOOR LOCK ACTUATOR.

1. Disconnect door lock actuator.
2. Apply 12V DC direct current to door lock actuator and check operation.


Door lock operation	Terminals	
	⊕	⊖
Lock	③	①
Unlock	①	③

NG → Replace door lock actuator.

OK →

Check harness for open or short between door lock actuator and LCU.

Component Parts and Harness Connector Location



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

System Description

POWER SUPPLY AND GROUND

BCM is connected to LCU01, LCU02, LCU03 and LCU04 as DATA LINE A-1 or A-2.

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)
- to key switch terminal 3.

When the key switch is in ON position (key is inserted in ignition key cylinder), power is supplied

- through key switch terminal 4
- to BCM terminal 69.

When any of the four door switches is in OPEN position, ground is supplied

- to BCM terminal 32 (37, 33, 28)
- through door switches body grounds.

When a door is unlocked, each door LCU terminal 5 receives a ground signal from terminal 2 of each door unlock sensor.

Remote controller signal input

- through window antenna
- to BCM terminal 89.

The multi-remote control system controls operation of the

- power door lock
- trunk lid opener
- panic alarm
- hazard and horn reminder

OPERATING PROCEDURE

BCM can receive signals from remote controller when key switch is in OFF position (key is not in cylinder). It then sends the signals to LCUs as DATA LINE A-1 or A-2.

Power door lock operation

When BCM receives a LOCK signal from remote controller, BCM will then send a LOCK signal

- from its terminals 70 and 61 (DATA LINES A-1 and A-2)
- to each door control unit (LCU) terminal 3.

When an UNLOCK signal is sent from remote controller once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from remote controller again within 3 seconds, all other doors will be unlocked. For detailed description, refer to "POWER DOOR LOCK — IVMS" (EL-289).

Hazard and horn reminder

Power is supplied at all times

- through 10A fuse [No. 13], located in the fuse block (J/B)
- to multi-remote control relay terminals 1, 3 and 6 and
- through 15A fuse (No. 64), located in the fusible link and fuse box)
- to horn relay terminal 1.

When BCM receives a LOCK or UNLOCK signal from remote controller, ground is supplied

- to multi-remote control relay terminal 2
- through BCM terminal 6 and
- to horn relay terminal 2
- through BCM terminal 41.

Multi-remote control relay and horn relay are now energized, and hazard warning lamps flash and horn sounds as a reminder.)

Hazard and horn reminder has a horn chirp mode and a non-horn chirp mode.


Operating function of hazard and horn reminder

	Horn chirp mode		Non-horn chirp mode	
	Hazard warning lamps	Horn	Hazard warning lamps	Horn
LOCK	Twice	Once	Twice	—
UNLOCK	Once	—	—	—

System Description (Cont'd)

How to change hazard and horn reminder

Horn chirp mode of hazard and horn reminder can be activated or deactivated by pressing LOCK and UNLOCK buttons of remote controller for more than 2 seconds at the same time. At this time, hazard warning lamps and horn turn on and off as follows.



Trunk lid opener operation

Power is supplied at all times

- through 20A fuse [No. 26], located in the fuse block (J/B)
- to trunk lid opener actuator terminal ①.

When a TRUNK OPEN signal is sent from remote controller without the ignition key inserted in the ignition key cylinder, if the trunk lid opener cancel switch is in the ON position, ground is supplied

- to trunk lid opener actuator terminal ②
- through trunk lid cancel switch terminals ① and ②, and
- through BCM terminal 109.

Then power and ground are supplied, trunk lid opener actuator opens trunk lid.

Panic alarm operation

Power is supplied at all times

- through 7.5A fuse [No. 14], located in the fuse block (J/B)
- to theft warning horn relay terminal ① and theft warning lamp relay terminal ①.

Theft warning horn relay terminal ② and theft warning lamp relay terminal ② are connected to BCM terminal 15.

Multi-remote control system activates horn and headlamps intermittently when an ALARM signal is sent from remote controller to multi-remote control system without the ignition key inserted in the ignition key cylinder. For detailed description, refer to "THEFT WARNING SYSTEM — IVMS" (EL-372).

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL



IDX

Schematic



Wiring Diagram — MULTI —

EL-MULTI-01



*: This connector is not shown in "HARNESS LAYOUT", EL section.



REFER TO THE FOLLOWING.
 (M50), (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA

EL
 IDX

MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)



REFER TO THE FOLLOWING.

(M4), (E66), (M50) -SUPER MULTIPLE JUNCTION (SMJ)


(M1), (E64), (B2) -FUSE BLOCK-JUNCTION BOX (J/B)

(M22) -ELECTRICAL UNITS


MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-03



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




REFER TO THE FOLLOWING.
 (M4), (M50) -SUPER MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

MULTI-REMOTE CONTROL SYSTEM — IVMS


Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-05



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

HA
EL
IDX





REFER TO THE FOLLOWING.
M4, D21 -SUPER MULTIPLE JUNCTION (SMJ)


MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-06




REFER TO THE FOLLOWING.
 (M4), (M50) -SUPER MULTIPLE JUNCTION (SMJ)




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "MULTI-REMOTE CONT SYS".



- WORK SUPPORT, DATA MONITOR and ACTIVE TEST are available for the multi-remote control system.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14 located in the fuse block (J/B)].


MULTI-REMOTE CONTROL SYSTEM — IVMS

Trouble Diagnoses (Cont'd)


- Note: ● Always check remote controller battery before replacing remote controller.
- The panic alarm operation and trunk open operation of multi-remote control system does not activate with the ignition key inserted in the ignition key cylinder.

TROUBLE SYMPTOM

- All functions of remote control system do not function.



- Multi-remote controller does not operate a part of the functions.



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1



A


CHECK REMOTE CONTROLLER BATTERY.

Remove battery and measure voltage across battery positive and negative terminals, ⊕ and ⊖.

Measuring terminal		Standard value
⊕	⊖	
Battery positive terminal	Battery negative terminal	2.5 - 3.0V
⊕	⊖	

Note:

Remote controller does not function if battery is not set correctly.



DIAGNOSTIC PROCEDURE 2

A

CHECK ANTENNA FEEDER CABLE.

1. Disconnect feeder cable connector from BCM.
2. Remove rear pillar garnish and disconnect feeder cable connector from rear window glass antenna. (Feeder cable connector is the one at bottom left.)
3. Check continuity between the feeder cable connectors.

Continuity should exist.

4. Check continuity between the feeder cable connector terminal and ground.

Continuity should not exist.

NG → Replace feeder cable.

OK ↓

B

CHECK REAR WINDOW GLASS ANTENNA.

1. Remove rear pillar garnish and disconnect feeder cable connector from rear window glass antenna.
2. Check continuity between glass antenna terminal and end of glass antenna.



Continuity should exist.

Note: When checking continuity, wrap tin foil around top of the probe. Then press the foil against the wire with your finger.

NG → Repair glass window antenna. Refer to REAR WINDOW DEFOGGER "Filament Repair".

OK ↓

Antenna of multi-remote control is OK.



Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 3

A

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	OFF
DOOR SW-RL	OFF
RECORD	

SEL527W

B


DATA MONITOR	
MONITOR	
LOCK SIG-DR	UNLK
LOCK SIG-AS	UNLK
LOCK SG-RR/RH	UNLK
LOCK SG-RR/LH	UNLK
RECORD	

SEL525W

C

DATA MONITOR	
MONITOR	
IGN ACC SW	ON
RECORD	

SEL505W



CHECK DOOR SWITCH INPUT SIGNAL.

A CONSULT-II

See "DOOR SW" in DATA MONITOR mode.

When door is open:

DOOR SW ON

When door is closed:

DOOR SW OFF

OR

ON BOARD

Check all doors switches in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-315.

NG

Check the following.

- Door switch
Refer to "Electrical Components Inspection" (EL-329).
- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between BCM and door switch

GI

MA

EM

LC

EC

CHECK DOOR UNLOCK SENSOR INPUT SIGNAL.

B CONSULT-II

See "LOCK SIG" in DATA MONITOR mode.

When door is locked:

LOCK SIG LOCK

When door is unlocked:

LOCK SIG UNLK

OR

ON BOARD

Check door lock knob operation in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-316, 317 or 318.

NG

Check the following.

- Door unlock sensor
Refer to "Electrical Components Inspection" (EL-329).
- Door unlock sensor ground circuit
- Harness for open or short between LCU and unlock sensor

FE

AT

PD

FA

RA

BR

CHECK IGNITION SWITCH "ACC" CIRCUIT.

C CONSULT-II

See "IGN ACC SW" in DATA MONITOR mode.

When ignition switch is ACC or ON:

IGN ACC SW ON

When ignition switch is OFF:

IGN ACC SW OFF

OR

TESTER

Check voltage between BCM terminal ⑥ and ground.

Condition of ignition switch	Voltage V
ACC or ON	Approx. 12
OFF	0

Refer to wiring diagram in EL-313.

NG

Check the following.

- 7.5A fuse [No. 23], located in fuse block (J/B)]
- Harness for open or short between BCM and fuse

RS

BT

HA

EL



IDX

OK

Ⓐ

MULTI-REMOTE CONTROL SYSTEM — IVMS

Trouble Diagnoses (Cont'd)



Ⓐ

↓

CHECK KEY SWITCH INPUT SIGNAL.

E **CONSULT-II**

See "IGN KEY SW" in DATA MONITOR mode.

When key is inserted in ignition key cylinder:

IGN KEY SW ON

When key is removed from ignition key cylinder:

IGN KEY SW OFF

OR

F **TESTER**

Check voltage between BCM terminals ⑥⑨ and ground.

Condition	Voltage V
Key is inserted	Approx. 12
Key is removed	0

Refer to wiring diagram in EL-314.

NG →

Check the following.

- 10A fuse [No. 28], located in fuse block (J/B)]
- Key switch
Refer to "Electrical Components Inspection" (EL-329).
- Harness for open or short between key switch and fuse
- Harness for open or short between BCM and key switch


OK

↓

Check operation parts in multi-remote control system for function.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4



CHECK HAZARD INDICATOR OPERATION.

Yes → Hazard indicator is OK.


A CONSULT-II

See "HAZARD" in ACTIVE TEST mode.
Perform operation shown on display.
Hazard warning lamp should illuminate.

B

1. Disconnect control unit connector.
 2. Apply ground to BCM terminal ⑥.
- Does hazard indicator illuminate?**

Refer to wiring diagram in EL-314.



No →

Check multi-remote control relay. NG → Replace.

OK →

C


CHECK POWER SUPPLY FOR MULTI-REMOTE CONTROL RELAY.

NG → Check the following.

- 10A fuse [No. 13, located in fuse block (J/B)]
- Harness for open or short between multi-remote control relay and fuse

1. Disconnect multi-remote control relay connector.
 2. Check voltage between terminal ① and ground.
- Battery voltage should exist.**

OK →



D


CHECK MULTI-REMOTE CONTROL RELAY CIRCUIT.

NG → Check harness for open or short.

1. Disconnect multi-remote control relay connector.
 2. Check voltage between terminals ③ and ⑤.
 3. Check voltage between terminals ⑥ and ⑦.
- Battery voltage should exist.**
- Battery voltage should exist.**

OK →

Check harness for open or short between BCM and multi-remote control relay.



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS



BT

HA

EL

IDX

Trouble Diagnoses (Cont'd)
DIAGNOSTIC PROCEDURE 5



CHECK HORN CHIRP OPERATION.

A CONSULT-II

See "HORN" in ACTIVE TEST mode. Perform operation shown on display.

Horn should sound.

OR

B

1. Disconnect control unit connector.
2. Apply ground to BCM terminal (41).

Does horn sound?

Refer to wiring diagram in EL-314.




Yes → Horn chirp operation is OK.

No ↓

Check harness for open or short between BCM and horn relay.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6



CHECK MULTI-REMOTE CONTROLLER OPERATION.

A CONSULT-II

See "TRUNK BTN-CON" in DATA MONITOR mode.

"TRUNK BTN-CON" should be "ON" when trunk lid opener button on multi-remote controller is continuously pressed for more than 1 second.

NG

Replace multi-remote controller.

OR

ON BOARD

Check trunk open signal from multi-remote controller in Switch monitor (Mode II) mode.

(Refer to On board Diagnosis, EL-255).

OK

CHECK TRUNK LID OPENER CIRCUIT.

B CONSULT-II

See "TRUNK OPEN S/V" in ACTIVE TEST mode.

Perform operation shown on display.

Trunk lid opener should operate.

OK

Trunk opener operation is OK.

OR

C TESTER

Check voltage between BCM connector terminal (109) and ground.

Battery voltage should exist.

Refer to wiring diagram in EL-314.

NG

Check harness for open or short between BCM and trunk lid opener cancel switch.

Note:

Trunk lid opener cancel switch should be in ON (activate) position to perform DIAGNOSTIC PROCEDURE 6.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Trouble Diagnoses (Cont'd)
DIAGNOSTIC PROCEDURE 7



A

CHECK TRUNK LID OPENER ACTUATOR.

1. Disconnect trunk lid opener actuator connector.
2. Check to see if trunk lid opens when 12V DC is applied across trunk lid opener actuator connector terminals ① and ② .


Refer to wiring diagram in EL-314.

NG → Replace trunk lid opener actuator.

OK ↓

Check the following.

- 7.5A fuse [No. 26], located in fuse block (J/B)
- Trunk lid opener cancel switch
- Harness for open or short between fuse and trunk lid opener actuator
- Harness for open or short between trunk lid opener actuator and cancel switch
- Harness for open or short between trunk lid opener cancel switch and BCM





Electrical Components Inspection

DOOR SWITCHES

Check continuity between terminals and switch body ground when door switch is pushed and released.


	Terminal No.	Condition	Continuity
Front door switch	① - Ground	Door switch is pushed.	No
		Door switch is released.	Yes
Rear door switches	① - ②	Door switch is pushed.	No
		Door switch is released.	Yes



DOOR LOCK ACTUATOR (Door unlock sensor)

Check continuity between terminals when door is locked and unlocked.

Terminal No.	Condition	Continuity
④ - ②	Door is locked.	No
	Door is unlocked.	Yes



KEY SWITCH (Insert)

Check continuity between terminals when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.

Terminal No.	Condition	Continuity
③ - ④	Key is inserted.	Yes
	Key is removed.	No

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

ID Code Entry Procedure

PROCEDURE 1 (Without CONSULT-II)

NOTE:

- If a remote controller is lost, the ID code of the lost remote controller must be erased to prevent unauthorized use. A specific ID code can be erased with CONSULT-II. However, when the ID code of a lost remote controller is not known, all controller ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new remote controllers must be re-registered. To erase all ID codes in memory, register one ID code (remote controller) four times. After all ID codes are erased, the ID codes of all remaining and/or new remote controllers must be re-registered.
- When registering an additional remote controller, the existing ID codes in memory may or may not be erased. If four ID codes are stored in memory, when an additional code is registered, only the oldest code is erased. If less than four ID codes are stored in memory, when an additional ID code is registered, the new ID code is added and no ID codes are erased.



ID Code Entry Procedure (Cont'd)

NOTE

- If you need to activate more than two additional new remote controllers, repeat the procedure “Additional ID code entry” for each new remote controller.
- Entry of maximum four ID codes is allowed. When more than four ID codes are entered, the oldest ID code will be erased.
- Even if the ID code that is already in the memory is input, the same ID code can be entered. The code is counted as an additional code.

GI

MA

EM

LC

EC


PROCEDURE 2 (With CONSULT-II)

NOTE:

If a remote controller is lost, the ID code of the lost remote controller must be erased to prevent unauthorized use. When the ID code of a lost remote controller is not known, all controller ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new remote controllers must be re-registered.

FE

AT




1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” to Data link connector.

PD

FA

RA

BR




3. Turn ignition switch “ON”.
4. Touch “START”.

ST

RS

BT

HA



5. Touch “IVMS”.

EL

IDX

ID Code Entry Procedure (Cont'd)

SELECT TEST ITEM
ILLUM LAMP
MULTI-REMOTE CONT SYS
INTERIOR ILLUMINATION
DOOR OPEN WARNING
AUTO LIGHT SYSTEM
BCM PART NUMBER

SEL485W

6. Touch "MULTI-REMOTE CONT SYS".

SELECT DIAG MODE
WORK SUPPORT
DATA MONITOR
ACTIVE TEST

SEL486W

7. Touch "WORK SUPPORT".

SELECT WORK ITEM
REMO CONT ID CONFIR
REMOTE CONT ID REG
REMO CONT ID ERASUR

SEL946W

8. The items are shown on the figure at left can be set up.
- "REMO CONT ID CONFIR"
 - Use this mode to confirm if a remote controller ID code is registered or not.
 - "REMOTE CONT ID REG"
 - Use this mode to register a remote controller ID code.


NOTE:
Register the ID code when remote controller or smart entrance control unit is replaced, or when additional remote controller is required.

- "REMO CONT ID ERASUR"
- Use this mode to erase a remote controller ID code.

System Description

OUTLINE

Interior illumination system turns interior illumination lamps on and off while operating the timer. The system operates by means of key switch, lighting switch, each door switch, driver side door unlock sensor, and switches of each lamp. This system is controlled by BCM.



TIMER OPERATION

The timer controls the lighting time of the interior illumination lamps via operation of the driver side door switch, key switch, driver side unlock sensor, and ignition key switch.

Switch	Operation
Driver side door unlock sensor	With driver side door closed and key removed from ignition key cylinder, the timer operates when driver side door unlock signal is received. The timer cancels itself when driver side door lock signal is received.
Driver side door switch	The timer operates when driver side door is opened and then closed.
Ignition key switch	The timer cancels itself when ignition key is in ACC or ON position while it is operating.
Key switch (Insert)	With driver side door closed, when key is removed from ignition key cylinder, the timer operates.

- For details of turning on/off function of each of the lamps, see the following charts.


BATTERY SAVER

When the main illumination switch and personal lamp switch are in AUTO position with ignition key in OFF or ACC position, if interior illumination lamps are turned on by door switch open signal and remain lit for more than 30 minutes, the lamps turn off automatically.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

System Description (Cont'd)


TURN ON/OFF MODE OF DRIVER SIDE DOOR OPEN/CLOSE




Note: Illumination lamp lighting is available in both 100% and 35% luminosity modes.

System Description (Cont'd)

TURN ON/OFF MODE OF PASSENGER SIDE DOOR OPEN/CLOSE



TURN ON/OFF MODE OF REAR DOOR OPEN/CLOSE




Note: Illumination lamp lighting is available in both 100% and 35% luminosity modes.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


System Description (Cont'd)

TURN ON/OFF MODE OF EACH SWITCH CONDITION



Note: Illumination lamp lighting is available in both 100% and 35% luminosity modes.


Schematic




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Wiring Diagram — ROOM/L —

EL-ROOM/L-01



Refer to EL-POWER.




REFER TO THE FOLLOWING.
 (E81) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1), (E62) -FUSE BLOCK-JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS


INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-02



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




REFER TO THE FOLLOWING.
 (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1), (E64) -FUSE BLOCK-JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS

INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-03



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M15)
W

1	1	1	1	1	1
---	---	---	---	---	---

(M61)
GY

6		1
7	5	2
	3	4

(R5)
W

REFER TO THE FOLLOWING.


(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

(M22) - ELECTRICAL UNITS

INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-04



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS

BT

HA

EL

IDX




REFER TO THE FOLLOWING.
 (M6) -SUPER MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-05



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M15) W

1	1	1	1	1	1
---	---	---	---	---	---

(M61) GY

	○	1	
5	4	3	2


(R7) W, (R8) W

REFER TO THE FOLLOWING.
(M22) -ELECTRICAL UNITS


INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-06



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT





REFER TO THE FOLLOWING.
 (M4), (M50) -SUPER MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

HA
EL
IDX


INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-07




REFER TO THE FOLLOWING.
 (M4), (E66), (D1) -SUPER
 MULTIPLE JUNCTION (SMJ)




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "INTERIOR ILLUMINATION".



- DATA MONITOR and ACTIVE TEST are available for the interior illumination.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses

WORK FLOW




NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14 located in the fuse block (J/B)].

Trouble Diagnoses (Cont'd)

WORK FLOW



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Trouble Diagnoses (Cont'd) DOOR UNLOCK SENSOR CHECK (DRIVER SIDE)



CHECK DOOR UNLOCK SENSOR INPUT SIGNAL. (DRIVER SIDE)

A CONSULT-II

See "LOCK SIG-DR" in DATA MONITOR mode.
"LOCK SIG-DR" should be "LOCK" when lock knob was locked.


OK → Door unlock sensor is OK.

OR

ON BOARD

Check driver's side door lock knob operation in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-344.



B

CHECK DOOR UNLOCK SENSOR.

1. Disconnect door lock actuator connector.
2. Check continuity between door lock actuator (door unlock sensor) terminals ② and ④ .

NG → Replace door lock actuator.

Condition	Continuity
Locked	No
Unlocked	Yes

OK

Check the following.

- Harness for open or short between LCU and door unlock sensor
- Ground circuit for door unlock sensor

Trouble Diagnoses (Cont'd) DOOR SWITCH CHECK

A

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	OFF
DOOR SW-RL	OFF
RECORD	

SEL527W

CHECK DOOR SWITCH INPUT SIGNAL.



CONSULT-II

See "DOOR SW" in DATA MONITOR mode.

When door is open:


DOOR SW ON

When door is closed:

DOOR SW OFF

OK

Door switch is OK.



ON BOARD

Check all doors switches in Switch monitor (Mode II) mode.
(Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-343.

NG


B

CHECK DOOR SWITCH.

1. Disconnect door switch connector.
2. Check continuity between terminals or switch body ground.

NG

Replace door switch.



	Terminals	Condition	Continuity
Front door switch	① - Ground	Pressed	No
		Released	Yes
Rear door switch	① - ②	Pressed	No
		Released	Yes

OK

Check the following.

- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between door switch and BCM

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

Trouble Diagnoses (Cont'd)
LIGHTING SWITCH (1ST) CHECK




A

DATA MONITOR	
MONITOR	
HD/LMP 1ST SW	ON
	RECORD

SEL500W



Trouble Diagnoses (Cont'd) KEY SWITCH (INSERT) CHECK



CHECK KEY SWITCH INPUT SIGNAL.

A CONSULT-II

See "IGN KEY SW" in DATA MONITOR mode.
When key is inserted in ignition key cylinder:

IGN KEY SW ON

When key is removed from ignition key cylinder:

IGN KEY SW OFF

B TESTER

Check voltage between BCM terminals 69 and ground.

Condition of key switch	Voltage V
Key is inserted	Approx. 12
Key is removed	0

Refer to wiring diagram in EL-339.

OK → Key switch is OK.

C

CHECK KEY SWITCH.

1. Disconnect key switch connector.
2. Check continuity between key switch (insert) terminals ③ and ④ when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.

Condition	Continuity
Key is inserted	Yes
Key is removed	No

NG → Replace key switch (insert).

OK

Check the following.

- 10A fuse [No. 28], located in fuse block (J/B)
- Harness for open or short between key switch and fuse
- Harness for open or short between BCM and key switch

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX


Trouble Diagnoses (Cont'd)

IGNITION KEY SWITCH (ACC AND IGN) INPUT SIGNAL CHECK

A

DATA MONITOR	
MONITOR	
IGN ON SW	ON
IGN ACC SW	ON
RECORD	

SEL533W



CHECK ACC AND IGN INPUT SIGNAL.

A CONSULT-II

See "IGN ON SW" and "IGN ACC SW" in DATA MONITOR mode.

When ignition switch is ON:

IGN ON SW ON
IGN ACC SW ON

When ignition switch is ACC:

IGN ON SW OFF
IGN ACC SW ON

When ignition switch is OFF:

IGN ON SW OFF
IGN ACC SW OFF

OR

B TESTER

Check voltage between BCM terminal ⑥① or ⑥② and ground.

Terminals	Ignition switch position			
	OFF	ACC	ON	START
⑥① - Ground	Approx. 0V	Battery voltage		Approx. 0V
⑥② - Ground	Approx. 0V		Battery voltage	

Refer to wiring diagram in EL-339.

NG

Check the following.


- 7.5A fuse [No. 23], located in the fuse block (J/B)]
- 7.5A fuse [No. 32], located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM

OK

ACC and IGN input signal is OK.

Trouble Diagnoses (Cont'd)

INTERIOR LAMP AND PERSONAL LAMP SWITCH CHECK



A

CHECK LAMP SWITCHES INPUT SIGNAL.

1. Disconnect BCM connector.
2. Check continuity between BCM terminals and ground.

Note: To perform this procedure, turn both map lamp switches to OFF.

Switch	Terminals	Condition	Continuity
Interior lamp	②1 - Ground	ON	Yes
		AUTO/OFF	No
	②5 - Ground	OFF	Yes
		AUTO/ON	No
Rear personal lamp LH/RH	④5 - Ground	FULL	Yes
		HALF/AUTO	No

Refer to wiring diagram in EL-340 or 342.

OK

Lamp switches are OK.

NG

Check the following.

- Lamp switch
- Lamp switch ground circuit
- Harness for open or short between BCM and lamp switch

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


INTERIOR ILLUMINATION CONTROL — IVMS

Trouble Diagnoses (Cont'd) ILLUMINATION LAMP CHECK

A

ACTIVE TEST	
FR PERSONAL LUMP	OFF
OR	
FOOT LAMP	OFF
CONSOLE LAMP	OFF
RR PERSONAL LAMP	OFF
KEY RING ILLUM	OFF
ON	

SEL534W



Check illumination lamp bulb. NG → Replace bulb.

OK ↓

Check 10A fuse [No. 27 located in the fuse block (J/B)]. NG → Replace fuse.

OK ↓

CHECK ILLUMINATION LAMP OPERATION.

1. Turn each lamp switch to the following conditions.
 Map lamp LH/RH switch: OFF
 Interior lamp switch: AUTO
 Rear personal lamp LH/RH switch: OFF

A CONSULT-II

See "FR PERSONAL LAMP (Front map lamp)", "FOOT LAMP (Footwell lamp)", "CONSOLE LAMP", "RR PERSONAL LAMP" or "KEY RING ILLUM" in ACTIVE TEST mode.
 Perform operation shown on display.
Illumination lamp should illuminate.

NG → Check the following.

- Harness for open or short between fuse and illumination lamp
- Harness for open or short between illumination lamp and BCM

OR

B

2. Disconnect BCM connector.
 3. Apply ground to each terminal of BCM connector.

Does illumination lamp turn on?


Illumination lamp	Terminals
Console lamp	②
Footwell lamp	⑬
Front map lamp LH	④⑩
Front map lamp RH	④④
Rear personal lamp RH	④⑦
Rear personal lamp LH	⑤①
Ignition key hole illumination	①①①

Refer to wiring diagram in EL-340, 341 or 342.

OK ↓

Illumination lamps and circuit is OK.

Component Parts and Harness Connector Locations



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

System Description

POWER SUPPLY AND GROUND

Power is supplied at all times

- to BCM terminal (105)
- through 7.5A fuse [No. 14], located in the fuse block (J/B).

Power is supplied at all times

- to all step lamps terminal (1)
- through 10A fuse [No. 27], located in the fuse block (J/B)].

Ground is supplied to terminal (14) of LCU01 and LCU02 through body grounds (M14) and (M47).

Ground is also supplied to terminal (14) of LCU03 and LCU04 through body grounds (B105) and (B118) or (B22) and (B35).

OPERATING PROCEDURE

BCM is connected to LCU01, LCU02, LCU03 and LCU04 as DATA LINE A-1 or A-2.


When any door switch is in OPEN position, ground is supplied

- to BCM terminal (32), (37), (33), or (28)
- through driver side, passenger side, rear LH or RH door switch.

Then BCM sends a signal to the LCU to turn on step lamp. With ground supplied, step lamp turns on.

STEP LAMP — IVMS

Schematic




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

STEP LAMP — IVMS

Wiring Diagram — STEP/L —

EL-STEP/L-01




- REFER TO THE FOLLOWING.
- (D1) -SUPER MULTIPLE JUNCTION (SMJ)
 - (M1) -FUSE BLOCK-JUNCTION BOX (J/B)
 - (M22) -ELECTRICAL UNITS


STEP LAMP — IVMS

Wiring Diagram — STEP/L — (Cont'd)

EL-STEP/L-02



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT



REFER TO THE FOLLOWING.
 (M4), (M50) -SUPER MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS





HA
EL
IDX

STEP LAMP — IVMS

Wiring Diagram — STEP/L — (Cont'd)

EL-STEP/L-03



▬ : DATA LINE



REFER TO THE FOLLOWING.
 (M4), (E66), (D1), (D21)
 -SUPER MULTIPLE JUNCTION (SMJ)


STEP LAMP — IVMS

Wiring Diagram — STEP/L — (Cont'd)



REFER TO THE FOLLOWING.
 (M4), (M50) -SUPER MULTIPLE JUNCTION (SMJ)


STEP LAMP — IVMS




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "STEP LAMP".



- DATA MONITOR and ACTIVE TEST are available for the step lamp.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

STEP LAMP — IVMS

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE

SYMPTOM: Step lamp does not illuminate/does not go off when door is opened/closed.

A

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	OFF
DOOR SW-RL	OFF
RECORD	

SEL527W



CHECK DOOR SWITCH INPUT SIGNAL.



CONSULT-II

See "DOOR SW" in DATA MONITOR mode.

When door is open:

DOOR SW ON

When door is closed:

DOOR SW OFF

OR



ON BOARD

Check all doors switches in Switch monitor (Mode II) mode.

(Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-359.

NG

Check the following.

- Door switch
- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between door switch and BCM

GI

MA

EM

LC

EC

FE

AT

OK

Check step lamp bulb.

NG

Replace bulb.

PD

OK

B

CHECK POWER SUPPLY CIRCUIT.

1. Disconnect step lamp connector.
2. Check voltage between step lamp terminal ① and ground.

Battery voltage should exist.

Refer to wiring diagram in EL-361 or 362.

NG

Check the following.

- 10A fuse [No. 27], located in the fuse block (J/B)]
- Harness for open or short between fuse and step lamp

FA

RA

BR

OK

Check harness for open or short between step lamp and LCU.

ST

RS

BT

HA

EL

IDX

System Description

REAR POWER WINDOW SWITCH ILLUMINATION

Power is supplied at all times

- to tail lamp relay terminals ① and ⑥
- through 15A fuse [No. ⑥3], located in the fuse, fusible link and relay box].

Ground is supplied

- to the lighting switch terminal ⑤
- through body grounds ②2 and ③6.

When the lighting switch is turned to 1ST or 2ND position, ground is supplied

- to tail lamp relay terminal ②
- from the lighting switch terminal ④.

Tail lamp relay is then energized, and power is supplied

- from tail lamp relay terminal ⑦
- through 7.5A fuse [No. ②2], located in the fuse block (J/B)].
- to BCM terminal ③.


BCM is connected to LCU03 and LCU04 as DATA LINE A-1 or A-2.

Rear power window switch illuminations are combined with LCUs.

When lighting switch is turned to 1ST or 2ND position, BCM sends a signal to turn on rear power window switch illuminations.

Wiring Diagram — SW/ILL —

EL-SW/ILL-01




Refer to EL-POWER.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

IDX




REFER TO THE FOLLOWING.

- (E81) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (E62) -FUSE BLOCK-JUNCTION BOX (J/B)
- (M22) -ELECTRICAL UNITS


REAR POWER WINDOW SWITCH ILLUMINATION — IVMS

Wiring Diagram — SW/ILL — (Cont'd)


EL-SW/ILL-02



— : DATA LINE




REFER TO THE FOLLOWING.
 (M4), (M50), (E66) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "ILLUM LAMP".



- DATA MONITOR and ACTIVE TEST are available for the rear power window switch illumination.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses


WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

Component Parts Harness Connector Location



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

System Description

DESCRIPTION

1. Setting the theft warning system

Disarmed phase

When the vehicle is being driven or when doors or trunk lid is open, the theft warning system is set in the disarmed phase on the assumption that the owner is inside or near the vehicle.

Pre-armed phase and armed phase

The theft warning system turns into the “pre-armed” phase when hood, trunk lid and all doors are closed and locked by key or multi-remote controller. (The security indicator lamp illuminates for 30 seconds.)

After about 30 seconds, the system automatically shifts into the “armed” phase (the system is set).

2. Canceling the set theft warning system

When the following (a) or (b) operation is performed, the armed phase is canceled.

- (a) Unlock the doors with the key or multi-remote controller.
- (b) Open the trunk lid with the key or multi-remote controller. When the trunk lid is closed after opening the trunk lid with the key or multi-remote controller, the system returns to the armed phase.

3. Activating the alarm operation of the theft warning system

Make sure the system is in the armed phase.

When the following operation (a), (b) or (c) is performed, the system sounds the horns and flashes the head-lamps for about 50 seconds.

- (a) Engine hood or any door is opened before unlocking door with key or multi-remote controller.
- (b) Door is unlocked without using key or multi-remote controller.
- (c) Trunk lid is opened without using key or multi-remote controller.

POWER SUPPLY

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)]
- to security indicator lamp terminal ①.

Power is supplied at all times

- through 7.5A fuse [No. 14], located in the fuse block (J/B)]
- to BCM terminal ⑩.

With the ignition switch in the ACC or ON position, power is supplied

- through 7.5A fuse [No. 23], located in the fuse block (J/B)]
- to BCM terminal ⑥.

With the ignition switch in the ON position, power is supplied

- through 7.5A fuse [No. 32], located in the fuse block (J/B)]
- to BCM terminal ⑧.

BCM is connected to LCU01, LCU02, LCU03 and LCU04 as DATA LINE A-1 or A-2.

INITIAL CONDITION TO ACTIVATE THE SYSTEM

The operation of the theft warning system is controlled by the doors, hood and trunk lid.

To activate the theft warning system, BCM must receive signals indicating the doors, hood and trunk lid are closed and the doors are locked.

When a door is open, BCM terminal ②⑧, ③②, ③③ or ③⑦ receives a ground signal from each door switch.

When a door is unlocked, each door LCU terminal ⑤ receives a ground signal from terminal ② of each door unlock sensor.

When the hood is open, BCM terminal ②⑩ receives a ground signal

- from terminal ① of the hood switch
- through body grounds ②② and ②③.

When the trunk lid is open, BCM terminal ①⑨ receives a ground signal

- from terminal ① of the trunk room lamp switch
- through body grounds ①②, ②② and ②③.

When the doors are locked with key or multi-remote controller and none of the described conditions exist, the theft warning system will automatically shift to armed phase.

THEFT WARNING SYSTEM — IVMS

System Description (Cont'd)

THEFT WARNING SYSTEM ACTIVATION (With key or remote controller used to lock doors)

If the key is used to lock doors, LCU01 or LCU02 terminal ① receives a ground signal

- from terminal ③ of the front door key cylinder switch (Driver side) or
- from terminal ① of the front door key cylinder switch (Passenger side)
- through body grounds (M14) and (M47)

If this signal or lock signal from remote controller is received by BCM, the theft warning system will activate automatically.

Once the theft warning system has been activated, BCM terminal ⑥⑤ supplies ground to terminal ② of the security indicator lamp.

The security lamp will illuminate for approximately 30 seconds and then blink.

Now the theft warning system is in armed phase.

GI

MA

EM

THEFT WARNING SYSTEM ALARM OPERATION

The theft warning system is triggered by

- opening a door
- opening the trunk lid
- opening the hood
- unlocking door without using the key or multi-remote controller.

Once the theft warning system is in armed phase, if BCM receives a ground signal at terminal ②⑧, ②②, ③③, ③⑦ (door switch), ①⑨ (trunk room lamp switch) or ②⑨ (hood switch), or LCU receives a ground signal at terminal ⑤ (door unlock sensor) the theft warning system will be triggered. The headlamps flash and the horn sounds intermittently.

Power is supplied at all times

- through 7.5A fuse (No. 14), located in fuse and fusible link box
- to theft warning lamp relay terminal ① and
- to theft warning horn relay terminal ①.

When the theft warning system is triggered, ground is supplied intermittently

- from terminal ①⑤ of BCM
- to theft warning lamp relay terminal ② and
- to theft warning horn relay terminal ②.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 2 or 3 minutes but will reactivate if the vehicle is tampered with again.

LC

EC

FE

AT

PD

FA

RA

THEFT WARNING SYSTEM DEACTIVATION

To deactivate the theft warning system, a door or the trunk lid must be unlocked with the key or remote controller.

When the key is used to unlock a door, BCM terminal ③① or ②⑦ receives a ground signal

- from terminal ① of the front door key cylinder switch (Driver side) or
- from terminal ③ of the front door key cylinder switch (Passenger side).

When the key is used to unlock the trunk lid, BCM terminal ②⑨ receives a ground signal from terminal ① of the trunk lid key cylinder switch.

When the BCM receives either one of these signals or unlock signal from remote controller, the theft warning system is deactivated. (Disarmed phase)

BR

ST

RS

BT

PANIC ALARM OPERATION

Multi-remote control system may or may not operate theft warning system (horn and headlamps) as required.

When the multi-remote control system is triggered, ground is supplied intermittently.

- from BCM terminal ①⑤
- to theft warning lamp relay terminal ② and
- to theft warning horn relay terminal ②.

The headlamp flashes and the horn sounds intermittently.


The alarm automatically turns off after 30 seconds or when smart entrance control unit receives any signal from multi-remote controller.

HA

EL

IDX


Schematic




THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-03



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX





REFER TO THE FOLLOWING.
 (M4), (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-04

— : DATA LINE





REFER TO THE FOLLOWING.
 (M4), (M50), (E66), (D1)
 -SUPER MULTIPLE JUNCTION (SMJ)

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-05





REFER TO THE FOLLOWING.
 (M4), (D21) -SUPER MULTIPLE JUNCTION (SMJ)

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-06





REFER TO THE FOLLOWING.
(M4), **(M50)** -SUPER MULTIPLE JUNCTION (SMJ)


THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-08




REFER TO THE FOLLOWING.
 (M50), (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "THEFT WARNING SYSTEM".



- DATA MONITOR and ACTIVE TEST are available for the theft warning system.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14 located in the fuse block (J/B)].

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

PRECAUTIONS FOR INFINITI COMMUNICATOR (IVCS)


The purpose of INFINITI Communicator is to increase security for the vehicle owner by providing a convenient way to contact the most appropriate emergency assistance provider during an emergency. Improper operation of the system may result in a police response.

The theft warning system also activates INFINITI Communicator. For details, refer to INFINITI Communicator (IVCS), EL-462.

PRELIMINARY CHECK

The system operation is canceled by turning ignition switch to “ACC” at any step between START and ARMED in the following flow chart.

NOTE: Before performing PRELIMINARY CHECK, disconnect IVCS unit connectors not to operate INFINITI communicator.



After performing preliminary check, go to symptom chart on next page.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

THEFT WARNING SYSTEM — IVMS



Trouble Diagnoses (Cont'd)

Before starting trouble diagnoses below, perform preliminary check, EL-385.

Symptom numbers in the symptom chart correspond with those of preliminary check.

SYMPTOM CHART

PROCEDURE	—		Diagnostic procedure										—											
REFERENCE PAGE	EL-385	EL-264	EL-387	EL-390	EL-391	EL-392	EL-394	EL-395	EL-396	EL-321	EL-248													
SYMPTOM	1	Theft warning system cannot be set by ...	All items	X	X	X																		
			Door outside key	X					X														X (LCU01, LCU02)	
			Multi-remote control	X													X							
	2	*1 Theft warning system does not alarm when ...	Any door is unlocked without using key or multi-remote controller	Any door is opened.	X		X																X (LCU01, 02, 03, 04)	
				Horn alarm	X									X										
				Headlamp alarm	X										X									
	3	Theft warning alarm does not activate.	Headlamp alarm																					
	4	Theft warning system cannot be canceled by ...	Door outside key									X											X (LCU01, LCU02)	
				Trunk lid key	X						X													
				Multi-remote control	X																			

X : Applicable

*1: Make sure the system is in the armed phase.

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1-(1)

(Door switch check)

A

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	OFF
DOOR SW-RL	OFF
RECORD	

SEL527W

CHECK DOOR SWITCH INPUT SIGNAL.

A CONSULT-II

See "DOOR SW" in DATA MONITOR mode.

When door is open:

DOOR SW ON

When door is closed:

DOOR SW OFF

OR

ON BOARD

Check all door switches in Switch monitor (Mode II) mode.

(Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-376.

OK

Door switch is OK, go to hood switch check.

GI


MA

EM

LC

EC

FE



NG

B

CHECK DOOR SWITCH.

1. Disconnect door switch connector.
2. Check continuity between terminals or switch body ground.

	Terminals	Condition	Continuity
Front door switch	① - Ground	Pressed	No
		Released	Yes
Rear door switch	① - ②	Pressed	No
		Released	Yes

NG

Replace door switch.


AT

PD

FA

RA

BR



OK

Check the following.

- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between door switch and BCM

ST

RS

BT

HA


EL

IDX

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1-(2) (Hood switch check)



CHECK HOOD SWITCH INPUT SIGNAL.

A CONSULT-II

See "HOOD SWITCH" in DATA MONITOR mode.

When hood is open:

HOOD SWITCH ON

When hood is closed:

HOOD SWITCH OFF


OR

ON BOARD

Check hood switch in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-377.

OK → Hood switch is OK, go to trunk room lamp switch check.



NG → Check hood switch and hood fitting condition.

NG → Adjust installation of hood switch or hood.

B

CHECK HOOD SWITCH.

1. Disconnect hood switch connector.
2. Check continuity between hood switch terminals.

Terminals	Condition	Continuity
① - ②	Pushed	No
	Released	Yes

NG → Replace hood switch.



OK → Check the following.

- Hood switch ground circuit
- Harness for open or short between BCM and hood switch

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1-(3) (Trunk room lamp switch check)



CHECK TRUNK ROOM LAMP SWITCH INPUT SIGNAL.

A CONSULT-II

See "TRUNK SWITCH" in DATA MONITOR mode.

When trunk lid is open:
TRUNK SWITCH ON

When trunk lid is closed:
TRUNK SWITCH OFF

_____ OR _____

ON BOARD

Check trunk room lamp switch in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-377.

OK → Trunk room lamp switch is OK.

NG ↓

B

CHECK TRUNK ROOM LAMP SWITCH.

1. Disconnect trunk room lamp switch connector.
2. Check continuity between trunk room lamp switch terminals.

Terminals	Condition	Continuity
① - ②	Closed	No
	Open	Yes

NG → Replace trunk room lamp switch.

OK ↓

Check the following.

- Trunk room lamp switch ground circuit
- Harness for open or short between BCM and trunk room lamp switch

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA




EL

IDX

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2 (Security indicator lamp check)



THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 3

(Door unlock sensor check)

A

DATA MONITOR	
MONITOR	
LOCK SIG-DR	UNLK
LOCK SIG-AS	UNLK
LOCK SG-RR/RH	UNLK
LOCK SG-RR/LH	UNLK
RECORD	

SEL525W



CHECK DOOR UNLOCK SENSOR INPUT SIGNAL.
A CONSULT-II

See "LOCK SIG" in DATA MONITOR mode.
 When door is locked:
LOCK SIG LOCK
 When door is unlocked:
LOCK SIG UNLK

OK → Door unlock sensor is OK.

OR
 ON BOARD
 Check door lock knob operation in Switch monitor (Mode II) mode.
 (Refer to On board Diagnoses, EL-255.)
 Refer to wiring diagram in EL-378, 379 or 380.

NG ↓

B **CHECK DOOR UNLOCK SENSOR.**
 1. Disconnect door lock actuator connector.
 2. Check continuity between door lock actuator (door unlock sensor) terminals ② and ④.

NG → Replace door lock actuator.

Condition	Continuity
Locked	No
Unlocked	Yes

OK ↓


- Check the following.
- Harness for open or short between LCU and door unlock sensor
 - Ground circuit for door unlock sensor

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4-(1) (Door key cylinder lock switch check)




CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK SIGNAL).

A CONSULT-II

See "KEY CYL LK" in DATA MONITOR mode.
"KEY CYL LK" should be "ON" when key inserted in door key cylinder was turned to lock.

OK → Door key cylinder switch (lock) is OK.




B TESTER

Check voltage between LCU01/02 terminal ① and ground.


Key position	Voltage V
Neutral/Unlock	Approx. 5
Lock	0

Refer to wiring diagram in EL-378 or 379.

NG



NG → Replace door key cylinder switch.



OK

Check the following.

- Door key cylinder switch ground circuit
- Harness for open or short between LCU and door key cylinder switch

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4-(2) (Door key cylinder unlock switch check)

A

DATA MONITOR	
MONITOR	
KEY CYL UN-DR	OFF
KEY CYL UN-AS	OFF
RECORD	

SEL538W

CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (UNLOCK SIGNAL).

A CONSULT-II

See "KEY CYL UN" in DATA MONITOR mode.

"KEY CYL UN" should be "ON" when key inserted in door key cylinder was turned to unlock.

OK → Door key cylinder switch (unlock) is OK.

B

H.S. CONNECT

BCM connector (M22)

C/UNIT CONNECTOR

27 31

PU/W PU

V

Neutral

Lock Unlock

Driver's side

Neutral

Unlock Lock

Passenger side

SEL952V

B TESTER

Check voltage between BCM terminals ⑳ or ㉑ and ground.

	Terminals		Key position	Voltage V
	⊕	⊖		
LH	㉑	Ground	Neutral/Lock	Approx. 12
			Unlock	0
RH	㉒	Ground	Neutral/Lock	Approx. 12
			Unlock	0

Refer to wiring diagram in EL-375.

C

CHECK DOOR KEY CYLINDER SWITCH.

1. Disconnect door key cylinder switch connector.
2. Check continuity between door key cylinder switch terminals.

Terminals	Key position	Continuity
LH: ① - ②	Neutral/Lock	No
RH: ③ - ②	Unlock	Yes

NG → Replace door key cylinder switch.

C

T.S. DISCONNECT

Door key cylinder switch connector

LH: (D6) RH: (D25)

3 2 1

Ω

① : Door unlock switch terminal (LH)

② : Ground terminal

③ : Door unlock switch terminal (RH)

SEL913U

- OK
- Check the following.
- Door key cylinder switch ground circuit
 - Harness for open or short between BCM and door key cylinder switch

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL



IDX

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

(Trunk lid key unlock signal check)



CHECK TRUNK LID KEY CYLINDER SWITCH INPUT SIGNAL (UNLOCK SIGNAL).

A CONSULT-II

See "TRUNK UNLK SW" in DATA MONITOR mode.
When key in key cylinder is at "NEUTRAL" position,

TRUNK UNLK SW OFF

When key is "UNLOCK" position,

TRUNK UNLK SW ON

OR

ON BOARD

Check trunk lid key cylinder switch in Switch monitor (Mode II) mode. (Refer to On board Diagnosis, EL-255.)

Refer to wiring diagram in EL-377.

OK → Trunk lid key unlock switch is OK.

NG

B

CHECK TRUNK LID KEY CYLINDER SWITCH (UNLOCK SWITCH).

1. Disconnect trunk lid key cylinder switch connector.
2. Check continuity between trunk lid key cylinder switch terminals.

Terminals	Condition	Continuity
① - ②	Neutral	No
	Unlocked	Yes

NG → Replace trunk lid key cylinder switch.

OK


Check the following.

- Trunk lid key cylinder switch ground circuit
- Harness for open or short between trunk lid key cylinder switch and BCM

THEFT WARNING SYSTEM — IVMS


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6 (Theft warning horn alarm check)



CHECK THEFT WARNING HORN ALARM OPERATION.
A CONSULT-II
 See "ALARM RELAY" in ACTIVE TEST mode.
 Perform operation shown on display.
Theft warning horn alarm should operate.

Yes → Horn alarm is OK.




B

1. Disconnect BCM connector.
 2. Apply ground to BCM terminal ⑮.
Does horn alarm activate?

Refer to wiring diagram in EL-382.

No → Check theft warning horn relay.
 NG → Replace.




C

CHECK POWER SUPPLY FOR THEFT WARNING HORN RELAY.

1. Disconnect theft warning horn relay connector.
 2. Check voltage between terminal ① and ground.
Battery voltage should exist.

NG → Check the following.
 • 7.5A fuse [No. 14, located in the fuse block (J/B)]
 • Harness for open or short between theft warning horn relay and fuse



D

CHECK THEFT WARNING HORN RELAY CIRCUIT.

1. Disconnect theft warning horn relay connector.
 2. Check voltage between terminals ③ and ⑤.
Battery voltage should exist.
 3. Check voltage between terminals ⑥ and ⑦.
Battery voltage should exist.

NG → Check harness for open or short.


OK → Check harness for open or short between theft warning horn relay and BCM.

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7 (Theft warning headlamp alarm check)



CHECK THEFT WARNING HEADLAMP ALARM OPERATION.

A CONSULT-II


See "ALARM RELAY" in ACTIVE TEST mode.

Perform operation shown on display.

Theft warning headlamp alarm should operate.

Yes → Headlamp alarm is OK.

OR



B

1. Disconnect BCM connector.
 2. Apply ground to BCM terminal ⑮.
- Does headlamp alarm activate?**

Refer to wiring diagram in EL-382.

No

Does headlamp come on when turning lighting switch "ON"?


No → Check headlamp system. Refer to "HEADLAMP".

Yes

Check theft warning lamp relay.

NG → Replace.

OK



C


CHECK POWER SUPPLY FOR THEFT WARNING LAMP RELAY.

1. Disconnect theft warning lamp relay connector.
 2. Check voltage between terminal ① and ground.
- Battery voltage should exist.**

NG → Check the following.

- 7.5A fuse [No. ⑭, located in the fuse block (J/B)]
- Harness for open or short between theft warning lamp relay and fuse

OK



D

CHECK THEFT WARNING LAMP RELAY CIRCUIT.

1. Disconnect theft warning lamp relay connector.
 2. Turn lighting switch to 2nd position.
 3. Check voltage between terminals ③ and ⑤.
- Battery voltage should exist.**


NG → Check harness for open or short.

4. Check voltage between terminals ⑥ and ⑦.
- Battery voltage should exist.**

OK

Check harness for open or short between theft warning lamp relay and BCM.

Component Parts and Harness Connector Location



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

SEL065X

EL

IDX

System Description

OPERATIVE CONDITION

The drive position and mirror can be set in 2 ways, manually and automatically.

Manual operation

The driver's seat can be adjusted for sliding, reclining, front cushion height, rear cushion height, and lumbar support with the LH power seat switches. The steering column can be adjusted for tilt and reach (telescopic) with the steering switch. The manual operation can be adjusted with the IGN key in any position.

Automatic operation

The driver's seat and steering column are adjusted to the proper positions for the driver automatically, in 3 different ways: MEMORY AUTOMATIC SET, AUTOMATIC EXITING SETTING and AUTOMATIC SET RETURN. (Automatic Drive Positioner = ADP)

CONDITIONS INHIBITING AUTOMATIC OPERATION

Automatic memory setting procedures are suspended under any of the following conditions:

- (a) When vehicle speed is more than 7 km/h (4 MPH).
- (b) When driver's side power seat switch, tilt or telescopic steering switch is turned on.
- (c) When any two of the switches (set switch and memory switches 1 and 2) are turned ON.
- (d) When cancel switch is turned on.
- (e) When selector lever is in any position other than "P".
- (f) When ignition switch is turned to "START" position.
(Operation resumes when ignition switch is returned to "ON".)
- (g) When any of the following malfunctions are detected:
 - Steering tilt lock detection
(Steering tilt lock is sensed when tilt sensor signal value does not change for a certain period of time.)
 - Steering tilt/telescopic sensor failure detection
(Sensor failure is sensed when sensor output is less than 0.1 volts or greater than 4.9 volts.)
 - Detention switch abnormality detection
[Detention switch failure is sensed when detention switch remains off for at least 2 seconds at a vehicle speed of greater than 7 km/h (4 MPH).]

FAIL-SAFE SYSTEM

Output failure

When the ignition switch is in the ON position, if any of the parts (indicated in the following chart) move more than the specified amount within a period "T2" when no "ON" input is sent from any of the switches (indicated in the following chart), or an output from the automatic drive positioner is not produced, an output failure is sensed. Motor operation will be suspended automatically, and all automatic operations will be ineffective. (In this case, the motor will not operate manually.)

OPERATED PORTION	T2	Allowable measurement
Seat sliding	Approx. 2.5 sec.	Within 6 mm (0.24 in)
Seat reclining	Same as above	Change angle within 1°
Steering tilt	Same as above	Change angle within 1°

Absolving

- When moving selector lever back to "P" position after having moved it to any position except "P", fail-safe operation will be canceled.
- If self-diagnosis is performed using CONSULT-II, fail-safe operation will be canceled.

System Description (Cont'd)

INITIALIZATION

After reconnecting battery cable, perform initialization procedure A or B. If initialization has not been performed, automatic drive positioner will not operate.

PROCEDURE A

- (1) Insert key in the ignition key cylinder. (Ignition switch is in "OFF" position.)
- (2) Open → close → open driver side door. (Do not perform with the door switch operation.)
- (3) End


PROCEDURE B

- (1) Drive the vehicle at more than 30 km/h (19 MPH).
- (2) End

MEMORY AUTOMATIC SET

Two drive positions can be retained in the memory. Press memory switch to set driver's seat to preset position.

(1) PROCEDURE FOR STORING MEMORY



NOTE: (1) When memory switch for which driver's seat positions are already retained in memory is pressed, new seat positions will be retained in memory in place of the previously set positions.
 (2) Drive position is erased from the memory when battery cable is disconnected. After connecting battery cable, perform initialization procedures.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

AUTOMATIC DRIVE POSITIONER — IVMS

System Description (Cont'd)

(2) SELECTING THE MEMORIZED POSITION



NOTES: (1) Do not keep cancel switch pressed as it will not operate.

(2) Automatic exiting setting will be performed.

(3) The driver's seat position and steering adjustment (see the following Table) operate simultaneously in the order of priority.

The order of priority	Operated portion
1	Seat sliding
2	Steering telescopic
3	Steering tilt
4	Seat reclining
5	Seat front lifting
6	Seat rear lifting


System Description (Cont'd)

AUTOMATIC EXITING SETTING

For ease of entry and exit, move driver's seat to "exiting" position.


"Exiting" positions:

Driver's seat ... Slides about 40 mm (1.57 in) rear from normal sitting position.




AUTOMATIC SET RETURN


With driver's seat set to the "exiting" position, operating one of the following procedures moves it to the position previously retained in memory.




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




Schematic



Wiring Diagram — AUT/DP —



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA





REFER TO THE FOLLOWING.
 (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1), (E64) -FUSE BLOCK-JUNCTION BOX (J/B)
 (M22) -ELECTRICAL UNITS

EL
IDX

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-02




REFER TO THE FOLLOWING.
 (M4), (M6), (E66) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)





EL-AUT/DP-03

To EL-AUT/DP-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

HA
EL
IDX





REFER TO THE FOLLOWING.
 (E66), (E81), (D1) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-04




REFER TO THE FOLLOWING.
 (M4), (E66), (E81) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M22) -ELECTRICAL UNITS

AUTOMATIC DRIVE POSITIONER — IVMS


Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-05



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

HA
EL
IDX




REFER TO THE FOLLOWING.
 (M4) -SUPER MULTIPLE JUNCTION (SMJ)

*: This connector is not shown in "HARNESS LAYOUT", EL section.

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-06



15	28	16	14
50	41	40	

B12
W

6	5	4	3	2	1			
16	15	14	13	12	11	10	9	8

S2
W

22	21	20	19	18	17		
32	31	30	27	26	25	24	23

S3
W

11	3	14	15	13	6		
10	12	32	21	31	33	5	4

S4
W

20	1
32	8

S5
W

30	2
32	9


S11
W

*: This connector is not shown in "HARNESS LAYOUT", EL section.

AUTOMATIC DRIVE POSITIONER — IVMS


Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-07




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

HA
EL
IDX




*: This connector is not shown in "HARNESS LAYOUT", EL section.




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "AUTO DRIVE POSITIONER".



- DATA MONITOR, ACTIVE TEST, and SELF-DIAGNOSIS are available for the automatic drive positioner.

CONSULT-II (Cont'd)

HOW TO PERFORM SELF-DIAGNOSIS

SELF-DIAG RESULTS	
TOUCH START. BOTH THE SEAT AND THE STEERING COLUMN MOVE TO DIAGNOSE. AFTER THEY COME TO A STOP. TRY TO DRIVE THE CAR AT THE SPEED OF 4 mph [7 km/h] OR MORE WITHIN 15 sec.	
START	

SEL488W

SELF-DIAG RESULTS	
DTC RESULTS	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
[CAR SPD SEN SYSTEM] DRIVE OVER 4mph [7km/h]	

SEL541W

SELF-DIAG RESULTS	
DTC RESULTS	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
PRINT	

SEL484W

SELF-DIAG RESULTS	
DTC RESULTS	
VEHICLE SPEED SENSOR	
ERASE	PRINT

SEL542W

1. Choose "AUTO DRIVE POSITIONER" in SELECT TEST ITEM.
2. Touch "SELF-DIAG RESULTS" of SELECT DIAG MODE.
3. Touch "START".

4. Seats and steering automatically move, and self-diagnosis will start.
5. Within 15 seconds after seat and steering come to a stop, drive the vehicle at speeds greater than 7 km/h (4 MPH) to diagnose the vehicle speed sensor.
6. After completing self-diagnosis, diagnostic results appear on the display.

- When no malfunction is detected.

- When malfunction is detected.
A summary of diagnostic results is given in the following chart.

7. Erase the diagnostic results memory.
 - a. Turn ignition switch "ON".
 - b. Touch "IVMS".
 - c. Touch "AUTO DRIVE POSITIONER".
 - d. Touch "SELF-DIAG RESULTS".
 - e. Touch "START".
 - f. Touch "ERASE".

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CONSULT-II (Cont'd)


SELF DIAGNOSTIC RESULT LIST

Diagnostic item	Explanation	Diagnostic procedure	Reference page
NO DTC IS DETECTED/FURTHER TESTING MAY BE REQUIRED.	Normal The automatic drive positioner system is in good order.	—	—
SEAT SLIDE	Condition: While the seat slide is moving backward for 2.5 seconds, then forward for 2.5 seconds. If the number of seat slide sensor pulses changes 2 times or less, the seat slide is determined to be malfunctioning.	PROCEDURE 5 (Sliding sensor check) PROCEDURE 11 (Sliding motor check)	EL-424 EL-430
SEAT RECLINING	Condition: While the seat is reclining forward for 2.5 seconds, then backward for 2.5 seconds. If the number of seat reclining sensor pulses changes 2 times or less, the seat reclining device is determined to be malfunctioning.	PROCEDURE 6 (Reclining sensor check) PROCEDURE 12 (Reclining motor check)	EL-425 EL-431
SEAT LIFTER-FR	Condition: While the lifter's front section is moving down for 2.5 seconds, then up for 2.5 seconds. If the number of sensor pulses (located in the front section of the seat lifter) changes 2 times or less, the front seat lifter is determined to be malfunctioning.	PROCEDURE 7 [Lifting sensor (front) check] PROCEDURE 13 [Lifting motor (front) check]	EL-426 EL-432
SEAT LIFTER-RR	Condition: While the lifter's rear section is moving down for 2.5 seconds, then up for 2.5 seconds. If the number of sensor pulses (located in the rear section of the seat lifter) changes 2 times or less, the rear seat lifter is determined to be malfunctioning.	PROCEDURE 8 [Lifting sensor (rear) check] PROCEDURE 14 [Lifting motor (rear) check]	EL-427 EL-433
STEERING TELESCO	Condition: While steering telesco is moving forward for 1 second, then backward for 1 second. If telesco sensor output changes 0.2 volts or less, the steering telesco section is determined to be malfunctioning.	PROCEDURE 4 (Telescopic sensor check) PROCEDURE 10 (Telescopic motor check)	EL-423 EL-429
STEERING TILT	Condition: While the steering wheel is tilting up for 1 second, then down for 1 second. If tilt sensor output changes 0.2 volts or less, the steering tilt device is determined to be malfunctioning.	PROCEDURE 3 (Tilt sensor check) PROCEDURE 9 (Tilt motor check)	EL-422 EL-428
VEHICLE SPEED SENSOR	If the vehicle speed sensor output of less than 7 km/h (4 MPH) is detected within 15 seconds after completing self-diagnosis on the seat and steering systems, the vehicle speed sensor is determined to be malfunctioning.	PROCEDURE 19 (Vehicle speed sensor check)	EL-438
DETENT SW [PAST INPUT FAIL]	If a vehicle speed of greater than 7 km/h (4 MPH) is detected while the A/T selector lever is set to "P", the detent switch input system is determined to be malfunctioning.	PROCEDURE 19 (Detent switch check)	EL-438

CONSULT-II (Cont'd)


Diagnostic item	Explanation	Diagnostic procedure	Reference page
SEAT SLIDE [PAST OUTPUT FAIL]	When neither manual input nor ADP output signal is produced, if the seat slides greater than 6 mm (0.24 in) within 2.5 seconds after the seat slide sensor receives an input signal, the seat slide output system is determined to be malfunctioning.	—	—
SEAT RECLINING [PAST OUTPUT FAIL]	When neither manual input nor ADP output signal is produced, if the seat reclines greater than 1° within 2.5 seconds after the seat reclining sensor receives an input signal, the seat reclining output system is determined to be malfunctioning.	—	—
STEERING TILT [PAST OUTPUT FAIL]	When neither manual input signal nor ADP output signal is produced, if the steering wheel tilts greater than 1° within 2.5 seconds after the steering tilt sensor receives an input signal, the steering tilt output system is determined to be malfunctioning.	—	—
TELESCO SEN [PAST]	If a voltage greater than 4.9 volts (in relation to the sensor power source of 5 volts) or less than 0.1 volts is detected across the telesco sensor, the telesco sensor system is determined to be malfunctioning.	PROCEDURE 4 (Telescopic sensor check)	EL-423
TILT SEN [PAST]	If a voltage greater than 4.9 volts (in relation to the sensor power source of 5 volts) or less than 0.1 volts is detected across the steering tilt sensor, the tilt sensor system is determined to be malfunctioning.	PROCEDURE 3 (Tilt sensor check)	EL-422

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



On board Diagnosis — Mode IV (Automatic drive positioner operation)

HOW TO PERFORM MODE IV



*1: If no malfunction is indicated, Mode IV will end after the vehicle speed sensor diagnosis is performed.

*2: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

AUTOMATIC DRIVE POSITIONER — IVMS

On board Diagnosis — Mode IV (Automatic drive positioner operation) (Cont'd)

MALFUNCTION CODE TABLE

In this mode, a malfunction code is indicated by the number of flashes from the automatic drive positioner indicator lamps (indicator lamp 1, indicator lamp 2) as shown below.

Code No.	Detected items	Indication of seat memory switches 1 and 2	Explanation
1	Seat sliding	IND1, IND2	While the seat motors are moving for 2.5 seconds, if the number of seat sliding/reclining/lifting sensor pulses changes 2 times or less, the seat device is determined to be malfunctioning.
2	Seat reclining	IND1, IND2	
3	Seat lifting front	IND1, IND2	
4	Seat lifting rear	IND1, IND2	
7	Steering telescopic	IND1, IND2	While the steering motors are moving, if the steering sensor output changes 0.2 volts or less, the steering device is determined to be malfunctioning.
8	Steering tilt	IND1, IND2	
9	Vehicle speed sensor circuit	IND1, IND2	If the vehicle speed sensor output of less than 7 km/h (4 MPH) is detected, the vehicle speed sensor is determined to be malfunctioning.
-	No malfunction in the above items		—

SEL015VA


Code No.	Detected items	Diagnostic procedure	Reference page	Code No.	Detected items	Diagnostic procedure	Reference page
1	Seat sliding	PROCEDURE 5 (Sliding sensor check) PROCEDURE 11 (Sliding motor check)	EL-424 EL-430	7	Steering telescopic	PROCEDURE 4 (Telescopic sensor check) PROCEDURE 10 (Telescopic motor check)	EL-423 EL-429
2	Seat reclining	PROCEDURE 6 (Reclining sensor check) PROCEDURE 12 (Reclining motor check)	EL-425 EL-431	8	Steering tilt	PROCEDURE 3 (Tilt sensor check) PROCEDURE 9 (Tilt motor check)	EL-422 EL-428
3	Seat lifting front	PROCEDURE 7 [Lifting sensor (front) check] PROCEDURE 13 [Lifting motor (front) check]	EL-426 EL-432	9	Vehicle speed sensor	PROCEDURE 19 (Vehicle speed sensor check)	EL-438
4	Seat lifting rear	PROCEDURE 8 [Lifting sensor (rear) check] PROCEDURE 14 [Lifting motor (rear) check]	EL-427 EL-433				

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST

RS
BT
HA
EL
IDX

Trouble Diagnoses

WORK FLOW




NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT-II will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT-II (Refer to EL-247.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14 located in the fuse block (J/B)].

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK



*1: After reconnecting battery cable, perform initialization procedure A or B.
If initialization has not been performed, automatic drive positioner will not operate.

PROCEDURE A

- (1) Insert key in the ignition key cylinder. (Ignition switch is in "OFF" position.)
- (2) Open → close → open driver side door. (Do not perform with the door switch operation.)
- (3) End

PROCEDURE B

- (1) Drive the vehicle at more than 30 km/h (19 MPH).
- (2) End

*2: If only seat slide operates during automatic exit setting, the problem may be due to mechanical tilt mechanism failure. (In this case, all other automatic operation items do not operate.)

After performing preliminary check, go to symptom chart on next page.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

Before starting trouble diagnoses below, perform preliminary check, EL-417. Symptom numbers in the symptom chart correspond with those of preliminary check.

SYMPTOM CHART

PROCEDURE		Self-diagnosis		Diagnostic procedure										
REFERENCE PAGE		EL-411	EL-414	EL-420	EL-420	EL-422	EL-423	EL-424	EL-425	EL-426	EL-427	EL-428	EL-429	
SYMPTOM		CONSULT-II	On board diagnosis (Mode V)	DIAGNOSTIC PROCEDURE 1 (Power supply and ground circuit for LCU05)	DIAGNOSTIC PROCEDURE 2 (Power supply and ground circuit for tilt/telescopic motor)	DIAGNOSTIC PROCEDURE 3 (Tilt sensor check)	DIAGNOSTIC PROCEDURE 4 (Telescopic sensor check)	DIAGNOSTIC PROCEDURE 5 (Sliding sensor check)	DIAGNOSTIC PROCEDURE 6 (Reclining sensor check)	DIAGNOSTIC PROCEDURE 7 [Lifting sensor (front) check]	DIAGNOSTIC PROCEDURE 8 [Lifting sensor (rear) check]	DIAGNOSTIC PROCEDURE 9 (Tilt motor check)	DIAGNOSTIC PROCEDURE 10 (Telescopic motor check)	
1	No seat system functions operate.			X										
2	No steering system functions operate.		X	X		X	X	X						
3	Some of the seat system functions do not operate during automatic/manual operation.	Sliding	X	X										
		Reclining	X	X										
		Lifting (Front)	X	X										
		Lifting (Rear)	X	X										
4	Some of the steering system functions do not operate during automatic/manual operation.	Tilt	X	X								X		
		Telescopic	X	X									X	
5	No functions operate during automatic operation, and some/all functions do not operate during manual operation.													
6	Some of the seat system functions do not operate during automatic operation.	Sliding	X	X				X						
		Reclining	X	X					X					
		Lifting (Front)	X	X						X				
		Lifting (Rear)	X	X							X			
7	No automatic operation functions operate.		X	X			X	X						
8	Drive position cannot be retained in the memory.													
9	Does not operate during manual operation. (Operates during automatic operation.)	Seat	Sliding											
			Reclining											
			Lifting (Front)											
			Lifting (Rear)											
		Steering	Lumber support											
10	Tilt													
		Telescopic												
11	Automatic operation cannot be canceled.													
12	Memory indicator does not light up.													


X: Applicable



AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

Diagnostic procedure	
GI	Diagnostic procedure
MA	DIAGNOSTIC PROCEDURE 11 (Sliding motor check) EL-430
EM	DIAGNOSTIC PROCEDURE 12 (Reclining motor check) EL-431
LC	DIAGNOSTIC PROCEDURE 13 [Lifting motor (front) check] EL-432
EC	DIAGNOSTIC PROCEDURE 14 [Lifting motor (rear) check] EL-433
FE	DIAGNOSTIC PROCEDURE 15 (Lifting limit switch check) EL-434
AT	DIAGNOSTIC PROCEDURE 16 (Tilt/telescopic switch check) EL-435
PD	DIAGNOSTIC PROCEDURE 17 (Power seat switch check) EL-436
BR	DIAGNOSTIC PROCEDURE 18 (Cancel switch check) EL-437
RA	DIAGNOSTIC PROCEDURE 19 (Key, detention, door switch and vehicle speed sensor check) EL-438
FA	DIAGNOSTIC PROCEDURE 20 (Seat memory switch check) EL-440
ST	DIAGNOSTIC PROCEDURE 21 (Memory indicator check) EL-441
RS	DIAGNOSTIC PROCEDURE 22 (Lumber support check) EL-441
BT	Wake-up Diagnosis for LCU05 EL-248
HA	
EL	
IDX	



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1 (Power supply and ground circuit for LCU05)


Power supply circuit check

Check voltage between LCU05 terminal ⑩ and ground.
(Refer to wiring diagram in EL-407.)

Terminals	Ignition switch position			
	OFF	ACC	ON	START
⑩ - Ground	Battery voltage			

If NG, check the following.


- 40A fusible link (letter h, located in the fuse, fusible and relay box)
- Circuit breaker-2
- Harness for open or short between circuit breaker-2 and LCU05
- Harness for open or short between fuse and circuit breaker-2



Ground circuit check

Check continuity between LCU05 terminal ⑭ and ground.
(Refer to wiring diagram in EL-407.)

Terminals	Continuity
⑭ - Ground	Yes



DIAGNOSTIC PROCEDURE 2

(Power supply and ground circuit for tilt/telescopic motor)

Power supply circuit check

Check voltage between BCM terminal ⑩④ and ground.
(Refer to wiring diagram in EL-406.)

Terminals	Ignition switch position			
	OFF	ACC	ON	START
⑩④ - Ground	Battery voltage			


If NG, check the following.

- 40A fusible link (letter h, located in the fuse, fusible and relay box)
- Circuit breaker-2
- Harness for open or short between circuit breaker-2 and BCM
- Harness for open or short between fuse and circuit breaker-2

Trouble Diagnoses (Cont'd)

Ground circuit check

Check continuity between BCM terminal (114) and ground.
(Refer to wiring diagram in EL-403.)



Terminals	Continuity
(114) - Ground	Yes

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT





HA

EL

IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3 (Tilt sensor check)



CHECK TILT SENSOR INPUT SIGNAL.

A **CONSULT-II**

See "TILT SEN" in DATA MONITOR mode.

Steering column in the uppermost position:
Approx. 2V

Steering column in the lowermost position:
Approx. 4V

OK → Tilt sensor is OK.

B **TESTER**

Check voltage between BCM terminals ④⑥ and ⑤③.

Steering column position	Voltage V
Uppermost	Approx. 2
Lowermost	Approx. 4

Refer to wiring diagram in EL-406.

NG

C **CHECK TILT SENSOR OPEN CIRCUIT.**

1. Disconnect BCM connector and tilt sensor connector.
2. Check harness continuity between BCM connector and tilt sensor connector.

Terminals		Continuity
BCM	Tilt sensor	
⑤④	①	Yes
④⑥	②	
⑤③	③	

NG → Repair harness.

OK

D **CHECK TILT SENSOR SHORT CIRCUIT.**

Check harness continuity between BCM connector terminals and ground.

Terminals	Continuity
⑤④ - ground	No
④⑥ - ground	
⑤③ - ground	





NG → Repair harness.

OK

Replace tilt sensor.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4 (Telescopic sensor check)



CHECK TELESCOPIC SENSOR INPUT SIGNAL.

A CONSULT-II

See "TELESCO SEN" in DATA MONITOR mode.
Steering column in the extreme front end position:

Approx. 4.5V

Steering column in the extreme rear end position:

Approx. 0.5V

B TESTER

Check voltage between BCM terminals ③ and ②.

Steering column position	Voltage
Extreme front end	Approx. 4.5V
Extreme rear end	Approx. 0.5V

Refer to wiring diagram in EL-406.

OK → Telescopic sensor is OK.

NG

C

CHECK TELESCOPIC SENSOR OPEN CIRCUIT.

1. Disconnect BCM connector and telescopic sensor connector.
2. Check harness continuity between BCM connector and telescopic sensor connector.

Terminals		Continuity
BCM	Telescopic sensor	
③	①	Yes
②	②	
④	③	

NG → Repair harness.

OK

D

CHECK TELESCOPIC SENSOR SHORT CIRCUIT.

Check harness continuity between BCM connector terminals and ground.

Terminals	Continuity
③ - ground	No
② - ground	
④ - ground	

NG → Repair harness.

OK

Replace telescopic sensor.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5 (Sliding sensor check)



A

CHECK SLIDING SENSOR INPUT SIGNAL.
Measure voltage between LCU05 terminal ②① and ground with oscilloscope when power seat slide is operated.
Refer to wiring diagram in EL-408.

OK → Sliding sensor is OK.

NG ↓


B

CHECK SLIDING SENSOR OPEN CIRCUIT.
1. Disconnect LCU05 connector and sliding motor connector.
2. Check harness continuity between LCU05 connector and sliding motor connector.

Terminals		Continuity
LCU05	Slide motor (Sliding sensor)	
②①	②①	Yes
③②	③②	

NG → Repair harness.

OK ↓



C


CHECK SLIDING SENSOR SHORT CIRCUIT.
Check harness continuity between LCU05 connector and ground.

Terminals	Continuity
②① - ground	No
③② - ground	

NG → Repair harness.


OK ↓

Replace sliding sensor.



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6 (Reclining sensor check)



A

CHECK RECLINING SENSOR INPUT SIGNAL.
Measure voltage between LCU05 terminal ⑩ and ground with oscilloscope when power seat reclining is operated.
Refer to wiring diagram in EL-408.

OK → Reclining sensor is OK.

NG


B

CHECK RECLINING SENSOR OPEN CIRCUIT.
1. Disconnect LCU05 connector and reclining motor connector.
2. Check harness continuity between LCU05 connector and reclining motor connector.

Terminals		Continuity
LCU05	Reclining motor (Sliding sensor)	
⑩	⑩	Yes
⑫	⑫	

NG → Repair harness.

OK



C


CHECK RECLINING SENSOR SHORT CIRCUIT.
Check harness continuity between LCU05 connector and ground.

Terminals	Continuity
⑩ - ground	No
⑫ - ground	

NG → Repair harness.

OK

Replace reclining sensor.









GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7 [Lifting sensor (front) check]









AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8


[Lifting sensor (rear) check]



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 9 (Tilt motor check)




A

TILT MOTOR ACTIVE TEST

CONSULT-II

See "TILT MOTOR" in ACTIVE TEST mode.
Perform operation shown on display.
Tilt motor should operate.
Note: If CONSULT-II is not available, start with diagnostic procedure B .

OK → Tilt motor is OK.




B

CHECK OUTPUT SIGNAL TO TILT MOTOR.
Check voltage between BCM connector terminals (102) or (103) and ground.

Condition of tilt switch	Terminals		Voltage V
	⊕	⊖	
Up	(103)	Ground	Approx. 12
Down	(102)	Ground	Approx. 12

Refer to wiring diagram in EL-406.

NG → Replace BCM.



C

CHECK TILT MOTOR.
1. Disconnect tilt motor connector.
2. Apply 12V DC direct current to motor and check operation.


Terminals		Operation
⊕	⊖	
①	②	Up
②	①	Down

NG → Replace tilt motor.

OK →
Check harness for operation between BCM and tilt motor.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 10 (Telescopic motor check)



A

TELESCOPIC MOTOR ACTIVE TEST

CONSULT-II

See "TELESCO MOTOR" in ACTIVE TEST mode.
Perform operation shown on display.
Telescopic motor should operate.
Note: If CONSULT-II is not available, start with diagnostic procedure B .

OK → Telescopic motor is OK.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



B


CHECK OUTPUT SIGNAL TO TELESCOPIC MOTOR.

Check voltage between BCM connector terminals (101) or (107) and ground.

Condition of telescopic switch	Terminals		Voltage V
	⊕	⊖	
Forward	(101)	Ground	Approx. 12
Backward	(107)	Ground	Approx. 12

Refer to wiring diagram in EL-406.

NG → Replace BCM.



C

CHECK TELESCOPIC MOTOR.

1. Disconnect telescopic motor connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
⊕	⊖	
①	②	Forward
②	①	Upward


NG → Replace telescopic motor.

OK →

Check harness for operation between BCM and telescopic motor.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 11 (Sliding motor check)




A

SLIDING SLIDE ACTIVE TEST
CONSULT-II

See "SEAT SLIDE" in ACTIVE TEST mode.
Perform operation shown on display.
Sliding motor should operate.
Note: If CONSULT-II is not available, start with diagnostic procedure B .

OK → Sliding motor is OK.




B

CHECK OUTPUT SIGNAL TO SLIDING MOTOR.
Check voltage between LCU05 connector terminals ① or ⑧ and ground.

Condition of sliding switch	Terminals		Voltage V
	⊕	⊖	
Forward	①	Ground	Approx. 12
Backward	⑧	Ground	Approx. 12

Refer to wiring diagram in EL-408.

NG → Replace LCU05.



C

CHECK SLIDING MOTOR.
1. Disconnect sliding motor connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
⊕	⊖	
①	⑧	Forward
⑧	①	Backward


NG → Replace sliding motor.

OK → Check harness for operation between LCU05 and sliding motor.

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 12 (Reclining motor check)




A

RECLINING MOTOR ACTIVE TEST
CONSULT-II

See "SEAT RECLINING" in ACTIVE TEST mode.
Perform operation shown on display.
Reclining motor should operate.
Note: If CONSULT-II is not available, start with diagnostic procedure B .

OK → Reclining motor is OK.




B

CHECK OUTPUT SIGNAL TO RECLINING MOTOR.
Check voltage between LCU05 connector terminals ② or ⑨ and ground.

Condition of reclining switch	Terminals		Voltage V
	⊕	⊖	
Forward	②	Ground	Approx. 12
Backward	⑨	Ground	Approx. 12

Refer to wiring diagram in EL-408.

NG → Replace LCU05.



C

CHECK RECLINING MOTOR.
1. Disconnect reclining motor connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
⊕	⊖	
②	⑨	Forward
⑨	②	Backward

NG → Replace reclining motor.

OK →
Check harness for operation between LCU05 and reclining motor.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 13 [Lifting motor (Front) check]




A

LIFTING MOTOR (FRONT) ACTIVE TEST

CONSULT-II

See “SEAT LIFTER FR” in ACTIVE TEST mode.
Perform operation shown on display.
Lifting motor (front) should operate.
Note: If CONSULT-II is not available, start with diagnostic procedure B .

OK → Lifting motor (front) is OK.




B

CHECK OUTPUT SIGNAL TO LIFTING MOTOR (FRONT).
Check voltage between LCU05 connector terminals ⑪ or ⑩ and ground.

Condition of lifting switch (front)	Terminals		Voltage V
	⊕	⊖	
Up	⑪	Ground	Approx. 12
Down	⑩	Ground	Approx. 12

Refer to wiring diagram in EL-408.

NG → Replace LCU05.



C

CHECK LIFTING MOTOR (FRONT).
1. Disconnect lifting device connector.
2. Apply 12V DC direct current to motor and check operation.




Terminals		Operation
⊕	⊖	
⑪	⑩	Up
⑩	⑪	Down

NG → Replace lifting motor (front).

OK → Check harness for operation between LCU05 and lifting motor (front).

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 14
[Lifting motor (Rear) check]



A

LIFTING MOTOR (REAR) ACTIVE TEST
CONSULT-II

See "SEAT LIFTER RR" in ACTIVE TEST mode.
Perform operation shown on display.
Lifting motor (rear) should operate.
Note: If CONSULT-II is not available, start with diagnostic procedure B .

OK → Lifting motor (rear) is OK.

GI

MA

EM

LC

EC

B

CHECK OUTPUT SIGNAL TO LIFTING MOTOR (REAR).
Check voltage between LCU05 connector terminals ⑥ or ④ and ground.

Condition of lifting switch (rear)	Terminals		Voltage V
	⊕	⊖	
Up	⑥	Ground	Approx. 12
Down	④	Ground	Approx. 12

Refer to wiring diagram in EL-409.

NG → Replace LCU05.

FE

AT

PD

FA

RA

C

CHECK LIFTING MOTOR (REAR).
1. Disconnect lifting device connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
⊕	⊖	
⑥	④	Up
④	⑥	Down

NG → Replace lifting motor (rear).

BR

ST

RS

BT

HA



OK → Check harness for operation between LCU05 and lifting motor (rear).

EL

IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 15 (Lifting limit switch check)



A

CHECK LIMIT SWITCH.

1. Disconnect lifting device connector.
2. Check continuity between lifting device (limit switch) terminals.

NG → Replace limit switch.

	Terminals	Condition of seat lifting	Continuity
Front	⑫ - ⑭	Fully up	No
		Except the above	Yes
Rear	③ - ⑭	Fully down	No
		Except the above	Yes
Front	⑤ - ⑬	Fully up	No
		Except the above	Yes
Rear	⑬ - ⑮	Fully down	No
		Except the above	Yes

Refer to wiring diagram in EL-408 or 409.

OK ↓

B

CHECK GROUND CIRCUIT FOR LIMIT SWITCH.

Check continuity between lifting device terminal ⑭ (for limit switch front) or ⑮ (for limit switch rear) and ground.
Continuity should exist.

NG → Repair harness.

OK ↓

Check harness for open or short between LCU05 and limit switch.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 16
(Tilt/telescopic switch check)

A

DATA MONITOR	
MONITOR	
TELESCO SW-FR	OFF
TELESCO SW-RR	OFF
TILT SW-UP	OFF
TILT SW-DOWN	OFF
RECORD	


SEL551W

CHECK TILT/TELESCOPIC SWITCH INPUT SIGNAL.

A CONSULT-II

See "TELESCO SW - FR/RR, TILT SW - UP/DOWN" in DATA MONITOR mode. **These switches should change from "OFF" to "ON" when switch is operated.**

OK → Tilt/telescopic switch is OK.



OR ON BOARD

Check tilt/telescopic switch operation is switch monitor (Mode II) mode. (Refer to On board diagnosis EL-255.)

Refer to wiring diagram in EL-405.

NG

B

CHECK TILT/TELESCOPIC SWITCH.

1. Disconnect ADP steering switch connector.
2. Check continuity between ADP steering switch terminals.

Switch	Condition	Terminal					
		②	③	④	⑤	⑥	
Tilt	Up		○	○			
	Down		○		○		
Telescopic	Forward		○			○	
	Backward	○	○				

NG → Replace ADP steering switch.

OK

Check the following.

- Ground circuit for ADP steering switch
- Harness for open or short between BCM and ADP steering switch

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 17 (Power seat switch check)

A

DATA MONITOR	
MONITOR	
SLIDE SW-FR	OFF
SLIDE SW-RR	OFF
RECLN SW-FR	OFF
RECLN SW-RR	OFF
LIFT FR SW-UP	OFF
LIFT FR SW-DN	OFF
LIFT RR SW-UP	OFF
LIFT RR SW-DN	OFF
Scroll Down	
RECORD	

SEL552W



CHECK POWER SEAT SWITCH INPUT SIGNAL.

A CONSULT-II

See "SLIDE SW, RECLN SW, LIFT FR, RR SW" in DATA MONITOR mode.

These switches should change from "OFF" to "ON" when switch is operated.

OK → Power seat switch is OK.

OR

ON BOARD

Check each power seat switch operation in switch monitor (Mode II) mode. (Refer to On board diagnosis EL-255.)

Refer to wiring diagram in EL-407.

NG

B

CHECK POWER SEAT SWITCH.

1. Disconnect power seat switch connector.
2. Check continuity between power seat switch terminals.

NG → Replace power seat switch.



Switch	Con- dition	Terminals									
		19	17	18	19	23	24	25	26	27	
Slid- ing	For- ward	○	○								
	Back- ward	○				○					
Reclin- ing	For- ward	○		○							
	Back- ward	○					○				
Lifting (Front)	Up	○			○						
	Down	○						○			
Lifting (Rear)	Up	○								○	
	Down	○									○

OK

- Check the following.
- Ground circuit for power seat switch
 - Harness for open or short between LCU05 and power seat switch

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 18 (Cancel switch check)



CHECK CANCEL SWITCH INPUT SIGNAL.

A CONSULT-II

See "CANCEL SW" in DATA MONITOR mode.

When cancel switch is ON:
CANCEL SW ON

When cancel switch is OFF:
CANCEL SW OFF

OR

ON BOARD

Check cancel switch in switch monitor (Mode II) mode.
(Refer to On board Diagnosis EL-255.)

Refer to wiring diagram in EL-405.

OK → Cancel switch is OK.

GI
MA
EM
LC
EC
FE
AT

B

CHECK CANCEL SWITCH.

1. Disconnect ADP steering switch connector.
2. Check continuity between ADP steering switch terminals.

Terminals	Cancel switch condition	Continuity
① - ③	ON	Yes
	OFF	No

NG → Replace ADP steering switch.

PD
FA
RA
BR
ST

OK →

Check the following.

- Ground circuit for ADP steering switch
- Harness for open or short between BCM and ADP steering switch

RS
BT
HA





EL

IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 19

(Key, detention, door switch and vehicle speed sensor check)



CHECK KEY SWITCH INPUT SIGNAL.

A CONSULT-II

See "IGN KEY SW" in DATA MONITOR mode.
When key is inserted in ignition key cylinder:

IGN KEY SW ON

When key is removed from ignition key cylinder:

IGN KEY SW OFF

B TESTER

Check voltage between BCM terminals 69 and ground.

Condition	Voltage V
Key is inserted.	Approx. 12
Key is removed.	0

Refer to wiring diagram in EL-403.

NG

Check the following.

- 10A fuse [No. 28], located in fuse block (J/B)]
- Key switch
- Harness for open or short between key switch and fuse
- Harness for open or short between BCM and key switch

OK

CHECK IGNITION SWITCH INPUT SIGNAL (ACC, ON AND START).

C CONSULT-II

See "IGN ACC SW, IGN ON SW, IGN START SW" in DATA MONITOR mode.
These switches should change from "OFF" to "ON" when ignition key switch is turned to each position.

D TESTER

Check voltage between BCM terminals and ground.

Terminals	Ignition key switch position	Ignition key switch position			
		OFF	ACC	ON	START
69	Ground	Approx. 0V	Battery voltage	Approx. 0V	Approx. 0V
68	Ground	Approx. 0V	Battery voltage	Battery voltage	Battery voltage
65	Ground	Approx. 0V	Battery voltage	Battery voltage	Battery voltage

Refer to wiring diagram in EL-403.

NG

Check the following.


- 7.5A fuse [No. 23] located in the fuse block (J/B)]
- 7.5A fuse [No. 32] located in the fuse block (J/B)]
- 7.5A fuse [No. 34] located in the fuse block (J/B)]
- Harness for open or short between BCM and fuse

OK

A

(Go to next page.)

Trouble Diagnoses (Cont'd)



Ⓐ

CHECK DETENTION SWITCH INPUT SIGNAL.
E CONSULT-II


See "DETENT SW" in DATA MONITOR mode.
"DETENT SW" should be "ON" when setting A/T selector lever in "P" position.

OR

NG → Check the following.

- Detention switch
- Harness for open or short

GI
MA
EM



ON BOARD

Check detention switch operation in switch monitor (Mode II) mode.
 (Refer to On board Diagnoses, EL-255.)

Refer to wiring diagram in EL-404.

OK

CHECK DRIVER DOOR SWITCH INPUT SIGNAL.
F CONSULT-II


See "DOOR SW DR" in DATA MONITOR mode.
 When driver's door is open:
DOOR SW-DR ON
 When driver's door is closed:
DOOR SW-DR OFF

OR

NG → Check the following.

- Driver door switch
- Driver door switch ground condition
- Harness for open or short between driver door switch and BCM

LC
EC
FE
AT
PD



ON BOARD

Check driver's door switch operation in Switch monitor (Mode II) mode.
 (Refer to On board Diagnoses EL-255.)

Refer to wiring diagram in EL-404.

OK

CHECK VEHICLE SPEED SENSOR.
 Does speedometer operate normally?

No → Check speedometer and vehicle speed sensor circuit.
 Refer to EL-108.

ST
RS

G

CHECK VEHICLE SPEED SENSOR PULL UP VOLTAGE.

1. Turn ignition switch to ACC.
2. Check voltage between BCM terminal ④ and ground.
Approx. 5V should exist.

Refer to wiring diagram in EL-404.

NG → Replace BCM.

BT
HA

OK

Check harness for open or short between BCM terminal ④ and combination meter terminal ⑩.

NG → Repair harness.

EL
IDX

OK

INSPECTION END


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 20 (Seat memory switch check)

A

DATA MONITOR	
MONITOR	
SET SW	OFF
MEMORY SW 1	OFF
MEMORY SW 2	OFF
RECORD	

SEL557W



CHECK SEAT MEMORY SWITCH INPUT SIGNAL.

A CONSULT-II

See "SET SW, MEMORY SW-1, 2" in DATA MONITOR mode.

These switches should change from "OFF" to "ON" when switch is operated.

OK → Seat memory switch is OK.

OR

ON BOARD

Check each seat memory switch operation in Switch monitor (Mode II) mode. (Refer to On board diagnosis EL-255.)

Refer to wiring diagram in EL-405.

NG

B

CHECK SEAT MEMORY SWITCH.

1. Disconnect seat memory switch connector.
2. Check continuity between seat memory switch terminals.

NG → Replace seat memory switch.




Switch	Terminals			
	①	②	③	④
Memory-1	○			○
Memory-2		○		○
Set			○	○

OK

- Check the following.
- Ground circuit for seat memory switch
 - Harness for open or short between BCM and seat memory switch

Trouble Diagnoses (Cont'd)

DIAGNOSES PROCEDURE 21
(Memory indicator check)



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS


DIAGNOSTIC PROCEDURE 22
(Lumbar support check)

Symptom	Possible cause	Repair order
Power lumbar support moves neither forward nor backward.	1. Power supply circuit for power lumbar support switch 2. Ground circuit 3. Lumbar support motor 4. Lumbar support motor circuit	1. Verify battery voltage is present at terminal ⑩ of power seat switch. 2. Check ground circuit for power seat switch terminal ⑭. 3. Check lumbar support motor. 4. Check harness for open or short between lumbar support motor and power seat switch.
Power lumbar support does not move forward or backward.	1. Lumbar support switch	1. Check power seat switch.

Refer to wiring diagram in EL-407.

EL
IDX

Component Parts and Harness Connector Location



SEL950W

NOTE:

If customer reports a “No Start” condition, request ALL KEYS to be brought to the Dealer in case of a NATS malfunction.

System Description

IVIS (Infiniti Vehicle Immobilizer System — NATS) has the following immobilizer functions:

- Since only IVIS (NATS) ignition keys, whose ID nos. have been registered into the ECM and IMMU of IVIS (NATS), allow the engine to run, operation of a stolen vehicle without a IVIS (NATS) registered key is prevented by IVIS (NATS).
That is to say, IVIS (NATS) will immobilize the engine if someone tries to start it without the registered key of IVIS (NATS).
- All of the originally supplied ignition key IDs (except for card plate key) have been IVIS (NATS) registered. If requested by the vehicle owner, a maximum of five key IDs can be registered into the IVIS (NATS) components.
- The security indicator blinks when the ignition switch is in “OFF” or “ACC” position. Therefore, IVIS (NATS) warns outsiders that the vehicle is equipped with the anti-theft system.
- When IVIS (NATS) detects trouble, the security indicator lamp lights up while ignition key is in the “ON” position.
- IVIS (NATS) trouble diagnoses, system initialization and additional registration of other IVIS (NATS) ignition key IDs must be carried out using CONSULT-II hardware and CONSULT-II IVIS (NATS) software. When IVIS (NATS) initialization has been completed, the ID of the inserted ignition key is automatically IVIS (NATS) registered. Then, if necessary, additional registration of other IVIS (NATS) ignition key IDs can be carried out.
Regarding the procedures of IVIS (NATS) initialization and IVIS (NATS) ignition key ID registration, refer to CONSULT-II operation manual, IVIS/NVIS.
- **When servicing a malfunction of the IVIS (NATS) (indicated by lighting up of Security Indicator Lamp) or registering another IVIS (NATS) ignition key ID no., it is necessary to re-register original key identification. Therefore, be sure to receive ALL KEYS from vehicle owner.**

GI

MA

EM

LC

EC

FE

AT

PD


System Composition

The immobilizer function of the IVIS (NATS) consists of the following:

- IVIS (NATS) ignition key
- IVIS (NATS) antenna amp. located in the ignition key cylinder
- IVIS (NATS) immobilizer control unit (IMMU)
- Engine control module (ECM)
- Security indicator

FA

RA



BR

ST

RS

BT



HA

EL


IDX

Wiring Diagram — NATS —

EL-NATS-01



REFER TO THE FOLLOWING.
 (M6), (E66), (F63) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1) -FUSE BLOCK-JUNCTION BOX (J/B)
 (M22), (F69) -ELECTRICAL UNITS



CONSULT-II


CONSULT-II INSPECTION PROCEDURE

1. Turn ignition switch OFF.
2. Connect "CONSULT-II" to Data link connector for CONSULT-II.

GI

MA

EM



3. Insert IVIS (NATS) program card into CONSULT-II.

◀: Program card
IVIS (NATS)


LC

4. Turn ignition switch ON.
5. Touch "START".

EC

FE

AT



6. Perform each diagnostic test mode according to each service procedure.

PD

For further information, see the CONSULT-II Operation Manual, IVIS/NVIS.

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses

WORK FLOW



GI
 MA
 EM
 LG
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Trouble Diagnoses (Cont'd)

SYMPTOM MATRIX CHART 1 (Self-diagnosis related item)

SYMPTOM	Displayed "SELF-DIAG RESULTS" on CONSULT-II screen.	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON NEXT PAGE
<ul style="list-style-type: none"> Security indicator lighting up* Engine will start. 	IMMU	PROCEDURE 1 (EL-450)	IMMU	A
	ECM	PROCEDURE 2 (EL-450)	ECM	B
<ul style="list-style-type: none"> Security indicator lighting up* Engine hard to start 	CHAIN OF ECM-IMMU	PROCEDURE 3 (EL-451)	Open circuit in battery voltage line of IMMU circuit	C1
			Open circuit in ignition line of IMMU circuit	C2
			Open circuit in ground line of IMMU circuit	C3
			Open circuit in communication line between IMMU and ECM	C4
			Short circuit between IMMU and ECM communication line and battery voltage line	C4
			Short circuit between IMMU and ECM communication line and ground line	C4
			Open circuit in power source line of ANT/AMP circuit	E3
			ECM	B
	IMMU	A		
	DIFFERENCE OF KEY	PROCEDURE 4 (EL-453)	Unregistered key	D
			IMMU	A
	CHAIN OF IMMU-KEY	PROCEDURE 5 (EL-454)	Communication line between ANT/AMP and IMMU:	E1
			Open circuit or short circuit of battery voltage line or short circuit of ground line	E2
			Open circuit in power source line of ANT/AMP circuit	E3
Open circuit in ground line of ANT/AMP circuit			E4	
Malfunction of key ID chip			E5	
IMMU			A	
Antenna amp.	E6			

*: When IVIS (NATS) detects trouble, the security indicator lights up while ignition key is in the "ON" position.

IVIS (Infiniti Vehicle Immobilizer System — NATS)

Trouble Diagnoses (Cont'd)


SYMPTOM	Displayed "SELF-DIAG RESULTS" on CONSULT-II screen.	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON NEXT PAGE
<ul style="list-style-type: none"> Security indicator lighting up* Engine hard to start 	ID DISCORD, IMM-ECM	PROCEDURE 6 (EL-455)	System initialisation has not yet been completed.	F
	ELECTRONIC/MINGLE NOISE	PROCEDURE 7 (EL-456)	ECM	F
	LOCK MODE	PROCEDURE 9 (EL-458)	LOCK MODE	D
<ul style="list-style-type: none"> MIL staying ON Security indicator lighting up* 	DON'T ERASE BEFORE CHECKING ENG DIAG	WORK FLOW (EL-447)	Engine trouble data and IVIS (NATS) trouble data have been detected in ECM	—

*: When IVIS (NATS) detects trouble, the security indicator lights up while ignition key is in the "ON" position.

SYMPTOM MATRIX CHART 2 (Non self-diagnosis related item)

SYMPTOM	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)
Security ind. does not light up.	PROCEDURE 8 (EL-457)	Security ind.
		Open circuit between Fuse and IVIS (NATS) IMMU
		Continuation of initialization mode
		IVIS (NATS) IMMU

DIAGNOSTIC SYSTEM DIAGRAM



Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 1

Self-diagnostic results:
“IMMU” displayed on CONSULT-II screen

A

SELF-DIAG RESULTS	
DTC RESULTS	TIME
IMMU	0

SEL951W



* Ref. part No.: reference part No. of Diagnostic System Diagram on EL-449.


A

SELF-DIAG RESULTS	
DTC RESULTS	TIME
ECM	0

SEL952W

DIAGNOSTIC PROCEDURE 2

Self-diagnostic results:
“ECM” displayed on CONSULT-II screen



Trouble Diagnoses (Cont'd)










DIAGNOSTIC PROCEDURE 3

Self-diagnostic results:
"CHAIN OF ECM-IMMU" displayed on CONSULT-II screen

A

SELF-DIAG RESULTS	
DTC RESULTS	TIME
CHAIN OF ECM-IMMU	0

SEL954W



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

IVIS (Infiniti Vehicle Immobilizer System — NATS)

Trouble Diagnoses (Cont'd)




F

CHECK COMMUNICATION LINE CIRCUIT.

1. Disconnect ECM connector and IMMU connector.
2. Check voltage between the following terminals and ground.
ECM (102), ECM (103), IMMU (5) and IMMU (6)
Voltage: 0V


NG → Communication line is short-circuited with battery voltage line or ignition switch ON line.
Repair harness or connectors.
Ref. part No. C4



G

Check continuity between the following terminals and ground.
ECM (102), ECM (103), IMMU (5) and IMMU (6)
Continuity should not exist.

NG → Communication line is short-circuited with ground line.
Repair harness or connectors.
Ref. part No. C4




H

CHECK POWER SUPPLY FOR IVIS (NATS) ANTENNA AMP.

1. Connect IMMU connector and IVIS (NATS) antenna amp. connector.
2. Check voltage between IVIS (NATS) antenna amp. terminal (1) and ground (Power supply from IVIS (NATS) IMMU terminal (2)) with analogue tester.
Before turning ignition switch "ON"
Voltage: 0V
Just after turning ignition switch "ON"
Pointer of tester should move.


NG → IVIS (NATS) antenna amp. +5V line is short-circuited with battery voltage line or ground line.
Repair harness or connectors.
Ref. part No. E3



I

SELF-FUNCTION CHECK

1. Connect ECM connector and disconnect IMMU connector.
2. Turn ignition switch "ON".
3. Touch "SELF-FUNCTION CHECK" on CONSULT-II "SELECT DIAG MODE" screen.



J

Touch "START". ECM will then check its communication interface by itself.

(See next page.)


NG → ECM is malfunctioning. Replace ECM.
Ref. part No. B

OK → (See next page.)

→ **B**

Perform initialisation with CONSULT-II.
For the operation of initialization, refer to "CONSULT-II operation manual IVIS/NVIS".

Trouble Diagnoses (Cont'd)



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


A

SELF-DIAG RESULTS	
DTC RESULTS	TIME
DIFFERENCE OF KEY	0



SEL956W

DIAGNOSTIC PROCEDURE 4

Self-diagnostic results:
"DIFFERENCE OF KEY" displayed on CONSULT-II screen



Initialization with CONSULT-II incomplete or failed



B

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL566W

IVIS (Infiniti Vehicle Immobilizer System — NATS)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

Self-diagnostic results:
“CHAIN OF IMMU-KEY” displayed on CONSULT-II screen

A

SELF-DIAG RESULTS	
DTC RESULTS	TIME
CHAIN OF IMMU-KEY	0

SEL957W

A

Confirm SELF-DIAGNOSTIC RESULTS “CHAIN OF IMMU-KEY” displayed on CONSULT-II screen.

Perform initialization with CONSULT-II. For the operation of initialization, refer to “CONSULT-II operation manual IVIS/NVIS”.

OK


CHECK IVIS (NATS) IGNITION KEY ID CHIP.
 Start engine with another registered IVIS (NATS) ignition key.

Start OK → Ignition key ID chip was malfunctioning. Replace the ignition key. **Ref. part No. E5**

Start NG

CHECK IVIS (NATS) ANTENNA AMP. INSTALLATION.
 Refer to “How to Replace IVIS (NATS) Antenna Amp.” in EL-459.

NG → Reinstall IVIS (NATS) antenna amp. correctly.



OK


B

CHECK POWER SUPPLY FOR IVIS (NATS) ANTENNA AMP.

1. Connect IMMU connector and IVIS (NATS) antenna amp. connector.
2. Check voltage between IVIS (NATS) antenna amp. terminal ① and ground (Power supply from IVIS (NATS) IMMU terminal ②) with analogue tester. Before turning ignition switch “ON”

Voltage: 0V
 Just after turning ignition switch “ON”
Pointer of tester should move.

NG → Check harness for open or short between for open or short between IMMU and IVIS (NATS) antenna amp. If harness is OK, replace IMMU, perform initialisation with CONSULT-II. For the initialisation procedure, refer to “CONSULT-II operation manual IVIS/NVIS”.




OK

C

CHECK SIGNAL LINE 1 BETWEEN IMMU AND IVIS (NATS) ANTENNA AMP.
 Check voltage between IVIS (NATS) antenna amp. terminal ② and ground with analogue tester. Before turning ignition switch “ON”

Voltage: 0V
 Just after turning ignition switch “ON”
Pointer of tester should move.

NG → Check harness for open or short between for open or short between IMMU and IVIS (NATS) antenna amp. If harness is OK, replace IMMU, perform initialisation with CONSULT-II. For the initialisation procedure, refer to “CONSULT-II operation manual IVIS/NVIS”.



OK

D

CHECK SIGNAL LINE 2 BETWEEN IMMU AND IVIS (NATS) ANTENNA AMP.
 Check voltage between IVIS (NATS) antenna amp. terminal ③ and ground with analogue tester. Before turning ignition switch “ON”

Voltage: 4.5 - 5V
 Just after turning ignition switch “ON”
Pointer of tester should move.



NG → Check harness for open or short between for open or short between IMMU and IVIS (NATS) antenna amp. If harness is OK, replace IMMU, perform initialisation with CONSULT-II. For the initialisation procedure, refer to “CONSULT-II operation manual IVIS/NVIS”.

OK

Ⓐ

IVIS (Infiniti Vehicle Immobilizer System — NATS)

Trouble Diagnoses (Cont'd)




A

SELF-DIAG RESULTS	
DTC RESULTS	TIME
ID DISCORD, IMM-ECM	0

SEL958W

DIAGNOSTIC PROCEDURE 6

Self-diagnostic results:
"ID DISCORD, IMM-ECM" displayed on CONSULT-II screen



B

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL566W

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 7

Self-diagnostic results:
“ELECTRONIC/MINGLE NOISE” displayed on CONSULT-II screen

A

SELF-DIAG RESULTS	
DTC RESULTS	TIME
ELECTRONIC/MINGLE NOISE	0




SEL959W



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

“SECURITY IND. DOES NOT LIGHT UP”



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 9

Self-diagnostic results:
 “LOCK MODE” displayed on CONSULT-II screen

A


SELF-DIAG RESULTS	
DTC RESULTS	TIME
LOCK MODE	0


SEL960W

B

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL566W





How to Replace IVIS (NATS) Antenna Amp.

NOTE:


- If IVIS (NATS) antenna amp. is not installed correctly, IVIS (NATS) system will not operate properly and SELF-DIAG RESULTS on CONSULT-II screen will show “LOCK MODE” or “CHAIN OF IMMU-KEY”.
- Initialization is not necessary only when IVIS (NATS) antenna amp. is replaced with a new one.

GI

MA

EM

INSTALLATION



LC

EC

FE

AT

PD

- After inserting the IVIS (NATS) antenna amp. into the ignition key cylinder, check if the IVIS (NATS) antenna amp. is set in the latched position as shown in the above illustration.

FA

RA

BR

ST

RS

BT





HA

EL




IDX

Wiring Diagram — TRNSMT —

EL-TRNSMT-01



REFER TO THE FOLLOWING.
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B)




Trouble Diagnoses

DIAGNOSTIC PROCEDURE

SYMPTOM: Transmitter does not activate receiver.

Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is at fault, not vehicle related.



*For details, refer to Technical Service Bulletin.

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Precaution

CAUTION:

- Use CONSULT-II to set the system “Demonstration mode” if INFINITI Communicator needs to be activated during service procedures. (For details of the demonstration mode, refer to EL-490.)
- Make sure to turn the demonstration mode OFF before returning the vehicle to the owner.
- In the demonstration mode, no service from the Communicator Response Center is available. Therefore, even if the customer encounters an emergency, no service will be dispatched.
- If the theft warning system is activated for more than 7 seconds, INFINITI Communicator will dial to the Communicator Response Center automatically. The operator will contact the customer to confirm whether the vehicle has been stolen or not.
- When “Mayday” emergency dialing is activated (if the system is not in the demonstration mode), the Communicator Response Center operator will come online. If there is no emergency, the operator will ask the occupant for the user password (option). Failure to provide the correct password results in a police response.
- IVCS unit memory includes VIN (Vehicle Identification Number) and other such vehicle specific data. Therefore, the IVCS unit cannot be transferred to another vehicle. When the IVCS unit is replaced, the new unit must be set up and programmed. The INFINITI Communicator system automatically contacts the Communicator Response Center the first time the vehicle is started after a phone number has been changed or a module (IVCS unit) is replaced. The VIN will be written in the memory of the new unit by transmitting data from the Communicator Response Center. For details, refer to “System Setting”, EL-492.
- Before servicing the vehicle, confirm that the VIN memorized by the IVCS unit is the same as the VIN on the vehicle’s identification plate.


Communicator Response Center Telephone Number for Technicians

The Communicator Response Center telephone number for technicians is **1-888-427-4812**.

Whenever an INFINITI dealer technician dials the above number, the following information will be required by the Communicator Response Center operator.

- Customer name
- Unit ID number of old IVCS unit (For details, refer to EL-478.)
- Unit ID number of new IVCS unit
- VIN
- Dealer name and code (For security purposes)
- Dealer contact person (technician)
- Dealer phone and fax numbers

Component Parts and Harness Connector Location



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

IDX

System Description

OUTLINE


INFINITI Communicator system uses the Global Positioning System (GPS), cellular phone technology and the Communicator Response Center to provide the following functions.

- One touch "Information" dialing
- One touch "Mayday" emergency dialing
- Automatic air bag inflation notification
- Stolen vehicle tracking
- Alarm notification
- Remote door unlock

There are limitations to the INFINITI Communicator system. To understand the system, read SYSTEM LIMITATIONS (EL-465) thoroughly.

SYSTEM COMPOSITION

- The INFINITI Communicator system is controlled by the IVCS (In Vehicle Communication System) unit. System status ("Mayday"-emergency dialing, or re-dialing, etc.) is displayed by the indicators in the IVCS switch.
- The INFINITI Communicator system can only make calls to the Communicator Response Center and receive calls from the center, unless the customer chooses to have the optional handset install.



SYSTEM LIMITATIONS

Service area

Depending on the cellular provider chosen, service is provided in the 48 contiguous states. Service is not available in Alaska, Hawaii, Canada, or Mexico. The Communicator Response Center will not be able to locate the customer's vehicle outside of the continental United States.

Inoperative if cellular phone is inactive or inoperative

INFINITI Communicator will be inoperative if the customer does not have an active account with cellular provider, since INFINITI Communicator relies on the cellular network. When the INFINITI Communicator system is outside of cellular service, the "NO SERVICE" indicator will illuminate. If you try to activate INFINITI Communicator, the REQUEST will be cancelled. Cellular phone transmission may become temporarily disabled, or interrupted by environmental factors like tunnels, bridges, or tall buildings. In such cases, INFINITI Communicator will re-dial up to four times. After several failed attempts, the system will quit dialing and return to normal mode.

Inoperative if the system is in the demonstration mode

The INFINITI Communicator system remains in the demonstration mode until the setup procedures are completed. If the system is activated in this mode, the Communicator Response Center will recognize this operation as a demonstration and will not provide any service. The system can be changed to the demonstration mode by using CONSULT-II to check the system operation. Do not forget to turn off the demonstration mode after confirmation.

Battery

Since INFINITI Communicator is powered by the vehicle's battery, if the battery is removed, damaged or discharged, the system will not work.

Inoperative if cellular system is busy

When INFINITI Communicator tries to contact the Communicator Response Center, but the cellular network is busy, the system attempts to re-dial for up to two hours. This time varies greatly depending on the cellular network and cellular signal strength. The system resets to ready when the system completes the re-dialing attempts.

Roaming

If the customer's cellular provider does not have a roaming agreement with the provider where the vehicle locates, it may not be possible to use the lines of a different cellular provider. Therefore, it is impossible that INFINITI Communicator will contact the Communicator Response Center.

Special cellular features

Some cellular carriers offer custom phone numbers that are assigned a Personal Identification Number (PIN). The cellular phone user is required to enter the PIN anytime a phone call is made. The INFINITI Communicator system is not compatible with the PIN feature. A PIN requirement on the cellular phone will cause the INFINITI Communicator system to be inoperative.

Other special features such as call waiting, voice mail, call forwarding, etc. can interfere with INFINITI Communicator system operation.

Cellular airwave interference

At times someone other than the Communicator Response Center operator may be heard. This is caused by Cellular Airwave Interference and is not caused by an INFINITI Communicator system malfunction.

Possibility of positioning capability degraded

Vehicle positioning is accomplished using the GPS (Global Positioning System). If the signal from the GPS satellite is obstructed by a tunnel or building, positioning capability may be degraded or lost. In this case, the last valid position obtained before the obstruction is transmitted to the Communicator Response Center. The precision is also influenced by the location of GPS satellites.

Once the battery cable is disconnected, it will take about 5 minutes to determine the vehicle location. This is because the memory related to GPS is lost when the battery cable is disconnected.

OPERATION

One touch "Information" dialing

- If the vehicle becomes disabled due to problems such as engine trouble, press the "Information" switch to connect to the Communicator Response Center and receive the desired service.
- When the indicator lamp on the switch lights up, it means that the system has started to contact the Communicator Response Center. (Voice communication with Communicator Response Center operator is not available while DATA is being transmitted even if the indicator lamp is lit.)
- When the indicator lamp blinks, it means that the system is preparing for cellular connection or attempting to re-dial.

INFINITI COMMUNICATOR (IVCS)

System Description (Cont'd)

One touch “Mayday” emergency dialing

- When an emergency occurs, press the “Mayday” emergency switch to connect to the Communicator Response Center. With this report, the Communicator Response Center recognizes that an emergency has occurred and provides necessary service.
- The operator will request a password (if the customer chooses to establish a password). If the wrong password or if no password is provided, the Communicator Response Center will assume the customer is in a duress situation and dispatch police.
- When no voice reply is heard from the vehicle or the sound heard indicates an emergency situation, the Communicator Response Center will have the police rush to the scene.
- Other operations are the same as service dialing.

Automatic air bag inflation notification

- When an air bag inflates, the air bag diagnosis sensor unit sends the air bag inflation signal to the IVCS unit, and the system automatically dials the Communicator Response Center to report the occurrence of an accident.

Stolen vehicle tracking

- When a vehicle is stolen, the owner can contact the Communicator Response Center to attempt to locate the stolen vehicle. The Communicator Response Center will activate the stolen vehicle tracking to locate the vehicle. If the Communicator Response Center successfully locates the vehicle, they will contact the police to provide the location.
- The vehicle location data is calculated using GPS.
- The vehicle ignition switch must be turned to the ON position to obtain the vehicle location. (This is because the system is in the sleep mode when the ignition switch is OFF.)
- Once this function starts up, regardless of the ignition switch position, the system keeps transmitting the vehicle location until the cancel signal is transmitted from the Communicator Response Center.
- While this function is operating, the operator can covertly monitor what is happening inside the vehicle through the hands-free microphone.

Alarm notification

- When theft warning system sounds an alarm for more than 7 seconds because of improper access, the alarm signal is transmitted from the rear LH passenger door control unit (LCU04) to the IVCS unit, and the system executes automatic dialing to the Communicator Response Center.
If the alarm is reset before 7 seconds has elapsed, the INFINITI Communicator will not place a call to the Communicator Response Center.
- This function operates regardless of ignition switch position.
- While this function is operating, the operator can covertly monitor what is happening inside the vehicle through the hands-free microphone.

Remote door unlock

- When the door is locked with the key inside the vehicle, the door can be unlocked by contacting the Communicator Response Center (Proof that the person calling is the owner must be received by the Communicator Response Center.)
- When the ignition key is in the “OFF” position, the system is in the sleep mode. Therefore, driver’s outside handle must be pulled to wake up the system.
- To perform remote door unlock, call the Communicator Response Center and follow the operator’s instructions.

NOTE:

- **When the system contacts the Communicator Response Center, data including the vehicle location is transmitted to the Communicator Response Center.**
- **Communication with the Communicator Response Center is not completed until the completion signal is transmitted from the Communicator Response Center. (Any calls to the Communicator Response Center can only be terminated by Communicator Response Center.)**
- **Functions other than alarm notification and remote door unlock operate while the ignition switch is ON and only for three minutes after the switch is turned OFF.**
- **Once a call to the Communicator Response Center is made, the communication continues regardless of the ignition key switch position.**
- **All the voice communication with the Communicator Response Center is made through the hands-free telephone.**
- **When the INFINITI Communicator system is activated, the handset does not function.**

INFINITI COMMUNICATOR (IVCS)

System Description (Cont'd)

DATA TRANSMITTING


When contact to the Communicator Response Center is made, vehicle sends electrical data including type of activation (i.e., emergency call or alarm notification), vehicle location, time, etc.

SLEEP/WAKE UP CONTROL

3 minutes after the ignition switch is turned OFF, the system goes into the SLEEP MODE to save battery power supply. Communication with Communicator Response Center is not available in the SLEEP MODE.

To wake up the system, perform either of the following operations.

- Turn Ignition switch ON.
- Pull driver side outside door handle for more than 10 seconds. (Operation for door unlock function)



INDICATOR LAMPS OPERATION

The system status is displayed as below by the indicator lamps.

Indicator	Condition	Description
MAYDAY	Blinks.	System is trying to acquire an available cellular channel by "Mayday" switch operation.
	Lights up. (See NOTE.)	System is connected to a cellular channel and is communicating information to the Communicator Response Center.
INFORMATION	Blinks.	System is trying to acquire an available cellular channel by "Information" switch operation.
	Lights up. (See NOTE.)	System is connected to a cellular channel and is communicating information to the Communicator Response Center.
REDIAL	Lights up.	Re-dialing
	Blinks.	Waiting for re-dial
NO SERVICE	Lights up.	Out of CELLULAR PHONE service area or signal is too weak.

NOTE:

- When connection to Communicator Response Center by re-dial ends in failure, all the indicators are turned off.
- All indicators illuminate for up to 30 seconds or more when ignition switch is turned from OFF to ON and the system performs a self check.
- If both of MAYDAY and INFORMATION indicators do not turn off 30 seconds or more after the ignition switch is turned to ON, the system is malfunctioning.


AUTOMATIC RE-DIAL/AUTO RESET TO READY

- When INFINITI Communicator tries to contact the Communicator Response Center, but the cellular network is busy, the system attempts to dial for up to 2 hours. This time varies greatly depending on the cellular network and cellular signal strength. The system resets to ready when the system completes the dialing attempts. The vehicle owner can press the button again if he or she still needs to contact the Communicator Response Center.
- INFINITI Communicator automatically redials if communication between the vehicle owner and Communicator Response Center is lost for some reason.
- The only way for a transmission to be officially terminated is for the Communicator Response Center to send an end transmission signal, which turns off the indicator in the switch. (Communication with Communicator Response Center can not be terminated by the occupant.)
- If the vehicle owner start the engine during a call, the conversation may be interrupted. When this happens the system may try to resume transmission once after the engine has been started.

INFINITI COMMUNICATOR (IVCS)

System Description (Cont'd)

GPS (Global Positioning System)




GPS is the global positioning system developed and operated by the US Department of Defense. GPS satellites (NAVSTAR) transmit radio waves and orbit around the earth at an altitude of approximately 21,000 km (13,000 miles).

GPS receiver calculates the three-dimensional position of the vehicle (latitude, longitude, and altitude from the sea level) by the time difference of the radio wave arriving from more than four GPS satellites (three-dimensional positioning).

When the radio wave is received from only three GPS satellites, the two-dimensional position (latitude and longitude) is calculated, using the altitude from the sea level data calculated by using four GPS satellites (two-dimensional positioning).

Positioning capability is degraded in the following cases.

- In two-dimensional positioning, when the vehicle's altitude from the sea level changes, the precision becomes lower.
- The location detection performance can have an error of about 100 m (300 ft) even in three-dimensional positioning with high precision. Because the precision is influenced by the location of GPS satellites used for positioning, the location detection performance may drop depending on the location of GPS satellites.
- When the radio wave from GPS satellites cannot be received, for example, when the vehicle is in a tunnel, in a parking lot inside building, under an elevated superhighway or near strong power lines, the location may not be detected. Turbulent/electric weather conditions may also affect positioning performance. If something is placed on the antenna, the radio wave from GPS satellites may not be received.



HANDSET (OPTION)

NOTE:

- If an optional handset is installed, INFINITI Communicator can be used as a normal cellular phone.
- If INFINITI Communicator is activated when INFINITI Communicator system's cellular phone is in use, the current phone transmission will be cut and INFINITI Communicator will dial the Communicator Response Center. The cellular handset will be disabled, and communication with the Communicator Response Center operator will be carried out through the hands-free microphone.
- After communication with Communicator Response Center is finished, the handset last number memory will be erased.
- While INFINITI Communicator is activated, the handset becomes inoperative and all communication with the operator is accomplished via the hands-free phone. When an activation is terminated, the handset will be unlocked.

INFINITI COMMUNICATOR (IVCS)

System Description (Cont'd)


TEL SWITCH

When any of the TEL switches is pressed, the TEL switch which is combined with the multiplex transmitting unit sends operational commands to the IVCS unit. TEL switch has following three functions.

- Volume adjust
- Placing re-dial call
- Placing memorized call (The telephone numbers are stored in the handset. A maximum of 6 memories are operative.)

GI

MA



SEND/END switch operation

- When a call is received, press SEND/END switch to permit conversation.
- At the completion of the conversation, press the SEND/END switch to terminate the call.
- To re-dial the last phone number, press SEND/END switch.

EM

LC

EC

MEMORY switch operation

- A maximum of 6 telephone numbers which stored in the memory of the handset can be dialed by MEMORY switch operation.
- The last phone number is erased if the ignition switch is turned off or if the INFINITI Communicator system has been activated.
- For the procedure to input telephone numbers, refer to the handset operation manual.
- To select memory 1 to 6, push MEMORY switch A or B. Every push on the switch changes the memory as follows.
 SWITCH A: Memory 1 → 2 → 3 → OFF
 SWITCH B: Memory 4 → 5 → 6 → OFF
 After selecting memory, push SEND/END switch to make a call.

FE

AT

PD

FA

RA

VOLUME switch

Voice volume from the front RH speaker can be adjusted by using the VOLUME switch.

BR

NOTE:

Memory switches are not functional unless handset is installed.

ST

RS

BT


HA

EL

IDX


INFINITI COMMUNICATOR (IVCS)

Schematic




Wiring Diagram — IVCS —

EL-IVCS-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL
IDX










* : This connector is not shown in "HARNESS LAYOUT", EL section.

REFER TO THE FOLLOWING.
 (M4), (E66) -SUPER MULTIPLE JUNCTION (SMJ)
 (B1) -FUSE BLOCK-JUNCTION BOX (J/B)

INFINITI COMMUNICATOR (IVCS)

Wiring Diagram — IVCS — (Cont'd)

EL-IVCS-02





REFER TO THE FOLLOWING.

- (M4) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1) -FUSE BLOCK-JUNCTION BOX (J/B)


INFINITI COMMUNICATOR (IVCS)

Wiring Diagram — IVCS — (Cont'd)

EL-IVCS-04




REFER TO THE FOLLOWING.
 (M4), (E66), (D1) -SUPER
 MULTIPLE JUNCTION (SMJ)




CONSULT-II

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.



3. Insert UEN99A program card into CONSULT-II.
4. Turn ignition switch "ON".
5. Touch "START".



6. Touch "IVCS".



7. Perform each diagnostic item according to the item application chart as follows:

8. When CONSULT-II inspection is terminated, follow the procedure shown below.
 - a. Touch "BACK" key of CONSULT-II until "SELECT SYSTEM" appears, then turn ignition switch to the OFF position.
 - b. Turn off CONSULT-II.
 - c. Disconnect CONSULT-II DDL connector.

NOTE: If the DDL connector is disconnected before turning ignition switch to "OFF" position, INFINITI communicator may not operate properly.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

INFINITI COMMUNICATOR (IVCS)

CONSULT-II (Cont'd)

APPLICATION ITEMS


Mode	Description	Reference page
SELF-DIAG RESULTS	Displays the result of self-diagnosis.	EL-477
DATA MONITOR	Two modes, "GPS MONITOR" and "SWITCH MONITOR" can be selected in this mode. <ul style="list-style-type: none"> ● Displays current data related to GPS in "GPS MONITOR" mode. ● Displays IVCS switch and outside door handle switch condition in "SWITCH MONITOR" mode. 	EL-478
FUNCTION CHECK	In this mode, "Remote door unlock function" can be checked using CONSULT-II. Door can be unlocked according to the commands to the door LCU by the IVCS unit. This check verifies communication circuit between LCU and IVCS unit.	EL-486
REGISTERED DATA	Displays the following data registered in the IVCS unit. In this mode the data cannot be re-written. <ul style="list-style-type: none"> ● Unit ID ● Cellular phone number ● VIN (Vehicle Identification Number) 	EL-478
CONFIGURATION (See Note.)	In this mode, the system can be set up in the demonstration mode to confirm system operation.	EL-490
	Various data related to both the Communicator Response Center contract and cellular provider can be written/updated in this mode. <ul style="list-style-type: none"> ● Phone number ● NAM (Number Assignment Module) ● Stolen vehicle tracking setting (Default should always be on.) ● Alarm notification setting (Default should always be on.) 	EL-492
ECU PART NUMBER	Displays the part number of the IVCS unit.	—

Note: Data must not be rewritten without prior approval from the customer.

INFINITI COMMUNICATOR (IVCS) CONSULT-II (Cont'd)


“DATA MONITOR” MODE

How to perform data monitor



Data monitor item chart

Mode	Monitor item	Description
GPS MONITOR	AVAILABLE GPS	The number of GPS satellites captured by GPS antenna
	DATE	Date of Greenwich mean time
	GMT TIME	Greenwich mean time (Different from local time)
	LAT.	Latitude
	LONG.	Longitude
	DOP	Index of precision (an index of location status of GPS satellites. The smaller the value is, the higher the positioning precision is.)
SWITCH MONITOR	MAYDAY	"MAYDAY" emergency switch condition
	INFORMATION	"INFORMATION" switch condition
	DR HANDLE	Driver side outside door handle switch condition




“REGISTERED DATA” MODE

Item	Description
UNIT ID	ID number of the IVCS unit. ID number is unique to each unit and differs for each unit.
CELLULAR PHONE #	—
VIN #	Vehicle Identification Number. When the IVCS unit is replaced, VIN # is written in the memory of the replaced unit by transmitting data from the Communicator Response Center.

Note: No data can be changed in this CONSULT-II mode.

Trouble Diagnoses

WORK FLOW



WARNING:




- Whenever possible, set the system to “Demonstration mode” if INFINITI Communicator system needs to be activated during service procedures. (For details of the demonstration mode, refer to EL-490.)
- If you activate the INFINITI Communicator system (when the system is not in the demonstration mode), the Communicator Response Center operator may dispatch police.

INFINITI COMMUNICATOR (IVCS)

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK

1. Turn ignition switch ON.
2. Check "MAYDAY", "INFORMATION", "REDIAL" and "NO SERVICE" indicator lamps operation.



- If no failure is detected, indicator lamps will turn off after the bulb check (self-diagnosis) is terminated for about 30 seconds or more.

NOTE:

- Bulb check (self-diagnosis) is not performed unless the ignition switch has been turned off for at least 3 minutes.
- Bulb check is not performed during contact with Communicator Response Center.

- If the system detects problems, both "MAYDAY" and "INFORMATION" indicator lamps remain illuminated. Perform self-diagnosis using CONSULT-II and repair or replace the system. Refer to "How to Perform Self-diagnosis", EL-477.

NOTE:

For details of indicator lamps operation, refer to "INDICATOR LAMPS OPERATION", EL-467.

SYMPTOM CHART 1 (CONSULT-II SELF-DIAGNOSIS ITEM)

Detected items (Screen items)	Description	Service procedure
CONNECTION ERROR [GPS ANTENNA]	Connection error between GPS antenna and IVCS unit.	Go to GPS ANTENNA CHECK, EL-487.
CELLULAR PHONE [TWB ERROR]	Communication error between CPU in the IVCS unit and transceiver	Replace IVCS unit.
MEMORY ERROR	Inner memory error of the IVCS unit	Replace IVCS unit.
CONNECTION ERROR [AIR BAG]	Connection error between air bag diagnosis sensor unit and IVCS unit.	Go to AIR BAG DIAGNOSIS SENSOR COMMUNICATION CHECK, EL-487.
CONNECTION ERROR [IVMS or S/ENT]	Connection error between door switch control unit (LCU04) and IVCS unit. If this error occurs, alarm notification and auto door unlock may not operate.	Go to IVMS (LAN) COMMUNICATION CHECK, EL-488.

NOTE: After replacing IVCS unit, set up the replaced IVCS unit. Refer to "System Setting (When IVCS Unit is Replaced.)" in EL-492.

INFINITI COMMUNICATOR (IVCS)

Trouble Diagnoses (Cont'd)

SYMPTOM CHART 2 (BASED ON SYMPTOM)

Before referencing this chart, confirm the operation of the indicator lamps. Refer to "PRELIMINARY CHECK" in EL-480. If the indicators show the system is malfunctioning, perform the self-diagnosis using CONSULT-II.

Symptom	Diagnoses/service procedure	Reference page	
"MAYDAY", "INFORMATION", "RE-DIAL", "NO SERVICE" indicator lamps do not illuminate when ignition switch is turned to ON position. (Bulb check is NG.)	1. Power supply and ground circuit for IVCS unit check	EL-482	GI
	2. Indicator lamps check	EL-483	MA
Mayday/Information call does not operate.	1. IVCS switch check	EL-484	
	2. INFINITI Communicator operation check in demonstration mode	EL-490	EM
Remote door unlocking function does not operate.	1. Driver's outside door handle switch check	EL-485	LC
	2. Remote door unlock function check	EL-486	
	3. INFINITI Communicator operation check in demonstration mode	EL-490	EC
Stolen vehicle tracking function does not operate.	1. Stolen vehicle tracking setting check (Check whether the function is disabled or not.)	EL-486	FE
	2. INFINITI Communicator operation check in demonstration mode	EL-490	AT
Alarm notification function does not operate.	1. Alarm notification setting check (Check whether the function is disabled or not.)	EL-486	
	2. INFINITI Communicator operation check in demonstration mode	EL-490	PD
Hands free telephone cannot be operated by using steering switch. (Cellular phone operates properly by using optional handset.)	1. Telephone steering switch check	EL-488	FA RA
No sounds related to the telephone are heard from Front RH speaker. (If the audio does not operate properly, check the audio system.)	1. Check harness for open or short between IVCS unit and radio.	—	BR
The "NO SERVICE" indicator lamp is not turned off. (Even if a contract with telephone carrier has not been made, the indicator lamp remains illuminated.)	1. Make sure the vehicle is in an area with cellular service.	—	ST
	2. Check cellular phone antenna feeder cable connection.	—	RS
Cellular phone does not operate properly.	1. Check hand set connector connection.	—	
	2. Check hand set.	—	BT
No sound is transmitted to the other party by hands free telephone.	1. Check harness for open or short between IVCS unit and microphone.	—	
	2. Replace microphone. (IVCS switch assembly)	—	HA

EL

IDX

INFINITI COMMUNICATOR (IVCS)

Trouble Diagnoses (Cont'd)



POWER SUPPLY AND GROUND CIRCUIT FOR IVCS UNIT CHECK

Main power supply circuit check

Terminal		Ignition switch		
(+)	(-)	OFF	ACC	ON
⑱	Ground	Battery voltage	Battery voltage	Battery voltage
②	Ground	0V	0V	Battery voltage

If NG, check the following:

- 15A fuse [No. 58], located in fuse and fusible link box
- 7.5A fuse [No. 32], located in fuse block (J/B)
- Harness for open or short between fuse and IVCS unit





Ground circuit check

Terminals	Continuity
⑰ - Ground	Yes

INFINITI COMMUNICATOR (IVCS)

Trouble Diagnoses (Cont'd)

INDICATOR LAMPS CHECK



A

CHECK POWER SUPPLY FOR INDICATOR LAMPS.
Check voltage between IVCS switch terminal ① and ground.
Does battery voltage exist?

No → Check the following.

- 10A fuse [No. 27], located in fuse block (J/B)]
- Harness for open or short between fuse and IVCS switch

Yes →

B

CHECK INDICATOR LAMPS.
 1. Disconnect IVCS unit connector (Control unit connector).
 2. Apply ground to IVCS switch each terminal and check illumination.

Indicator	Terminal
Redial	⑧
No service	⑨
Mayday	⑩
Information	⑪

NG → Replace IVCS switch assembly.

OK → Check harness for open or short between indicators and IVCS unit.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

INFINITI COMMUNICATOR (IVCS)

Trouble Diagnoses (Cont'd)

IVCS SWITCH CHECK



A

CHECK IVCS SWITCH INPUT SIGNAL.

1. Turn ignition switch "ON".
2. Select "SWITCH MONITOR" in "DATA MONITOR" mode.
3. Check each switch signal.

When MAYDAY/INFORMATION switch is pushed:
MAYDAY/INFORMATION ON

When MAYDAY/INFORMATION switch is released:
MAYDAY/INFORMATION OFF

NOTE:
When CONSULT-II "Data mode" is operating, INFINITI Communicator does not dial to Communicator Response Center when the switches are operated.

OK → IVCS switch is OK.

NG ↓

B

CHECK IVCS SWITCH.

1. Disconnect IVCS switch.
2. Check continuity between IVCS switch terminals.

Terminals	Condition	Continuity
⑥ - ③	Mayday switch is turned ON.	Yes
	Mayday switch is OFF.	No
⑦ - ③	Information switch is turned ON.	Yes
	Information switch is OFF.	No

OK → Check the following:

- IVCS switch ground circuit
- Harness for open or short between IVCS switch and IVCS unit.



NG ↓

Replace IVCS switch assembly.

INFINITI COMMUNICATOR (IVCS)

Trouble Diagnoses (Cont'd)

DRIVER'S OUTSIDE DOOR HANDLE SWITCH CHECK



A

CHECK OUTSIDE DOOR HANDLE SWITCH INPUT SIGNAL.

1. Turn ignition switch "ON".
2. Select "SWITCH MONITOR" in "DATA MONITOR" mode.
3. Check the switch operation.

When driver side outside door handle is pulled:
DR HANDLE ON

When driver side outside door handle is released:
DR HANDLE OFF

NOTE:
When CONSULT-II "Data mode" is operating, INFINITI Communicator do not dial to Communicator Response Center when the switches are operated.

OK → Driver's door outside handle switch is OK.

NG ↓

B

CHECK OUTSIDE DOOR HANDLE SWITCH.

1. Disconnect driver side door key cylinder switch connector. (outside door handle switch connector is combined with the key cylinder switch.)
2. Check continuity between the door key cylinder switch terminal ① and ② .

Outside door handle switch condition	Continuity
Pulled	Yes
Released	No

OK → Check the following.

- Outside door handle switch ground circuit
- Harness for open or short between outside door handle switch and IVCS unit.

NG ↓

Replace outside door handle switch.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

INFINITI COMMUNICATOR (IVCS)

Trouble Diagnoses (Cont'd)

REMOTE DOOR UNLOCK FUNCTION CHECK (CONSULT-II "FUNCTION CHECK" MODE)

Description




"Remote door unlock function" can be checked using CONSULT-II. Driver side door can be unlocked according to the commands to the door LCU by the IVCS unit.

Note:


Before performing the function check, confirm that power door lock system operates properly.

How to perform function check.

1. Lock the doors with door lock/unlock switch on driver's door trim.
2. Touch "FUNCTION CHECK".
3. Touch "DOOR UNLOCK".
4. Touch "START". Then driver side door will be unlocked.
 - If the door cannot be unlocked using CONSULT-II, check harness for open or short between rear LH door control unit (LCU04) terminal ② and IVCS unit terminal ⑩.




STOLEN VEHICLE TRACKING/ALARM NOTIFICATION SETTING CHECK (CONSULT-II "CONFIGURATION" MODE)



INFINITI COMMUNICATOR (IVCS)

Trouble Diagnoses (Cont'd)

GPS ANTENNA CHECK



A

CHECK VOLTAGE FOR GPS ANTENNA.

1. Disconnect GPS feeder cable connector from IVCS unit.
2. Turn ignition switch ON.
3. Check voltage at IVCS unit GPS feeder cable terminal.


Does approx. 5V exist?

No → Replace IVCS unit.

Yes ↓

Replace GPS antenna.

GI
MA
EM
LC
EC
FE
AT



AIR BAG DIAGNOSES SENSOR UNIT COMMUNICATION CHECK

A

AIR BAG OPERATION CHECK

Turn ignition switch ON and check air bag warning lamp operation. (For details, refer to RS section.)

Does air bag warning lamp operate properly?

No → Check supplemental restraint system. Refer to RS section in the Service manual.

Yes ↓

Check harness connector connection between air bag diagnosis sensor unit and IVCS unit.


PD
FA
RA
BR
ST
RS
BT
HA

EL


IDX

Trouble Diagnoses (Cont'd)

IVMS (LAN) COMMUNICATION CHECK



TELEPHONE STEERING SWITCH CHECK



Trouble Diagnoses for Intermittent Incident


DESCRIPTION

An intermittent incident may be occurring if all of the following conditions exist.

- Both “MAYDAY” emergency and “INFORMATION” indicators have shown that the system is malfunctioning.
- CONSULT-II self-diagnosis result screen indicates a trouble code with “TIME = 1 or greater”.
- The INFINITI Communicator system has not been previously serviced.

To find out the cause of a problem, follow the procedures shown below.

DIAGNOSTIC PROCEDURE



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

NOTE:

Enlarged spring contact of terminals may be cause of intermittent problem for “CONNECTION ERROR [AIR BAG]/[IVMS or S/ENT]”. When you inspect terminals for enlarged contact, refer to “How to Check Enlarged Contact Spring of Terminals” in GI section.

Demonstration Mode


DESCRIPTION

By setting up the system in the demonstration mode, automatic dialing operation can be confirmed by “MAYDAY” emergency and “INFORMATION” switch operation.

Automatic dialing in this mode is connected to the demonstration center of Communicator Response Center, and is different from the normal service.


When the contract with Communicator Response Center is not concluded, all the INFINITI Communicator operations are connected to the demonstration center.

Connection to Communicator Response Center in this mode will not be charged by Communicator Response Center nor will the call be handled as an emergency.




SYSTEM OPERATION CHECK

1. Touch “CONFIGURATION”.




2. Touch “DEMO MODE”.



3. Touch “ON”. Now, the system is in demonstration mode. (To return to normal mode, touch “OFF”.)

INFINITI COMMUNICATOR (IVCS)

Demonstration Mode (Cont'd)




4. Touch "BACK" key of CONSULT-II until "SELECT SYSTEM" appears, then turn off CONSULT-II.
5. Turn ignition switch to the OFF position.
6. Disconnect CONSULT-II DDL connector.
7. Start the engine.
8. Touch the "MAYDAY" or "INFORMATION" switches. Then the system will call the demonstration center.

GI

MA

EM



9. Check INFINITI Communicator operation.
 - If contact with Communicator Response Center is successful, system is OK.

LC


NOTE:

During the system contact to Communicator Response Center in demonstration mode, "REDIAL" and "NO SERVICE" indicators blink alternately.

EC

FE

AT



- If "NO SERVICE" indicator illuminates and the contact to Communicator Response Center is unsuccessful, retry from other location where the cellular connection seems good. (e.g.; move the vehicle outside of the workshop and retry.)

PD


FA

RA

BR

NOTE:

If "NO SERVICE" indicator frequently illuminates from a location where the cellular connection seems good, check the connection of the feeder cable for the cellular phone antenna.



- If "REDIAL" indicator lamp illuminates and the contact to Communicator Response Center is unsuccessful, the cellular network is busy or there are no open cellular channels. The system will redial automatically.

ST

RS

BT

HA

NOTE:

If redial fails several times, confirm whether the roaming agreement of customer's cellular provider at the vehicle location is available or not.

Warning:

- Make sure to turn the demonstration mode OFF before returning the vehicle to the owner.
- In the demonstration mode, any service from Communicator Response Center is not available. Therefore, even if the customer encounters an emergency, no service will be dispatched.

EL

IDX

System Setting (When IVCS unit is replaced)

DESCRIPTION


When the IVCS unit is replaced, carry out the following data settings.

- Phone setup — Data setting regarding NAM (Number Assignment Module)
- Phone number — Phone number setting

NOTE:

- **Data must not be updated without prior approval from the customer.**
- **NAM and phone number can be programmed by using optional handset. For details, refer to the handset operation manual.**
- **The IVCS unit does not permit updating of NAM more than 15 times.**

WORK FLOW



NOTE:

- **If a Communicator Response Center operator does not come on line even though the system activates, the system may not be properly configured. Call the Communicator Response Center at 1-888-427-4812 to verify the configuration information.**
- **Whenever dialing the above number, information about the vehicle is required by the operator. For details, refer to EL-462.**
- **Never release the vehicle to the customer unless INFINITI Communicator system operation is verified by a Communicator Response Center operator coming on line.**

INFINITI COMMUNICATOR (IVCS)

System Setting (When IVCS unit is replaced) (Cont'd)

PHONE SET UP

1. Touch "CONFIGURATION".
2. Touch "PHONE SET UP".

SELECT ITEM
PHONE SETUP
PHONE NUMBER
VEHICLE TRACKING
ALARM NOTIFICATION
DEMO MODE

SEL461W

PHONE SETUP
THIS UNIT HAS NO REQUIRED DATA PROGRAMMED.
ERASE
REWRITE
PRINT
Scroll Down

SEL716W

3. Touch "WRITE" or "REWRITE".
 - If no data is previously memorized, the display shows "This unit has no required data programmed".

PHONE SETUP
SYS.ID:
11111
GR.ID:
11
OVERLOAD CLASS:
11
THE ABOVE DATA WILL BE PROGRAMMED. OK?
CANCEL
OK
Scroll Down

SEL465W

- If NAM (Number Assignment Module) data is previously memorized, the display shows the current NAM data.
- To erase the NAM, touch "ERASE".

PHONE SETUP
SYS.ID:
GR.ID:
OVERLOAD CLASS:
1
2
3
4
5
6
7
8
9
0
BS
CANCEL
ENTER
Scroll Down

SEL464W

4. Input new NAM data.
 - SYS ID (Carrier system ID number) — Available number: 0 to 32765
 - GR ID (Group ID mark) — Available number: 0 to 15
 - OVERLOAD CLASS (Access overload class) — Available number: 0 to 15
 - SECURITY CODE (User security code)
 - UNLOCK CODE
 - INIT PAGE CH (Initial paging channel)

NOTE: If an unavailable number is input as "SYS ID", "GR ID" or "OVERLOAD CLASS", CONSULT-II may be locked. In such cases, disconnect the vehicle battery cable once and then setup the system again.

5. Touch "ENTER".

INFINITI COMMUNICATOR (IVCS)

System Setting (When IVCS unit is replaced) (Cont'd)

PHONE SETUP		
SYS.ID:		
00000		
GR.ID:		
00		
OVERLOAD CLASS:		
00		
THIS UNIT HAS THE ABOVE DATA PROGRAMMED.		
ERASE	REWRITE	PRINT
		Scroll Down

SEL462W

6. Touch "OK".
7. Carry out the next system setting or contact Communicator Response Center and inform them that data has been updated or IVCS unit has been replaced. For details, refer to EL-492.

NOTE: Whenever the phone number is updated or the IVCS unit is replaced, the INFINITI Communicator system automatically contacts the Communicator Response Center the first time the vehicle is started.

SELECT ITEM	
PHONE SETUP	
PHONE NUMBER	
VEHICLE TRACKING	
ALARM NOTIFICATION	
DEMO MODE	

SEL466W

STOLEN VEHICLE TRACKING/ALARM NOTIFICATION SETTING CHECK

1. Touch "CONFIGURATION".
2. Touch "VEHICLE TRACKING" or "ALARM NOTIFICATION".

ALARM NOTIFICATION	
CURRENT SETTING IS	
ON	
ALARM NOTIFICATION FUNCTION IS ACTIVE.	
	OFF
	PRINT

SEL467W

3. This function should always be "ON" (function activate.)

NOTE:

- If either setting is "OFF", contact the Communicator Response Center at 1-888-427-4812 to verify the system setting.
- Whenever dialing the above number, information about the vehicle is required by the operator. For details, refer to EL-462.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS



BT

HA







EL

IDX

Engine Compartment




Luggage Compartment




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

LOCATION OF ELECTRICAL UNITS

Passenger Compartment




A Instrument panel LH side



LOCATION OF ELECTRICAL UNITS

Passenger Compartment (Cont'd)




CEL920

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

IDX


Outline



NOTE: For detailed ground distribution information, refer to "GROUND DISTRIBUTION", EL-21.

How to Read Harness Layout

Example:



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Body Harness and Tail Harness
- Body No. 2 Harness

To use the grid reference

- 1) Find the desired connector number on the connector list.
- 2) Find the grid reference.
- 3) On the drawing, find the crossing of the grid reference letter column and number row.
- 4) Find the connector number in the crossing zone.
- 5) Follow the line (if used) to the connector.

CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> ● Cavity: Less than 4 ● Relay connector 				
<ul style="list-style-type: none"> ● Cavity: From 5 to 8 				
<ul style="list-style-type: none"> ● Cavity: More than 9 	—	—		
<ul style="list-style-type: none"> ● Ground terminal etc. 	—			

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT


HA

EL

IDX

Engine Room Harness





HARNESS LAYOUT

Engine Room Harness (Cont'd)


B2	(E1)	-	Fuse, fusible link and relay box	F3	(E41)	GY/4	Daytime light control unit (For Canada)
B1	(E2)	-	Fuse, fusible link and relay box	F3	(E42)	B/1	Theft warning horn
B1	(E4)	BR/6	Cooling fan relay-1	F2	(E43)	GY/4	ASCD pump
B1	(E5)	W/3	Horn relay	E2	(E44)	GY/2	Brake fluid level switch
C1	(E6)	B/5	Front wiper relay	E3	(E45)	GY/2	Front wheel sensor LH
C1	(E7)	BR/6	Cooling fan relay-2	B2	(E46)	GY/6	Joint connector-13
B1	(E8)	GY/6	Tail lamp relay	B2	(E48)	W/6	Joint connector-15
B1	(E9)	GY/6	Park/Neutral position relay	A1	(E49)	BR/6	HID Relay (For U.S.A.)
D2	(E11)	DGY/8	To (F4)	A1	(E50)	BR/6	HID Relay (For Canada)
D2	(E12)	SB/8	To (F3)	B1	(E51)	BR/6	Headlamp relay (For U.S.A.)
C2	(E13)	GY/8	To (F2)	B1	(E52)	BR/6	Headlamp relay (For Canada)
D2	(E14)	GY/6	To (F1)	C3	(E53)	-	Body ground (With active damper suspension)
D3	(E15)	B/2	ABS actuator	C2	(E54)	DGY/6	Front shock absorber actuator RH (With active damper suspension)
A4	(E16)	GY/2	Front washer motor	A3	(E58)	GY/3	Front combination lamp RH
B4	(E17)	BR/2	Washer level switch	A3	(E60)	B/3	Headlamp aiming motor RH (With headlamp aiming system)
A4	(E18)	GY/2	Front fog lamp RH	A4	(E150)	GY/4	Headlamp RH (For U.S.A.)
B3	(E19)	B/6	To (E102)	A4	(E151)	GY/4	Headlamp RH (For Canada)
B2	(E20)	GY/1	To (E103)	C3	(E153)	BR/6	Cooling fan relay-3
C3	(E21)	SB/8	To (E101)	E4	(E154)	GY/3	Front combination lamp LH
A2	(E22)	-	Body ground	D4	(E156)	B/3	Headlamp aiming motor LH (With headlamp aiming system)
C3	(E26)	GY/2	Dropping resistor	D4	(E157)	GY/4	Headlamp LH (For U.S.A.)
B3	(E27)	DGY/4	Cooling fan motor-2	C4	(E158)	GY/4	Headlamp LH (For Canada)
B4	(E28)	B/1	Horn low	D3	(E160)	SB/6	Front shock absorber actuator LH (With active damper suspension)
C4	(E29)	B/1	Horn high	D3	(E163)	-	Body ground (With active damper suspension system)
B4	(E30)	B/2	Ambient sensor				
C4	(E31)	DGY/4	Cooling fan motor-1				
C4	(E35)	B/4	Triple-pressure switch				
E3	(E36)	-	Body ground				
D5	(E37)	GY/2	Front fog lamp LH				
E4	(E38)	GY/2	Hood switch				
E4	(E39)	GY/8	Daytime light control unit (For Canada)				
F4	(E40)	GY/6	Daytime light control unit (For Canada)				

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

HARNESS LAYOUT


Engine Room Harness (Cont'd)



(E65) : Diode



(E74) : Diode



Engine room harness

- (E61) W/6 : Fuse block (J/B)
- (E62) W/12 : Fuse block (J/B)
- (E63) B/2 : Fuse block (J/B)
- (E64) W/10 : Fuse block (J/B)
- (E65) W/2 : Diode (For Canada)
- (E66) SMJ : To (M12)
- (E67) W/16 : Data link connector
- (E68) W/3 : Telescopic sensor
- (E69) W/2 : Telescopic motor
- (E70) W/48 : To (E81)
- (E71) W/4 : Key switch and key lock solenoid
- (E72) B/5 : Ignition switch
- (E73) W/6 : NATS antenna amp.
- (E74) W/2 : Diode
- (E75) W/20 : To (M65)
- (E76) W/2 : Telephone microphone


Engine combination sub-harness

- (E70) W/48 : To (E70)
- (E82) Y/8 : To (Z4)
- (E83) W/8 : ADP steering switch
- (E84) Y/7 : Spiral cable
- (E85) BR/4 : Combination switch
- (E86) W/3 : Front fog lamp switch
- (E87) W/8 : Combination switch
- (E88) GY/8 : Front wiper switch
- (E90) W/2 : Tilt motor
- (E91) W/4 : Tilt sensor
- (E92) W/6 : Steering wheel angle sensor (With active damper suspension)

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS LAYOUT

Instrument Harness




- ★ N1 SMJ : To M6
- N3 W/18 : To M66
- N4 W/4 : Headlamp aiming switch (With headlamp aiming system)
- N5 W/8 : Active damper suspension select switch (With Active damper suspension)
- N6 W/3 : Front cigarette lighter
- N7 W/6 : TCS switch
- N8 W/4 : Illumination time control switch
- N9 W/2 : Security indicator
- N10 W/3 : Warning chime
- N11 W/4 : Optical sensor
- ★ N12 BR/16 : Combination meter
- ★ N13 W/14 : Combination meter
- N14 W/16 : Combination meter
- N15 B/2 : Sunload sensor
- N16 W/2 : Ignition key hole illumination
- N17 W/12 : A/C control unit
- N18 W/12 : Audio unit
- N20 W/10 : Audio unit
- N21 W/6 : Audio unit
- N22 W/8 : Hazard switch
- N23 W/3 : Illumination control switch
- N24 GY/6 : Joint connector-18
- N25 W/6 : Telephone switch
- N28 W/4 : Clock
- N29 W/16 : Audio unit
- N30 W/6 : Rear sunshade switch

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

HARNESS LAYOUT

Main Harness



For detailed ground distribution information, refer to "GROUND DISTRIBUTION".


HARNESS LAYOUT

Main Harness (Cont'd)


A3★	M1	SMJ	: Fuse block (J/B)	D3	M43	W/3	: Air mix door motor
A2	M2	L/4	: Sunroof relay	C3	M44	W/20	: A/C auto amp.
A3	M3	W/48	: To B4	C2	M45	W/16	: A/C auto amp.
A3★	M4	SMJ	: To B3	G2	M47	-	: Body ground
B3★	M6	SMJ	: To N1	G2	M48	W/40	: To D21
A2	M11	W/40	: To D1	G3★	M49	W/48	: To F63
B3★	M12	SMJ	: To E66	G2★	M50	W/48	: To B101
B2	M13	B/1	: Parking brake switch	B3	M51	L/12	: Joint connector-1
A2	M14	-	: Body ground	A3	M52	G/12	: Joint connector-2
A1	M15	W/18	: To R1	A3	M53	G/12	: Joint connector-3
B2	M16	W/2	: Diode	B2	M54	G/12	: Joint connector-4
B2	M17	W/2	: Diode	F1	M55	B/12	: Joint connector-5
C2	M18	W/8	: Shift lock control unit	F1★	M56	G/12	: Joint connector-6
C3	M19	B/20	: ASCD control unit	B4	M57	G/12	: Joint connector-7
C2	M20	B/2	: Stop lamp switch	B4★	M58	L/12	: Joint connector-8
C2	M21	L/2	: ASCD brake switch	A4	M59	B/12	: Joint connector-9
D2	M22	SMJ	: BCM (Body control module)	D1	M60	W/6	: Joint connector-10
D2	M23	W/6	: ASCD hold unit	E2	M61	GY/6	: Joint connector-11
E2	M24	W/2	: Trunk lid opener cancel switch	E2	M62	W/6	: Joint connector-12
E2	M25	BR/2	: Glove box lamp switch	A2	M64	W/6	: To R9
F3	M26	W/2	: Glove box lamp	B3	M65	W/20	: To E75
F3	M27	W/2	: Blower motor	B3	M66	W/18	: To N3
G3	M28	W/2	: Footwell lamp (Passenger side)	G2★	M68	W/20	: To E185
F3	M29	W/4	: Fan control amp.	A2	M69	BR/6	: Theft warning lamp relay
F2	M30	W/8	: Intake door motor	E3	M82	B/20	: Steering wheel receiver control switch
E1	M31	W/3	: Bi-level door motor				
F2	M32	W/20	: To Z1				
E2	M33	W/8	: Power steering control unit				
F3	M34	W/3	: Intake sensor				
D2	M35	W/3	: Mode door motor				
E4	M36	W/12	: A/T device				
E3	M38	W/12	: NATS IMMU				
E2	M39	B/3	: Combination flasher unit				
E3	M40	B/6	: Rear vent door motor				
D3	M41	W/2	: In-vehicle sensor				
C3	M42	W/2	: Footwell lamp (Driver side)				

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working
 according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

M16 : Diode




M17 : Diode






GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

HARNESS LAYOUT

Engine Control Harness



For detailed ground distribution information, refer to "GROUND DISTRIBUTION".
Engine ground



HARNESS LAYOUT

Engine Control Harness (Cont'd)

Engine control harness

C1★	(F1)	GY/6	: To (E14)
C1★	(F2)	GY/8	: To (E13)
C1★	(F3)	GY/8	: To (E12)
D1	(F4)	B/8	: To (E11)
D1	(F5)	SB/6	: Front wiper motor
D1	(F6)	GY/1	: Check connector
D1	(F7)	SB/8	: ABS actuator
C2	(F8)	DGY/8	: ABS actuator
C1	(F9)	L/4	: Air conditioner relay
C2	(F11)	GY/2	: Front wheel sensor RH
D1★	(F12)	GY/3	: Front heated oxygen sensor RH
D1★	(F13)	GY/3	: Intake valve timing control position sensor RH
D2★	(F14)	GY/8	: To (F131)
C2★	(F15)	GY/3	: Ignition coil (With power transistor No. 8)
C2★	(F16)	GY/3	: Ignition coil (With power transistor No. 6)
C2★	(F17)	GY/3	: Ignition coil (With power transistor No. 4)
C2★	(F18)	GY/3	: Ignition coil (With power transistor No. 2)
D4★	(F22)	SB/6	: To (F101)
E2	(F23)	GY/2	: Condenser
C3★	(F24)	-	: Engine ground
C4★	(F25)	-	: Engine ground
C3★	(F26)	SB/8	: To (F106)
C3★	(F27)	B/2	: Intake valve timing control solenoid valve RH
C3	(F28)	B/1	: Thermal transmitter
C3★	(F29)	B/2	: Intake valve timing control solenoid valve LH
D3★	(F30)	GY/6	: IACV-AAC valve
D4★	(F31)	GY/4	: Camshaft position sensor
E4★	(F32)	GY/3	: Mass air flow sensor
E4★	(F33)	GY/2	: Intake air temperature sensor
E4★	(F34)	GY/3	: Ignition coil (With power transistor No. 1)
F3★	(F35)	GY/3	: Ignition coil (With power transistor No. 3)
E4	(F36)	PU/2	: IACV-FICD solenoid valve
F3★	(F37)	BR/3	: Secondary throttle position sensor
F4★	(F38)	GY/4	: Throttle position switch
F3★	(F39)	B/4	: Throttle position sensor
F3★	(F40)	GY/3	: Ignition coil (With power transistor No. 7)
F3★	(F41)	GY/3	: Ignition coil (With power transistor No. 5)
F3	(F42)	B/2	: Throttle motor
F2★	(F43)	GY/2	: EGR temperature sensor
G2★	(F44)	GY/3	: Intake valve timing control position sensor LH

F2★	(F45)	GY/3	: Front heated oxygen sensor LH
B5★	(F60)	L/4	: Fuel pump relay-2
A4★	(F63)	W/48	: To (M49)
B4★	(F64)	W/30	: To (B102)
A4	(F65)	GY/2	: Resistor
B4★	(F66)	BR/6	: ECM relay
B5★	(F67)	L/4	: Fuel pump relay-1
A5★	(F69)	SMJ	: ECM
B5	(F70)	L/4	: Fog lamp relay
A5	(F74)	GY/H6	: TAC module
A5★	(F75)	GY/20	: TAC module
B5	(F76)	-	: Body ground
E1★	(F77)	GY/6	: EVAP canister purge volume control solenoid valve
E1★	(F78)	B/2	: EVAP canister purge control solenoid valve
E1★	(F79)	GY/3	: Absolute pressure sensor
D2★	(F80)	SB/8	: To (F126)

Engine control sub-harness-1

D4★	(F101)	GY/6	: To (F22)
E3★	(F102)	B/2	: Injector No. 1
E3★	(F103)	B/2	: Injector No. 3
E3★	(F104)	B/2	: Injector No. 5
F2★	(F105)	B/2	: Injector No. 7
C2★	(F106)	GY/8	: To (F26)
C3★	(F107)	B/2	: Injector No. 2
D2★	(F108)	B/2	: Injector No. 4
E3★	(F109)	B/2	: Injector No. 6
D3★	(F110)	GY/2	: Engine coolant temperature sensor
F1★	(F111)	B/2	: Injector No. 8

Engine control sub-harness-2

E2★	(F122)	B/2	: Knock sensor LH
F2★	(F123)	B/2	: Knock sensor RH
F2★	(F124)	BR/2	: MAP/BARO switch solenoid valve
F3★	(F125)	B/2	: EGRC-solenoid valve
D3★	(F126)	GY/8	: To (F80)


Engine control sub-harness-3

D1★	(F131)	SB/8	: To (F14)
E1★	(F132)	GY/2	: Crankshaft position sensor (OBD)
F1★	(F133)	GY/4	: Rear heated oxygen sensor RH

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS LAYOUT

Body Harness and Tail Harness



For detailed ground distribution information, refer to "GROUND DISTRIBUTION".

Under driver's seat (On the 2nd, cross member)

Body ground

Body ground

Toward ground point

Body ground

Body ground

Body ground

B10 : Diode

Park/Neutral position switch

TCM (Transmission control module)

B11 : Diode

Park/Neutral position switch

TCM (Transmission control module)

HARNESS LAYOUT

Body Harness and Tail Harness (Cont'd)

Body harness

B2	★	(B1)	W/16	: Fuse block (J/B)
B2		(B2)	W/6	: Fuse block (J/B)
B3	★	(B3)	SMJ	: To (M4)
B3		(B4)	W/48	: To (M3)
A3		(B5)	W/2	: Circuit breaker-1
A2		(B6)	W/2	: Circuit breaker-2
A3		(B7)	L/4	: Door mirror defogger relay
A2		(B8)	BR/6	: Rear window defogger relay
A4	★	(B9)	SMJ	: TCM (Transmission control module)
B4		(B10)	W/2	: Diode
B4		(B11)	W/2	: Diode
F2		(B12)	W/8	: Driver's seat control unit (LCU05)
G2		(B13)	B/2	: Front power socket
G2		(B15)	W/12	: Handset
F2		(B16)	L/4	: Heated seat switch (Driver side)
F1	★	(B17)	GY/3	: Revolution sensor
F1	★	(B18)	BR/8	: AT solenoid valve
F1	★	(B19)	GY/8	: Park/Neutral position switch
E1	★	(B20)	GY/2	: Vehicle speed sensor
F1	★	(B21)	BR/3	: Turbine revolution sensor
B4	★	(B22)	-	: Body ground
B4		(B23)	BR/1	: Front door switch (Driver side)
C4		(B24)	W/4	: Seat belt pre-tensioner LH
B3		(B25)	W/18	: To (D41)
E2	★	(B26)	GY/16	: To (B11)
D3		(B27)	W/2	: Condenser
E3		(B28)	W/4	: Rear speaker LH
E2	★	(B29)	W/6	: Fuel pump, Fuel level sensor unit
F3		(B30)	GY/26	: BOSE speaker amp.
E4		(B31)	B/4	: Receiver
E4		(B32)	W/16	: Receiver
E4		(B33)	W/6	: Receiver
D4		(B34)	W/6	: Power antenna timer and motor
D4	★	(B35)	-	: Body ground
D3		(B36)	W/16	: To (T1)
D4	★	(B37)	W/4	: Fuel pump control module (FPCM)
A3	★	(B38)	GY/6	: Joint connector-16
G2		(B39)	W/4	: Heated seat switch (Passenger side)
G1		(B55)	Y/10	: Air bag diagnosis sensor unit
G1		(B56)	-	: Body ground

Tail harness


D2		(T1)	W/16	: To (B36)
F3		(T3)	W/2	: License lamp LH
G3		(T5)	B/2	: Trunk lid opener actuator
F3		(T6)	W/2	: License lamp RH
G3		(T8)	W/3	: Trunk lid key cylinder switch (Unlock switch)
E4		(T9)	W/4	: Rear combination lamp LH
G4		(T10)	W/12	: Stop and Tail lamp sensor
F3		(T11)	W/2	: Trunk room lamp switch
F4		(T12)	-	: Body ground
G3		(T13)	W/4	: Rear combination lamp RH
G4		(T14)	W/4	: Trunk closure control unit
F4		(T15)	W/2	: Back-up lamp LH
G3		(T16)	W/2	: Back-up lamp RH
G4		(T17)	GY/2	: Striker switch

(With active damper suspension)

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Body No. 2 Harness



HARNES LAYOUT

Body No. 2 Harness (Cont'd)

Body No. 2 harness

- G3★ (B101) W/48 : To (M50)
- F3★ (B102) W/30 : To (F64)
- F3★ (B103) SMJ : ABS/TCS control unit
- E2 (B104) W/6 : Power seat switch (Passenger side)
- F4★ (B105) - : Body ground
- F3 (B106) W/18 : To (D61)
- F4 (B107) BR/1 : Front door switch (Passenger side)
- E4 (B108) W/4 : Seat belt pre-tensioner RH
- D3 (B109) B/1 : Condenser (Rear window defogger)
- C3 (B110) W/4 : Rear speaker RH
- A3★ (B111) GY/16 : To (B26)
- C4 (B112) GY/4 : Rear wheel sensor
- D3 (B113) W/2 : Diode
- D3 (B114) L/4 : Fuel lid opener relay
- C4 (B115) BR/6 : Multi-remote control relay
- C3 (B116) L/4 : Audio amp. relay
- C3 (B117) BR/6 : Theft warning horn relay
- C4★ (B118) - : Body ground
- D4 (B119) BR/2 : Fuel lid opener actuator
- B3 (B120) W/10 : To (B15)
- D4★ (B121) W/2 : Dropping resistor
- C4 (B122) W/16 : CD auto changer
- E5★ (B123) GY/6 : Joint connector-17
- B2 (B124) B/1 : Rear window defogger (Ground cable)
- D3 (B146) L/4 : Throttle motor relay
- F4 (B171) - : Body ground
- E5 (B172) Y/2 : Satellite sensor RH
- E1 (B175) Y/4 : To (B58)
- D1 (B177) W/3 : To (B59)
- A3★ (B178) W/20 : To (B65)
- F3★ (B185) W/20 : To (M68)
- F2 (B186) Y/2 : Side air bag module RH
- B4 (B188) W/6 : Rear shock absorber actuator RH
(With active damper suspension)
- D5 (B189) W/3 : Rear vertical G sensor RH (With active damper suspension)


Body No. 2 sub-harness

- B3 (B151) W/10 : To (B120)
- B3 (B152) W/2 : High-mounted stop lamp
- B4 (B153) W/2 : Trunk room lamp
- B3 (B155) W/6 : Rear sunshade unit

Chassis sub-harness

- C5★ (C11) GY/3 : EVAP control system pressure sensor
- D5★ (C12) G/2 : Vacuum cut valve bypass valve
- C5★ (C13) B/2 : EVAP canister vent control valve
- A4★ (C14) GY/8 : To (B64)

(B113) : Diode




★ : Be sure to connect and lock the connectors securely after the repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Engine Harness

For detailed ground distribution information, refer to "GROUND DISTRIBUTION".



Engine ground




Body ground

E101	GY/8	:	To	E21
E102	B/6	:	To	E19
E103	GY/1	:	To	E20
E104	-	:	Fuse, fusible link and relay box	
E105	-	:	Engine ground	
E106	GY/2	:	Power steering oil pressure switch	
E107	-	:	Alternator	
E108	GY/4	:	Alternator	
E109	-	:	Fusible link box (Battery (+))	
E110	-	:	Fusible link box (F/L)	
E111	-	:	Fuse, fusible link and relay box	
E112	-	:	Body ground	
E113	BR/2	:	Power steering solenoid valve	
E114	B/1	:	Compressor	
E115	B/1	:	Oil pressure switch	
E116	GY/1	:	Starter motor	
E117	-	:	Starter motor	
E118	GY/2	:	Park/Neutral Position switch	
E119	GY/4	:	Rear heated oxygen sensor LH	

- ★ : Be sure to connect and lock the connectors securely after repair work.
- Failure to do so may cause the ECM to have diagnostic trouble codes.
- Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


Room Lamp Harness



- | | | |
|------------|---|-------------------------------------|
| R1 | : | Vanity mirror lamp (Driver side) |
| R2 | : | Vanity mirror lamp (Passenger side) |
| R3 | : | Auto anti-dazzling inside mirror |
| R4 | : | Interior lamp |
| R5 | : | Rear personal lamp LH |
| R6 | : | Rear personal lamp RH |
| R7 | : | To (M15) |
| R8 | : | To (M15) |
| R9 | : | To (M15) |
| R10 | : | IVCS switch |
| R11 | : | Sunroof switch |
| R12 | : | Sunroof motor assembly |
| R13 | : | Sunroof motor assembly |

- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

Air Bag Harness




HARNESS LAYOUT

DRIVER SIDE

Front Door Harness


- D1** W/40 : To **(M11)**
- D2** BR/3 : Door mirror actuator (Driver side)
- D3** GY/2 : Door mirror defogger (Driver side)
- D4** W/8 : Seat memory switch
- D5** BR/2 : Tweeter LH
- D6** BR/3 : Front door key cylinder switch (Driver side)
- D7** GY/4 : Front door lock actuator (Driver side)
- D8** W/2 : Front step lamp (Driver side)
- D9** GY/6 : Front power window regulator (Driver side)
- D10** W/10 : Door mirror remote control switch
- D11** W/3 : Trunk lid and fuel lid opener switch
- D12** W/2 : Front power window main switch illumination
- D13** W/18 : Driver's door control unit (LCU01)
- D14** BR/2 : Front door speaker LH
- D16** GY/2 : Driver side door outside handle switch



CEL066M

PASSENGER SIDE

- D21** W/40 : To **(M48)**
- D22** BR/3 : Door mirror actuator (Passenger side)
- D23** GY/2 : Door mirror defogger (Passenger side)
- D24** BR/2 : Tweeter RH
- D25** BR/3 : Front door key cylinder switch (Passenger side)
- D26** GY/4 : Front door lock actuator (Passenger side)
- D27** W/2 : Front step lamp (Passenger side)
- D28** GY/6 : Front power window regulator (Passenger side)
- D29** W/18 : Passenger door control unit (LCU02)
- D30** BR/2 : Front door speaker RH




CEL067M

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


HARNESS LAYOUT

LH SIDE

Rear Door Harness




RH SIDE



SPLICE LOCATION

How to Read Splice Location

- “GT2”, “T4” etc., which are shown in the wiring diagram, refer to wiring harness splice points. These points are located in shaded areas “GT2”, “T4”, etc. in illustrations under the title “SPLICE LOCATION”.
- Wiring harness splice points are subject to change without prior notice.



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL


IDX

Engine Room Harness



SPLICE LOCATION

Engine Room Harness (Cont'd)



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


SPLICE LOCATION

Main Harness



SPLICE LOCATION


Instrument Harness




- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

SPLICE LOCATION

Engine Control Harness



Engine Harness



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX



SPLICE LOCATION

Body Harness and Tail Harness

Under driver's seat (On the 2nd, cross member)




Body No. 2 Harness



- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX


Room Lamp Harness



SPLICE LOCATION


DRIVER SIDE

Front Door Harness



CEL075M

PASSENGER SIDE




CEL076M

- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

SPLICE LOCATION


LH SIDE

Rear Door Harness



CEL612

RH SIDE



CEL615

Headlamp

Item	Wattage W
High/Low	55/35 (H1/D2R)

GI

Exterior Lamp

Item	Wattage W
Front fog lamp	55
Front combination lamp	
Turn signal/Parking lamp	27/8
Rear combination lamp	
Turn signal lamp	21
Stop/Tail lamp	21/5
Tail lamp	5
Back-up lamp	18
License lamp	5
High-mounted stop lamp	18

MA

EM

LC

EC

FE

AT

Interior Lamp

Item	Wattage W
Front map lamp	8
Rear personal lamp	8
Vanity mirror lamp	1.4
Step lamp	2.7
Footwell lamp	3.4
Trunk room lamp	3.4

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

WIRING DIAGRAM CODES (Cell codes)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
AAC/V	EC	IACV-AAC Valve
A/C	HA	Air Conditioner
ACTIVE	FA	Active Damper Suspension System
AP/SEN	EC	Absolute Pressure Sensor
ASCD	EL	Automatic Speed Control Device (ASCD)
A/T	AT	A/T
AT/IND	EL	A/T Indicator Lamp
AT/C	EC	A/T Control
AUDIO	EL	Audio
AUT/DP	EL	Automatic Drive Positioner — IVMS
BACK/L	EL	Back-up Lamp
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CANI/V	EC	EVAP Canister Purge Control Valve/Solenoid Valve
CHARGE	EL	Charging System
CHIME	EL	Warning Chime
CIGAR	EL	Cigarette Lighter
CKPS	EC	Crank Shaft Position Sensor (OBD)
CLOCK	EL	Clock
CMPS	EC	Camshaft Position Sensor
COMM	EL	IVMS — Communication Check, Power Supply & Ground
COOL/F	EC	Cooling Fan Control
DEF	EL	Rear Window Defogger
D/LOCK	EL	Power Door Lock — IVMS
DTRL	EL	Headlamp - With Daytime Light System
ECTS	EC	Engine Coolant Temperature Sensor
EGRC1	EC	EGR Function
EGRC/V	EC	EGRC-Solenoid Valve
EGR/TS	EC	EGR Temperature Sensor
EPS	ST	Electric Controlled Power Steering System
F/FOG	EL	Front Fog Lamp
FO2H-L	EC	Front Heated Oxygen Sensor Heater (Left Bank)
FO2H-R	EC	Front Heated Oxygen Sensor Heater (Right Bank)
FPCM	EC	Fuel Pump Control Module

Code	Section	Wiring Diagram Name
F/PUMP	EC	Fuel Pump
FRO2LH	EC	Front Heated Oxygen Sensor Heater (Front HO2S) (Left Bank)
FRO2RH	EC	Front Heated Oxygen Sensor Heater (Front HO2S) (Right Bank)
FUELLH	EC	Fuel Injection System Function (Left Bank)
FUELRH	EC	Fuel Injection System Function (Right Bank)
H/AIM	EL	Headlamp Aiming Control System
H/LAMP	EL	Headlamp
HORN	EL	Horn
HSEAT	EL	Heated Seat
IATS	EC	Intake Air Temperature Sensor
IGN/SG	EC	Ignition Signal
ILL	EL	Illumination
I/MIRR	EL	Inside Mirror
INJECT	EC	Injector
INT/L	EL	Vanity Mirror and Trunk Room Lamps
IVC-L	EC	Intake Valve Timing Control Solenoid Valve LH
IVC-R	EC	Intake Valve Timing Control Solenoid Valve RH
IVCS	EL	Infiniti Communicator (IVCS)
IVCS-L	EC	Intake Valve Timing Control Position Sensor LH
IVCS-R	EC	Intake Valve Timing Control Position Sensor RH
KS	EC	Knock Sensor
LOAD	EC	Load Signal
MAFS	EC	Mass Air Flow Sensor
MAIN	EC	Main Power Supply and Ground Circuit
METER	EL	Speedometer, Tachometer, Temp., Oil and Fuel Gauges
MIL/DL	EC	MIL and Data Link Connectors
MIRROR	EL	Door Mirror
MULTI	EL	Multi-remote Control System — IVMS
NATS	EL	NATS (Nissan Anti-Theft System)
P/ANT	EL	Power Antenna

WIRING DIAGRAM CODES (Cell codes)

Code	Section	Wiring Diagram Name
PGC/V	EC	EVAP Canister Purge Control Solenoid Valve
PHONE	EL	Telephone
PNP/SW	EC	Park/Neutral Position Switch
POWER	EL	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PST/SW	EC	Power Steering Oil Pressure Switch
REMOTE	EL	Audio (Remote Control Switch)
ROOM/L	EL	Interior Room Lamp — IVMS
RO2H-L	EC	Rear Heated Oxygen Sensor Heater LH
RO2H-R	EC	Rear Heated Oxygen Sensor Heater RH
RRO2LH	EC	Rear Heated Oxygen Sensor LH
RRO2H	EC	Rear Heated Oxygen Sensor RH
SEAT	EL	Power Seat
SHADE	EL	Rear Sunshade
SHIFT	AT	A/T Shift Lock System
SROOF	EL	Sunroof
SRS	RS	Supplemental Restraint System
S/SIG	EC	Start Signal
START	EL	Starting System
STEP/L	EL	Step Lamp — IVMS
STOP/L	EL	Stop lamp

Code	Section	Wiring Diagram Name	
STPS	EC	Secondary Throttle Position Sensor	
SW/ILL	EL	Power Window Switch Illumination — IVMS	GI
SW/V	EC	MAP/BARO Switch Solenoid Valve	
TAIL/L	EL	Parking, License, Tail and Stop Lamps	MA
T/CLOS	EL	Trunk Closure	
TCS	EC	Traction Control System	EM
TCS	BR	Traction Control System	
TCS/SW	EC	TCS Signal	LC
T&FLID	EL	Trunk Lid and Fuel Filler Lid Opener	
FTTS	EC	Fuel Tank Temperature Sensor	EC
THEFT	EL	Theft Warning System — IVMS	
TPS	EC	Throttle Position Sensor	FE
TP/SW	EC	Throttle Position Switch	
TRNSMT	EL	Integrated Homelink Transmitter	AT
TURN	EL	Turn Signal and Hazard Warning Lamps	
VENT/V	EC	EVAP Canister Vent Control Valve	PD
VSS	EC	Vehicle Speed Sensor	
WARN	EL	Warning Lamps	FA
WINDOW	EL	Power Window — IVMS	
WIPER	EL	Front Wiper and Washer	RA

BR

ST

RS

BT

HA

EL

IDX

NOTES