

SECTION **LAN**

LAN SYSTEM

CONTENTS

CAN

PRECAUTIONS	3
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3
Precautions When Using CONSULT-II	3
CHECK POINTS FOR USING CONSULT-II	3
Precautions For Trouble Diagnosis	3
CAN SYSTEM	3
Precautions For Harness Repair	4
CAN SYSTEM	4
Maintenance Information	4
RHD MODELS	4
LHD MODELS	4
CAN COMMUNICATION	5
System Description	5
CAN Communication Unit	5
TYPE 1/TYPE2	6
TYPE 3/TYPE4	9
CAN SYSTEM (TYPE 1)	11
System Description	11
Component Parts and Harness Connector Location ..	11
Wiring Diagram — CAN —	12
Work Flow	14
CHECK SHEET	15
CHECK SHEET RESULTS (EXAMPLE)	17
INSPECTION	21
Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)	22
ECM Circuit Check	24
Data Link Connector Circuit Check	25
Combination Meter Circuit Check	26
Intelligent Key Unit Circuit Check	27
EPS Control Unit Circuit Check	28
BCM Circuit Check	29
ABS Actuator and Electric Unit (Control Unit) Circuit Check	30
TCM Circuit Check	31
IPDM E/R Circuit Check	32
CAN Communication Circuit Check	33

IPDM E/R Ignition Relay Circuit Check	36
Component Inspection	36
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	36
CAN SYSTEM (TYPE 2)	37
System Description	37
Component Parts and Harness Connector Location ..	37
Wiring Diagram — CAN —	38
Work Flow	40
CHECK SHEET	41
CHECK SHEET RESULTS (EXAMPLE)	43
INSPECTION	46
Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)	47
ECM Circuit Check	49
Data Link Connector Circuit Check	50
Combination Meter Circuit Check	51
EPS Control Unit Circuit Check	52
BCM Circuit Check	53
ABS Actuator and Electric Unit (Control Unit) Circuit Check	54
TCM Circuit Check	55
IPDM E/R Circuit Check	56
CAN Communication Circuit Check	57
IPDM E/R Ignition Relay Circuit Check	60
Component Inspection	60
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	60
CAN SYSTEM (TYPE 3)	61
System Description	61
Component Parts and Harness Connector Location ..	61
Wiring Diagram — CAN —	62
Work Flow	64
CHECK SHEET	65
CHECK SHEET RESULTS (EXAMPLE)	67
INSPECTION	70
Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)	71
ECM Circuit Check	73
Data Link Connector Circuit Check	74

A
B
C

D

E

F

G

H

J

LAN

L

M

Combination Meter Circuit Check	75	CHECK SHEET RESULTS (EXAMPLE)	91
Intelligent Key Unit Circuit Check	76	INSPECTION	93
EPS Control Unit Circuit Check	77	Circuit Check Between BCM and ABS Actuator and	
BCM Circuit Check	78	Electric Unit (Control Unit)	94
ABS Actuator and Electric Unit (Control Unit) Circuit		ECM Circuit Check	96
Check	79	Data Link Connector Circuit Check	97
IPDM E/R Circuit Check	80	Combination Meter Circuit Check	98
CAN Communication Circuit Check	81	EPS Control Unit Circuit Check	99
IPDM E/R Ignition Relay Circuit Check	84	BCM Circuit Check	100
Component Inspection	84	ABS Actuator and Electric Unit (Control Unit) Circuit	
ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-		Check	101
TION	84	IPDM E/R Circuit Check	102
CAN SYSTEM (TYPE 4)	85	CAN Communication Circuit Check	103
System Description	85	IPDM E/R Ignition Relay Circuit Check	106
Component Parts and Harness Connector Location..	85	Component Inspection	106
Wiring Diagram — CAN —	86	ECM/IPDM E/R INTERNAL CIRCUIT INSPEC-	
Work Flow	88	TION	106
CHECK SHEET	89		

PRECAUTIONS**Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"**

EKS0089Q

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.


Precautions When Using CONSULT-II

EKS0073H

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

**CHECK POINTS FOR USING CONSULT-II**

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-5, "CAN Communication Unit"](#) .

Precautions For Trouble Diagnosis**CAN SYSTEM**

- Do not apply voltage of 7.0V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.

A
B
C
D
E
F
G
H
I
J

LAN

L


M

EKS0073I


Precautions For Harness Repair CAN SYSTEM

EKS0073J

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



Maintenance Information

EKS008WQ

If any of following part is replaced, always replace with new* one.

If it's not (or fail to do so), the electrical system may not be operated properly.

*: New one means a virgin control unit that has never been energized on-board.

RHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM
- IPDM E/R
- Combination meter
- EPS control unit

LHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM

CAN COMMUNICATION

PFP:23710

System Description

EKS007UG

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS007UH

Go to CAN system, when selecting your car model from the following table.

Body type	3door/5door							
Axle	2WD							
Engine	CR10DE/CR12DE/CR14DE							
Handle	LHD/RHD							
Brake control	ABS							
Transmission	A/T				M/T			
Intelligent Key system	Applicable	Not applicable			Applicable	Not applicable		
CAN communication unit								
ECM	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×
Intelligent Key unit	×	×			×	×		
Drive computer	×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×
TCM	×	×	×	×				
IPDM E/R	×	×	×	×	×	×	×	×
CAN communication type	LAN-6, "TYPE 1/TYPE2"				LAN-9, "TYPE 3/TYPE4"			
CAN system trouble diagnosis	LAN-11, "CAN SYSTEM (TYPE 1)"	LAN-37, "CAN SYSTEM (TYPE 2)"	LAN-61, "CAN SYSTEM (TYPE 3)"	LAN-85, "CAN SYSTEM (TYPE 4)"				

x: Applicable

A

B

C

D

E

F

G

H

I

J

LAN

L


M

CAN COMMUNICATION


[CAN]

TYPE 1/TYPE2 System diagram

- Type1



- Type2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

CAN COMMUNICATION

[CAN]

Signals	ECM	Combi- nation meter.	Intelli- gentKey unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

A
B
C
D
E
F
G
H
I
J

LAN

L

M


CAN COMMUNICATION

[CAN]


Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

TYPE 3/TYPE4 System diagram

- Type3



- Type4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

CAN COMMUNICATION

[CAN]

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

CAN SYSTEM (TYPE 1)

PFP:23710


System Description

EKS0073M

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS0073N



MKIB0313E

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 1)

[CAN]



Wiring Diagram — CAN —

EKS00730

LAN-CAN-01

— : DATA LINE

WD : WITH DRIVE COMPUTER



REFER TO THE FOLLOWING.

(M1) -SUPER MULTIPLE JUNCTION (SMJ)

(E49) -ELECTRICAL UNITS



MKWA0790E

CAN SYSTEM (TYPE 1)

[CAN]


LAN-CAN-02

■ : DATA LINE



REFER TO THE FOLLOWING.


(M1) -SUPER MULTIPLE
JUNCTION (SMJ)




Work Flow

EKS0073P


- When there are no indications of "INTELLIGENT KEY", "EPS", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "INTELLIGENT KEY", "EPS", "BCM", "ABS", "A/T" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "DATA MONITOR (CAN DIAG SUPPORT MNTR)" for "ENGINE", "INTELLIGENT KEY", "EPS", "BCM", "ABS", "A/T" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" onto the check sheet. Refer to [LAN-15. "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "DATA MONITOR (CAN DIAG SUPPORT MNTR)", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-15. "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "CAN COMM" as "DATA MONITOR (CAN DIAG SUPPORT MNTR)" for the diagnosed control unit, replace the control unit.
- The "DATA MONITOR (CAN DIAG SUPPORT MNTR)" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of "DATA MONITOR (CAN DIAG SUPPORT MNTR)" items which are not indicated in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-17. "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET

Check sheet table

SELECT SYSTEM		DATA MONITOR (CAN DIAG SUPPORT MNTR)									
ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	—	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 2	CAN CIRC 7
INTELLIGENT KEY	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 4	CAN CIRC 3	—	—	CAN CIRC 2	—	—	—
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 5	CAN CIRC 3	—	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	CAN CIRC 5	—	—	—	CAN CIRC 6	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—	—	—
A/T	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 3	—	—	—

Symptoms:

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J

LAN

L

M

MKIB0277E

CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
INTELLIGENT KEY
SELF-DIAG RESULTS

Attach copy of
EPS
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
DATA MONITOR

Attach copy of
INTELLIGENT KEY
DATA MONITOR

Attach copy of
EPS
DATA MONITOR

Attach copy of
BCM
DATA MONITOR

Attach copy of
ABS
DATA MONITOR

Attach copy of
A/T
DATA MONITOR

Attach copy of
IPDM
DATA MONITOR

MKIB0278E

INSPECTION

Proceed trouble diagnosis according to the check sheet results (example).

Case 1: Replace ECM.

Case 2: Replace Intelligent Key unit.

Case 3: Replace EPS control unit.

Case 4: Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#) .

Case 5: Replace ABS actuator and electric unit (control unit).

Case 6: Replace TCM.

Case 7: Replace IPDM E/R.

Case 8: Check harness between BCM and ABS actuator and electric unit (control unit). Refer to [LAN-22, "Circuit Check Between BCM and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

Case 9: Check ECM circuit. Refer to [LAN-24, "ECM Circuit Check"](#) .

Case 10: Check data link connector circuit. Refer to [LAN-25, "Data Link Connector Circuit Check"](#) .

Case 11: Check combination meter circuit. Refer to [LAN-26, "Combination Meter Circuit Check"](#) .

Case 12: Check Intelligent Key unit circuit. Refer to [LAN-27, "Intelligent Key Unit Circuit Check"](#)

Case 13: Check EPS control unit circuit. Refer to [LAN-28, "EPS Control Unit Circuit Check"](#)

Case 14: Check BCM circuit. Refer to [LAN-29, "BCM Circuit Check"](#) .

Case 15: Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-30, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

Case 16: Check TCM circuit. Refer to [LAN-31, "TCM Circuit Check"](#) .

Case 17: Check IPDM E/R circuit. Refer to [LAN-32, "IPDM E/R Circuit Check"](#) .

Case 18: Check CAN communication circuit. Refer to [LAN-33, "CAN Communication Circuit Check"](#) .

Case 19: Check IPDM E/R ignition relay circuit. Refer to [LAN-36, "IPDM E/R Ignition Relay Circuit Check"](#) .

A

B

C

D

E

F

G

H

I

J


LAN

L

M

Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)

EKS0073Q

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M1
 - Harness connector E101

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect following connector.
 - Harness connector M1
 - Combination meter connector
 - Intelligent Key unit connector
 - Drive computer connector
 - EPS control unit connector
 - BCM connector
2. Check continuity between BCM harness connector M48 terminals 19 (R), 39 (W) and harness connector M1 terminals 2C (R), 1C (W).

19 (R) – 2C (R)**: Continuity should exist.****39 (W) – 1C (W)****: Continuity should exist.**OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector E101 terminals 2C (R), 1C (W) and ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R), 15 (W).

2C (R) – 26 (R)

: Continuity should exist.


1C (W) – 15 (W)

: Continuity should exist.

OK or NG


OK >> Reconnect all connectors to perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-14, "Work Flow"](#).

NG >> Repair harness.



ECM Circuit Check

EKS0073U



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector M1
 - Harness connector E101

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E49 terminals 94 (R) and 86 (W).

94 (R) – 86 (W)**: Approx. 108 – 132Ω**OK or NG


OK >> Replace ECM.

NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Check

EKS0073W



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M17 terminals 6 (R) and 14 (W).

6 (R) – 14 (W) : Approx. 54 – 66ΩOK or NG


OK >> Perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-14, "Work Flow"](#).

NG >> Repair harness between data link connector and combination meter



Combination Meter Circuit Check

EKS0073X



MKIB0312E

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M22 terminals 1 (R) and 2 (W).

1 (R) – 2 (W)**: Approx. 54 – 66Ω**OK or NG

OK >> Replace combination meter


NG >> Repair harness between combination meter and data link connector.



SKIA2378E

Intelligent Key Unit Circuit Check

EKS007XM



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of Intelligent Key unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector.
2. Check resistance between Intelligent Key unit harness connector M51 terminals 2 (R) and 3 (W).

2 (R) – 3 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace Intelligent Key unit.

NG >> Repair harness between Intelligent Key unit and data link connector.



EPS Control Unit Circuit Check

EKS007XN



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of EPS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect EPS control unit connector.
2. Check resistance between EPS control unit harness connector M23 terminals 8 (R) and 7 (W).

8 (R) – 7 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace EPS control unit.

NG >> Repair harness between EPS control unit and data link connector.



BCM Circuit Check

EKS0073Y



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.


NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M48 terminals 19 (R) and 39 (W).


19 (R) – 39 (W)**: Approx. 54 – 66Ω**OK or NGOK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

NG >> Repair harness between BCM and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

EKS0073Z



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R) and 15 (W).

26 (R) – 15 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace ABS actuator and electric unit (control unit).

NG >> Repair harness between ABS actuator and electric unit (control unit) and TCM.



TCM Circuit Check

EKS0073V



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector.
2. Check resistance between TCM harness connector E105 terminals 5 (R) and 6 (W).

5 (R) – 6 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace TCM.

NG >> Repair harness between TCM and IPDM E/R.



IPDM E/R Circuit Check

EKS00740



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E16 terminals 52 (R) and 58 (W).

52 (R) – 58 (W)**: Approx. 108 – 132Ω**OK or NG

OK >> Replace IPDM E/R.

NG >> Repair harness between IPDM E/R and TCM.



CAN Communication Circuit Check

EKS00741

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, control unit side and harness side).
 - ECM
 - Combination meter
 - Intelligent Key unit
 - Drive computer
 - EPS control unit
 - BCM
 - ABS actuator and electric unit (control unit)
 - TCM
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E101.
2. Check continuity between ECM harness connector E49 terminals 94 (R) and 86 (W).

94 (R) – 86 (W) : Continuity should not exist.OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E101.


**3. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between ECM harness connector E49 terminals 94 (R), 86 (W) and ground.

94 (R) – Ground : Continuity should not exist.**86 (W) – Ground : Continuity should not exist.**OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E101.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ABS actuator and electric unit (control unit) connector
 - TCM connector
 - IPDM E/R connector
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R) and 15 (W).


26 (R) – 15 (W) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and TCM
- Harness between ABS actuator and electric unit (control unit) and harness connector E101
- Harness between ABS actuator and electric unit (control unit) and IPDM E/R



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R), 15 (W) and ground.

26 (R) – Ground : Continuity should not exist.


15 (W) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and TCM
- Harness between ABS actuator and electric unit (control unit) and harness connector E101
- Harness between ABS actuator and electric unit (control unit) and IPDM E/R



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Combination meter connector
 - Intelligent Key unit connector
 - Drive computer connector
 - EPS control unit connector
 - BCM connector
2. Check continuity between data link connector M17 terminals 6 (R) and 14 (W).

6 (R) – 14 (W)


: Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M1
- Harness between data link connector and combination meter
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and drive computer
- Harness between data link connector and EPS control unit
- Harness between data link connector and BCM



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M17 terminals 6 (R), 14 (W) and ground.

6 (R) – Ground

: Continuity should not exist.

14 (W) – Ground


: Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M1
- Harness between data link connector and combination meter
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and drive computer
- Harness between data link connector and EPS control unit
- Harness between data link connector and BCM



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-36, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Reconnect all connectors to perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-14, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

EKS00742

Perform the self-diagnosis for IPDM E/R. Refer to [PG-35, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#). If the result is OK, carry out following inspections.

- IPDM E/R power supply circuit. Refer to [PG-38, "IPDM E/R Power Supply and Ground Circuit Check"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START""](#).


Component Inspection

EKS00743

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 52 and 58.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 – 86	108 - 132
IPDM E/R	52 – 58	



LKIA0037E

CAN SYSTEM (TYPE 2)

PFP:23710


System Description

EKS00744

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00745

A
B
C
D
E
F
G
H
I
J

LAN

M

CAN SYSTEM (TYPE 2)



[CAN]

Wiring Diagram — CAN —

EKS007Y0

LAN-CAN-03

— : DATA LINE
—WD— : WITH DRIVE COMPUTER



REFER TO THE FOLLOWING.

(M1) -SUPER MULTIPLE JUNCTION (SMJ)
(E49) -ELECTRICAL UNITS




MKWA0792E

CAN SYSTEM (TYPE 2)

[CAN]

LAN-CAN-04

■ : DATA LINE



REFER TO THE FOLLOWING.


(M1) -SUPER MULTIPLE JUNCTION (SMJ)

MKWA1307E


Work Flow

EKS00810


- When there are no indications of "EPS", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "EPS", "BCM", "ABS", "A/T" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "DATA MONITOR (CAN DIAG SUPPORT MNTR)" for "ENGINE", "EPS", "BCM", "ABS", "A/T" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" onto the check sheet. Refer to [LAN-41, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "DATA MONITOR (CAN DIAG SUPPORT MNTR)", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-41, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "CAN COMM" as "DATA MONITOR (CAN DIAG SUPPORT MNTR)" for the diagnosed control unit, replace the control unit.
- The "DATA MONITOR (CAN DIAG SUPPORT MNTR)" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of "DATA MONITOR (CAN DIAG SUPPORT MNTR)" items which are not indicated in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-43, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET

Check sheet table

SELECT SYSTEM		DATA MONITOR (CAN DIAG SUPPORT MNTR)								
ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 2	CAN CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN CIRC 3	—	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 6	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—	—
A/T	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—	—

Symptoms:

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J

LAN

L

M

MKIB0287E

CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
EPS
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
DATA MONITOR

Attach copy of
EPS
DATA MONITOR

Attach copy of
BCM
DATA MONITOR

Attach copy of
ABS
DATA MONITOR

Attach copy of
A/T
DATA MONITOR

Attach copy of
IPDM E/R
DATA MONITOR

MKIB0288E

Case 17

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 2	CAN CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN CIRC 3	—	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 6	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—	—
A/T	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—	—

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 2	CAN CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN CIRC 3	—	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 6	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—	—
A/T	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—	—

MKIB0294E

INSPECTION

Proceed trouble diagnosis according to the check sheet results (example).

Case 1: Replace ECM.

Case 2: Replace EPS control unit.

Case 3: Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#) .

Case 4: Replace ABS actuator and electric unit (control unit).

Case 5: Replace TCM.

Case 6: Replace IPDM E/R.

Case 7: Check harness between BCM and ABS actuator and electric unit (control unit). Refer to [LAN-47, "Circuit Check Between BCM and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

Case 8: Check ECM circuit. Refer to [LAN-49, "ECM Circuit Check"](#) .

Case 9: Check data link connector circuit. Refer to [LAN-50, "Data Link Connector Circuit Check"](#) .

Case 10: Check combination meter circuit. Refer to [LAN-51, "Combination Meter Circuit Check"](#) .

Case 11: Check EPS control unit circuit. Refer to [LAN-52, "EPS Control Unit Circuit Check"](#) .

Case 12: Check BCM circuit. Refer to [LAN-53, "BCM Circuit Check"](#) .

Case 13: Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-54, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

Case 14: Check TCM circuit. Refer to [LAN-55, "TCM Circuit Check"](#) .


Case 15: Check IPDM E/R circuit. Refer to [LAN-56, "IPDM E/R Circuit Check"](#) .

Case 16: Check CAN communication circuit. Refer to [LAN-57, "CAN Communication Circuit Check"](#) .

Case 17: Check IPDM E/R ignition relay circuit. Refer to [LAN-60, "IPDM E/R Ignition Relay Circuit Check"](#) .

Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)

EKS00811



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M1
 - Harness connector E101

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect following connector.
 - Harness connector M1
 - Combination meter connector
 - Drive computer connector
 - EPS control unit connector
 - BCM connector
2. Check continuity between BCM harness connector M48 terminals 19 (R), 39 (W) and harness connector M1 terminals 2C (R), 1C (W).

19 (R) – 2C (R)

: Continuity should exist.


39 (W) – 1C (W)

: Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector E101 terminals 2C (R), 1C (W) and ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R), 15 (W).

2C (R) – 26 (R)

: Continuity should exist.


1C (W) – 15 (W)

: Continuity should exist.

OK or NG


OK >> Reconnect all connectors to perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-40, "Work Flow"](#).

NG >> Repair harness.



ECM Circuit Check

EKS00812

A
B
C
D
E
F
G
H
I
J
LAN
L
M

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector M1
 - Harness connector E101

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E49 terminals 94 (R) and 86 (W).

94 (R) – 86 (W)**: Approx. 108 – 132Ω**OK or NG


OK >> Replace ECM.

NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Check

EKS00813



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M17 terminals 6 (R) and 14 (W).

6 (R) – 14 (W) : Approx. 54 – 66Ω

OK or NG


OK >> Perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-40, "Work Flow"](#).

NG >> Repair harness between data link connector and combination meter



Combination Meter Circuit Check

EKS00814



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M22 terminals 1 (R) and 2 (W).

1 (R) – 2 (W) : Approx. 54 – 66ΩOK or NG


OK >> Replace combination meter

NG >> Repair harness between combination meter and data link connector.



EPS Control Unit Circuit Check

EKS00815



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of EPS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect EPS control unit connector.
2. Check resistance between EPS control unit harness connector M23 terminals 8 (R) and 7 (W).

8 (R) – 7 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace EPS control unit.

NG >> Repair harness between EPS control unit and data link connector.



BCM Circuit Check

EKS00816



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.


NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M48 terminals 19 (R) and 39 (W).


19 (R) – 39 (W)**: Approx. 54 – 66Ω**OK or NGOK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

NG >> Repair harness between BCM and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

EKS00817



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R) and 15 (W).

26 (R) – 15 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace ABS actuator and electric unit (control unit).

NG >> Repair harness between ABS actuator and electric unit (control unit) and TCM.



TCM Circuit Check

EKS00818

A
B
C
D
E
F
G
H
I
J
LAN
L
M

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector.
2. Check resistance between TCM harness connector E105 terminals 5 (R) and 6 (W).

5 (R) – 6 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace TCM.

NG >> Repair harness between TCM and IPDM E/R.



IPDM E/R Circuit Check

EKS00819



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E16 terminals 52 (R) and 58 (W).

52 (R) – 58 (W)**: Approx. 108 – 132Ω**OK or NG

OK >> Replace IPDM E/R.

NG >> Repair harness between IPDM E/R and TCM.



CAN Communication Circuit Check

EKS0081A

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, control unit side and harness side).
 - ECM
 - Combination meter
 - Drive computer
 - EPS control unit
 - BCM
 - ABS actuator and electric unit (control unit)
 - TCM
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E101.
2. Check continuity between ECM harness connector E49 terminals 94 (R) and 86 (W).

94 (R) – 86 (W) : Continuity should not exist.OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E101.


**3. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between ECM harness connector E49 terminals 94 (R), 86 (W) and ground.

94 (R) – Ground : Continuity should not exist.**86 (W) – Ground** : Continuity should not exist.OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E101.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ABS actuator and electric unit (control unit) connector
 - TCM connector
 - IPDM E/R connector
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R) and 15 (W).


26 (R) – 15 (W) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and TCM
- Harness between ABS actuator and electric unit (control unit) and harness connector E101
- Harness between ABS actuator and electric unit (control unit) and IPDM E/R



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R), 15 (W) and ground.

26 (R) – Ground : Continuity should not exist.


15 (W) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and TCM
- Harness between ABS actuator and electric unit (control unit) and harness connector E101
- Harness between ABS actuator and electric unit (control unit) and IPDM E/R



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Combination meter connector
 - Drive computer connector
 - EPS control unit connector
 - BCM connector
2. Check continuity between data link connector M17 terminals 6 (R) and 14 (W).


6 (R) – 14 (W) : Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M1
- Harness between data link connector and combination meter
- Harness between data link connector and drive computer
- Harness between data link connector and EPS control unit
- Harness between data link connector and BCM.



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M17 terminals 6 (R), 14 (W) and ground.

6 (R) – ground : Continuity should not exist.


14 (W) – ground : Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M1
- Harness between data link connector and combination meter
- Harness between data link connector and drive computer
- Harness between data link connector and EPS control unit
- Harness between data link connector and BCM.



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-60, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Reconnect all connectors to perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-40, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

EKS0081B

Perform the self-diagnosis for IPDM E/R. Refer to [PG-35, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#). If the result is OK, carry out following inspections.

- IPDM E/R power supply circuit. Refer to [PG-38, "IPDM E/R Power Supply and Ground Circuit Check"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START""](#).


Component Inspection

EKS0081C

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 52 and 58.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 – 86	108 - 132
IPDM E/R	52 – 58	



LKIA0037E

CAN SYSTEM (TYPE 3)

PFP:23710


System Description

EKS0074L

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS0074M



A
B
C
D
E
F
G
H
I
J

LAN

L

CAN SYSTEM (TYPE 3)

[CAN]



Wiring Diagram — CAN —

EKS007YF

LAN-CAN-05

— : DATA LINE

WD : WITH DRIVE COMPUTER



REFER TO THE FOLLOWING.

(M1) -SUPER MULTIPLE JUNCTION (SMJ)

(E49) -ELECTRICAL UNITS

MKWA1308E

CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-06

 : DATA LINE

A

B


6

D

5

1

181




I REFER TO THE FOLLOWING.

**M1 -SUPER MULTIPLE
JUNCTION (SMJ)**


Work Flow

EKS0081D


- When there are no indications of "INTELLIGENT KEY", "EPS", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "INTELLIGENT KEY", "EPS", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "DATA MONITOR (CAN DIAG SUPPORT MNTR)" for "ENGINE", "INTELLIGENT KEY", "EPS", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" onto the check sheet. Refer to [LAN-65, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "DATA MONITOR (CAN DIAG SUPPORT MNTR)", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-65, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "CAN COMM" as "DATA MONITOR (CAN DIAG SUPPORT MNTR)" for the diagnosed control unit, replace the control unit.
- The "DATA MONITOR (CAN DIAG SUPPORT MNTR)" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of "DATA MONITOR (CAN DIAG SUPPORT MNTR)" items which are not indicated in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-67, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET

Check sheet table

SELECT SYSTEM		DATA MONITOR (CAN DIAG SUPPORT MNTR)								
ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	—	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 7
INTELLIGENT KEY	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 4	CAN CIRC 3	—	—	CAN CIRC 2	—	—
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	CAN CIRC 5	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 3	—	—

Symptoms:

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J

LAN

L

M

MKIB0295E

CAN SYSTEM (TYPE 3)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
INTELLIGENT KEY
SELF-DIAG RESULTS

Attach copy of
EPS
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
DATA MONITOR

Attach copy of
INTELLIGENT KEY
DATA MONITOR

Attach copy of
EPS
DATA MONITOR

Attach copy of
BCM
DATA MONITOR

Attach copy of
ABS
DATA MONITOR

Attach copy of
IPDM
DATA MONITOR

MKIB0296E

Case 17

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	—	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 7
INTELLIGENT KEY	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 4	CAN CIRC 3	—	—	CAN CIRC 2	—	—
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	CAN CIRC 5	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 3	—	—

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	—	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 7
INTELLIGENT KEY	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 4	CAN CIRC 3	—	—	CAN CIRC 2	—	—
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	CAN CIRC 5	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	—	CAN CIRC 3	—	—

MKIB0302E

INSPECTION

Proceed trouble diagnosis according to the check sheet results (example).

Case 1: Replace ECM.

Case 2: Replace Intelligent Key unit.

Case 3: Replace EPS control unit.

Case 4: Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#) .

Case 5: Replace ABS actuator and electric unit (control unit).

Case 6: Replace IPDM E/R.

Case 7: Check harness between BCM and ABS actuator and electric unit (control unit). Refer to [LAN-71, "Circuit Check Between BCM and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

Case 8: Check ECM circuit. Refer to [LAN-73, "ECM Circuit Check"](#) .

Case 9: Check data link connector circuit. Refer to [LAN-74, "Data Link Connector Circuit Check"](#) .

Case 10: Check combination meter circuit. Refer to [LAN-75, "Combination Meter Circuit Check"](#) .

Case 11: Check Intelligent Key unit circuit. Refer to [LAN-76, "Intelligent Key Unit Circuit Check"](#) .

Case 12: Check EPS control unit circuit. Refer to [LAN-77, "EPS Control Unit Circuit Check"](#) .

Case 13: Check BCM circuit. Refer to [LAN-78, "BCM Circuit Check"](#) .

Case 14: Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-79, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .


Case 15: Check IPDM E/R circuit. Refer to [LAN-80, "IPDM E/R Circuit Check"](#) .

Case 16: Check CAN communication circuit. Refer to [LAN-81, "CAN Communication Circuit Check"](#) .

Case 17: Check IPDM E/R ignition relay circuit. Refer to [LAN-84, "IPDM E/R Ignition Relay Circuit Check"](#) .

Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)

EKS0081E



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M1
 - Harness connector E101

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect following connector.
 - Harness connector M1
 - Combination meter connector
 - Intelligent Key unit connector
 - Drive computer connector
 - EPS control unit connector
 - BCM connector
2. Check continuity between BCM harness connector M48 terminals 19 (R), 39 (W) and harness connector M1 terminals 2C (R), 1C (W).

19 (R) – 2C (R)**: Continuity should exist.****39 (W) – 1C (W)****: Continuity should exist.**OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector E101 terminals 2C (R), 1C (W) and ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R), 15 (W).

2C (R) – 26 (R)

: Continuity should exist.


1C (W) – 15 (W)

: Continuity should exist.

OK or NG


OK >> Reconnect all connectors to perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-64, "Work Flow"](#).

NG >> Repair harness.



ECM Circuit Check

EKS0081F



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector M1
 - Harness connector E101

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E49 terminals 94 (R) and 86 (W).


94 (R) – 86 (W)

: Approx. 108 – 132Ω

OK or NG


OK >> Replace ECM.

NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Check

EKS0081G



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M17 terminals 6 (R) and 14 (W).

6 (R) – 14 (W) : Approx. 54 – 66Ω

OK or NG


OK >> Perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-64, "Work Flow"](#).

NG >> Repair harness between data link connector and combination meter



Combination Meter Circuit Check

EKS0081H



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M22 terminals 1 (R) and 2 (W).

1 (R) – 2 (W) : Approx. 54 – 66ΩOK or NG


OK >> Replace combination meter.

NG >> Repair harness between combination meter and data link connector.



Intelligent Key Unit Circuit Check

EKS00811



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of Intelligent Key unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect Intelligent Key unit connector.
2. Check resistance between Intelligent Key unit harness connector M51 terminals 2 (R) and 3 (W).

2 (R) – 3 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace Intelligent Key unit.

NG >> Repair harness between Intelligent Key unit and data link connector.



EPS Control Unit Circuit Check

EKS0081J



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of EPS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect EPS control unit connector.
2. Check resistance between EPS control unit harness connector M23 terminals 8 (R) and 7 (W).


8 (R) – 7 (W)

: Approx. 54 – 66Ω

OK or NG


OK >> Replace EPS control unit.

NG >> Repair harness between EPS control unit and data link connector.



BCM Circuit Check

EKS0081K



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.


NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M48 terminals 19 (R) and 39 (W).


19 (R) – 39 (W)**: Approx. 54 – 66Ω**OK or NGOK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

NG >> Repair harness between BCM and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

EKS0081L



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R) and 15 (W).

26 (R) – 15 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace ABS actuator and electric unit (control unit).

NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Check

EKS0081M



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E16 terminals 52 (R) and 58 (W).

52 (R) – 58 (W)**: Approx. 108 – 132Ω**OK or NG

OK >> Replace IPDM E/R.

NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



CAN Communication Circuit Check

EKS0081N

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, control unit side and harness side).
 - ECM
 - Combination meter
 - Intelligent Key unit
 - Drive computer
 - EPS control unit
 - BCM
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector E101.
2. Check continuity between ECM harness connector E49 terminals 94 (R) and 86 (W).

94 (R) – 86 (W) : Continuity should not exist.OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E101.


**3. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between ECM harness connector E49 terminals 94 (R), 86 (W) and ground.

94 (R) – Ground : Continuity should not exist.**86 (W) – Ground : Continuity should not exist.**OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E101.



4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ABS actuator and electric unit (control unit) connector
 - IPDM E/R connector
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R) and 15 (W).


26 (R) – 15 (W) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E101
- Harness between ABS actuator and electric unit (control unit) and IPDM E/R



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E45 terminals 26 (R), 15 (W) and ground.

26 (R) – Ground : Continuity should not exist.


15 (W) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E101
- Harness between ABS actuator and electric unit (control unit) and IPDM E/R



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Combination meter connector
 - Intelligent Key unit connector
 - Drive computer connector
 - EPS control unit connector
 - BCM connector
2. Check continuity between data link connector M17 terminals 6 (R) and 14 (W).

6 (R) – 14 (W)


: Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M1
- Harness between data link connector and combination meter
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and drive computer
- Harness between data link connector and EPS control unit
- Harness between data link connector and BCM



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M17 terminals 6 (R), 14 (W) and ground.

6 (R) – Ground

: Continuity should not exist.

14 (W) – Ground


: Continuity should not exist.

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M1
- Harness between data link connector and combination meter
- Harness between data link connector and Intelligent Key unit
- Harness between data link connector and drive computer
- Harness between data link connector and EPS control unit
- Harness between data link connector and BCM



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-84, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Reconnect all connectors to perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-64, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

EKS00810

Perform the self-diagnosis for IPDM E/R. Refer to [PG-35, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#). If the result is OK, carry out following inspections.

- IPDM E/R power supply circuit. Refer to [PG-38, "IPDM E/R Power Supply and Ground Circuit Check"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START""](#).


Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

EKS0081P

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 52 and 58.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 – 86	108 - 132
IPDM E/R	52 – 58	



LKIA0037E

CAN SYSTEM (TYPE 4)

PFP:23710


System Description

EKS00754

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00755



MKIB0325E

A
B
C
D
E
F
G
H
I
J

LAN

L

M

CAN SYSTEM (TYPE 4)

[CAN]



Wiring Diagram — CAN —

EKS007YU

LAN-CAN-07

□ : DATA LINE

 : WITH DRIVE COMPUTER



**M1 -SUPER MULTIPLE
JUNCTION (SMJ)**




JUNCTION (SMJ)

CAN SYSTEM (TYPE 4)

[CAN]

LAN-CAN-08

■ : DATA LINE




REFER TO THE FOLLOWING.

(M1) -SUPER MULTIPLE JUNCTION (SMJ)


Work Flow

EKS0081Q


- When there are no indications of "EPS", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "EPS", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "DATA MONITOR (CAN DIAG SUPPORT MNTR)" for "ENGINE", "EPS", "BCM", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" onto the check sheet. Refer to [LAN-89, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "DATA MONITOR (CAN DIAG SUPPORT MNTR)", put marks "v" onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-89, "CHECK SHEET"](#).

NOTE:

- If "NG" is displayed on "CAN COMM" as "DATA MONITOR (CAN DIAG SUPPORT MNTR)" for the diagnosed control unit, replace the control unit.
- The "DATA MONITOR (CAN DIAG SUPPORT MNTR)" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of "DATA MONITOR (CAN DIAG SUPPORT MNTR)" items which are not indicated in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-91, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET

Check sheet table

SELECT SYSTEM		DATA MONITOR (CAN DIAG SUPPORT MNTR)							
ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—

Symptoms:

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J

LAN

L
M

MKIB0303E

CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
EPS
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
DATA MONITOR

Attach copy of
EPS
DATA MONITOR

Attach copy of
BCM
DATA MONITOR

Attach copy of
ABS
DATA MONITOR

Attach copy of
IPDM E/R
DATA MONITOR

MKIB0304E

CAN SYSTEM (TYPE 4)

[CAN]

Case 6

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN CIRC 9	CAN CIRC 6	CAN ✓RC 3	CAN ✓RC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN ✓RC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN ✓RC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN ✓RC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—

Case 7

ENGINE	—	CAN COMM	CAN ✓RC 1	—	CAN CIRC 4	CAN ✓RC 9	CAN ✓RC 6	CAN ✓RC 3	CAN ✓RC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN ✓RC 2	CAN CIRC 4	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN ✓RC 2	CAN CIRC 4	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN ✓RC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN ✓RC 3	—	—	CAN CIRC 3	—	—

Case 8

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN ✓RC 4	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—

Case 9

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN ✓RC 4	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN ✓RC 4	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN ✓RC 4	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—

Case 10

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN ✓RC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—

Case 11

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN CIRC 9	CAN ✓RC 6	CAN CIRC 3	CAN CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN ✓RC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN ✓RC 3	—	—

Case 12

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN CIRC 9	CAN CIRC 6	CAN ✓RC 3	CAN CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN ✓RC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN ✓RC 1	CAN ✓RC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—

CAN SYSTEM (TYPE 4)

[CAN]

Case 13

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN <input checked="" type="checkbox"/> CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN <input checked="" type="checkbox"/> CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—

Case 14

ENGINE	—	CAN COMM	CAN <input checked="" type="checkbox"/> CIRC 1	—	CAN <input checked="" type="checkbox"/> CIRC 4	CAN <input checked="" type="checkbox"/> CIRC 9	CAN <input checked="" type="checkbox"/> CIRC 6	CAN <input checked="" type="checkbox"/> CIRC 3	CAN <input checked="" type="checkbox"/> CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN <input checked="" type="checkbox"/> CIRC 1	CAN <input checked="" type="checkbox"/> CIRC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—

Case 15

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN <input checked="" type="checkbox"/> CIRC 4	CAN <input checked="" type="checkbox"/> CIRC 9	CAN <input checked="" type="checkbox"/> CIRC 6	CAN CIRC 3	CAN <input checked="" type="checkbox"/> CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN CIRC 3	—	—	CAN CIRC 3	—	—

ENGINE	—	CAN COMM	CAN CIRC 1	—	CAN CIRC 4	CAN CIRC 9	CAN CIRC 6	CAN CIRC 3	CAN CIRC 7
EPS	No indication	CAN COMM	CAN CIRC 1	CAN <input checked="" type="checkbox"/> CIRC 2	CAN CIRC 4	—	CAN CIRC 5	CAN <input checked="" type="checkbox"/> CIRC 3	—
BCM	No indication	—	CAN CIRC 1	CAN <input checked="" type="checkbox"/> CIRC 2	CAN CIRC 4	—	—	—	CAN CIRC 3
ABS	—	CAN COMM	CAN CIRC 1	CAN CIRC 2	—	—	—	—	—
IPDM E/R	No indication	—	CAN CIRC 1	CAN <input checked="" type="checkbox"/> CIRC 3	—	—	CAN CIRC 3	—	—

MKIB0307E

INSPECTION

Proceed trouble diagnosis according to the check sheet results (example).

Case 1: Replace ECM.

Case 2: Replace EPS control unit.

Case 3: Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

Case 4: Replace ABS actuator and electric unit (control unit).

Case 5: Replace IPDM E/R.

Case 6: Check harness between BCM and ABS actuator and electric unit (control unit). Refer to [LAN-94, "Circuit Check Between BCM and ABS Actuator and Electric Unit \(Control Unit\)"](#).

Case 7: Check ECM circuit. Refer to [LAN-96, "ECM Circuit Check"](#).

Case 8: Check data link connector circuit. Refer to [LAN-97, "Data Link Connector Circuit Check"](#).

Case 9: Check combination meter circuit. Refer to [LAN-98, "Combination Meter Circuit Check"](#).

Case 10: Check EPS control unit circuit. Refer to [LAN-99, "EPS Control Unit Circuit Check"](#).

Case 11: Check BCM circuit. Refer to [LAN-100, "BCM Circuit Check"](#).

Case 12: Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-101, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

Case 13: Check IPDM E/R circuit. Refer to [LAN-102, "IPDM E/R Circuit Check"](#).

Case 14: Check CAN communication circuit. Refer to [LAN-103, "CAN Communication Circuit Check"](#).

Case 15: Check IPDM E/R ignition relay circuit. Refer to [LAN-106, "IPDM E/R Ignition Relay Circuit Check"](#).

A

B

C

D

E

F

G

H


LAN

L

M

Circuit Check Between BCM and ABS Actuator and Electric Unit (Control Unit)

EKS0081R

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M1
 - Harness connector E101

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect following connector.
 - Harness connector M1
 - Combination meter connector
 - Drive computer connector
 - EPS control unit connector
 - BCM connector
2. Check continuity between BCM harness connector M48 terminals 19 (R), 39 (W) and harness connector M1 terminals 2C (R), 1C (W).

19 (R) – 2C (R)**: Continuity should exist.****39 (W) – 1C (W)****: Continuity should exist.**OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector E101 terminals 2C (R), 1C (W) and ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R), 15 (W).

2C (R) – 26 (R)

: Continuity should exist.


1C (W) – 15 (W)

: Continuity should exist.

OK or NG


OK >> Reconnect all connectors to perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-88, "Work Flow"](#).

NG >> Repair harness.



ECM Circuit Check

EKS0081S



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector M1
 - Harness connector E101

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E49 terminals 94 (R) and 86 (W).

94 (R) – 86 (W)**: Approx. 108 – 132Ω**OK or NG


OK >> Replace ECM.

NG >> Repair harness between ECM and data link connector.



Data Link Connector Circuit Check

EKS0081T



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector and terminals for damage, bend and loose connection (connector side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M17 terminals 6 (R) and 14 (W).

6 (R) – 14 (W) : Approx. 54 – 66ΩOK or NG


OK >> Perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-88, "Work Flow"](#).

NG >> Repair harness between data link connector and combination meter



Combination Meter Circuit Check

EKS0081U



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M22 terminals 1 (R) and 2 (W).

1 (R) – 2 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace combination meter

NG >> Repair harness between combination meter and data link connector.



EPS Control Unit Circuit Check

EKS0081V



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of EPS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect EPS control unit connector.
2. Check resistance between EPS control unit harness connector M23 terminals 8 (R) and 7 (W).

8 (R) – 7 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace EPS control unit.

NG >> Repair harness between EPS control unit and data link connector.



BCM Circuit Check

EKS0081W



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.


NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M48 terminals 19 (R) and 39 (W).


19 (R) – 39 (W)**: Approx. 54 – 66Ω**OK or NGOK >> Replace BCM. Refer to [BCS-17, "Removal and Installation of BCM"](#).

NG >> Repair harness between BCM and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

EKS0081X



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R) and 15 (W).

26 (R) – 15 (W)**: Approx. 54 – 66Ω**OK or NG


OK >> Replace ABS actuator and electric unit (control unit).

NG >> Repair harness between ABS actuator and electric unit (control unit) and IPDM E/R.



IPDM E/R Circuit Check

EKS0081Y



1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E16 terminals 52 (R) and 58 (W).

52 (R) – 58 (W)**: Approx. 108 – 132Ω**OK or NG

OK >> Replace IPDM E/R.

NG >> Repair harness between IPDM E/R and ABS actuator and electric unit (control unit).



CAN Communication Circuit Check

EKS0081Z

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, meter side, control unit side and harness side).
 - ECM
 - Combination meter
 - Drive computer
 - EPS control unit
 - BCM
 - ABS actuator and electric unit (control unit)
 - IPDM E/R
 - Between ECM and IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector and harness connector E101.
2. Check continuity between ECM harness connector E49 terminals 94 (R) and 86 (W).

94 (R) – 86 (W) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector E101.



PKIA0816E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E49 terminals 94 (R), 86 (W) and ground.


94 (R) – Ground : Continuity should not exist.

86 (W) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector E101.



PKIA0829E

4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - ABS actuator and electric unit (control unit) connector
 - IPDM E/R connector
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E45 terminals 26 (R) and 15 (W).


26 (R) – 15 (W) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E101
- Harness between ABS actuator and electric unit (control unit) and IPDM E/R



5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector E45 terminals 26 (R), 15 (W) and ground.

26 (R) – Ground : Continuity should not exist.


15 (W) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ABS actuator and electric unit (control unit) and harness connector E101
- Harness between ABS actuator and electric unit (control unit) and IPDM E/R



6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
 - Combination meter connector
 - Drive computer connector
 - EPS control unit connector
 - BCM connector
2. Check continuity between data link connector M17 terminals 6 (R) and 14 (W).


6 (R) – 14 (W) : Continuity should not exist.

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M1
- Harness between data link connector and combination meter
- Harness between data link connector and drive computer
- Harness between data link connector and EPS control unit
- Harness between data link connector and BCM



7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M17 terminals 6 (R), 14 (W) and ground.

6 (R) – Ground : Continuity should not exist.


14 (W) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M1
- Harness between data link connector and combination meter
- Harness between data link connector and drive computer
- Harness between data link connector and EPS control unit
- Harness between data link connector and BCM



8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

Check components inspection. Refer to [LAN-106, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#).

OK or NG

OK >> Reconnect all connectors to perform "SELECT SYSTEM", "SELF-DIAG RESULTS" and "DATA MONITOR (CAN DIAG SUPPORT MNTR)" displayed on CONSULT-II. Refer to [LAN-88, "Work Flow"](#).

NG >> Replace ECM and/or IPDM E/R.

IPDM E/R Ignition Relay Circuit Check

EKS00820

Perform the self-diagnosis for IPDM E/R. Refer to [PG-35, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#). If the result is OK, carry out following inspections.

- IPDM E/R power supply circuit. Refer to [PG-38, "IPDM E/R Power Supply and Ground Circuit Check"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START""](#).

Component Inspection

EKS00821

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 52 and 58.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 – 86	108 - 132
IPDM E/R	52 – 58	

