

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

PRECAUTIONS	3	INSPECTION IN AUTO ACTIVE TEST MODE ... 30	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	CONCEPT OF AUTO ACTIVE TEST 31	
Maintenance Information	3	Schematic 33	
RHD MODELS	3	IPDM E/R Terminal Arrangement 34	
LHD MODELS	3	Inspection With CONSULT-II (Self-Diagnosis) 35	
POWER SUPPLY ROUTING	4	IPDM E/R Terminal Inspection 37	
Schematic	4	IPDM E/R Power Supply and Ground Circuit Check.. 38	
Wiring Diagram — POWER —	5	Diagnosis of IPDM E/R Integrated Relay 39	
BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION	5	Removal and Installation of IPDM E/R 41	
ACCESSIONARY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"	11	REMOVAL 41	
IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"	12	INSTALLATION 41	
Fuse	17	GROUND	42
Fusible Link	17	Ground Distribution 42	
Circuit Breaker	17	MAIN HARNESS 42	
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	18	ENGINE ROOM HARNESS 46	
System Description	18	ENGINE CONTROL HARNESS/QR ENGINE MODELS 49	
SYSTEMS CONTROLLED BY IPDM E/R	18	BODY HARNESS 50	
FAIL-SAFE FUNCTION	19	HARNESS	54
IPDM E/R STATUS CONTROL	19	Harness Layout 54	
FUNCTION OF IPDM E/R	19	HOW TO READ HARNESS LAYOUTS 54	
CAN Communication	20	OUTLINE/LHD MODELS 55	
A/T MODELS	20	OUTLINE/RHD MODELS 56	
M/T MODELS	23	MAIN HARNESS/LHD MODELS 57	
Function of Detecting Ignition Relay Malfunction	25	MAIN HARNESS/RHD MODELS 59	
CONSULT-II Functions	25	ENGINE ROOM HARNESS 61	
CONSULT-II BASIC OPERATION	25	ENGINE CONTROL HARNESS 63	
SELF-DIAG RESULTS	26	BODY HARNESS 65	
DATA MONITOR	27	ROOM LAMP HARNESS 68	
CAN TROUBLE DIAGNOSIS SUPPORT MONITOR	28	FRONT DOOR HARNESS LH SIDE/LHD MOD-ELS	69
ACTIVE TEST	28	FRONT DOOR HARNESS LH SIDE/RHD MOD-ELS	70
Auto Active Test	29	FRONT DOOR HARNESS RH SIDE/LHD MOD-ELS	71
DESCRIPTION	29	FRONT DOOR HARNESS RH SIDE/RHD MOD-ELS	72
OPERATION PROCEDURE	29	REAR DOOR HARNESS LH	73
		REAR DOOR HARNESS RH	74
		Wiring Diagram Codes (Cell Codes)	75

ELECTRICAL UNITS LOCATION	78	SMJ (SUPER MULTIPLE JUNCTION)	84
Electrical Units Location	78	Terminal Arrangement	84
ENGINE COMPARTMENT	78	STANDARDIZED RELAY	85
PASSENGER COMPARTMENT/LHD MODELS..	79	Description	85
HARNESS CONNECTOR	81	NORMAL OPEN, NORMAL CLOSED AND	
Description	81	MIXED TYPE RELAYS	85
HARNESS CONNECTOR (TAB-LOCKING		TYPE OF STANDARDIZED RELAYS	85
TYPE)	81	FUSE BLOCK - JUNCTION BOX (J/B)	87
HARNESS CONNECTOR (SLIDE-LOCKING		Terminal Arrangement	87
TYPE)	82	FUSE AND FUSIBLE LINK BOX	88
ELECTRICAL UNITS	83	Terminal Arrangement	88
Terminal Arrangement	83		

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EKS008IN

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

Maintenance Information

EKS008IP

If any of following part is replaced, always replace with new* one.

If it's not (or fail to do so), the electrical system may not be operated properly.

*: New one means a virgin control unit that has never been energized on-board.

RHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM
- IPDM E/R
- Combination meter
- EPS control unit

LHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM

A

B

C

D

E

F

G

H

I

J

PG

L

M


POWER SUPPLY ROUTING

POWER SUPPLY ROUTING

PFP:00011

Schematic

EKS00795






★: This relay is built into the IPDM E/R (Intelligent power distribution module engine room)

POWER SUPPLY ROUTING

Wiring Diagram — POWER — BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION

EKS00796




PG-POWER-01




MKWA1324E

POWER SUPPLY ROUTING

PG-POWER-02




REFER TO THE FOLLOWING.



MKWA1325E

POWER SUPPLY ROUTING

PG-POWER-03




MKWA1326E

POWER SUPPLY ROUTING

PG-POWER-04


■ : DATA LINE



MKWA1327E

POWER SUPPLY ROUTING


PG-POWER-05



MKWA1328E

POWER SUPPLY ROUTING

PG-POWER-06





MKWA1329E

POWER SUPPLY ROUTING

ACCESSORY POWER SUPPLY — IGNITION SW. IN “ACC” OR “ON”

PG-POWER-07

(L) : LHD MODELS
(R) : RHD MODELS



REFER TO THE FOLLOWING.
(M1) -SUPER MULTIPLE
JUNCTION (SMJ)


(M16) -FUSE BLOCK-
JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17							

POWER SUPPLY ROUTING

IGNITION POWER SUPPLY — IGNITION SW. IN “ON” AND/OR “START”

PG-POWER-08



REFER TO THE FOLLOWING.



(M1) -SUPER MULTIPLE
JUNCTION (SMJ)

(M16) -FUSE BLOCK-
JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17							

POWER SUPPLY ROUTING

PG-POWER-09



REFER TO THE FOLLOWING.


(M1) -SUPER MULTIPLE JUNCTION (SMJ)

(M16) -FUSE BLOCK- JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17							

POWER SUPPLY ROUTING

PG-POWER-10



MKWA1333E

POWER SUPPLY ROUTING


PG-POWER-11

A
B
C
D
E
F
G
H
I
J

PG

L

M




MKWA1334E

POWER SUPPLY ROUTING

PG-POWER-12

(L) : LHD MODELS
(R) : RHD MODELS



REFER TO THE FOLLOWING.

(M16) -FUSE BLOCK-
JUNCTION BOX (J/B)

1 2 3 4 5 6 7 8 9 10 11 12


13 14 15 16 17

POWER SUPPLY ROUTING

Fuse

EKS00797

- If fuse is blown, be sure to eliminate cause of incident before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




Fusible Link

EKS00798

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:


- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of incident.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker

EKS00799

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



A
B
C
D
E
F
G
H
I
J
PG
L
M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

PFP:284B7

System Description

EKS0080P

- IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) integrates the relay box and the fuse box which has been conventionally placed in the engine room. It controls the built-in relay with the control circuit in IPDM E/R.
- IPDM E/R integrated control circuit performs ON-OFF control of the relay and transmission of various signals (oil pressure switch, park/neutral position switch, reverse switch) through CAN communication with BCM and ECM.

NOTE:

All IPDM E/R integrated relays can never be removed.

SYSTEMS CONTROLLED BY IPDM E/R

1. Lamp control
Using the CAN communication line, it receives signals from BCM and controls following lamps:
 - Headlamps (Hi, Lo)
 - Parking lamps, tail lamps and license plate lamp
 - Front fog lamps
2. Front wiper control
Using the CAN communication line, it receives signals from BCM and controls front wiper.
3. Headlamp washer control
Using the CAN communication line, it receives signals from BCM and controls headlamp washer.
4. Rear window defogger control
Using the CAN communication line, it receives signals from BCM and controls rear window defogger.
5. A/C compressor control
Using the CAN communication line, it receives signals from ECM and controls A/C compressor.
6. Cooling fan control
Using the CAN communication line, it receives signals from ECM and controls cooling fan.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

FAIL-SAFE FUNCTION

- When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.
- Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled parts	Fail-safe mode
Headlamp	With the ignition switch ON, the headlamp (low) is ON. With the ignition switch OFF, the headlamp (low) is OFF.
Parking lamp/ license plate lamp/ tail lamp	With the ignition switch ON, the tail lamp is ON. With the ignition switch OFF, the tail lamp is OFF.
Cooling fan	With the ignition switch ON, the cooling fan HI operates. With the ignition switch OFF, the cooling fan stops.
Front wiper	Until the ignition switch is turned off, the front wiper LO and HI remains in the same status it was in just before fail-safe control was initiated.
Rear window defogger	Rear window defogger is OFF
Front fog lamp	Front fog lamp is OFF
Headlamp washer	Headlamp washer is OFF
A/C compressor	A/C compressor is OFF

IPDM E/R STATUS CONTROL

In order to save power, the IPDM E/R switches status by itself based on each operating condition.

- CAN communication status
 - CAN communication is normally performed with other control units.
 - Individual unit control by the IPDM E/R is normally performed.
 - When the IPDM E/R is not controlling any load, a sleep request signal is received from the BCM and the mode is switched to sleep waiting status.
- Sleep waiting status
 - Process to stop CAN communication is activated.
 - All systems controlled by IPDM E/R are stopped. When 1 second has elapsed after CAN communication with other control units is stopped, mode switches to sleep status.
- Sleep status
 - The IPDM E/R operates in low current consumption mode.
 - CAN communication is not active.
 - When a change in the CAN communication line or ignition switch ON is detected, the mode switches to CAN communication status.

FUNCTION OF IPDM E/R

- Park/neutral position switch signal output function
The signal (ON/OFF) input from the Park/neutral position is output to ECM.
- Oil pressure switch output function
The signal (ON/OFF) input from the oil pressure switch is output to the combination meter using the CAN communication line.
- Reverse switch signal output function
The signal (ON/OFF) input from the reverse switch is output to BCM using the CAN communication line.

CAN Communication


EKS0080Q

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. A modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, two control units are connected with two communication lines (CAN H-line, L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.


A/T MODELS

System diagram

- With intelligent key unit



- Without intelligent key unit



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combi-nation meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R

A
B
C
D
E
F
G
H
I
J

PG
L
M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


M/T MODELS

System diagram

- With intelligent key unit



- Without intelligent key unit



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

Function of Detecting Ignition Relay Malfunction

EKS0080R

- When a contact point of the integrated ignition relay is stuck and cannot be turned OFF, the IPDM E/R turns ON tail lamp relay for 10 minutes to indicate IPDM E/R malfunction.

NOTE:

When the ignition switch is turned ON, the tail lamp is off.

CONSULT-II Functions

EKS0080S

CONSULT-II performs the following functions with combination of data receiving, command and transmission using the CAN communication line from the IPDM E/R.

Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	The IPDM E/R performs diagnosis of the CAN communication and self-diagnosis.
DATA MONITOR	The input/output data of the IPDM E/R is displayed in real time.
ACTIVE TEST	The IPDM E/R sends a drive signal to electronic components to check their operation.


CONSULT-II BASIC OPERATION

- Turn ignition switch OFF.
- Connect CONSULT-II CONVERTER and CONSULT-II to data link connector.


CAUTION:

If CONSULT-II is used without connecting CONSULT-II CONVERTER, malfunction may be detected in some control unit performing CAN communication by self-diagnosis.


- Turn ignition switch ON.



- Touch "START (NISSAN BASED VHCL)".
- Touch "IPDM E/R" on "SELECT SYSTEM" screen.
 - If "IPDM E/R" is not displayed, print "SELECT SYSTEM" screen, then refer to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



- Select part to be diagnosed on "SELECT DIAG MODE" screen.



SELF-DIAG RESULTS

Operation Procedure

1. Touch “SELF-DIAG RESULTS” on “SELECT DIAG MODE” screen.
2. Check display content in self-diagnostic results.

Display Item List

Display Items	Malfunction Return Condition	TIME		Possible causes
		CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—	—
CAN COMM CIRCUIT	<ul style="list-style-type: none"> • If CAN communication reception/transmission data has an malfunction, or if any of the control units malfunction, data reception/transmission cannot be confirmed. • When the data in CAN communication is not received before the specified time 	×	×	Any of or several items below have malfunctions. <ul style="list-style-type: none"> • CAN CIRC 1 • CAN CIRC 2 • CAN CIRC 3 • CAN1 STAT • CAN2 STAT • CAN3 STAT
IGN RELAY ON	When the ignition switch is not ON position, the ignition relay in the IPDM E/R is ON.	×	×	Ignition relay (integrated in IPDM E/R)
IGN RELAY OFF	When the ignition switch is ON position, the ignition relay in the IPDM E/R is OFF.	×	×	Ignition relay (integrated in IPDM E/R)
EEPROM	Malfunction is detected with the integrated EEPROM memory diagnosis.	×	×	IPDM E/R

×:Applicable

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

DATA MONITOR

Operation Procedure

1. Touch “DATA MONITOR” on “SELECT MONITOR ITEM” screen.
2. Touch “ALL SIGNALS”, “MAIN SIGNALS” or “SELECT FROM MENU” on the “DATA MONITOR” screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitor the predetermined item.
SELECT FROM MENU	Select any item for monitoring.

3. Touch “START”.
4. Touch the required monitoring item on “SELECT ITEM MENU”. In “ALL SIGNALS”, all items are monitored. In “MAIN SIGNALS”, predetermined items are monitored.
5. Touch “RECORD” while monitoring to record the status of the item being monitored. To stop recording, touch “STOP”.

All Items, Main Items, Select Item Menu

Item name	Display or unit	Monitor item selection			Description
		ALL SIGNALS	MAIN SIGNALS	SELECT FROM MENU	
MOTOR FAN REQ	1/2/3/4	×	×	×	Signal status input from ECM
A/C COMP REQ	ON/OFF	×	×	×	Signal status input from ECM
TAIL & CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
HL WASHER REQ	ON/OFF	×		×	This item cannot be monitored. (No change of display)
FR WIP REQ	OFF/1LO/LO/HI	×	×	×	Signal status input from BCM
WIP AUTO STOP	ON/OFF	×	×	×	Output status of IPDM E/R
WIP PROTECTION	OFF/LS/HS/Block	×		×	Control status of IPDM E/R
ST RLY REQ	ON/OFF	×		×	Status of input signal CAUTION
IGN RLY STATUS	ON/OFF	×	×	×	Ignition relay status monitored with IPDM E/R
RR DEF REQ	ON/OFF	×	×	×	Signal status input from BCM
RR DEF STOP REQ	ON/OFF	×		×	Input signal status
ALT LOAD	%	×		×	This item cannot be monitored. (No change of display)
ALT CRNT	A	×		×	
ALT NO	##	×		×	
BAT VOLT	V	×		×	Value measured with IPDM E/R
ENG COOL TEMP	°C	×		×	Signal status input from ECM
OIL P SW	OPEN/CLOSE	×		×	Signal status input in IPDM E/R
REV SW	OPEN/CLOSE	×		×	Signal status input in IPDM E/R

x:applicable

NOTE:

- Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.
- The vehicle without the intelligent key system displays only ON without change.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

CAN TROUBLE DIAGNOSIS SUPPORT MONITOR

Operation Procedure

1. Touch “DATA MONITOR” on “SELECT MONITOR ITEM” screen.
2. Touch “CAN DIAG SUPPORT MNTR” on the “DATA MONITOR” screen.
3. Touch “START”.
4. Touch “RECORD” while monitoring to record the status of the item being monitored. To stop recording, touch “STOP”.

Display item	Display
CAN CIRC 1	OK/UNKWN
CAN CIRC 2	OK/UNKWN
CAN CIRC 3	OK/UNKWN
CAN1 STAT	0.00/1.00
CAN2 STAT	0.00/1.00
CAN3 STAT	0.00/1.00

NOTE:

The details for display of the period are as follows:

- 0.00 = Normal
- 1.00 = IPDM E/M detected malfunction of CAN communication in the past.

ACTIVE TEST

Operation Procedure

1. Touch “ACTIVE TEST” on “SELECT DIAG-MODE” screen.
2. Touch item to be tested, and check operation.
3. Touch “START”.
4. Touch “STOP” while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Headlamp (HI, LO) output	HEADLAMP	With a certain operation (OFF, HI ON, LO ON), the headlamp relay (Lo, Hi) can be operated.
Front fog lamp output	FRONT FOG LAMP	With a certain ON-OFF operation, the fog lamp relay can be operated.
Tail lamp output	TAIL LAMP	With a certain ON-OFF operation, the tail lamp relay can be operated.
Rear window defogger output	REAR DEFOGGER	With a certain ON-OFF operation, the rear window defogger relay can be operated.
Front wiper (HI, LO) output	FRONT WIPER	With a certain operation (OFF, HI ON, LO ON), the front wiper relay (Lo, Hi) can be operated.
Cooling fan output	MOTOR FAN	With a certain operation (OFF, Status 1, Status 2, Status 3), the cooling fan can be operated.
Headlamp washer output	HEADLAMP WASHER	With a certain ON-OFF operation, the headlamp washer can be operated.

Auto Active Test

DESCRIPTION

EKS0080T

- In the auto active test, the IPDM E/R sends a drive signal to the following systems to check operation.
 - Rear window defogger
 - Front wiper (Low, High)
 - Parking lamps, license lamps, tail lamps
 - Front fog lamp
 - Headlamp (Low, High)
 - Headlamp washer
 - A/C compressor (magnetic clutch)
 - Cooling fan

OPERATION PROCEDURE

1. Close hood, and keep wiper arms off the windshield (to prevent glass damage by wiper operation).

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn ignition switch OFF.
3. Turn ignition switch ON, and within 20 seconds, press the driver's seat door switch 10 times. Then turn ignition switch OFF.

CAUTION:

Keep passenger's the seat door closed.

4. Turn ignition switch ON within 10 seconds.
5. When auto active test mode is actuated, oil pressure warning lamp starts blinking.
6. After a series of operations is repeated 3 times, auto active test is completed.

NOTE:

When the auto active test mode has to be cancelled halfway, turn ignition switch OFF.

CAUTION:

When the auto active test cannot be started, check the oil pressure switch system [DI-54, "Oil Pressure Warning Lamp Stays Off \(Ignition Switch ON\)"](#) and the [BL-48, "Check Door Switch"](#).

A

B

C

D

E

F

G

H

I

J

PG

L

M

INSPECTION IN AUTO ACTIVE TEST MODE

When the auto active test is started, repeat steps 1 to 9 as below three times.

- Step 1: Rear window defogger is operated for 10 seconds.
- Step 2: Front wiper is operated with low speed for 5 seconds and high speed for 5 seconds.
- Step 3: Parking, license plate, tail lamp are turned on for 10 seconds.
- Step 4: Front fog lamp is turned on for 10 seconds.

NOTE:


If the fog lamp is not equipped, this step will be skipped. (In this case, next step will be start after 10 seconds.)

- Step 5: Headlamp (low) is turned on for 10 seconds.
- Step 6: Headlamp (high) is blinked ON and OFF for 5 times.
- Step 7: Headlamp washer is operated for 1 second and it is stopped for 9 seconds.

NOTE:

If the headlamp washer is not equipped, this step will be skipped. (In this case, next step will be start after 10 seconds.)

- Step 8: A/C compressor ON and OFF operation is repeated for 5 times.
- Step 9: Cooling fan motor is operated with low speed for 5 seconds and high speed for 5 seconds.



MKIB0523E

*1: Step 4 will be skipped, if the front fog lamp is not equipped. (In the case, next step will be start after 10 seconds.)

*2: Step 7 will be skipped, if the headlamp washer is not equipped. (In the case, next step will be start after 10 seconds.)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

CONCEPT OF AUTO ACTIVE TEST

- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.

Diagnosis Chart in Auto Active Test Mode

Symptom	Inspection Contents	Possible causes		Reference page
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES	● BCM signal input system	GW-14
		NO	● Harness for open or short between the IPDM E/R and the rear window defogger ● Open circuit of rear window defogger ● IPDM E/R (integrated relay) malfunction (Rear window defogger relay)	
Front wiper does not illuminate.	Perform auto active test. Does the front wiper operate?	YES	● BCM signal input system	WW-4 (without rain sensor) or WW-37 (with rain sensor)
		NO	● Wiper motor malfunction ● Front wiper motor ground.	
Either of parking lamp, license plate lamp and tail lamp does not illuminate.	Perform auto active test. Does parking lamp, license plate lamp and tail lamp illuminate?	YES	● BCM signal input system	LT-82
		NO	● Bulb ● Harness for open or short between IPDM E/R and parking, license plate or tail lamp. ● IPDM E/R (integrated relay) malfunction	
Front fog lamp does not illuminate.	Perform auto active test. Does the front fog lamp illuminate?	YES	● BCM signal input system	LT-48
		NO	● Bulb ● Harness for open or short between IPDM E/R and front fog lamp. ● IPDM E/R (integrated relay) malfunction	
Headlamp (Hi, Lo) does not illuminate.	Perform auto active test. Does headlamp?	YES	● BCM signal input system	LT-5_ "HEAD-LAMP-CONVENTIONAL TYPE -" or LT-32_ "HEAD-LAMP-DAYTIME LIGHT SYSTEM -"
		NO	● Bulb ● Headlamp ground system malfunction ● Open or short in harness or headlamp between IPDM E/R and headlamps ● IPDM E/R (integrated relay) malfunction (headlamp relay)	
Headlamp washer does not operate.	Perform auto active test. Does the Headlamp washer operate?	YES	● BCM signal input system	WW-73
		NO	● Harness for open or short between IPDM E/R and headlamp washer. ● Headlamp washer relay is malfunction.	
The cooling fan is inoperative.	Perform auto active test. Does the cooling fan operate?	YES	● Signal input system of ECM ● CAN communication signal between ECM and IPDM E/R*	EC-326 (with EURO-OBD) or EC-613 (without EURO-OBD)
		NO	● Malfunction of cooling fan ● Harness open or short between the IPDM E/R and the cooling fan. ● IPDM E/R (integrated relay) malfunction	

A
B
C
D
E
F
G
H
I
J

PG
L
M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


Symptom	Inspection Contents		Possible causes	Reference page
The A/C compressor is inoperative.	Perform auto active test. Does magnetic clutch operate?	YES	<ul style="list-style-type: none"> ● CAN communication signal between BCM and ECM*. ● CAN communication signal between ECM and IPDM E/R*. ● BCM signal input system ● Signal input system of ECM. 	ATC-39
		NO	<ul style="list-style-type: none"> ● Magnetic clutch inoperative. ● Harness for open or short between IPDM E/R and magnetic clutch. ● IPDM E/R (integrated relay) malfunction 	
Oil pressure warning lamp does not operate.	Perform auto active test. Does oil pressure warning lamp blink?	YES	<ul style="list-style-type: none"> ● Harness for open or short between IPDM E/R and oil pressure switch. ● Oil pressure switch malfunction 	DI-48
		NO	<ul style="list-style-type: none"> ● CAN communication signal between IPDM E/R and combination meter*. ● Combination meter 	

*: Perform IPDM E/R self-diagnosis with CONSULT-II. Refer to [PG-35, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Schematic

EKS0080U




NOTE:

Refer to each control system for details of connecting parts.

MKWA1360E

IPDM E/R Terminal Arrangement

EKS0080V



MKWA1370E

Inspection With CONSULT-II (Self-Diagnosis)

EKS0080W

1. CHECK SELF-DIAGNOSTIC RESULT

1. Connect CONSULT-II and select "IPDM E/R" on the Diagnosis System Selection screen.
2. Select "SELF-DIAG RESULTS" on the diagnosis mode selection screen.
3. Check display content in self-diagnostic results.

CONSULT-II display	CONSULT-II display code	TIME		Details of diagnosis result
		CRN T	PAS T	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—	—
IGN RELAY ON	B2098	×	×	Ignition relay malfunction (integrated in IPDM E/R)
IGN RELAY OFF	B2099	×	×	Ignition relay malfunction (integrated in IPDM E/R)
EEPROM	B2100	×	×	IPDM E/R malfunction
CAN COMM CIRCUIT	U1000	×	×	Any of or several items below have malfunction. • CAN CIRC 1 • CAN CIRC 2 • CAN CIRC 3 • CAN1 STAT • CAN2 STAT • CAN3 STAT

x: Applicable

CAUTION:

If errors of the CAN communication system and the ignition relay ON or OFF are displayed at the same time after the self-diagnostic result, replace the IPDM E/R and perform the self-diagnosis again.

NOTE:

The details for display of the period are as follows:

- CRNT: Malfunction currently detected with IPDM E/R.
- PAST: Malfunction detected in the past and memorized with IPDM E/R.

Contents displayed

NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.>>INSPECTION END.

CAN COMM CIRCUIT>>Print out the self-diagnostic result and go to 2.

IGN RELAY ON>>Replace IPDM E/R.

IGN RELAY OFF>>Replace IPDM E/R.

EEPROM>>Replace IPDM E/R.

2. SYMPTOM CHECK

1. Select "CAN DIAG SUPPORT MNTR" on the DATA MONITOR.
2. Select "START" and check display contents.

Diagnosis item	Data monitor display contents	
	Normal conditions	Malfunction conditions (example)
CAN CIRC 1	OK	UNKWN
CAN CIRC 2	OK	UNKWN
CAN CIRC 3	OK	UNKWN
CAN1 STAT	0.00	1.00
CAN2 STAT	0.00	1.00
CAN3 STAT	0.00	1.00

NOTE:

- 0.00: Normally
- 1.00: IPDM E/R detects malfunction in the past.

>> After print-out of the monitor items, refer to [LAN-3, "Precautions When Using CONSULT-II"](#) .



IPDM E/R Terminal Inspection

EKS0080X

CAUTION:

This is performed when the IPDM E/R is checked without removing the battery.

1. Remove the headlamp (LH).
2. Remove tabs of the IPDM E/R and place the IPDM E/R with its connector facing upward. Check each terminal.



A
B
C
D
E
F
G
H
I
J

PG

L

M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R Power Supply and Ground Circuit Check

EKS0089R

1. CHECK FUSE AND FUSIBLE LINK

Make sure that the following fusible links or IPDM E/R fuses are not blown.

Terminal No.	Power source	Fuse, fusible link No.
1	Battery	Letter C
2	Battery	Letter D
40	Ignition switch (ON)	80

OK or NG


OK >> GO TO 2.

NG >> Replace fuse or fusible link.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R harness connector.
2. Check voltage between IPDM E/R and ground.

Terminals		Ignition switch position		
Connector	(+)	(-)	OFF	ACC
E10	1 (R)	Ground	Battery voltage	Battery voltage
	2 (G)		Battery voltage	Battery voltage
E14	40 (PU)		0V	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Check harness between fuse, fusible link and IPDM E/R.

3. CHECK GROUND CIRCUIT


1. Disconnect IPDM E/R harness connectors.
2. Check continuity between IPDM E/R harness connectors E12 terminal 14 (B), E16 terminal 54 (B) and ground.

Continuity should exist.

OK or NG

OK >> INSPECTION END.

NG >> Repair harness for ground circuit.



Diagnosis of IPDM E/R Integrated Relay

EKS0080Z

1. CHECK SYMPTOM

Check the symptom of the malfunction relay.

What is the symptom?

No operation>>GO TO 2.

No stop>> GO TO 4.

2. CHECK RELAY TYPEWhich is the relay with error?

Front fog lamp relay, headlamp relay (Hi, Lo), tail lamp relay, front wiper relay (main, Hi/Lo), rear window defogger relay, A/C relay, starter motor relay, cooling fan relay (1, 2, 3)>>GO TO 5.

Ignition relay>> Go to [PG-35, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#)ECM relay>>Go to [EC-115, "POWER SUPPLY CIRCUIT FOR ECM"](#) (with EURO-OBD) or [EC-500, "POWER SUPPLY CIRCUIT FOR ECM"](#) (without EURO-OBD) in "EC engine control".Throttle motor relay>>Go to [EC-284, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (with EURO-OBD) or [EC-599, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (without EURO-OBD) in "EC engine control"Fuel pump relay>>Go to [EC-391, "FUEL PUMP CIRCUIT"](#) (with EURO-OBD) or [EC-717, "FUEL PUMP CIRCUIT"](#) (without EURO-OBD) in "EC engine control"**3. CHECK RELAY**Send an operation signal to the relay using a diagnosis tool. Check the voltage at the input and output terminals of inoperative relays according to the table below or check for continuity between input and output terminals. Refer to [PG-28, "ACTIVE TEST"](#) or [PG-29, "Auto Active Test"](#) .

Relay name	IPDM E/R terminal number		Voltage [V]	Diagnosis tool	
	Input side	Output side		CONSULT-II ACTIVE TEST	Auto ACTIVE TEST
Front fog lamp relay	1	43, 44	Battery voltage	×	×
Headlamp Hi relay		46, 47		×	×
Headlamp Lo relay		48, 50		×	×
Tail lamp relay		15, 16, 45, 49		×	×
Front wiper main relay		23		×	×
Front wiper HI/LO relay		24		×	×
A/C relay		41			×
Rear windows defogger relay	2	8		×	×
Cooling fan Lo relay 1	14	10		×	×
Cooling fan Hi relay 2		12		×	×

x: Applicable

OK or NG

OK >> Check the control unit that controls the inoperative relay. (system)

NG >> Replace the IPDM E/R. (malfunction of relay)

A

B

C

D

E

F

G

H

I

J

PG

L

M

4. CHECK RELAY TYPE

Which is the relay with error?

Front fog lamp relay, headlamp relay (Hi, Lo), tail lamp relay, front wiper relay (main, Hi/Lo), rear window defogger relay, A/C relay, starter motor relay, cooling fan relay (1, 2, 3)>>GO TO 5.

Ignition relay>> Go to [PG-35, "Inspection With CONSULT-II \(Self-Diagnosis\)"](#)

ECM relay>>Go to [EC-115, "POWER SUPPLY CIRCUIT FOR ECM"](#) (with EURO-OBD) or [EC-500, "POWER SUPPLY CIRCUIT FOR ECM"](#) (without EURO-OBD) in "EC engine control".

Throttle motor relay>>Go to [EC-284, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (with EURO-OBD) or [EC-599, "DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY"](#) (without EURO-OBD) in "EC engine control"

Fuel pump relay>>Go to [EC-391, "FUEL PUMP CIRCUIT"](#) (with EURO-OBD) or [EC-717, "FUEL PUMP CIRCUIT"](#) (without EURO-OBD) in "EC engine control"

5. CHECK INPUT SIGNAL

Check the control signal status of the relay on the IPDM E/R that receives from each control unit with the data monitor of CONSULT-II. Refer to [PG-27, "DATA MONITOR"](#) .

What is the data monitor result?

Other than OFF>>Check the control unit that controls the relay (system) not deactivated.

OFF >> Replace the IPDM E/R. (error of relay ON)

Removal and Installation of IPDM E/R

EKS0087Q



CAUTION:

Always replace with new* IPDM E/R when the IPDM E/R replacement is required.


*: New one means virgin control unit that has never been energized on-board.

REMOVAL

1. Remove battery. Refer to [SC-13, "Removal and Installation"](#) in SC section.
2. Pull out IPDM E/R cover A from IPDM cover B.



3. Disconnect harness connector from IPDM E/R.
4. Remove IPDM E/R from IPDM E/R cover A.



INSTALLATION

- Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J


PG
L
M

GROUND

PFP:00011

Ground Distribution
MAIN HARNESS

EKS0079A



A



Next page

MKWA1312E

GROUND

Preceding page

A



A

B

C

D

E

F

G

H

I

J

PG

L

M

CONNECTOR NUMBER	CONNECT TO
(M11)	Headlamp aiming switch (Terminal No. 2)
(M11)	Headlamp aiming switch (Terminal No. 4)
(M12)	Headlamp washer switch (Terminal No. 2) (With headlamp washer)
(M12)	Headlamp washer switch (Terminal No. 4) (With headlamp washer)
(M13)	Door mirror remote control switch (LHD models)
(M17)	Data link connector (Terminal No. 4) (LHD models)
(M17)	Data link connector (Terminal No. 5) (LHD models)
(M28)	Drive computer
(M32)	Combination switch (LHD models)
(M37)	Clutch interlock switch (With M/T and Intelligent Key system)
(M42)	Fan control amp. (With auto A/C)
(M45)	Thermo control amp. (With manual A/C)
(M48)	BCM (Body control module) (Terminal No. 2) (RHD models)
(M50)	BCM (Body control module) (Terminal No. 70) (RHD models)
(M51)	Intelligent Key unit (With intelligent key system)
(M58)	A/C control unit (Terminal No. 6) (Without auto A/C)
(M58)	A/C control unit (Terminal No. 7) (Without auto A/C)
(M58)	A/C control unit (Terminal No. 10) (Without auto A/C)
(M61)	Hazard switch (Terminal No. 1)
(M61)	Hazard switch (Terminal No. 4)
(M62)	Ashtray illumination
(M63)	A/C auto amp. (Terminal No. 12) (With auto A/C)
(M63)	A/C auto amp. (Terminal No. 14) (With auto A/C)

B

Next page

MKWA1313E

GROUND

Preceding page

B

CONNECTOR NUMBER	CONNECT TO
(M68)	A/T device (Terminal No. 4) (With A/T) • Illumination
(M68)	A/T device (Terminal No. 6) (With A/T) • Overdrive control switch
(M69)	Air bag diagnosis sensor unit
(M203)	Stop lamp switch (RHD models with A/T)
(D3)	Door mirror actuator (Driver side) (LHD models with door mirror defogger)
(D7)	Power window main switch (LHD models)
(D10)	Door request switch (Driver side) (LHD models with Intelligent Key system)
(D33)	Door mirror actuator (Passenger side) (RHD models with door mirror defogger)
(D37)	Front power window switch (Passenger side) (RHD models)
(D39)	Door request switch (Passenger side) (RHD models with Intelligent Key system)

Sub-harness



(M71) (M201)

(M6) (D1)



(M56) (D31)

MKWA1314E

GROUND




CONNECTOR NUMBER	CONNECT TO
M24	EPS control unit



CONNECTOR NUMBER	CONNECT TO
M27	Audio unit (Terminal No. 38) (With audio unit)
M27	Audio and NAVI control unit (Terminal No. 38) (With NAVI control unit)

GROUND

ENGINE ROOM HARNESS





◀ C

Next page

GROUND

Preceding page



CONNECTOR NUMBER	CONNECT TO
(E2)	Daytime light relay (With daytime light system)
(E3)	Cooling fan motor (With A/C)
(E4)	Cooling fan motor (Without A/C)
(E8)	Front turn signal lamp LH
(E11)	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 3)
(E16)	IPDM E/R (Intelligent power distribution module engine room) (Terminal No. 54)
(E20)	Headlamp aiming motor LH
(E24)	Side turn signal lamp LH
(E34)	Front fog lamp RH (With front fog lamp)
(E37)	Parking lamp RH
(E42)	Headlamp RH (Without daytime light system)
(E43)	Brake fluid level switch
(E109)	Stop lamp switch (LHD models with A/T)

Next page

A
B
C
D
E
F
G
H
I
J

PG



L

M



MKWA1317E

GROUND

Preceding page




CONNECTOR NUMBER	CONNECT TO
(E7)	Front fog lamp LH (With front fog lamp)
(E21)	Headlamp LH
(E22)	Parking lamp LH
(E27)	Shield wire (Crash zone sensor) (For circuit from terminal No. 1, 2)
(E30)	Horn
(E32)	Front turn signal lamp RH
(E33)	Headlamp washer motor (With headlamp washer)
(E35)	Side turn signal lamp RH
(E39)	Headlamp aiming motor RH
(E44)	Front wiper motor



CONNECTOR NUMBER	CONNECT TO
(E45)	ABS actuator and electric unit (Control unit) (Terminal No. 1)
(E45)	ABS actuator and electric unit (Control unit) (Terminal No. 4)


GROUND

ENGINE CONTROL HARNESS/QR ENGINE MODELS



Engine ground

CONNECTOR NUMBER	CONNECT TO
(F26)	Condenser
(F33)	Ignition coil No. 1 (With power transistor)
(F34)	Ignition coil No. 2 (With power transistor)
(F35)	Ignition coil No. 3 (With power transistor)
(F36)	Ignition coil No. 4 (With power transistor)




Body ground


CONNECTOR NUMBER	CONNECT TO
(F31)	Alternator (E)

GROUND

BODY HARNESS




CONNECTOR NUMBER	CONNECT TO
(B13)	Shield wire [RH side air bag (Satellite) sensor] (For circuit from terminal No. 1, 2)



CONNECTOR NUMBER	CONNECT TO
(B19)	Shield wire [LH side air bag (Satellite) sensor] (For circuit from terminal No. 1, 2)

GROUND



Body ground



CONNECTOR NUMBER	CONNECT TO
(B5)	Seat belt buckle switch RH
(B6)	Heated seat RH (With heated seat)
(B10)	Seat belt buckle switch LH
(B11)	Heated seat LH (With heated seat)
(B28)	Fuel level sensor unit and fuel pump • Fuel pump
(B36)	Rear combination lamp RH
(B37)	Rear combination lamp LH
(B38)	License plate lamp
(B56)	Heated seat switch RH (Terminal No. 4) (With heated seat)
(B56)	Heated seat switch RH (Terminal No. 6) (With heated seat)
(B57)	Heated seat switch LH (Terminal No. 4) (With heated seat)
(B57)	Heated seat switch LH (Terminal No. 6) (With heated seat)
(B58)	Door lock/unlock switch

Next page

A
B
C
D
E
F
G
H
I
J
PG
L
M


GROUND

Preceding page



CONNECTOR NUMBER	CONNECT TO
(B47)	High-mounted stop lamp



Body ground



Next page

GROUND

Preceding page



HARNESS

PFP:00011

Harness Layout

EKS0079B

HOW TO READ HARNESS LAYOUTS

The following Harness Layouts use a map style grid to help locate connectors on the drawings:


- Main Harness
- Engine Room Harness (Engine Compartment)
- Body Harness
- Body No.2 Harness

To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.




Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9	—	—		
• Ground terminal etc.	—			

SKIA0404E

HARNESS

OUTLINE/LHD MODELS




A
B
C
D
E
F
G
H
I
J

PG
L
M


HARNESS

OUTLINE/RHD MODELS



HARNESS

MAIN HARNESS/LHD MODELS



MKWA1336E

A
B
C
D
E
F
G
H
I
J
K
L
M
PG

HARNESS


B2 ★ M1	SMJ	To (E101)	D2 (M35)	GY/4	NATS antenna amp. (Without multi-remote)	G4 (M69)	Y/20	: Air bag diagnosis sensor unit
B3 M2	Y/4	To (E102)	D2 (M36)	-/4	NATS antenna amp. (With multi-remote) AMP			
A2 M3	B/2	To (E103)	D2 (M36)	-/4	NATS antenna amp. (With multi-remote) AMP			
A3 M4	W/2	To (E104) (With headlamp washer)	D2 (M37)	BR/2	Clutch interlock switch (With M/T and Intelligent Key system)			
A4 M5	W/12	To D2						
A5 M6	W/10	To D1	D2 (M38)	W/6	Ignition switch			
A5 M7	W/12	To B4	D2 (M39)	W/2	In-vehicle sensor (With auto A/C)			
B5 M8	W/10	To B3	D3 (M40)	W/4	Fan switch (Without auto A/C)			
F3 M9	W/24	To B2	E3 (M41)	G/6	Fan control amp. (With auto A/C)			
F3 M10	W/10	To B1	D3 (M42)	G/2	Fan control amp. (With auto A/C)			
B3 M11	W/4	Headlamp aiming switch	D4 (M43)	B/6	Intake door motor (With auto A/C)			
C3 M12	GY/8	Headlamp washer switch (With headlamp washer)	D4 (M44)	-/2	Intake sensor (With auto A/C)			
C3 M13	W/10	Door mirror remote control switch	E3 (M45)	W/3	Thermal control amplifier (Without auto A/C)			
C3 M14	GY/6	VDC off switch (With VDC)	E1 (M46)	B/2	Blower motor (Without auto A/C)			
B4 M15	W/5	Headlamp washer relay (With headlamp washer)	E1 (M47)	-/2	Blower motor (Without auto A/C)			
B4 ★ M16	-	Fuse block (J/B)	F1 (M48)	W/40	BCM (Body control module)			
C4 M17	W/16	Data link connector	E1 (M49)	W/24	BCM (Body control module)			
B2 M18	W/2	Sunload sensor (With auto A/C)	E1 (M50)	B/15	BCM (Body control module)			
B2 ★ M19	-	Body ground	F2 (M51)	W/40	Intelligent Key unit (With Intelligent Key system)			
B2 ★ M20	-	Body ground	E2 (M52)	W/5	Door lock relay (Without multi-remote)			
B2 M21	-	Body ground						
C2 ★ M22	W/40	Combination meter	F1 (M53)	Y/2	Front passenger air bag module			
C1 M23	W/6	EPS control unit	F1 (M54)	W/8	To (R1)			
C1 M24	W/1	EPS control unit	F2 (M55)	W/12	To (D32)			
C2 M25	B/1	EPS control unit	F2 (M56)	W/10	To (D31)			
E1 M26	-/20	Audio unit or NAVI control unit	F3 (M57)	W/1	Towbav kit			
E2 M27	B/16	Audio unit or NAVI control unit	E3 (M58)	-/15	Heater control panel (With manual A/C)			
E2 M28	W/12	Board computer (With board computer)	E3 (M59)	B/2	Power socket			
C3 M29	GY/8	Combination switch (Spiral cable) (Steering switch)	E3 (M60)	-	Body ground			
C3 M30	Y/6	Combination switch (Air bag)	F3 (M62)	W/4	Hazard switch			
C3 M31	W/4	Steering lock unit (Without multi-remote)	F3 (M63)	B/18	A/C auto amp. (With auto A/C)			
C2 M32	W/16	Combination switch	F2 (M64)	W/18	A/C auto amp. (With auto A/C)			
C3 M33	W/2	Key switch (With multi-remote)	E4 (M65)	B/6	Mode door motor (With auto A/C)			
D2 M34	GY/6	Key/push switch (Without multi-remote)	E4 (M66)	B/1	Air mix door motor (With auto A/C)			
			G5 (M67)	★ (M68)	Parking brake switch			
			F4 (M68)	W/6	A/T device (With A/T)			

MKWA1337E

★ : Be sure to connect and lock the connectors securely
after repair work.
Failure to do so may cause the ECM to have
diagnostic trouble codes.
Do not disconnect these connectors
except in the case of working according to
WORK FLOW of TROUBLE DIAGNOSES
in EC and AT sections.

HARNESS

MAIN HARNESS/RHD MODELS



MKWA1338E


HARNESS

		Sub-harness 1	
C1 ★	M1	To E101	Clutch interlock switch (With M/T and Intelligent Key system)
C1	M2	To E102	G2 ★ (M20)
D1	M3	To E103	W/10 : To M71
G4	M5	To D2	G3 ★ (M202) : Stop lamp switch (With M/T)
G4	M6	To D1	G3 ★ (M203) : Stop lamp switch (With A/T)
C3	M7	To B4	F4 ★ (M204) : Accelerator pedal position sensor
C3	M8	To B3	
G4	M9	To B2	
G5	M10	To B1	
G3	M11	W/4	Fan control amp. (With auto A/C)
G3	M13	W/10	Fan control amp. (With auto A/C)
G2	M14	GY/6	Intake door motor (With auto A/C)
F3 ★	M16	—	Intake sensor (With auto A/C)
F4	M17	W/16	Thermal control amplifier (Without auto A/C)
D1	M18	W/2	Blower motor (With auto A/C)
F2 ★	M19	—	Blower motor (Without auto A/C)
F2	M20	—	BCM (Body control module)
F2	M21	—	BCM (Body control module)
F5 ★	M22	W/40	BCM (Body control module)
F2	M23	W/6	Intelligent Key unit (With Intelligent Key system)
F2	M24	W/1	Door lock relay (Without multi-remote)
F1	M25	B/1	Front passenger air bag module
C2	M26	—/20	Intelligent Key unit
C2	M27	B/16	To D32
C2	M28	W/12	To D31
E4	M29	GY/8	To D31
E4	M30	Y/6	Heater control panel (With manual A/C)
E3	M31	W/4	Power socket
E4	M32	W/16	(Without multi-remote)
F5	M33	W/2	Body ground
G5	M34	GY/6	Hazard switch
E4	M35	GY/4	Ashtray illumination
F4	M36	—/4	A/C auto amp. (With auto A/C)
			A/C auto amp. (With auto A/C)
			Mode door motor (With auto A/C)
			Air mix door motor (With auto A/C)
			Parking brake switch
			A/T device (With A/T)
			Air bag diagnosis sensor unit
			Dougle unit
			To M20
			After market alarm unit (Option connector)

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

Harness

ENGINE ROOM HARNESS



MKWA1340E

HARNESS


B1	E1	-	Fuse and fusible link box	C3 ★ (E40)	-	Body ground
B1	E2	W/5	Daytime light relay	D3 (E41)	B/3	Headlamp RH (With daytime light system)
F3 ★ (E3)	B1/2		Cooling fan motor (With A/C)	D3 (E42)	B/3	Headlamp RH (Without daytime light system)
F3 ★ (E4)	-/2		Cooling fan motor (Without A/C)	C2, D1 (E43)	GY/2	Brake fluid level switch
F3 ★ (E5)	B/2		Resistor (With A/C)	D2 (E44)	GY/6	Front wiper motor
G3 ★ (E6)	GY/2		Dropping resistor (With A/T)	D3, F3 (E45)	B/26	ABS actuator and electric unit (Control unit) (With ABS)
G4 (E7)	B/2		Front fog lamp LH (With front fog lamp)	D2, E2 (E46)	-	Body ground (With ABS)
G3 (E8)	GY/2		Front turn signal lamp LH	E3, F3 (E47)	-/46	VDC/TCS/ABS control unit (With VDC)
G2 (E9)	B/1		After market alarm unit (Hood switch)	D2, E2 (E48)	-	Body ground (With VDC)
E5 (E10)	B/2		PDM E/R (Intelligent power distribution module engine room)	F2 ★ (E49)	B/40	ECM
E5 ★ (E11)	B/6		PDM E/R (Intelligent power distribution module engine room)	F2 ★ (E50)	SMJ	To (F1)
F5 ★ (E12)	W/6		PDM E/R (Intelligent power distribution module engine room)	B1 ★ (E51)	W/3	Horn relay
F5 ★ (E13)	BR/12		PDM E/R (Intelligent power distribution module engine room)	G4 (E52)	-	Outside temperature sensor
F5 ★ (E14)	W/16		PDM E/R (Intelligent power distribution module engine room)	E1 ★ (E101)	SMJ	To (M1)
F5 (E15)	BR/8		PDM E/R (Intelligent power distribution module engine room)	E1 (E102)	Y/4	To (M2)
G5 ★ (E16)	W/12		PDM E/R (Intelligent power distribution module engine room)	F1 (E103)	B/2	To (M3)
G5 ★ (E17)	W/8		PDM E/R (Intelligent power distribution module engine room)	E1 (E104)	W/2	To (M4) (LHD models with headlamp washer)
G2 (E18)	BR/2		Fusible link holder	F1 ★ (E105)	W/24	TCM
F2 (E19)	GY/2		Fusible link holder	F1 ★ (E106)	GY/24	TCM
F1 (E20)	B/3		Headlamp aiming motor LH	E1 ★ (E107)	B/6	Accelerator pedal position sensor (LHD models with M/T)
G2 (E21)	B/3		Headlamp LH	E1 ★ (E108)	B/2	Stop lamp switch (LHD models with M/T)
G1 (E22)	B/2		Parking lamp LH	E1 ★ (E109)	W/4	Stop lamp switch (LHD models with A/T)
G2 (E23)	B/2		Front wheel sensor LH			
F1 (E24)	W/2		Side turn signal lamp LH			
G1 ★ (E25)	-		Body ground			
F2 (E26)	-		Body ground			
E3 (E27)	Y/2		Crash zone sensor			
E4 (E28)	B/3		Refrigerant pressure sensor (With A/C)			
F4 (E29)	B/2		Ambient sensor (With A/C)			
G4 (E30)	B/1		Horn (-)			
F4 (E31)	B/1		Horn (+)			
D4 (E32)	GY/2		Front turn signal lamp RH			
E5 (E33)	-/2		Head lamp washer motor (With front fog lamp)			
E4 (E34)	B/2		Front fog lamp RH (With front fog lamp)			
B2 (E35)	-/2		Side turn signal lamp RH			
D5 (E36)	B/2		Washer motor			
D2 (E37)	B/2		Parking lamp RH			
C3 (E38)	B/2		Front wheel sensor RH			
D3 (E39)	B/3		Headlamp aiming motor RH			

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

MKWA1341E

Harness

ENGINE CONTROL HARNESS



★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS


E2★	F1	SMJ	:	To (E50)
F2	F2	B/81	:	ECM
F2	F3	-	:	Fusible link holder
F2	F4	-	:	Fusible link holder
E2	F6	-	:	Starter motor
D2	F7	-	:	Starter motor (For cold area)
D2	F8	-	:	Starter motor
E3	F9	B/1	:	Starter motor (For cold area)
F3★	F10	G/3	:	Park/neutral position switch (With M/T)
F2★	F11	BR/3	:	Revolution sensor (With A/T)
F4★	F12	B/10	:	Park/neutral position switch (With A/T)
G4★	F13	B/8	:	Terminal cord assembly (With A/T)
E2★	F14	B/3	:	Camshaft position sensor
E2	F15	-	:	Engine ground
D2★	F16	GY/4	:	Manifold absolute pressure sensor
E2	F17	L/2	:	EVAP canister purge volume control solenoid valve
C3★	F18	GY/2	:	Injector No. 1
D3★	F19	GY/2	:	Injector No. 2
D2★	F20	GY/2	:	Injector No. 3
E2★	F21	GY/2	:	Injector No. 4
D3★	F22	G/2	:	Intake valve timing control solenoid valve
E2★	F23	GY/2	:	Engine coolant temperature sensor
E4★	F24	G/4	:	Heated oxygen sensor 2
D3★	F25	GY/1	:	Oil pressure switch
C3★	F26	W/2	:	Condenser
D3★	F27	B/2	:	Knock sensor
D5	F28	B/1	:	Compressor (With A/C)
E4	F29	GY/2	:	Alternator
E4	F30	-	:	Alternator
E4	F31	-	:	Alternator (E)
D4	F32	-	:	Body ground
D4	F33	GY/3	:	Ignition coil No. 1
E3	F34	GY/3	:	Ignition coil No. 2
E3	F35	GY/3	:	Ignition coil No. 3
E3	F36	GY/3	:	Ignition coil No. 4
E3★	F37	G/4	:	Heated oxygen sensor 1
F3★	F38	G/3	:	Crankshaft position sensor
C2★	F39	B/6	:	Electric throttle control actuator

MKWA1343E

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS

BODY HARNESS






HARNESS

G2 (B1)	W/10	: To (M10)	D2 (B40)	: Luggage room lamp (+)
G2 (B2)	W/24	: To (M9)	D2 (B41)	: Luggage room lamp
D1 (B3)	W/10	: To (M8)	E1 (B42)	: RH side curtain air bag module
D2 (B4)	W/12	: To (M7)	C1 (B43)	: LH side curtain air bag module
E2 (B5)	W/2	: Seat belt buckle switch RH	E1 (B44)	– : Body ground
E2 (B6)	W/3	: Heated seat RH	D1 (B47)	: High-mounted stop lamp
E2 (B7)	BR/2	: Front RH side air bag module	F3 (B48)	: Front RH seat belt pre-tensioner (With 3 doors)
E2 (B8)	Y/12	: Air bag diagnosis sensor unit	C3 (B49)	: Front LH seat belt pre-tensioner (With 3 doors)
D2 (B9)	Y/12	: Air bag diagnosis sensor unit	D3 (B56)	: Heated seat switch RH
D2 (B10)	W/2	: Seat belt buckle switch LH	D3 (B57)	: Heated seat switch LH
C3 (B11)	W/3	: Heated seat LH	C3 (B58)	: Power window main switch
D3 (B12)	BR/2	: Front LH side air bag module		
E2 (B13)	Y/2	: RH side air bag (satellite) sensor		
F1 (B14)	W/6	: To (D81)		
F3 (B15)	B/2	: Front RH seat belt pre-tensioner (With 5 doors)		
E2 (B16)	W/3	: Front door switch RH		
F3 (B17)	–	: Body ground		
F3 (B18)	–	: Body ground		
C2 (B19)	Y/2	: LH side air bag (satellite) sensor		
C2 (B20)	W/6	: To (D81)		
C3 (B21)	B/2	: Front LH seat belt pre-tensioner (With 5 doors)		
C2 (B22)	W/3	: Front door switch LH		
C2 (B23)	–	: Body ground		
C2 (B24)	–	: Body ground		
D3 (B25)	GY/2	: Center console antenna		
D2 (B26)	W/6	: yaw rate/side G sensor		
D3 (B28)	GY/4	: Fuel level sensor unit and fuel pump		
D3 (B29)	BR/2	: Luggage room antenna		
F3 (B30)	W/1	: Rear door switch RH (With 5 doors)		
B2 (B31)	W/1	: Rear door switch RH (With 5 doors)		
E4 (B32)	BR/2	: Rear door speaker RH (With 3 doors)		
B3 (B33)	BR/2	: Rear door speaker LH (With 3 doors)		
E3 (B34)	B/2	: Rear wheel sensor RH		
B3 (B35)	B/2	: Rear wheel sensor LH		
D4 (B36)	B/6	: Rear combination lamp RH		
A2 (B37)	B/6	: Rear combination lamp LH		
C3 (B38)	B/2	: License lamp		
B4 (B39)	GY/2	: Back door antenna		

MKWA1346E

HARNESS


B50	B/1	: Rear window defogger (+)
B51	-	: Body ground
B52	W/2	: Back door opener switch
B53	W/3	: Rear wiper motor
B54	BR/2	: Back door request (With Intelligent Key system)
B55	W/4	: Back door release actuator
B201	B/1	: Rear window defogger (-)
B202	-	: Body ground



HARNESS

ROOM LAMP HARNESS


- (R1) W/8 : To W54
- (R2) W/3 : Interior room lamp
- (R3) B/3 : Rain sensor
- (R4) W/4 : Sunroof switch
- (R5) GY/10 : Sunroof motor assembly (With sunroof)



HARNESS

FRONT DOOR HARNESS LH SIDE/LHD MODELS

- (D1) W/10 : To **M6**
- (D2) W/12 : To **M5**
- (D3) GY/6 : Door mirror actuator LH
- (D4) BR/2 : Tweeter LH
- (D5) GY/6 : Front power window regulator LH
- (D6) W/2 : Front door speaker LH
- (D7) W/16 : Power window main switch
- (D8) BR/2 : Buzzer
- (D9) B/4 : Door lock actuator LH
- (D10) GY/2 : Door request switch LH
- (D11) W/2 : Door antenna LH




MKWA1348E

PG

HARNESS

FRONT DOOR HARNESS LH SIDE/RHD MODELS


- (D31) W/10 : To **M56**
- (D32) W/12 : To **M55**
- (D33) GY/6 : Door mirror actuator LH
- (D34) BR/2 : Tweeter LH
- (D35) GY/2 : Front power window regulator LH
- (D36) W/2 : Front door speaker LH
- (D37) W/8 : Front power window switch LH
- (D38) B/4 : Door lock actuator LH
- (D40) W/2 : Door antenna LH



HARNESS

FRONT DOOR HARNESS RH SIDE/LHD MODELS

- [D31] W/10 : To **M56**
- [D32] W/12 : To **M55**
- [D33] GY/8 : Door mirror actuator RH
- [D34] BR/2 : Tweeter RH
- [D35] GY/2 : Front power window regulator RH
- [D36] W/2 : Front door speaker RH
- [D37] W/8 : Front power window switch RH
- [D38] B/4 : Door lock actuator RH
- [D39] GY/2 : Door request switch RH
- [D40] W/2 : Door antenna RH




MKWA1350E

PG

HARNESS

FRONT DOOR HARNESS RH SIDE/RHD MODELS

- (D1) W/10 : To (M6)
- (D2) W/12 : To (M5)
- (D3) GY/6 : Door mirror actuator RH
- (D4) BR/2 : Tweeter RH
- (D5) GY/2 : Front power window regulator RH
- (D6) W/2 : Front door speaker RH
- (D7) W/16 : Power window main switch
- (D8) BR/2 : Buzzer
- (D9) B/4 : Door lock actuator RH
- (D10) GY/2 : Door request switch RH
- (D11) W/2 : Door antenna RH



MKWA1351E


HARNESS

REAR DOOR HARNESS LH

D61 W/6 : To B20

D62 W/2 : Rear door speaker LH (With 6 speakers)

D63 B/4 : Rear door lock actuator LH



A

B

C

D

E

F

G

H

I

J

MKWA1352E

PG


L

M

HARNESS

REAR DOOR HARNESS RH

- (D81) W/6 : To **B14**
- (D82) W/2 : Rear door speaker RH
- (D83) B/4 : Rear door lock actuator RH



MKWA1353E

HARNESS

Wiring Diagram Codes (Cell Codes)

EKS0079C

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
1STSIG	AT	A/T 1ST Signal
2NDSIG	AT	A/T 2ND Signal
3RDSIG	AT	A/T 3RD Signal
4THSIG	AT	A/T 4TH Signal
A/C	ATC	Auto Air Conditioner
A/C	MTC	Manual Air Conditioner
A/WIP	WW	Front Wiper and Washer System (With Rain Sensor)
ABS	BRC	Anti-lock Brake System
AP/SEN	EC	Manifold Absolute Pressure Sensor
APPS1	EC	Accelerator pedal position Sensor 1
APPS2	EC	Accelerator pedal position Sensor 2
APPS3	EC	Accelerator pedal position Sensor
AUDIO	AV	Audio
BA/FTS	AT	A/T Fluid Temperature Sensor and TCM Power Supply
BACK/L	LT	Back-up Lamp
BRK/SW	EC	Brake Switch
CAN	AT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
CIGAR	WW	Cigarette Lighter
COMBSW	LT	Combination Switch
COOL/F	EC	Cooling Fan Control
D/COMP	DI	Drive Computer
D/LOCK	BL	Power Door Lock
DEF	GW	Rear Window Defogger
DTRL	LT	Headlamp - With Daytime Light System
ECM/PW	EC	ECM Power Supply
ECTS	EC	Engine Coolant Temperature Sensor
ENGSS	AT	Engine Speed Signal
EPS	STC	Electric Power Steering System
ETC1	EC	Electrical Throttle Control Function
ETC2	EC	Electrical Throttle Control Motor Relay
ETC3	EC	Electrical Throttle Control Motor
F/FOG	LT	Front Fog Lamp
F/FUMP	EC	Fuel Pump
FTS	AT	A/T Fluid Temperature Sensor
FUEL	EC	Fuel Injection System Function
H/AIM	LT	Headlamp Aiming Control System
H/LAMP	LT	Headlamp

HARNESS

Code	Section	Wiring Diagram Name
H/SEAT	SE	Heated Seat
HEATER	MTC	Heater
HLC	WW	Headlamp Washer
HO2S1	EC	Heated Oxygen Sensor 1
HO2S1H	EC	Heated Oxygen Sensor 1 Heater
HO2S2	EC	Heated Oxygen Sensor 2
HO2S2H	EC	Heated Oxygen Sensor 2 Heater
HORN	WW	Horn
I/KEY	BL	Intelligent Key System
IATS	EC	Intake Air Temperature sensor
IGNSYS	EC	Ignition Signal
ILL	LT	Illumination
INJECT	EC	Injector
INT/L	LT	Interior and Luggage Room Lamps
IVC	EC	Intake Valve Timing Control Solenoid Valve
KS	EC	Knock Sensor
LPSV	AT	Line Pressure Solenoid Valve
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
METER	DI	Combination Meters
MIL/DL	EC	Malfunction Indicator, Data Link Connector for CONSULT-II
MIRROR	GW	Door Mirror
MULTI	BL	Multi-remote Control System
NATS	BL	NATS (Nissan Anti-Theft System)
NAVI	AV	Audio and Navigation System
NONDTC	AT	NON-detective Items
OVRCVS	AT	Overrun Clutch Solenoid Valve
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHASE	EC	Camshaft Position Sensor (PHASE)
PNP/SW	AT	Park/Neutral Position (PNP) Switch
PNP/SW	EC	Park/Neutral Position (PNP) Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	PG	Power Supply Routing Circuit
PRWIRE	BL	After Market Alarm - Prewire
R/FOG	LT	Rear Fog Lamp
RP/SEN	EC	Refrigerant Pressure Sensor
S/LOCK	BL	Power Door Lock-Super Lock
SHIFT	AT	A/T Shift Lock System
SROOF	RF	Sunroof
SRS	SRS	Supplemental Restraint System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STOP/L	LT	Stop Lamp

HARNESS

Code	Section	Wiring Diagram Name
SW/ILL	GW	Power Window Illumination
TAIL/L	LT	Parking, License and Tail Lamps
TCV	AT	Torque Converter Clutch Solenoid Valve
TPS	AT	Throttle Position Sensor
TPS1	EC	Electric Throttle Control Actuator (Throttle Position Sensor 1)
TPS2	EC	Electric Throttle Control Actuator (Throttle Position Sensor 2)
TPS3	EC	Electric Throttle Control Actuator (Throttle Position Sensor 3)
TURN	LT	Turn Signal and Hazard Warning Lamps
VSSAT	AT	Vehicle Speed Sensor A/T (Revolution Senor)
VSSMTR	AT	Vehicle Speed Sensor MTR
WARN	DI	Warning Lamps
WINDOW	GW	Power Window
WIP/R	WW	Rear Wiper and Washer System
WIPER	WW	Front Wiper and Washer System

A

B

C

D

E

F

G

H

I

J

PG

L

M

ELECTRICAL UNITS LOCATION

ELECTRICAL UNITS LOCATION

PFP:25230

Electrical Units Location ENGINE COMPARTMENT

EKS0079D

ABS actuator and electric unit
(LHD models with ABS system)
VDC/TCS/ABS control unit
(LHD models with VDC system)

ABS actuator and electric unit
(RHD models with ABS system)
VDC/TCS/ABS control unit
(RHD models with VDC system)


ECM

Fuse and fusible link box

IPDM E/R (Intelligent power
distribution module engine room)


IPDM E/R (Intelligent power
distribution module engine room)

View with headlamp RH removed



Fuse and fusible link box


Horn relay Daytime light relay



MKWA1356E

ELECTRICAL UNITS LOCATION

PASSENGER COMPARTMENT/LHD MODELS




A
B
C
D
E
F
G
H
I
J

PG

L

M

ELECTRICAL UNITS LOCATION



MKWA1358E

HARNESS CONNECTOR

HARNESS CONNECTOR

PFP:00011

Description

EKS0079E

HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR


HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

- **Do not pull the harness or wires when disconnecting the connector.**
- **Be careful not to damage the connector support bracket when disconnecting the connector.**

[Example]



ELECTRICAL UNITS

ELECTRICAL UNITS

Terminal Arrangement

PFP:00011

EKS0079F

A

B

C

D

E

F

G

H

I

J

PG

L

M

ECM

E49

116	115	114	89	88	87	86	85	84	83	82
			97	96	95	94	93	92	91	90
			118	117						
			105	104	103	102	101	100	99	98
121	120	119	113	112	111	110	109	108	107	106

(Black)

F2

63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	2	1
44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62		
25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43		3
6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24		5

(Black)



TCM (TRANSMISSION CONTROL MODULE)

E105

1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20	21						
			22	23	24			

(White)

E106

25	26	27	28	29	30	31	32	33
34	35	36	37	38	39	40	41	42
43	44	45						
			46	47	48			

(Gray)



ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

E45

26	25	24	23	22	21	20	19	18	17	16
15	14	13	12	11	10	9	8	7	6	5

(Black)



BCM (BODY CONTROL MODULE)

M48

20	19	18	17	16	15	14	13	12	11	10	9
40	39	38	37	36	35	34	33	32	31	30	29

(White)

M49

52	51	50	49	48	47	46	45	44	43	42	41
64	63	62	61	60	59	58	57	56	55	54	53

(White)

M50

65	66	67	68	69	70	71	72	73
74	75	76	77	78	79			

(Black)

A/C AUTO AMP.

M63

		8		12	13		1
2	1	11	10	17	16	15	9

(Black)

M64

19	31	34	30	32	26	29	25	27
20			6	18	3	4	7	5

(White)



MKWA1364E


SMJ (SUPER MULTIPLE JUNCTION)

SMJ (SUPER MULTIPLE JUNCTION)

PFP:B4341

Terminal Arrangement

EKS007XZ



MKWA1361E

STANDARDIZED RELAY

STANDARDIZED RELAY


PFP:00011

Description

EKS0079G

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H


TYPE OF STANDARDIZED RELAYS

1M 1 Make

2M 2 Make















1T 1 Transfer

1M-1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W

FUSE BLOCK - JUNCTION BOX (J/B)

FUSE BLOCK - JUNCTION BOX (J/B)

PFP:24350

Terminal Arrangement

EKS0079H

A

B

C

D

E

F

G

H


I

J

PG

L

M



MKWA1362E



FUSE AND FUSIBLE LINK BOX

FUSE AND FUSIBLE LINK BOX

PFP:24381

Terminal Arrangement

EKS0079I



MKWA1363E