

SECTION **BL**

BODY, LOCK & SECURITY SYSTEM

CONTENTS

PRECAUTIONS	5	CAN Communication	18	F
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	5	SYSTEM DESCRIPTION	18	
Maintenance Information	5	CAN Communication Unit	18	G
RHD MODELS	5	TYPE 1/TYPE 2	19	
LHD MODELS	5	TYPE 3/TYPE 4	22	
Precautions	5	TYPE 5/TYPE 6	24	
CLIP AND FASTENER	6	TYPE 7/TYPE 8	27	H
List of Table	6	TYPE 9/TYPE 10	29	
HOOD	7	Schematic—D/LOCK—(Without Intelligent Key System)	32	BL
Fitting Adjustment	7	Wiring Diagram—D/LOCK—(Without Intelligent Key System)	33	
FRONT END HEIGHT ADJUSTMENT AND LATERAL/LONGITUDINAL CLEARANCE ADJUSTMENT	7	Schematic—D/LOCK—(With Intelligent Key System)	38	J
SURFACE MISMATCH ADJUSTMENT	7	Wiring Diagram—D/LOCK—(With Intelligent Key System)	39	
Removal and Installation	8	Terminal and Reference Value for BCM	44	K
REMOVAL	8	CONSULT-II Inspection Procedure	45	
INSTALLATION	9	CONSULT-II Application Items	46	L
Removal and Installation of Hood Lock Control	9	WORK SUPPORT	46	
REMOVAL	9	DATA MONITOR	46	
INSTALLATION	10	ACTIVE TEST	46	
Hood Lock Control Inspection	11	TROUBLE DIAGNOSES CHART BY SYMP-TOM/WITHOUT INTELLIGENT KEY SYSTEM	47	M
RADIATOR CORE SUPPORT	12	TROUBLE DIAGNOSES CHART BY SYMP-TOM/WITH INTELLIGENT KEY SYSTEM	48	
Removal and Installation	12	Check Power Supply and Ground Circuit of BCM	49	
REMOVAL	12	Check Door Lock / Unlock Switch	50	
INSTALLATION	13	Check Key Switch /Without Intelligent Key System	51	
FRONT FENDER	14	Check Key Switch/With Intelligent Key System	52	
Removal and Installation	14	Check Door Lock Actuator Circuit	53	
REMOVAL	14	Check Door Lock Actuator	54	
INSTALLATION	14	DRIVER SIDE	54	
POWER DOOR LOCK SYSTEM	15	PASSENGER SIDE	55	
Component Parts and Harness Connector Location	15	REAR LH SIDE	56	
System Description	16	REAR RH SIDE	57	
OPERATION	16	Check Door Switch	58	
DOOR LOCK AND UNLOCK SWITCH OPERATION	16	DRIVER SIDE	58	
KEY REMINDER SYSTEM	17	PASSENGER SIDE	60	
UNLOCK LINK FUNCTION	17	REAR LH SIDE	62	
BACK DOOR OPENER OPERATION	17			

REAR RH SIDE	64	MULTI-REMOTE CONTROL SYSTEM	131
Check External Back Door Release Switch	66	Component Parts and Harness Connector Location	131
Check Back Door Release Actuator	68	System Description	132
Check Door Lock/Unlock Switch Indicator	69	INPUTS	132
Check Door Lock/Unlock Relay Circuit	69	OPERATE	132
POWER DOOR LOCK — SUPER LOCK —	70	OPERATED PROCEDURE	132
Component Parts and Harness Connector Location..	70	Schematic	134
System Description	71	Wiring Diagram — MULTI —	135
OUTLINE	71	Terminal and Reference Value for BCM	139
OPERATION	71	CONSULT- II Inspection Procedure	140
CAN Communication	72	CONSULT- II Application Items	141
SYSTEM DESCRIPTION	72	DATA MONITOR	141
CAN Communication Unit	72	Work Flow	141
TYPE 1/TYPE 2	73	Trouble Diagnosis Chart by Symptom	142
TYPE 3/TYPE 4	76	Remote controller Check	143
TYPE 5/TYPE 6	78	Door Switch Check	143
TYPE 7/TYPE 8	81	DOOR SWITCH DRIVER SIDE	143
TYPE 9/TYPE 10	83	DOOR SWITCH PASSENGER SIDE	144
Schematic—S/LOCK—(Without Intelligent Key Sys- tem)	86	DOOR SWITCH REAR LH	145
Wiring Diagram — S/LOCK — (Without Intelligent Key System)	87	DOOR SWITCH REAR RH	146
Schematic — S/LOCK — (With Intelligent Key Sys- tem)	93	BACK DOOR SWITCH	147
Wiring Diagram—S/LOCK—(With Intelligent Key System)	94	Key Switch Check	148
Terminal and Reference Value for Smart Entrance Control Unit	100	Hazard Reminder Check	150
CONSULT- II Inspection Procedure	101	Remote Controller Battery Replacement	151
CONSULT- II Application Items	102	INTELLIGENT KEY SYSTEM	152
WORK SUPPORT	102	Component Parts and Harness Connector Location	152
DATA MONITOR	102	System Description	153
WORK SUPPORT	102	DOOR LOCK FUNCTION	153
Trouble Diagnoses	103	REMOTE CONTROL ENTRY FUNCTIONS	154
PRELIMINARY CHECK	103	ENGINE STARTUP FUNCTION	155
SYMPTOM CHART	104	WARNING AND ALARM FUNCTION	156
Power Supply and Ground Circuit Check	105	CHANGE SETTINGS FUNCTION	158
Door Lock / Unlock Switch Check	106	INTELLIGENT KEY REGISTRATION	158
Check Key Switch /Without Intelligent Key System	107	STEERING LOCK UNIT REGISTRATION	158
Check Key Switch/With Intelligent Key System ...	108	CAN Communication	159
Power Door Lock / Unlock Output Signal Check..	109	SYSTEM DESCRIPTION	159
Super Lock Output Signal Check.	110	CAN Communication Unit	159
Door Lock Actuator Check	111	TYPE 1	160
DRIVER SIDE	111	TYPE 3	162
PASSENGER SIDE	112	TYPE 5	164
REAR LH SIDE	113	TYPE 7	167
REAR RH SIDE	114	TYPE 9	169
Super Lock Actuator Check	115	Schematic —I/KEY—	171
DRIVER SIDE	115	Wiring Diagram — I/KEY—	172
PASSENGER SIDE	116	Terminals and Reference Value for INTELLIGENT KEY UNIT	180
REAR LH SIDE	117	Terminals and Reference Value for Steering Lock unit	182
REAR RH SIDE	118	Terminal and Reference Value for BCM	182
Door Switch Check	119	Diagnosis Procedure	184
DRIVER SIDE	119	WORK FLOW	184
PASSENGER SIDE	121	CONSULT-II Function (INTELLIGENT KEY)	185
REAR LH SIDE	123	CONSULT-II Inspection Procedure	185
REAR RH SIDE	125	BASIC OPERATION	185
External Back Door Release Switch Check	127	CONSULT-II Application Items	186
Back Door Release Actuator Check	129	SELF-DIAGNOSTIC RESULTS	186
		DATA MONITOR	186
		ACTIVE TEST	186
		WORK SUPPORT	187

List of Operation Related Parts	187	
Trouble Diagnosis Symptom Chart	188	
ALL FUNCTIONS OF THE INTELLIGENT KEY		A
ARE NOT OPERATING	188	
REMOTE CONTROL ENTRY FUNCTION MAL-		B
FUNCTION	188	
DOOR LOCK FUNCTION MALFUNCTION	188	C
ENGINE START FUNCTION MALFUNCTION	189	
WARNING CHIME FUNCTION MALFUNCTION	189	
Check CAN Communication System	191	D
Check Intelligent Key Unit Power Supply and		
Ground Circuit	191	
Check Key Switch	191	
Check Ignition Knob Switch	193	
Check Door Request Switch	194	
Check Intelligent Key Warning Buzzer	196	
Check Outside Antenna	197	
Check Inside Key Antenna	198	
Check Steering Lock Unit	199	
Check Stop Lamp Switch	201	
Removal and Installation of Intelligent key unit	202	
REMOVAL	202	
INSTALLATION	202	
Intelligent Key Inspection	202	
INTELLIGENT KEY DISASSEMBLY AND		
ASSEMBLY	202	
REMOTE CONTROLLER BATTERY INSPEC-		
TION	203	
DOOR	204	
Fitting Adjustment (5-Door Vehicles)	204	
FRONT DOOR	204	
REAR DOOR	204	
STRIKER ADJUSTMENT	204	
Fitting Adjustment (3-Door Vehicles)	205	
FRONT DOOR	205	
STRIKER ADJUSTMENT	205	
Removal and Installation	205	
FRONT DOOR	205	
REAR DOOR	206	
Door Weatherstrip	207	
5 DOORS	207	
3 DOORS	207	
FRONT DOOR LOCK	209	
Component Parts Location	209	
Removal and Installation	209	
REMOVAL	209	
Disassembly and Assembly	212	
DOOR KEY CYLINDER ASSEMBLY	212	
OUTSIDE HANDLE	212	
REAR DOOR LOCK	213	
Component Parts Location	213	
Removal and Installation	213	
REMOVAL	213	
BACK DOOR	216	
Fitting Adjustment	216	
VERTICAL/LATERAL CLEARANCE(SURFACE		
DIFFERENCE) ADJUSTMENT	216	
Back Door Assembly	216	
REMOVAL	216	
INSPECTION	217	
Back Door Striker	217	
REMOVAL	217	
INSTALLATION	217	
Back Door Stay Assembly	218	
REMOVAL	218	
INSTALLATION	218	
Removal and Installation of Back Door Weatherstrip	219	
REMOVAL	219	
INSTALLATION	219	
BACK DOOR LOCK	220	
Removal and Installation	220	
BACK DOOR LOCK ASSEMBLY	220	
BACK DOOR HANDLE ASSEMBLY	220	
FUEL FILLER LID OPENER	221	
Component Parts Location	221	
THEFT WARNING SYSTEM	222	
Wiring Diagram — THEFT —/PRWIRE	222	
NATS(NISSAN ANTI-THEFT SYSTEM)	223	
Component Parts and Harness Connector Location	223	
System Description	223	
DESCRIPTION	223	
SECURITY INDICATOR	224	
System Composition	225	
ECM Re-communicating Function	225	
Wiring Diagram —NATS—	226	
WITHOUT INTELLIGENT KEY SYSTEM	226	
WITH INTELLIGENT KEY SYSTEM	227	
Terminals and Reference Value for Steering Lock		
Unit/with Intelligent Key System	229	
Terminals and Reference Value for Intelligent Key		
Unit/with Intelligent Key System	229	
Terminals and Reference Value for BCM/without		
Intelligent Key System	230	
CONSULT-II	231	
CONSULT-II INSPECTION PROCEDURE	231	
CONSULT-II DIAGNOSTIC TEST MODE FUNC-		
TION	231	
NATS IMMU FUNCTION CHECK RESULT ITEM		
CHART	232	
Diagnosis Procedure	233	
WORK FLOW	233	
Trouble Diagnosis Symptom Chart	234	
MODELS WITHOUT INTELLIGENT KEY SYS-		
TEM	234	
MODELS WITH INTELLIGENT KEY SYSTEM	235	
Security Indicator Inspection	235	
Diagnostic Procedure 1	236	
Diagnostic Procedure 2	236	
MODELS WITHOUT INTELLIGENT KEY SYS-		
TEM	236	
MODELS WITH INTELLIGENT KEY SYSTEM	238	
Diagnostic Procedure 3	240	
Diagnostic Procedure 4	240	
Diagnostic Procedure 5	241	
Diagnostic Procedure 6	241	

Diagnostic Procedure 7	243
Removal and Installation NATS Antenna Amp. ...	244
REMOVAL	244
INSTALLATION	244

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EIS004QW

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Maintenance Information

EIS004QX

If any of following part is replaced, always replace with new* one.

If it's not (or fail to do so), the electrical system may not be operated properly.

*: New one means a virgin control unit that has never been energized on-board.

RHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM
- IPDM E/R
- Combination meter
- EPS control unit

LHD MODELS

- BCM (Models without Intelligent Key system)
- Intelligent Key unit (Models with Intelligent Key system)
- ECM

Precautions

EIS004LF

- After installing removed lids or doors, be sure to adjust hinges and mount points so that lids or doors can open and close properly.
- Confirm parts for proper lubrication, damage or wear. Lubricate, repair or replace as necessary.

A

B

C

D

E

F

G

H

BL

J

K

L

M






CLIP AND FASTENER

CLIP AND FASTENER

PFP:76906

List of Table

EIS004LI


Symbol No.	Shape	Removal and installation
C103		 PIIA1350J
CE103		 PIIA1354J
C205		<p>Removal:</p> <p>Flat-bladed screwdriver</p> <p>Clip</p> <p>Finisher</p> MIIIB0153E

HOOD

PFP:F5100

Fitting Adjustment

EIS004LJ



FRONT END HEIGHT ADJUSTMENT AND LATERAL/LONGITUDINAL CLEARANCE ADJUSTMENT


1. Remove hood lock. Rotate bumper rubber to adjust height until hood becomes 1 to 1.5 mm lower than the fender.
2. Position hood lock and engage striker. Check hood lock and striker for looseness. Tighten lock bolts to the specified torque.

CAUTION:

Adjust the clearance between hood and other parts so that the dimensional difference left and right is as follows.

Hood (B) - Headlamp (B) : 1.5 mm or less

Hood (C) - Headlamp (C) : 1.0 mm or less



SURFACE MISMATCH ADJUSTMENT

1. Release hood lock, and adjust surface level difference of hood, fender, and headlamp according to the fitting standard dimension, using RH and LH bumper rubbers.

Hood (B) - Headlamp (B) : 1.0 mm


Hood (C) - Headlamp (C) : 0.2 mm

2. Install hood lock, and move hood lock laterally until the centers of striker and lock become vertical when viewed from the front.
3. Make sure the secondary latch is securely engaged with the secondary striker from either the dead weight of the hood (free-fall from approx. 200 mm height), or by applying light pressure (approx. 3 kg).

CAUTION:

Do not drop hood from a height of 300 mm or more.


4. Move hood lock up and down until striker smoothly engages the lock when the hood is closed.
5. After adjustment, tighten lock bolts to the specified torque.



Removal and Installation

EIS004LK

SEC. 650




MIIIB0104E

- 1. Hood hinge
- 2. Hood stay
- 3. Radiator core seal rubber
- 4. Hood assembly
- 5. Hood lock
- 6. Hood stay holder

REMOVAL

Hood Assembly


1. Disconnect washer hose at the connecting point.
2. Remove hinge nuts on hood and remove hood assembly.



MIIIB0105E

Hood Hinge

1. Remove hood assembly.
2. Remove front fender. Refer to [BL-14, "Removal and Installation"](#).
3. Remove bolts and then remove hood hinge.




MIIIB0106E

INSTALLATION


- Perform installation in the reverse order of removal while being careful of the following items while performing the work.
- Apply Anti-Corrosion Wax M-97 Super or comparable product to the hood hinge, hood ledge, and hood assembly.
- After installing, perform hood fitting adjustment. Refer to [BL-7, "Fitting Adjustment"](#) .

Removal and Installation of Hood Lock Control


EIS004LL

**REMOVAL****Hood Lock**

1. Remove front grille (LH/RH). Refer to [EI-8, "Removal and Installation"](#) .
2. Remove hood lock bolts.
3. Remove hood lock cable from hood lock.

**Hood Lock Mounting Reinforcement**

1. Remove front bumper. Refer to [EI-4, "Removal and Installation"](#) .
2. Remove bolts, and then remove hood lock mounting reinforcement.




HOOD

Hood Lock Cable

1. Remove front grille (LH/RH). Refer to [EI-8, "Removal and Installation"](#) .
2. Remove fender protector (RH). Refer to [EI-11, "Removal and Installation"](#) .
3. Remove hood lock, and remove hood lock cable from hood lock.
4. Remove radiator core upper support and hood ledge clips, and then remove hood lock cable.
5. Remove hood opener on bottom right of instrument panel, and then remove hood lock cable.
6. Remove grommet on lower dashboard, and pull out hood lock cable from passenger room side.

CAUTION:

While pulling the cable, be careful not to damage (peel) hood opener cable outer surface on edges of body through hole.



INSTALLATION

- Perform installation in the reverse order of removal while being careful of the following items while performing the work.
- After installing, perform hood fitting adjustment. Refer to [BL-7, "Fitting Adjustment"](#) .


Hood Lock Mounting Reinforcement

- When installing hood lock mounting reinforcement, loosen hood bolts, and then tighten bolts in the order shown in the figure.

Bolt No. 1 to 5.


Tightening torque (N·m, (kg-m))

: 20.6 - 26.5 (2.1 - 2.7)




Hood Lock Cable

1. Pass hood lock cable through the opening while keeping the winding radius 100 mm or larger.
2. After confirming grommet is properly positioned, push it securely into the hole.
3. Apply sealant (POS seal) to area on the grommet indicated with the * mark.



HOOD

4. Install cable securely to lock.
5. After installing, check hood lock adjustment and hood opener operation.




EIS004LM

Hood Lock Control Inspection


CAUTION:

If hood lock cable is bent or deformed, replace it.

1. Confirm hood lock secondary latch securely engages secondary striker by releasing it from a height of approximately 200 mm.
2. While operating the hood opener carefully, make sure the front end of the hood is lifted by approximately 20 mm. Also, make sure the hood opener returns to the original position.



3. Inspect hood lock grease, and if insufficient, apply grease to the area shown in the figure.



A
B
C
D
E
F
G
H

BL
J
K
L

M

RADIATOR CORE SUPPORT



RADIATOR CORE SUPPORT

PFP:62500

Removal and Installation

EIS004LN

SEC. 625




MIIB0113E

REMOVAL

Radiator Core Upper Support

1. Remove headlamp (LH/RH). Refer to [LT-41, "Removal and Installation"](#) .
2. Remove hood lock assembly and hood lock mounting reinforcement. Refer to [BL-9, "Removal and Installation of Hood Lock Control"](#) .
3. Remove hood lock cable and air duct installation clips at top of air guide (RH).
4. Remove washer tank cap, and then pull washer tank inlet downward to pull it out.
5. Remove bolts, and then remove radiator core upper support.



MIIB0114E


Radiator Core Lower Support

1. Remove front grille (LH/RH). Refer to [EI-8, "Removal and Installation"](#) .
2. Remove installation clips on top of air guide (RH).
3. Remove front bumper lower clip. Refer to [EI-4, "Removal and Installation"](#) .
4. Remove screws and clips and separate bumper fascia from fender protector left/right.
5. Tie cord to all radiator core upper supports of the radiator and condenser.

NOTE:

To prevent the compressor and radiator from being dropped when the radiator core lower support is removed.


6. Remove bolts, and lower radiator core lower supports.



MIIB0115E

RADIATOR CORE SUPPORT

7. Remove air guide (RH) bottom clips, and remove radiator core lower supports from passenger room.



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
BL
J
K
L
M


FRONT FENDER

FRONT FENDER

PFP:63100

Removal and Installation

EIS004LO



REMOVAL

1. Remove side turn signal lamp. Refer to [LT-150, "Removal and Installation"](#) .
2. Remove front bumper. Refer to [EI-4, "Removal and Installation"](#) .
3. Remove headlamps. Refer to [LT-41, "Removal and Installation"](#) .
4. Remove fender protector front fender side clips (2) and screws (3). Refer to [EI-11, "Removal and Installation"](#) .
5. Remove bolts and then front fender.

INSTALLATION

Install in the reverse order of removal.

POWER DOOR LOCK SYSTEM

POWER DOOR LOCK SYSTEM

Component Parts and Harness Connector Location


SMA for VIN

>SJN**AK12U1309269

PFP:24814

EIS004X9

A
B
C
D
E
F
G
H
BL
J
K
L
M



POWER DOOR LOCK SYSTEM

System Description OPERATION

SMA for VIN
>SJN**AK12U1309269

EIS004X8

Power is supplied at all times

- to BCM terminals 74 and 79
- through 40A fusible link (letter J, located in the fusible link box).
- to key switch terminal 1 (Without Intelligent Key system)
- through 10A fuse [No. 6, located in the fuse block (J/B)] (Without Intelligent Key system)
- to key switch and ignition knob switch terminal 3 (With Intelligent Key system)
- through 10A fuse [No. 17, located in the fuse block (J/B)] (With Intelligent Key system).

When the key switch is ON (Ignition key is inserted in ignition key cylinder), power is supplied

- to BCM terminal 3.

- through key switch terminal 2

When the ignition switch is ON or START, power is supplied

- to BCM terminal 24
- through 10A fuse [No. 4, located in the fuse block (J/B)].

Ground is supplied

- to BCM terminals 2 and 70

- through body ground M19 and M20.

When the front door switch LH (LHD Models) or RH (RHD Models) is ON (door is open), ground supplied

- to BCM terminal 29
- through front door switch LH (LHD Models) or RH (RHD Models) terminal 1
- through front door switch LH (LHD Models) or RH (RHD Models) case ground.

When the front door switch RH (LHD Models) or LH (RHD Models) is ON (door is open), ground supplied

- to BCM terminal 30
- through front door switch RH (LHD Models) or LH (RHD Models) terminal 1
- through front door switch RH (LHD Models) or LH (RHD Models) case ground.

When the rear door switch LH is ON (door is open), ground is supplied

- to BCM terminal 59 (5 door models)
- through rear door switch LH terminal 1
- through rear door switch LH case ground.

When the rear door switch RH is ON (door is open), ground is supplied

- to BCM terminal 60 (5 door models)
- through rear door switch RH terminal 1
- through rear door switch RH case ground.

When the back door switch is ON (back door is open), ground is supplied

- to BCM terminal 10
- through back door switch terminals 1 and 2
- through body grounds B17, B23, B44 and B51.

DOOR LOCK AND UNLOCK SWITCH OPERATION

When door lock/unlock switch is in LOCK position, ground is supplied

- through body grounds B23,B17,B44 and B51
- through door lock/unlock switch terminal 4 and 6
- to BCM (Body Control Module) terminal 6.

With power and ground supplied, doors are locked.

When door lock/unlock switch is in UNLOCK position, ground is supplied

- through body grounds B23,B17,B44 and B51
- through door lock/unlock switch terminal 4 and 5
- to BCM (Body Control Module) terminal 25

With power and ground supplied, all doors are unlocked.

POWER DOOR LOCK SYSTEM

Lock/unlock switch indicated by LED when key in switch is on or on with timer.

KEY REMINDER SYSTEM

- If the ignition key is in the ignition key cylinder and driver door is open, setting door lock/unlock switch, key or remote controller to “LOCK” locks the door once but then immediately unlocks all doors.

UNLOCK LINK FUNCTION

When this function is activated, if the car is door lock/unlock switch locked, opening the drivers repossessing door from the inside handle override will cause the whole car to unlock.

Selectable Function

	Door Lock/unlock switch
How to change setting	Unlock press for more than 4 seconds
contents	Unlock link activate/deactivate
How to confirm	All should have buzzer sound for 0.2 seconds

BACK DOOR OPENER OPERATION

Back door can be opened with back door switch: When all door are unlocked, or When back door request switch pushed (With Intelligent Key system).

A

B

C

D

E

F

G

H

BL

J

K

L

M

POWER DOOR LOCK SYSTEM

CAN Communication SYSTEM DESCRIPTION

EIS008BZ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EIS004AQ

Go to CAN system, when selecting your car model from the following table.

Body type	3door/5door									
Axle	2WD									
Engine	CR10DE/CR12DE/CR14DE				CR12DE/CR14DE				K9K	
Handle	LHD/RHD									
Brake control	ABS system				ESP system				ABS	
Transmission	A/T		M/T		A/T		M/T		M/T	
Intelligent Key system	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable						
CAN communication unit										
ECM	x	x	x	x	x	x	x	x	x	x
Data link connector	x	x	x	x	x	x	x	x	x	x
Combination meter	x	x	x	x	x	x	x	x	x	x
Intelligent Key unit	x	x			x	x		x	x	
Drive computer	x		x		x		x		x	
EPS control unit	x	x	x	x	x	x	x	x	x	x
BCM	x	x	x	x	x	x	x	x	x	x
ABS actuator and electric unit (control unit)	x	x	x	x	x	x	x	x	x	x
TCM	x	x	x	x			x	x		
IPDM E/R	x	x	x	x	x	x	x	x	x	x
CAN communication type	BL-19, "TYPE 1/ TYPE 2"		BL-22, "TYPE 3/ TYPE 4"		BL-24, "TYPE 5/ TYPE 6"		BL-27, "TYPE 7/ TYPE 8"		BL-29, "TYPE 9/ TYPE 10"	


x: Applicable

POWER DOOR LOCK SYSTEM


TYPE 1/TYPE 2

System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

POWER DOOR LOCK SYSTEM

Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R				T		R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

POWER DOOR LOCK SYSTEM

Signals	ECM	Combi- nation meter.	Intelli- gentKey unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A

B

C

D

E

F

G

H

BL

J

K

L


M

POWER DOOR LOCK SYSTEM


TYPE 3/TYPE 4

System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

POWER DOOR LOCK SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


A
 B
 C
 D
 E
 F
 G
 H
 BL
 J
 K
 L
 M

POWER DOOR LOCK SYSTEM


TYPE 5/TYPE 6

System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

POWER DOOR LOCK SYSTEM

Signals	ECM	Combi-nation meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

POWER DOOR LOCK SYSTEM


Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction sig- nal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

POWER DOOR LOCK SYSTEM


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

POWER DOOR LOCK SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


POWER DOOR LOCK SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal	R	T						


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



POWER DOOR LOCK SYSTEM

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn-ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

POWER DOOR LOCK SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A

B

C

D

E

F

G

H

BL

J

K


L

M

POWER DOOR LOCK SYSTEM

Schematic – D/LOCK – (Without Intelligent Key System)

EIS00550





MKWA1773E

POWER DOOR LOCK SYSTEM

Wiring Diagram — D/LOCK — (Without Intelligent Key System)

EIS00551

BL-D/LOCK-01







M1 -SUPER MULTIPLE

JUNCTION (SMJ)

M16 -FUSE BLOCK-

POWER DOOR LOCK SYSTEM








BL-D/LOCK-02



POWER DOOR LOCK SYSTEM


BL-D/LOCK-03

5D : WITH 5 DOORS



MKWA0865E





POWER DOOR LOCK SYSTEM



POWER DOOR LOCK SYSTEM

BL-D/LOCK-05

A
B
C
D
E
F
G
H
BL
J
K
L
M




MKWA0867E

POWER DOOR LOCK SYSTEM

Schematic – D/LOCK – (With Intelligent Key System)

EIS00552



MKWA1777E



POWER DOOR LOCK SYSTEM

Wiring Diagram — D/LOCK — (With Intelligent Key System)

EIS00553

SMA for VIN
>SJN**AK12U1309269

BL-D/LOCK-06







REFER TO THE FOLLOWING.

- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M16) -FUSE BLOCK- JUNCTION BOX (J/B)
- (M79, M82) -JOINT CONNECTOR (J/C)

POWER DOOR LOCK SYSTEM







BL-D/LOCK-07



POWER DOOR LOCK SYSTEM


BL-D/LOCK-08

5D : WITH 5 DOORS







POWER DOOR LOCK SYSTEM

BL-D/LOCK-09



POWER DOOR LOCK SYSTEM

BL-D/LOCK-10



POWER DOOR LOCK SYSTEM

Terminal and Reference Value for BCM

EIS00554

Terminal	Wire color	Item	Condition	Voltage (V) (Approx.)
2	B	Ground	—	0
3	OR *P	Key switch	Key inserted (ON) → key removed from Ignition key cylinder (OFF)	Battery voltage → 0
5	Y	External back door release switch	Release switch open operation	5 → 0
6	LG	Door lock / unlock switch (Lock signal)	Lock operation (ON)	0
			Other than above (OFF)	5
10	OR	Back door switch	Open (ON) → Close (OFF)	0 → 5
19	R	CAN-H	—	—
24	OR	Ignition power supply	Ignition switch (ON or START position)	Battery voltage
25	BR	Door lock/unlock switch (Unlock signal)	Unlock operation (ON)	0
			Other than above (OFF)	5
29	L	Front door switch RH	Door open (ON) → close (OFF)	0 → Battery voltage
30	LG	Front door switch LH	Door open (ON) → close (OFF)	0 → Battery voltage
32	PU	Door lock status indicator	Goes OFF → Illuminates (Ignition switch ON and all door closed)	0 → Battery voltage
39	W	CAN-L	—	—
59	L	Rear door switch LH	Door open (ON) → close (OFF)	0 → Battery voltage
60	G	Rear door switch RH	Door open (ON) → close (OFF)	0 → Battery voltage
67	L	Door lock actuator unlock (Passenger and rear LH, RH doors)	Door lock / unlock switch Unlock operation	0 → Battery voltage
68	OR	Back door release actuator	Power window main switch (Trunk or back door release switch) Open operation	Battery voltage → 0
70	B	Ground (Power)	—	0
74	W	Battery power supply (BCM)	—	Battery voltage
76	BR	Door lock actuator unlock (DR side door)	Door lock / unlock switch Unlock operation	0 → Battery voltage
77	L	Door lock actuator lock signal (All doors)	Door lock/unlock switch & remote controller lock operation	0 → Battery voltage
79	Y	Battery power supply (Power)	—	Battery voltage

*: With Intelligent Key system models


CONSULT-II Inspection Procedure

EIS00555


CAUTION:

If CONSULT-II is used with no connector of CONSULT-II CONVERTER, malfunction might be detected in self-diagnosis depending on control which carry out CAN communication.


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "BCM" on "SELECT ITEM" screen. If "BCM" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




6. Touch "DOOR LOCK".



POWER DOOR LOCK SYSTEM

7. Touch "WORK SUPPORT", "DATA MONITOR", or "ACTIVE TEST" on the "SELECT DIAG MODE" screen.



CONSULT-II Application Items

WORK SUPPORT

EIS00556

Supported Item	Description
SECURITY DOOR LOCK SET	Anti-hijack function mode can be changed in this mode.
AUTO LOCK SET	Auto locking function mode can be changed in this mode.

Security Door Lock Set

	ON	OFF
Anti hijack function	Activation	Deactivation

Auto Lock Set

	MODE1	MODE2	MODE3	MODE4	MODE5	MODE6*	MODE7*	MODE8*
Auto locking function	1 minute	2 minutes	3 minutes	4 minutes	5 minutes	-	-	-

*: These mode are not supported.

DATA MONITOR

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
PUSH SW (*1)	Indicates [ON/OFF] condition of ignition knob switch.
KEY IN SW (*2)	Indicates [ON/OFF] condition of key switch.
CDL LOCK SW	Indicates [ON/OFF] condition of lock signal from door lock/ unlock switch.
CDL UNLOCK SW	Indicates [ON/OFF] condition of unlock signal from door lock/ unlock switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch (driver side).
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch (passenger side).
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch LH.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch RH.
BACK DOOR SW	Indicates [ON/OFF] condition of back door switch.
TRNK OPNR SW	Indicates [ON/OFF] condition of external back door release switch.

*1: Models with Intelligent Key System.

*2: Models without Intelligent Key System.

ACTIVE TEST

Monitored Item	Description
DOOR LOCK	This test is able to check all door lock actuator (except for back door) lock / unlock operation. These actuator lock / unlock when "LOCK" or "UNLOCK" on CONSULT-II screen is touched.
TRUNK / BACK DOOR	This test is able to check back door release actuator open operation. These actuator open when "OPEN" on CONSULT-II screen is touched.

POWER DOOR LOCK SYSTEM

TROUBLE DIAGNOSES CHART BY SYMPTOM/WITHOUT INTELLIGENT KEY SYSTEM

Always check the "Work Flow" before troubleshooting. Refer to Service Manual

Symptom	Malfunctioning system	Refer to page
Power door lock does not operate with door lock / unlock switch.	1. Check BCM power supply and ground circuit.	BL-49
	2. Check door lock / unlock switch.	BL-50
	3. Check door lock actuator (driver side).	BL-54
	4. Replace BCM.	BCS-31
Specific door lock actuator does not operate.	Check door lock actuator.	BL-54
Front door lock actuator (driver side) does not operate. (All other door lock actuators operate properly)	Check front door lock actuator (driver side).	BL-54
All door lock actuator (except driver side) does not operate.	1. Check door lock actuator circuit.	BL-53
	2. Replace BCM.	BCS-31
Key reminder system does not operate.	1. Check key switch.	BL-51
	2. Check door switch.	BL-58
	3. Replace BCM.	BCS-31
Back door does not open. But power door lock operates properly.	1. Check external back door release switch.	BL-66
	2. Check back door release actuator.	BL-68
	3. Replace BCM.	BCS-31
Door lock/unlock switch indicator does not illumination. (All other door lock system is "OK".)	1. Check door lock/unlock switch indicator.	BL-69
	3. Replace BCM.	BCS-31

A

B

C

D

E

F

G

H

BL

J

K

L

M

POWER DOOR LOCK SYSTEM

TROUBLE DIAGNOSES CHART BY SYMPTOM/WITH INTELLIGENT KEY SYSTEM

Always check the "Work Flow" before troubleshooting. Refer to Service Manual

Symptom	Malfunctioning system	Refer to page
Power door lock does not operate with door lock / unlock switch.	1. Check BCM power supply and ground circuit.	BL-49
	2. Check door lock / unlock switch.	BL-50
	3. Check door lock actuator (driver side).	BL-54
	4. Replace BCM.	BCS-31
Specific door lock actuator does not operate.	Check door lock actuator.	BL-54
Front door lock actuator (driver side) does not operate. (All other door lock actuators operate properly)	Check front door lock actuator (driver side).	BL-54
All door lock actuator (except driver side) does not operate.	1. Check door lock actuator circuit.	BL-53
	2. Replace BCM.	BCS-31
Key reminder system does not operate.	1. Check key switch.	BL-52
	2. Check door switch.	BL-58
	3. Replace BCM.	BCS-31
Back door does not open. But power door lock operates properly.	1. Check external back door release switch.	BL-66
	2. Check back door release actuator.	BL-68
	3. Replace BCM.	BCS-31
Door lock/unlock switch indicator does not illumination. (All other door lock system is "OK".)	1. Check door lock/unlock switch indicator.	BL-69
	3. Replace BCM.	BCS-31
All door lock actuator (except passenger side) does not operate.	1. Check door lock/unlock relay circuit.	BL-69

Check Power Supply and Ground Circuit of BCM

EIS00558

First perform the “SELF-DIAG RESULTS” in “BCM” with CONSULT-II, then perform the each trouble diagnosis of malfunction system indicated “SELF-DIAG RESULTS” of “BCM”, Refer to [BCS-22, “CONSULT-II Function \(BCM\)”](#).

1. FUSE INSPECTION

- Check 10A fuse [No.4, located in fuse block (J/B)]
- Check 40A fusible link (letter **J** located in the fuse and fusible link box).

NOTE:

Refer to [BL-15, "Component Parts and Harness Connector Location"](#).

OK or NG

OK >> GO TO 2

NG >> If fuse is blown out, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING"](#)

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch ON.
- Check voltage between BCM connector M48, M50 terminal 24, 79 and ground.


24 (OR) – Ground :Battery voltage.

79 (Y) – Ground :Battery voltage.

OK or NG

OK >> GO TO 3

NG >> Check BCM power supply circuit for open or short.

**3. CHECK GROUND CIRCUIT**

- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check continuity between BCM connector M48, M50 terminal 2, 70 and ground.


2 (B) – Ground :Continuity should exist.

70 (B) – Ground :Continuity should exist.

OK or NG

OK >> Power supply and ground circuit is OK.

NG >> Check BCM ground circuit for open or short.



POWER DOOR LOCK SYSTEM

Check Door Lock / Unlock Switch

EIS00559

1. CHECK DOOR LOCK / UNLOCK SWITCH SIGNAL

With CONSULT- II

Check door lock / unlock switch input signal ("CDL LOCK SW" "CDL UNLOCK SW") in "DATA MONITOR" mode with CONSULT- II.

When door lock/unlock switch is turned to LOCK:

CDL LOCK SW ⇒ ON

When door lock/unlock switch is turned to UNLOCK:

CDL UNLOCK SW ⇒ ON

DATA MONITOR	
MONITOR	
CDL LOCK SW	ON
CDL UNLOCK SW	ON

SIIA1566E

Without CONSULT- II


Door lock / unlock switch operate, check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)	
	(+)	(-)			
M48	6 (LG)	Ground	Lock	0	
			Neutral / Unlock	5	
	25 (BR)		Unlock	0	
			Neutral / Lock	5	

OK or NG

OK >> Door lock / unlock switch is OK.

NG >> GO TO 2.



2. CHECK DOOR LOCK/UNLOCK SWITCH

1. Turn ignition switch OFF.
2. Disconnect door lock / unlock switch connector.
3. Check continuity between door lock / unlock switch terminals 5, 6 and 4.


Terminals		Condition	Continuity
5	4	Unlock	Yes
		Neutral / Lock	No
6	4	Lock	Yes
		Neutral / Unlock	No

OK or NG

OK >> Check the following.

- Ground circuit for door lock / unlock switch
- Harness for open or short between BCM and door lock / unlock switch.

NG >> Replace door lock / unlock switch.



Check Key Switch /Without Intelligent Key System

EIS0055A

1. CHECK KEY SWITCH INPUT SIGNAL

With CONSULT-II

Check key switch input signal "KEY IN SW" in "DATA MONITOR" mode with CONSULT- II.

When key is inserted in ignition key cylinder:

KEY IN SW ⇒ ON

When key is removed from ignition key cylinder:

KEY IN SW ⇒ OFF


Without CONSULT- II

Check voltage between BCM connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	3 (OR)	Ground	Key is inserted	Battery voltage
			Key is removed	0

OK or NG

OK >> Key switch is OK.
NG >> GO TO 2.



2. CHECK KEY SWITCH (INSERT)

1. Turn ignition switch OFF.
2. Disconnect key switch connector.
3. Check continuity between key switch terminals 1 and 2.


Terminals		Condition	Continuity
1	2	Key is inserted	YES
		Key is removed	NO

OK or NG?

OK >> Check the following.

- 10A fuse [No. 6, located in fuse block (J/B)].
- Harness for open or short between key switch and fuse.
- Harness for open or short between BCM and key switch.

NG >> Replace key switch.



POWER DOOR LOCK SYSTEM

Check Key Switch/With Intelligent Key System

EIS0056D

1. KEY SWITCH INSPECTION

With CONSULT-II

Display "PUSH SW" on DATA MONITOR screen, and check if ON-OFF display is linked to ignition knob switch operation.

When ignition knob is pushed : PUSH SW ON

When ignition knob is released : PUSH SW OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
PUSH SW	OFF
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

MKIB0841E

Without CONSULT-II


Check voltage between BCM connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	3 (OR)	Ground	Key is inserted	Battery voltage
			Key is removed	0

OK or NG

OK >> Key switch is OK.

NG >> GO TO 2.



2. KEY SWITCH POWER SUPPLY CIRCUIT INSPECTION


1. Remove mechanical key from ignition knob.
2. Disconnect key switch and ignition knob switch connector.
3. Check voltage between key switch and ignition knob switch connector M34 terminal 1 and ground.

1 (W) - Ground : Approx. 12V

OK or NG

OK >> GO TO 3.

NG >> Repair or replace key switch power supply circuit.



POWER DOOR LOCK SYSTEM

3. KEY SWITCH OPERATION INSPECTION

1. Insert mechanical key into ignition knob.
2. Check continuity between key switch and ignition knob switch connector M34 terminal 1 and 2.

1 - 2

Insert mechanical key into ignition knob.

: Continuity should exist.


Remove mechanical key from ignition knob.

: Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Replace key switch.



4. KEY SWITCH CIRCUIT INSPECTION

1. Disconnect Intelligent Key unit connector.
2. Check continuity between Intelligent Key unit connector M51 terminal 27 and key switch and ignition knob switch connector M34 terminal 2.

27 (P) - 2 (P)

: Continuity should exist.

3. Check continuity between key switch connector M34 terminal 2 and ground.


2 (P) - Ground

: Continuity should not exist.

OK or NG

OK >> Key switch is OK.

NG >> Repair or replace harness between Intelligent Key unit and key switch and ignition knob switch.



Check Door Lock Actuator Circuit.

EIS0055B

1. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 67 and front door lock actuator (passenger side) connector D38 terminal 2.

67 (L) - 2 (L)

: Continuity should exist.

3. Check continuity between BCM connector M50 terminal 67 and ground.


67 (L) - Ground

: Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.

NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM


Check Door Lock Actuator DRIVER SIDE

EIS0055C

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect front door lock actuator (driver side) connector.
3. Door lock / unlock switch operate, check voltage between front door lock actuator (driver side) connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D9	5 (BR)	Ground	Unlock	0 → Battery voltage → 0
	4 (L)		Lock	0 → Battery voltage → 0



OK or NG

OK >> Replace front door lock actuator (driver side).
 NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 76, 77 and front door lock actuator (driver side) connector D9 terminal 4, 5.


76 (BR) – 5 (BR) : Continuity should exist.
77 (L) – 4 (L) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 76, 77 and ground.

76 (BR) – Ground : Continuity should not exist.
77 (L) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
 NG >> Repair or replace harness.




POWER DOOR LOCK SYSTEM

PASSENGER SIDE

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect front door lock actuator (passenger side) connector.
3. Door lock / unlock switch operate, check voltage between front door lock actuator (passenger side) connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D38	3 (L)	Ground	Lock	0 → Battery voltage → 0
	2 (L)		Unlock	0 → Battery voltage → 0



OK or NG

OK >> Replace front door lock actuator (passenger side).
 NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 67, 77 and front door lock actuator (passenger side) connector D38 terminal 2, 3.


67 (L) – 2 (L) : Continuity should exist.
77 (L) – 3 (L) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 67, 77 and ground.

67 (L) – Ground : Continuity should not exist.
77 (L) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
 NG >> Repair or replace harness.




POWER DOOR LOCK SYSTEM

REAR LH SIDE

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect rear door lock actuator LH connector.
3. Door lock / unlock switch operate, check voltage between rear door lock actuator LH connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D63	4 (BR)	Ground	Lock	0 → Battery voltage → 0
	5 (Y)		Unlock	0 → Battery voltage → 0



OK or NG

OK >> Replace rear door lock actuator LH.
NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 67, 77 and rear door lock actuator LH connector D63 terminal 4, 5.


67 (L) – 5 (Y) : Continuity should exist.
77 (L) – 4 (BR) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 67, 77 and ground.

67 (L) – Ground : Continuity should not exist.
77 (L) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.




POWER DOOR LOCK SYSTEM

REAR RH SIDE

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect rear door lock actuator RH connector.
3. Door lock / unlock switch operate, check voltage between rear door lock actuator RH connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D83	2 (Y)	Ground	Unlock	0 → Battery voltage → 0
	3 (L)		Lock	0 → Battery voltage → 0



OK or NG

OK >> Replace rear door lock actuator RH.
 NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 67, 77 and rear door lock actuator RH connector D83 terminal 2, 3.


67 (L) – 2 (Y) : Continuity should exist.
77 (L) – 3 (L) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 67, 77 and ground.

67 (L) – Ground : Continuity should not exist.
77 (L) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
 NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM

Check Door Switch DRIVER SIDE

EIS0055D

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT- II

Check door switch "DOOR SW-DR" in "DATA MONITOR" mode with CONSULT- II.

When front door (driver side) is opend:

DOOR SW-DR ⇒ ON

When front door (driver side) is close:

DOOR SW-DR ⇒ OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
PUSH SW	OFF
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON
	Page Down
	RECORD
MODE	BACK
	LIGHT
	COPY

MKIB0841E


Without CONSULT- II

Check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	29 (L)	Ground	Open	0
			Close	Battery voltage

OK or NG

OK >> Front door switch LH is OK.
NG >> GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and front door switch LH connector.
3. Check continuity between BCM connector M48 terminal 29 and front door switch LH connector B22 terminal 1.


29 (L) – 1 (LG) : Continuity should exist.

4. Check continuity between BCM connector M48 terminal 29 and ground.

29 (L) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.
NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM


3. CHECK DOOR SWITCH

Check continuity between door switch terminal 1 and body ground part of door switch.

Terminals		Condition	Continuity
1	Body ground part of door switch	Pushed	No
		Released	Yes

OK or NG

OK >> GO TO 4.
NG >> Replace door switch.



4. CHECK BCM OUTPUT SIGNAL


1. Connect BCM connector.
2. Check voltage between BCM connector M48 terminal 29 and ground.

Driver side door is closed.

29 (L) – Ground : Battery voltage

OK or NG

OK >> Check door switch ground condition.
NG >> Replace BCM.



POWER DOOR LOCK SYSTEM

PASSENGER SIDE

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT- II

Check door switch "DOOR SW-AS" in "DATA MONITOR" mode with CONSULT- II.

When front door (passenger side) is open:

DOOR SW-AS ⇒ ON

When front door (passenger side) is close:

DOOR SW-AS ⇒ OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
PUSH SW	OFF
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON

Page Down

RECORD

MODE BACK LIGHT COPY

MKIB0841E

Without CONSULT- II


Check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	30 (LG)	Ground	Open	0
			Close	Battery voltage

OK or NG

OK >> Front door switch RH is OK.

NG >> GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and front door switch RH connector.
3. Check continuity between BCM connector M48 terminal 30 and front door switch RH connector B16 terminal 1.

30 (LG) – 1 (L) : Continuity should exist.


4. Check continuity between BCM connector M48 terminal 30 and ground.

30 (LG) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM


3. CHECK DOOR SWITCH

Check continuity between door switch terminal 1 and body ground part of door switch.

Terminals		Condition	Continuity
1	Ground	Pushed	No
		Released	Yes

OK or NG

OK >> GO TO 4.
NG >> Replace door switch.



4. CHECK BCM OUTPUT SIGNAL


1. Connect BCM connector.
2. Check voltage between BCM connector M48 terminal 30 and ground.

Passenger side door is closed.

30 (LG) – Ground : Battery voltage

OK or NG

OK >> Check door switch ground condition.
NG >> Replace BCM.



POWER DOOR LOCK SYSTEM

REAR LH SIDE

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT- II

Check door switch "DOOR SW-RL" in "DATA MONITOR" mode with CONSULT- II.

When front door (rear LH side) is open:

DOOR SW-RL \Rightarrow ON

When front door (rear LH side) is close:

DOOR SW-RL \Rightarrow OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
PUSH SW	OFF
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON
	Page Down
	RECORD
MODE	BACK
	LIGHT
	COPY

MKIB0841E

Without CONSULT- II


Check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M49	59 (L)	Ground	Open	0
			Close	Battery voltage

OK or NG

OK \Rightarrow Rear door switch LH is OK.

NG \Rightarrow GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and rear door switch LH connector.
3. Check continuity between BCM connector M49 terminal 59 and rear door switch LH connector B31 terminal 1.

59 (L) – 1 (L) : Continuity should exist.


4. Check continuity between BCM connector M49 terminal 59 and ground.

59 (L) – Ground : Continuity should not exist.

OK or NG

OK \Rightarrow GO TO 3.

NG \Rightarrow Repair or replace harness.



POWER DOOR LOCK SYSTEM


3. CHECK DOOR SWITCH

Check continuity between door switch terminal 1 and body ground part of door switch.

Terminals		Condition	Continuity
1	Ground	Pushed	NO
		Released	YES

OK or NG

OK >> GO TO 4.
NG >> Replace door switch.



4. CHECK BCM OUTPUT SIGNAL


1. Connect BCM connector.
2. Check voltage between BCM connector M49 terminal 59 and ground.

Rear LH door is closed.

59 (L) – Ground : Battery voltage

OK or NG

OK >> Check door switch ground condition.
NG >> Replace BCM.



POWER DOOR LOCK SYSTEM

REAR RH SIDE

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT- II

Check door switch "DOOR SW-RR" in "DATA MONITOR" mode with CONSULT- II.

When front door (rear RH side) is open:

DOOR SW-RR \Rightarrow ON

When front door (rear RH side) is close:

DOOR SW-RR \Rightarrow OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
PUSH SW	OFF
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON
	Page Down
	RECORD
MODE	BACK
	LIGHT
	COPY

MKIB0841E

Without CONSULT- II


Check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M49	60 (G)	Ground	Open	0
			Close	Battery voltage

OK or NG

OK \Rightarrow Rear door switch RH is OK.

NG \Rightarrow GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and rear door switch RH connector.
3. Check continuity between BCM connector M49 terminal 60 and rear door switch RH connector B30 terminal 1.

60 (G) – 1 (G) : Continuity should exist.


4. Check continuity between BCM connector M49 terminal 60 and ground.

60 (G) – Ground : Continuity should not exist.

OK or NG

OK \Rightarrow GO TO 3.

NG \Rightarrow Repair or replace harness.



POWER DOOR LOCK SYSTEM


3. CHECK DOOR SWITCH

Check continuity between door switch terminal 1 and body ground part of door switch.

Terminals		Condition	Continuity
1	Ground	Pushed	NO
		Released	YES

OK or NG

OK >> GO TO 4.
NG >> Replace door switch.



4. CHECK BCM OUTPUT SIGNAL


1. Connect BCM connector.
2. Check voltage between BCM connector M49 terminal 60 and ground.

Rear RH door is closed.

60 (G) – Ground : **Battery voltage**

OK or NG

OK >> Check door switch ground condition.
NG >> Replace BCM.



POWER DOOR LOCK SYSTEM

Check External Back Door Release Switch

EIS0055E

1. CHECK EXTERNAL BACK DOOR RELEASE SWITCH INPUT SIGNAL

With CONSULT- II


Check external back door release switch "TRNK OPNR SW" in "DATA MONITOR" mode with CONSULT- II.

External back door release switch is pushed

TRNK OPNR SW : ON

External back door release switch is released

TRNK OPNR SW : OFF



Without CONSULT- II


Check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	5 (Y)	Ground	Pushed	0
			Released	5

OK or NG

OK >> External back door release switch is OK.

NG >> GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and external back door release switch connector.
3. Check continuity between BCM connector M48 terminal 5 and external back door release switch connector B52 terminal.

5 (Y) – 1 (Y) : Continuity should exist.


4. Check continuity between BCM connector M48 terminal 5 and ground.

5 (Y) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM


3. CHECK EXTERNAL BACK DOOR RELEASE SWITCH

Check continuity between external back door release switch terminal 1 and 2.

Terminals		Condition	Continuity
1	2	Pushed	Yes
		Released	No

OK or NG

OK >> GO TO 4.
NG >> Replace external back door release switch.




4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM connector M48 terminal 5 and ground.

5 (Y) – Ground : Approx. 5V

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Replace BCM.



POWER DOOR LOCK SYSTEM

Check Back Door Release Actuator

EIS0055F

1. CHECK BCM OUTPUT SIGNAL

Check back door release output signal

Perform ("TRUNK/BACK DOOR") in "ACTIVE TEST" mode with CONSULT-II.

When "ACTIVE TEST" is executed, does the back door open?

OK or NG

OK >> Back door release output is OK.
NG >> GO TO 2.

ACTIVE TEST	
TRUNK/BACK DOOR	OFF
ON	

MIIIB0354E


2. CHECK BACK DOOR RELEASE ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect back door release actuator connector.
3. External back door release switch operate, check voltage between back door release actuator connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
B55	3 (OR)	Ground	Pushed	0 → Battery voltage → 0

OK or NG

OK >> GO TO 4.
NG >> GO TO 3.



3. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 68 and back door release actuator connector B55 terminal 3.


68 (OR) – 3 (OR) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 68 and ground.

68 (OR) – Ground : Continuity should not exist.

OK or NG

OK >> Replace BCM.
NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM


4. CHECK GROUND CIRCUIT

Check continuity between back door release actuator connector B55 terminal 4 and ground.

4 (B) – Ground : Continuity should exist.

OK or NG

OK >> Replace back door release actuator.
NG >> Repair or replace harness.



EIS00566

Check Door Lock/Unlock Switch Indicator


1. CHECK DOOR LOCK/UNLOCK SWITCH INDICATOR

Check continuity between door lock/unlock switch indicator harness connector terminal 1 and 4.

Terminals		Continuity
(+)	(-)	
1	4	Yes
4	1	No

OK or NG

OK >> Check harness for open or short between BCM and door lock/unlock switch.
NG >> replace door lock/unlock switch.




MIB0413E

Check Door Lock/Unlock Relay Circuit

1. CHECK HARNESS CONTINUITY

1. Disconnect BCM and door lock/unlock relay and front door lock actuator (driver side).
2. Check continuity between BCM connector M50 terminal 77 and door lock/unlock relay connector M52 terminal 4.

77 (L) – 4 (L) : Continuity should exist.




MIB0414E

3. Check continuity between door lock/unlock relay connector M52 terminal 3 and front door lock actuator (driver side) connector D9 terminal 4.

3 (L) – 4 (L) : Continuity should not exist.

OK or NG

OK >> Check door lock/unlock relay.
NG >> Repair or replace harness.



MIB0415E

POWER DOOR LOCK — SUPER LOCK —

POWER DOOR LOCK — SUPER LOCK —


Component Parts and Harness Connector Location

SMA for VIN

PFP:24814

>SJN**AK12U1309269

EIS0054P



MIIIB0380E

System Description OUTLINE

EIS004XP

Power door lock system with super lock and key reminder is controlled by BCM (Body Control Module). Super lock has a higher anti-theft performance than conventional power door lock systems.

When super lock is in released condition, lock knob operation locks or unlocks door.

When super lock is in set condition, lock knob operation cannot lock nor unlock door.

OPERATION

Power door lock / unlock and super lock set / release operation by remote controller

- Pressing remote controller LOCK button will lock all doors and set super lock. (Super lock will not be set while key is inserted in the ignition key cylinder.)
- Pressing remote controller UNLOCK button once will unlock driver door and release super lock. Then, if an unlock signal is sent from the remote controller again within 5 seconds, all other doors will be unlocked.

Power door lock / unlock and super lock release operation by door key cylinder

With the key inserted into driver door key cylinder, turning it to UNLOCK will unlock passenger door and release super lock.

Power door lock and super lock release operation

When the super lock is set, turning the ignition key switch to ON will release the super lock. All doors will unlock once, but then immediately lock again.

Power door lock / unlock operation by lock / unlock switch

- With door lock / unlock switch on center console setting to LOCK will lock all doors.
- With door lock / unlock switch on center console setting to UNLOCK will unlock all doors.

Door lock / unlock switch operation cannot control super lock

Key reminder system

If the ignition key is in the ignition key cylinder and driver door is open, setting door lock / unlock switch, lock knob, key or remote controller to “LOCK” locks the door once but then immediately unlocks all doors.
(signal from door unlock sensor driver side)

BL

System initialization

- System initialization is required when battery cables are reconnected. Conduct the following to release super lock once:
 - insert the key into the ignition key cylinder and turn it to ON.
 - LOCK / UNLOCK operation using remote controller.

Back door open operation

Back door open operates when all doors door lock and super lock are unlocked.

J

K

L

M

POWER DOOR LOCK — SUPER LOCK —

CAN Communication SYSTEM DESCRIPTION

EIS008C1

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EIS00AOR

Go to CAN system, when selecting your car model from the following table.

Body type	3door/5door									
Axle	2WD									
Engine	CR10DE/CR12DE/CR14DE				CR12DE/CR14DE				K9K	
Handle	LHD/RHD									
Brake control	ABS system				ESP system				ABS	
Transmission	A/T		M/T		A/T		M/T		M/T	
Intelligent Key system	Appli-cable	Not appli-cable	Appli-cable	Not appli-cable						
CAN communication unit										
ECM	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×	×			×	×		×	×	
Drive computer	×		×		×		×	×	×	
EPS control unit	×	×	×	×	×	×	×	×	×	
BCM	×	×	×	×	×	×	×	×	×	
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	
TCM	×	×	×	×			×	×		
IPDM E/R	×	×	×	×	×	×	×	×	×	
CAN communication type	BL-73, "TYPE 1/ TYPE 2"		BL-76, "TYPE 3/ TYPE 4"		BL-78, "TYPE 5/ TYPE 6"		BL-81, "TYPE 7/ TYPE 8"		BL-83, "TYPE 9/ TYPE 10"	


×: Applicable

POWER DOOR LOCK — SUPER LOCK —


TYPE 1/TYPE 2

System diagram

- Type 1



- Type 2



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	

POWER DOOR LOCK — SUPER LOCK —

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R				T		R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					

POWER DOOR LOCK — SUPER LOCK —

Signals	ECM	Combi- nation meter.	Intelli- gentKey unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A

B

C

D

E

F

G

H

BL

J

K

L


M

POWER DOOR LOCK — SUPER LOCK —


TYPE 3/TYPE 4

System diagram

- Type 3



- Type 4



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R

POWER DOOR LOCK — SUPER LOCK —

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					


A
 B
 C
 D
 E
 F
 G
 H
 BL
 J
 K
 L
 M

POWER DOOR LOCK — SUPER LOCK —


TYPE 5/TYPE 6

System diagram

- Type 5



- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combination meter.	Intelligent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	

POWER DOOR LOCK — SUPER LOCK —

Signals	ECM	Combi-nation meter.	Intelli-gentKey unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		

A
 B
 C
 D
 E
 F
 G
 H
 BL
 J
 K
 L
 M

POWER DOOR LOCK — SUPER LOCK —


Signals	ECM	Combi- nation meter.	Intelli- gent Key unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction sig- nal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

POWER DOOR LOCK — SUPER LOCK —


TYPE 7/TYPE 8

System diagram

- Type 7



- Type 8



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina- tion meter.	Intelli- gent Key unit	Drive computer	EPS con- trol unit	BCM	ABS actuator and elec- tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R

POWER DOOR LOCK — SUPER LOCK —

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R


POWER DOOR LOCK — SUPER LOCK —

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and electric unit (control unit)	IPDM E/R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal	R	T						


TYPE 9/TYPE 10

System diagram

- Type 9



- Type 10



POWER DOOR LOCK — SUPER LOCK —

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn-ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			T			R		
Door lock/unlock status signal			R			T		

POWER DOOR LOCK — SUPER LOCK —

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A

B

C

D

E

F

G

H

BL

J

K


L

M

POWER DOOR LOCK — SUPER LOCK —

Schematic – S/LOCK – (Without Intelligent Key System)

EIS004XQ



POWER DOOR LOCK — SUPER LOCK —



Wiring Diagram — S/LOCK — (Without Intelligent Key System)

EIS004XR

BL-S/LOCK-01

SMA for VIN
>SJN**AK12U1309269

REFER TO PG-POWER.



M1 -SUPER MULTIPLE


JUNCTION (SMJ)

M16 -FUSE BLOCK-

JUNCTION BOX (J/B)

POWER DOOR LOCK — SUPER LOCK —



BL-S/LOCK-02



POWER DOOR LOCK — SUPER LOCK —






BL-S/LOCK-03

5D : WITH 5 DOORS



POWER DOOR LOCK — SUPER LOCK —





BL-S/LOCK-04



MKWA1784E

POWER DOOR LOCK — SUPER LOCK —





BL-S/LOCK-05



MKWA1785E

POWER DOOR LOCK — SUPER LOCK —

BL-S/LOCK-06




MKWA0880E

POWER DOOR LOCK — SUPER LOCK —

Schematic — S/LOCK — (With Intelligent Key System)

EIS0054Q





MKWA1786E

POWER DOOR LOCK — SUPER LOCK —

Wiring Diagram — S/LOCK — (With Intelligent Key System)

EIS0054R



REFER TO THE FOLLOWING.





(M1) -SUPER MULTIPLE
JUNCTION (SMJ)

(M16) -FUSE BLOCK-
JUNCTION BOX (J/B)

(M79, M82)
-JOINT CONNECTOR (J/C)

POWER DOOR LOCK — SUPER LOCK —

BL-S/LOCK-08





MKWA1788E

POWER DOOR LOCK — SUPER LOCK —


BL-S/LOCK-09

 : WITH 5 DOORS



POWER DOOR LOCK — SUPER LOCK —





BL-S/LOCK-10



MKWA1789E

POWER DOOR LOCK — SUPER LOCK —





BL-S/LOCK-11



MKWA1790E

POWER DOOR LOCK — SUPER LOCK —

BL-S/LOCK-12



POWER DOOR LOCK — SUPER LOCK —

Terminal and Reference Value for Smart Entrance Control Unit

EIS004XS

Terminal	Wire color	Item	Condition	Voltage (V) (Approx.)
2	B	Ground	—	0
3	OR (P)	Key switch	Key inserted (ON) → key removed from IGN key cylinder (OFF)	Battery voltage → 0
5	Y	External back door release switch	Release switch open operation	5 → 0
6	LG	Door lock / unlock switch (Lock signal)	Lock operation (ON)	0
			Other than above (OFF)	5
10	OR	Back door switch	Open (ON) → Close (OFF)	0 → 5
19	R	CAN-H	—	—
24	OR	IGN power supply	Ignition switch (ON or START position)	Battery voltage
25	BR	Door lock/unlock switch (Unlock signal)	Unlock operation (ON)	0
			Other than above (OFF)	5
29	L	Front door switch RH	Door open (ON) → close (OFF)	0 → Battery voltage
30	LG	Front door switch LH	Door open (ON) → close (OFF)	0 → Battery voltage
32	PU	Door lock status indicator	Goes OFF → Illuminates (Ignition switch ON and all door closed)	0 → Battery voltage
39	W	CAN-L	—	—
59	L	Rear door switch LH	Door open (ON) → close (OFF)	0 → Battery voltage
60	G	Rear door switch RH	Door open (ON) → close (OFF)	0 → Battery voltage
67	L	Door lock actuator & super lock actuator unlock signal (Passenger and rear LH, RH doors)	Door lock / unlock switch & remote controller unlock operation *	0 → Battery voltage
68	OR	Back door release actuator	Power window main switch (Trunk or back door release switch) Open operation	Battery voltage → 0
70	B	Ground (Power)	—	0
74	W	BAT power supply (BCM)	—	Battery voltage
75	R	Super lock actuator lock signal (All doors)	Remote controller lock operation	0 → Battery voltage
76	BR	Door lock actuator & super loci actuator unlock signal (Driver side)	Door lock / unlock switch & remote controller unlock operation *	0 → Battery voltage
77	L	Door lock actuator lock signal (All doors)	Door lock/unlock switch & remote controller lock operation	0 → Battery voltage
79	Y	BAT power supply (PW)	—	Battery voltage

() : With Intelligent Key switch models

* : It is operation only of door lock actuator to operate door lock / unlock switch.


CONSULT-II Inspection Procedure

EIS004XT

CAUTION:


If CONSULT-II is used with no connector of CONSULT-II CONVERTER, malfunction might be detected in self-diagnosis depending on control which carry out CAN communication.

1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector.




PBIA3525E


3. Turn ignition switch "ON".
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "BCM".




6. Touch "DOOR LOCK".



POWER DOOR LOCK — SUPER LOCK —

7. Select diagnosis mode.
“WORK SUPPORT”, “DATA MONITOR” and “ACTIVE TEST” are available.



CONSULT-II Application Items

WORK SUPPORT

EIS004XU

Supported Item	Description
SECURITY DOOR LOCK SET	Anti-hijack function mode can be changed in this mode.
AUTO LOCK SET	Auto locking function mode can be changed in this mode.

Security Door Lock Set

	ON	OFF
Anti hijack function	Activation	Deactivation

Auto Lock Set

	MODE1	MODE2	MODE3	MODE4	MODE5	MODE6*	MODE7*	MODE8*
Auto locking function	1 minute	2 minutes	3 minutes	4 minutes	5 minutes	—	—	—

*: These mode are not supported.

DATA MONITOR

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
PUSH SW (*1)	Indicates [ON/OFF] condition ignition knob switch.
KEY IN SW (*2)	Indicates [ON/OFF] condition of key switch.
CDL LOCK SW	Indicates [ON/OFF] condition of lock signal from door lock/ unlock switch.
CDL UNLOCK SW	Indicates [ON/OFF] condition of unlock signal from door lock/ unlock switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch (driver side).
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch (passenger side).
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch (RH).
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch (LH).
BACK DOOR SW	Indicates [ON/OFF] condition of back door switch.
TRNK OPNR SW	Indicates [ON/OFF] condition of external back door release switch.

*1: Models with Intelligent Key System.

*2: Models without Intelligent Key System.

WORK SUPPORT

Monitored Item	Description
DOOR LOCK	This test is able to check all door lock actuator (except for back door) lock / unlock operation. These actuator lock / unlock when “LOCK” or “UNLOCK” on CONSULT-II screen is touched.
TRUNK / BACK DOOR	This test is able to check back door release actuator open operation. These actuator open when “OPEN” on CONSULT-II screen is touched.

POWER DOOR LOCK — SUPER LOCK —

Trouble Diagnoses PRELIMINARY CHECK

EIS004XV

A

B

C

D

E

F

G

H


BL

J

K

L

M



MIIB0358E

After performing preliminary check, go to SYMPTOM CHART.

Before starting trouble diagnoses below, perform preliminary check.

Symptom numbers in the symptom chart correspond with those of Preliminary check.

POWER DOOR LOCK — SUPER LOCK —

SYMPTOM CHART

Symptom	Malfunctioning system	Refer to page
SYMPTOM 1 Power door lock does not operate with door lock / unlock switch	1. Power supply and ground circuit check	BL-105
	2. Key switch check	BL-107
	3. Door lock / unlock switch check.	BL-106
	4. Replace BCM.	BCS-31
SYMPTOM 2 Power door lock does not operate with door lock / unlock switch.	1. Power door lock / unlock output signal check.	BL-109
	2. Replace BCM.	BCS-31
SYMPTOM 3 Specific door lock actuator does not operate.	1. Door lock actuator check.	BL-111
	2. Replace BCM.	BCS-31
SYMPTOM 4 Super lock does not operate.	1. Super lock output signal check.	BL-110
	2. Replace BCM.	BCS-31
SYMPTOM 5 Specific super lock does not unlock operate.	1. Super lock actuator check.	BL-115
	2. Replace BCM.	BCS-31
SYMPTOM 6 Key reminder system does not operate.	1. Door switch check.	BL-119
	2. Replace BCM.	BCS-31
SYMPTOM 7 Back door does not open. But power door lock operate is properly.	1. External back door release switch check.	BL-127
	2. Back door release actuator check.	BL-129
	3. Replace BCM.	BCS-31

Power Supply and Ground Circuit Check

EIS0054S

First perform the “SELF-DIAG RESULTS” in “BCM” with CONSULT-II, then perform the each trouble diagnosis of malfunction system indicated “SELF-DIAG RESULTS” of “BCM”, Refer to [BCS-22, "CONSULT-II Function \(BCM\)"](#).

1. FUSE INSPECTION

- Check 10A fuse [No.4, located in fuse block (J/B)]
- Check 40A fusible link (letter **J** located in the fuse and fusible link box).

NOTE:

Refer to [BL-70, "Component Parts and Harness Connector Location"](#).

OK or NG

OK >> GO TO 2

NG >> If fuse is blown out, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING"](#).

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch ON.
- Check voltage between BCM connector M48, M50 terminal 24, 79 and ground.


24 (OR) – Ground :Battery voltage.

79 (Y) – Ground :Battery voltage.

OK or NG

OK >> GO TO 3

NG >> Check BCM power supply circuit for open or short.



3. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector.
- Check continuity between BCM connector M48, M50 terminal 2, 70 and ground.


2 (B) – Ground :Continuity should exist.

70 (B) – Ground :Continuity should exist.

OK or NG

OK >> Power supply and ground circuit is OK.

NG >> Check BCM ground circuit for open or short.



POWER DOOR LOCK — SUPER LOCK —

Door Lock / Unlock Switch Check

EIS004XY

1. CHECK DOOR LOCK / UNLOCK SWITCH SIGNAL

With CONSULT- II


Check door lock / unlock switch input signal ("CDL LOCK SW" "CDL UNLOCK SW") in "DATA MONITOR" mode with CONSULT- II.

When door lock/unlock switch is turned to LOCK:

CDL LOCK SW ⇒ ON

When door lock/unlock switch is turned to UNLOCK:

CDL UNLOCK SW ⇒ ON



Without CONSULT- II


Door lock / unlock switch operate, check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)	
	(+)	(-)			
M48	6 (LG)	Ground	Lock	0	
			Neutral / Unlock	5	
	25 (BR)		Unlock	0	
			Neutral / Lock	5	

OK or NG

OK >> Door lock / unlock switch is OK.

NG >> GO TO 2.



2. CHECK DOOR LOCK/UNLOCK SWITCH

1. Turn ignition switch OFF.
2. Disconnect door lock / unlock switch connector.
3. Check continuity between door lock / unlock switch terminals 5, 6 and 4.


Terminals		Condition	Continuity
5	4	Unlock	YES
		Neutral / Lock	NO
6		Lock	YES
		Neutral / Unlock	NO

OK or NG

OK >> Check the following.

- Ground circuit for door lock / unlock switch
- Harness for open or short between BCM and door lock / unlock switch.

NG >> Replace door lock / unlock switch.



Check Key Switch /Without Intelligent Key System

EIS00AQ1

1. CHECK KEY SWITCH INPUT SIGNAL

With CONSULT-II

Check key switch input signal "KEY ON SW" in "DATA MONITOR" mode with CONSULT- II.

When key is inserted in ignition key cylinder:

KEY IN SW ⇒ ON

When key is removed from ignition key cylinder:

KEY IN SW ⇒ OFF


Without CONSULT- II

Check voltage between BCM connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	3 (OR)	Ground	Key is inserted	Battery voltage
			Key is removed	0

OK or NG

OK >> Key switch is OK.
NG >> GO TO 2.



2. CHECK KEY SWITCH (INSERT)

1. Turn ignition switch OFF.
2. Disconnect key switch connector.
3. Check continuity between key switch terminals 1 and 2.


Terminals		Condition	Continuity
1	2	Key is inserted	YES
		Key is removed	NO

OK or NG?

OK >> Check the following.

- 10A fuse [No. 6, located in fuse block (J/B)].
- Harness for open or short between key switch and fuse.
- Harness for open or short between BCM and key switch.

NG >> Replace key switch.



POWER DOOR LOCK — SUPER LOCK —

Check Key Switch/With Intelligent Key System

EIS00AQ2

1. KEY SWITCH INSPECTION

With CONSULT-II

Display "PUSH SW" on DATA MONITOR screen, and check if ON-OFF display is linked to ignition knob switch operation.

When ignition knob is pushed : PUSH SW ON

When ignition knob is released : PUSH SW OFF

DATA MONITOR	
MONITOR	
IGN ON SW	ON
PUSH SW	OFF
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON
Page Down	
RECORD	
MODE	BACK
LIGHT	COPY

MKIB0841E

Without CONSULT-II


Check voltage between BCM connector and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	3 (OR)	Ground	Key is inserted	Battery voltage
			Key is removed	0

OK or NG

OK >> Key switch is OK.

NG >> GO TO 2.



2. KEY SWITCH POWER SUPPLY CIRCUIT INSPECTION


1. Remove mechanical key from ignition knob.
2. Disconnect key switch and ignition knob switch connector.
3. Check voltage between key switch and ignition knob switch connector M34 terminal 1 and ground.

1 (W) - Ground : Approx. 12V

OK or NG

OK >> GO TO 3.

NG >> Repair or replace key switch power supply circuit.



POWER DOOR LOCK — SUPER LOCK —

3. KEY SWITCH OPERATION INSPECTION

1. Insert mechanical key into ignition knob.
2. Check continuity between key switch and ignition knob switch connector M34 terminal 1 and 2.

1 - 2

Insert mechanical key into ignition knob.

: Continuity should exist.


Remove mechanical key from ignition knob.

: Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Replace key switch.



4. KEY SWITCH CIRCUIT INSPECTION

1. Disconnect Intelligent Key unit connector.
2. Check continuity between Intelligent Key unit connector M51 terminal 27 and key switch and ignition knob switch connector M34 terminal 2.

27 (P) - 2 (P) : Continuity should exist.


3. Check continuity between key switch connector M34 terminal 2 and ground.

2 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Key switch is OK.

NG >> Repair or replace harness between Intelligent Key unit and key switch and ignition knob switch.



Power Door Lock / Unlock Output Signal Check.

EIS00AQ3

1. CHECK POWER DOOR LOCK OUTPUT SIGNAL


Door lock / unlock switch operate, check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M50	67 (L)	Ground	Unlock	0 → Battery voltage → 0
	76 (BR)		Unlock	0 → Battery voltage → 0
	77 (L)		Lock	0 → Battery voltage → 0

OK or NG

OK >> Check the condition of the harness and the connector.

NG >> Replace BCM.



POWER DOOR LOCK — SUPER LOCK —

Super Lock Output Signal Check.

EIS00AQ4


1. CHECK SUPER LOCK OUTPUT SIGNAL

Remote controller operate, check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M50	75 (R)	Ground	Lock button is pressed.	0 → Battery voltage → 0

OK or NG

OK >> Check the condition of the harness and connector.
NG >> Replace BCM.



POWER DOOR LOCK — SUPER LOCK —

Door Lock Actuator Check DRIVER SIDE


SMA for VIN
>SJN**AK12U1309269

EIS00AQ5

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect front door lock actuator (driver side) connector.
3. Door lock / unlock switch operate, check voltage between front door lock actuator (driver side) connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D9	2 (BR)	Ground	Unlock	0 → Battery voltage → 0
	3 (L)		Lock	0 → Battery voltage → 0



OK or NG

OK >> Replace front door lock actuator (driver side).
NG >> GO TO 2.


2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 76, 77 and front door lock actuator (driver side) connector D9 terminal 2, 3.

76 (BR) – 2 (BR) : Continuity should exist.
77 (L) – 3 (L) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 76, 77 and ground.

76 (BR) – Ground : Continuity should not exist.
77 (L) – Ground : Continuity should not exist.



OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.


POWER DOOR LOCK — SUPER LOCK —

PASSENGER SIDE

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect front door lock actuator (passenger side) connector.
3. Door lock / unlock switch operate, check voltage between front door lock actuator (passenger side) connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D38	4 (L)	Ground	Lock	0 → Battery voltage → 0
	5 (L)		Unlock	0 → Battery voltage → 0



OK or NG

OK >> Replace front door lock actuator (passenger side).
NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 67, 77 and front door lock actuator (passenger side) connector D38 terminal 4, 5.


67 (L) – 5 (L) : Continuity should exist.
77 (L) – 4 (L) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 67, 77 and ground.

67 (L) – Ground : Continuity should not exist.
77 (L) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.




POWER DOOR LOCK — SUPER LOCK —

REAR LH SIDE

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect rear door lock actuator LH connector.
3. Door lock / unlock switch operate, check voltage between rear door lock actuator LH connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D63	4 (BR)	Ground	Lock	0 → Battery voltage → 0
	5 (Y)		Unlock	0 → Battery voltage → 0



OK or NG

OK >> Replace rear door lock actuator LH.
 NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 67, 77 and rear door lock actuator LH connector D63 terminal 4, 5.


67 (L) – 5 (Y) : Continuity should exist.
77 (L) – 4 (BR) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 67, 77 and ground.

67 (L) – Ground : Continuity should not exist.
77 (L) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
 NG >> Repair or replace harness.




POWER DOOR LOCK — SUPER LOCK —

REAR RH SIDE

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect rear door lock actuator RH connector.
3. Door lock / unlock switch operate, check voltage between rear door lock actuator RH connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D83	2 (Y)	Ground	Unlock	0 → Battery voltage → 0
	3 (L)		Lock	0 → Battery voltage → 0



OK or NG

OK >> Replace rear door lock actuator RH.
NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 67, 77 and rear door lock actuator RH connector D83 terminal 2, 3.


67 (L) – 2 (Y) : Continuity should exist.
77 (L) – 3 (L) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 67, 77 and ground.

67 (L) – Ground : Continuity should not exist.
77 (L) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.



POWER DOOR LOCK — SUPER LOCK —


Super Lock Actuator Check DRIVER SIDE

EIS00AQ6

1. CHECK SUPER LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect front door lock actuator (driver side) connector.
3. Door lock / unlock switch operate, check voltage between front door lock actuator (driver side) connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D9	1 (OR)	Ground	Lock button is pressed.	0 → Battery voltage → 0



OK or NG

OK >> Replace front door lock actuator (driver side).
 NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 75 and front door lock actuator (driver side) connector D9 terminal 1.


75 (R) – 1 (OR) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 75 and ground.

75 (R) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
 NG >> Repair or replace harness.




POWER DOOR LOCK — SUPER LOCK —

PASSENGER SIDE

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect front door lock actuator (passenger side) connector.
3. Remote controller operate, check voltage between front door lock actuator (passenger side) connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D38	6 (G)	Ground	Lock button is pressed.	0 → Battery voltage → 0



OK or NG

OK >> Replace front door lock actuator (passenger side).
NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 75 and front door lock actuator (passenger side) connector D38 terminal 6.


75 (R) – 6 (G) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 75 and ground.

75 (R) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.




POWER DOOR LOCK — SUPER LOCK —

REAR LH SIDE

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect rear door lock actuator LH connector.
3. Remote controller operate, check voltage between rear door lock actuator LH connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D63	6 (L)	Ground	Lock button is pressed.	0 → Battery voltage → 0



OK or NG

OK >> Replace rear door lock actuator LH.
NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 75 and rear door lock actuator LH connector D63 terminal 6.


75 (R) – 6 (L) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 75 and ground.

75 (R) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.




POWER DOOR LOCK — SUPER LOCK —

REAR RH SIDE

1. CHECK DOOR LOCK ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect rear door lock actuator RH connector.
3. Remote controller operate, check voltage between rear door lock actuator RH connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D83	1 (R)	Ground	Lock button is pressed.	0 → Battery voltage → 0



OK or NG

OK >> Replace rear door lock actuator RH.
NG >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 75 and rear door lock actuator RH connector D83 terminal 1.


75 (R) – 1 (R) : Continuity should exist.

3. Check continuity between BCM connector M50 terminal 75 and ground.

75 (R) – Ground : Continuity should not exist.

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Repair or replace harness.



POWER DOOR LOCK — SUPER LOCK —

Door Switch Check DRIVER SIDE


EIS00AQ7

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT- II

Check door switch "DOOR SW-DR" in "DATA MONITOR" mode with CONSULT- II.

Monitor item	Condition
DOOR SW-DR	OPEN : ON
	CLOSE : OFF




Without CONSULT- II

Check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	29 (L)	Ground	OPEN	0
			CLOSE	Battery voltage

OK or NG

OK >> Front door switch RH is OK.
NG >> GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and front door switch RH connector.
3. Check continuity between BCM connector M48 terminal 29 and front door switch RH connector B16 terminal 1.


29 (L) – 1 (L) : Continuity should exist.

4. Check continuity between BCM connector M48 terminal 29 and ground.

29 (L) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.
NG >> Repair or replace harness.



POWER DOOR LOCK — SUPER LOCK —


3. CHECK DOOR SWITCH

Check continuity between door switch terminal 1 and body ground part of door switch.

Terminals		Condition	Continuity
1	Body ground part of door switch	Pushed	NO
		Released	YES

OK or NG

OK >> GO TO 4.
NG >> Replace door switch.



4. CHECK BCM OUTPUT SIGNAL


1. Connect BCM connector.
2. Check voltage between BCM connector M48 terminal 29 and ground.

Driver side door is closed.

29 (L) – Ground : Battery voltage

OK or NG

OK >> Check door switch ground condition.
NG >> Replace BCM.



POWER DOOR LOCK — SUPER LOCK —


PASSENGER SIDE

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT- II

Check door switch "DOOR SW-AS" in "DATA MONITOR" mode with CONSULT- II.

Monitor item	Condition	
DOOR SW-AS	OPEN	: ON
	CLOSE	: OFF



Without CONSULT- II


Check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	30 (LG)	Ground	OPEN	0
			CLOSE	Battery voltage

OK or NG

OK >> Front door switch LH is OK.

NG >> GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and front door switch LH connector.
3. Check continuity between BCM connector M48 terminal 30 and front door switch LH connector B22 terminal 1.

30 (LG) – 1 (LG) : Continuity should exist.


4. Check continuity between BCM connector M48 terminal 29 and ground.

30 (LG) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



POWER DOOR LOCK — SUPER LOCK —


3. CHECK DOOR SWITCH

Check continuity between door switch terminal 1 and body ground part of door switch.

Terminals		Condition	Continuity
1	Body ground part of door switch	Pushed	NO
		Released	YES

OK or NG

OK >> GO TO 4.
NG >> Replace door switch.



4. CHECK BCM OUTPUT SIGNAL


1. Connect BCM connector.
2. Check voltage between BCM connector M48 terminal 30 and ground.

Passenger side door is closed.

30 (LG) – Ground : Battery voltage

OK or NG

OK >> Check door switch ground condition.
NG >> Replace BCM.



POWER DOOR LOCK — SUPER LOCK —


REAR LH SIDE

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT- II

Check door switch "DOOR SW-RL" in "DATA MONITOR" mode with CONSULT- II.

Monitor item	Condition	
DOOR SW-RL	OPEN	: ON
	CLOSE	: OFF




Without CONSULT- II

Check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M49	59 (L)	Ground	OPEN	0
			CLOSE	Battery voltage

OK or NG

OK >> Rear door switch LH is OK.
NG >> GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and rear door switch LH connector.
3. Check continuity between BCM connector M49 terminal 59 and rear door switch LH connector B31 terminal 1.


59 (L) – 1 (L) : Continuity should exist.

4. Check continuity between BCM connector M49 terminal 59 and ground.

59 (L) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.
NG >> Repair or replace harness.



POWER DOOR LOCK — SUPER LOCK —


3. CHECK DOOR SWITCH

Check continuity between door switch terminal 1 and body ground part of door switch.

Terminals		Condition	Continuity
1	Body ground part of door switch	Pushed	NO
		Released	YES

OK or NG

OK >> GO TO 4.
NG >> Replace door switch.



4. CHECK BCM OUTPUT SIGNAL


1. Connect BCM connector.
2. Check voltage between BCM connector M49 terminal 59 and ground.

Rear LH door is closed.

59 (L) – Ground : Battery voltage

OK or NG

OK >> Check door switch ground condition.
NG >> Replace BCM.



POWER DOOR LOCK — SUPER LOCK —


REAR RH SIDE

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT- II

Check door switch "DOOR SW-RR" in "DATA MONITOR" mode with CONSULT- II.

Monitor item	Condition	
DOOR SW-RR	OPEN	: ON
	CLOSE	: OFF



Without CONSULT- II


Check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M49	60 (G)	Ground	OPEN	0
			CLOSE	Battery voltage

OK or NG

OK >> Rear door switch RH is OK.

NG >> GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and rear door switch RH connector.
3. Check continuity between BCM connector M49 terminal 60 and rear door switch RH connector B30 terminal 1.

60 (G) – 1 (G) : Continuity should exist.


4. Check continuity between BCM connector M49 terminal 60 and ground.

60 (G) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



POWER DOOR LOCK — SUPER LOCK —

3. CHECK DOOR SWITCH


Check continuity between door switch terminal 1 and body ground part of door switch.

Terminals		Condition	Continuity
1	Body ground part of door switch	Pushed	NO
		Released	YES

OK or NG

OK >> GO TO 4.

NG >> Replace door switch.



4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM connector M49 terminal 60 and ground.


Rear RH door is closed.

60 (G) – Ground : Battery voltage

OK or NG

OK >> Check door switch ground condition.

NG >> Replace BCM.



POWER DOOR LOCK — SUPER LOCK —

External Back Door Release Switch Check

EIS00AQ8

1. CHECK EXTERNAL BACK DOOR RELEASE SWITCH INPUT SIGNAL

With CONSULT- II


Check external back door release switch "TRNK OPNR SW" in "DATA MONITOR" mode with CONSULT- II.

External back door release switch is pushed

TRNK OPNR SW : ON

External back door release switch is released

TRNK OPNR SW : OFF



Without CONSULT- II


Check voltage between BCM connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M48	5 (Y)	Ground	Pushed	0
			Released	5

OK or NG

OK >> External back door release switch is OK.

NG >> GO TO 2.



2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and external back door release switch connector.
3. Check continuity between BCM connector M48 terminal 5 and external back door release switch connector B52 terminal.

5 (Y) – 1 (Y) : Continuity should exist.


4. Check continuity between BCM connector M48 terminal 5 and ground.

5 (Y) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



POWER DOOR LOCK — SUPER LOCK —


3. CHECK EXTERNAL BACK DOOR RELEASE SWITCH

Check continuity between external back door release switch terminal 1 and 2.

Terminals		Condition	Continuity
1	2	Pushed	YES
		Released	NO

OK or NG

OK >> GO TO 4.
NG >> Replace external back door release switch.




4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM connector M48 terminal 5 and ground.

5 (Y) – Ground : Approx. 5V

OK or NG

OK >> Check the condition of the harness and the connector.
NG >> Replace BCM.



POWER DOOR LOCK — SUPER LOCK —

Back Door Release Actuator Check

EIS00AQ9

1. CHECK BCM OUTPUT SIGNAL

Check back door release output signal

Perform ("TRUNK/BACK DOOR") in "ACTIVE TEST" mode with CONSULT-III.

When “ACTIVE TEST” is executed, does the back door open?

OK or NG

OK >> Back door release output is OK.
NG >> GO TO 2.

ACTIVE TEST	
TRUNK/BACK DOOR	OFF
ON	


2. CHECK BACK DOOR RELEASE ACTUATOR

1. Turn ignition switch OFF.
2. Disconnect back door release actuator connector.
3. External back door release switch operate, check voltage between back door release actuator connector and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
B55	3 (OR)	Ground	Pushed	0 → Battery voltage → 0

OK or NG

OK >> GO TO 4.
NG >> GO TO 3.



3. CHECK HARNESS CONTINUITY

1. Disconnect BCM connector.
2. Check continuity between BCM connector M50 terminal 68 and back door release actuator connector B55 terminal 3.

68 (OR) – 3 (OR) : Continuity should exist.


3. Check continuity between BCM connector M50 terminal 68 and ground.

68 (OR) – Ground : Continuity should not exist.

OK or NG

OK >> Replace BCM.

NG >> Repair or replace harness.



POWER DOOR LOCK — SUPER LOCK —

4. CHECK GROUND CIRCUIT


Check continuity between back door release actuator connector B55 terminal 4 and ground.

4 (B) – Ground

: Continuity should exist.

OK or NG

OK >> Replace back door release actuator.
NG >> Repair or replace harness.



MULTI-REMOTE CONTROL SYSTEM


MULTI-REMOTE CONTROL SYSTEM

PFP:28596

Component Parts and Harness Connector Location

EIS004Y9

A
B
C
D
E
F
G
H
BL
J
K
L
M



MIIIB0307E

MULTI-REMOTE CONTROL SYSTEM

System Description

INPUTS

EIS004YA

Power is supplied at all times

- to BCM terminals 74 and 79
- through 40A fusible link (letter J, located in the fusible link box).
- to key switch terminal 1
- through 10A fuse [No. 6, located in the fuse block (J/B)].

When the key switch is ON (Ignition key is inserted in ignition key cylinder), power is supplied

- to BCM terminal 3.
- through key switch terminal 2

When the ignition switch is ON or START, power is supplied

- to BCM terminal 24
- through 10A fuse [No. 4, located in the fuse block (J/B)].

Ground is supplied

- to BCM terminals 2 and 70
- through body grounds M19 and M20.

When the front door switch LH (LHD Models) or RH (RHD Models) is ON (door is open), ground supplied

- to BCM terminal 29
- through front door switch LH (LHD Models) or RH (RHD Models) terminal 1
- through front door switch LH (LHD Models) or RH (RHD Models) case ground.

When the front door switch RH (LHD Models) or LH (RHD Models) is ON (door is open), ground supplied

- to BCM terminal 30
- through front door switch RH (LHD Models) or LH (RHD Models) terminal 1
- through front door switch RH (LHD Models) or LH (RHD Models) case ground.

When the rear door switch LH is ON (door is open), ground is supplied

- to BCM terminal 59
- through rear door switch LH terminal 1
- through rear door switch LH case ground.

When the rear door switch RH is ON (door is open), ground is supplied

- to BCM terminal 60
- through rear door switch RH terminal 1
- through rear door switch RH case ground.

When the back door switch is ON (back door is open), ground is supplied

- to BCM terminal 10
- through back door switch terminals 1 and 2
- through body grounds B17, B23, B44 and B51.

Remote controller signal is inputted to BCM (The antenna of the system is combined with BCM).

OPERATE

The multi-remote control system controls operation of the

- power door lock
- answer back
- auto door lock

OPERATED PROCEDURE

Power Door Lock Operation

NORMAL MODE

BCM receives a LOCK/UNLOCK signal from remote controller.

Then BCM locks/unlocks all doors with input of LOCK/UNLOCK signal from remote controller.

ANTI HI-JACK MODE

BCM receives a LOCK signal from remote controller.

MULTI-REMOTE CONTROL SYSTEM

Then BCM locks all doors with input of LOCK signal from remote controller.

When an UNLOCK signal is sent from remote controller once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from remote controller again within 5 seconds, all door will be unlocked.

HOW TO CHANGE DOOR LOCK FUNCTION MODE

With CONSULT-II

Door lock function can be changed using "SECURITY DOOR LOCK SET" mode in "WORK SUPPORT" of "DOOR LOCK".

Refer to [BL-46, "WORK SUPPORT"](#).

Without CONSULT-II

When LOCK and UNLOCK signals are sent from the remote controller for more than 5 seconds at the same time, the lock function mode is changed.

Answer Back

When the doors are locked or unlocked by remote controller, supply power to hazard warning lamp flashes as follows

- LOCK operation: Flash once
- UNLOCK operation: Flash twice

Answer back mode can be changed using "HAZARD LAMP SET" mode in "WORK SUPPORT" of "FLUSHER".

Refer to [LT-145, "WORK SUPPORT"](#).

Auto Door Lock Operation

Auto door lock function signal is sent for operation when any of the following signals are not sent within 2 minutes after the unlock signal is sent from remote controller:

- when door switch is turned on for door open.
- when key switch is turned on.
- when the lock signal is sent from the remote controller.

Auto door lock mode can be changed using "AUTO LOCK SET" mode in "WORK SUPPORT" of "DOOR LOCK".

Refer to [BL-46, "WORK SUPPORT"](#).

Remote Controller ID Code Entry

A maximum of four remote controller can be entered.

Dedicated remote controller ID registration procedure is not required.


Remote controller ID registration must be completed in conjunction with immobilizer transponder ID registration.

MULTI-REMOTE CONTROL SYSTEM

Schematic

EIS004YB

- (L) : LHD models
- (R) : RHD models
- (5D) : With 5 doors





MKWA1791E

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI —

EIS004YC

BL-MULTI-01



REFER TO THE FOLLOWING.

(M1) -SUPER MULTIPLE


JUNCTION (SMJ)

(M16) -FUSE BLOCK-

JUNCTION BOX (J/B)

MULTI-REMOTE CONTROL SYSTEM

BL-MULTI-02







MKWA0890E

MULTI-REMOTE CONTROL SYSTEM

BL-MULTI-03

(L) : LHD MODELS
(R) : RHD MODELS

A
B
C
D
E
F
G
H
BL
J
K
L
M





MKWA0891E

MULTI-REMOTE CONTROL SYSTEM

BL-MULTI-04

 : RHD MODELS



MKWA0892E

MULTI-REMOTE CONTROL SYSTEM

Terminal and Reference Value for BCM

EIS004YD

TER-MINAL	WIRE COLOR	ITEM	CONDITION	VOLTAGE (V) Approx.
2	B	Ground	—	0
3	OR	Key switch	Key is removed from IGN key cylinder (OFF) → Key is inserted in IGN key cylinder (ON)	0 → Battery voltage
10	OR	Back door switch	Back door open (ON) → Back door close (OFF)	0 → Battery voltage
19	R	CAN-H	—	—
24	OR	IGN power supply	Ignition switch is in ON or START position	Battery voltage
29	L	Front door switch LH (LHD models)	Door open (ON) → Door close (OFF)	0 → Battery voltage
		Front door switch RH (RHD models)		
30	LG	Front door switch RH (LHD models)	Door open (ON) → Door close (OFF)	0 → Battery voltage
		Front door switch LH (RHD models)		
39	W	CAN-L	—	—
59	L	Rear door switch LH	Door open (ON) → Door close (OFF)	0 → Battery voltage
60	G	Rear door switch RH	Door open (ON) → Door close (OFF)	0 → Battery voltage
65	P	Answer back (Turn signal lamp LH)	When door lock operated using remote controller* ¹	(V) 15 10 5 0 0.5s PIIA2486J
			When door unlock operated using remote controller* ¹	(V) 15 10 5 0 0.5s PIIA2487J
66	R	Answer back (Turn signal lamp RH)	When door lock operated using remote controller* ¹	(V) 15 10 5 0 0.5s PIIA2486J
			When door unlock operated using remote controller* ¹	(V) 15 10 5 0 0.5s PIIA2487J
67	L	Door lock actuator unlock (ALL Door) (Except driver side)	Door lock/unlock switch UNLOCK operation	0 → Battery voltage

A
B
C
D
E
F
G
H
BL
J
K
L
M

MULTI-REMOTE CONTROL SYSTEM

TER-MINAL	WIRE COLOR	ITEM	CONDITION	VOLTAGE (V) Approx.
68	OR	Back door opener actuator	Power window main switch (Back door release switch) OPEN operation	Battery voltage → 0
70	B	Ground	—	0
74	W	BAT power supply (fusible link) (BCM)	—	Battery voltage
75* ²	R	Super lock set output (All door)	Super lock operation (Set)	0 → Battery voltage
76	BR	Door lock actuator unlock (Driver side)	Door lock/unlock switch Unlock operation	0 → Battery voltage
77	L	Door lock actuator lock (ALL Door)	Door lock/unlock switch LOCK operation	0 → Battery voltage
79	Y	BAT power supply (fusible link) (Power window)	—	Battery voltage

*¹ : In the state that answer back operates

*² : Only the model equipped with super lock system (RHD Models)


CONSULT-II Inspection Procedure

EIS004YE


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START(NISSAN BASED VHCL)".




5. Touch "BCM".

If "BCM" is not indicated, Refer to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).




MULTI-REMOTE CONTROL SYSTEM

6. Touch "MULTI REMOTE ENT".



7. Select diagnosis mode.
"DATA MONITOR" is available.



CONSULT-II Application Items

DATA MONITOR

EIS004YF

A
B
C
D
E
F
G
H

BL
J
K
L
M

Monitored Item	Description
MEMORY 1	Indicates [ON/OFF] condition of remote controller ID code registration.
MEMORY 2	Indicates [ON/OFF] condition of remote controller ID code registration.
MEMORY 3	Indicates [ON/OFF] condition of remote controller ID code registration.
MEMORY 4	Indicates [ON/OFF] condition of remote controller ID code registration.

Work Flow

EIS0055G

K
L
M

1. Check the trouble symptom and customer's requests.
2. Understand outline of system. Refer to [BL-132, "System Description"](#) .
3. Confirm that power door lock system operates normally.
Refer to [BL-15, "POWER DOOR LOCK SYSTEM"](#) .
4. Refer to trouble diagnosis chart by symptom, repair or replace any malfunctioning parts.
5. INSPECTION END

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnosis Chart by Symptom

EIS004YG

First perform the "SELF-DIAG RESULTS" in "BCM" with CONSULT-II, when perform the each trouble diagnosis. Refer to [BCS-31, "CAN Communication Inspection With CONSULT-II \(Self-Diagnosis\)"](#) .

NOTE:

- Always check "Work Flow" before troubleshooting. Refer to [BL-141, "Work Flow"](#) .
- Always check remote controller battery before replacing remote controller.

Symptom	Diagnoses/service procedure	Reference page
All function of multi-remote control system do not operate.	1. Remote controller check 2. Replace remote controller. NOTE: If the result of remote controller function check with CONSULT-II is OK, remote controller is not malfunction.	BL-143 BL-133 BCS-31
Door lock or unlock does not function with remote controller. (Power door lock system is "OK")	1. Remote controller check 2. Key switch check 3. Replace remote controller. NOTE: If the result of remote controller function check with CONSULT-II is OK, remote controller is not malfunction.	BL-143 BL-148 BL-133 BCS-31
Answer back does not activate properly when pressing lock or unlock button of remote controller.	1. Check answer back mode.* *: Answer back mode can be changed. First check the hazard reminder setting. 2. Hazard reminder check 3. Replace BCM.	LT-145 BL-150 BCS-31
Auto door lock operation does not activate properly. (All other remote keyless entry system function is "OK".)	1. Check auto door lock operation mode.* *: Auto door lock operation can be changed. First check the auto door lock operation setting. 2. Door switch check 3. Replace BCM.	BL-46 BL-143 BCS-31

MULTI-REMOTE CONTROL SYSTEM

Remote controller Check

EIS004YH


1. CHECK REMOTE CONTROLLER BATTERY

Remove battery and measure voltage across battery positive and negative terminals, (+) and (-).

Battery voltage : 2.5V – 3.0V

NOTE:

Remote controller does not function if battery is not set correctly.



SEL237W

OK or NG

OK >> GO TO 2

NG >> Replace battery. Refer to [BL-151, "Remote Controller Battery Replacement"](#) .

2. CHECK REMOTE CONTROLLER FUNCTION

With CONSULT-II

Check remote controller function.

Remote controller function	Check item
Pushing LOCK button	All of doors are locked
Pushing UNLOCK button	All of doors are unlocked

OK or NG

OK >> Remote controller is OK.

NG >> Replace remote controller.

Door Switch Check

EIS0054Y

DOOR SWITCH DRIVER SIDE

1. CHECK DOOR SWITCH INPUT SIGNAL


1. Turn ignition switch OFF.
2. Check voltage between BCM connector M48 terminal 29 and ground.

Terminal		Driver door condition	Voltage (V) Approx.
(+)	(-)		
29 (L)	Ground	Closed	5
		Open	0

OK or NG

OK >> Door switch circuit is OK.

NG >> GO TO 2.



MULTI-REMOTE CONTROL SYSTEM

2. CHECK DOOR SWITCH HARNESS

- Check continuity between BCM connector M48 terminal 29 and driver door switch connector B22(LHD Models) or B16 (RHD Models) terminal 1.

Terminal	Continuity
LHD Models 29 (L) - 1 (LG)	Yes
RHD Models 29 (L) - 1 (L)	


- Check continuity between BCM connector M48 terminal 29 and ground.

29 (L) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



3. CHECK DOOR SWITCH


Check continuity between driver door switch terminal 1 and ground part of door switch.

Terminal	Driver door switch condition	Continuity
1 - Ground part of door switch	Pushed	No
	Released	Yes

OK or NG

OK >> Check driver door switch ground condition.

NG >> Replace driver door switch.



DOOR SWITCH PASSENGER SIDE

1. CHECK DOOR SWITCH INPUT SIGNAL


- Turn ignition switch OFF.
- Check voltage between BCM connector M48 terminal 30 and ground.

Terminal		Passenger door condition	Voltage (V) Approx.
(+)	(-)		
30 (LG)	Ground	Closed	5
		Open	0

OK or NG

OK >> Door switch circuit is OK.

NG >> GO TO 2



MULTI-REMOTE CONTROL SYSTEM

2. CHECK DOOR SWITCH HARNESS

- Check continuity between BCM connector M48 terminal 30 and passenger door switch connector B16(LHD Models) or B22(RHD Models) terminal 1.

Terminal	Continuity
LHD Models 30 (LG) - 1 (L)	Yes
RHD Models 30 (LG) - 1 (LG)	


- Check continuity between BCM connector M48 terminal 30 and ground.

30 (LG) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



3. CHECK DOOR SWITCH


Check continuity between passenger door switch terminal 1 and ground part of door switch.

Terminal	Passenger door switch condition	Continuity
1 - Ground part of door switch	Pushed	No
	Released	Yes

OK or NG

OK >> Check passenger door switch ground condition.

NG >> Replace passenger door switch.



DOOR SWITCH REAR LH

1. CHECK DOOR SWITCH INPUT SIGNAL


- Turn ignition switch OFF.
- Check voltage between BCM connector M49 terminal 59 and ground.

Terminal		Rear door LH condition	Voltage (V) Approx.
(+)	(-)		
59 (L)	Ground	Closed	5
		Open	0

OK or NG

OK >> Door switch circuit is OK.

NG >> GO TO 2



MULTI-REMOTE CONTROL SYSTEM

2. CHECK DOOR SWITCH HARNESS

1. Check continuity between BCM connector M49 terminal 59 and rear door switch LH connector B31 terminal 1.

59 (L) – 1 (L) : Continuity should exist.


2. Check continuity between BCM connector M49 terminal 59 and ground

59 (L) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



3. CHECK DOOR SWITCH


Check continuity between rear door switch LH terminal 1 and ground part of door switch.

Terminal	Rear door switch LH condition	Continuity
1 - Ground part of door switch	Pushed	No
	Released	Yes

OK or NG

OK >> Check rear door switch LH ground condition.

NG >> Replace rear door switch LH.



DOOR SWITCH REAR RH

1. CHECK DOOR SWITCH INPUT SIGNAL


1. Turn ignition switch OFF.
2. Check voltage between BCM connector M49 terminal 60 and ground.

Terminal		Rear door RH condition	Voltage (V) Approx.
(+)	(-)		
60 (G)	Ground	Closed	5
		Open	0

OK or NG

OK >> Door switch circuit is OK.

NG >> GO TO 2



2. CHECK DOOR SWITCH HARNESS

1. Check continuity between BCM connector M49 terminal 60 and rear door switch LH connector B31 terminal 1.

60 (G) – 1 (G) : Continuity should exist.


2. Check continuity between BCM connector M49 terminal 60 and ground

60 (G) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



MULTI-REMOTE CONTROL SYSTEM


3. CHECK DOOR SWITCH

Check continuity between rear door switch RH terminal 1 and ground part of door switch.

Terminal	Rear door switch RH condition	Continuity
1 - Ground part of door switch	Pushed	No
	Released	Yes

OK or NG

OK >> Check rear door switch RH ground condition.
 NG >> Replace rear door switch RH.



BACK DOOR SWITCH


1. CHECK BACK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between BCM connector M48 terminal 10 and ground.

Terminal		Back door condition	Voltage (V) Approx.
(+)	(-)		
10 (OR)	Ground	Closed	5
		Open	0

OK or NG


OK >> Back door switch circuit is OK.
 NG >> GO TO 2



2. CHECK BACK DOOR SWITCH HARNESS

1. Disconnect back door switch connector.
2. Check voltage between back door switch connector B55 terminal 1 and ground. (Check harness for open.)

1 (OR) – Ground : Battery voltage




3. Disconnect BCM connector.
4. Check continuity between back door switch connector B55 terminal 1 and ground. (Check harness for short.)

1 (OR) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.
 NG >> Repair or replace harness.



MULTI-REMOTE CONTROL SYSTEM

3. CHECK BACK DOOR SWITCH


Check continuity between back door switch terminal 1 and 2.

Terminal	Rear door condition	Continuity
1 - 2	Closed	No
	Opened	Yes

OK or NG

OK >> GO TO 4.

NG >> Replace back door release actuator (back door switch).



4. CHECK BACK DOOR SWITCH GROUND HARNESS


Check continuity between back door switch connector B55 terminal 2 and ground.

2 (B) – Ground : Continuity should not exist.

OK or NG

OK >> Check harness connection.

NG >> Replace back door switch.



Key Switch Check

EIS0054Z

1. CHECK KEY SWITCH INPUT SIGNAL


Check voltage between BCM connector M48 terminal 3 and ground.

Terminals		Key switch condition	Voltage (V) Approx.
(+)	(-)		
3 (OR)	Ground	Key is inserted in IGN key cylinder (key switch is "ON".)	Battery voltage
		Key is removed from IGN key cylinder (Key switch is "OFF".)	0

OK or NG

OK >> Key switch circuit is OK.

NG >> GO TO 2



MULTI-REMOTE CONTROL SYSTEM

2. CHECK KEY SWITCH (INSERT)

1. Disconnect key switch connector.
2. Check continuity between key switch terminals 1 and 2.


Terminals	Key switch condition	Continuity
1 – 2	Key is inserted in IGN key cylinder (Key switch is "ON".)	Yes
	Key is removed from IGN key cylinder (Key switch is "OFF".)	No

OK or NG

OK >> Check the following.

- 10A fuse [No. 6, located in fuse block (J/B)]
- Harness for open or short between key switch and fuse
- Harness for open or short between BCM and key switch

NG >> Replace key switch.



A
B
C
D
E
F
G
H
BL
J
K
L
M

MULTI-REMOTE CONTROL SYSTEM

Hazard Reminder Check

EIS004YL

1. CHECK HAZARD WARNING LAMP

Check if hazard warning lamp flashes with hazard switch.

Does hazard warning lamp operate?



Yes >> GO TO 2

No >> Check hazard warning lamp circuit. Refer to [LT-121, "TURN SIGNAL AND HAZARD WARNING LAMPS"](#).

2. CHECK HAZARD REMINDER OPERATION

Check the following at when push the remote controller switch.


Check voltage between smart entrance control unit harness connector M43 terminal 65, 66 and ground.

Remote controller	Voltage (V) Approx.
Pushing LOCK button	 PIIA2486J
Pushing UNLOCK button	 PIIA2487J

OK or NG

OK >> Check harness for open between BCM and hazard switch.

NG >> Check harness for short between BCM and hazard switch. If check result is "OK", replace BCM. If check result is "NG", repair or replace harness.



MULTI-REMOTE CONTROL SYSTEM

Remote Controller Battery Replacement

EIS004YN

1. Remove installation screw on the rear of remote controller.
2. Place the key with the lower case facing up. Set a screwdriver wrapped with tape into section A of the lower case and separate the lower case from the upper case.
3. When replacing the circuit board assembly, remove circuit board assembly from the upper case.
(Circuit board assembly: Switch rubber + Board surface)
4. When replacing the battery
Remove battery from the lower case and replace it.

Battery replacement : Coin-type lithium battery (CR1620)


CAUTION:

When replacing battery, be sure to keep dirt, grease and other foreign materials off the electrode contact area.

5. After replacement, fit the lower and upper cases together, part and tighten with the screw.

CAUTION:

After replacing the battery, be sure to check that door locking operates normally using the remote controller.



A
B
C
D
E
F
G
H

BL

J
K
L
M


INTELLIGENT KEY SYSTEM

INTELLIGENT KEY SYSTEM

PFP:285e2




Component Parts and Harness Connector Location

EIS00563




MIIIB0723E

INTELLIGENT KEY SYSTEM



Intelligent Key



MIIIB0301E

BL

EIS004MH

System Description

- The Intelligent Key system is a system that makes it possible to lock and unlock the door locks (door lock function) and start the engine (engine start function) by carrying around the Intelligent Key, which operates based on the results of electrical key-ID verification using two-way communications between the Intelligent Key and the vehicle
- Operation of the remote control buttons on the Intelligent Key also provides the same functions as the remote control entry system. (Remote control entry functions)
- As an ignition key warning function, when a door lock is locked or unlocked with entry switch or remote controller button operation, the hazard lamps flash and the Intelligent Key warning buzzer sounds.
- Even if the vehicle or Intelligent Key battery runs down, the door locks can be locked and unlocked and the engine started with the mechanical key built into the Intelligent Key.
- If an Intelligent Key is lost, a new Intelligent Key can be registered. A maximum of 4 Intelligent Keys can be registered.
- It has been made possible to diagnose the system, change the function setting and register an Intelligent Key with the CONSULT-II.

DOOR LOCK FUNCTION

Operation Description

- When the driver door, passenger door, or back door request switch is pressed, Intelligent Key unit sends a request signal from the transmission antenna corresponding to the pressed door request switch, key-ID verification is performed using two-way communication with Intelligent Key, and if ID is successfully verified, a door lock/unlock request signal is sent to BCM (Body Control Module) using CAN communication to lock/unlock the door lock.
- When door is locking, door is unlocked, when door is unlocking, door is locked.
- When door lock is locked/unlocked by door request switch operation, hazard lamps flash and Intelligent Key warning buzzer sounds.
- With the locking operation of door request switch, door lock actuators of all door are locked.

Driver side door request switch operation

- When door request switch (driver side) is pushed (unlock), driver side door lock actuator is unlocked.

A

B

C

D

E

F

G

H

J

K

L

M

INTELLIGENT KEY SYSTEM

- When door request switch (driver side) is pushed (unlock) for the second time within 5 seconds after the first operation, door lock actuators on passenger's and other's doors are unlocked.
- Unlock mode can be changed using "WORK SUPPORT" mode in "DOOR LOCK-UNLOCK SET". Refer to [BL-185, "CONSULT-II Function \(INTELLIGENT KEY\)"](#).

Passenger side door request switch operation

- When door request switch (passenger side) is pushed (unlock), passenger side door lock actuator is unlocked.
- When door request switch (passenger side) is pushed (unlock) for the second time within 5 seconds after the first operation, door lock actuators on driver's and other's doors are unlocked.
- Unlock mode can be changed using "WORK SUPPORT" mode in "DOOR LOCK-UNLOCK SET". Refer to [BL-185, "CONSULT-II Function \(INTELLIGENT KEY\)"](#).

Operation Condition

Request switch operation	Operating conditions (When all the conditions below are met)
Door request switch (Driver side)	<ul style="list-style-type: none">Closing all doors (door switch: OFF)
Door request switch (passenger side)	<ul style="list-style-type: none">Key switch OFF (key removed)Ignition knob switch: OFF (ignition knob switch not pressed)
Door request switch (back door)	<ul style="list-style-type: none">The Intelligent Key is in the antenna detection area for the door for which the door request switch was operated.

Operation Range

The antenna detection area for each door is about 80 cm (31.50 in) from the handle of each door (driver door, passenger door and back door). However, this operating range depends on the ambient conditions.

Auto Door Lock Function

After the door request switch in the driver or passenger or back door is operated and the vehicle door locks are unlocked, all the doors are automatically locked unless the mechanical key is inserted into the ignition knob, the ignition knob is pressed, any one of the doors is opened, or an Intelligent Key remote control button is operated within 30 seconds.

Key Reminder Function

Number of times the hazard lamps are flashed and the Intelligent Key warning buzzer buzzed when the door lock is locked or unlocked by door request switch operation.

Vehicle operation	Hazard lamp	Intelligent Key warning buzzer
Door unlock operation	Twice	Twice
Door lock operation	Once	Once

Intelligent Key Lock-in Prevention Function

When Intelligent Key is in vehicle, a door is open, and doors are locked using door lock and unlock switch, driver door lock knob, or door request switch, Intelligent Key unit sends door unlock request signal to BCM via CAN communication to unlock all doors to prevent Intelligent Key from becoming locked in vehicle.

CAUTION:

The above function operates when the Intelligent Key is inside the vehicle. However, there may be times when Intelligent Key cannot be detected and this function will not operate when Intelligent Key is on the instrument panel, rear parcel shelf, or in the glove box. Also, this system sometimes does not operate if the Intelligent Key is in the door pocket for the open door.

REMOTE CONTROL ENTRY FUNCTIONS

Door Lock Function

- Operating a remote controller button on the Intelligent Key sends the Intelligent Key-ID to the Intelligent Key unit. Intelligent Key unit conducts a verification of the received key-ID, and if the verification is accepted, a door lock or door unlock request signal is sent to BCM via CAN communication to lock/unlock the door lock.
- When door lock/unlock is performed using Intelligent Key remote controller button operation, operation confirmation is conducted by making hazard lamps flash and Intelligent Key warning buzzer sound.

OPERATION CONDITION

INTELLIGENT KEY SYSTEM

Remote control operation	Operation condition
Door lock operation	<ul style="list-style-type: none"> • All doors closed • Key switch OFF (key removed) • Ignition knob switch: OFF (ignition knob not pressed)
Door unlock operation	<ul style="list-style-type: none"> • Key switch OFF (key removed) • Ignition knob switch: OFF (ignition knob not pressed)

Map Lamp And Keyhole Illumination Function

When the following conditions come:

- condition of map lamp switch is DOOR position;
- door switch OFF (when all the doors are closed);

Remote keyless entry system turns on interior lamp (for 30 seconds) with input of UNLOCK signal from Intelligent Key.

For detailed description, refer to [LT-200, "INTERIOR ROOM LAMP"](#) .

Key Reminder Function

As an operation verification function, when door locks are locked or unlocked using Intelligent Key remote controller button operation, hazard lamps flash and Intelligent Key warning buzzer sounds.

Vehicle operation	Hazard lamp	Intelligent Key warning buzzer
Door unlocking operation	Twice	Twice
Door locking operation	Once	Once

Operation Range

The range for reliable remote control operation is about 80 cm (31.50 in) from each door handle (driver, passenger, and back door). However, this operating range depends on the ambient conditions.

ENGINE STARTUP FUNCTION

Operation Description

- When ignition knob is pressed, Intelligent Key unit sends request signal from inside key antenna, key-ID verification is conducted with Intelligent Key using two-way communication, and if verification is successful, an ignition rotation prohibition latch release signal is sent to steering lock unit. Steering lock unit releases ignition knob rotation prohibition latch. (Ignition knob can now be turned.)
- When it becomes possible to rotate the ignition knob, "KEY" warning lamp in combination meter lights up green to notify driver that ignition knob can be turned.

NOTE:

When it becomes impossible to rotate the ignition knob, "KEY" warning lamp in combination meter lights up red.

- When key-ID verification is successful and ignition knob switch is in the ON state, Intelligent Key unit uses CAN communication to send engine start permission signal to BCM.
- When BCM receives engine start permission signal, it uses CAN communication to sent starter request signal to IPDM E/R so that the engine will start when ignition knob is rotated to START position.

Operation Range

Engine can be started when Intelligent Key is in vehicle. However, sometimes engine might not start when Intelligent Key is on instrument panel, rear parcel shelf, or in glove box.

NOTE:

Luggage room is not within the operation range, but sometimes it is possible to start the engine from there.

Active Check Function

Confirm whether or not ignition knob can be rotated by checking the color of warning lamp in combination meter.

Condition	Operation
Ignition knob rotation possible	"KEY" warning lamp in combination meter is lit up green.
Ignition knob rotation not possible	"KEY" warning lamp in combination meter is lit up red.

INTELLIGENT KEY SYSTEM

WARNING AND ALARM FUNCTION

Operation Description

The warnings and alarms are as follows and are given to the user as warning information and warnings using combinations of Intelligent Key warning buzzer (in driver door), inside vehicle buzzer (in combination meter), and warning lamps "KEY" and "LOCK."

- Ignition switch return forgotten warning
With the ignition in OFF or ACC position, if the driver door is opened, this warning is issued.
- Key left in ignition warning (when mechanical key used)
With the mechanical key in the ignition knob and the ignition switch is in the OFF, ACC, or LOCK position, if the driver door is opened, this warning is issued.
- Ignition switch OFF position warning (for inside car: when door closed)
This warning is issued when the user forgets to return the ignition knob to the LOCK position.
- Ignition switch OFF position warning (for outside car: when door opened/closed)
This warning is issued when the user leaves the car without returning the ignition knob to the LOCK position.
- Warning for removal of Intelligent Key to outside the car (when door open/closed)
This warning is issued if the Intelligent Key is taken outside the car while the engine is running.
- Warning for removal of Intelligent Key to outside the car (from window)
This warning is issued if the Intelligent Key is taken outside the car through a window while the engine is running.
- Door lock non-operation warning
This warning is issued if the door lock (lock) operation by a door request switch is not effected.
- Intelligent Key low battery warning
This warning is issued when it is detected that the battery in the Intelligent Key has been used up.

Operation Condition

Warning and alarm names	Operating conditions (when all the conditions below are met)
Ignition knob return forgotten warning	<ul style="list-style-type: none">● The ignition switch is in the ACC, OFF, or LOCK position (knob pressed)● The driver door is opened.
Ignition key warning (When mechanical key used)	<ul style="list-style-type: none">● The mechanical key is inserted in the ignition knob (key switch: ON)● The ignition switch is in the ACC, OFF, or LOCK position.● Driver door closed → open
Ignition knob OFF position warning (for inside car: when door closed)	<ul style="list-style-type: none">● The ignition switch is in the OFF or LOCK position (knob pressed)● In the above state, when the ACC switch is changed from ON to OFF and 1 second passes. (However, this warning is not issued if the mechanical key is inserted in the ignition knob.)
Ignition knob OFF position warning (for outside car: when door opened/closed)	<ul style="list-style-type: none">● The ignition switch is in the OFF or LOCK position (knob pressed)● In the above state, when the ACC switch is changed from ON to OFF and 1 second passes. (However, this warning is not issued if the mechanical key is inserted in the ignition knob.)● Driver door open → closed
Warning for take out of Intelligent Key to outside the car (when door open/closed)	<p>When Any of the Following Conditions Are Met</p> <ul style="list-style-type: none">● When the ignition knob is pressed in so that it can be rotated (or has been rotated), if any of the doors has been opened, when all the doors are closed, the Intelligent Key unit compares the key-ID with that of the Intelligent Key using the inside key antenna (center console), if the results of the comparison are NG (the Intelligent Key is not found)● When the ignition knob is pressed in so that it can be rotated (or has been rotated), if any of the doors is open, the Intelligent Key unit compares the key-ID with that of the Intelligent Key every 5 seconds using the inside key antenna (center console), if the results of the comparison are NG (the Intelligent Key is not found) <p>NOTE: However, this warning is not issued if the mechanical key is inserted in the ignition knob.</p>

INTELLIGENT KEY SYSTEM

Warning and alarm names	Operating conditions (when all the conditions below are met)
Warning for take out of Intelligent Key to outside the car (from window)	<p>When the ignition knob is pressed in so that it can be rotated (or has been rotated), if the vehicle speed is no greater than 5 km per hour, the Intelligent Key unit compares the key-ID with that of the Intelligent Key every 30 seconds using the inside key antenna (center console), if the results of the comparison are NG (the Intelligent Key is not found)</p> <p>Note: The factory setting for this function is OFF.</p>
Door lock non-operation warning	<p>When any of the following conditions are met</p> <p>Intelligent Key Lock-in Prevention Warning</p> <ul style="list-style-type: none"> When the Intelligent Key is inside the car and the ignition knob is not pressed, when an attempt is made to lock a door lock with a door request switch <p>NOTE: This warning is issued even if the Intelligent Key is not in the door antenna detection area corresponding to the door request switch was operated.</p> <p>Knob Return Forgotten Warning</p> <ul style="list-style-type: none"> When the ignition knob is pressed, when an attempt is made to lock a door lock with a door request switch <p>NOTE: This warning is only issued if the Intelligent Key is in the door antenna detection area corresponding to the door request switch was operated.</p> <p>Door Ajar Alarm</p> <ul style="list-style-type: none"> When any of the doors is open, when an attempt is made to lock a door lock with a door request switch <p>NOTE: This warning is only issued if the Intelligent Key is in the door antenna detection area corresponding to the door request switch was operated.</p>
Intelligent Key low battery pre-warning	This warning is issued when it is detected that the battery in the Intelligent Key has been used up.

Warning Procedure

Warning and alarm names	Buzzer		Warning lamp	
	Inside car	Outside car	"KEY"	"LOCK"
Ignition switch return forgotten warning	Buzzer: Continuous	—	—	—
Ignition key warning (When mechanical key used)	Buzzer: Continuous	—	—	—
Ignition switch OFF position warning (for inside car: when door closed)	Buzzer (twice)	—	—	Illuminate
Ignition switch OFF position warning (for outside car: when door opened/closed)	—	Buzzer (3 seconds)	—	Illuminate
Warning for removal of Intelligent Key to outside the car (when door open/closed)	—	Buzzer (3 seconds)	Red illuminate	—
Warning for removal of Intelligent Key to outside the car (from window)	Buzzer (3 seconds)	—	Red illuminate	—
Door lock non-operation warning	—	Buzzer (2 seconds)	—	—
Intelligent Key low battery pre-warning	—	—	Green illuminate (30 seconds after ignition switch comes ON)	—

INTELLIGENT KEY SYSTEM

CHANGE SETTINGS FUNCTION

The settings for each function can be changed with the CONSULT-II or Intelligent Key and door request switch operation.

Changing Settings With the Intelligent Key and Door Request Switches

Intelligent Key remote controller button and door request switch operations change the engine startup function settings (startup enabled/disabled) for each Intelligent Key independently.

Settings Change Procedure

1. With the ignition switch is in the LOCK position (ignition knob not pressed), hold down both the LOCK and UNLOCK remote control buttons on the Intelligent Key at the same time for at least 10 seconds (The yard-stick is that the Intelligent Key LED flashes 20 times.)
2. Within 5 seconds of releasing the Intelligent Key remote controller buttons, press the driver door request switch.
3. The KEY warning lamp in combination meter lights up for 3 seconds (engine starting enabled → starting disabled: lights up red, engine starting disabled → flashes green). This completes the settings change.

Changing Settings Using CONSULT-II

The settings for the Intelligent Key system functions can be changed using CONSULT-II (WORK SUPPORT).

NOTE:

Once a function setting is changed, it will remain effective even if the battery is disconnected.

INTELLIGENT KEY REGISTRATION

Intelligent Key-ID registration is executed using the CONSULT-II. Up to 4 can be registered.

CAUTION:

- After a new Intelligent Key-ID is registered, be sure to check the function.
- When registering an additional Intelligent Key-ID, take any Intelligent Keys already registered and Intelligent Keys for any other vehicles out of the vehicle before starting.

CONSULT-II can be used to check and delete Intelligent Key-IDs.

For future information, see the CONSULT-II Operation Manual NATS.

STEERING LOCK UNIT REGISTRATION

Steering Lock Unit ID Registration

CAUTION:

- The method for registering a steering lock unit ID depends on the status of the steering lock unit and Intelligent Key unit (new or old unit).
- After registration is completed, press ignition knob with a portable unit in the vehicle so that it can be rotated, and confirm that it cannot be rotated even when ignition switch is pressed without a portable unit in the vehicle.

For future information, see the CONSULT-II Operation Manual NATS.

INTELLIGENT KEY SYSTEM

CAN Communication SYSTEM DESCRIPTION

EIS00AOS

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EIS00AOT

Go to CAN system, when selecting your car model from the following table.

Body type	3door/5door				
Axle	2WD				
Engine	CR10DE/CR12DE/CR14DE		CR12DE/CR14DE		K9K
Handle	LHD/RHD				
Brake control	ABS system		ESP system		ABS
Transmission	A/T	M/T	A/T	M/T	M/T
Intelligent Key system	Applicable				

CAN communication unit


ECM	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×
Intelligent Key unit	×	×	×	×	×	×	×	×	×	×
Drive computer	×		×		×		×		×	
EPS control unit	×	×	×	×	×	×	×	×	×	×
BCM	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×
TCM	×	×			×	×				
IPDM E/R	×	×	×	×	×	×	×	×	×	×
CAN communication type	BL-160, "TYPE 1"		BL-162, "TYPE 3"		BL-164, "TYPE 5"		BL-167, "TYPE 7"		BL-169, "TYPE 9"	

×: Applicable

INTELLIGENT KEY SYSTEM

TYPE 1

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R		R	R				
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T							R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T							R	
A/T shift position signal		R						T	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T

INTELLIGENT KEY SYSTEM


Signals	ECM	Combi- nation meter.	Intelli- gentKey unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ABS operation signal	R						T		
Brake warning lamp signal		R		R			T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

A
B
C
D
E
F
G
H
BL
J
K
L
M

INTELLIGENT KEY SYSTEM

TYPE 3

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R

INTELLIGENT KEY SYSTEM


Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ABS operation signal	R			R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn-ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

A
 B
 C
 D
 E
 F
 G
 H
 BL
 J
 K
 L
 M

INTELLIGENT KEY SYSTEM

TYPE 5

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Engine speed signal	T	R		R	R		R		
Engine coolant temperature signal	T	R							
A/T self-diagnosis signal	R							T	
Output shaft revolution signal	R							T	
Accelerator pedal position signal	T						R	R	
Closed throttle position signal	T							R	
Wide open throttle position signal	T						R	R	
A/T shift position signal		R						T	
A/T shift schedule change demand signal							T	R	
Stop lamp switch signal		T						R	
O/D OFF indicator lamp signal		R						T	
Engine and A/T integrated control signal	T							R	
	R							T	
Fuel consumption monitor signal	T	R							
Oil pressure switch signal		R		R					T
A/C compressor request signal	T								R
A/C switch signal	R								T
Heater fan switch signal	R					T			
Cooling fan speed request signal	T								R
Cooling fan speed status signal	R								T
Position lights request signal		R		R		T			R

INTELLIGENT KEY SYSTEM

Signals	ECM	Combi- nation meter.	Intelli- gentKey unit	Drive com- puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/ R
Position light status signal	R								T
Low beam request signal						T			R
Low beam status signal	R								T
High beam request signal		R				T			R
High beam status signal	R								T
Day time light request signal						T			R
Vehicle speed signal	R	R			R		T		
	R	T	R	R	R	R			
Sleep/wake up signal		R	R			T			R
Door switch signal		R	R	R		T			R
Turn indicator signal		R				T			
Buzzer output signal		R				T			
		R	T						
MI signal	T	R		R					
Front wiper request signal						T			R
Front wiper stop position signal						R			T
Rear window defogger switch signal						T			R
Rear window defogger control signal	R								T
Drive computer signal		T		R					
EPS warning lamp signal		R		R	T				
ABS warning lamp signal		R		R			T		
ESP warning lamp signal		R		R			T		
ESP OFF indicator signal		R					T		
SLIP indicator lamp signal		R					T		
ESP operation signal	R						T		
TCS operation signal	R						T		
ABS operation signal	R						T		
Steering angle signal					T		R		
Brake warning lamp signal		R					T		
Buck-up lamp signal					R	T			
Fuel low warning signal		T		R					
Battery charge malfunction signal		T		R					
Air bag system warning signal		T		R					
Brake fluid level warning signal		T		R					
Engine coolant temperature warning signal		T		R					
Front fog lamp request signal		R				T			R
Rear fog lamp status signal		R				T			
Headlamp washer request signal						T			R


INTELLIGENT KEY SYSTEM

Signals	ECM	Combi-nation meter.	Intelli-gent Key unit	Drive com-puter	EPS control unit	BCM	ABS actuator and electric unit (control unit)	TCM	IPDM E/R
Door lock/unlock request signal			R			T			
Door lock/unlock status signal			R			T			
KEY indicator signal		R	T						
LOCK indicator signal		R	T						

INTELLIGENT KEY SYSTEM

TYPE 7

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/ R
Engine speed signal	T	R		R	R		R	
Engine coolant temperature signal	T	R						
Fuel consumption monitor signal	T	R						
Accelerator pedal position signal	T						R	
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
A/C switch signal	R							T
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Cooling fan speed status signal	R							T
Position lights request signal		R		R		T		R
Position light status signal	R							T
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal		R				T		R
High beam status signal	R							T
Day time light request signal						T		R
Vehicle speed signal	R	R			R		T	
	R	T	R	R	R	R		
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					


INTELLIGENT KEY SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Rear window defogger control signal	R							T
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			
ABS warning lamp signal		R		R			T	
ESP warning lamp signal		R		R			T	
ESP OFF indicator signal		R					T	
SLIP indicator lamp signal		R					T	
ESP operation signal	R						T	
TCS operation signal	R						T	
ABS operation signal	R						T	
Steering angle signal					T		R	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warning signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal						T		R
Door lock/unlock request signal			R			T		
Door lock/unlock status signal			R			T		
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

INTELLIGENT KEY SYSTEM

TYPE 9

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS con-trol unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			
Engine coolant temperature signal	T	R				R		
Fuel consumption monitor signal	T	R						
Oil pressure switch signal		R		R				T
A/C compressor request signal	T							R
Heater fan switch signal	R					T		
Cooling fan speed request signal	T							R
Position lights request signal		R		R		T		R
Low beam request signal						T		R
High beam request signal		R				T		R
Day time light request signal						T		R
Vehicle speed signal	R	R			R	R	T	
	R	T	R	R	R			
Sleep/wake up signal		R	R			T		R
Door switch signal		R	R	R		T		R
Turn indicator signal		R				T		
Buzzer output signal		R				T		
		R	T					
MI signal	T	R		R				
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal						T		R
Drive computer signal		T		R				
EPS warning indicator signal		R		R	T			


INTELLIGENT KEY SYSTEM

Signals	ECM	Combina-tion meter.	Intelli-gent Key unit	Drive computer	EPS control unit	BCM	ABS actuator and elec-tric unit (control unit)	IPDM E/R
ABS warning lamp signal		R		R			T	
ABS operation signal				R			T	
Brake warning lamp signal		R					T	
Buck-up lamp signal					R	T		
Fuel low warning signal		T		R				
Battery charge malfunction signal		T		R				
Air bag system warning signal		T		R				
Brake fluid level warning signal		T		R				
Engine coolant temperature warn-ing signal		T		R				
Front fog lamp request signal		R				T		R
Rear fog lamp status signal		R				T		
Headlamp washer request signal				T			T	R
Door lock/unlock request signal				R			R	
Door lock/unlock status signal				R			T	
KEY indicator signal		R	T					
LOCK indicator signal		R	T					

INTELLIGENT KEY SYSTEM

Schematic —I/KEY—

EIS004MK



MKWA1546E

INTELLIGENT KEY SYSTEM



Wiring Diagram — I/KEY —

SMA for VIN
>SJN**AK12U1309269



EIS004YP

BL-I/KEY-01



— : DATA LINE
M : WITH M/T



REFER TO THE FOLLOWING.
(M16) -FUSE BLOCK-
JUNCTION BOX (J/B)



INTELLIGENT KEY SYSTEM




REFER TO THE FOLLOWING.

- (M1)** -SUPER MULTIPLE JUNCTION (SMJ)
- (M16)** -FUSE BLOCK- JUNCTION BOX (J/B)
- (M79, M80, M81, M82)** -JOINT CONNECTOR (J/C)

INTELLIGENT KEY SYSTEM




BL-I/KEY-03



MKWA1794E

INTELLIGENT KEY SYSTEM

BL-I/KEY-04







INTELLIGENT KEY SYSTEM

 : DATA LINE

L : LHD MODELS

 BHD MODELS



1 REFER TO THE FOLLOWING.

M1 -SUPERB MULTIPLE

JUNCTION (SM-I)


M16 -E11SE BLOCK-

MTU FUSE BOX
ILLUMINATION BOX (I/B)

INTELLIGENT KEY SYSTEM

BL-I/KEY-06

5D : WITH 5 DOORS





MKWA1412E

INTELLIGENT KEY SYSTEM


BL-I/KEY-07

 : RHD MODELS



MKWA1413E

INTELLIGENT KEY SYSTEM







REFER TO THE FOLLOWING.
 (M1) -SUPER MULTIPLE JUNCTION (SMJ)

INTELLIGENT KEY SYSTEM

Terminals and Reference Value for INTELLIGENT KEY UNIT

EIS004ML

Terminal No.	Wire color	ITEM	Measuring condition		Standard (V) Approx.
			Ignition knob position	Operation or conditions	
1	R	Steering lock unit power supply	LOCK	—	5
2	R	CAN-H	—	—	—
3	W	CAN-L	—	—	—
4	P	Intelligent Key warning buzzer	LOCK	Operate remote controller button or door request switch. Buzzer OFF Sound buzzer	Battery voltage 0
5	OR	Door request switch (driver side)	—	Door request switch operation: Press (ON). Other than the above (OFF)	0 5
6	W	Ignition power supply	ON	—	Battery voltage
7	GY	Ignition knob switch	—	Press ignition knob. Return ignition knob to LOCK position.	Battery voltage 0
10	L	ACC power supply	ACC	—	Battery voltage
11	BR	Battery power supply	—	—	Battery voltage
12	B	GND	—	—	0
13	R	Inside key antenna (+) (Luggage room)	LOCK	Any door open → all doors shut (Door switch: ON → OFF)	 SIIA1910J
14	BR	Inside key antenna (-) (Luggage room)			
15	G	Inside key antenna (+) (Center console)	LOCK	Any door open → Close (Door switch: ON → OFF) Ignition knob switch: ON (press ignition knob.)	 SIIA1910J
16	R	Inside key antenna (-) (Center console)			
17	LG	Out side antenna (+)	LOCK	Back door request switch operation (Switch: ON)	 SIIA1910J
18	OR	Back door antenna (-)			
19	R	Outside antenna (driver side) (+)	LOCK	Driver door request signal operation (Switch: ON)	 SIIA1910J
20	W	Outside antenna (driver side) (-)			
22	W	Clutch inter lock switch	—	Clutch pedal depressed (ON) Clutch pedal not depressed (OFF)	0 5


INTELLIGENT KEY SYSTEM

Ter- minal No.	Wire color	ITEM	Measuring condition		Standard (V) Approx.	A B C D E F G H BL J K L M
			Ignition knob position	Operation or conditions		
25	LG	Door request switch (passenger side)	—	Door request switch operation: Press (ON)	0	B
				Other than the above (OFF)	5	
26	PU	Stop lamp switch	—	Brake pedal depressed (ON)	5	C
				Brake pedal not depressed (OFF)	0	
27	P	Key switch	LOCK	Insert mechanical key into ignition key cylinder.	Battery voltage	D
				Remove mechanical key from ignition key cylinder.	0	
29	R	Door request switch (back door)	—	Back door request switch operation: Press (ON)	0	E
				Other than the above (OFF)	5	
31	R	Steering lock unit ground	—	—	0	F
32	Y	Steering lock unit com- munication signal	LOCK	Press ignition knob with Intelligent Key inside vehicle.	(V) 6 4 2 0 ↓ 2 ms	G H SIIA1911J
				Other than the above	5	
37	BR	Outside antenna (pas- senger side) (+)	LOCK	Passenger door request switch opera- tion (Switch: ON)	(V) 15 10 5 0 ↓ 10 μs	BL J K L M
38	Y	Outside antenna (pas- senger side) (-)				

INTELLIGENT KEY SYSTEM

Terminals and Reference Value for Steering Lock unit

EIS004MM





Terminal number	Wire color	ITEM	Measuring condition		Standard (V) Approx.
			Ignition knob position	Operation or conditions	
1	BR	Battery power supply	LOCK	—	Battery voltage
2	R	Steering lock unit power supply	LOCK	—	5
3	Y	Steering lock unit communication signal	LOCK	Press ignition knob with Intelligent Key inside vehicle.	 SIIA1911J
				Other than the above	5
4	R	Steering lock unit ground	—	—	0

Terminal and Reference Value for BCM

EIS00569

TERMINAL	WIRE COLOR	ITEM	CONDITION	VOLTAGE (V) Approx.
2	B	Ground	—	0
3	P	Key switch	Mechanical key is removed from ignition knob (OFF) → Mechanical key is inserted in ignition knob (ON)	0 → Battery voltage
10	OR	Back door switch	Back door open (ON) → Back door close (OFF)	0 → Battery voltage
19	R	CAN-H	—	—
24	OR	IGN power supply	Ignition knob ON or START position	Battery voltage
29	L	Front door switch LH (LHD models) Front door switch RH (RHD models)	Door open (ON) → Door close (OFF)	0 → Battery voltage
30	LG	Front door switch RH (LHD models) Front door switch LH (RHD models)	Door open (ON) → Door close (OFF)	0 → Battery voltage
39	W	CAN-L	—	—
59	L	Rear door switch LH	Door open (ON) → Door close (OFF)	0 → Battery voltage
60	G	Rear door switch RH	Door open (ON) → Door close (OFF)	0 → Battery voltage

INTELLIGENT KEY SYSTEM

TER-MINAL	WIRE COLOR	ITEM	CONDITION	VOLTAGE (V) Approx.
65	P	Answer back (Turn signal lamp LH)	When door lock operated using remote controller* ¹	 PIIA2486J
			When door unlock operated using remote controller* ¹	 PIIA2487J
66	R	Answer back (Turn signal lamp RH)	When door lock operated using remote controller* ¹	 PIIA2486J
			When door unlock operated using remote controller* ¹	 PIIA2487J
67	L	Door lock actuator unlock (ALL Door) (Except driver side)	Door lock/unlock switch UNLOCK operation	0 → Battery voltage
68	OR	Back door opener actuator	Power window main switch (Back door release switch) OPEN operation	Battery voltage → 0
70	B	Ground	—	0
74	W	BAT power supply (fusible link) (BCM)	—	Battery voltage
75* ²	R	Super lock set output (All door)	Super lock operation (Set)	0 → Battery voltage
76	BR	Door lock actuator unlock (Driver side)	Door lock/unlock switch Unlock operation	0 → Battery voltage
77	L	Door lock actuator lock (ALL Door)	Door lock/unlock switch LOCK operation	0 → Battery voltage
79	Y	BAT power supply (fusible link) (Power window)	—	Battery voltage

*¹ : In the state that answer back operates


*² : Only the model equipped with super lock system (RHD Models)

A
B
C
D
E
F
G
H
BL
J
K
L
M

INTELLIGENT KEY SYSTEM

Diagnosis Procedure WORK FLOW

EIS004MN



MIIIB0488E

INTELLIGENT KEY SYSTEM

CONSULT-II Function (INTELLIGENT KEY)

EIS004MP

- CONSULT-II has display and inspection functions for work support, self-diagnosis, data monitor, and control unit part number by combining data reception and command transmission via communication lines from the Intelligent Key unit.

Part to be diagnosed	Inspection Item, Diagnosis Mode	Description
Intelligent Key	WORK SUPPORT	<ul style="list-style-type: none"> Performs Intelligent Key-ID registration, check, and deletion. Performs steering lock unit ID registration. Changes settings for each function (ON/OFF).
	SELF-DIAG RESULTS	Intelligent Key unit performs CAN communication diagnosis.
	DATA MONITOR	Displays Intelligent Key unit input data in real time.
	CAN DIAG SUPPORT MNTR	The results of transmit/receive diagnosis of CAN communication can be read.
	ACTIVE TEST	Sends drive signals door lock actuator, buzzer or combination meter to perform operation check.
	ECC PART NUMBER	Displays Intelligent Key unit part No.

CONSULT-II Inspection Procedure


EIS00564

BASIC OPERATION


- Turn ignition knob to LOCK position.
- Connect CONSULT-II CONVERTER and CONSULT-II to data link connector.

CAUTION:


When CONSULT-II is used without connecting CONSULT-II CONVERTER, a malfunction may be detected by self-diagnosis in control modules that use CAN Communication.



- Use mechanical key to turn ignition switch to ON.
- Touch "START (NISSAN BASED VHCL)".




- Touch "INTELLIGENT KEY" on "SELECT SYSTEM" screen.
 - If "INTELLIGENT KEY" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



INTELLIGENT KEY SYSTEM

6. Select diagnosis mode. "WORK SUPPORT", "SELF-DIAG RESULTS", "DATA MONITOR", "CAN DIAG SUPPRT MNTR", "ACTIVE TEST" and "ECU PART NUMBER" are available.



CONSULT-II Application Items SELF-DIAGNOSTIC RESULTS

EIS00565

In the Intelligent Key unit, the CONSULT-II self-diagnostic results can be used to check for malfunctions in CAN communications.

DATA MONITOR

MAIN SIGNALS Display Item

Monitor item [OPERATION]	Description
PUSH SWITCH [ON/OFF]	Displays status (Ignition knob switch ON/ignition knob switch OFF) as judged from ignition knob switch signal.
KEY ROT SW [ON/OFF]	Displays status (Ignition switch ON position: ON/Ignition switch OFF position: OFF) as judged from key rotation detection switch signal.
KEY SW [ON/OFF]	Displays status (Key inserted: ON/Key removed: OFF) as judged by key switch.
DR REQ SW [ON/OFF]	Displays status (Operable: ON/Non-operable: OFF) as judged from door request switch (driver side) signal.
AS REQ SW [ON/OFF]	Displays status (Operable: ON/Non-operable: OFF) as judged from door request switch (passenger side) signal.
BD/TR REQ SW [ON/OFF]	Displays status (Operable: ON/Non-operable: OFF) as judged from door request switch (back door) signal.
IGN SW [ON/OFF]	Displays status (Ignition knob ON position: ON/Ignition knob OFF position: OFF) as judged from ignition switch signal.
ACC SW [ON/OFF]	Displays status (Ignition switch ACC position: ON/Ignition switch OFF position: OFF) as judged from ignition switch signal.
STOP LAMP SW [ON/OFF]	Displays status (Brake pedal depress: ON/brake pedal not depress: OFF) as judged from stop lamp switch signal.
P RANGE SW* [ON/OFF]	Displays status from park/neutral position switch ON/OFF condition.
BD OPEN SW [ON/OFF]	Displays status (Back door open: ON/Back door closed: OFF) as judged from back door opener switch signal.

*: With A/T models only.

ACTIVE TEST

Monitor item	Description
DOOR LOCK/UNLOCK	This test is able to check all door lock actuators lock operation. These actuators lock when "ON" on CONSULT-II screen is touched.
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation. The buzzer will be activated on when "ON" on CONSULT-II screen is touched.
INSLDE BUZZER	This test is able to check buzzer (builtin combination meter) operation. The buzzer will be activated on when "ON" on CONSULT-II screen is touched.
INDICATOR	This test is able to check warning lamp operation. The lamp will be turned on when "ON" on CONSULT-II screen is touched.

INTELLIGENT KEY SYSTEM

WORK SUPPORT

Monitor item	Description
INTELLI KEY WARNING	The condition of warning system can be changed.
LOW BATTERY WARNING	The condition of low battery warning system can be changed.
INTELLI KEY FUNCTION	The all of Intelligent Key system functions can be changed.
SELSELECTIVE UNLOCK	The condition of select unlock function can be changed.
ANTIKEY LOCK IN	The condition of Intelligent Key lock-in prevention function can be changed.
FLASH WITH REMOTE AND KEY	The condition of ignition key warning function can be changed.
ANSWER BACK WITH I-KEY LOCK	The condition of ignition key warning function (LOCK) can be changed.
ANSWER BAKE WITH I-KEY UNLOCK	The condition of ignition key warning function (UNLOCK) can be changed.
AUTO RELOCK TIMER	Auto locking function mode can be changed in this mode. The function mode will be changed when.
ENG START BY I-KEY	The condition of engine start function can be changed.
LOCK/UNLOCK BY I-KEY	The condition of door lock function can be changed.
FOR TAKE OUT WARN TRIGGER	The condition of Intelligent Key take out warn trigger can be changed.

List of Operation Related Parts

EIS004MQ

Parts marked with \times are the parts related to operation.

Will not operate if there is a malfunction in the area where there is a \times .	Intelligent Key	key switch	Ignition knob switch	ACC switch	Ignition switch	Door switch	Door request switch	Inside key antenna	Door antenna	Intelligent Key unit	CAN system	BCM	Combination meter	Stop lamp switch
Door lock/unlock operation using Intelligent Key remote controller button operation	\times	\times	\times			\times				\times	\times	\times		
Door lock/unlock operation using door request switch operation	\times	\times	\times			\times	\times	\times	\times	\times	\times	\times		
Door lock/unlock operation using mechanical key													\times	
Ignition knob rotation permission using Intelligent Key	\times	\times	\times					\times		\times				\times
Engine start using Intelligent Key	\times				\times			\times		\times	\times	\times		\times
Engine start using mechanical key					\times	\times					\times	\times		\times
Ignition switch return forgotten warning			\times	\times	\times	\times				\times	\times	\times		
Ignition key warning (when using mechanical key)		\times									\times	\times	\times	
Ignition switch OFF position warning (for inside car: when door closed)			\times	\times	\times					\times	\times			\times
Ignition switch OFF position warning (for outside car: when door opened/closed)	\times		\times	\times	\times	\times				\times	\times	\times		
Warning for removal of Intelligent Key to outside the car (when door open/closed)	\times		\times			\times		\times		\times	\times	\times	\times	\times
Warning for removal of Intelligent Key to outside the car (from window)	\times		\times			\times		\times		\times	\times			\times
Door lock non-operation warning	\times		\times			\times	\times	\times		\times	\times	\times		
Intelligent key low battery warning	\times				\times					\times	\times			\times

A
B
C
D
E
F
G
H
BL
J
K
L
M

INTELLIGENT KEY SYSTEM

Trouble Diagnosis Symptom Chart

ALL FUNCTIONS OF THE INTELLIGENT KEY ARE NOT OPERATING

EIS004MR

Symptom	Diagnoses service procedure	Refer to page
"KEY" and "LOCK" warning lamps in combination meter do not light up at all.	<ol style="list-style-type: none"> 1. Check Intelligent Key unit power supply and ground circuit 2. Check CAN communication 3. Replace Intelligent Key unit. 	BL-191 BL-191 —
"KEY" and "LOCK" warning lamps in combination meter turn on, but doors cannot be locked/unlocked or the engine starter using Intelligent Key.	<ol style="list-style-type: none"> 1. Use CONSULT-II to check if the Intelligent Key has been registered. 2. Use CONSULT-II setting change function to check if Intelligent Key system has been cancelled. 3. Intelligent Key inspection 4. Replace Intelligent Key unit. 	BL-158 BL-158 BL-202 BL-202

REMOTE CONTROL ENTRY FUNCTION MALFUNCTION

Symptom	Diagnoses service procedure	Refer to page
Door lock/unlock does not operate (other functions normal) when Intelligent Key remote controller button is operated.	<ol style="list-style-type: none"> 1. Intelligent Key inspection 2. Check key switch 3. Check ignition knob switch 4. Check door switch 5. Replace Intelligent Key unit. 	BL-202 BL-191 BL-193 BL-143 —

DOOR LOCK FUNCTION MALFUNCTION

Before conducting the diagnosis in the following table, check all power door lock system function. Refer to [BL-15. "POWER DOOR LOCK SYSTEM"](#).

Symptom	Diagnoses service procedure	Refer to page
Door lock/unlock does not operate when door request switch operation is used (operates when Intelligent Key remote controller button is operated).	<ol style="list-style-type: none"> 1. Check door request switch 2. Check outside antenna 3. Intelligent Key inspection 4. Replace Intelligent Key unit. 	BL-194 BL-197 BL-202 BL-202
Door lock/unlock do not operate using door request switch and Intelligent Key remote controller button operation (power door lock system is normal).	<ol style="list-style-type: none"> 1. Check door switch 2. Check key switch 3. Check ignition knob switch 4. Replace Intelligent Key unit. 	BL-143 BL-191 BL-193 BL-202
Hazard lamps do not flash during door lock operation using door request switch and Intelligent Key remote controller button operation. (Turn signal lamp operation is normal.)	Replace Intelligent Key unit.	BL-202
Hazard lamps do not flash during door lock operation using door request switch and Intelligent Key remote controller button operation. (Turn signal lamps do not operate.)	Conduct turn signal lamp inspection.	LT-121
Intelligent Key warning buzzer does not sound during door lock/unlock operation using Intelligent Key (regardless of whether Intelligent Key remote controller button or request switch operation is used).	<ol style="list-style-type: none"> 1. Check if the operation confirmation Intelligent Key warning buzzer was cancelled by the CONSULT-II settings change function. 2. Check Intelligent Key warning buzzer 3. Replace Intelligent Key unit. 	BL-158 BL-196 BL-202
Door lock/unlock operation confirmation Intelligent Key warning buzzer sounds, but door lock actuator does not operate. (And hazard lamps do not flash.)	<ol style="list-style-type: none"> 1. Check CAN communication 2. Replace Intelligent Key unit. 	BL-191 BL-202

INTELLIGENT KEY SYSTEM

ENGINE START FUNCTION MALFUNCTION

Intelligent Key Operation Inspection

Symptom	Diagnoses service procedure	Refer to page
Ignition knob can not turn	1. Intelligent Key inspection.	BL-202
	2. Check inside key antenna	BL-198
	3. Replace Intelligent Key unit.	BL-202
	1. Ignition knob switch system	BL-193
	2. Steering lock unit system	BL-199
	3. Intelligent Key unit power supply and ground circuit system	BL-191
	4. Replace Intelligent Key unit.	BL-202
Ignition knob turns even without both Intelligent Key and mechanical key.	Replace steering lock unit.	—
Security indicator will still flash when ignition knob is pressed.	1. Check key switch	BL-191
	2. Replace Intelligent Key unit.	BL-202
Security indicator does not flash with ignition knob released at LOCK position. (push switch OFF)	1. CAN communication system	BL-191
	2. Ignition knob switch system	BL-193
	3. Intelligent Key unit power supply and ground circuit system	BL-191
	4. Inspect combination meter (warning lamp).	BL-235

Mechanical Key Operation Inspection

Symptom	Diagnoses service procedure	Refer to page
Ignition knob can not turn	1. Check key switch.	BL-191
	2. Replace Intelligent Key unit.	BL-202
KEY indicator and security indicator does not flash with mechanical key inserted.	1. Check stop lamp switch	BL-201
	2. Replace Intelligent Key unit	BL-202

WARNING CHIME FUNCTION MALFUNCTION

Before conducting the diagnosis in the following table, check "key reminder function" with power door lock system.

Symptom	Diagnoses service procedure	Refer to page
Ignition knob OFF position warning chime (for inside vehicle) does not sound. (Ignition key warning chime operates)	1. Check CAN communication	BL-191
	2. Check ignition knob switch	BL-193
	3. Check key switch	BL-191
	4. Replace Intelligent Key unit.	BL-202
Ignition key warning chime is inoperative. (When mechanical key used)	1. Check CAN communication	BL-191
	2. Check key switch	BL-191
	3. Check door switch	BL-143
	4. Inspect combination meter (warning).	DI-25
	5. Replace Intelligent Key unit	BL-202

INTELLIGENT KEY SYSTEM

Symptom	Diagnoses service procedure	Refer to page
Ignition knob OFF position warning chime (for outside vehicle: after door open/closed) does not sound.	1. Check CAN communication 2. Check ignition knob switch 3. Check door switch system 4. Check Intelligent Key warning buzzer 5. Replace Intelligent Key unit.	BL-191 BL-193 BL-143 BL-196 BL-202
Intelligent Key take out warning chime (when door open/closed) does not sound.	1. Check CAN communication 2. Intelligent Key inspection 3. Check ignition knob switch 4. Check door switch system 5. Check Intelligent Key warning buzzer 6. Replace Intelligent Key unit.	BL-191 BL-202 BL-193 BL-143 BL-196 BL-202
Intelligent Key take out warning chime (when door opened/closed) sounds even though Intelligent Key is in vehicle.	1. Check inside key antenna 2. Intelligent Key inspection 3. Replace Intelligent Key unit.	BL-198 BL-202 BL-202
Intelligent Key take out warning chime (through window) does not sound	1. Check if Intelligent Key removal warning (take out from window) was canceled by CONSULT-II settings change function. 2. Check CAN communication 3. Intelligent Key inspection 4. Check ignition knob switch 5. Replace Intelligent Key unit.	BL-158 BL-191 BL-202 BL-193 BL-202
Intelligent Key take out warning chime (through window) sounds even though Intelligent Key is in vehicle.	1. Check inside key antenna 2. Intelligent Key inspection 3. Replace Intelligent Key unit.	BL-198 BL-202 BL-202
Door lock non-operation warning does not sound.	Intelligent Key warning chime does not sound 1. Intelligent Key inspection 2. Check door request switch 3. Check inside key antenna 4. Check Intelligent Key warning buzzer 5. Replace Intelligent Key unit.	BL-202 BL-194 BL-198 BL-196 BL-202
	Ignition knob OFF position warning chime does not sound 1. Intelligent Key inspection 2. Check door request switch 3. Check outside antenna 4. Check Intelligent Key warning buzzer 5. Check ignition knob switch 6. Replace Intelligent Key unit.	BL-202 BL-194 BL-197 BL-196 BL-193 BL-202
	Door ajar alarm 1. Check CAN communications 2. Check door request switch 3. Check outside antenna 4. Check Intelligent Key warning buzzer 5. Check door switch 6. Intelligent Key inspection 7. Replace Intelligent Key unit.	BL-191 BL-194 BL-197 BL-196 BL-143 BL-202 BL-202

Check CAN Communication System

EIS004MS

Go to [LAN-4, "Precautions When Using CONSULT-II"](#).


Check Intelligent Key Unit Power Supply and Ground Circuit

EIS004MT

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition knob OFF position.
2. Disconnect Intelligent Key unit connector M51 and measure the connector terminal (+) and ground (-) shown in the following table.

Terminal (wire color)	Signal Designation	Ignition switch	Standard voltage (V)
6 (W)	Ignition power supply	ON	Battery voltage
10 (L)	ACC power supply	ACC	Battery voltage
11 (BR)	Battery power supply	OFF	Battery voltage



OK or NG

OK >> GO TO 2.

NG >> Repair or replace Intelligent Key power supply circuit.

2. CHECK GROUND CIRCUIT


Check continuity between Intelligent Key unit connector M51 terminal 12 and ground.

12 (B) - Ground : Continuity should exist.

OK or NG

OK >> Power supply and ground circuits are normal.

NG >> Repair or replace the Intelligent Key unit ground circuit.



Check Key Switch

EIS004MV

1. KEY SWITCH INSPECTION

With CONSULT-II

Display "KEY SW" on DATA MONITOR screen, and check if ON-OFF display is linked to insertion of mechanical key in ignition knob.

When key is inserted in ignition knob : ON

When key is removed in ignition knob : OFF

OK or NG

OK >> Key switch is OK.

NG >> GO TO 2.

INTELLIGENT KEY SYSTEM

2. KEY SWITCH POWER SUPPLY CIRCUIT INSPECTION


1. Remove mechanical key from ignition knob.
2. Disconnect key switch and ignition knob switch connector.
3. Check voltage between key switch and ignition knob switch connector M34 terminal 1 and ground.

1 (W) - Ground : **Approx. 12V**

OK or NG

OK >> GO TO 3.

NG >> Repair or replace key switch power supply circuit.



3. KEY SWITCH OPERATION INSPECTION

1. Insert mechanical key into ignition knob.
2. Check continuity between key switch and ignition knob switch connector M34 terminal 1 and 2.

1 - 2

Insert mechanical key into ignition knob.

: Continuity should exist.


Remove mechanical key from ignition knob.

: Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Replace key switch.



4. KEY SWITCH CIRCUIT INSPECTION

1. Disconnect Intelligent Key unit connector.
2. Check continuity between Intelligent Key unit connector M51 terminal 27 and key switch and ignition knob switch connector M34 terminal 2.

27 (P) - 2 (P) : **Continuity should exist.**


3. Check continuity between key switch connector M34 terminal 2 and ground.

2 (P) - Ground : **Continuity should exist.**

OK or NG

OK >> Key switch is OK.

NG >> Repair or replace harness between Intelligent Key unit and key switch and ignition knob switch.



Check Ignition Knob Switch

EIS004MX

1. IGNITION KNOB SWITCH INSPECTION

With CONSULT-II

Display "PUSH SW" on DATA MONITOR screen, and check if ON/OFF display is linked to ignition knob operation.

Press ignition knob. : ON

Return ignition knob (remove hands). : OFF

OK or NG

OK >> Ignition knob switch is OK.

NG >> GO TO 2.

2. IGNITION KNOB SWITCH POWER SUPPLY CIRCUIT INSPECTION


1. Turn ignition knob LOCK position.
2. Disconnect key switch and ignition knob switch connector.
3. Check voltage between key switch and ignition knob switch connector M34 terminal 3 and ground.

3 (BR) - Ground : Approx. 12V

OK or NG

OK >> GO TO 3.

NG >> Repair or replace key switch and ignition knob switch power supply circuit.



3. IGNITION KNOB SWITCH OPERATION INSPECTION

Check continuity between key switch and ignition knob switch connector M34 terminal 3 and 4.

3- 4


Press ignition knob. : Continuity should exist.

Return ignition knob (remove hands). : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Replace key switch and ignition knob switch.



INTELLIGENT KEY SYSTEM

4. IGNITION KNOB SWITCH CIRCUIT INSPECTION

1. Disconnect Intelligent Key unit connector.
2. Check continuity between Intelligent Key unit connector M51 terminal 7 and key switch and ignition knob switch connector M34 terminal 4.

7 (GY) - 4 (GY) : Continuity should exist.


3. Check continuity between key switch and ignition knob switch connector terminal 4 and ground.

4 (GY) - Ground : Continuity should not exist.

OK or NG

OK >> Replace Intelligent Key unit.

NG >> Repair or replace harness between Intelligent Key unit and key switch and ignition knob switch.



EIS004MY

Check Door Request Switch

1. DOOR REQUEST SWITCH INSPECTION

With CONSULT-II

Display "DR REQ SW" (driver door), "AS REQ SW" (passenger door) and "BD/TR REQ SW" (back door) on DATA MONITOR screen, and check if ON-OFF display is linked to door request switch operation.

Press door request switch. : ON

Release door request switch. : OFF

OK or NG

OK >> Door request switch is OK.

NG >> GO TO 2.

2. DOOR REQUEST SWITCH SIGNAL INSPECTION

1. Turn ignition knob LOCK position.
2. Disconnect door request switch connector.
3. Check voltage between door request switch connector D10 (driver door), D39 (passenger door), B54 (back door) terminal 1 and ground.

Driver 1 (OR) - Ground : Approx. 5V


Passenger 1 (LG) - Ground : Approx. 5V

Back door 1 (R) - Ground : Approx. 5V

OK or NG

OK >> GO TO 3.

NG >> GO TO 5.



INTELLIGENT KEY SYSTEM

3. DOOR REQUEST SWITCH OPERATION INSPECTION


Check continuity between door request switch connector D10 (driver door), D39 (passenger door), B54 (back door) terminal 1 and 2.

1 - 2

Press door request switch. : Continuity should exist.
Return door request switch. : Continuity should not exist.

OK or NG

OK >> GO TO 4.
NG >> Replace door request switch.




4. DOOR REQUEST SWITCH GROUND CIRCUIT INSPECTION

Check continuity between door request switch connector 2 and ground.

2 (B) - Ground : Continuity should exist.

OK or NG

OK >> GO TO 5.
NG >> Repair or replace door request switch ground circuit.



5. DOOR REQUEST SWITCH CIRCUIT INSPECTION

1. Disconnect Intelligent Key unit connector.
2. Check continuity between Intelligent Key unit connector M51 terminals 5 (driver door), 25 (passenger door), and 29 (back door) and door request switch connector D10 (driver door), D39 (passenger door), B54 (back door) terminal 1.


Driver 5 (OR) - 1 (OR) : Continuity should exist.
Passenger 25 (LG) - 1 (LG) : Continuity should exist.
Back door 29 (R) - 1 (R) : Continuity should exist.

3. Check continuity between door request switch connector D10 (driver door), D39 (passenger door), B54 (back door) terminal 1 and ground.

1 - Ground : Continuity should not exist.

OK or NG

OK >> Replace Intelligent Key unit.
NG >> Repair or replace harness between Intelligent Key unit and door request switch.



INTELLIGENT KEY SYSTEM

Check Intelligent Key Warning Buzzer

EIS004N1


1. INTELLIGENT KEY WARNING BUZZER POWER SUPPLY CIRCUIT INSPECTION

1. Turn ignition knob LOCK position.
2. Remove Intelligent Key warning buzzer connector.
3. Check voltage between Intelligent Key warning buzzer connector D8 terminal 2 and ground.

2 (G) - Ground : Approx. 12V

OK or NG

OK >> GO TO 2.
NG >> Repair or replace Intelligent Key warning buzzer power supply circuit.



2. INTELLIGENT KEY WARNING BUZZER CIRCUIT INSPECTION

1. Disconnect Intelligent Key unit connector.
2. Check continuity between Intelligent Key unit connector M51 terminal 4 and Intelligent Key warning buzzer connector D8 terminal 1.


4 (P) - 1 (P) : Continuity should exist.

3. Check continuity between Intelligent Key warning buzzer connector D8 terminal 1 and ground.

1 (P) - Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.
NG >> Repair or replace harness between Intelligent Key warning buzzer and Intelligent Key unit.




3. INTELLIGENT KEY WARNING BUZZER OPERATION INSPECTION

Connect battery power supply to Intelligent Key warning buzzer connector D8 terminals 1 and 2, and check the operation.

2 (BAT+) - 1 (BAT-) : the buzzer sounds

OK or NG

OK >> Intelligent Key warning buzzer is OK.
NG >> Replace Intelligent Key warning buzzer



INTELLIGENT KEY SYSTEM

Check Outside Antenna


EIS004N2

1. OUTSIDE ANTENNA POWER SUPPLY INSPECTION

SMA for VIN
>SJN**AK12U1309269


Operate each door request switch (push), and use an oscilloscope to check voltage waveform of harness between Intelligent Key unit connector M51 terminals 17 (back door), 19 (driver door), and 37 (passenger door) and ground.

Push each door request switch.

Back door: 17 (LG) - Ground	
Driver: 19 (R) - Ground	
Passenger: 37 (BR) - Ground	

OK or NG

OK >> Outside antenna circuit is OK.
NG >> GO TO 2.




2. OUTSIDE ANTENNA OPERATION INSPECTION

1. Disconnect each door antenna connector.
2. Check continuity between each door antenna connector D11 (driver door), B39 (back door), D40 (passenger door) terminals 1 and 2.

1 - 2 : Continuity should exist.

OK or NG

OK >> GO TO 3.
NG >> Replace outside antenna.




INTELLIGENT KEY SYSTEM

3. OUTSIDE ANTENNA CIRCUIT INSPECTION

1. Disconnect Intelligent Key unit connector.
2. Check continuity between each outside antenna connector D11 (driver door), B39 (back door), D40 (passenger door) terminals 1 and 2 and Intelligent Key unit connector M51 terminals 17, 18, 19, 20, 37, and 38.

Back door	1 (LG) - 17 (LG): Continuity should exist. 2 (OR) - 18 (OR): Continuity should exist.
Driver door	1 (R) - 19 (R): Continuity should exist. 2 (W) - 20 (W): Continuity should exist.
Passenger door	1 (BR) - 37 (BR): Continuity should exist. 2 (Y) - 38 (Y): Continuity should exist.

3. Check continuity between each door antenna connector terminals 1 and 2 and ground.



MIIIB0377E

1 - Ground : Continuity should not exist.
2 - Ground : Continuity should not exist.

OK or NG

OK >> Replace Intelligent Key unit.
NG >> Replace harness between door antenna and Intelligent Key unit.

Check Inside Key Antenna

EIS004N3


1. INSIDE KEY ANTENNA POWER SUPPLY CIRCUIT INSPECTION

Operate ignition knob and use an oscilloscope to check voltage waveform between Intelligent Key unit connector M51 terminals 13 (luggage room), 15 (center console) and ground.

Press ignition knob.	
luggage room: 13 (R) - Ground	(V) 15 10 5 0 + - 10 μ s
Center console: 15 (G) - Ground	

OK or NG

OK >> Inside key antenna circuit is OK.
NG >> GO TO 2.



MIIIB0378E

INTELLIGENT KEY SYSTEM

2. INSIDE KEY ANTENNA OPERATION INSPECTION


1. Disconnect inside key antenna connector.
2. Check continuity between inside key antenna connector B25 (center console), B29 (luggage room) terminals 1 and 2.

1 - 2 : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Replace malfunctioning inside key antenna.



3. INSIDE KEY ANTENNA INSPECTION


1. Disconnect Intelligent Key unit connector.
2. Check continuity between inside key antenna connector B25 (center console), B29 (luggage room) terminals 1 and 2 and Intelligent Key unit connector terminals 13, 14, 15, and 16.

Inside key antenna (luggage room)	1 (R) - 13 (R): Continuity should exist.
	2 (BR) - 14 (BR): Continuity should exist.
Inside key antenna (center console)	1 (G) - 15 (G): Continuity should exist.
	2 (R) - 16 (R): Continuity should exist.

3. Check continuity between inside key antenna connector B25 (center console), B29 (luggage room) terminals 1 and 2 and ground.

1 (G or R) - Ground : Continuity should not exist.

2 (R or BR) - Ground : Continuity should not exist.



OK or NG

OK >> Replace Intelligent Key unit.

NG >> Repair or replace harness between inside key antenna and Intelligent Key unit.

Check Steering Lock Unit

EIS004N4

1. STEERING LOCK UNIT POWER SUPPLY INSPECTION


1. Turn ignition knob LOCK position.
2. Disconnect steering lock unit connector.
3. Check voltage between steering lock unit connector M31 terminal 1 and ground.

1 (BR) - Ground : Approx. 12V

OK or NG

OK >> GO TO 2.

NG >> Repair or replace steering lock unit power supply circuit.



INTELLIGENT KEY SYSTEM

2. STEERING LOCK UNIT GROUND CIRCUIT INSPECTION

Check continuity between steering lock unit connector M31 terminal 4 and ground.


4 (R) - Ground

: Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.




3. STEERING LOCK COMMUNICATION CIRCUIT INSPECTION

1. Connect steering lock unit connector.
2. Check voltage between Intelligent Key unit connector M51 terminal 1 and ground.

1 (R) - Ground



: Approx. 5V



3. Immediately after operating (pushing) ignition knob, use an oscilloscope to check voltage waveform between Intelligent Key unit connector M51 terminal 32 and ground.

Immediately after ignition knob operation (pushing).

32 (Y) - Ground



OK or NG

OK >> GO TO 4.

NG >> Replace Intelligent Key unit.

INTELLIGENT KEY SYSTEM

4. STEERING LOCK UNIT COMMUNICATION CIRCUIT INSPECTION

1. Disconnect Intelligent Key unit and steering lock unit connectors.
2. Check continuity between Intelligent Key unit connector M51 terminals 1, 31, and 32 and steering lock unit connector M31 terminals 2, 3, and 4.

1 (R) - 2 (R) : Continuity should exist.

31 (R) - 4 (R) : Continuity should exist.


32 (Y) - 3 (Y) : Continuity should exist.

3. Check continuity between steering lock unit connector M31 terminals 2, 3, 4 and ground.

2 (R) - Ground : Continuity should not exist.

3 (Y) - Ground : Continuity should not exist.

4 (R) - Ground : Continuity should not exist.



OK or NG

OK >> Replace steering lock unit.

● After replacing steering lock unit, Refer to [BL-158, "STEERING LOCK UNIT REGISTRATION"](#).

NG >> Repair or replace harness between steering lock unit and Intelligent Key unit.

Check Stop Lamp Switch

EIS0055H

1. STOP LAMP SWITCH POWER SUPPLY CIRCUIT INSPECTION


1. Check stop lamp switch connector.
2. Check voltage between stop lamp switch connector E108 (LHD models with M/T), E109 (LHD models with A/T), M202 (RHD models with M/T), M203 (RHD models with A/T) terminal 1 and ground.

1 and ground : Approx. 12V

OK or NG

OK >> GO TO 2.

NG >> Repair or replace harness between Intelligent Key unit and stop lamp switch.




2. STOP LAMP SWITCH OPERATION INSPECTION

Check continuity between stop lamp switch connector E108 (LHD models with M/T), E109 (LHD models with A/T), M202 (RHD models with M/T), M203 (RHD models with A/T) terminal 1 and 2.

1 - 2

Brake pedal depressed : Continuity should exist.

Brake pedal not depressed : Continuity should not exist.



OK or NG

OK >> GO TO 3.

NG >> Replace stop lamp switch.

INTELLIGENT KEY SYSTEM


3. STOP LAMP SWITCH GROUND CIRCUIT INSPECTION

1. Check continuity between stop lamp switch connector E108 (LHD models with M/T), E109 (LHD models with A/T), M202 (RHD models with M/T), M203 (RHD models with A/T) terminal 2 and Intelligent Key unit connector M51 terminal 26.

2 (Y) - 26 (PU) : Continuity should exist.

2. Check continuity between stop lamp switch connector E108 (LHD models with M/T), E109 (LHD models with A/T), M202 (RHD models with M/T), M203 (RHD models with A/T) terminal 2 and ground.

2 (Y) - Ground : Continuity should not exist.



OK or NG

OK >> Stop lamp switch is OK.


NG >> Repair or replace harness.

Removal and Installation of Intelligent key unit

EIS0055J

REMOVAL

1. Remove the instrument lower driver panel. Refer to [IP-5, "Removal and Installation"](#) .
2. Disconnect the Intelligent Key unit connector, remove the screw and Intelligent Key unit.



INSTALLATION


Install in the reverse order of removal.

Intelligent Key Inspection

EIS004N5

INTELLIGENT KEY DISASSEMBLY AND ASSEMBLY

1. Remove Intelligent Key cover.
2. Insert a thin screwdriver wrapped with tape into Area A and then separate lower and upper cases while twisting screwdriver.



INTELLIGENT KEY SYSTEM


3. When replacing the circuit board or rubber
 - Remove the circuit board assembly from the upper case.
(Substrate assembly: circuit board + rubber)
 - Gently press the rubber and remove the circuit board.

CAUTION:
Be careful not to touch the printed circuits directly.
4. When replacing the battery
 - Remove the battery from the lower case and replace it.

Battery replacement : Coin-shaped lithium battery 3V (CR2032)

CAUTION:
When replacing battery, be sure to keep dirt, grease, and other foreign materials off the electrode contact area.
5. After replacement, assemble the upper and lower cases by engaging the hooks on their circumference while being careful not to pinch the rubber, etc.


CAUTION:
After replacing the battery, check to make sure all Intelligent Key functions work normally.



REMOTE CONTROLLER BATTERY INSPECTION

Check by connecting a resistance (approximately 300Ω) so that the current value becomes about 10 mA.

Standard : Approx. 2.5V - 3.0V




DOOR

DOOR

PFP:80100

Fitting Adjustment (5-Door Vehicles)

EIS004N6



FRONT DOOR

Longitudinal Gap and Front End Height Difference Adjustment

1. Remove front fender. Refer to [BL-14, "Removal and Installation"](#).
2. Loosen the hinge bolts on body, then lift the rear end of front door to adjust the clearance and surface difference properly.


REAR DOOR

Longitudinal Gap and Front End Height Difference Adjustment

1. Remove center pillar upper garnish and center pillar lower garnish. Refer to [EI-19, "Removal and Installation \(5-Door\)"](#).
2. Working from inside and outside vehicle, loosen bolts and nuts, and then open rear door, and adjust while raising rear door by rear edge.


STRIKER ADJUSTMENT

Adjust the striker so that it becomes parallel with the lock inserting direction.



Fitting Adjustment (3-Door Vehicles)

EIS004N7




FRONT DOOR

Longitudinal Gap and Front End Height Difference Adjustment

1. Remove front fender. Refer to [BL-14, "Removal and Installation"](#).
2. Loosen the hinge bolts on body, then lift the rear end of front door to adjust the clearance and surface difference properly.

STRIKER ADJUSTMENT

Adjust the striker so that it becomes parallel with the lock inserting direction.



Removal and Installation

EIS004N8

CAUTION:

- During removal and installation of the door assembly, use a jack to support the door. Place a shop cloth or other suitable material onto the jack plate to protect the door and body from damage.
- After removal and installation of the door assembly, always adjust the fit.
- Check hinge rotating part for poor lubrication. If necessary, apply "Body Grease".


FRONT DOOR

1. Remove front door finisher. Refer to [EI-16, "Removal and Installation"](#).
2. Remove door window. Refer to [GW-69, "Removal and Installation"](#).
3. Remove connectors and harness clamps in front door, and then pull out harness from front door.


A
 B
 C
 D
 E
 F
 G
 H
 BL
 J
 K
 L
 M

DOOR

4. Remove check link bolts.




5. Remove hinge nuts on the door and then the door assembly. Install in the reverse order of removal.




REAR DOOR

1. Remove rear door finisher. Refer to [EI-16, "Removal and Installation"](#) .
2. Remove door window. Refer to [GW-72, "Removal and Installation"](#) .
3. Remove connectors and harness clamps from rear door and then pull out harness from rear door.
4. Remove check link bolts.



5. Remove hinge nuts on the door and then the door assembly. Install in the reverse order of removal.




DOOR

Door Weatherstrip 5 DOORS

EIS004N9

A
B
C
D
E
F
G
H
BL
J
K
L
M



MIIB0123E


Double-sided tape (0.8 mm thick, 7 mm wide)

: Product equivalent to Sumitomo 3M No. 5561

CAUTION:

During removal, if peeling off the double-sided tape is difficult, apply remover (product equivalent to Sumitomo 3M Cleaner 30) and then remove the double-sided tape. When using remover, keep it way from open flame and work in a sufficiently ventilated area.

3 DOORS



MIIB0124E

Double-sided tape (0.8 mm thick, 7 mm wide)

: Product equivalent to Sumitomo 3M No. 5561

DOOR

CAUTION:

During removal, if peeling off the double-sided tape is difficult, apply remover (product equivalent to Sumitomo 3M Cleaner 30) and then remove the double-sided tape. When using remover, keep it way from open flame and work in a sufficiently ventilated area.


FRONT DOOR LOCK

FRONT DOOR LOCK Component Parts Location

PFP:80502

EIS004NA

SEC. 805



- 1. Inside handle
- 2. Lock knob cable
- 3. Inside handle cable
- 4. Holder
- 5. Outside handle cable
- 6. Door lock assembly
- 7. Key cylinder connecting rod
- 8. Outside handle bracket
- 9. Outside handle
- 10. *Door key cylinder assembly
- 11. Front gasket
- 12. Rear gasket
- 13. Grommet


*: Outside handle escutcheon for vehicles with passenger door key cylinders.

Removal and Installation

REMOVAL

EIS004NB

1. Remove front door finisher. Refer to [EI-16, "Removal and Installation"](#) .
2. Fully close front door window.
3. Remove front door lower sash (rear). Refer to [GW-69, "Removal and Installation"](#) .
4. Remove inside handle cable and lock knob cable from holder.
5. Remove inside handle screws, slide handle toward rear of vehicle, disengage handle from door panel, and remove inside handle.




FRONT DOOR LOCK

6. Disconnect inside handle cable and lock knob cable from inside handle.


CAUTION:

During removal and installation, work so as not to bend the ends of the lock knob cable and inside handle cable.




MIIB0127E

7. Remove door side grommets, and then remove door key cylinder assembly (escutcheon) bolts (Torx T30) from the grommet holes.
8. Remove key cylinder connecting rod (key cylinder side).: If there is no door key cylinder, GO TO 9.
9. Disconnect door antenna and door request switch connector and remove harness clamp. (Vehicle with intelligent key systems only)




MIIB0128E

10. Remove door cylinder assembly while pulling outside handle forward.




MIIB0129E

11. Pull outside door handle forward and then slide it toward vehicle rear to remove.



MIIB0130E


12. Remove front and rear gaskets.



MIIB0131E


FRONT DOOR LOCK

13. Remove door lock assembly bolts (Torx T30).




14. Slide outside handle bracket toward rear of vehicle, and then remove outside handle bracket and door lock assembly.

15. Disconnect door lock assembly connector.



16. Disconnect outside handle cable from outside handle bracket.



Install in the reverse order of removal.


CAUTION:

- Before installing door lock assembly, apply “anti-corrosion wax M-97 super” onto mounting seat on the body.
- Install each rod by rotating the rod holder until it engages with a tactile feel.

FRONT DOOR LOCK

Disassembly and Assembly DOOR KEY CYLINDER ASSEMBLY


EIS004NC



MIIB0135E

1. Remove key cylinder escutcheon engagement (3 locations), and then remove door key cylinder.
2. Remove hook (2 locations) engagements, and then remove door request switch from key cylinder escutcheon. (Vehicles with intelligent key systems only)

OUTSIDE HANDLE



MIIB0136E

1. Remove handle cover screws.
2. Remove handle cover, and then remove door antenna. (Vehicles with intelligent key systems only)

REAR DOOR LOCK



REAR DOOR LOCK

PFP:82502

Component Parts Location

EIS004ND

SEC. 825



MIB0725E


- 1. Inside handle
- 2. Lock knob cable
- 3. Inside handle cable
- 4. Outside handle cable
- 5. Door lock assembly
- 6. Outside handle bracket
- 7. Outside handle
- 8. Outside handle escutcheon
- 9. Front gasket
- 10. Rear gasket
- 11. Grommet

Removal and Installation

REMOVAL

EIS004NE

1. Remove rear door finisher. Refer to [EI-16, "Removal and Installation"](#) .
2. Remove partition sash. Refer to [GW-72, "Removal and Installation"](#) .
3. Support door glass while lifting it up to the door window completely closed position.
4. Remove inside handle bolts, slide handle toward rear of vehicle, remove engagement with door panel, and remove inside handle.




MIB0126E

5. Disconnect inside handle cable and lock knob cable from inside handle.

CAUTION:


During removal and installation, work so as not to bend the ends of the lock knob cable and inside handle cable.



MIB0127E


REAR DOOR LOCK

6. Remove door side grommets, and then remove outside handle escutcheon screws (Torx T30) from grommet holes.




MIIB0128E

7. Pull outside handle forward while removing outside handle escutcheon.




MIIB0138E

8. Pull outside door handle forward and then slide it toward vehicle rear to remove.




MIIB0130E

9. Remove front and rear gaskets.



MIIB0131E


10. Remove door lock assembly screws (Torx T30).




MIIB0132E

REAR DOOR LOCK

11. Slide outside handle bracket toward rear of vehicle, and then remove outside handle bracket and door lock assembly.
12. Disconnect door lock assembly connector.




13. Disconnect outside handle cable from outside handle bracket.



Install in the reverse order of removal.

CAUTION:

- Before installing door lock assembly, apply "anti-corrosion wax M-97 super" onto mounting seat on the body.
- When installing door lock assembly, be careful when rotating the outside handle cable as shown in the figure.
- Place the outside handle bracket cable on the outside of door lock assembly before installing.




BACK DOOR

PFP:90100

Fitting Adjustment

EIS004NF



VERTICAL/LATERAL CLEARANCE (SURFACE DIFFERENCE) ADJUSTMENT

1. Remove luggage rear plate. Refer to [EI-26, "Removal and Installation"](#).
2. Loosen back door striker screws.
3. Use a rubber hammer, etc., to strike back door striker to make the gap on the right and left and with the rear bumper even, and then tighten striker screws to specified torque.


CAUTION:

Adjust gap between back door and other areas to attain the right and left dimensional difference shown below.

Back door glass (B) - Body side outer (B)	: 2.0 mm or less
Back door outer (C) - Body side outer (C)	: 1.5 mm or less
Back door outer (D) - Rear combination lamp (D)	: 2.0 mm or less

4. If following the steps above does not result in fine adjustment, remove headliner and loosen the hinge nuts on vehicle for further adjustment.

For removing headliner, refer to [EI-24, "Removal and Installation"](#).


**Back Door Assembly
REMOVAL**

EIS004NG


1. Remove back door finisher. Refer to [EI-18, "Removal and Installation"](#).
2. Disconnect connectors in back door and unclamp harness. Pull out harness from back door.

BACK DOOR

3. After supporting the back door lock to keep it from falling, use a screwdriver, etc., to remove the back door stay (glass stay) door side hooks, and then pull out back door stay from stud pole.




4. Remove back door hinge bolts, and then remove back door assembly.




INSPECTION

1. Check hinges for the following:
 - Unusual noise or door closing and opening effort
 - Component wear or damage
2. Apply body grease to the rotating part of the hinge.



Back Door Striker REMOVAL

1. Remove luggage rear plate. Refer to [E1-26, "Removal and Installation"](#) .
2. Remove screws and back door striker.



INSTALLATION

Install in the reverse order of removal.

CAUTION:


- After finishing work, confirm proper operation.
- After finishing work, adjust fitting. Refer to [BL-216, "Fitting Adjustment"](#) .

BACK DOOR


Back Door Stay Assembly REMOVAL

EIS004NI

1. Support back door lock to prevent it from falling.
2. Remove back door stay assembly (gas stay) vehicle side bracket bolts.



3. Remove back door stud balls, and then remove back door stay assembly from back door.



INSTALLATION

Install in the reverse order of removal.

CAUTION:



- After finishing work, confirm proper operation.

BACK DOOR

Removal and Installation of Back Door Weatherstrip

EIS004NJ

SEC. 900



MIIIB0148E

A
B
C
D
E
F
G
H

BL

J

K

L

M

REMOVAL

Pull up and remove engagement with body from weatherstrip joint.

CAUTION:

After removal, do not pull strongly on the weatherstrip.

INSTALLATION

Install in the reverse order of removal.

- Working from the upper section, align weatherstrip mark with vehicle center position mark and install weatherstrip onto the back door.
- For the lower section, align the weatherstrip seam with center of the striker.
- After finishing work, pull weatherstrip lightly to check for looseness.
- Make sure the weatherstrip is fit tightly at each corner and luggage rear plate.

BACK DOOR LOCK

BACK DOOR LOCK


PFP:90504

Removal and Installation BACK DOOR LOCK ASSEMBLY

EIS004NK

Removal

1. Remove back door finisher. Refer to [EI-18, "Removal and Installation"](#) .
2. Disconnect back door lock assembly connector.
3. Remove bolts to remove back door lock assembly from inside back door panel.



Installation


Install in the reverse order of removal.

- If greasing condition in each sliding section on back door assembly is poor, apply "BODY GREASE".
- After finishing work, confirm proper operation.

BACK DOOR HANDLE ASSEMBLY

Removal

1. Remove back door finisher. Refer to [EI-18, "Removal and Installation"](#) .
2. Remove back door request switch (vehicles with intelligent key systems) and back door open switch harness fastening clips and connectors.
3. Remove back door handle assembly nuts, and then remove back door handle assembly.



Installation


Install in the reverse order of removal.

CAUTION:

After finishing work, confirm proper operation.

Disassembly and Assembly

Remove screws, and then remove back door request switch (vehicles with intelligent key systems) and back door open switch.




FUEL FILLER LID OPENER

FUEL FILLER LID OPENER

PFP:78820

Component Parts Location

EIS004NL



A

B

C

D

E

F

G

H

BL

J

K

L

M


THEFT WARNING SYSTEM

THEFT WARNING SYSTEM

PFP:25362

Wiring Diagram — THEFT —/PRWIRE

EIS00551



MKWA1797E


NATS(NISSAN ANTI-THEFT SYSTEM)

PFP:28591

Component Parts and Harness Connector Location

EIS004Q1

A
B
C
D
E
F
G
H
BL
J
K
L
M



NOTE:

If customer reports a "NO START" condition, request ALL ignition key (without intelligent key system) or mechanical key (with intelligent key system) to be brought to the dealer to check for a NATS malfunction.

System Description

DESCRIPTION

EIS004Q2

NATS (Nissan Anti-Theft System) has the following immobilizer functions:

- Engine immobilizer shows high anti-theft performance to prevent engine start by other than the owner (registered key: ignition key, mechanical key and Intelligent Key).

NATS(NISSAN ANTI-THEFT SYSTEM)

- Only a key with key ID registered in BCM (without Intelligent Key system) or Intelligent Key unit (with Intelligent Key system) and ECM can start engine, and shows high anti-theft performance to prevent key from being copied or stolen.
- In the vehicle without Intelligent Key system, security indicator always flashes with other than ignition switch ON or START position.
- In the vehicle with Intelligent Key system, security indicator always flashes with mechanical key removed condition (key switch OFF) and ignition knob released condition on LOCK position (ignition knob switch OFF).
- Therefore, NATS warns outsiders that the vehicle is equipped with the anti-theft system.
- If system detects malfunction, it turns on security indicator in ignition switch ON position.
- If the owner requires, mechanical key ID can be registered for up to 5 keys.
- During trouble diagnosis or when the following parts have been replaced, and if ignition key or mechanical key is added, registration* is required.
*: All keys kept by the owner of the vehicle should be registered with ignition key or mechanical key.

- ECM
- BCM (models without Intelligent Key system)
- Intelligent Key unit (models with Intelligent Key system)
- Ignition key (models without Intelligent Key system)
- Mechanical key (models with Intelligent Key system)

- NATS trouble diagnoses, system initialization and additional registration of other ignition key or mechanical key IDs must be carried out using CONSULT-II hardware and CONSULT-II NATS software. When NATS initialization has been completed, the ID of the inserted ignition key or mechanical key is automatically registered. Then, if necessary, additional registration of other ignition key or mechanical key IDs can be carried out. Regarding the procedures of NATS initialization and ignition key or mechanical key ID registration, refer to CONSULT-II operation manual, NATS.

SECURITY INDICATOR

- Warns that the vehicle has NATS (Nissan Anti-Theft System).
- In the vehicle without Intelligent Key system, security indicator always flashes with other than ignition switch ON or START position. In the vehicle with Intelligent Key system, security indicator always flashes with mechanical key removed condition (key switch OFF) and ignition knob released condition on LOCK position (ignition knob switch OFF).

NOTE:

Because security indicator is highly efficient, the battery is barely affected.

Condition of Security Indicator (Normal)

WITHOUT INTELLIGENT KEY SYSTEM

Security indicator condition	Ignition key	Operation or condition of ignition key			
		Ignition switch: ON position	Ignition switch: ACC position	Ignition switch: OFF position (Key is inserted.)	Ignition switch: OFF position (Remove key.)
	Register key	OFF	Flashing	Flashing	Flashing
	Ignition key not registered	ON	Flashing	Flashing	Flashing

WITH INTELLIGENT KEY SYSTEM

- In ignition knob operation with Intelligent Key, it always turns on with pushing ignition knob, and always flashes with ignition knob released (ignition knob switch OFF) condition on ignition knob "LOCK" position.
- In ignition knob operation with mechanical key, it turns off on the condition that mechanical key is inserted in key cylinder, and always flashes with ignition knob released (ignition knob switch OFF) condition on mechanical key removed condition.


System Composition

The immobilizer function of the NATS consists of the following:

- Ignition key (models without Intelligent Key system)
- Mechanical key (models with Intelligent Key system)
- NATS antenna amp.
- Steering lock unit. (models with Intelligent Key system)
- BCM (models without Intelligent Key system)
- Intelligent Key unit (models with Intelligent Key system)
- Engine control module (ECM)
- Security indicator (built-in combination meter)

NOTE:

The communication between ECM and BCM/Intelligent Key unit uses the CAN communication system.



MIB0390E

ECM Re-communicating Function

Performing following procedure can automatically perform re-communication of ECM and BCM or Intelligent Key unit, but only when the ECM has been replaced with a new one (*1).

*1: New one means a virgin ECM which has never been energized on-board.

(In this step, initialization procedure by CONSULT-II is not necessary)

NOTE:

- When registering new Key IDs or replacing the ECM other than brand new, refer to CONSULT-II Operation Manual NATS.
- If multiple keys are attached to the key holder, separate them before work.
- Distinguish keys with unregistered key ID from those with registered ID.

1. Install ECM.

2. Using a registered key (*2), turn ignition switch to "ON".

*2: To perform this step, use the key that has been used before performing ECM replacement.

3. Maintain ignition switch in "ON" position for at least 5 seconds.

4. Turn ignition switch to "OFF".

5. Start engine.


If engine can be started, procedure is completed.

If engine cannot be started, refer to CONSULT-II Operation Manual NATS and initialize control unit.

NATS(NISSAN ANTI-THEFT SYSTEM)

Wiring Diagram —NATS— WITHOUT INTELLIGENT KEY SYSTEM

EIS004Q6







REFER TO THE FOLLOWING.

- (M1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M16) -FUSE BLOCK- JUNCTION BOX (J/B)
- (M81, M82) -JOINT CONNECTOR (J/C)

NATS(NISSAN ANTI-THEFT SYSTEM)

WITH INTELLIGENT KEY SYSTEM








REFER TO THE FOLLOWING.

(M16) -FUSE BLOCK-
JUNCTION BOX (J/B)
(M79), (M80), (M81), (M82)
-JOINT CONNECTOR (J/C)

NATS(NISSAN ANTI-THEFT SYSTEM)

BL-NATS-03




MKWA1799E

NATS(NISSAN ANTI-THEFT SYSTEM)


Terminals and Reference Value for Steering Lock Unit/with Intelligent Key System

EIS004Q7




Terminal number	Wire color	Signal Designation	Measuring condition		Voltage (V)
			Ignition knob position	Operation or conditions	
1	BR	Battery power supply	LOCK	—	Approx. 12
2	R	Steering wheel lock unit power supply	LOCK	—	Approx. 5
3	Y	Steering wheel lock unit communication signal	LOCK	Press ignition knob with Intelligent Key inside vehicle.	 SIIA1911J
				Other than the above	
4	R	Steering wheel lock unit ground	—	—	Approx. 0

Terminals and Reference Value for Intelligent Key Unit/with Intelligent Key System

EIS004Q8

Terminal No.	Wire color	Signal designation	Measuring condition		Voltage (V)
			Ignition knob position	Operation or conditions	
1	R	Steering wheel lock unit power supply	LOCK	—	Approx. 5
2	R	CAN communication H	—	—	—
3	W	CAN communication L	—	—	—
6	W	Ignition power supply	ON	—	Approx. 12
7	GY	Ignition knob switch	—	Press ignition knob.	Approx. 12
				Return ignition knob to LOCK position.	Approx. 0
8	W	NATS antenna amp.	—	Ignition knob OFF → ON position	Just after turning ignition switch "ON" pointer tester
9	OR	NATS antenna amp.	—	Ignition knob OFF → ON position	Should move, Just after turning ignition switch "ON" pointer tester
10	L	ACC power supply	ACC	—	Approx. 12
11	BR	Battery power supply	—	—	Approx. 12
12	B	GND	—	—	Approx. 0
13	R	Inside key antenna (+) (Luggage room)	LOCK	Any door open → all doors shut (Door switch: ON → OFF)	 SIIA1910J
14	BR	Inside key antenna (-) (Luggage room)			

NATS(NISSAN ANTI-THEFT SYSTEM)

Terminal No.	Wire color	Signal designation	Measuring condition		Voltage (V)
			Ignition knob position	Operation or conditions	
15	G	Inside key antenna (+) signal (Center console)	LOCK	Any door open → Close (Door switch: ON → OFF) Ignition knob switch: ON (press ignition knob.)	 SIIA1910J
16	R	Inside key antenna (-) signal (Center console)			
27		Key switch signal	LOCK	Insert mechanical key into ignition key cylinder.	Approx. 12
				Remove mechanical key from ignition key cylinder.	Approx. 0
30	P	Security indicator lamp	LOCK	Goes OFF → illuminates (Every 2.4 seconds)	Approx. 12 → 0
31	R	Steering wheel lock unit ground	—	—	Approx. 0
32	Y	Steering wheel lock unit communication signal	LOCK	Press ignition knob with Intelligent Key inside vehicle.	 SIIA1911J
				Other than the above	
37	BR	Outside antenna (passenger side) (+) signal	LOCK	Passenger door request switch operation (Switch: ON)	 SIIA1910J
38	Y	Outside antenna (passenger side) (-) signal			

Terminals and Reference Value for BCM/without Intelligent Key System

EIS004YO

Terminal No.	Wire color	Signal designation	Measuring condition		Voltage (V)
			Ignition knob position	Operation or conditions	
2	B	GND	—	—	Approx. 0
19	R	CAN communication H	—	—	—
24	OP	Ignition power supply	ON	—	Approx. 12
38	OR	NATS antenna amp.	—	Ignition knob OFF → ON position	Should move, Just after turning ignition switch "ON" pointer tester
39	W	CAN communication L	—	—	—
47	P	Security indicator lamp	LOCK	Goes OFF → illuminates (Every 2.4 seconds)	Approx. 12 → 0
70	B	GND	—	—	Approx. 0
74	W	Battery power supply	—	—	Approx. 12
79	Y	Battery power supply	—	—	Approx. 12

CONSULT-II


CONSULT-II INSPECTION PROCEDURE

EIS004QQ


1. Turn ignition switch OFF.
2. Insert NATS program card into CONSULT-II.

Program card : NATS (AEN02C)

3. Connect CONSULT-II and "CONSULT-II CONVERTER" to data link connector.




4. Turn ignition switch ON position.
5. Touch "START".



6. Select "K12"
7. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual, NATS.



CONSULT-II DIAGNOSTIC TEST MODE FUNCTION

CONSULT- II DIAGNOSTIC TEST MODE	Description
IMMU INITIALIZE	When replacing any of the following three components, C/U initialization is necessary. [Ignition key or mechanical key/BCM or Intelligent Key unit]
IMMU FUNCTION CHECK	Detected items (screen terms) are as shown in the chart.

NOTE:

When any initialization is performed, all ID numbers previously registered will be erased and all ignition keys or mechanical key must be registered again. The engine cannot be started with an unregistered key. The system will show "DIFFERENCE OF KEY" as a IMMU FUNCTION CHECK on the CONSULT-II screen.

A
B
C
D
E
F
G
H
BL
J
K
L
M

NATS(NISSAN ANTI-THEFT SYSTEM)

NATS IMMU FUNCTION CHECK RESULT ITEM CHART


Detected items (Screen terms)	Description
UNREGISTERED BCM*	ID is not registered in BCM
CHAIN OF IMMU-KEY	NATS IMMU cannot receive the key ID signal.
DIFFERENCE OF KEY	BCM or Intelligent Key unit can receive the key ID signal but the result of ID verification between key ID and BCM or Intelligent Key is NG
CHAIN OF IPDM-IMMU*	The communication with IPDM E/R is malfunction.
ID DISCORD IPDM-IMMU	BCM or Intelligent Key unit can receive from IPDM E/R signal but the result of ID verification is NG.
CHAIN OF METER-IMMU*	The communication with combination meter is malfunction.
ID DISCORD METER-IMMU	BCM or Intelligent Key unit can receive from combination meter ID signal but the result of ID verification is NG.
CHAIN OF EPS-IMMU*	The communication with EPS is malfunction.
ID DISCORD EPS-IMMU	BCM or Intelligent Key unit can receive from EPS ID signal but the result of ID verification is NG.
UNREGISTERED ECM	ID is not registered in ECM.
ID DISCORD ECM-IMMU	The result of ID verification between BCM and ECM is NG. System initialization is required.

*: Applied for models without Intelligent Key system.

NATS(NISSAN ANTI-THEFT SYSTEM)

Diagnosis Procedure WORK FLOW

EIS004QA



MIB0492E

Trouble Diagnosis Symptom Chart MODELS WITHOUT INTELLIGENT KEY SYSTEM

EIS004QB

NOTE:

Perform "Diagnostic Procedure 7", when "P1610" is displayed by the "SELF-DIAG RESULTS" of the ENGINE. Refer to "CONSULT-II Operation Manual NATS".

SYMPTOM	Displayed "IMMU FUNCTION CHECK" results on CONSULT-II screen.	Diagnoses service procedure	DIAGNOSTIC PROCEDURE
<ul style="list-style-type: none"> ● Security indicator lighting up* ● Engine hard to start 	UNREGISTERED BCM	Replace BCM	Refer to BL-236, "Diagnostic Procedure 1" .
	CHAIN OF IMMU-KEY	1. Check the following parts ● Open or short circuit between BCM and NATS antenna amp. ● Malfunction of key ID chip ● NATS antenna amp. 2. If the above system are "OK", replace BCM	Refer to BL-236, "Diagnostic Procedure 2" .
	DIFFERENCE OF KEY	1. Perform registration key 2. If the above system is "OK", replace BCM	Refer to BL-240, "Diagnostic Procedure 3" .
	CHAIN OF IPDM-IMMU	1. Check CAN communication system 2. If CAN communication is "OK", replace IPDM E/R	Refer to BCS-31, "CAN Communication Inspection With CONSULT-II (Self-Diagnosis)" .
	ID DISCORD IPDM-IMMU	Replace IPDM E/R	Refer to PG-52, "Removal and Installation of IPDM E/R" .
	CHAIN OF METER-IMMU	1. Check CAN communication system 2. If CAN communication is "OK", replace combination meter	Refer to BCS-31, "CAN Communication Inspection With CONSULT-II (Self-Diagnosis)" .
	ID DISCORD METER-IMMU	Replace combination meter	Refer to DI-34, "Removal and Installation for Combination Meter" .
	CHAIN OF EPS-IMMU	1. Check CAN communication system 2. If CAN communication is "OK", replace EPS	Refer to BCS-31, "CAN Communication Inspection With CONSULT-II (Self-Diagnosis)" .
	ID DISCORD EPS-IMMU	Replace EPS	Refer to PS-7, "STEERING COLUMN" .
	UNREGISTERED ECM	Replace ECM	Refer to BL-240, "Diagnostic Procedure 4" .
	ID DISCORD ECM-IMMU	Replace ECM	Refer to BL-241, "Diagnostic Procedure 5" .

*: When NATS detects trouble, the security indicator lights up while ignition key is in the "ON" position.

NATS(NISSAN ANTI-THEFT SYSTEM)

MODELS WITH INTELLIGENT KEY SYSTEM

NOTE:

Perform "Diagnostic Procedure 7", when "P1610" is displayed by the "SELF-DIAG RESULTS" of the ENGINE. Refer to "CONSULT-II Operation Manual NATS".

SYMPTOM	Displayed "IMMU FUNCTION CHECK" results on CONSULT-II screen.	Diagnoses service procedure	DIAGNOSTIC PROCEDURE
<ul style="list-style-type: none"> ● Security indicator lighting up* ● Engine hard to start 	CHAIN OF IMMU-KEY	1. Check the following parts <ul style="list-style-type: none"> ● Open or short circuit between BCM and NATS antenna amp. ● Malfunction of key ID chip ● NATS antenna amp. 	Refer to BL-236, "Diagnostic Procedure 2" .
		2. If the above system are "OK", replace Intelligent Key unit	Refer to BL-202, "Removal and Installation of Intelligent key unit" .
	DIFFERENCE OF KEY	1. Perform registration key	Refer to BL-240, "Diagnostic Procedure 3" .
		2. If the above system is "OK", replace Intelligent Key unit	Refer to BL-202, "Removal and Installation of Intelligent key unit" .
	ID DISCORD IPDM-IMMU	1. Check CAN communication system	Refer to BL-191, "Check CAN Communication System" .
		2. If CAN communication system is "OK", replace IPDM E/R	Refer to PG-52, "Removal and Installation of IPDM E/R" .
	ID DISCORD METER-IMMU	1. Check CAN communication system	Refer to BL-191, "Check CAN Communication System" .
		2. If CAN communication system is "OK", replace combination meter	Refer to DI-34, "Removal and Installation for Combination Meter" .
	ID DISCORD EPS-IMMU	1. Check CAN communication system	Refer to BL-191, "Check CAN Communication System" .
		2. If CAN communication system is "OK", replace EPS	Refer to PS-7, "STEERING COLUMN" .
	ID DISCORD ECM-IMMU	Replace ECM	Refer to BL-241, "Diagnostic Procedure 5" .

*: When NATS detects trouble, the security indicator lights up while mechanical key is inserted.

Security Indicator Inspection

EIS004QC

SYMPTOM	SYSTEM (Malfunctioning part or mode)	DIAGNOSTIC PROCEDURE
Security indicator does not operate*	Security indicator	Refer to BL-241, "Diagnostic Procedure 6" .
	Open circuit between Fuse and NATS IMMU (BCM or Intelligent Key unit)	
	Continuation of initialization mode	
	BCM (models without Intelligent Key system)	
	Intelligent Key unit (models with Intelligent Key system)	

*: CONSULT-II "IMMU FUNCTION CHECK" results display screen "no malfunction is detected".

Diagnostic Procedure 1

EIS004QE

IMMU FUNCTION CHECK results:

“UNREGISTERD BCM” displayed on CONSULT-II screen

1. CONFIRM IMMU FUNCTION CHECK

Confirm “IMMU FUNCTION CHECK” results “UNREGISTERD BCM” displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as above?

YES >> ● BCM is malfunctioning.

- Replace BCM.
- Perform initialization with CONSULT-II.
 - For initialization, refer to “CONSULT-II Operation Manual NATS”.

NO >> GO TO [BL-234, "Trouble Diagnosis Symptom Chart"](#) .

Diagnostic Procedure 2

EIS004QF

MODELS WITHOUT INTELLIGENT KEY SYSTEM

IMMU FUNCTION CHECK results:

“CHAIN OF IMMU-KEY” displayed on CONSULT-II screen

1. CONFIRM IMMU FUNCTION CHECK

Confirm “IMMU FUNCTION CHECK” results “CHAIN OF IMMU-KEY” displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as above?

Yes >> GO TO 2.

No >> GO TO [BL-234, "Trouble Diagnosis Symptom Chart"](#) .

2. CHECK NATS ANTENNA AMP. INSTALLATION

Check NATS antenna amp. installation. Refer to [BL-244, "Removal and Installation NATS Antenna Amp."](#) .

OK or NG

OK >> GO TO 3.

NG >> Reinstall NATS antenna amp. correctly.

3. CHECK IGNITION KEY ID CHIP

Start engine with another registered ignition key.

Does the engine start?

Yes >> ● Ignition key ID chip is malfunctioning.

- Replace the ignition key.
- Perform initialization with CONSULT-II.
 - For initialization, refer to “CONSULT-II Operation Manual NATS”.

No >> GO TO 4.

NATS(NISSAN ANTI-THEFT SYSTEM)

4. CHECK POWER SUPPLY FOR NATS ANTENNA AMP.


1. Turn ignition switch "ON".
2. Check voltage between NATS antenna amp. connector M36 terminal 3 (LG) and ground with CONSULT-II or tester.

Battery voltage should exist.

OK or NG

OK >> GO TO 5.

NG >> Check harness for open or short between NATS antenna amp. and fuse.



5. CHECK NATS ANTENNA AMP. SIGNAL LINE

Check voltage between NATS antenna amp. connector M36 terminal 1 (OR) and ground with analogue tester.

Before turning ignition switch "ON"

Voltage: 0V

Just after turning ignition switch "ON"

: Pointer of tester should move.

OK or NG


OK >> GO TO 6.

NG >> ● Check harness for open or short between NATS antenna amp. and BCM.

NOTE:

If harness is OK, replace new* BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS".

*: New one means virgin control unit that has never been energized on-board.



6. CHECK NATS ANTENNA AMP. GROUND LINE CIRCUIT

1. Turn ignition switch "OFF".
2. Check continuity between NATS antenna amp. connector M36 terminal 2 (B) and ground.

Continuity should exist.

OK or NG


OK >> NATS antenna amp. is malfunctioning.

NG >> ● Check harness for open or short between NATS antenna amp. and ground.

NOTE:

If harness is OK, replace new* BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS".

*: New one means virgin control unit that has never been energized on-board.



NATS(NISSAN ANTI-THEFT SYSTEM)

MODELS WITH INTELLIGENT KEY SYSTEM

IMMU FUNCTION CHECK results:

“CHAIN OF IMMU-KEY” displayed on CONSULT-II screen

1. CONFIRM IMMU FUNCTION CHECK

Confirm “IMMU FUNCTION CHECK” results “CHAIN OF IMMU-KEY” displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as above?

Yes >> GO TO 2.

No >> GO TO [BL-234, "Trouble Diagnosis Symptom Chart"](#).

2. CHECK NATS ANTENNA AMP. INSTALLATION

Check NATS antenna amp. installation. Refer to [BL-244, "Removal and Installation NATS Antenna Amp."](#).

OK or NG

OK >> GO TO 3.

NG >> Reinstall NATS antenna amp. correctly.

3. CHECK MECHANICAL KEY ID CHIP

Start engine with another registered mechanical key.

Does the engine start?

Yes >> ● Mechanical key ID chip is malfunctioning.

● Replace the mechanical key.

● Perform initialization with CONSULT-II.

For initialization, refer to “CONSULT-II Operation Manual NATS”.

No >> GO TO 4.

4. CHECK POWER SUPPLY FOR NATS ANTENNA AMP.

1. Turn ignition switch “ON”.


2. Check voltage between NATS antenna amp. connector M35 terminal 4 (LG) and ground with CONSULT-II or tester.

Battery voltage should exist.

OK or NG

OK >> GO TO 5.

NG >> Check harness for open or short between NATS antenna amp. and fuse.



NATS(NISSAN ANTI-THEFT SYSTEM)

5. CHECK NATS ANTENNA AMP. SIGNAL LINE- 1

Check voltage between NATS antenna amp. connector M35 terminal 2 (W) and ground with analogue tester.

Before inserting mechanical key in ignition knob

Voltage: 0V

Just after inserting mechanical key in ignition knob

: Pointer of tester should move.

OK or NG


OK >> GO TO 6.

NG >> ● Check harness for open or short between NATS antenna amp. and Intelligent Key unit.

NOTE:

If harness is OK, replace new* Intelligent Key unit, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS".

*: New one means virgin control unit that has never been energized on-board.



6. CHECK NATS ANTENNA AMP. SIGNAL LINE- 2

Check voltage between NATS antenna amp. connector M35 terminal 3 (OR) and ground with analogue tester.

Before inserting mechanical key in ignition knob

Voltage: 0V

Just after inserting mechanical key in ignition knob

: Pointer of tester should move.

OK or NG


OK >> GO TO 7.

NG >> ● Check harness for open or short between NATS antenna amp. and Intelligent Key unit.

NOTE:

If harness is OK, replace new* Intelligent Key unit, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS".

*: New one means virgin control unit that has never been energized on-board.



7. CHECK NATS ANTENNA AMP. GROUND LINE CIRCUIT

1. Turn ignition switch "OFF".

2. Check continuity between NATS antenna amp. connector M35 terminal 1 (B) and ground.

Continuity should exist.

OK or NG


OK >> NATS antenna amp. is malfunctioning.

NG >> ● Check harness for open or short between NATS antenna amp. and ground.

NOTE:

If harness is OK, replace new* Intelligent Key unit, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS".

*: New one means virgin control unit that has never been energized on-board.



Diagnostic Procedure 3

EIS004QG

IMMU FUNCTION CHECK results:

“DIFFERENCE OF KEY” displayed on CONSULT-II screen

1. CONFIRM IMMU FUNCTION CHECK

Confirm “IMMU FUNCTION CHECK” results “DIFFERENCE OF KEY” displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as above?

Yes >> GO TO 2.

No >> GO TO [BL-234, "Trouble Diagnosis Symptom Chart"](#) .

2. PERFORM INITIALIZATION WITH CONSULT-II

Perform initialization with CONSULT-II. Re-register all NATS ignition key IDs.

For initialization and registration of NATS ignition key IDs, refer to “CONSULT-II Operation Manual NATS”.

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows message on the screen.

Can the system be initialized and can the engine be started with re-registered NATS ignition key?

Yes >> ● Ignition key ID was unregistered.

No >> ● BCM is malfunctioning. (models without Intelligent Key system)

● Replace new* BCM.


● Intelligent Key unit is malfunctioning. (models with Intelligent Key system)

● Replace new* Intelligent Key unit.

● Perform initialization with CONSULT-II.

● For initialization, refer to “CONSULT-II Operation Manual NATS”.

*: New one means virgin control unit that has never been energized on-board.



SEL297W

Diagnostic Procedure 4

EIS0056B

IMMU FUNCTION CHECK results:

“UNREGISTERD ECM” displayed on CONSULT-II screen

1. CONFIRM IMMU FUNCTION CHECK

Confirm “IMMU FUNCTION CHECK” results “UNREGISTERD ECM” displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as above?

YES >> ● ECM is malfunctioning.

● Replace ECM.

● Perform initialization or re-communicating function.

– For initialization, refer to [BL-225, "ECM Re-communicating Function"](#) .

NO >> GO TO [BL-234, "Trouble Diagnosis Symptom Chart"](#) .

Diagnostic Procedure 5

EIS0056C

IMMU FUNCTION CHECK results:

“ID DISCORD ECM-IMMU” displayed on CONSULT-II screen

1. CONFIRM IMMU FUNCTION CHECK

Confirm “IMMU FUNCTION CHECK” results “UNREGISTERD ECM” displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as above?

YES >> ● ECM is malfunctioning.

- Replace ECM.
- Perform initialization or re-communicating function.
 - For initialization, refer to “CONSULT-II Operation Manual NATS”.

NO >> GO TO [BL-234, "Trouble Diagnosis Symptom Chart"](#).

Diagnostic Procedure 6

EIS0056G

MODELS WITHOUT INTELLIGENT KEY SYSTEM

“Security indicator does not light up”

1. CHECK FUSE

Check 10A fuse [No. 8, located in the fuse block (J/B)]

OK or NG

OK >> GO TO 2.

NG >> Replace fuse.

2. CHECK SECURITY INDICATOR LAMP

1. Install 10A fuse.
2. Start engine and turn ignition switch OFF.
3. Check the security indicator lamp lights up.

Security indicator lamp should light up.

OK or NG

OK >> Inspection END.

NG >> GO TO 3.

3. CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT


1. Disconnect combination meter (security indicator lamp) connector.
2. Check voltage between security indicator lamp connector M22 terminal 27 (LG) and ground.

Battery voltage should exist.

OK or NG

OK >> GO TO 4.

NG >> Check harness for open or short between fuse and security indicator lamp.



4. CHECK BCM FUNCTION

1. Connect combination meter (security indicator lamp) connector.
2. Disconnect BCM connector M3.
3. Check voltage between BCM connector M49 terminal 47 (P) and ground.

Battery voltage should exist.

OK or NG

OK >> BCM is malfunctioning.

- Replace BCM.
- Perform initialization with CONSULT-II.
- For initialization, refer to "CONSULT-II Operation Manual NATS".

NG >> Check the following.

- Harness for open or short between security indicator lamp and BCM.
- Indicator lamp condition

MODELS WITH INTELLIGENT KEY SYSTEM

"Security indicator does not light up"

1. CHECK FUSE

Check 10A fuse [No. 8, located in the fuse block (J/B)]

OK or NG

OK >> GO TO 2.

NG >> Replace fuse.

2. CHECK SECURITY INDICATOR LAMP

1. Install 10A fuse.
2. Start engine and turn ignition knob OFF position.
3. Check the security indicator lamp lights up.

Security indicator lamp should light up.

OK or NG

OK >> Inspection END.

NG >> GO TO 3.

3. CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT



1. Disconnect combination meter (security indicator lamp) connector.
2. Check voltage between security indicator lamp connector M22 terminal 27 (LG) and ground.

Battery voltage should exist.

OK or NG

OK >> GO TO 4.

NG >> Check harness for open or short between fuse and security indicator lamp.



4. CHECK INTELLIGENT KEY UNIT FUNCTION

1. Connect combination meter (security indicator lamp) connector.
2. Disconnect Intelligent Key unit connector M51.
3. Check voltage between Intelligent Key unit connector M51 terminal 30 (P) and ground.

Battery voltage should exist.


OK or NG

OK >> Intelligent Key is malfunctioning.

- Replace Intelligent Key unit.
- Perform initialization with CONSULT-II.
- For initialization, refer to "CONSULT-II Operation Manual NATS".

NG >> Check the following.

- Harness for open or short between security indicator lamp and Intelligent Key unit.
- Indicator lamp condition



Diagnostic Procedure 7

EIS0056H

IMMU FUNCTION CHECK results:

"P1610" displayed on CONSULT-II screen

1. CONFIRM IMMU FUNCTION CHECK

Confirm "IMMU FUNCTION CHECK" results "P1610" (LOCK MODE) is displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as above?

Yes >> GO TO 2.

No >> GO TO [BL-233, "WORK FLOW"](#) .

2. ESCAPE FROM LOCK MODE

1. Turn ignition switch OFF.
2. Turn ignition switch ON with registered key. (Do not start engine.) Wait 5 seconds.
3. Return the key to OFF position. Wait 5 seconds.
4. Repeat steps 2 and 3 twice (total of three cycles).
5. Start the engine.

Does engine start?

Yes >> System is OK (Now system is escaped from "LOCK MODE").

No >> Perform "IMMU FUNCTION CHECK", and repair the diagnosis result on the display.

A
B
C
D
E
F
G
H
BL
J
K
L
M

Removal and Installation NATS Antenna Amp.


EIS004QK

REMOVAL

CAUTION:

Before servicing SRS, turn ignition switch OFF, disconnect both battery cables and wait at least 3 minutes.

1. Remove the spiral cable. Refer to [SRS-38, "Removal and Installation"](#) .
2. Disconnect the NATS antenna amp. connect, remove the screw and NATS antenna amp.



INSTALLATION

Install in the reverse order of removal.